Maintenance

7 Maintenance

Target groups O, E, M, C



Definition of the target groups:

Operating Instructions General,
 Chapter Introduction/target groups.



Observe the following information:

- Operating Instructions General,
 Chapter Safety,
 Chapter Maintenance,
- Subsuppliers' Operating Instructions,
- Electrical Equipment Operating Instructions.

7.1 Maintenance schedule

Area	Inspection	Action	ОС	TI
General	Fastening	■ Fasten	Р	Υ
	Damage	- Replace	Р	М
	(condition)	■ Repair		
	- Function	Repair	N	S
	 Unusual noises 	Eliminate the cause	N	М
	• Wear	Replace	Р	М
		- Repair		
	Contamination	- Clean	Р	М
Cylinder	Function	Replace	N	S
		- Repair		
		Set speed		
	Bearing assembly	■ Fasten	Р	Υ
		■ Replace		
		Repair		
	- Seal	Replace	Р	W
		Repair		



Dry-strip system

Maintenance

Area	Inspection	Action	ОС	TI
Fluid line,	Leaks	- Replace	Р	М
fluid connection		 Repair 		
	 Volumetric flow rate 	Set volumetric flow rate	Z	М
Nozzle	Spraying pattern	Replace nozzle	Z	W
		Clean nozzle		
		Set volumetric flow rate		
		Fasten nozzle		
Suction forces	 Passage 	Replace	Р	W
	 Cleanliness 	■ Repair		

Operating condition (OC)		Time interval (TI)		
N	Normal operation (production)	S	every shift (8 hours)	
Р	Stop (maintenance, troubleshooting)	W	every week	
Z	Enabling mode	M	every month	
		Υ	every year	

NOTICE

In the first three months after commissioning, the pipework must be inspected every two weeks. This allows leaks to be detected at an early stage.