

7 Maintenance

Target groups O, E, M, C



Definition of the target groups:

Operating Instructions General,
 Chapter Introduction/target groups.



Observe the following information:

- Operating Instructions General,
 Chapter Safety,
 Chapter Maintenance,
- Subsuppliers' Operating Instructions,
- Electrical Equipment Operating Instructions.

7.1 Maintenance schedule

Area	Inspection	Action	ОС	TI
General	 Fastening 	Fasten	Р	Υ
	Damage	- Replace	Р	М
	(condition)	■ Repair		
	Function	Repair	N	S
	 Unusual noises 	Eliminate the cause	N	М
	• Wear	Replace	Р	М
		■ Repair		
	Contamination	■ Clean	Р	М
Rolls (deflector roll)	Damage	- Replace	Р	ЗМ
	- Corrosion	■ Repair		
	• Wear			
Cylinder	Function	- Replace	N	S
		 Repair 		
		 Set speed 		
	 Bearing assembly 	Fasten	Р	Υ
		Replace		



Pivoting table

Maintenance

		■ Repair		
	■ Sealing	■ Replace	Р	М
		 Repair 		
Fluid line,	• Leaks	■ Replace	Р	М
fluid connection		Repair		
	Volumetric flow rate	Set volumetric flow rate	Ν	М

Operating condition (OC)

N Normal operation (production)

P Stop (maintenance, troubleshooting)

Time interval (TI)

S every shift (8 hours)

**)M every month

**)Y every year

**) Intervals combined with numbers signify for example: 3M= every three months

NOTICE

In the first three months after commissioning, the pipework must be inspected every two weeks. This allows leaks to be detected at an early stage.

7.2 Lubrication instructions



For supplementary information on lubrication refer to:

- Operating Instructions General
 Chapter Maintenance/operating materials and auxiliaries and
 Chapter Maintenance/lubricants and specifications,
- Subsuppliers' Operating Instructions.

Designation	Material number	
Lubrication chart	14333065	

AISHA-CCM Version: A - 2018-09-28 11