

Maintenance

7 Maintenance

Target groups O, E, M, C



Definition of the target groups:

Operating Instructions General,
 Chapter Introduction/target groups.



Observe the following information:

- Operating Instructions General,
 Chapter Safety,
 Chapter Maintenance,
- Subsuppliers' Operating Instructions,
- Electrical Equipment Operating Instructions.

7.1 Maintenance schedule

Area	Inspection	Action	ОС	TI
General	Fastening	■ Fasten	Р	Υ
	- Damage	- Replace	Р	М
	(condition)	■ Repair		
	- Function	Repair	N	S
	 Unusual noises 	Eliminate the cause	N	М
	• Wear	Replace	Р	М
		- Repair		
	Contamination	- Clean	Р	М
Swivel drive	Function	- Replace	Р	6M
		Repair		
	 Lubrication system 	Top up	Р	М
	• Wear	 Adjust 		Υ
		- Adapt		
Bearing assembly	Function	Adjust clearance	Р	6M
		■ Replace		
	Centralized	Top up	Р	W



Snubber roll

Maintenance

Area	Inspection	Action	ОС	TI
	lubrication	 Adjust 		
		 Adapt 		
	• Wear	Replace	Р	Υ
		Repair		
Cylinder	Function	Replace	N	S
		Repair		
		Set speed		
	Bearing assembly	Fasten	Р	Υ
		Replace		
		Repair		
	- Seal	Replace	Р	3M
		Repair		
Fluid line,	• Leaks	Replace	Р	3M
fluid connection		Repair		
	Volumetric flow rate	Set volumetric flow rate	N	М

Operating condition (OC)

N Normal operation (production)

P Stop (maintenance, troubleshooting)

Time interval (TI)

S every shift (8 hours)

**)W every week

**)M every month

**)Y every year

**) Intervals combined with numbers denote for example:

3M= every three months

NOTICE

In the first three months after commissioning, the pipework must be inspected every two weeks. This allows leaks to be detected at an early stage.