2 System release and shut down behaviour

Failure type	Failure description	DTC	ABS	MTC	CC	CAN	ABS W/L	MTC W/L	Reversible
ECU[1]	Control unit failure	0x502100	×	rd[4]	×	○[2]	(●)	(●)	No
VR	Valve Relay Fault	0x501900	×	rd	×[6]	○	●	●	No[8]
Valves EV[1]	Inlet valve failure	F: 0x505400 R: 0x505200	×	rd	×[6]	○	●	●	No
Valves AV[1]	Outlet valve failure	F: 0x504900 R: 0x504800	×	rd	×[6]	○	●	●	No
UZ_Over[2]	UZ supply Voltage fault (Over-Voltage)	0x505900	×	rd[4]	×	○	●	●	Yes
UZ_Under[2]	UZ supply Voltage fault (Under-voltage)	0x505800	×[5]	rd[4]	×	○	●	●	Yes[7]
NetUZ Over	Net over voltage	0xE93100	○	rd	×	○	-	●	Yes
NetUZ Under	Net under voltage	0xE93000	○	rd	×	○	-	●	Yes
RFP/RFP_HW	Pump Motor Failure	0x501500	nnc	×	×	○	●	●	No[3]
RFP/RFP_Supply	Pump Motor Supply Failure	0x501600	nnc	×	×	○	●	●	Yes
WSS_ohmic	WSS ohmic failure	F: 0x503300 R: 0x503100	×	rd	×	○	●	●	No
WSS_ plausibility	WSS plausibility failure	F: 0x503400 R: 0x503200	×	rd	×	○	●	●	No
	WSS short-term signal disturbance (Suspicious)	F: 0x503600 R: 0x503700	×	rd	×	○	●	●	Yes
WSS_GENERIC[1]	WSS generic failure	0x502400	×	rd	×	○	●	●	No
CAN_BUSOFF[1]	CAN Bus Off Failure	0xE92200	○	×	×	×	(-)	●	No
CAN_GENERIC[1]	CAN Controller generic failure	0xE92100	○	×	×	×	(-)	●	No
CAN frame	Engine Frame failure (IDs 0x170, 0x150, 0x151, 0x352)	0xE92400	○	×	×	○	-	●	No
	Engine Frame failure (ID 0x351)		○	○	○	○	-	●	Yes
	Cluster message failure (ID 0x120)	0xE92300	○	○	×	○	-	●	No

© Bosch Corporation, reserves all rights in the event of industrial property.
We reserve all rights of disposal such as copying and passing to third parties

Failure type	Failure description	DTC	ABS	MTC	CC	CAN	ABS W/L	MTC W/L	Reversible
	Cluster message failure (ID 0x125)	0xE92600	○	○	○	○	-	-	Yes
	Cluster message failure (ID 0x550)								No
VAR Coding Error	Variant OutOfRange Variant Not Configured	0x520000	×	×	×	○	●	●	No
VAR Coding Error	Variant Read error	0x510000	×	×	×	○	●	●	No
CAN Engine Signal	CAN Engine signal	0xE92500	○	rd	×	×	-	●	No
CAN Gear Signal	CAN Gear signal failure	0xE93200	○	rp[9]	×	×	-	★	No
CC Plausibility failure	CC AxRange / CC Plausibility failure	0x530100	○	○	×	○	-	-	No

1 : System is passive
2 : Cannot output any data for some cases
3 : Chapter 7.10 Overheat Protection is “Yes”
4 : As long as ECU is not reset, the ramp down can be continued.
5: Only Chapter 7.8 UBMR Line monitor behavior is “x” (Shutdown immediately). (Other monitors are “nnc”.)
6: Off_SisOn ,Some functions are available
7: Not reversible when detected failure by supply voltage line test (Chapter.6.2)
8: Chapter 4.3 Overheat Protection is “Yes”
9: Some functions are restricted

Table 1: System release table

DRAFT

© Bosch Corporation, reserves all rights in the event of industrial property.
We reserve all rights of disposal such as copying and passing to third parties

Description of degraded modes and functionality's

Mode	Description
○	Functionality on
×	Shutdown immediately
nnc	No new control (shut off at end of control)
rd	Ramp down/off control

Reversible	Description
Yes	Yes: Reversible without Re-IGN ON
No	No: Irreversible without Re-IGN ON

Warning Lamp	Description
—	OFF
●	ON immediately
★	Blink
（ ）	Unknown

Table 2: Description of degraded modes and functionality's

DRAFT

© Bosch Corporation, reserves all rights in the event of industrial property.
We reserve all rights of disposal such as copying and passing to third parties