



# ST67W611 Wi-Fi 6 + Bluetooth® LE + Thread

Santa Clara Wireless Team

## Prerequisites

#### PLEASE DOWNLOAD ALL THE TOOL LISTED BELOW


- X\_CUBE\_ST67W61\_V1.0.0 (To be installed under C drive)
- STM32CubeIDE v1.16.1+
- <u>STM32CubeProgrammer v2.18.0+</u> To be installed in default directory (C:\Program Files\STMicroelectronics\STM32Cube\STM32CubeProgrammer)
- STM32CubeMX v6.15.0
- HyperTerminal TeraTerm v.5.4.0
- ST BLE Toolbox (To be downloaded on mobile)




# Installing X-CUBE-ST67W61

#### Open STM32CubeMX with admin rights

- 1. Go to "Install/Remove" software packages
- Under STMicroelectronics tab
- Install the X-CUBE-ST67W61








## X-CUBE-FREERTOS

Download latest X-CUBE-FREERTOS






### **STM32U5**





## STM32G0



Download latest STM32G0



# Our technology starts with You





ST logo is a trademark or a registered trademark of STMicroelectronics International NV or its affiliates in the EU and/or other countries. For additional information about ST trademarks, please refer to <a href="https://www.st.com/trademarks">www.st.com/trademarks</a>.
All other product or service names are the property of their respective owners.

