

VANTARA PETROCHEM - UNIT 3

STANDARD OPERATING PROCEDURE

CENTRIFUGAL PUMP STARTUP

Document Number:	SOP-PUMP-001
Revision:	Rev 3
Effective Date:	2023-03-01
Applies To:	P-101A, P-101B, and similar centrifugal pumps
Author:	Priya Sharma, Rotating Equipment

STARTUP SEQUENCE

Pre-Start Checks:

1. Verify LOTO removed and equipment is cleared for operation
2. Check lubricant oil level in bearing housing - must be at center of sight glass
3. Verify suction and discharge valves are in correct position
4. Ensure minimum flow recirculation valve is functional
5. Check seal flush system is operational

Startup:

1. Open suction valve fully
2. Partially open discharge valve (to minimum flow position)
3. Start pump motor
4. Verify pump comes up to speed normally
5. Check for unusual noise or vibration
6. Slowly open discharge valve to operating position
7. Monitor discharge pressure and flow
8. Check bearing temperature (should stabilize within 30 minutes)
9. Verify no leakage from mechanical seal

Post-Start Monitoring:

- First hour: Check every 15 minutes
- After stabilization: Hourly checks per operator rounds

IMPORTANT - Lubricant Requirements:

Use ONLY approved lubricants as listed in equipment records. For P-101A/B, the approved lubricant is VantaLube Premium 320. Do not substitute without engineering approval and Management of Change review.