Pump Seal Replacement

Standard operating procedure for the maintenance team.

1. Procedure

#	Step	Instructions	Done when
1	Isolate	Switch off the pump at the local panel. Lock the isolator and attach your personal tag to it.	Isolator locked and tagged
2	Drain	Open the drain valve slowly and collect the fluid in an approved container. Record the volume drained.	Casing empty, volume recorded
3	Inspect	Check the seal faces, the bearings and the coupling for wear or damage. Photograph anything unusual.	Inspection sheet completed
4	Replace	Fit the new seal kit to the manufacturer torque settings. Never reuse an old gasket.	New seal fitted and torqued
5	Restore	Remove your tag and lock, close the drain valve and restart the pump. Watch for leaks for ten minutes.	Pump running without leaks