SOFTWARE FAMILY: 52 IC208CX

SOFTWARE RELEASE: 7.5

PARAMETERS DESCRIPTOR(E2): 7.5

Revision:
0.4 2019/06/05

GENERAL RULES:

CRC calculation: standard modbus RTU CRC

Baudrate	9600
Data Lenght	8
Parity	none
Stop bit	1
Minimum TimeOut	60ms

Reading function code:0x 03
Writing function code: 0x 10

ANALOG INPUT

Reading function code: 0x 03

The data received must be added to "Offset" and then multiplied by "Gain".
The result can have "Dec" decimal digit

Example:

sent	ADDR+FUNCTION CODE + 01000001+CRC		
received	ADDR+030202B9+CRC		
where			
	0x02B9 = 697(dec)	(697 + 0)* 0.1 = 69.7 °C	Evapor. (Pb1)
sent	ADDR+FUNCTION CODE + 01020001+CRC		
received	ADDR+03020060+CRC		
where			
	0x0060 = 96(dec)	(96 + 0)* 1 = 96 °F	Outlet °F(Pb2)

	HEX	HEX	HEX	HEX							
Name	***Read Register***	***Num. Elements Read***	***Write Register***	***Num. Elements Write***	***Gain***	***Dec***	***Offset***	***Unit***	***Byte ORDER***	***Format***	***R / W***
Probe 1	0100	0001	\	\	0,1	1	0	°C	H-L	16 bit Signed	R
Probe 2	0102	0001	\	\	0,1	1	0	°C	H-L	16 bit Signed	R
Probe 3	0104	0001	\	\	0,1	1	0	°C / bar	H-L	16 bit Signed	R
Probe 4	0106	0001	\	\	0,1	1	0	°C / bar	H-L	16 bit Signed	R
Probe 5	0108	0001	\	\	0,1	1	0	°C	H-L	16 bit Signed	R
Probe 6	010A	0001	\	\	0,1	1	0	°C	H-L	16 bit Signed	R
Remote Probe 1	010C	0001	\	\	0,1	1	0	°C	H-L	16 bit Signed	R
Remote Probe 2	010E	0001	\	\	0,1	1	0	°C	H-L	16 bit Signed	R
I/O Exp. Probe 1	0110	0001	\	\	0,1	1	0	°C	H-L	16 bit Signed	R
I/O Exp. Probe 2	0112	0001	\	\	0,1	1	0	°C	H-L	16 bit Signed	R
I/O Exp. Probe 3	0114	0001	\	\	0,1	1	0	°C / bar	H-L	16 bit Signed	R
I/O Exp. Probe 4	0116	0001	\	\	0,1	1	0	°C / bar	H-L	16 bit Signed	R
I/O Exp. Probe 5	0118	0001	\	\	0,1	1	0	°C / bar	H-L	16 bit Signed	R
I/O Exp. Probe 6	011A	0001	\	\	0,1	1	0	°C	H-L	16 bit Signed	R
I/O Exp. Probe 7	011C	0001	\	\	0,1	1	0	°C	H-L	16 bit Signed	R
I/O Exp. Probe 8	011E	0001	\	\	0,1	1	0	°C	H-L	16 bit Signed	R
Probe 1-F	0100	0001	\	\	1	0	0	°F	H-L	16 bit Signed	R
Probe 2-F	0102	0001	\	\	1	0	0	°F	H-L	16 bit Signed	R
Probe 3-F	0104	0001	\	\	1	0	0	°F/ psi	H-L	16 bit Signed	R
Probe 4-F	0106	0001	\	\	1	0	0	°F/ psi	H-L	16 bit Signed	R
Probe 5-F	0108	0001	\	\	1	0	0	°F	H-L	16 bit Signed	R
Probe 6-F	010A	0001	\	\	1	0	0	°F	H-L	16 bit Signed	R
Remote Probe 1-F	010C	0001	\	\	1	0	0	°F	H-L	16 bit Signed	R
Remote Probe 2-F	010E	0001	\	\	1	0	0	°F	H-L	16 bit Signed	R
I/O Exp. Probe 1-F	0110	0001	\	\	1	0	0	°F	H-L	16 bit Signed	R
I/O Exp. Probe 2-F	0112	0001	\	\	1	0	0	°F	H-L	16 bit Signed	R
I/O Exp. Probe 3-F	0114	0001	\	\	1	0	0	°F/ psi	H-L	16 bit Signed	R
I/O Exp. Probe 4-F	0116	0001	\	\	1	0	0	°F/ psi	H-L	16 bit Signed	R
I/O Exp. Probe 5-F	0118	0001	\	\	1	0	0	°F/ psi	H-L	16 bit Signed	R
I/O Exp. Probe 6-F	011A	0001	\	\	1	0	0	°F	H-L	16 bit Signed	R
I/O Exp. Probe 7-F	011C	0001	\	\	1	0	0	°F	H-L	16 bit Signed	R
I/O Exp. Probe 8-F	011E	0001	\	\	1	0	0	°F	H-L	16 bit Signed	R
Analog output 1	0900	0001	\	\	1	0	0	%	H-L	16 bit Unsigned	R
Analog output 2	0901	0001	\	\	1	0	0	%	H-L	16 bit Unsigned	R
Analog output 3	0902	0001	\	\	1	0	0	%	H-L	16 bit Unsigned	R
Analog output 4	0903	0001	\	\	1	0	0	%	H-L	16 bit Unsigned	R
Analog output 5 (output 1 expansion)	0904	0001	\	\	1	0	0	%	H-L	16 bit Unsigned	R
Analog output 6 (output 1 expansion)	0905	0001	\	\	1	0	0	%	H-L	16 bit Unsigned	R
Analog output 7 (output 1 expansion)	0906	0001	\	\	1	0	0	%	H-L	16 bit Unsigned	R

SET POINT

Reading function code: 0x 03
Writing function code: 0x 10

The data received must be added to "Offset" and then multiplied by "Gain".
The result can have "Dec" decimal digit

Example:

sent	ADDR+0303000001+CRC		
received	ADDR+030202A6+CRC		
where			
	0x02A6 = 678(dec)	(678 + 0)* 0.1 = 67.8 °C	Chiller Set read value
sent	ADDR+1003000001+02+01E7+CRC		
received	ADDR+1003000001+CRC		
where			
	0x01E7 = 487(dec)	(487 + 0)* 0.1 = 48.7 °C	Chiller Set written value

	HEX	HEX	HEX	HEX							
Name	*Read Register*	*Num. Elements Read*	*Write Register*	*Num. Elements Write*	*Gain*	*Dec*	*Offset*	*Unit*	*Byte ORDER*	*Format*	*R / W*
Chiller Set	0601	0001	0601	0001	0,1	1	0	°C	H-L	16 bit Signed	R/W
Heat Pump Set	0602	0001	0602	0001	0,1	1	0	°C	H-L	16 bit Signed	R/W
Chiller Set °F	0601	0001	0601	0001	1	0	0	°F	H-L	16 bit Signed	R/W
Heat P. Set °F	0602	0001	0602	0001	1	0	0	°F	H-L	16 bit Signed	R/W

DIGITAL INPUT

Reading function code: 0x 03

The data received worked with "Mask", if the result equal to "Value"
That present the variable activate, otherwise the variable is inactive

Example:

sent	ADDR+0302030001+CRC		
received	ADDR+03020005+CRC		
	where		
		0x0005 And 0x0001= 0x0001	"Energy Saving" is active
		0x0005 And 0x0004= 0x0004	"Low Pressure Switch" is active
		0x0005 And 0x0008= 0x0000	"High Pressure Switch" is inactive

	HEX	HEX	HEX	HEX							
Name	*Read Register*	*Num. Elements Read*	*Mask*	*Value*							*R / W*
Remote PDC	0200	0001	0100	0100							R
Remote Off	0200	0001	0200	0200							R
Remote Chiller	0200	0001	0400	0400							R
Flow Switch	0200	0001	0800	0800							R
Flow Switch Hot Side	0200	0001	1000	1000							R
Anti-freeze circ.1	0200	0001	2000	2000							R
Anti-freeze circ.2	0200	0001	4000	4000							R
High Pressure circ.1	0200	0001	8000	8000							R
High Pressure circ.2	0200	0001	0001	0001							R
Low Pressure circ.1	0200	0001	0002	0002							R
Low Pressure circ.2	0200	0001	0004	0004							R
High Pressure comp.1	0200	0001	0008	0008							R
High Pressure comp.2	0200	0001	0010	0010							R
High Pressure comp.3	0200	0001	0020	0020							R
High Pressure comp.4	0200	0001	0040	0040							R
Thermal compressor 1	0201	0001	0200	0200							R
Thermal compressor 2	0201	0001	0400	0400							R
Thermal compressor 3	0201	0001	0800	0800							R
Thermal compressor 4	0201	0001	1000	1000							R
Thermal condenser fan circ.1	0201	0001	8000	8000							R
Thermal condenser fan circ.2	0201	0001	0001	0001							R
Thermal common condenser fan	0201	0001	0002	0002							R
Thermal evaporator pump 1	0201	0001	0004	0004							R
Thermal evaporator pump 2	0201	0001	0008	0008							R
Thermal condenser pump 1	0201	0001	0010	0010							R
Thermal condenser pump 2	0201	0001	0020	0020							R
Recovery circ.1	0201	0001	0040	0040							R
Recovery circ.2	0201	0001	0080	0080							R
Defrost end circ.1	0202	0001	0100	0100							R
Defrost end circ.2	0202	0001	0200	0200							R
Energy Saving	0202	0001	0400	0400							R
Oil pressure compressor 1	0202	0001	0800	0800							R
Oil pressure compressor 2	0202	0001	1000	1000							R
Oil pressure compressor 3	0202	0001	2000	2000							R
Oil pressure compressor 4	0202	0001	4000	4000							R
Pump-down flow switch circ. 1	0202	0001	0002	0200							R
Pump-down flow switch circ. 2	0202	0001	0004	0400							R
Global alarm circ.1	0202	0001	0008	0800							R
Global alarm circ.2	0202	0001	0010	1000							R
Auto/Manual functioning	0202	0001	0020	2000							R
Only evaporator fan required	0202	0001	0040	4000							R
Motocondensing Enable	0202	0001	0080	8000							R
Motocond. Chiller	0203	0001	0100	0100							R
Motocond. Heat Pump	0203	0001	0200	0200							R
2nd power step request	0203	0001	0400	0400							R
3rd power step request	0203	0001	0800	0800							R
4th power step request	0203	0001	1000	1000							R
5th power step request	0203	0001	2000	2000							R
6th power step request	0203	0001	4000	4000							R
7th power step request	0203	0001	8000	8000							R
8th power step request	0203	0001	0001	0001							R
9th power step request	0203	0001	0002	0002							R
10th power step request	0203	0001	0004	0004							R
11th power step request	0203	0001	0008	0008							R
12th power step request	0203	0001	0010	0010							R
13th power step request	0203	0001	0020	0020							R
14th power step request	0203	0001	0040	0040							R
15th power step request	0203	0001	0080	0080							R
16th power step request	0204	0001	0100	0100							R
Sanitary water flow switch	0204	0001	0200	0200							R
Solar panel flow switch	0204	0001	0400	0400							R
Only sanitary water enable	0204	0001	0800	0800							R
Thermal Sanitary resistors	0204	0001	1000	1000							R
Thermal Sanitary Water Pump	0204	0001	2000	2000							R
2nd Sanitary water Set enable	0204	0001	4000	4000							R
Phases sequence alarm	0204	0001	8000	8000							R
Sanitary water priority	0204	0001	0001	0001							R
Free cooling flow switch	0204	0001	0002	0002							R
Auxiliary valve circ.1	0204	0001	0004	0004							R
Auxiliary valve circ.2	0204	0001	0008	0008							R

DIGITAL OUTPUT

Reading function code: 0x 03

The data received worked with "Mask", if the result equal to "Value"

That present the variable activate, otherwise the variable is inactive

Example:

sent ADDR+0308010001+CRC

received ADDR+03020300+CRC

where

0x0300 And 0x0100= 0x0100 "Compressor" is active

0x0300 And 0x0200= 0x0200 "Compressor 2" is active

0x0300 And 0x1000= 0x0000 "Antifreeze Heater" is inactive

	HEX	HEX	HEX	HEX							
Name	***Read Register***	***Num. Elements Read***	***Mask***	***Value***							***R / W***
Alarm	0800	0001	0100	0100							R
Evaporator water pump	0800	0001	0200	0200							R
Evaporator water pump support	0800	0001	0400	0400							R
Antifreeze circ1 / 1 step	0800	0001	0800	0800							R
Antifreeze circ2 / 2 step	0800	0001	1000	1000							R
Condenser water pump	0800	0001	2000	2000							R
Condenser water pump aux	0800	0001	4000	4000							R
Reversing valve circ.1	0800	0001	8000	8000							R
Reversing valve circ.2	0801	0001	0100	0100							R
Condenser fan 1 circ.1	0801	0001	0200	0200							R
Condenser fan 2 circ.1	0801	0001	0400	0400							R
Condenser fan 3 circ.1	0801	0001	0800	0800							R
Condenser fan 4 circ.1	0801	0001	1000	1000							R
Condenser fan 1 circ.2	0801	0001	2000	2000							R
Condenser fan 2 circ.2	0801	0001	4000	4000							R
Condenser fan 3 circ.2	0801	0001	8000	8000							R
Condenser fan 4 circ.2	0802	0001	0100	0100							R
Pump down circ.1	0802	0001	0200	0200							R
Pump down circ.2	0802	0001	0400	0400							R
Recovery valve 1	0802	0001	0800	0800							R
Recovery valve 2	0802	0001	1000	1000							R
Free Cooling ON_OFF	0802	0001	2000	2000							R
Auxiliary circ.1	0802	0001	4000	4000							R
Auxiliary circ.2	0802	0001	8000	8000							R
Interm. valve compr. 1	0803	0001	0100	0100							R
Interm. valve compr. 2	0803	0001	0200	0200							R
Injection valve compr. 1	0803	0001	0400	0400							R
Injection valve compr. 2	0803	0001	0800	0800							R
ON/OFF valve 1 sanitary	0803	0001	1000	1000							R
ON/OFF valve 2 sanitary	0803	0001	2000	2000							R
1 step sanit. water resistor	0803	0001	4000	4000							R
2 step sanit. water resistor	0803	0001	8000	8000							R
3 step sanit. water resistor	0804	0001	0100	0100							R
Solar panel pump	0804	0001	0200	0200							R
ON/OFF solar panel	0804	0001	0400	0400							R
Sanitary water pump	0804	0001	0800	0800							R
1° ibrid exchanger circ.1	0804	0001	1000	1000							R
2° ibrid exchanger circ.1	0804	0001	2000	2000							R
1° ibrid exchanger circ.2	0804	0001	4000	4000							R
2° ibrid exchanger circ.2	0804	0001	8000	8000							R
Cooling/heating circuit 1	0805	0001	0100	0100							R
Cooling/heating circuit 2	0805	0001	0200	0200							R
Defrost circuit 1	0805	0001	0400	0400							R
Defrost circuit 2	0805	0001	0800	0800							R
Circuit 1 on regulation	0805	0001	1000	1000							R
Circuit 2 on regulation	0805	0001	2000	2000							R
Sanitary water on regulation	0805	0001	4000	4000							R
Stand-by or remote off	0805	0001	8000	8000							R
Solenoid valve circuit 1	0806	0001	0100	0100							R
Solenoid valve circuit 2	0806	0001	0200	0200							R
Compressor 1	0806	0001	0400	0400							R
Part-winding coil comp 1	0806	0001	0800	0800							R
Capacity step valve 1 comp 1	0806	0001	1000	1000							R
Capacity step valve 2 comp 1	0806	0001	2000	2000							R
Capacity step valve 3 comp 1	0806	0001	4000	4000							R
By-pass valve compressor 1	0806	0001	8000	8000							R
Compressor 2	0807	0001	0100	0100							R
Part-winding coil comp 2	0807	0001	0200	0200							R
Capacity step valve 1 comp 2	0807	0001	0400	0400							R
Capacity step valve 2 comp 2	0807	0001	0800	0800							R
Capacity step valve 3 comp 2	0807	0001	1000	1000							R
By-pass valve compressor 2	0807	0001	2000	2000							R
Compressor 3	0807	0001	4000	4000							R
Part-winding coil comp 3	0807	0001	8000	8000							R
Capacity step valve 1 comp 3	0808	0001	0100	0100							R
Capacity step valve 2 comp 3	0808	0001	0200	0200							R
Capacity step valve 3 comp 3	0808	0001	0400	0400							R
By-Pass valve compressor 3	0808	0001	0800	0800							R
Compressor 4	0808	0001	1000	1000							R
Part-winding coil comp 4	0808	0001	2000	2000							R
Capacity step valve 1 comp 4	0808	0001	4000	4000							R
Capacity step valve 2 comp 4	0808	0001	8000	8000							R
Capacity step valve 3 comp 4	0809	0001	0100	0100							R
By-Pass valve compressor 4	0809	0001	0200	0200							R
Laser enable	0809	0001	0400	0400							R

Device Status

Reading function code: 0x 03

The data received worked with "Mask", if the result equal to "Value"
That present the variable activate, otherwise the variable is inactive

Example:

sent ADDR+0305000001+CRC

received ADDR+03020100+CRC

where

0x0100 And 0x0100= 0x0100 "On" is active

0x0100 And 0x0200= 0x0000 "Defrost" is inactive

HEX	HEX	HEX	HEX

Name	Read Register	Num. Elements Read	Mask	Value							R / W
Stand-by / Remote OFF	0500	0001	0100	0000							R
Chiller / heat pump	0500	0001	0100	0100							R
Device On	0500	0001	0200	0000							R
Device Off by digital input	0500	0001	0200	0200							R
Chiller	0500	0001	0400	0400							R
Heat Pump	0500	0001	0800	0800							R
Alarm reset	0500	0001	1000	0100							R
Alarm mouting	0500	0001	2000	0200							R
Dynamic setpoint status	0500	0001	4000	0400							R
Energy saving status	0500	0001	8000	0800							R
Compressor 1 disabled	0501	0001	0100	0100							R
Compressor 2 disabled	0501	0001	0200	0200							R
Compressor 3 disabled	0501	0001	0400	0400							R
Compressor 4 disabled	0501	0001	0800	0800							R
Circuit 1 disabled	0501	0001	4000	4000							R
Circuit 2 disabled	0501	0001	8000	8000							R
Defrost circuit 1	0502	0001	0100	0100							R
Defrost circuit 2	0502	0001	0200	0200							R
Heat recovery circuit 1	0502	0001	0400	0400							R
Heat recovery circuit 2	0502	0001	0800	0800							R
Free cooling	0502	0001	1000	1000							R
Sanitary hot water	0503	0001	0100	0100							R
Antilegionella cycle	0503	0001	0200	0200							R

ALARMS

Reading function code: 0x 03

The data received worked with "Mask", if the result equal to "Value"
That present the variable activate, otherwise the variable is inactive

Example:

sent	ADDR+030D0030001+CRC	
received	ADDR+03021300+CRC	
where		
	0x1300 And 0x1000= 0x1000	"Error Pb4" is active
	0x1300 And 0x0100= 0x0100	"EEPROM Failure" is active
	0x1300 And 0x0001= 0x0000	"Low Value Pb2" is inactive

	HEX	HEX	HEX	HEX							
Name	Read Register	Num. Elements Read	Mask	Value							R / W
Clock error	0D00	0001	0100	0100							R
Error Pb1	0D00	0001	0200	0200							R
Error Pb2	0D00	0001	0400	0400							R
Error Pb3	0D00	0001	0800	0800							R
Error Pb4	0D00	0001	1000	1000							R
Error Pb5	0D00	0001	2000	2000							R
Error Pb6	0D00	0001	4000	4000							R
Remote probe 1	0D00	0001	0008	0008							R
Remote probe 2	0D00	0001	0010	0010							R
Comp 1 maintenance warning	0D00	0001	0020	0020							R
Comp 2 maintenance warning	0D00	0001	0040	0040							R
Comp 3 maintenance warning	0D00	0001	0080	0080							R
Comp 4 maintenance warning	0D01	0001	0100	0100							R
WaterPump/SupplyFan mainten.	0D01	0001	0800	0800							R
Evap. 2 pump mainten. warning	0D01	0001	1000	1000							R
Cond. 1 pump mainten. warning	0D01	0001	2000	2000							R
Cond. 2 pump mainten. warning	0D01	0001	4000	4000							R
Sanitary water pump mainten.	0D01	0001	8000	8000							R
Solar panel water pump maint.	0D01	0001	0001	0001							R
Free cooling water pump main.	0D01	0001	0002	0002							R
Configuration alarm ACF2	0D01	0001	0004	0004							R
Configuration alarm ACF3	0D01	0001	0008	0008							R
Configuration alarm ACF4	0D01	0001	0010	0010							R
Configuration alarm ACF5	0D01	0001	0020	0020							R
Configuration alarm ACF6	0D01	0001	0040	0040							R
Configuration alarm ACF7	0D01	0001	0080	0080							R
Configuration alarm ACF8	0D02	0001	0100	0100							R
Configuration alarm ACF9	0D02	0001	0200	0200							R
Configuration alarm ACF10	0D02	0001	0400	0400							R
Configuration alarm ACF11	0D02	0001	0800	0800							R
Defrost alarm circuit 1	0D02	0001	1000	1000							R
Defrost alarm circuit 2	0D02	0001	2000	2000							R
Low inlet air temperature	0D02	0001	8000	8000							R
1st remote keyboard com. fail	0D02	0001	0001	0001							R
2nd remote keyboard com. fail	0D02	0001	0002	0002							R
Free cooling config alarm	0D02	0001	0004	0004							R
Sanitary water config alarm	0D02	0001	0008	0008							R
Power supply phase seq. alr	0D02	0001	0010	0010							R
Configuration alarm ACF1	0D02	0001	0020	0020							R
Configuration alarm AC14	0D02	0001	0040	0040							R
I/O expan. board comm. alarm	0D02	0001	0080	0080							R
Expan. valve comm. alarm	0D03	0001	0100	0100							R
I/O expansion probe 1 error	0D03	0001	0200	0200							R
I/O expansion probe 2 error	0D03	0001	0400	0400							R
I/O expansion probe 3 error	0D03	0001	0800	0800							R
I/O expansion probe 4 error	0D03	0001	1000	1000							R
I/O expansion probe 5 error	0D03	0001	2000	2000							R
I/O expansion probe 6 error	0D03	0001	4000	4000							R
I/O expansion probe 7 error	0D03	0001	8000	8000							R
I/O expansion probe 8 error	0D03	0001	0001	0001							R
Expansion valve probe 1 error	0D03	0001	0002	0002							R
Expansion valve probe 2 error	0D03	0001	0004	0004							R
Expansion valve probe 3 error	0D03	0001	0008	0008							R
Expansion valve probe 4 error	0D03	0001	0010	0010							R
Expansion valve alarm circuit 1	0D03	0001	0020	0020							R
Expansion valve alarm circuit 2	0D03	0001	0040	0040							R
Laser macine conf alarm (AC15)	0D04	0001	0100	0100							R
EEPROM alarm	0D05	0001	0100	0100							R
Faulty clock	0D05	0001	0200	0200							R
Compressor 1 high pressure	0D05	0001	0400	0400							R
Compressor 2 high pressure	0D05	0001	0800	0800							R

Compressor 3 high pressure	0D05	0001	1000	1000							R
Compressor 4 high pressure	0D05	0001	2000	2000							R
Compressor 1 overload	0D05	0001	0001	0001							R
Compressor 2 overload	0D05	0001	0002	0002							R
Compressor 3 overload	0D05	0001	0004	0004							R
Compressor 4 overload	0D05	0001	0008	0008							R
Condenser fan overload cir. 1	0D05	0001	0040	0040							R
Condenser fan overload cir. 2	0D05	0001	0080	0080							R
Evap. 1 pump overload	0D06	0001	0100	0100							R
Evap. 2 pump overload	0D06	0001	0200	0200							R
Condenser 1 pump overload	0D06	0001	0400	0400							R
Condenser 2 pump overload	0D06	0001	0800	0800							R
Supply fan overload	0D06	0001	1000	1000							R
Cont. heating and cooling req.	0D06	0001	2000	2000							R
Compressor 1 oil level	0D09	0001	0100	0100							R
Compressor 2 oil level	0D09	0001	0200	0200							R
Compressor 3 oil level	0D09	0001	0400	0400							R
Compressor 4 oil level	0D09	0001	0800	0800							R
High inlet temperature	0D09	0001	4000	4000							R
Evaporator flow swtich	0D09	0001	8000	8000							R
Condenser flow switch	0D09	0001	0001	0001							R
Low pres. switch cir.1 (DI)	0D09	0001	0002	0002							R
Low pres. switch cir.2 (DI)	0D09	0001	0004	0004							R
Low pres.circuit 1 (probe)	0D09	0001	0008	0008							R
Low pres.circuit 2 (probe)	0D09	0001	0010	0010							R
Pump-down circuit 1 alarm	0D09	0001	0020	0020							R
Pump-down circuit 2 alarm	0D09	0001	0040	0040							R
Pump-down in switch off cir 1	0D09	0001	0080	0080							R
Pump-down in switch off cir 2	0D0A	0001	0100	0100							R
Chiller antifreeze alarm cir 1	0D0A	0001	0200	0200							R
Chiller antifreeze alarm cir 2	0D0A	0001	0400	0400							R
Heat pump antifreeze cir 1	0D0A	0001	0800	0800							R
Heat pump antifreeze cir 2	0D0A	0001	1000	1000							R
High temp comp 1 discharge	0D0A	0001	2000	2000							R
High temp comp 2 discharge	0D0A	0001	4000	4000							R
High temp comp 3 discharge	0D0A	0001	8000	8000							R
High temp comp 4 discharge	0D0A	0001	0001	0001							R
General alarm 1	0D0A	0001	0008	0008							R
General alarm 2	0D0A	0001	0010	0010							R
High pres. switch cir 1(DI)	0D0A	0001	0020	0020							R
High pres. switch cir 2(DI)	0D0A	0001	0040	0040							R
High pres. circuit 1 (probe)	0D0A	0001	0080	0080							R
High pres. circuit 2 (probe)	0D0B	0001	0100	0100							R
Sanitary water flow switch	0D0B	0001	0200	0200							R
Solar panel flow switch	0D0B	0001	0400	0400							R
Overload sanitary water heater	0D0B	0001	0800	0800							R
Overload sanitary water pump	0D0B	0001	1000	1000							R
Comp 1 oil diff. pres. switch	0D0B	0001	2000	2000							R
Comp 2 oil diff. pres. switch	0D0B	0001	4000	4000							R
Free cooling water pump switch	0D0B	0001	8000	8000							R

COMMANDS

Writing function code: 0x 10

Data format:
ADDR + 10 + register addr + written elements number + written bytes number + written value

Example:

Command	ADDR + 1005000001020001 + CRC	writing value 0001 to register 0x0500 that means "Device OFF"
Command	ADDR + 1005000001020202 + CRC	writing value 0202 to register 0x0500 that means "Active Defrost"

	HEX										
Name	***Modbus Command***										***R / W***
Stand by	05000001020001										W
Chiller	05000001020404										W
Heat pump	05000001020808										W
Alarm reset	05000001021010										W
Alarm mouting	05000001022020										W
EnergySaving ON	05000001028080										W
EnergySaving OFF	05000001020080										W
CMP1 Disabled	05010001020101										W
CMP1 Enabled	05010001020001										W
CMP2 Disabled	05010001020202										W
CMP2 Enabled	05010001020002										W
CMP3 Disabled	05010001020404										W
CMP3 Enabled	05010001020004										W
CMP4 Disabled	05010001020808										W
CMP4 Enabled	05010001020008										W
CIR1 Disabled	05010001024040										W
CIR1 Enabled	05010001020040										W
CIR2 Disabled	05010001028080										W
CIR2 Enabled	05010001020080										W
Defrost CIR1 ON	05020001020101										W
Defrost CIR2 ON	05020001020202										W