

## COMPONENTS AND FUNCTIONS OF CAMERA



- 1. Body** – The casing of the camera which holds the camera parts.
- 2. Lens** - It draws the light into the camera and focuses it on the film plane.
- 3. Shutter Release Button** – The button that releases or "trips" the shutter mechanism.
- 4. Mode Dial** - This dial allows you to select a shooting mode, automatic or manual or a choice between one of the pre-defined settings.



- 5. Viewfinder** – The "window" through which you look to frame your picture.
- 6. Aperture Ring** - Found around the old manual lens of SLR camera this is used to select an aperture opening.
- 7. Focusing Ring** - This can also be found around the lens of a DSLR camera. This is turned to manually focus the lens.
- 8. LCD Display** - In some compact cameras this acts as the viewfinder.
- 9. Flash** - It provides an instantaneous burst of bright light to illuminate a poorly lit scene.
- 10. Control Buttons** - Usually includes a set of directional keys and a few other buttons to activate certain functions and menus, this is used to let users interact with the camera's computer system.



**11. Power Switch** - Turns On or Off the camera. This may also contain a Record / Play Mode selector on some cameras.

**12. Zoom Control** - Usually marked with W and T, which stands for "Wide" and "Tele" respectively, this is used to control the camera's lenses to zoom-in or zoom-out. For DSLR cameras, the zoom is usually controlled by a zoom ring in the lens.



**13. Battery Compartment** - Holds the batteries.

**14. Memory Card Slot** - This is where expansion memory cards are inserted.

**15. Flash Mount (Hot-Shoe)** - Standard holder with contact plates for optional Flash accessory.

**16. Diopter Adjuster** - This varies the focal length of the lens in the viewfinder to make even people wearing eyeglasses to see clearly through it even without the eyeglasses.

**17. Tripod Mount** - Here is where your standard Tripod or Monopod is attached for added stability.