Meeting room video conferencing equipment guide

Article KB0010103 | Owner: Desktop Support | Subcategory: General | Applies to: Windows 11 laptops (Dell Latitude 5440/7440, Lenovo ThinkPad T14/X1 Carbon, HP EliteBook 840), macOS laptops (MacBook Pro/Air on macOS 14/15), Acme Meeting Room Video Conferencing System (Logitech MeetUp camera, Jabra Speak 710 speakerphone, 55"+ display with HDMI/USB-C inputs, Crestron/AMX touch panel), Microsoft Teams Rooms client, ACME-Corp Wi-Fi (802.1X) and wired Ethernet

Summary

This guide helps Acme employees connect their laptops to meeting-room video-conferencing equipment and troubleshoot common issues. It covers wired/wireless connections, using the room touch panel, selecting correct audio/video devices in Teams, and quick fixes for no video, audio, or touch-panel problems. Follow the self-help steps first; if the problem persists, contact the Desktop Support team with the details outlined in the escalation section.

Symptoms

- No video appears on the room display; screen stays black or shows "No signal".
- Audio is missing, distorted, or produces echo when speaking.
- The room touch panel is unresponsive or shows "Offline".
- The camera feed is black or frozen.
- Unable to join the scheduled Teams meeting from the room system; Teams reports "We couldn't find any audio/video devices".

Common causes

- Incorrect input source selected on the room display (HDMI vs USB-C).
- Loose, damaged, or incompatible HDMI/USB-C cable.
- Outdated firmware on the camera, speakerphone, or touch panel.
- Laptop not authenticated to ACME-Corp Wi-Fi or Ethernet (certificate issue).
- Teams client configured to use the wrong audio/video device (e.g., default laptop mic instead of room system).

Pre-Check

Before attempting any connection, verify that the meeting room is powered on and the display shows the Acme welcome screen. Ensure the room's touch panel is lit and responds to touch. Confirm that your laptop is connected to either the ACME-Corp Wi-Fi network (using your domain credentials) or to the room's Ethernet jack via a dock or adapter. If you are using a USB-C to HDMI adapter, make sure it supports DisplayPort Alt Mode and is plugged into a USB-C port that carries video.

Self-Help Procedure: Connecting Your Laptop to the Room System

Follow these steps to connect your laptop and start a Teams meeting using the room's audiovisual equipment. The procedure works for both Windows and macOS laptops.

1. 1. Locate the HDMI or USB-C cable labelled "Room-In" on the table or credenza. Plug the appropriate end into your laptop (use an adapter if necessary).
2. 2. On the room touch panel, press the "Source" button and select the input that matches the cable you used (HDMI?1, HDMI?2, or USB-C). The display should now show your laptop desktop.
3. 3. Click the Teams icon on your laptop, then join the meeting via the calendar invite or by clicking "Join".
4. 4. In the meeting window, click the three-dot menu -> "Show device settings". Under "Speaker", choose "Crestron Speakerphone" (or the Jabra Speak 710 name shown). Under "Microphone", choose the same device. Under "Camera", select "Logitech MeetUp" or the room camera name.
5. 5. Toggle your video and microphone on. You should see yourself on the room display and hear remote participants through the room speakers. If you need to share content, click the "Share" button in Teams and select your screen or a specific window.

Using the Room Touch Panel and Controls

The touch panel provides quick access to volume, camera mute, and source selection without touching the laptop. Use the volume slider to adjust speaker output; press the microphone icon to mute/unmute the room mic. The "Camera"

button toggles the room camera on/off. If the display shows a blue screen or "No signal", revisit the Source selection step to ensure the correct input is active. Some rooms also have a "Presentation" button that switches the display to a wireless Miracast/Apple AirPlay source-use this only if you intend to share via wireless projection.

Common Issues and Quick Fixes

No video - Verify the cable is firmly seated at both ends and that the touch panel source matches the cable type. Try a different HDMI/USB-C port on the laptop or a spare cable if available.

No audio or echo - In Teams device settings, ensure the room speakerphone is selected for both speaker and microphone. If you hear echo, disable "Listen to this device" in the laptop's sound control panel and make sure only the room mic is active.

Touch panel unresponsive - Power-cycle the panel by pressing the physical power button (usually on the side) for 5 seconds, then wait for it to reboot. If it remains offline, check the Ethernet link light on the panel's rear; reseat the cable or try a different port on the wall jack.

Camera black screen - Press the camera button on the touch panel to toggle the camera off and on. If the image does not return, unplug the camera's USB cable from the room compute module, wait 10 seconds, and plug it back in.

Cannot join Teams meeting - Confirm that the laptop is signed into Teams with your Acme credentials. If you see "We couldn't find any audio/video devices", restart the Teams client or log out and back in.

Service-Desk Procedure

When a user reports that the self-help steps did not resolve the issue, follow this procedure to diagnose and fix the room system. Gather the required information before escalating to the Desktop Support team's Audio-Visual sub-team.

1. 1. Ask the user for the meeting-room name or number, date/time of the incident, and a brief description of what they observed (exact error messages if any).
2. 2. Remotely check the room's touch panel status via the Central Management Console (if available) - look for "Offline" alerts or firmware version mismatches.
3. 3. If the panel is reachable, run a factory reset of the input selection menu and re-apply the default HDMI/USB-C source labels.
4. 4. Inspect the physical cabling: reseat HDMI/USB-C cables at the wall plate and at the laptop end; replace with a known-good cable if the problem persists.
5. 5. Verify that the room's camera and speakerphone appear as USB devices in the room compute module's Device Manager (Windows) or System Information (macOS). Update firmware using the vendor's supplied utility if versions are outdated.
6. 6. If video still fails, test the display with a known-good source (e.g., a spare laptop) to isolate whether the fault lies in the display or the source side.
7. 7. Document all findings, including cable types used, firmware versions, and any error logs from the touch panel or Teams client.
8. 8. Escalate to Desktop Support - Audio-Visual team with the collected details, requesting on-site inspection or replacement of faulty hardware.

When to escalate

If the self-help procedure and the service-desk checks above do not restore video or audio, escalate to the Desktop Support team's Audio-Visual sub-team. Include the room identifier, time of failure, exact symptom (e.g., 'No signal on HDMI?2'), the cable type and adapter used, the laptop model and OS version, firmware versions of the camera/speakerphone/touch panel (if known), and any error messages displayed on the touch panel or in Teams. Attach a photo of the rear cabling if possible. The Audio-Visual team will respond within the P2 High target (8?hours) for non-critical impact, or P1 Critical (4?hours) if the room is required for a leadership-level meeting.

Keywords: meeting room, video conferencing, Teams Rooms, HDMI, USB-C, camera, speakerphone, touch panel, ACME-Corp Wi-Fi, Ethernet, no video, no audio, echo, black screen, source selection, firmware update, cable replacement, Desktop Support, Audio-Visual