

TechMart Electronics- Technical Troubleshooting Guide

SMARTPHONE ISSUES

Problem: Phone won't turn on

Solution: Charge for at least 30 minutes. Hold power button for 10 seconds. If no response, contact support.

Problem: Phone overheating

Solution: Remove case, close all background apps, avoid charging while gaming. If persistent, could indicate battery issue- contact support.

Problem: Touch screen not responding

Solution: Restart the device. Clean screen with dry cloth. If unresponsive after restart, contact support for hardware check.

Problem: Cannot connect to Wi-Fi

Solution: Forget the network and reconnect. Restart router. Check if other devices connect. Reset network settings under Settings > General > Reset.

LAPTOP ISSUES

Problem: Laptop won't boot

Solution: Hold power button 10 seconds to force shutdown. Disconnect all peripherals. Try booting again. If no display, contact support.

Problem: Laptop running slowly

Solution: Check for background processes in Task Manager. Ensure less than 90% disk usage. Restart and run system updates.

Problem: Battery draining fast

Solution: Reduce screen brightness. Disable Bluetooth and Wi-Fi when not needed. Check battery health in settings. Contact support if below 80% capacity within warranty.

Problem: Keyboard keys not working

Solution: Restart device. Check for debris under keys. Connect external keyboard to confirm if hardware issue. Contact support if confirmed hardware fault.

ACCOUNT ISSUES

Problem: Cannot log in to TechMart account

Solution: Use "Forgot Password" on login page. Check email for reset link (check spam folder). If account is locked after 5 failed attempts, wait 30 minutes or contact support.

Problem: OTP not received

Solution: Check mobile signal. Try "Resend OTP" after 60 seconds. Ensure your registered mobile number is correct. Contact support to update mobile number.

GENERAL

Problem: App crashing

Solution: Update the TechMart app to the latest version. Clear app cache under phone settings. Uninstall and reinstall if issue persists.

Problem: Order not showing in account

Solution: Confirm you placed the order on the correct account email. Check spam for order confirmation. Contact support with payment reference number.