# OBJECTIVE DEFUSAL SIMULATION UNIT

# USER MANUAL — DEFUSE ANALYSER

TRAINING & SIMULATION ONLY

VERSION 1.3 – 2026

WARNING: This manual is for simulation purposes only.
Do not attempt to apply these procedures on real devices.

FOLLOW INSTRUCTIONS EXACTLY
READ CAREFULLY BEFORE PROCEED

# Table of content

**!!! IMPORTANT NOTICE !!!** **3**

**OPERATOR WARNING** **3**

**INTRODUCTION** **3**

**SECTION I — OBJECTIVE IDENTIFICATION** **4**

**SECTION II — ANALYSER INITIALIZATION & DEVICE IDENTIFICATION** **4**

**SECTION III — PRIMARY LOCK: QUANTUM POTMETER** **5**

REFERENCE TABLE — POTMETER VALUES: 5

**SECTION IV — SECONDARY SEQUENCE: COLOR PATTERN** **5**

REFERENCE TABLE — COLOR PATTERNS: 6

**SECTION V — FINAL STAGE: WIRE RESOLUTION** **6**

REFERENCE TABLE — COLOR PATTERNS: 6

**FINAL REMARK** **6**

## !!! IMPORTANT NOTICE !!!

This manual describes the operation of a simulated device intended strictly for training, entertainment, and controlled demonstration purposes.

All components referenced herein are non-functional prop elements designed to imitate the appearance and behavior of a hazardous mechanism. Under no circumstances does this device contain or represent a real explosive system.

Any resemblance to real-world devices is purely coincidental and exists solely to enhance the realism of the simulation.

## OPERATOR WARNING

The procedures described in this manual must be followed **EXACTLY** as written.

Improvisation, assumption, or deviation from the outlined steps may result in failure of the simulation scenario. The system is designed to respond only to correct and deliberate actions performed in the proper sequence.

Do **not** attempt to interpret beyond the given instructions.
Do **not** skip steps.
Do **not** act on instinct.

**Read. Understand. Execute.**

## INTRODUCTION

You are presented with a device.

It does not explain itself. It does not forgive hesitation. It does not reward guesswork.

Every wire, every switch, every signal has meaning, though not always obvious at first glance. The purpose of this manual is not merely to inform, but to guide your thinking under pressure.

The simulation has been constructed to test observation, logic, and discipline. Success depends not on speed alone, but on precision and adherence to instruction.

You will encounter uncertainty. This is by design.

Where clarity is absent, procedure must take its place.

## GENERAL OPERATING PRINCIPLE

The objective operates as a closed system governed by predefined rules. Inputs are accepted only when conditions are met. Incorrect interaction may alter system state, restrict further actions, or accelerate failure conditions.

The operator is expected to:

- Observe all visible indicators before acting
- Cross-reference findings with the manual
- Execute instructions in exact order
- Confirm each step before proceeding

The simulation does not provide correction. Only consequence.

## SECTION I — OBJECTIVE IDENTIFICATION

Identify the objective before any interaction.

All procedures depend on correct model classification.

Inspect the unit:

- Casing edges and underside
- Panels and seams
- Exposed motherboard areas
- Markings near wires or connectors

Look for:

- Serial strings
- Engraved or stamped codes
- Printed labels
- Markings near solder points

If none are visible, continue inspection.

If required, use the **Defuse Analyser** to read internal data and reveal identifiers.

Be advised:
System probing may be interpreted as hostile. Some models include protective measures.

Use only when necessary.

## SECTION II — ANALYSER INITIALIZATION & DEVICE IDENTIFICATION

Upon connection, the **Defuse Analyser** will:

- Output terminal data
- Pause briefly
- Enter active state

A **blinking** indicator and visible **countdown** confirm activation.
The objective is now live.

To **retrieve** the objective profile, enter the following command:
“sudo ddefuser get-device --info model”

The analyser will return a structured profile, for example:
**********
[DEVICE] ID: XXAABBZZ
[DEVICE] MODEL: XXAABBZZ
[DEVICE] SERIAL: SN-XXX-YYYY
[DEVICE] HASH: XXXX-YYYY-ZZZZ
[DEVICE] MANUFACTURER: Abcdefg
[DEVICE] FIRMWARE: vx.x.x
[DEVICE] STATUS: CONNECTED (SECURE)
**********
[COMPLETE] Operation finished successfully.

Instructions:

- Extract the **MODEL** field. This is the reference for all tasks.
- Do not act if the output is incomplete or corrupted; re-run the command if needed.
- The analyser provides structure. Interpretation and action remain the operator’s responsibility.

# SECTION III — PRIMARY LOCK: QUANTUM POTMETER

The first mechanism is the **Quantum Potmeter Lock**.

A rotational control outputs values from 0 to 1025. The correct value depends on the objective model.

Procedure:

- Open the analyser graph
- Adjust the control and observe values
- Compare with model references

A blue indicator may appear, confirming analyser communication.

Determine the correct value through comparison.

To confirm:

- Press SW4

A status light will indicate the result.

Do not proceed without confirmation.

REFERENCE TABLE — POTMETER VALUES:

| MODEL | Manufacturer | Correct Value |
|---|---|---|
| QD-5000 Mk.A | QuantumDyne Systems | 998 - 1022 |
| EX-1200 Rev.B | NexaCore Systems | 123 - 321 |
| DDEF-3000 Model X | QuantumTech Labs | 734 -801 |
| NX-1400 Sigma | QuantumDyne Systems | 67 - 420 |
| ZX-900 Pro | NexaCore Systems | 402 - 530 |

# SECTION IV — SECONDARY SEQUENCE: COLOR PATTERN

After successful confirmation, the objective advances.

A second indicator activates.

A color sequence will be displayed.

Procedure:

- Observe order and timing
- Compare with reference patterns

Input the solution using SW3:

- Short press and hold represent different inputs
- Match sequence precisely

The objective will indicate the result.

Proceed only on correct confirmation.

REFERENCE TABLE — COLOR PATTERNS:

| MODEL | Manufacturer | Input Sequence |
|---|---|---|
| EX-1200 Rev.B | NexaCore Systems | PRESS, PRESS, HOLD |
| NX-1550 Omega | QuantumDyne Systems | HOLD, PRES, HOLD |
| ZX-900 Pro | NexaCore Systems | HOLD, HOLD, HOLD, |
| QD-5500 Omega | QuantumDyne Systems | * UNKNOWN * |
| DDEF-3000 Model X | QuantumTech Labs | HOLD, PRES, HOLD |

(Wires marked as * Unknown * indicate that only the creator of the objective knows the correct wire choice.)

# SECTION V — FINAL STAGE: WIRE RESOLUTION

Three wires are present. Only one is correct.

Procedure:

- Evaluate all gathered information
- Consider the objective model
- Use prior results

There is no universal solution.

Once decided:

- Disconnect one wire

This completes the procedure.

REFERENCE TABLE —WIRE RESOLUTION:

| MODEL | Manufacturer | Correct Wire |
|---|---|---|
| ZX-900 Pro | NexaCore Systems | * UNKNOWN * |
| DDEF-3000 Model X | QuantumTech Labs | GRAY |
| NX-1400 Sigma | QuantumDyne Systems | BLACK |
| QD-5500 Omega | QuantumDyne Systems | WHITE |
| EX-1200 Rev.B | NexaCore Systems | WHITE |

(Wires marked as * Unknown * indicate that only the creator of the objective knows the correct wire choice.)

# FINAL REMARK

Treat the objective with seriousness.

Success requires patience, precision, and strict adherence to procedure.

The manual is your only guide.

Follow it without deviation.