6.1 SERVICE PARTS LIST

HAAS Surface Grinder - Service Parts List

Revision C - 06/2026

Service Parts List

PART NUMBERS	DESCRIPTION
93-4718	AC CONTACTOR HSG-2550
93-4719	TRANSFORMER HSG-2550
93-4720	CIRCUIT BREAKER HSG-2550
93-4721	Z-AXIS PULLEY BELT HSG-2550
93-4722	Y-AXIS PULLEY BELT HSG-2550
93-4723	Z-AXIS SCREW WITH NUT HSG-2550
93-4724	Y-AXIS SCREW HSG-2550
93-4725	O-RING HYDRAULIC CYLINDER HSG-2550
93-4726	GUIDE BELT HYDRAULIC CYLINDER HSG-2550
93-4727	GLYD RING HYDRAULIC CYLINDER HSG-2550
93-4728	DUST SEAL HYDRAULIC CYLINDER HSG-2550
93-4729	HYDRAULIC CYLINDER SEAL RING HSG-2550
93-4730	DC RELAY HSG-2550
93-4731	AC RELAY HSG-2550
93-4732	MAIN POWER SWITCH HSG-2550
93-4733	POWER SUPPLY HSG-2550
93-4734	MOTOR CIRCUIT BREAKER 2.5-4A HSG-2550
93-4735	MOTOR CIRCUIT BREAKER 0.4-0.63A HSG-2550
93-4736	MOTOR CIRCUIT BREAKER 4-6.3A HSG-2550
93-5168	VFD SURFACE GRINDER HSG-2550
93-5169	MAGNETIC CONTROLLER HSG-2550
93-5715	LIMIT SWITCH HSG-2550
93-6172	GRINDING WHEEL BASE HSG-2550

6.1 HSG - MAINTENANCE SCHEDULE

MAINTENANCE		
Items	**Lubrication**	**Interval**
Inspect lubrication tank level.	ISO 68 oil for guide ways (e.g Mobil Vactra Oil No.2)	Daily
Clean the filter inside the oil reservoir	ISO 68 oil for guide ways (e.g Mobil Vactra Oil No.2)	Biannually
Inspect hydraulic unit level	ISO 32 hydraulic oil (e.g Mobil DTE 10 Excel 32)	Monthly
Inspect coolant tank level	Cutting fluid	Monthly

Note : New machines need to change the hydraulic oil in the hydraulic tank after the first 3 months. It is recommended to change the hydraulic oil annually after the initial change.

Daily Inspection

ITEM	INSPECTION ITEMS	MACHINE STATE		ACTION / VERIFICATION
		Off	On	
1	Lubrication tank level	X		Ensure oil level is above the limit line
2	Table speed control lever position	X		Set to the lowest setting
3	Grinding wheel position	X		Above work piece
4	Hydraulic unit Level	X		Shut off
5	Cooling unit level	X		Shut off
6	Spindle motor	X		Shut off
7	Grinding wheel cover	X		Closed and locked
8	Electrical panel door	X		Closed and locked
9	Running direction		X	Clockwise
10	Warm-up		X	30 minutes before full operation