5.1 MAINTENANCE SCHEDULE

Overview

This chapter provides information on what maintenance is needed for the Haas Laser Marker Series. There is a maintenance schedule as well as instructions on how to perform the required maintenance.

HL-50E/XT Maintenance



In order to operate the Laser Marker safely, maintenance is recommended on the fume extractor. The fume extractor is used to prevent particles in the air. The fume extractor is equipped with four filters that will need to be replaced periodically. See the table below to see the recommended maintenance for the fume extractor.

NOTE: Maintenance can vary depending on the operational usage of the Laser Marker.

FILTER NAME	INTERVAL	QUANTITY
[1] First Layer - Cotton	Replace every 7-30 days	1
[2] Second Layer - Cotton - Polypropylene (PP)	Replace every 3-6 months	1
[3] Third Layer - Cotton - Glass Fiber	Replace every 3-6 months	1
[4] Fourth Layer - Cotton - Activated Carbon	Replace every 3-6 months	1

Fume Extractor Maintenance Procedure





1
With the fume extractor power switched off, disconnect the power cable from the unit. Unscrew the hose clamp to disconnect the fume extractor hose.



2
Unclamp the lid to reveal the four filters.



3
With the fume extractor lid removed, remove the existing filter elements as necessary. Grab handles can be found on the side of the filter elements, to assist with handling.

NOTE: Labelling or noting the filters as specified by the table at the top of this page will make installation/uninstallation an easier process.



4
Reinstall the filter elements as specified by the table at the top of this page.

The filter elements should easily slide into place into the fume extractor unit. Each filter element (besides the top cotton layer) includes labels that specify the correct orientation for proper air flow.



5
With the filter elements reinstalled, simply latch the fume extractor shut, reinstall the fume extractor hose, and reconnect the power. The unit should be ready for operation.

5.2 HL50E - SPARE PARTS LIST

HAAS Laser Engraver 50E Series - Service Parts List

Revision F - 09/2026

Service Parts List

IMPORTANT: Haas Service permission is required for certain kits before they may be ordered.

MACHINE	PART NUMBER	DESCRIPTION
HL-50E or HL-50E-XT	**93-4712**	50W FIBER LASER SOURCE HL-50E/XT **NOTE**: You must receive approval from Haas Service to order this kit.
	93-4713	GALVO SCANNER FOR FIBER LASER HL-50E/XT **NOTE**: You must receive approval from Haas Service to order this kit.
	93-4714	EZCAD CONTROL BOARD HL-50E/XT **NOTE**: You must receive approval from Haas Service to order this kit.
	93-4715	24V POWER SUPPLY HL-50E/XT **NOTE**: You must receive approval from Haas Service to order this kit.
	93-4716	COMPUTER HL-50E/XT **NOTE**: You must receive approval from Haas Service to order this kit.
	93-5204	GALVO TO BJCZFIBER BOARD CABLE HL-50E/XT
	93-5167	19" MONITOR, HL-50E/XT
	93-5205	MOTOR DRIVER FOR Z AXIS HL-50E/XT **NOTE**: You must receive approval from Haas Service to order this kit.
	09-1050	HL-50E/XT REPLACEMENT SSD **NOTE**: You must receive approval from Haas Service to order this kit.
	09-1049A	HL-50E/XT RACK MOUNT PC W/ DISK DRIVE **NOTE**: You must receive approval from Haas Service to order this kit.
	93-5190	LENS F160 F-THETA HL-50E
	93-5191	LENS HOUSING F-THETA HL-50E/XT
	93-5200	DOOR SAFETY SENSOR SWITCH HL-50E/XT
	93-5199	E-STOP SWITCH HL-50E/XT
	93-5198	LASER ENABLE SWITCH HL-50E/XT
	93-5197	LASER KEY SWITCH HL-50E/XT
	93-5196	MOVEMENT SWITCH HL-50E/XT
	93-5203	3-PIN AVIATION POWER PLUG HL-50E/XT
	93-5201	3-PIN AVAITION POWER PLUG HL-50E/XT-EU
	93-5301	Z-AXIS MOTOR HL-50E/XT
	93-5300	ROTARY MOTOR DRIVER HL-50E/XT
	93-5634	BSCREW 18-4-586.5-11.9 HL-50E/XT
	93-5520	RAM STICK HL-50E/XT
	93-5307	MONITOR HOLDER HL-50E/XT
	93-5544	KEYBOARD HL-50E/XT
	93-5545	MOUSE HL-50E/XT
	93-5522	RELAY, 5V 2 CHANNEL NO HL-50E/XT
	93-5604	RELAY ADAPTER PLATE HL-50E/XT
	93-5634	BSCREW 18-4-586.5-11.9 HL-50E/XT
	93-5664	JUMPER DOOR SWITCH HL-50E/XT
	93-5779	BREAKER 10A HL-50E/XT
	93-5862	COLUMN Z-AX HL-50E/XT
HL-50E ONLY	**93-5189**	OD RATED WINDOW SET HL-50E
	93-5192	DOOR CABLE PULLEY ASSY HL-50E (PAIR)
	93-5193	ALUMINUM FIXTURE PLATE HL-50E
	93-5202	OVERHEAD LIGHT HL-50E
	93-5439	LOCKING CASTER HL-50E
	93-5566	DOOR SWITCH SVC KIT HL-50E
	93-5621	DOOR SWITCH CABLE HL-50E
	93-5837	ROLLERS Z-AX COLUMN HL-50E
	93-5838	NUT HOUSING Z-AX COLUMN HL-50E
	93-5839	BEARING ASSY Z-AX COLUMN TOP HL-50E
	93-5855	BEARING ASSY Z-AX COLUMN BOTTOM HL-50E
	93-5863	DOOR LEFT SIDE HL-50E W/ DECALS
	93-5864	DOOR RIGHT SIDE HL-50E W/ DECALS
	93-6041	DOOR FRONT HL-50E W/ HARDWARE
	93-6055	DOOR FRONT SLIDING RAILS HL-50E
	93-6063	CONTROL PLATE FRONT W/ DECAL HL-50E
	93-6064	ENCL FRAME TOP W/ DECAL HL-50E
	93-6691	DOOR LATCH HL-50E
HL-50E-XT ONLY	**93-5640**	WINDOW SET, OD RATED HL-50E-XT
	93-5768	DOOR PULLEY (SET OF 2) HL-50E-XT
	93-5769	DOOR RAILS W/ SLIDERS (2) HL-50E-XT
	93-5770	DOOR HOLD MAGNETS (2) HL-50E-XT
	93-5858	DOOR SWITCH CABLE HL-50-XT
	93-5859	LASER HEAD MOUNT, HL-50E-XT
	93-6058	GROMMET CABLE PASS THROUGH HL-50E-XT
	93-6455	RAILS/TRUCKS/WASHERS X-AXIS HL-50E-XT
	93-6692	SIDE DOOR HINGE HL-50E-XT

Feedback