

NEXA

FRONX

OWNER'S MANUAL

For vehicle fitted with CNG fuel system, use **FRONX CNG Supplementary Owner's Manual**

- Refer for vehicle usage at all times
- Contains Warranty policy and Important Information On Safety, Operation & Maintenance

Part No. 99011M74T05-74W
July , 2024
ENG.

This Owner Manual applies to the FRONX series produced by
MARUTI SUZUKI INDIA LIMITED



Note: The illustrated models are one of the FRONX Series.

© Copyright 2024 **Maruti Suzuki India Limited**. All rights reserved.
No part of this manual can be reproduced in any manner whatsoever or transmitted
in any form or by any means without prior written consent of Maruti Suzuki India Limited.

FOREWORD

The digital Owner's Manual is an essential part of your vehicle a rich document which familiarizes you with the vehicle by providing information such as features, warnings, operations and equipment description etc. Please read this manual carefully before operating your new MARUTI SUZUKI vehicle and review the manual from time to time. It is recommended to download this manual (from "Maruti Suzuki Rewards" mobile application with your registered mobile number) and save a soft copy of the same for easy access all times. Please visit MARUTI SUZUKI authorised workshop for availing any service.

To prolong the life of your vehicle and reduce maintenance cost, the periodic maintenance must be carried out according to "PERIODIC MAINTENANCE SCHEDULE" described in "INSPECTION AND MAINTENANCE" section of this manual. It is essential for preventing trouble and accidents to ensure your satisfaction and safety.

Daily inspection and care as per "DAILY INSPECTION CHECKLIST" described in the "OPERATING YOUR VEHICLE" section of this manual is essential for prolonging the life of the vehicle and for safe driving.

Vehicle and the available features/accessories therein should be used and plied by the owner/user in accordance with the applicable legal requirements.

MARUTI SUZUKI INDIA LIMITED believes in conservation and protection of Earth's natural resources.

To that end, we encourage every vehicle owner to recycle, trade-in or properly dispose of, as appropriate, used Engine Oil, coolant and other fluids, batteries and tyres etc.

MARUTI SUZUKI INDIA LIMITED

All information in this manual is based on the latest product information available at the time of publication. Due to improvements or other changes, there may be discrepancies between information in this manual and your vehicle.

MARUTI SUZUKI INDIA LIMITED reserves the right to make production changes at any time, without notice and without incurring any obligation to make the same or similar changes to vehicles previously built or sold.

This vehicle may not comply with standards or regulations of other countries. Before attempting to register this vehicle in any other country, check all applicable regulations and make any necessary modifications.

IMPORTANT

⚠ WARNING/ ⚠ CAUTION/NOTICE/ NOTE

Please read this manual and follow its instructions carefully. To emphasize special information, the symbol and the words **WARNING**, **CAUTION**, **NOTICE** and **NOTE** have special meanings. Pay particular attention to messages highlighted by these signal words:

⚠ WARNING

Indicates a potential hazard that could result in death or serious injury.

⚠ CAUTION


Indicates a potential hazard that could result in minor or moderate injury.

NOTICE

Indicates a potential hazard that could result in vehicle damage.

NOTE:

Indicates special information to make maintenance easier or instructions clearer.



75F135

The circle with a slash in this manual means "Don't do this" or "Don't let this happen".

NOTE:

- Words like car, model/variant are invariably used in this manual to denote the "Vehicle".
- Pictorial representations used in this manual are for reference purposes only.

MODIFICATION WARNING

⚠ WARNING

Do not modify your vehicle. Modification could adversely affect safety, handling, performance, or durability and may violate governmental regulations. In addition, damage or performance problems resulting from modification shall not be covered under warranty.

NOTICE

Improper installation of mobile communication equipment such as cellular telephones, CB (Citizen's Band) radios may cause electronic interference with your vehicle's ignition system, resulting in vehicle performance problems. Consult your Maruti Suzuki authorised workshop or qualified service technician for advice on installing such mobile communication equipment.

NOTICE

The diagnostic connector of your vehicle is prepared only for the specific diagnostic tool for inspection and service purpose. Connecting any other tool or device may interfere with electronic parts operations and cause running out of batteries.

“WARNING”



Vehicle may break-down, meet with an accident or catch fire due to

1. Installation of
 - High wattage bulbs
 - Non genuine lamps / horns
 - Modified suspension / wheels
 - Non genuine parts / accessories etc.
2. Retrofitment of LPG / CNG fuel systems/kits.
3. Usage of domestic LPG.
4. Short circuiting due to tampering of wiring harness.

CAUTION: DO NOT STORE OR CARRY INFLAMMABLE MATERIALS IN THE VEHICLE.



Avoid driving into or starting the vehicle in a heavily water logged area. Vehicle may break-down or engine may fail due to

1. Water entry into the engine (which may lead to hydrostatic lock).
2. Short circuiting of the electrical systems.

If the vehicle is stuck in deep water, do not start / crank the vehicle until the level of water drops below the level of exhaust pipe.

NOTE:
IF THE VEHICLE IS SUBMERGED IN WATER, REPORT TO THE NEAREST AUTHORIZED WORKSHOP.

“CAUTION”

1. Retro-fitment of LPG / CNG kit may deteriorate vehicle performance, reduce engine & engine related component's life and also warranty will be null and void for such vehicles.
2. Do not use domestic LPG/LPG cylinder for your factory fitted LPG vehicles.
3. Usage of domestic LPG for running vehicles is prohibited as per law.
4. Do not remove company fitted LPG/CNG kit to install some other kit. It may affect vehicle performance and may cause fire.
5. Drive slowly on wet roads. Tires may slip while braking at higher speeds due to aquaplaning.(reduced contact area between tire and road due to presence of water)
6. Do not leave engine running in garages or confined areas, with passengers inside. This may result in accumulation of carbon-monoxide in cabin and may lead to suffocation or breathing problems.
7. Do not park vehicle on dry leaves or grass. This may lead to fire due to hot catalytic converter, igniting the dry leaves/grass.
8. If the vehicle is equipped with CNG/LPG, ensure availability of fire extinguisher in the vehicle all the time.
9. Always wear seat belt at all the times.
10. Do not use mobile phone while driving.
11. Avoid Smoking in the car, live bud thrown in car may cause fire.
12. Do not put any body part under the vehicle when it is supported on a Jack.
13. Do not use non-genuine accessories in your vehicle.
14. Do not fit accessories from unauthorized workshops/sources.
15. Usage of non-approved electrical accessories in your vehicle may result in spark, fire or personal injury.
16. Do not use camphor, incense sticks inside cabin room. Doing so may cause fire.
17. Avoid usage of cellular phones while refueling. Electric current and/or electronic interference from cellular phones can potentially ignite fuel vapors and cause fire.
18. Avoid entry inside vehicle immediately once after you have begun refueling. You can generate a build up of static electricity by touching, rubbing or sliding against any item or fabric capable of producing static electricity. Static electricity discharge can ignite fuel vapors and may causing a fire.
19. Do not check the engine room / open the hood near the fire area (Outside the vehicle). Fuel, washer fluid, etc. are flammable oils that may cause fire.
20. Avoid driving when vehicle has met with an accident . Before driving, Please contact with authorized MSIL dealership.

To experience and use the Digital Owner's Manual, download Maruti Suzuki app



Maruti Suzuki Rewards app ensures a hassle free car ownership experience. Get easy access to all the services and information you need by downloading the app



How to download Owners manual from Maruti Suzuki application

Step 1: Download “Maruti Suzuki Rewards” application from apple app store / google play store on your mobile phone

Step 2: Input registered mobile number and the OTP received from SMS

Step 3: Select “S-Assist BOT” icon and click “View Owner’s Manual” to access digital Owner’s Manual

Step 4: Click “Down Arrow” download and save Owner’s Manual on your mobile phone

Now, the Owner's Manual is available on your mobile phone for reference at all times.

(For assistance, contact Maruti Suzuki authorised workshop)

WARRANTY POLICY

Maruti Suzuki India Limited (hereinafter called "Maruti Suzuki"), warrants that each new Maruti Suzuki vehicle distributed in India by Maruti Suzuki and sold by a Maruti Suzuki authorised dealer will be free, under normal use and service, from any defects in material and workmanship at the time of manufacture SUBJECT TO THE FOLLOWING TERMS AND CONDITIONS:

(1) Qualification:

To qualify for this warranty the vehicle must be delivered by a Maruti Suzuki authorised dealer and set-up, and serviced by a Maruti Suzuki authorised workshop.

(2) Term:

The term of the warranty shall be Thirty-Six (36) months or 1,00,000 kilometers (whichever occurs first) from the date of invoice to the first owner.

NOTE:

Maruti Suzuki offers warranty for the below parts in vehicle, if equipped, as follows:

- *Lithium-ion battery, Integrated Starter Generator (ISG), Hybrid ECU, Inverter / Converter Unit, Power Management ECU - Sixty (60) months or 1,00,000 kilometers (whichever occurs first).*
- *Hybrid Electric Vehicle (HEV) Battery- Ninety six (96) months or 1,60,000 kilometers (whichever occurs first).*

(3) Maruti Suzuki Warranty Obligation:

If any defect(s) should be found in a Maruti Suzuki vehicle within the term stipulated above, Maruti Suzuki's only obligation is to repair or replace at its sole discretion any part shown to be defective, with a new part or the equivalent at no cost to the owner for parts or labor, when Maruti Suzuki acknowledges that such a defect is attributable to faulty material or workmanship at the time of manufacture. Such defective parts, which have been replaced, will become the property of Maruti Suzuki. The owner is responsible for any repair or replacements which are not covered by this warranty. The decision of Maruti Suzuki shall be final & binding.

(4) Limitation:

This warranty shall not apply to:

- (a) Normal maintenance service required other than the three free services, including without limitation, oil and fluid changes, Consumables, headlight aiming, fastener retightening, wheel balancing, wheel alignment and tyre rotation, cleaning of injectors, adjustments of clutch and valve clearance.
- (b) The normal wear of parts including without limitation, bulbs, tyres* and tubes, spark plugs, belts, hoses, filters, wiper blades, brushes, contact points, fuses, clutch disc, brake shoes, brake pads, cable and all rubber parts (except oil seal and glass run).
- (c) Any vehicle which has been used for competition, rallies or racing.
- (d) Any repairs or replacement arising from accidents or collision.

(* - If there is a complaint related to tyre, the customer may contact respective tyre manufacturer.)

-
- (e) Any defect/ damage caused by misuse, negligence, abnormal use, insufficient care, vandalism, theft, riot, fire, flooding - not limited to entry of water in the components resulting in engine seizure, hydrostatic lock, etc. or external damages to the body/ components.
 - (f) Any damage resulting due to usage of adulterated fuel/ lubricants/ oil/ coolant/ fluids/ polishing products and fuel/ lubricants/ oil/ coolant/ fluids used other than those specified in the Owner's Manual.
 - (g) Any vehicle which has been modified or altered, including without limitation, the installation of performance accessories, enlargements of lights, other changes and external/ consequential reasons.
 - (h) Any vehicle on which parts or accessories not approved by Maruti Suzuki (Non-MSGA, Non-MSGP) have been used.
 - (i) Any vehicle which has not been operated in accordance with the operating instructions in this Owner's Manual and Service Booklet.
 - (j) Any vehicle which has not received the service inspections prescribed in this Owner's Manual and Service Booklet.
 - (k) Any vehicle which has been assembled, disassembled, adjusted or repaired by other than a Maruti Suzuki authorised workshop.
 - (l) Any vehicle which has been used for purposes other than what it was designed for.
 - (m) Any damage or deterioration caused by airborne fallout, industrial fallout, acid rain, hail or hail storm, wind storm, lightning, bird droppings, rodents bite / rat bite and such other thing that result in damage to the vehicle.
 - (n) Insignificant defects which do not affect the function of the vehicle including without limitation, sound, vibration and fluid seep.
 - (o) Any natural wear and tear including without limitation, ageing, wear & tear or deterioration such as discolouration, fading, deformation or blurring and fabric discolouration.
 - (p) Installation and usage of domestic LPG gas/LPG Cylinder.
 - (q) V-belts, hoses and gas leaks.
 - (r) Any vehicle retrofitted with LPG/CNG kits.
 - (s) Repainting including patchwork, bodywork and mouldings and interior trims.
 - (t) Corrosion, rusting of body parts and/ or components.
 - (u) Any vehicle on which odometer has been changed unauthorisedly or odometer reading has been modified/ tampered with/ or not matching the service records.
 - (v) The damage(s) caused to the vehicle being unattended despite knowledge that the defect exists and ignorance by the owner/ user of the vehicle.
 - (w) Any damage(s) caused to vehicle including battery/ tyre due to parking of the vehicle in idle condition for long duration of time periods.
 - (x) Any vehicle on which the retro-fitment is not authorized and/ or type approved as per the standards prescribed by the relevant authority including but not limited to Automotive Standards of India.
 - (y) Any vehicle on which the retro-fitment is such which directly or indirectly causes any damage to the vehicle or affects the functions of the vehicle in any manner whatsoever.

(5) Extent of Warranty:

This warranty is the entire written warranty given by Maruti Suzuki for Maruti Suzuki vehicles and no dealer or its or his agent or employee is authorised to extend or enlarge this warranty and no dealer or its or his agent or employee is authorised to make any oral warranty or representation or assurance on behalf of Maruti Suzuki.

Maruti Suzuki reserves the right to add any improvements or change the design of any model at any time with no obligation to make the same changes on units previously sold.

(6) Warranty Service:

To obtain warranty service, the complete vehicle must be presented at the owner's expenses to Maruti Suzuki authorised workshop.

The customer shall be responsible for his belongings or accessories fitted in the vehicle at the time of presenting the vehicle for service and no claim shall be entertained in any manner under any circumstances.

(7) Owner's Warranty Responsibilities:

NOTICE

The owner shall not use the vehicle in a damaged condition and report the same immediately to the nearest Maruti Suzuki authorized workshop. This would result in early inspection and repair of the vehicle and any possible harm to the person or aggravation of damage to the vehicle can be prevented.

It is responsibility of each owner to:

- Have performed, at his own expenses, by a Maruti Suzuki authorised workshop all the service inspections specified in the Owner's Manual described in "INSPECTION AND MAINTENANCE" SECTION".
- Should you resell the vehicle, please guide the new users/ owners to download this manual (from "Maruti Suzuki Rewards" mobile application with your registered mobile number). Also the soft copy of the manual must be passed on to new users/ owners when resold or otherwise transferred.

If the Owner's Manual is lost due to any reason, the owner or user may download a soft copy of the same (from "Maruti Suzuki Rewards" mobile application with the mobile number) and save it for easy access at any point of time.

(8) Disclaimer of Consequential Damage:

Maruti Suzuki assumes no responsibility for loss of vehicle, loss of time, inconvenience or any other indirect incidental or consequential damage resulting from the vehicle not being available to the owner because of any defect covered by this warranty.

(9) Change of Owner

Even if ownership of the vehicle changes, the remaining warranty period is effective for the new owner.

This warranty is applicable only in India and not transferable to any other country.

NOTE:

Notwithstanding the warranty obligations, Maruti Suzuki may reuse reworked (refurbished) parts for undertaking rectification of recalled vehicles in terms of applicable laws.

EMISSION WARRANTY POLICY

Maruti Suzuki offers the Emission Warranty on all Maruti Suzuki vehicles (apart from the Regular Warranty and will run parallel to the regular product warranty) only in four metropolitan cities (**New Delhi, Kolkata, Mumbai and Chennai**) with effect from July 1st, 2001.

Terms:

The Emission Warranty will be applicable for **80,000 kms or 3 years** (Whichever comes earlier) from the date of invoice to the first owner. The remaining warranty terms will be valid in case of any change in ownership provided the production of all valid documents.

Conditions:

1. Under Emission Warranty, Warranty claims will be admitted for a prima-facie examination, in case vehicle fails to meet the Emission Standard as specified in sub rule (2) of rule no. 115 of Central Motor Vehicles Rules (CMVR), 1989.
2. The warranty claims will only be accepted after examination carried out by Maruti Suzuki or Maruti Suzuki authorised workshop which leads to firm conclusions that the
 - a) Original settings have not been tampered in any case.
 - b) Part (as given in Annexure - A) has a manufacturing defect.
 - c) Vehicle is unable to meet the Emission Standards (as given in 1.), inspite of the vehicle having been maintained and used in accordance with the instructions as specified in Owner's Manual and Service Booklet and the used fuel and different oils (Engine oil, Transmission oil, Brake oil etc.) are also as per specification.

3. The method of examination for deciding the warranty of the parts will be at the sole discretion of Maruti Suzuki and Maruti Suzuki authorised workshop and results of the examination will be final and binding. If after examination, the warrantable condition is not established, Maruti Suzuki and Maruti Suzuki authorised workshop has the right to charge all, or part of the cost of such examination.
4. Under Emission Warranty, the parts (as given in Annexure - A) will be changed free of cost, but the consumables will be charged as per actual.
5. If the part covered under Emission Warranty or the associated parts, are not independently replaceable, on account of these being integral parts of a complete assembly, Maruti Suzuki and Maruti Suzuki authorised workshop will have the sole discretion to replace either the entire assembly or by using some of the parts of the system through suitable repairs or modifications.
6. Any consequential repairs or replacement of parts which may be found necessary to establish compliance of Emission Warranty, will not be considered under warranty, unless the same is under product warranty. The consumable will be charged as per actual under such repair or replacement.
7. Maruti Suzuki will not be responsible for the cost of transportation of the vehicle to the nearest Maruti Suzuki authorised workshop or any loss due to non-availability of the vehicle during the period of lodging of a warranty claim and examination and/or repair by Maruti Suzuki authorised workshop.
8. Maruti Suzuki will not be responsible for any penalty that may be charged by statutory authorities on account of failure to comply with the EMISSION STANDARDS.
9. Emission Warranty will not be affected by the change of owner, provided all the documents are available.

-
10. All maintenance actions (as specified in the Owner's Manual need to be followed for emission warranty).
 11. The customer needs to produce the PUC (Pollution Under Control) certificate valid for the period preceding the test during which the failure is discovered. The records/receipts (for the maintenance of the vehicle as per maintenance schedule specified in the Owner's Manual and Service Booklet from the date of original purchase of the vehicle) will also be required.

NOTE:

To keep the engine running at idle speed (for strong hybrid model, if equipped) switch to maintenance mode by performing following steps within 60 seconds:

- Turn the ignition switch to ON
- Move the shift lever to P or select park (P) and fully depress the accelerator pedal twice
- Move the shift lever to N or select neutral (N) and fully depress the accelerator pedal twice
- Move the shift lever to P or select park (P) and fully depress the accelerator pedal twice.
- Start the engine by turning the ignition switch ON (READY) while depressing the brake pedal.
- Check that the 2WD maintenance mode message is displayed on the multi-information display.
- Post completion of test:
- Turn the Ignition Switch OFF and wait for at least 30 seconds, the hybrid system will turn off.
- After deactivating maintenance mode, turn the Ignition Switch ON and check corresponding message is no longer displayed.

Conditions under which the Emission Warranty is not APPLICABLE

1. In the absence of valid PUC certificate.
2. Vehicle not serviced from Maruti Suzuki authorised workshop as per the schedule specified in the Owner's Manual.
3. Vehicle subjected to abnormal use (accident, motor race, rallies or for the purpose of establishing the records etc).
4. Use of non MSGP (Maruti Suzuki Genuine Part).
5. Vehicle that has been tampered with.
6. Tampering with odometer so that the actual kilometer reading cannot be determined.
7. Use of adulterated fuel and/or unspecified oils (Engine oil, Transmission oil and Brake oil etc).


Annexure - A

List of parts (if applicable) covered under Emission Warranty

1. Fuel Injection Assembly, Pressure Regulator, Throttle Body Assembly.
2. ECM (Electronic Control Module).
3. Intake Manifold.
4. EGR valve.
5. Ignition Coil.
6. Canister Assembly.
7. Vapour Liquid Seperator.
8. Fuel Tank and Filler Cap.
9. PCV (Positive Crankcase Ventilation) Valve.
10. Oil Filler Cap.
11. Catalytic Convertor.
12. Exhaust Manifold.
13. All Fuel Injection System related Sensors.
14. High Pressure Fuel Pump.
15. Glow Plug.
16. Glow Plug Controller.

QUICK GUIDE

Illustrated Table of Contents	1-1
Warning Lights and Indicators	1-9
Warning Buzzer	1-18




59RN00020

QUICK GUIDE

Illustrated Table of Contents

Exterior

- (1) Door (P.3-1)
- (2) Door Locks (P.3-2)
- (3) Outside Rearview Mirror (P.2-10)
- (4) Windshield Wiper (P.3-27, 9-35)
- (5) Fuel Filler Cap (P.7-1)
- (6) Front Turn Signal Light (P.3-24, 9-31)
(if equipped)
- (7) High Mount Stop Light (P.9-32)
- (8) Tailgate (P.3-4)
- (9) Rear Window Wiper (if equipped)
(P.3-28, 9-36)
- (10) Rear Camera (if equipped)
(P.5-66, 5-97)
- (11) Side turn signal light on outside rear-view mirror (if equipped) (P.9-31)
- (12) Side Camera (if equipped) (P.5-66)
- (13) Side turn signal light on fender
(if equipped) (P.9-30)
- (14) Daytime running light (D.R.L.) (P.3-23), Position light (P.9-31), Front Turn Signal Light (P.3-24, 9-31) (if equipped)
- (15) Position light (P.9-31) (if equipped)
- (16) Headlight (P.3-20, 9-30)
- (17) Engine Hood (P.7-4)
- (18) Front Camera (if equipped) (P.5-66)
- (19) Towing Eye Cover (P.10-2)
- (20) Brake Light & Tail Light (P.9-32)
- (21) Reversing Light (P.9-32)
- (22) Rear Turn Signal Light (P.3-24, 9-32)
- (23) Tail Light (P.9-32)
- (24) Parking sensor (P.5-92)
- (25) License Plate Light (P.9-32)



Interior, Side


- (1) Inside Rearview Mirror (P.2-8)
- (2) Front Interior Light (P.7-7, 9-32)
- (3) Sun Visor (P.7-6)
- (4) Warning Label for Front Passenger's Front Airbag (P.2-40) *1, *2
- (5) Hands-free microphone (if equipped) (P.7-29)
- (6) Center Interior Light (P.7-7, 9-32)
- (7) Seat Belt (P.2-19)
- (8) Side Curtain Airbag (if equipped) (P.2-41)
- (9) Front Seat (P.2-5)
- (10) Side Airbag (if equipped) (P.2-41)
- (11) Front Seat Back Pocket (if equipped) (P.7-17)

*1: Be sure to read the detailed information in the target page before using a child restraint system.

*2: NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur.



74TB01001




55TB102

QUICK GUIDE

Interior, Rear


- (1) Assist Grip (P.7-14)
 - (2) Seat Belt (P.2-19)
 - (3) Rear Seat (P.2-13)
 - (4) Accessory Socket (if equipped)
(P.7-10)
 - (5) USB Charging Socket (if equipped)
(P.7-16)



55TB1011

Interior, Front


- (1) Glove Box (P.7-13)
- (2) Front passenger's front airbag (P.2-40)
- (3) Accessory socket (P.7-10)
- (4) Heating and Air Conditioning System (P.7-18)
- (5) USB socket (if equipped) (P.7-16)
- (6) Driver's Front Airbag (P.2-40)
- (7) Engine Hood Release Handle (P.7-4)
- (8) Fuel Lid Opener Lever (P.7-1)
- (9) Parking brake Lever (P.5-16)
- (10) Gearshift Lever (P.5-20, 5-21)
- (11) Window Lock Switch (P.3-18)
- (12) Electric Window Control (P.3-17)
- (13) Electric Mirror Control (P.2-10)
- (14) Door Lock Switch (P.3-2)



QUICK GUIDE

Instrument Panel 1


- (1) Hazard Warning Switch (P.3-25)
- (2) Hands-free switch (if equipped) (P.7-28)
 - Voice recognition switch (if equipped) (P.7-29)
- (3) Windshield Wiper and Washer Lever (P.3-26)/
 - Rear Window Wiper/Washer Switch (if equipped) (P.3-28)
- (4) Remote Audio Controls (if equipped) (P.7-28)
- (5) Instrument Cluster (P.4-1, 4-14)
- (6) Head-up Display (if equipped) (P.5-58)
- (7) Cruise Control Switches (if equipped) (P.5-56)
- (8) Lighting Control Lever (P.3-21)/
 - Turn Signal Control Lever (P.3-24)
- (9) Heated Rear Window Switch (P.3-29)
- (10) Drink Holder (P.7-11)
- (11) Tilt / Telescoping (if equipped) Steering Lock Lever (P.2-7)
- (12) Ignition Switch (vehicle without keyless push start system) (if equipped) (P.5-3)
- (13) Engine Switch (vehicle with keyless push start system) (if equipped) (P.5-5)
- (14) Instrument Panel Under Tray (Driver's Side) (P.7-12)
- (15). Fuses (P.9-24)



Instrument Panel 2

- (1) Down Switch* (if equipped) (P.5-58)
- (2) Up Switch* (if equipped) (P.5-58)
- (3) Brightness Control Switch*
(if equipped) (P.5-58)
- (4) Head-up Display Switch*
(if equipped) (P.5-58)
- (5) ESP® OFF Switch (P.5-101)
- (6) Camera Switch (if equipped) (P.5-66)
- (7) Headlight leveling switch (P.3-20)
- (8) ENG A-STOP OFF switch
(if equipped) (P.5-52)
- (9) For Non Keyless Entry (P.3-5, 5-3)
- (10) For Keyless Entry (P.3-5, 5-5)


*: For Head-up display



QUICK GUIDE

Luggage Compartment

- (1) Luggage compartment cover
(if equipped) (P.7-17)
- (2) Spare tyre (if equipped)
- (3) Luggage compartment light
(if equipped) (P.7-8, 9-33, 12-7)
- (4) Luggage Compartment Hook (P.7-17)
- (5) Luggage Compartment Board
- (6) Towing Eye (P.10-2)
- (7) Jack Handle (P.10-4)
- (8) Jack (P.10-6)
- (9) Wheel Wrench (P.10-4)
- (10) Tool bag (P.10-4)
- (11) Flat tyre repair kit (If equipped)(P.10-11)



NOTE:



For CNG variant, please refer CNG supplementary Owner's Manual

Key

(1) Keyless Push Start System Remote Controller (P.3-9)
Keyless Push Start System (P.5-9)
Starting Engine (P.5-12)

(2) Key (P.3-1)
Door Locks (P.3-2)

(3) Keyless Entry System Transmitter
(P.3-6)
Starting Engine (P.5-12)
Key (P.3-1)
Door Locks (P.3-2)




55T010010

QUICK GUIDE


Warning Lights and Indicators

Warning Lights

Instrument cluster (Type A)



55TB01014

Instrument cluster (Type B)

55TB01015

QUICK GUIDE


- If a warning light continues to be lit or is blinking, there may be a problem with the vehicle or the system. Carefully read the following reference information and consult with a Maruti Suzuki authorized workshop.
- It is considered normal that warning lights and indicators marked with an asterisk (*) are lit when turn the ignition switch to ON position or pressing the engine switch to change the ignition mode to ON (i.e., high engine coolant temperature warning light initially lights up in red). If such lights do not light up, consult with a Maruti Suzuki authorized workshop.
- For the ENG A-STOP system, there is the particular condition that a warning light or an indicator is lit.

Warning light		Color	Name
(1)		*	Red Brake System Warning Light
(2)		Red	Driver's Seat Belt Reminder Light / Front Passenger's Seat Belt Reminder Light
(3)		White	Rear Seat Passenger's Seat Belt Reminder Light (Left / Center / Right)
(4)		*	Red Airbag Warning Light
(5)		Orange	Low Fuel Warning Light

Warning light		Color	Name
(6)		*	Orange Anti-lock Brake System (ABS) Warning Light
(7)		*	Red High Engine Coolant Temperature Warning Light
(8)		*	Orange Malfunction Indicator Light
(9)		*	Orange Electric Power Steering Light
(10)		*	Red Engine Oil Pressure Warning Light
(11)		*	Red Charge Warning Light
(12)		*	Orange Immobilizer/Keyless Push Start System Warning Light
(13)			Red Open Door Warning Light

QUICK GUIDE


Warning light		Color	Name
(14)		Orange	Brake Request Indicator (for AGS models)
(15)		Orange	Transmission Warning Light (for AGS / AT models)
(16)		*	Master Warning Indicator Light (if equipped)

Indicators**Instrument cluster (Type A)**

55TB01016

QUICK GUIDE

Instrument cluster (Type B)



55TB01017

Indicator		Color	Name
(17)		Green	Turn Signal Indicators
(18)		Blue	Main Beam (High Beam) Indicator Light
(19)		Green	Illumination Indicator Light
(20)		White	Deceleration Energy Regenerating Indicator Light (if equipped)
(21)		*	ESP® OFF Indicator Light
(22)		*	ESP® Warning Light
(23)		Blue	Low Engine Coolant Temperature Light
(24)		*	ENG A-STOP Indicator Light (if equipped)

QUICK GUIDE

Indicator		Color	Name
(25)		*	Orange ENG A-STOP OFF Indicator Light (if equipped)
(26)			Red Security System Indicator

Warning Buzzer

- *1: The master warning  in the instrument cluster blinks. At the same time, the message will be shown on the information display to inform the driver of the vehicle condition and the remedy.
- *2: The message will be shown on the information display to inform the driver of the vehicle condition and the remedy.

For All model

When	Warning buzzer	Instrument cluster	Cause and remedy
When one of the doors is opened	Interior buzzer • Beeping at short intervals for approx. 10 seconds	 Blinks every 2 seconds	The security system warning is being activated. You can stop the warning by either of the following operations: • Unlock the doors using the keyless push start system remote controller or the request switch. • Press the engine switch to change the ignition mode to ON.
When the engine switch is pressed to change the ignition mode to ON	Interior buzzer • Beeping 4 times	 Blinks rapidly for approx. 8 seconds	Indicates that a security system has been activated while the vehicle has been parked; check the vehicle to make sure that it is not broken into or nothing is stolen.
	Interior buzzer • Chime (once)	*1	The steering wheel lock has not been released. With load not applied, turn the steering wheel to the left or right so as to press the engine switch again.
When stopping or backing up the vehicle	Interior buzzer • Short beeps at long intervals, short beeps at short intervals, short beeps at very short intervals, or continuous beep	—	Rear parking sensors detect an obstacle on the rear side of the vehicle. Check the surrounding area directly with your eyes and the mirrors, and back up the vehicle slowly.

QUICK GUIDE

When	Warning buzzer	Instrument cluster	Cause and remedy
When the engine switch is in ON mode	Interior buzzer	 Lights up	The brake fluid is insufficient or the brake system may be faulty. Consult with a Maruti Suzuki authorized workshop.
	• Chime (once)		
	Interior buzzer	 Lights up	The fuel level is low. Refuel soon.
	• Chime (once)		

When	Warning buzzer	Instrument cluster	Cause and remedy
When driving	Interior buzzer • Beeping at short intervals for approx. 95 seconds	 Blinks *1	The driver does not wear his/her seat belt. Stop the vehicle in a safe place and wear your seat belt. The front or rear passenger(s) does not wear his/her seat belt. Wear the seat belt.
	Interior buzzer • Beeping at short intervals for approx. 35 seconds	 REAR L [] [] R Blinks *1	
		 L [] [] R Blinks *1	
	Interior buzzer • 3 beeps repeating at short intervals	 Lights up *1	The parking brake has not been released. Stop the vehicle in a safe place and release the parking brake.
When driving	Interior buzzer • Chime (once)	 Lights up *1	One of the doors is not completely closed. Stop the vehicle in a safe place and close all doors completely.

QUICK GUIDE

When	Warning buzzer	Instrument cluster	Cause and remedy
When opening the driver's door	Interior buzzer • Continuous beep	 Lights up *1	The headlights and/or the position lights are left on. Turn them off.
When stopping or reversing the vehicle	Interior buzzer • Beeping at short intervals	 or  Indicates	The gearshift lever is in "R" (Reverse) position. Check the gearshift lever position.
When the engine is stopped automatically by the ENG A-STOP system (if equipped)	Interior buzzer • 1 Beeps	*2	The engine has restarted automatically because either of the following conditions occurred. <ul style="list-style-type: none"> The difference between the set temperature of the air conditioner and the interior air temperature became big. The defroster is turned on. Brake booster vacuum pressure is low. The battery continues to be discharged. 3 minutes passed after the engine is automatically stopped by the ENG A-STOP system. The temperature selector was greatly set toward cool while cooling or greatly set toward hot while heating.

For Manual Transmission models

When	Warning buzzer	Instrument cluster	Cause and remedy
When the engine switch is pressed to change the ignition mode to LOCK (OFF)	Interior buzzer • Chime (once)	*1	You cannot change the ignition mode to LOCK (OFF) because there may be malfunction of the gearshift lever. Consult with a Maruti Suzuki authorized workshop.
When the engine is stopped automatically by the ENG A-STOP system (if equipped)	Interior buzzer • 2 Beeps	—	The engine stalled because the hood is opened after the engine is stopped automatically. To restart the engine, follow the procedure below. 1) Set the parking brake firmly, and then shift into "N" (Neutral). 2) Securely close the engine hood. 3) Turn the ignition switch or press the engine switch to restart the engine.
When the engine is stopped automatically by the ENG A-STOP system (if equipped)	Interior buzzer • 2 Beeps	—	The gearshift lever is in a position other than "N" (Neutral). Place the gearshift lever in "N" (Neutral) position.
	Interior buzzer • 5 beeps	 and  Lights up	The engine stalled because the following operations were performed. • The driver's seat belt is unfastened. • The driver's door is opened. Unbuckle the driver's seat belt & open the driver's door to stop the engine

QUICK GUIDE

When	Warning buzzer	Instrument cluster	Cause and remedy
When the engine is stopped automatically by the ENG A-STOP system (if equipped)	Interior buzzer • 2 Beeps	 Lights up	The driver's seat belt is unfastened. You can restart the engine by depressing the clutch pedal when the seat belt is fastened.

For Automatic Transmission models

When	Warning buzzer	Instrument cluster	Cause and remedy
When the engine is stopped automatically by the ENG A-STOP system (if equipped)	Interior buzzer • 1 Beeps	 *2	<p>The engine has restarted automatically because either of the following conditions occurred.</p> <ul style="list-style-type: none"> • The difference between the set temperature of the air conditioner and the interior air temperature became big. • The defroster is turned on. • Brake booster vacuum pressure is low. • The battery continues to be discharged. • 3 minutes passed after the engine is automatically stopped by the ENG A-STOP system. • The temperature selector was greatly set toward cool while cooling or greatly set toward hot while heating.
	Interior buzzer • 10 beeps		<p>The engine has restarted automatically because either of the following operations was performed.</p> <ul style="list-style-type: none"> • The driver's seat belt is unfastened. • The driver's door is opened. <p>Before driving, close the door and buckle the seat belt. In addition, before getting out of the vehicle, follow the procedure below.</p> <ol style="list-style-type: none"> 1) Set the parking brake firmly, and then place the gearshift lever in the "P" position. 2) When the vehicle will be stopped for a long time or when you will leave the vehicle unattended, press the engine switch to stop the engine.

When	Warning buzzer	Instrument cluster	Cause and remedy
When using the shift paddle	Interior buzzer • 2 beeps at short intervals	–	The gear position is not set in the desired position by operating the paddle shift switch. Select the proper gear position for the vehicle speed.
When the engine is stopped automatically by the ENG A-STOP system (if equipped)	Interior buzzer • 2 Beeps	–	The engine stalled because the hood is opened after the engine is stopped automatically. To restart the engine, follow the procedure below. 1) Set the parking brake firmly, and then place the gearshift lever in the "P" position. 2) Securely close the engine hood. 3) Press the engine switch to restart the engine.

For Auto Gear Shift Model

When	Warning buzzer	Instrument cluster	Cause and remedy
When the engine is stopped automatically by the ENG A-STOP system (if equipped)	Interior buzzer • 5 beeps	 or  Lights up *2	<p>The engine has restarted automatically because either of the following operations was performed.</p> <ul style="list-style-type: none"> • The driver's seat belt is unfastened. • The driver's door is opened. <p>Before driving, close the door and buckle the seat belt. In addition, before getting out of the vehicle, follow the procedure below.</p> <ol style="list-style-type: none"> 1) Set the parking brake firmly, and then place the gearshift lever in the "N" position. 2) When the vehicle will be stopped for a long time or when you will leave the vehicle unattended, turn the ignition switch to stop the engine.

QUICK GUIDE

For Vehicle Without Keyless Push Start System

When	Warning buzzer	Instrument cluster	Cause and remedy
When opening the driver's door	Interior buzzer • Continuous beep	–	The ignition key is in the ignition switch. Remove the ignition key from the ignition switch.

For Vehicle With Keyless Push Start System

When	Warning buzzer	Instrument cluster	Cause and remedy
When the engine switch is pressed to change the ignition mode to ON	Interior buzzer • Beeping once	 Blinks every 1 second *1	There may be a problem with the keyless push start system. Ask your Maruti Suzuki authorized workshop for inspection.
When the engine switch operated	Interior buzzer • Beeping twice	 Lights up *1	The remote controller may be outside the vehicle or its battery may have become discharged. Bring the remote controller in the vehicle or touch the engine switch with the remote controller.
When the engine switch is pressed to change the ignition mode to ON or ACC	Exterior and/or interior buzzers • 5 beeps repeating at short intervals Interior buzzer • Chime (once)	 Blinks *1	When the engine switch was pressed to change the ignition mode to ON or ACC, the remote controller was detected. However, when starting the engine, the remote controller was not detected. Place the remote controller in the interior workable area and then press the engine switch again.

When	Warning buzzer	Instrument cluster	Cause and remedy
When one of the door is opened or closed	Exterior and/or interior buzzers • 5 beeps repeating at short intervals		The remote controller may be outside the vehicle. Bring the remote controller in the vehicle.
When opening the driver's door	Interior buzzer • Beeping at short intervals	—	Press the engine switch to change the ignition mode from ACC to LOCK (OFF).
	Interior buzzer • Continuous short beeps	—	The steering lock fails to engage due to a fault in the system when the ignition mode is turned to LOCK (OFF) by pressing the engine switch. Have the vehicle inspected by a Maruti Suzuki authorized workshop.
When pushing the request switch	Exterior buzzer • Beeping at short intervals for approx. 2 seconds	— — 	The engine switch is in ACC or ON mode. Press the engine switch to change the ignition mode to LOCK (OFF). The remote controller is left inside the vehicle. Take the remote controller outside the vehicle. Any door (including the tailgate) is open. Close all doors completely
When pushing LOCK button on the remote controller	Exterior buzzer • Beeping at short intervals for approx. 2 seconds		Any door (including the tailgate) is open. Close all doors completely

FOR SAFE DRIVING




59RN02300

Driver's Seat Floor	2-1
Seat Belts and Child Restraint Systems	2-2
Front Seats	2-5
Tilt / Telescoping (if equipped) Steering Lock Lever	2-7
Mirrors	2-8
Rear Seats	2-13
Seat Utility	2-14
Safety for Child	2-16
Seat Belt	2-19
Handling and Care for Seat Belt	2-24
Seat Belt Pretensioner System (Only for Front Seat)	2-26
Seat Belt Force Limiter System (Only for Front Seat)	2-27
Child Restraint Systems	2-28
Supplemental Restraint System (Airbags)	2-36
When Driving the Vehicle with SRS Airbag System	2-38
Handling for Airbags	2-42
Function of Airbags	2-44
When Starting the Engine	2-52
When Loading the Luggage	2-53

FOR SAFE DRIVING

Driver's Seat Floor Floor Mats

Example for genuine floor mat



55T020010

To prevent the driver's side floor mat from sliding forward and possibly interfering with the operation of the pedals, Maruti Suzuki genuine floor mats are recommended.

Whenever you put the driver's side floor mat back in the vehicle after it has been removed, hook the floor mat grommets to the fasteners and position the floor mat properly in the footwell.

When you replace the floor mats in your vehicle with a different type such as all-weather floor mats, we highly recommend to use Maruti Suzuki genuine floor mats for proper fitting.

⚠ WARNING

Failure to take the following precautions may result in the driver's side floor mat interfering with the pedals and causing a loss of vehicle control or an accident.

- Check that the floor mat grommets are hooked to the fasteners.
- Never stack floor mats.
- Never use a floor mat which does not fit the floor as the same may cause hindrance/damage in vehicle and its functioning.
- Never use damaged floor mats.

Clearing the Floor




69RHS157

⚠ WARNING

Do not leave empty cans, etc. at your feet. These objects may interfere with pedal operation and cause accidents.

Seat Belts and Child Restraint Systems



59RN02300

⚠ WARNING


- Wear your seat belts at all times.
- An airbag supplements or adds to the frontal collision protection offered by seat belts. The driver and all passengers must be properly restrained by wearing seat belts at all times, even if driving for a very short distance, whether or not an airbag is mounted at their seating position, to minimize the risk of severe injury or death in the event of a collision.

(Continued)


⚠ WARNING

(Continued)

- Do not modify, remove, disassemble seat belts. Doing so may prevent them from functioning properly and cause the risk of severe injury or death in the event of a collision.



59RN02390



59RN02400



59RN02380

FOR SAFE DRIVING

⚠ WARNING

- Never allow persons to ride in the cargo area of a vehicle. In the event of an accident, there is a much greater risk of injury for persons who are not riding in a seat with their seat belt securely fastened.
- Ensure that all seat belts are worn correctly. An improperly worn seat belt increases the risk of injury or death if a collision occurs.
- Seat belts should always be adjusted as follows:
 - the lap portion of the belt should be worn low across the pelvis, not across the waist.
 - the shoulder straps should be worn on the outside shoulder only, and never under the arm.
 - the shoulder straps should be away from your face and neck, but not falling off your shoulder.
- Seat belts should never be worn with the straps twisted and should be adjusted as tightly as is comfortable to provide the protection for which they have been designed. A slack belt will provide less protection than a snug belt.

(Continued)

⚠ WARNING

(Continued)

- Check that seat belt latch plate (tongue) is inserted into the proper buckle especially in the rear seats. It is not possible to insert into the wrong buckles in the rear seats.
- Pregnant women should use seat belts, although specific recommendations about driving should be made by the woman's medical advisor. Remember that the lap portion of the belt should be worn as low as possible across the hips, as shown in the illustration.
- Do not wear seat belts over hard, fragile, or sharp items such as pens, keys, eyeglasses, etc in pockets or on clothing. The pressure from seat belt on such items can cause injury in case of an accident.



59RN02440

(Continued)

⚠ WARNING

(Continued)

- Do not hold a child on a passenger's lap. Even if the passenger holds the child tightly, he/she would not be supported enough in the event of an accident and it could result in a serious injury of the child.
- Never use the same seat belt for more than one occupant and never attach a seat belt over an infant or child being held on an occupant's lap. Such seat belt use could cause serious injury in the event of an accident.
- Periodically inspect seat belt assemblies for excessive wear and damage. Seat belts should be replaced if webbing becomes frayed, contaminated or damaged in any way. It is essential to replace the entire seat belt assembly after it has been worn in a severe impact, even if damage to the assembly is not obvious.
- Children aged 12 and under should ride properly restrained in the rear seat.

(Continued)

⚠ WARNING

(Continued)

- Infants and small children should never be transported unless they are properly restrained. Restraint systems for infants and small children can be purchased locally and should be used. Check that the system you purchase meets applicable safety standards. Read and follow all the directions provided by the manufacturer.
- For child, if the seat belt irritates the neck or face, use a child restraint system appropriately for the child. The seat belts of your vehicle are principally designed for persons of adult size.
- Avoid contamination of seat belt webbing by polishes, oils, chemicals, and particularly battery acid. Cleaning may safely be carried out using mild soap and water.
- Do not insert any items such as coins and clips into the seat belt buckles, and be careful not to spill liquids into these parts. If foreign materials get into a seat belt buckle, the seat belt may not work properly.
- All seatbacks should always be in an upright position when driving, or seat belt effectiveness may be reduced. Seat belts are designed to offer maximum protection when seatbacks are in the upright position.

Adjustment before Driving

80J014

Correct Use of Seat Belt


69RHS158

⚠ WARNING

- When driving, do not adjust the steering wheel (only adjustable type with certain specifications), the seat, the inside rearview mirror or the outside rearview mirrors. Otherwise, there is the risk of mistaken operation of the steering wheel or reduced awareness of what is in front of you, possibly leading to an accident.
- Do not tilt the seatback further back than necessary. Otherwise, the head restraint and the seat belt cannot function as intended.

- Adjust the seat to the correct position. Sit your body fully into the seat.
- Make sure that the seat belt is not twisted.
- Make sure that you place the lap portion of the belt as low as possible across the pelvis.
- The upper belt should rest on the area midway between the shoulder and the base of the neck.
- Confirm that the belt is not twisted in any way, and remove any slack.

FOR SAFE DRIVING



77R20050

⚠ WARNING

- If you do not fasten your seat belt properly, your body may not be restrained in a sudden braking and a collision. This may cause severe injury.
Fasten your seat belt properly before driving.
- If all the passengers do not fasten their seat belts properly, their body may not be restrained in a sudden braking and a collision. This may cause severe injury.
Ask all the passengers on the front passenger's seat and the rear seats to fasten their seat belts properly before driving.

Front Seats Seat Adjustment

⚠ WARNING

- Never attempt to adjust the driver's seat or seatback while driving. The seat or seatback could move unexpectedly, causing loss of control. Check that the driver's seat and seatback are properly adjusted before you start driving.
- To avoid excessive seat belt slack, which reduces the effectiveness of the seat belts as a safety device, check that the seats are adjusted before the seat belts are fastened.
- All seatbacks should always be in an upright position when driving, or seat belt effectiveness may be reduced. Seat belts are designed to offer maximum protection when seatbacks are in the upright position.

(Continued)


⚠ WARNING

(Continued)

- If you place a cushion, etc. between the seatback and your back, you may not be able to drive the vehicle in a correct posture. Also, the seat belt and the head restraint may not provide the best performance. This may cause severe injury in an accident.

Do not place a cushion, etc. between the seatback and your back.


- Do not place any object under the front seat. If an object gets stuck under the front seat, the seat shall not be latched properly and may cause injury.
- Do not leave cigarette lighters or spray cans on the floor. If a cigarette lighter or spray can is on the floor, it may light accidentally when luggage is loaded or the seat is adjusted, causing a fire.



55T020160

Seat position adjustment lever (1)


Pull the lever up and slide the seat.



55T020170

Seatback angle adjustment lever (2)

Pull the lever up and move the seatback.



55T020180

Seat height adjustment lever (3) (if equipped)


Pull the lever up to raise the seat. Push the lever down to lower the seat.

After adjustment, move the seat and seatback back and forth to check if it is securely latched.

NOTE:

To operate the seat back smoothly, pull the seat back adjustment lever (2) in upward direction. Ensure to move seat back only after lever is moved to fully up position. After adjustment of seat back, release the lever gently. Check that seat back is locked by moving it forward and backward.

Head Restraints



80J001

Head restraints are designed to help reduce the risk of neck injuries in the case of an accident. Adjust the head restraint to the position which places the center of the head restraint closest to the top of your ears. If this is not possible for very tall passengers, adjust the head restraint as high as possible.


FOR SAFE DRIVING

⚠ WARNING

- If you drive the vehicle with the head restraint removed, a passenger's backward tilting cannot be prevented in a collision from the backward and the impact to a passenger's head cannot be reduced in a sudden braking or a collision. This may cause severe injury. Never drive the vehicle with the head restraints removed.
- If the head restraint is installed back to front or it is not installed securely, the head restraint may not provide the best performance in case of emergency, resulting in severe injury.
If the head restraint is installed back to front, you cannot adjust the height and install it securely. Make sure to install the head restraint securely in the right direction.
- Being distracted by head restraint adjustment could lead to an accident.
Do not attempt to adjust the head restraint while driving.

NOTE:

It may be necessary to recline the seat-back to provide enough overhead clearance to remove the head restraint.



55T020190

To raise the front head restraint, pull upward the head restraint until it clicks. To lower the head restraint, push down the head restraint while holding in the lock button (1). If a head restraint must be removed (for cleaning, replacement, etc.), push in the lock button (1) and pull the head restraint all the way out.

Tilt / Telescoping (if equipped) Steering Lock Lever



55TB0201

- (1) LOCK
- (2) UNLOCK

The lock lever is located under the steering column. To adjust the steering wheel height:

- 1) Push down the lock lever to unlock the steering column.
- 2) Adjust the steering wheel to the desired height and fore-aft position and lock the steering column by pulling up the lock lever.
- 3) Try moving the steering wheel up and down back and forth to check that it is securely locked in position.

⚠ WARNING


Never attempt to adjust the steering wheel while the vehicle is moving or you could lose control of the vehicle.

Mirrors

⚠ WARNING

Failure to observe following point may result in loss of vehicle control and cause an accident, leading to death or serious injury. Always follow below points while driving.


- Always unfold all the outside rear-view mirrors and adjust properly before driving.
- Do not place objects in the rear of the vehicle which may hinder visibility or interfere with your vision from the rear window glass.



83S02352

- (1) Night driving
- (2) Day driving
- (3) Selector tab

Inside Rearview Mirror



81M30360

You can adjust the inside rearview mirror by hand to see the rear of your vehicle in the mirror. To adjust the mirror, set the selector tab (3) to the day position, then move the mirror up, down or sideways by hand to obtain the best view.

When driving at night, you can move the selector tab (3) to the night position to reduce glare from the headlights of vehicles behind you.

⚠ WARNING

- If you adjust the inside rearview mirror while driving, you could lose control of the vehicle, resulting in an accident.

Adjust the inside rearview mirror before driving.


- Only use the night position if it is necessary to reduce glare from the headlights of vehicles behind you. Be aware that in this position you may not be able to see some objects that could be seen in the day position.

⚠ CAUTION

Do not modify the inside rearview mirror or install a non-genuine wide mirror. It could result in injury during accident.

FOR SAFE DRIVING


Auto Dimming Rearview Mirror (if equipped)



You can adjust the auto dimming rearview mirror by hand so you can see to the rear of your vehicle in the mirror. This rearview mirror has a function of automatically reducing glare from the lights of vehicles behind you. The function works when the ignition mode has been changed to "ON" by pressing the engine switch.

- The mirror is always set to the automatic dimming mode when the ignition mode is "ON".
- When the switch (2) is pushed, the green indicator (1) is lit, indicating that the mirror is set to the automatic dimming mode. To cancel the automatic dimming mode, push the switch (2); the indicator (1) then goes out.

- The auto dimming rearview mirror is automatically deactivated while the gear-shift lever is in the "R" position.



CAUTION

The electrolyte may come out when the mirror is broken. Do not allow it to come into contact with your skin or eyes. If it accidentally comes in contact with eyes or skin, flush with water and consult a doctor immediately.

NOTICE

Do not hook anything heavy on the mirror, or the mirror may break under the weight.

NOTE:

Auto dimming system may not work in any of the following cases:

- Light from the rear is not directly focused to the sensor (3).
- Rear window glass is not transparent enough or is dark tinted glass.

WARNING

Do not touch or cover the sensor (3) since this may impair normal operation of the system. Blocking glare from the sensor with an object such as a shade, sticker, accessory or baggage may also impair proper operation of the system.

Outside Rearview Mirrors

Adjust the outside rearview mirrors so you can just see the side of your vehicle in the mirrors.

⚠ WARNING

If you adjust the outside rearview mirrors while driving, you could lose control of the vehicle, resulting in an accident.

Adjust the outside rearview mirrors before driving.


Manual mirrors (if equipped)



55T020220

You can adjust the outside rearview mirrors by hand so as to see the sides of your vehicle in the mirrors.

Electric mirrors (if equipped)



The switch to control the electric mirrors is located on the driver's door panel. You can adjust the mirrors when the ignition switch is in "ACC" or "ON" position, or the ignition mode is ACC or ON. To adjust the mirrors:


- 1) Move the selector switch (1) to the left or right to select the mirror you wish to adjust.
- 2) Press the outer part of the switch (2) that corresponds to the direction in which you wish to move the mirror.
- 3) Return the selector switch (1) to the center position to help prevent unintended adjustment.

NOTICE


- The electric type outside rearview mirror operates even though the ignition switch is in the ACC position. However, to prevent unnecessary battery discharge, do not adjust the mirrors longer than necessary while the engine is not running.
- The mirrors stop moving when they reach the maximum adjusting angles, but the motor continues to operate while the switch is pressed. Do not continue to press the switch in such a situation as the motor may be damaged.
- Do not attempt to adjust the outside rearview mirror by hand which may cause damage to the motor.
- Do not fold the electrical foldable outside rearview mirror by hand. It could cause motor failure.

FOR SAFE DRIVING

Outside Rearview Mirror Folding Switch (if equipped)



55TB020250



74TB02002

You can fold the mirrors when you park the vehicle in a narrow space. Push the folding switch to fold and unfold the mirrors. Make sure the mirrors are completely unfolded before you start driving.

⚠ WARNING

If you drive the vehicle with the outside rearview mirrors folded, it may result in an accident.

Do not drive the vehicle with the outside rearview mirrors folded.

⚠ CAUTION

Moving mirrors can pinch and injure a hand. Do not allow anyone's hand to get near the mirrors when folding and unfolding the mirrors.

NOTE:

- If you press the folding switch to open the outside rearview mirrors and simultaneously start the engine, then the outside rearview mirrors may get stuck during that moment. To open the outside rearview mirrors completely, again press the folding switch after starting the engine.
- Slight time difference in opening of both outside rearview mirrors is due to angular positioning of the driver seat.

Remote Folding Mirrors (if equipped)

When the outside rearview mirror folding switch is in the unfolded position, the outside rearview mirrors are folded or unfolded in conjunction with the door locking or engine switch operation.

- When you lock the doors (including the tailgate) by using the remote controller or pushing the request switch, the mirrors will be folded automatically.
- To unfold the mirrors, push the engine switch to change the ignition mode to ACC or ON.
- The factory setting is that the function is enabled. You can switch the function from enabled to disabled, and vice versa. To switch the function for your preference, refer to "How to switch the remote folding mirror function" in this section.

NOTICE

In a cold winter such as the mirrors are frozen, disable the function. If the mirrors are folded and unfolded repeatedly without thawing, the mirrors may be damaged.

NOTE:

- If the doors are locked by using the key or lock knob, the mirrors will not be folded automatically.
- If the outside rearview mirror folding switch is in the folded position, the mir-


rors will not be unfolded automatically, even when the engine switch is pushed to change the ignition mode to ACC or ON.

- If any of the doors is not opened within about 30 seconds after the doors are unlocked by using the keyless push start system remote controller or request switch, the doors will be locked again and the mirrors will be folded automatically.

How to switch the remote folding mirror function

When the ignition mode is LOCK (OFF), you can switch the function from the enabled state to the disabled state, and vice versa, using the following method.

- Sit in the driver's seat and make sure that all doors are closed.
 - If any door is open, the open door warning light comes on.




74TB02003

- Turn the lock knob (1) on the driver's door rearward (2).


NOTE:

All operations included in the following steps 3) and 4) must be completed within 15 seconds.



74TB02004

- Turn the lock knob (1) on the driver's door forward (3) to lock the doors, and then turn rearward (2) to unlock the doors. Repeat this operation 4 times.



59RN02110

- Push any of the buttons on the keyless push start system remote controller 3 times.
 - Push any buttons described above you like.
 - During operation, the doors are not locked, unlocked, opened or closed.

Every time you perform the series of the above steps, the state of the remote folding mirror function changes from the currently selected one to the other. You can check whether the system is enabled or disabled by the number of interior buzzer beeps at the end of the procedure as follows.

FOR SAFE DRIVING

System state	Number of beeps
Disabled	Once 
Enabled	Twice

- If you cannot complete the operations in step 3) and 4) within 15 seconds correctly, the state of the remote folding mirror function will not change and the interior buzzer does not beep. Perform the procedure again from the beginning.

Rear Seats

Head Restraints (if equipped)

Head restraints are designed to help reduce the risk of neck injuries in the case of an accident.

⚠ WARNING

- If you drive the vehicle with the head restraint removed, a passenger's backward tilting cannot be prevented in a collision from the backward and the impact to a passenger's head cannot be reduced in a sudden braking or a collision. This may cause severe injury. Never drive the vehicle with the head restraints removed.
- If the head restraint is installed back to front or it is not installed securely, the head restraint may not provide the best performance in case of emergency, resulting in severe injury. If the head restraint is installed back to front, you cannot adjust the height and install it securely. Make sure to install the head restraint securely in the right direction.

(Continued)

⚠ WARNING

(Continued)

- Being distracted by head restraint adjustment could lead to an accident.

Do not attempt to adjust the head restraint while driving.

- If you try to install a child restraint system and it touches the head restraint, a child may be severely injured in a collision.

When you install a child restraint system, adjust the height of the head restraint as high as possible or remove the head restraint for avoiding that the child restraint system touches the head restraint.


⚠ CAUTION

If you leave the removed head restraint in the vehicle, it may jump out and hit passengers or objects, resulting in injury or damage.


Do not leave the removed head restraint in the vehicle.

NOTE:

It may be necessary to fold forward the seatback to provide enough overhead clearance to remove the head restraint.



55TB0207




55TB0208

To raise the rear head restraint, pull up the head restraint until it clicks. To lower the head restraint, push down the head restraint while holding in the lock button (1). If a head restraint must be removed

(for cleaning, replacement, etc.), push in the lock button (1) and pull the head restraint all the way out.

When installing a child restraint system, adjust the height of the head restraint or remove it for fitting the child restraint system, as necessary.

Rear center head restraint



55TB0209

When using the rear center head restraint, pull it up and lock it securely before driving.

WARNING

Do not allow anyone to sit in the rear center seat with the rear center head restraint removed or in stowed position.


Seat Utility

Folding Rear Seats

The rear seats of your vehicle can be folded forward to provide additional cargo space.

To fold the rear seats forward:

- 1) Lower the head restraint fully.




55TB02010

- 2) Hook the webbing of the outboard lap-shoulder belts in the belt hangers.

FOR SAFE DRIVING

NOTICE

- When you move a seatback, make sure the belt webbing is hooked in the seat belt hangers so the seat belts are not caught by the seatback, seat hinge, or seat latch. This helps prevent damage to the belt system.
- Make sure the belt webbing is not twisted.



- Slide the release lever on the top of each split seat in arrow direction, and fold the seatbacks forward.

NOTICE

After folding the rear seatback forward, do not allow any foreign material to enter the lock opening. This may cause damage to the inside of the lock and prevent the seatback from being locked securely.

WARNING

If you need to carry cargo in the passenger compartment with the rear seatback folded forward, secure the cargo or it may be thrown about, causing injury. Never pile cargo higher than the seatbacks.


To return the seat to the normal position, follow the procedure below.

CAUTION

When returning the rear seatback to the normal position, be careful that your finger is not caught between the lock and the striker.

NOTICE

When you move a seatback, make sure the belt webbing is hooked in the seat belt hangers so the seat belts are not caught by the seatback, seat hinge, or seat latch. This helps prevent damage to the belt system.



55TB02012

Raise the seatback until it locks into place.

After returning the seat, move the seatback back and forth to check if it is securely latched.

CAUTION

Do not put your hand into the rear seatback lock opening, or your finger may get caught and be injured.

CAUTION

After securing the rear seatback, check that it is locked securely. If it is not, red will appear in the release lever.

NOTICE

- When returning the rear seatback to the normal position, do not allow any foreign material to enter the lock opening. This may prevent the seatback from being locked securely.
- When returning the rear seatback to the normal position, handle it carefully by hand to avoid any damage to the lock itself. Do not push it by using some material or by applying excessive force.
- As the lock is designed exclusively for securing the rear seatback, do not use it for any other purpose. Incorrect use of it may cause damage to the inside of the lock and prevent the seatback from being locked securely.

Safety for Child

For safety, carefully drive at lower speed than usual.

Place a Child in the Rear Seat

51K0188

- Seat a child next to an adult when possible, and ensure that the child can be visually monitored.
- Select an appropriate child restraint system suitable for the child's age and physical size.

WARNING

- If you do not use the child-proof lock, a child may open a door and the child may be thrown out, resulting in severe injury. To avoid this, use the child-proof lock setting.
- When it is necessary to seat the child who does not need a child restraint system in the front passenger's seat, observe the following point.
 - Slide the front passenger's seat all the way back. If the front passenger's seat is in a forward position, there is a risk of serious injury due to major impact if the front passenger's seat airbag was to be deployed.

(Continued)

FOR SAFE DRIVING

⚠ WARNING

(Continued)



59RN04650

- If a child put a hand out of the window or lean on a door, the child may get severe injury by a strong impact of side or curtain airbag activation.
Do not allow a child to put hand out of the window or lean on a door.
- Do not allow the hands or feet, etc., of a child near movable parts inside a vehicle, such as the armrests and the seat rails. Otherwise, there is the possibility of injury.

A Child Needs to Wear Seat Belt



69RHS159



69RHS160

⚠ WARNING

- Do not drive with a child on your lap. Even if you hold the child tightly, proper support is not possible, and in the event of a collision, etc., the child may get serious injury.
- If a child does not wear a seat belt, in a sudden braking and a collision, the child may get serious injury. Be sure to always have a child wear a seat belt.
- If two or more people use a single seat belt, in a sudden braking and a collision, the seat belt may not provide the best performance, resulting in severe injury.

Do not allow two or more people to use a single seat belt.

⚠ WARNING

- The seat belts of this vehicle are designed to be suitable for occupants of adult size. If the shoulder strap rests on the neck or chin of a child rather than the shoulder, or if the lap portion of the belt does not rest securely on the hipbone, ensure that the child is seated in a child restraint system placed in the rear seat. Failure to properly use a seat belt may result in serious injury to the child.
- Use a child restraint system securely fastened to the rear seat for any child that cannot hold their head upright or sit on their own.

Do not Let a Child Play with Seat Belt

69RHS161

⚠ WARNING

If a child play with a seat belt, for example, if the child's body is wrapped by the seat belt, it may cause severe injury such as suffocation. In case of emergency, cut the seat belt with scissors.

Using the Child Restraint System

Refer to "Securing Child Restraint System by Seat Belt" in this section.

An Adult Needs to Open or Close Each Door or Window, and Adjust Seats

Only an adult should open or close each door or window and adjust seats, not to get a child's hands, arms, legs or neck, etc. caught in.



69RHS162

⚠ WARNING

- If the windows are not locked, a child may operate the windows by mistake or the other passengers may be caught in the windows. To avoid unintended operation of the power window by a child, use the window lock switch.

(Continued)

⚠ WARNING

(Continued)

- If you leave the power window in ready condition, it may cause unintended operation of the power window by a child, resulting in an accident.

When you leave the vehicle, make sure to press the engine switch to change the ignition mode to OFF or turn the ignition switch to "OFF" position, keep the key with you and leave the vehicle with your child.

Do not Let a Child Stick His/her Head or Hands out of the Window

69RHS163

FOR SAFE DRIVING

⚠ WARNING

Ensure that a child does not put their hands or heads, etc., out the windows. Otherwise, serious injuries due to falling out or sudden braking may occur. Moreover, serious injury could also occur if a child were to come into contact with objects outside the vehicle.

Do not Leave a Child Unattended in the Vehicle




69RHS164

⚠ WARNING

When getting out of the vehicle, do not allow a child to stay in the vehicle without you.

- Unintended and wrong operations by a child may cause a fire or an accident from the vehicle start.
- As the inside temperature of the vehicle will become hot under the blazing sun, a child may suffer from heat stroke or dehydration, resulting in severe health problems or death in the worst case. Even if you turn on the air conditioner, do not leave a child alone in the vehicle.

Do not Place a Child in Luggage Compartment



69RHS165

⚠ WARNING

The luggage areas do not feature a structure that can accommodate people. Do not allow a child to ride in such areas. Otherwise, there is the danger of accidents due to sudden braking, etc. Do not let a child play in luggage areas even while the vehicle is stopped on the road.

Seat Belt

A Child Needs to Wear Seat Belt

Refer to "Safety for Child" in this section.

Information for Pregnant Woman and the Sick Person





69RHS166

⚠ WARNING


- Those that are pregnant or sick/disabled must also wear their seat belts. However, in the event of a collision, there is the danger of heavy pressure focused on certain body areas. Consultation with a physician is recommended.
- For those that are pregnant, ensure that the lap portion of the belt is as low as possible across the pelvis, avoiding to touch the abdomen. Make sure that the shoulder strap rests halfway between the shoulder and the base of the neck, crossing the chest and avoiding to touch the abdomen.

Lap-shoulder Belt**Emergency locking retractor (ELR)**

The seat belt has an emergency locking retractor (ELR), which is designed to lock the seat belt only during a sudden stop or impact. It also may lock if you pull the belt across your body very quickly. If this happens, let the belt go back to unlock it, and then pull the belt across your body more slowly.

Safety reminder


upward through the latch plate. The length of the diagonal shoulder strap adjusts itself to allow freedom of movement.



To fasten the seat belt, sit up straight and far back into the seat, pull the latch plate attached to the seat belt across your body and press it straight into the buckle until you hear a click. After pressing the latch plate into the buckle, pull the seat belt to make sure it is securely latched. After pressing the latch plate into the buckle, pull the seat belt to make sure it is securely latched.

To reduce the risk of sliding under the belt during a collision, position the lap portion of the belt across your lap as low on your hips as possible and adjust it to a snug fit by pulling the shoulder portion of the belt

FOR SAFE DRIVING



59RN02340

To unfasten the seat belt, push the red "PRESS" button on the buckle and retract the belt slowly while holding the belt or/and the latch plate.

NOTE:

If the seat belt cannot be pulled from its fully retracted position, firmly pull the belt and release it. Then smoothly pull the belt out of the retractor.

Adjustment of Seat Belt Length

The seat belt does not require length adjustment. The seat belt extends and retracts according to the movement of the body. If the seat belt gets a strong impact, the belt locks its tension automatically, in order to secure the body.

Correct Use of Seat Belt


⚠ WARNING

Use the seat belt correctly. Otherwise, in a sudden braking or a collision, the body may not be restrained, resulting in severe injury. Observe the following points.

- If the seat belt is twisted or contains excessive slack, there is a danger of heavy pressure focused on certain body areas.
- If the seat belt rests on the abdomen, this area may sustain heavy pressure when you get a strong impact.
- If the seat belt does not rest firmly over the shoulder, you may be thrown forward when you get a strong impact.


Seat Belt Reminder

Type A



74TB02010

Type B



74TB02011

- 1) Driver's seat belt reminder light / front passenger's seat belt reminder light.
- 2) Rear passenger's seat belt reminder light (rear left)
- 3) Rear passenger's seat belt reminder light (rear center)
- 4) Rear passenger's seat belt reminder light (rear right)

For more details, refer to the explanation below.

WARNING

It is absolutely essential that the driver, front passenger and rear passenger fasten their seat belts at all times. Persons who are not fastening seat belts have a much greater risk of injury if an accident occurs. Make a regular habit of buckling your seat belt before starting the engine.

NOTE:

- Along with the seat belt reminder light, a reminder message shall also come on the information display (if equipped), for un-restrained driver and/or front passenger.
- The driver's seat belt reminder light / front passenger's seat belt reminder light is for both the driver and front passenger.

FOR SAFE DRIVING

Driver's seat belt reminder

If the driver's seat belt remains unbuckled when the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, the reminder works as follows:


- 1) The driver's seat belt reminder light will come on. The front passenger's seat belt reminder light will also come on if a front passenger does not fasten his/her seat belt.
- 2) After the vehicle's speed has reached about 15 km/h, the driver's seat belt reminder light will blink and a buzzer will sound for about 95 seconds.
- 3) The reminder light will remain on until the driver's seat belt is buckled.

If the driver has buckled his or her seat belt and later unbuckles the seat belt, the reminder system will be activated from Step 1) or 2) according to the vehicle's speed. When the vehicle's speed is less than 15 km/h, the reminder will start from Step 1). When the vehicle's speed is more than 15 km/h, the reminder will start from Step 2).

The reminder will be automatically canceled when the driver's seat belt is buckled or the ignition switch is turned to off, or the engine switch is pressed to change the ignition mode to LOCK (OFF).

Front passenger's seat belt reminder

If there is a person sitting in the front passenger seat and the front passenger seat belt is unbuckled when the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, the front passenger's seat belt reminder will activate.



69RH203

(2) The sensor of the front passenger's seat belt reminder

The seat belt reminder sensor (2) detects whether a person is sitting in the front seat. The sensor of the front passenger's seat belt reminder is located in the seat cushion. The front passenger's seat belt reminder works in the same manner as the driver's seat belt reminder.

NOTICE

- The sensor of the front passenger's seat belt reminder is located in the seat cushion. If heavy or sharp objects are put on the seat cushion, or a removal, disassembly and modification of the passenger's seat are performed, the sensor may not work properly or can be damaged. Do not put heavy or sharp objects on the seat cushion. Do not remove, disassemble and modify the passenger's seat.
- Depending on the variety of seat cover, operation of the sensor may be adversely affected. Maruti Suzuki highly recommends that you use Maruti Suzuki genuine seat cover exclusively for this vehicle. If a seat cover is installed, consult with Maruti Suzuki authorized workshop.
- If you spill liquid such as liquid aromatics, soft drinks or juice on the front passenger's seat cushion, the sensor of the front passenger's seat belt reminder located in the seat cushion can be damaged. Immediately wipe it dry with a soft cloth when spilled.

(Continued)

NOTICE

(Continued)

- When sitting on the front passenger's seat, it is very important that the passenger sits upright, leaning against the seat backrest and centered on the seat cushion in order for the seatbelt reminder system to function effectively. An occupant sitting improperly (slouches, turns sideways, sits forward or sideways) may hamper the functioning of this system as it may not detect the occupant.**

NOTE:

- If you put an object on the passenger's seat, the weight of the object will be sensed by the sensor and the front passenger's seat belt reminder light will come on and then the interior buzzer may beep.*
- If a child or a small sized person sit on the front passenger's seat or the cushion is put on the front passenger's seat, the weight will not be sensed by the sensor and the interior buzzer may not beep.*

Rear passenger's seat belt reminder

Reminder light in speedometer for rear passengers to fasten their seat belts.

Whether or not a passenger is seated, the rear seat belt reminder system works as follows, when ignition mode is turned ON:

- 1) Reminder light will turn ON for the non-buckled seats and continue for vehicle speed below 15km/h.
- 2) When vehicle speed is above 15km/h, reminder light will remain ON for the non-buckled seats for about 65 seconds and then turn OFF.
- 3) Further, when a buckled seat belt is unbuckled, the corresponding reminder light will turn ON. Above 15km/h, the reminder light will blink (about 65 seconds) along with a buzzer sound (about 35 seconds). The reminder light will remain ON until the seat belt is buckled.

If rear door is opened in vehicle stationary condition, then reminder system will start from step 1.

The reminder will be automatically canceled when all the rear seat belts are buckled or the ignition mode to LOCK (OFF).

Handling and Care for Seat Belt**Seat Belt Handling**

55T020330

Periodically check if the seat belts work properly and are not damaged. Check the webbing, buckles, latch plates, retractors, anchorages and guide loops. Replace any seat belts which do not work properly or are damaged.

FOR SAFE DRIVING

⚠ WARNING

- Inspect all seat belt assemblies after any collision. Any seat belt assembly which was in use during a collision (other than a very minor one) should be replaced, even if damage to the assembly is not obvious. Any seat belt assembly even which was not in use during a collision must be replaced if the seat belt pretensioners were activated. The pretensioners and the load limiter only function once. In case they did not activate, consult with Maruti Suzuki authorized workshop.
- If frays, scratches, cuts are found on the seat belt, replace it with a new one.
- If the buckle does not work properly, ask Maruti Suzuki authorized workshop for inspection.
- If strong force was applied to the seat belt in a collision, the seat belt function may be damaged, even though its appearance is normal. Replace the seat belt with a new one.

(Continued)

⚠ WARNING

(Continued)

- As the seat belt may not provide the best performance and it may result in severe injury in case of emergency, observe the following points.
 - When foreign material enters into the buckle or you spill a drink, the seat belt may not work properly. In this case, ask Maruti Suzuki authorized workshop for inspection.
 - As the seat belt may be damaged, be careful not to get the seat belt caught in the door. Before closing the door, check that the seat belt is retracted without any slack.
 - Do not modify or remove the seat belt.


Seat Belt Care

Caring for seat belts is the same as caring for any type of regular cloth material, etc.

⚠ WARNING

Do not use bleach, solvent or dyes on seat belts. Doing so may cause stains, discoloration and strength deterioration, and the seat belt may not function properly.

Seat Belt Hanger




55TB02013

NOTICE

When you move a seatback, make sure the belt webbing is hooked in the seat belt hangers so the seat belts are not caught by the seatback, seat hinge, or seat latch. This helps prevent damage to the belt system.

Seat Belt Pretensioner System (Only for Front Seat)



⚠ WARNING

This section describes your Maruti Suzuki vehicle's seat belt pretensioner system. Read and follow all these instructions carefully to minimize your risk of severe injury or death.

To determine if your vehicle is equipped with a seat belt pretensioner system at the front or rear seating positions, check the label on the seat belt at the bottom part. If the letter "p" appears as illustrated, your vehicle is equipped with the seat belt pretensioner system. You can use the pre-

sioner seat belts in the same manner as ordinary seat belts.

Read this section and "Supplemental Restraint System (Airbags)" section to learn more about the pretensioner system.

The seat belt pretensioner system works with the supplemental restraint system (airbags). The crash sensors and the electronic controller of the airbag system also control the seat belt pretensioners. The pretensioners are triggered only when there is a frontal or side collision severe enough to trigger the airbags and the seat belts are fastened. For precautions and general information including servicing the pretensioner system, refer to "Supplemental Restraint System (Airbags)" section in addition to this "Seat Belt Pretensioner system" section, and follow all those precautions.

The pretensioner is located in each front seat belt retractor. The pretensioner tightens the seat belt so the belt fits the occupant's body more snugly in the event of a frontal or side collision. The retractors will remain locked after the pretensioners are activated. Upon activation, some noise will occur and some smoke may be released. These conditions are not harmful and do not indicate a fire in the vehicle.

The driver and all passengers must be properly restrained by fastening seat belts at all times, whether or not a pretensioner is equipped at their seating position, to

minimize the risk of severe injury or death in the event of a collision.

Sit fully back in the seat; sit up straight; do not lean forward or sideways. Adjust the belt so the lap portion of the belt is worn low across the pelvis, not across the waist. Please refer to "Seat Adjustment" section and the instructions and precautions about the seat belts in this "Seat Belts and Child Restraint Systems" section for details on proper seat and seat belt adjustments.

Please note that the pretensioners along with the airbags will activate in severe frontal or side collisions. They are not designed to activate in rear impacts, roll-overs, or minor frontal side collisions. The pretensioners can be activated only once. If the pretensioners are activated (that is, if the airbags are activated), have the pretensioner system serviced by Maruti Suzuki authorized workshop as soon as possible.

The pretensioner system or the airbag system may not work properly if any of the following conditions occurs:

- 1) If the air bag warning light on the instrument cluster does not come on briefly, when the ignition switch is turned to the "ON" position or the engine switch is pressed to change the ignition mode to "ON".
- 2) If the air bag light comes on and stays on for more than 10 seconds, when the ignition switch is turned to the "ON"

FOR SAFE DRIVING

position or the engine switch is pressed to change the ignition mode to "ON".
3) If the air bag light comes on while driving.

Have both systems inspected by Maruti Suzuki authorized workshop as soon as possible.

Service on or around the pretensioner system components or wiring must be performed only by Maruti Suzuki authorized workshop who is specially trained. Improper service could result in unintended activation of pretensioners or could render the pretensioner inoperative. Either of these two conditions may result in personal injury.

To prevent damage or unintended activation of the pretensioners, check that the lead-acid battery is disconnected and the ignition switch has been in "LOCK" position or the ignition mode has been in LOCK (OFF) for at least 90 seconds before performing any electrical service work on your Maruti Suzuki vehicle.

Do not touch pretensioner system components or wiring. The wires are wrapped with yellow tape or yellow tubing, and the couplers are yellow. When scrapping your Maruti Suzuki vehicle, ask a Maruti Suzuki authorized workshop, body repair shop, or scrap yard for assistance.

For Proper Operation of Seat Belt Pretensioner System

Do not modify any parts that can affect the functionality of the seat belt pretensioner system. The seat belt may be retracted unexpectedly, or it may not be properly retracted when necessary.


Disposal and Scrapping

Seat belt pretensioners that have not been activated must be activated according to the predetermined procedure before disposal.


⚠ WARNING

If you do not handle a pretensioner properly for disposal, the pretensioner system may activate unexpectedly, resulting in severe injury.
When disposing of a pretensioner or scrapping the vehicle equipped with a pretensioner, consult Maruti Suzuki authorized workshop.

Seat Belt Force Limiter System (Only for Front Seat)




In the event of a strong impact coming from the front, the seat belt force limiter operates in two stages (driver's seat) and one stage (front passenger's seat) to reduce a force to the shoulder strap, thus lessening the impact being sustained by the front passengers.




⚠ WARNING

If the seat belt sustains strong impact, the resin of the shoulder anchor part (1) and the tongue plate part (2) could soften due to heavy friction, thus sticking to the seat belt, making the belt slide less easily. In such a case, the seat belt may not provide the best performance, resulting in severe injury in case of emergency. Have the seat belt replaced by Maruti Suzuki authorized workshop.


Child Restraint Systems**Child Restraint System Usage**

59RN02280


The following types of child restraint system are available generally.

Infant restraint

80JC007

Child restraint

59RN02350

Booster seat

80RN02290

Maruti Suzuki highly recommends that you use a child restraint system to restrain infants and small children. Many different types of child restraint systems are avail-



FOR SAFE DRIVING

able; check that the restraint system you select meets applicable safety standards.

All child restraint systems are designed to be secured in vehicle seats either by seat belts (lap portion of lap-shoulder belts) or by special rigid lower anchor bars built onto the floor. Whenever possible, Maruti Suzuki recommends that child restraint systems be installed on the rear seat. According to accident statistics, children are safer when properly restrained in rear seating positions than in front seating positions.

NOTE:

Observe any statutory regulation about child restraints.



Child Restraint System for India

Child Restraint

The suitability of each passenger's seat position for carriage of children and fitting of child restraint system is shown in the table below. Whenever you carry children up to 12 years of age, properly use the child restraints which conform to AIS 072, the standard for child restraints, referring to the table.

MASS GROUP	Seating position (or other site)				
	Front Passenger	Rear Outboard	Rear Center	Intermediate Outboard	Intermediate Center
Group 0 Up to 10 kg	X	U	U	N.A.	N.A.
Group 0+ Up to 13 kg	X	U	U	N.A.	N.A.
Group I 9 to 18 kg	X	U	U	N.A.	N.A.
Group II 15 to 25 kg	X	U	U	N.A.	N.A.
Group III 22 to 36 kg	X	U	U	N.A.	N.A.

Key of letters to be inserted in the above table:

U = Suitable for 'universal' category restraints approved for use in this mass group

X = Seat position not suitable for children in this mass group

N.A. = Seat position not available for children in this mass group.

NOTE:

- 'universal' is the category in the AIS 072.
- 'Outboard' indicates window side seat.

FOR SAFE DRIVING

Securing Child Restraint System by Seat Belt

Choose the appropriate seat for the child's age and physical size.

⚠ WARNING



61M0241

- Do not install a child restraint system on the front passenger's seat.
- If you install a child restraint system in the rear seat, slide the front seat far enough forward so that the child's feet do not contact the front seatback. This will help avoid injury to the child in the event of an accident.
- Do not hold a child on passenger's lap when the vehicle is in motion.

(Continued)

⚠ WARNING

(Continued)

- Even if the passenger holds the child tightly, he/she would not be supported enough in the event of an accident and it could result in a serious injury of the child

⚠ CAUTION


If your vehicle is equipped with the head restraint, adjust the height of the head restraint or remove it for fitting the child restraint, as necessary. However, if a booster cushion not equipped with the head restraint is fitted, the head restraint should not be removed. If the head restraint is removed for fitting the child restraint, you need to install it again after removing the child restraint. If the child restraint is fitted improperly, a child sitting in it could be injured in a collision.

NOTE:

Stow the removed head restraint in the luggage compartment so it will not cause inconvenience to the occupants.

Securing

This section explains securing the child restraint system in the rear seat.



55TB02014


- 1) When the child restraint system contacts the head restraint, adjust the height of the head restraint or remove it for fitting the child restraint system.

! WARNING

If the child restraint system contacts the head restraint, the child restraint system cannot be secured firmly. This may cause severe injury to a child in a collision.


When installing the child restraint system, adjust the head restraint height to the highest position as much as possible or remove the head restraint so that the child restraint system would not contact the head restraint.

- 2) If your vehicle is equipped with the reclining mechanism of rear seatback, adjust the angle of the seatback so that there is no gap between the child restraint system and the seatback.
- 3) Make sure that the child restraint system is securely fastened to the main seat.
- 4) Make sure to pass the seat belt of the passenger's seat through the specified parts, according to the instruction manual that came with the child restraint system.



59RN02140

- 5) Insert the tongue plate (3) firmly into the seat belt buckle (4) until you hear a click.
 • The child restraint system in the above figure is a typical example.



72M00172

- 6) If the child restraint system does not have a seat belt locking mechanism or a locking clip, secure it to the seat by using the aftermarket locking clip.
 • The aftermarket locking clip shown in the above figure is a typical example.

! WARNING

Failure to securely fasten a child restraint system via the seat belt locking mechanism or a locking clip may cause serious injury to a child when sudden braking or a collision occurs.

- 7) Shake the child restraint system back and forth, and left and right to check if it is securely in position.
- If you cannot ensure secure positioning, check the instruction manual that came with the child restraint system or consult the authorized workshop where you purchased the seat.


! WARNING

Make sure to position the child restraint system securely. Failure in doing so could result in the child sustaining serious injury when sudden braking or a collision occurs.

FOR SAFE DRIVING

Securing Child Restraint System by ISOFIX

Securing



55T020350


(1) Lower anchorage

Your vehicle is equipped with the lower anchorages in the rear seat outboard seating positions for securing a ISOFIX type of child restraints with the connecting bars. The lower anchorages are located where the rear of the seat cushion meets the bottom of the seatback.

⚠ WARNING

Install the ISOFIX type of child restraint(s) in the only outboard seating positions, not in the central position for the rear seat.

Install the ISOFIX type child restraint system according to the instructions provided by the child restraint system manufacturer. After installation, try moving the child restraint system in all directions especially forward to check that connecting bars are securely latched to the anchorages.



55T020360

(2) Top tether anchorage

Your vehicle is equipped with the top tether anchorages. Use the top tether strap of the child restraint according to the instructions provided by the child restraint system manufacturer.


Here is a general instruction:

⚠ CAUTION

If your vehicle is equipped with the head restraint, adjust the height of the rear head restraint or remove it for fitting the child restraint, as necessary. However, if a booster cushion not equipped with the head restraint is fitted, the head restraint should not be removed. If the head restraint is removed for fitting the child restraint, you need to install it again after removing the child restraint. If the child restraint is fitted improperly, a child sitting in it could be injured in a collision.

NOTE:

Stow the removed head restraint in the luggage compartment so it will not cause inconvenience to the occupants.




55TB02014

- When the child restraint system contacts the head restraint, adjust the height of the head restraint or remove it for fitting the child restraint system.


! WARNING

If the child restraint system contacts the head restraint, the child restraint system cannot be secured firmly. This may cause severe injury to a child in a collision.
When installing the child restraint system, adjust the head restraint height to the highest position as much as possible or remove the head restraint so that the child restraint system would not contact the head restraint.




55T020370

- Place the child restraint in the rear seat, inserting the connecting bars (3) to the lower anchorages (1) between the seat cushion and the seatback.




68LM268

- Push the child restraint toward the anchorages so that the connecting bar tips are partially hooked to the anchorages. Use your hands to confirm the position.



54G185

- Use your hands to carefully align the connecting bar tips with the anchorages. Take care not to pinch your fingers.



54G184

- Grasp the front of the child restraint and push the child restraint forcefully to latch the connecting bars. Check that they are securely latched by trying to move the child restraint system in all directions, especially forward.

- Attach the top tether strap referring to "Installation of child restraint with top tether" section.


When you put your child in the child restraint system, appropriately slide the front seat forward not to touch a part of your child's body.

FOR SAFE DRIVING

NOTICE

When installing a child restraint system to the rear seat, adjust the front seat position so that the front seat does not interfere with the child restraint system.

Installation of Child Restraint with Top Tether



Some child restraint systems require the use of a top tether strap. Top tether anchorages are provided in your vehicle at the locations shown in the illustrations.


The number of the top tether anchorage brackets provided in your vehicle depends

on the vehicle specification. Install the child restraint system as follows:

- 1) Remove the luggage compartment cover (if equipped).
- 2) Secure the child restraint on the rear seat using the procedure described above for securing a restraint system that does not require a top tether strap.
- 3) Hook the top tether strap to the top tether anchorage and tighten the top tether strap according to the instructions provided by the child restraint system manufacturer. Attach the top tether strap to the corresponding top tether anchorage located directly behind the child restraint. Do not attach the top tether strap to the luggage restraint loops (if equipped).

WARNING

Do not attach the child restraint top tether strap to the luggage restraint loops. Incorrectly attached top tether strap will reduce the intended effectiveness of the child restraint system.



52RS20431

- 4) When routing the top tether strap, pass the top tether strap as shown in the illustration. (Refer to "Head Restraints" section for details on how to adjust the height of head restraint or remove it.)
- 5) Check that cargo does not interfere with routing of the top tether strap.

WARNING

If the seat belt, etc. gets stuck in the child restraint system, it may not be secured properly and this may cause severe injury to a child in a collision. When you install the child restraint system, check that obstacles and the seat belt do not exist near the ISOFIX anchorages and the top tether anchorages.

FOR SAFE DRIVING


Supplemental Restraint System (Airbags)

⚠ WARNING

This section describes the protection provided by your Maruti Suzuki vehicle's supplemental restraint system (airbags). Read and follow all instructions carefully to minimize your risk of severe injury or death in the event of a collision.

Your vehicle is equipped with a supplemental restraint system consisting of the following components in addition to a lap-shoulder belt at each seating position.

- (1) Side curtain airbag module (if equipped)
- (2) Side crash sensor (if equipped)
- (3) Front passenger's front airbag module
- (4) Driver's front airbag module
- (5) Forward crash sensor
- (6) Side airbag module (if equipped)
- (7) Airbag controller



74TB02006

FOR SAFE DRIVING

What is SRS Airbag System?

SRS stands for "Supplemental Restraint System". This system aims to restrain passengers in their seats for safety.



55TB0204

If airbag warning light on the instrument cluster does not blink or come on when the ignition switch is first turned to "ON" position, or the ignition mode is first changed to ON, or airbag warning light stays on, or comes on while driving, the airbag system (or the seat belt pretensioner system) may not work properly. Have the airbag system inspected by Maruti Suzuki authorized workshop as soon as possible.


! WARNING

- SRS airbag system is not a substitute for seat belts. SRS airbag system is the supplemental restraint system and will provide the effectiveness by using the seat belts at the same time.**
If you and the passengers do not fasten their seat belts, it may result in severe injury in a sudden braking or a collision.
Even when you drive the vehicle equipped with SRS airbag system, make sure to fasten seat belt.
- If the seat belts are not fastened properly, airbags may not provide the best performance. This may cause severe injury in a sudden braking and a collision.**
Make sure that the driver and all the passengers fasten the seat belts properly in a correct posture.

NOTE:

Via the event data recorder (EDR) system, this vehicle records and accumulates data when the airbag is deployed.

Front airbags



80J090

Front airbags are designed to inflate in severe frontal collisions when the ignition switch is in "ON" position or the ignition mode is ON.


NOTE:

In a frontal angle collision, the side airbags (if equipped) and side curtain airbags (if equipped) may inflate.

Front airbags are not designed to inflate in rear impacts, side impacts, rollovers or minor frontal collisions, since they would offer no protection in those types of accidents. Since an airbag deploys only one time during an accident, seat belts are needed to restrain occupants from further movements during the accident.

Therefore, an airbag is not a substitute for seat belts. To maximize your protection, always fasten your seat belts. Be aware that no system can prevent all possible injuries that may occur in an accident.

Side airbags (if equipped) and side curtain airbags (if equipped)



68KM090


Side airbags and side curtain airbags are designed to inflate in severe side impact collisions when the ignition mode is ON.

Side airbags and side curtain airbags are not designed to inflate in frontal or rear collisions, rollovers or minor side collisions, since they would offer no protection in those types of accidents. Only the side airbag and side curtain airbag on the side of the vehicle that is struck will inflate. However, in a frontal angle collision, the side airbags and side curtain airbags may inflate. Since an airbag deploys only one time during an accident, seat belts are needed to restrain occupants from further movements during the accident.

Therefore, an airbag is not a substitute for seat belts. To maximize your protection, always fasten your seat belts. Be aware that no system can prevent all possible injuries that may occur in an accident.

When Driving the Vehicle with SRS Airbag System

Make Sure to Fasten Seat Belt




65J106

⚠ WARNING

SRS airbag system is not a substitute for seat belts. SRS airbag system is the supplemental restraint system and will provide the effectiveness by using the seat belts at the same time. If you and the passengers do not fasten their seat belts, it may result in severe injury in a sudden braking or a collision.

Even when you drive the vehicle equipped with SRS airbag system, make sure to fasten seat belt.

Correct Sitting Posture



80J014

There is a possibility of major impact from the front airbags when the airbags activate and deploy instantaneously, the driver and the passenger should sit deeply into their seats and touch their backs lightly to the seatback. In addition, the seat should be positioned so that it is not too far forward.




59RN02190

FOR SAFE DRIVING


⚠ WARNING

- Do not position your face, chest, etc., close to the steering wheel or instrument cluster, and do not rest your feet up into this area. Otherwise, there is the risk of serious injury due to major impact if the airbag were to be deployed.
- If side airbags (if equipped) or side curtain airbags (if equipped) activate, you may get strong impact, resulting in severe injury. Do not put hands out of the window or lean on the door. Also, when sitting in the rear seat, do not hug the seatback of the front seat.

For Proper SRS Airbag System Operation



69RHS169



59RN02200

⚠ WARNING

For the vehicle with side airbags or side curtain airbags, do not attach accessories such as cup holders or hangers near the door. Also, do not lean umbrellas against the door.

⚠ WARNING


- Do not modify the steering wheel, such as replacing it, placing stickers on it, painting it or putting the cover on it.
- Do not place stickers on the airbag units or the surrounding areas or paint them. Also, do not attach any accessories, fragrances, electronic toll control units, portable car navigation systems, etc. to this area, and do not lean umbrellas or other objects against it.
- Do not attach accessories (except for Maruti Suzuki genuine products), etc., to the windshield or the inside rearview mirror.

Warning Label of SRS Airbag for Front Passenger's Seat



72M00150

You may find this label on the sun visor.



Description of warning label

Symbol	Symbol meaning
	Do not install a rear-facing child restraint system to the front passenger's seat equipped with an airbag.
	If the front passenger's seat airbag were to be deployed, a major impact could be applied to a rear-facing child restraint system and the child.
	For more details, read this owner's manual.

“SRS AIRBAG” Mark and Location Driver's front airbag



55TB0202

6) Front passenger's front airbag




74TB02001

FOR SAFE DRIVING

Side airbags (if equipped)



Side curtain airbags (if equipped)



The driver's front airbag is located behind the center pad of the steering wheel and

the front passenger's front airbag is located behind the passenger's side of the dashboard.

Side airbags are located in the part of the front seatbacks closest to the doors.

Side curtain airbags are located in the roof lining.

The words "SRS AIRBAG" are molded into the airbag covers to identify the location of the airbags.

⚠ WARNING

- If the airbag stored place is damaged or cracked, the airbag system may not work properly, which could result in serious injury in the event of a collision. Have your vehicle inspected by Maruti Suzuki authorized workshop.
- If you smash the airbag stored place or apply a strong impact to it, the airbag may not work properly or may inflate unexpectedly, resulting in serious injury.
Do not smash the airbag stored place or apply a strong impact to it.

Installation of Child Restraint System



Refer to "Seat Belts and Child Restraint Systems" section for details on securing your child.

Handling for Airbags

For Proper SRS Airbag System Operation

If objects are positioned within the range where the airbag deploys, such objects might be impacted and blown off or the airbag may not deploy properly.

! WARNING

- As the airbag may not provide the best performance and it may result in severe injury in case of emergency, observe the following points.
 - Do not modify the suspension. If the vehicle height or the stiffness of the suspension were to change, airbag malfunction may result.
 - When installing a grille guard, etc., on the front of the vehicle, consult Maruti Suzuki authorized workshop. If you modify the front part of the vehicle, the airbag system may not work properly.
 - When installing radio equipment, etc., consult Maruti Suzuki authorized workshop. Radio waves, etc., from a radio may adversely affect the computer module used in the airbag system.

(Continued)

! WARNING

(Continued)

- Even though your vehicle is damaged by a collision, it may not be severe enough to trigger front, side or side curtain airbags to inflate. If your vehicle sustains any front-end or side damage, have the airbag system inspected by Maruti Suzuki authorized workshop to ensure that it works properly. If the original function of airbag system is damaged, airbag may not function effectively and fully in case of an emergency.
- If the airbag-related parts are replaced or repaired, which has an impact on the airbag functions, the airbag may activate unnecessarily or may not activate when necessary.
The following situations may give a negative impact to the airbag system. In these cases, consult Maruti Suzuki authorized workshop beforehand.
 - Removing the steering wheel, repairing the areas around the steering wheel, etc.

(Continued)


! WARNING

(Continued)

- Center console repair, repairs around the instrument cluster, repairs under the front seat, and repairs of electrical wiring
- Installation of audio equipment, etc.
- Sheet metal painting and repairs around the dashboard
- Replacement of the front seat and repairs around the seat
- Repairs around the front pillar, the back pillar or the roof side
- Repairs around the center pillar

FOR SAFE DRIVING

Driver's front airbag precautions




69RHS022

⚠ WARNING

- Do not position your hands, face, chest, etc., close to airbag unit area or lean on the steering wheel. Otherwise, there is the risk of serious injury due to major impact if the airbag were to be deployed.
- Do not modify the steering wheel, such as replacing it, placing stickers on it, painting it or putting the cover on it. Otherwise, the airbag may not deploy normally in case of emergency, resulting in severe injury.

Front passenger's front airbag precautions



69RHS170

⚠ WARNING

- When riding in the front passenger's seat or when allowing a child to ride in this seat, be sure to observe the following points. Failure to do so may result in serious injury due to major impact if the airbag is deployed.
 - Do not position your hands or feet on the airbag unit area, and do not position your face, chest, etc., close to this area.
 - Do not allow a child to stand in front of the airbag unit area or sit on a passenger's lap in the front passenger's seat. Have a child ride in the rear seat wearing a seat belt.

(Continued)

⚠ WARNING

(Continued)

- For a child that is not yet big enough to wear a seat belt properly, be sure to use a child restraint system on the rear seat.




69RHS171

⚠ WARNING

- As the airbag may not provide the best performance and it may result in severe injury in case of emergency, observe the following points.
 - Do not place stickers on the airbag units or the surrounding areas or paint them. Also, do not attach any accessories, fragrances, electronic toll control units, portable car navigation systems, etc. to this area, and do not lean umbrellas or other objects against it.
 - Do not attach accessories (except for Maruti Suzuki genuine products), etc., to the windshield or the inside rearview mirror.

Side airbags (if equipped) and side curtain airbags (if equipped) precautions



59RN02200

⚠ WARNING

If you attach accessories such as cup holders or hangers near the door, or if you lean umbrellas against the door, when side airbags or side curtain airbags activate, these objects may be thrown out and may not inflate properly, resulting in severe injury.

Do not attach accessories such as cup holders or hangers near the door. Also, do not lean umbrellas against the door.

Function of Airbags

How the System Works

In a frontal collision, the collision sensors will detect rapid deceleration, and if the controller judges that the deceleration represents a severe frontal collision, the controller will trigger the inflators. The inflators inflate the appropriate airbags with nitrogen or argon gas. The inflated airbags provide a cushion for your head and upper body. The airbag inflates and deflates so quickly that you may not even realize that it has activated. The airbag will neither hinder your view nor make it harder to exit the vehicle.

A seat belt helps keep you in the proper position for maximum protection when an airbag inflates. Adjust your seat as far back as possible while still maintaining control of the vehicle. Sit fully back in your seat; sit up straight; do not lean over the steering wheel or dashboard. Front occupants should not lean on or sleep against the door. Refer to "Seat Adjustment" section and "Seat Belts and Child Restraint Systems" section in this section for details on proper seat and seat belt adjustments.

FOR SAFE DRIVING



59RN02370



59RN04670



59RN02360

⚠ WARNING

- The driver should not lean over the steering wheel. The front passenger should not rest his or her body against the dashboard where a front air bag is mounted or a child should not stand in front of the dashboard. Otherwise, he or she will get too close to the dashboard. For vehicles with side air bags and side curtain air bag, occupants should not lean on or sleep against the door. In these situations, the out-of-position occupant would be too close to an inflating airbag, and may suffer severe injury.

(Continued)

⚠ WARNING

(Continued)

- Do not attach any objects to, or place any objects over, the steering wheel or dashboard. Do not place any objects between the airbag and the driver or front passenger. These objects may interfere with airbag operation or may be propelled by the airbag in the event of a collision. Also, these objects may move when you start moving vehicle or while vehicle is moving, they may interfere with driver's view or safe driving. In each condition, it may cause severe injury.

- For vehicles with side airbags, do not use non-genuine seat covers on the front seats, because non-genuine seat covers may obstruct the inflation of side airbags. Maruti Suzuki highly recommends Maruti Suzuki-genuine seat covers to be used when covering the front seats of such vehicles with side airbags. Also, near the door, do not place cup holders, hangers or any other objects and do not lean an umbrella, as these objects could be propelled by the airbag in the event of a collision. Either of these conditions may cause severe injury.

(Continued)

⚠ WARNING

(Continued)

- Do not strike or apply significant levels of impact to the airbag component areas. It can cause the airbags to malfunction.
- Even though your vehicle is damaged by a collision, it may not be severe enough to trigger front, side or side curtain airbags to inflate. If your vehicle sustains any front-end or side damage, have the airbag system inspected by Maruti Suzuki authorized workshop to ensure that it works properly. If the original function of air bag system is damaged, air bag may not function effectively and fully in case of an emergency.

⚠ CAUTION

Airbags must inflate quickly and forcefully in order to reduce the chance of serious or fatal injuries. However, an unavoidable consequence of the quick inflation is that the airbag may irritate bare skin, such as the facial area against a front airbag. Wash off any residue as soon as possible to prevent skin irritation. Also, upon inflation, a loud noise will occur and some powder and smoke will be released. These conditions are not harmful and do not indicate a fire in the vehicle. Be aware, however, that some airbag components may be hot for a while after inflation. This may cause burn injury.

Your vehicle is equipped with a diagnostic module which records information about the airbag system if the airbags deploy in a collision. The module records information about overall system status, and which sensors activated the deployment.

Servicing the airbag system

If the airbags inflate, have the airbags and related components replaced by Maruti Suzuki authorized workshop as soon as possible.

If your vehicle ever gets in deep water and the driver's floor is submerged, the airbag controller could be damaged. If this happens, ask Maruti Suzuki authorized workshop to check the airbag system as soon as possible.

Special procedures are required for servicing or replacing an airbag. For that reason, only Maruti Suzuki authorized workshop should be allowed to service or replace your airbags. Remind anyone who services your Maruti Suzuki vehicle that it has airbags.

Service on or around airbag components or wiring must be performed only by Maruti Suzuki authorized workshop. Improper service could result in unintended airbag deployment or could render the airbag inoperative. Either of these two conditions may result in severe injury.

To prevent damage or unintended inflation of the airbag system, check that the battery is disconnected and the ignition switch has been in "LOCK" position or the ignition mode has been in LOCK (OFF) for at least 90 seconds before performing any electrical service work on your Maruti Suzuki vehicle. Do not touch airbag system components or wires. The wires are wrapped with yellow tape or yellow tubing, and the couplers are yellow for easy identification.


FOR SAFE DRIVING

▲ CAUTION


If you do not handle the airbags properly, they may inflate unexpectedly, resulting in personal injury.
When scrapping the airbags or the vehicle that has the airbags, consult Maruti Suzuki authorized workshop.

Front Airbag Deployment Conditions

Front airbags deploy (inflation)




- Frontal collision with a fixed wall that does not move or deform at more than about 25 km/h




- Strong impact equivalent to frontal collision such as above at left and right angles of about 30 degrees (1) or less from the front of your vehicle

Front airbags may inflate


Receiving a strong impact to the lower body of your vehicle, the front airbags may inflate.



- Hitting a curb or medial strip




- Falling into a deep hole or ditch




80J101

- Landing hard or falling




80J102

- Frontal collision to a stopped vehicle at less than about 50 km/h




80J104

- Collision with a utility pole or stumpage



80J103

- Collision that the front of your vehicle goes under the bed of a truck etc.



80J105E


- Collision with a fixed wall or guardrail at left and right angles of greater than about 30 degrees (1) from the front of your vehicle

Front airbags may not inflate

The front airbags may not inflate when a strong impact has not occurred since the collision object (including living beings like animals) was easy to be deformed or moved, or the crashed portion of your vehicle was easy to be deformed.


Also, front airbags may not inflate in many cases when the collision angle is greater than about 30 degrees at left and right angles from the front of your vehicle. Also, in certain collisions at low speed, the airbag may not inflate.

FOR SAFE DRIVING



80J106

- Frontal collision with a fixed wall that does not move or deform at less than about 25 km/h




80J119

- Impact from the side


Side Airbags (if equipped) and Side Curtain Airbags (if equipped) Deployment Conditions

Side airbags and side curtain airbags deploy (inflation)



80J119

- Impacts from the side at about a right angle by a general passenger car to your vehicle at more than about 30 km/h or in a greater impact



80J110

- Vehicle rollover

Front airbags do not inflate

Front airbags do not inflate in rear impacts, side impacts or rollovers, etc. However, these might inflate in a strong impact.




80J120

- Impact from the rear

Side airbags and side curtain airbags may inflate in a strong impact

Side airbags and side curtain airbags may inflate even in a frontal collision, if there is a strong impact to the lateral direction.




80J102

- Frontal collision



52RM20730

- Hitting a curb or bump



80J100E


- Falling into a deep hole or ditch




80J101

- Landing hard or falling

Side airbags and side curtain airbags may not inflate



80J121



80J122

- Impact from the side to the vehicle body other than the passenger compartment

FOR SAFE DRIVING



80J123

- Impact from the side at an oblique angle



80J125

- Impact from the side by a motorcycle or bicycle



80J124

- Impact from the side by a high hood vehicle



80J126

- Collision with a utility pole or stumpage



80J120

- Impact from the rear



80J110

- Vehicle rollover


When Starting the Engine

Be Careful of Carbon Monoxide Poisoning

⚠ WARNING

Exhaust gases contain carbon monoxide, a potentially lethal gas that is colorless and odorless. If you breath exhaust gases, you may feel drowsy, resulting in severe health problems or death in the worst case.
If you start the engine, be careful of carbon monoxide poisoning.

Do not Run Engine in a Poorly-ventilated Area



52D334

⚠ WARNING

Avoid breathing exhaust gases. Exhaust gases contain carbon monoxide, a potentially lethal gas that is colorless and odorless. Since carbon monoxide is difficult to detect by itself, take the following precautions to help prevent carbon monoxide from entering your vehicle.

Otherwise, it may result in severe health problems or death in the worst case.

- Do not leave the engine running in garages or confined areas, with passengers inside. This may result in accumulation of carbon monoxide in cabin and may lead to suffocation or breathing problem and lead to death.
- Do not park with the engine running for a long period of time, even in an open area. In case of long periods, danger of choking and death on being inside the vehicle is a possibility when the engine is running. If it is necessary to sit for a short time in a parked vehicle with the engine running, check that the air intake selector is set to "FRESH AIR" and the blower is at high speed.

(Continued)

⚠ WARNING

(Continued)

- Avoid operating the vehicle with the tailgate or trunk open. If it is necessary to do so, check that the all windows are closed, and the blower is at high speed with the air intake selector set to "FRESH AIR".
- To allow proper operation of your vehicle's ventilation system, keep the air inlet grill in front of the windshield clear of snow, leaves or other obstructions at all times.
- Keep the exhaust tailpipe area clear of snow and other material to help reduce the buildup of exhaust gases under the vehicle. This is particularly important when parked in blizzard conditions.
- Have the exhaust system inspected periodically for damage and leakage. Any damage or leakage should be repaired immediately.

FOR SAFE DRIVING

Do not Take a Nap with Engine Running



⚠ WARNING

Do not take a nap with the engine running. Otherwise, it may result in an accident, severe health problems or death in the worst case.

- Exhaust gases can enter the vehicle due to surrounding conditions and wind direction, possibly causing carbon monoxide poisoning.
- The gearshift lever could change unintentionally, or the accelerator pedal could be depressed accidentally, causing an accident.
- If you were to accidentally step on the accelerator pedal while asleep, the engine and exhaust system could overheat, resulting in danger of fire

When Loading the Luggage

Loading too much luggage in the vehicle may have negative effects to the vehicle body or driving performance.

59RN02230

- Fuel, chemical containers, spray cans etc. may catch a fire or cause an explosion.
Do not bring these objects into the vehicle.

(Continued)

⚠ WARNING

(Continued)



- If you place any objects on the instrument panel, these objects may move and interfere with driver's view or safe driving. Also, the front passenger's front airbag may not work properly or these objects may be thrown out when the airbag inflates in an accident.
Do not place any objects on the instrument panel.



59RN07290

▲ CAUTION

- If you hang any objects on the gearshift lever or use it as a handrest, the gearshift lever may not work properly, resulting in a malfunction or an accident.
Do not hang any objects on the gearshift lever or use it as a handrest.
- If you pile up luggage, it may interfere with driver's view. Also, in a sudden braking, the luggage would jump out and it may result in an accident.
Do not pile up luggage in the vehicle.
- If animals move about in the vehicle, it may interfere with driver's view. Also, in a sudden braking, it may result in an accident.
When you bring animals into the vehicle, make sure that animals do not move about.

BEFORE DRIVING



60G404


Keys	3-1
Doors	3-1
Keyless Entry System Transmitter /	
Keyless Push Start System Remote Controller	3-5
Security System (if equipped)	3-15
Windows	3-17
Headlight Leveling Switch	3-20
Lighting Control Lever	3-21
Turn Signal Control Lever	3-24
Hazard Warning Switch	3-25
Windshield Wiper and Washer Lever	3-26
Horn	3-29
Heated Rear Window Switch	3-29

BEFORE DRIVING

Keys

Your vehicle comes with a pair of identical keys. Keep one of the keys as a spare key in a safe place. One key can open all of the locks on the vehicle.

Key Number Plate



55T030020

The key identification number (1) is stamped on a metal tag (2) provided with the keys. Keep the tag in a safe place. If you lose your keys, you will need this number to have new keys made. Write the number below for your future reference.

KEY NUMBER:

NOTE:

- Carefully keep the tag in the place other than your vehicle, so that someone does not find out about the key identification number. If you lose your key, inform the key identification number to a Maruti Suzuki authorized workshop.
- When you resell or transfer your vehicle to a new owner or operator, give the key number plate with your vehicle to him or her.

Immobilizer System

For detail of immobilizer system, "Immobilizer System" in the "OPERATING YOUR VEHICLE" section

Doors

⚠ WARNING

- When a seat belt or luggage is caught by a door, the door cannot be shut properly and it may open while driving. This may cause an accident. Close a door not to catch a seat belt or luggage in the door.
- When you keep the tailgate open with the engine running, exhaust gases will enter the vehicle and cause carbon monoxide poisoning. This may cause severe health problems or death in the worst case. Do not keep the tailgate open with the engine running.
- When opening a door, be careful of the surrounding area. An accident, such as a collision with the vehicle or a pedestrian behind your vehicle, may occur. Be very careful when opening a door especially on a windy day.
- When a child opens or closes a door, his / her hands, legs or head may be caught in the door and this may cause injury. Opening or closing a door should be performed not by a child but by an adult.


CAUTION

- When a child opens or closes a door, his / her hands, legs or head may be caught in the door and this may cause injury. Opening or closing a door should be performed not by a child but by an adult.
- When the tailgate is not fully opened, it may be unexpectedly closed and this may cause injury. When opening the tailgate, open it fully.
- Opening the tailgate right behind the exhaust pipes may cause burn injury. With the engine running, do not open the tailgate right behind the exhaust pipes.

NOTE:

- When leaving the vehicle even for a short period of time, do not leave cash or valuables in the vehicle, to avoid risk of theft.
- Depending on the setting conditions of the security alarm and the opening conditions of the doors, an alarm may operate. Refer to "Security System (if equipped)" in this section.

Side Door Locks




59RN03180

- (1) UNLOCK
- (2) LOCK
- (3) Front
- (4) Rear

To lock a front door from outside the vehicle:

- Insert the key and turn the top of the key toward the front of the vehicle, or
- Turn the lock knob forward, then pull and hold the door handle as you close the door.

To unlock a front door from outside the vehicle, insert the key and turn the top of the key toward the rear of the vehicle.



74TB03001

- (1) UNLOCK
- (2) LOCK

To lock a door from inside the vehicle, turn the lock knob forward. Turn the lock knob backward to unlock the door.


To lock a rear door from outside the vehicle, turn the lock knob forward and close the door. You do not need to pull and hold the door handle as you close the door.

NOTE:

Be sure to hold the door handle when you close a locked front door, or the door will not remain locked.

BEFORE DRIVING

Central Door Locking System



- (1) UNLOCK
- (2) LOCK
- (3) Front
- (4) Rear

You can lock and unlock all doors (including the tailgate) simultaneously by using the key in the driver's door lock.


To lock all doors simultaneously, insert the key in the driver's door lock and turn the top of the key toward the front of the vehicle.

To unlock all doors simultaneously, insert the key in the driver's door lock and turn the top of the key toward the rear of the vehicle twice.

NOTE:

You can switch the function that unlocks all doors from requiring two turns to requiring one turn, and vice versa, via the information display setting mode. For details on how to use the information display, refer to "Information display" in "INSTRUMENT CLUSTER" section.

To unlock the driver's door only, insert the key in that door lock and turn the top of the key toward the rear of the vehicle once.



- (1) LOCK
- (2) UNLOCK


You can also lock or unlock all doors by pressing the front or rear of the switch, respectively.

NOTE:

- You can also lock or unlock all doors by operating the transmitter or remote controller. Refer to "Keyless Entry System Transmitter / Keyless Push Start System Remote Controller" in this section.

- If your vehicle is equipped with the keyless push start system, you can also lock or unlock all doors by pushing the request switch. Refer to "Keyless Entry System Transmitter / Keyless Push Start System Remote Controller" in this section.

Child-proof Locks (Rear Door)



- (1) UNLOCK
- (2) LOCK

Each of the rear doors is equipped with a child-proof lock which can be used to help prevent unwanted opening of the door

from inside the vehicle. When the lock lever is in the lock position (2), the rear door can only be opened from outside. When the lock lever is in the unlock position (1), the rear door can be opened from inside or outside.

⚠ WARNING


Be sure to place the child-proof lock in the lock position whenever children are seated in the rear.

NOTE:

When you open a door from inside, put your hand out of the window and use the door handle.

Tailgate

Locking and unlocking from outside the vehicle



55TB0304

- (1) UNLOCK
- (2) LOCK
- (3) Tailgate unlatch switch

You can lock and unlock the tailgate by using the key in the driver's door lock.

To open the tailgate, push and hold the tailgate unlatch switch (3) and lift the tailgate.

NOTE:

When the tailgate is closed incompletely, follow the procedure below:

- 1) Push the tailgate unlatch switch (1) and open the tailgate.
- 2) After a few seconds, close the tailgate.
- 3) Check that the tailgate is closed completely.

⚠ CAUTION



55TB0306

To avoid damage and malfunction of the dumper stay, observe the following precautions. Otherwise, the damper stay (4) which upholds the tailgate may not operate smoothly and the tailgate may not be kept up when opening it.


- Do not scratch the rod part of the damper stay and do not attach foreign materials such as dirt, vinyl and tape to this part.
- Do not lay your hands on the damper stay and do not hang any objects.

BEFORE DRIVING


Unlocking from inside the vehicle

If you cannot unlock the tailgate by using the key in the driver's door lock due to a discharged lead-acid battery or malfunction, ask Maruti Suzuki authorized workshop. In emergency situations, follow the procedures below.

- 1) Remove the luggage compartment cover (if equipped) and fold the rear seat forward for easier access. Refer to "Folding rear seats" in "FOR SAFE DRIVING" section for details on how to fold the rear seat forward.



- 2) Remove the cover (5) using a flat-bladed screwdriver.




- 3) Open the cover (6), and then, move the emergency lever (7) to the direction of the arrow with a flat-blade screwdriver as shown in the illustration.
- 4) Push open the tailgate from inside. The tailgate will be latched again by simply closing the tailgate.

If the tailgate cannot be unlatched by pushing the unlatch switch (3), have the vehicle inspected by a Maruti Suzuki authorized workshop .

⚠ CAUTION

Check that there is no one near the tailgate when pushing open the tailgate from inside the vehicle.

Keyless Entry System Transmitter / Keyless Push Start System Remote Controller




Your vehicle is equipped with either a keyless entry system transmitter (1) or a keyless push start system remote controller (2). The transmitter has only a keyless entry system. The remote controller has a keyless entry system and a keyless push start system. For details, refer to the following explanations.

⚠ WARNING

Radio waves from the keyless push start system antenna(s) may interfere with operation of electrical medical equipment such as pacemakers. Failure to take the precautions listed below can increase the risk of severe injury or death due to radio wave interference.

- Anyone who uses electrical medical equipment such as a pacemaker should consult the medical equipment supplier or their medical advisor about whether radio waves from the antenna(s) can interfere with the medical equipment.
- If radio wave interference is a concern, have the function of the antenna(s) disabled by a Maruti Suzuki authorized workshop .

Keyless Entry System Transmitter

- (1) LOCK button
(2) UNLOCK button

You can lock or unlock all doors (including the tailgate) simultaneously by operating the transmitter near the vehicle.

Central door locking system

- To lock all doors, push LOCK button (1) once.
- To unlock only the driver's door, push UNLOCK button (2) once.
- To unlock other doors, push UNLOCK button (2) once again.

NOTE:

You can switch the function that unlocks all doors from requiring two pushes to requiring one push, and vice versa, via the information display setting mode. For details on how to use the information display, refer to "Information display" in "INSTRUMENT CLUSTER" section.

The turn signal lights will flash once and the siren will sound once (if equipped) when the doors are locked.

When the doors are unlocked:

- The turn signal lights will flash twice and the siren will sound twice (if equipped).
- If the interior light switch is in DOOR position, the interior light will turn on for about 15 seconds and then fade out. If you insert the key into the ignition switch during this time, the light will start to fade out immediately.

Check that the doors are locked after you operate LOCK button (1).

BEFORE DRIVING

NOTE:

If no door is opened within about 30 seconds after UNLOCK button (2) is operated, the doors will automatically lock again.

NOTE:

- If you lock the doors using the transmitter when the engine hood is open, the siren will sound 3 times to remind you (if equipped).
- If the security system was triggered due to an unauthorized entry into the vehicle and then you unlock the doors using the transmitter, the siren will sound 4 times to remind you. If this happens, check whether your vehicle has been broken into while you were away from it.
- Once you push both of the LOCK button (1) and UNLOCK button (2), then you push one of the buttons within 5 seconds, the siren will not sound (if equipped). However, push one of the buttons 5 seconds later, the siren will sound.
- You can set whether the siren sounds (if equipped) when locking or unlocking the door(s) via the setting mode of the information display. For details on how to use the information display, refer to "Information Display" in "INSTRUMENT CLUSTER" section.

NOTE:

- The maximum operating distance of the keyless entry system transmitter is about 5 m (16 ft.), but this can vary depending on the surroundings, especially near

other transmitting devices such as radio towers or CB (Citizen's Band) radios.

- The door locks cannot be operated with the transmitter, if the ignition key is inserted in the ignition switch.
- When any door is open, the door locks can only be unlocked with the transmitter, and the turn signal light will not flash.
- If you lose one of the transmitters, ask your Maruti Suzuki authorized workshop as soon as possible for a replacement. Have your Maruti Suzuki authorized workshop program the new transmitter code in your vehicle's memory so that the old code is erased.

The turn signal lights will blink for about 27.5 seconds. Also, the siren will sound for about 27.5 seconds at the same time.

To cancel the car locator function, press any button (LOCK or UNLOCK).

You can also turn the ignition switch to the "ON" position to cancel the car locator function.

NOTE:

The car locator function will not activate when the key is in the ignition switch or pre warning / full blast warning by shock sensor or alarm is in activated condition.

NOTICE

The transmitter is a sensitive electronic instrument. To avoid damaging the transmitter:

- Do not expose it to impacts, moisture or high temperature such as by leaving it on the dashboard under direct sunlight.
- Keep the transmitter away from magnetic objects such as a television.


Car locator function (if equipped)

This function helps in locating the vehicle. Push both of the LOCK button (1) and UNLOCK button (2) for more than 3 seconds.

Battery replacement


If the transmitter becomes unusable, replace the battery.

To replace the battery of the transmitter:



55T030370

- 1) Remove the screw (1), and open the transmitter cover.
- 2) Remove the transmitter (2).




55T030380


- (3) Lithium disc type battery:
CR1616 or equivalent
- 3) Put the edge of a flat-bladed screwdriver in the slot of the transmitter (2) and pry it open.
- 4) Replace the battery (3) so its + terminal faces "+" mark of the transmitter.
- 5) Close the transmitter and install it into the transmitter holder.
- 6) Close the transmitter cover, install and tighten the screw (1).
- 7) Check that the door locks can be operated with the transmitter.
- 8) Dispose of the used battery properly according to applicable rules or regulations. Do not dispose of lithium batteries with ordinary household trash.

NOTICE

- The transmitter is a sensitive electronic instrument. To avoid damaging it, do not expose it to dust or moisture or tamper with internal parts.
- When replacing the battery by yourself, the transmitter controller could be damaged affected by static electricity. Discharge the static electricity built up in your body by touching metal before replacing the battery.



NOTE:
Used batteries must be disposed of properly according to applicable rules or regulations and must not be disposed of with ordinary household trash.



80JM133

(1) Crossed-out wheeled bin symbol

The crossed-out wheeled bin symbol (1) indicates that a used battery should be collected separately from ordinary household trash.

BEFORE DRIVING

By ensuring the used battery is disposed of or recycled correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate battery disposal. The recycling of materials will help to conserve natural resources. For more detailed information about disposing of or recycling of the used battery, consult a Maruti Suzuki authorized workshop.

Be careful not to lose your key and to leave it in the locked vehicle.

⚠ WARNING


When you take the remote controller in an airplane, do not press the lock button or the unlock button. When you put the remote controller in a bag, place it so that either of these buttons is not pressed easily. If either of these buttons is pressed, radio wave may interfere with operation of the airplane.

*The remote controller is an electronic device which has a restriction on its use in the airplane.

Keyless Push Start System Remote Controller

The remote controller enables the following operations:

- You can lock or unlock the doors by operating LOCK/UNLOCK buttons on the remote controller. Refer to the explanation in this section.
- You can lock or unlock the doors by pushing the request switch. For details, refer to the explanation in this section.
- You can start the engine without using an ignition key. For details, refer to "Engine switch (vehicle with keyless push start system) (if equipped)" in "OPERATING YOUR VEHICLE" section.



52RM20060

(1) LOCK button
(2) UNLOCK button

There are two ways to lock or unlock all doors (including the tailgate) simultaneously by operating the remote controller near the vehicle.

Central door locking system

- To lock all doors, push LOCK button (1) once.
- To unlock only the driver's door, push UNLOCK button (2) once.
- To unlock other doors, push UNLOCK button (2) once again.

NOTE:

You can switch the function that unlocks all doors from requiring two pushes to requiring one push, and vice versa, via the information display setting mode. For details on how to use the information display, refer to "Information display" in "INSTRUMENT CLUSTER" section.

The turn signal lights will flash once and the siren will sound once (if equipped) when the doors are locked.

When the doors are unlocked:

- The turn signal lights will flash twice and the siren will sound twice.
- If the interior light switch is in DOOR position, the interior light will turn on for about 15 seconds and then fade out. If you press the engine switch during this time, the light will start to fade out immediately.

Check that the doors are locked after you operate LOCK button (1).

NOTE:

If no door is opened within about 30 seconds after UNLOCK button (2) is operated, the doors will automatically lock again.

Car locator function

This function helps in locating the vehicle. Push both of LOCK button (1) and UNLOCK button (2) for more than 3 seconds. The turn signal lights will blink for about 27.5 seconds. Also, the siren will sound for about 27.5 seconds at the same time.

To cancel the car locator function, press any button (LOCK or UNLOCK).

You can also cancel the car locator function in any of the following operations.


- Press the engine switch to change the ignition mode to "ON".
- Bring the remote controller with you and press the request switch.

NOTE:

- The car locator function will not activate when the ignition mode is "ACC" or "ON" or pre warning / full blast warning by shock sensor or alarm is in activated condition.
- If you lock the doors using the remote controller when the engine hood are open, the siren will sound 3 times to remind you.
- If the security system was triggered due to an unauthorized entry into the vehicle and then you unlock the doors using the remote controller, the siren will sound 4 times to remind you. If this happens,

check whether your vehicle has been broken into while you were away from it.

- Once you push both of LOCK button (1) and UNLOCK button (2), then you push one of the buttons within 5 seconds, the siren will not sound. However, push one of the buttons 5 seconds later, the siren will sound.
- You can set whether the siren sounds when locking or unlocking the door(s) via the setting mode of the information display.
- For details on how to use the information display, refer to "Information Display" in "INSTRUMENT CLUSTER" section.
- The maximum operating distance of the remote controller is about 5 m (16 ft.), but this can vary depending on the surroundings, especially near other transmitting devices such as radio towers or CB (Citizen's Band) radios.
- The door locks cannot be operated with the remote controller if the ignition mode is other than the "LOCK" (OFF).
- When any door is open, if you push LOCK button on the remote controller, the exterior buzzer will sound and doors cannot be locked.
- If you lose one of the remote controllers, ask a Maruti Suzuki authorized workshop as soon as possible for replacement. Have a Maruti Suzuki authorized workshop program the new remote controller code in your vehicle's memory so that the old code is erased.

Keyless unlocking/locking using the request switches

55TB0305

When the remote controller is within the operating range described in this section, you can lock or unlock all the doors (including tailgate) by pushing the request switch (1) on the driver's door handle or front passenger's door handle or tailgate.

When all doors are unlocked:

- To lock all doors, push one of the request switches once.

The turn signal lights will flash once and the siren will sound once when the doors are locked.

To unlock a door or all doors:

- Push one of the request switches once to unlock only one door.

BEFORE DRIVING

- Push one of the request switches twice to unlock all doors.

NOTE:

You can switch the function that unlocks all doors from requiring two pushes to requiring one push, and vice versa, via the information display setting mode. For details on how to use the information display, refer to "Information display" in "INSTRUMENT CLUSTER" section.


When the doors are unlocked:

- The turn signal lights will flash twice and the exterior buzzer will sound twice.
- If the interior light switch is in DOOR position, the interior light will turn on for about 15 seconds and then fade out. If you press the engine switch during this time, the light will start to fade out immediately.

Check that the doors are locked after you operate the request switch to lock the doors.

NOTE:

- The door locks cannot be operated by the request switch under the following conditions:
 - If any door is open or is not completely closed.
 - If the ignition mode is in any other mode than LOCK (OFF).
- If no doors are opened within about 30 seconds after unlocking the doors by pushing the request switch, the doors will be locked again automatically.



68PH00210

(1) 80 cm (2.6 ft)

When the remote controller is within approximately 80 cm (2.6 ft) from a front door handle or the tailgate switch, you can lock or unlock the doors by pushing the request switch.

NOTE:

- If the remote controller is outside the request switch operating range described above, you will not be able to operate the request switch.
- If the battery of the remote controller runs down or there are strong radio waves or noise, the request switch operating range may be reduced or the remote controller may be inoperative.
- If the remote controller is too close to the door glass, the request switches may not operate.

- If a spare remote controller is in the vehicle, the request switches may not operate normally.
- The remote controller will only operate a request switch if it is within the switch's operating range. For example, if the remote controller is within the operating range of the driver's door request switch but not the front passenger's door request switch or the tailgate request switch, the driver's door switch can be operated but the front passenger's door switch or tailgate switch cannot be operated.

NOTICE

The remote controller is a sensitive electronic instrument. To avoid damaging the remote controller:

- Do not expose it to impacts, moisture or high temperature such as by leaving it on the dashboard under direct sunlight.
- Keep the remote controller away from magnetic objects such as a television.

NOTE:


The keyless push start system may not function correctly in certain environments or under certain operating conditions such as the following:

- When there are strong signals coming from a television, power station or a cellular phone.

- When the remote controller is in contact with or covered by a metal object.
- When a radio wave type remote keyless entry is used nearby.
- When the remote controller is placed near an electronic device such as personal computer.


Some additional precautions you should take and information you should be aware of are:

- Check that the key is stowed in the remote controller. If the remote controller becomes unusable, you will not be able to lock or unlock the doors.
- Check that the driver always carries the remote controller.
- If you lose one of the remote controllers, ask a Maruti Suzuki authorized workshop as soon as possible for a replacement. Have a Maruti Suzuki authorized workshop program the new remote controller code in your vehicle's memory so that the old code is erased.
- You can use up to four remote controllers and the keys for your vehicle. Ask a Maruti Suzuki authorized workshop for details.
- The battery life of the remote controller is about two years, but it can vary depending on usage conditions.



55T030030

To stow the key into the remote controller, push the key in the remote controller until you hear a click.



55T030040

To remove the key from the remote controller, slide the lock knob (A) in arrow direction and pull the key out from the remote controller.

Request switch warning buzzer

The exterior buzzer beeps for about 2 seconds in the following conditions to warn you that the request switch is not working:


- The request switch is pressed after all doors are closed with the ignition mode changed to ACC or ON position by pressing the engine switch when the remote controller is outside the vehicle.
- The request switch is pressed in any of the following conditions after changing the ignition mode to LOCK (OFF) by pressing the engine switch.
 - The remote controller is left inside the vehicle.
 - Any door (including the tailgate) is open.

Press the request switch again after doing the following:

With the ignition mode changed to LOCK (OFF) by pressing the engine switch, bring out the remote controller if it is inside the vehicle and check that all doors are completely closed.

BEFORE DRIVING

Reminder function



74TB03006

If the remote controller is not in the vehicle under the following conditions, the buzzer sounds intermittently for about 2 seconds and the immobilizer/keyless push start system warning light on the instrument cluster blinks:

When one or more doors are opened and all of the doors are later closed with the ignition in any other mode than LOCK (OFF).

The indicator light will turn off within several seconds after the remote controller is returned to an area of the vehicle other than the rear luggage area.

If the remote controller is left in the vehicle and you lock the driver's door or front passenger's door as described below, the door will be automatically unlocked.

- If you open the driver's door and lock the door by turning the lock knob forward or pushing the power door locking switch, the driver's door will be automatically unlocked.
- If you open the front passenger's door and lock the door by turning the lock knob forward or pushing the power door locking switch, the front passenger's door will be automatically unlocked.

NOTE:

- *The reminder will not operate when the remote controller is on the instrument panel, in the glove box, in a storage compartment, in the sun visor or on the floor, etc.*
- *Check that the driver always carries the remote controller.*
- *Do not leave the remote controller in the vehicle when leaving the vehicle.*

Battery Replacement

WARNING

Swallowing a lithium battery may cause serious internal injury or death in the worst case. Do not allow anyone to swallow a lithium battery. Keep lithium batteries away from children and pets. If swallowed, contact a physician immediately.

NOTICE


- **The remote controller is a sensitive electronic instrument. To avoid damaging it, do not expose it to dust or moisture or tamper with internal parts.**
- **When you replace the battery by yourself, touch a metallic part and remove static electricity to prevent damaging the remote controller.**

NOTE:

- *Used batteries must be disposed of properly according to applicable rules or regulations and must not be disposed of with ordinary household trash.*
- *You may damage the remote controller when replacing its battery. Asking Maruti Suzuki authorized workshop is recommended.*
- *When you purchase the battery by yourself at a Maruti Suzuki authorized work-*

shop or the other stores, check the year of manufacture for the battery.

If the remote controller becomes unreliable, replace the battery as follows:




- Pry open the remote controller.
 - To prevent the case from being damaged, cover the flat-bladed screwdriver with a soft cloth. Insert the flat-bladed screwdriver in the slot (1) to pry it open.

NOTICE

When you pry open the remote controller with a flat-bladed screwdriver, you may damage the internal unit. Be careful not to damage the internal unit with the flat-bladed screwdriver.


- Replace the battery.
 - Remove the old battery. To prevent the case from being damaged, use

the flat-bladed screwdriver covered with a soft cloth.



(3) Lithium disc type battery:
CR2032 or equivalent

- Place the battery (3) so its + terminal faces up as shown in the illustration.
- Close the remote controller firmly.
- Make sure the door locks can be operated with the remote controller.
- Dispose of the used battery properly according to applicable rules or regulations. Do not dispose of lithium batteries with ordinary household trash.



(1) Crossed-out wheeled bin symbol

The crossed-out wheeled bin symbol (1) indicates that a used battery should be collected separately from ordinary household trash.

By ensuring the used battery is disposed of or recycled correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate battery disposal. The recycling of materials will help to conserve natural resources. For more detailed information about disposing of or recycling of the used battery, consult Maruti Suzuki authorized workshop.

BEFORE DRIVING

Security System (if equipped)

The security system is armed after you close and lock all doors (including engine hood and tailgate) by using the keyless entry system transmitter, keyless push start system remote controller or request switch.

Once the system is armed, any attempt to open a door by using any other means (*) than the keyless entry system transmitter, keyless push start system remote controller, request switch or open the engine hood, will cause the alarm to be triggered.

* These means include the following:

- The key
- The lock knob on a door
- The central door locking switch
- The tailgate unlatch switch

Also, in case that you have set the shock sensor to enabled state and set sensitivity of the pre-warning function and full blast warning function to a level other than 0, the warning will be triggered in case of any attempt to tamper with the vehicle. The shock sensor can be selected enabled or disabled state, and sensitivity of each warning can be adjusted as desired. To set the shock sensor, ask your Maruti Suzuki authorized workshop or use the setting mode of the information display.

NOTE:

- The default setting of the shock sensor is in the disabled state. Set to the enabled state and adjust sensitivity of each warning according to your preference. For details on how to use the information display, refer to “Information Display” in “INSTRUMENT CLUSTER” section.
- Your authorized workshop may have already set the shock sensor of the vehicle to the enabled state before you purchase it. Consult your authorized workshop for further information.

NOTE:

- The security system generates alarms when any of the predetermined conditions is met. However, the system does not have any function of blocking unauthorized entry into the vehicle.
- Always use the keyless entry system transmitter, keyless push start system remote controller or request switch to unlock the doors when the security system has been armed. Using a key instead will trigger the alarm.
- If a person who does not know the security system is going to drive the vehicle, we recommend you explain the system and its operation to the person. Mistakenly triggering the alarm may cause a nuisance to others.

- Even if the security system is armed, you should still be careful to guard against theft. Do not leave money or valuable things in the vehicle.

How to Arm the Security System

Lock all doors (including engine hood and tailgate) using the keyless entry system transmitter, keyless push start system remote controller or request switch.

When the system is armed, the indicator continues to blink at intervals of approximately 2 seconds.



55TB0301

NOTE:

- To prevent the alarm from being accidentally triggered, avoid arming it while anyone remains inside the vehicle. The alarm will be triggered if any person inside opens the door, tailgate, engine hood, or the warning may be triggered if anyone swings the vehicle (if the shock sensor is in the enabled state).

- *The security system is not armed when all doors are locked using the key from outside, using the door lock knobs or the central door locking switch from inside.*
- *If any door is not operated within approximately 30 seconds after the doors have been unlocked using the keyless entry system transmitter, keyless push start system remote controller or request switch, the doors are automatically locked again. When the doors are locked, the security system will be armed.*
- *If the security system indicator (1) blinks when the ignition switch is in the "ON" position or the ignition mode is "ON", there may be something wrong with the security system. Ask your Maruti Suzuki authorized workshop to inspect the system.*

How to Disarm the Security System

Simply unlock the doors using the keyless entry system transmitter, keyless push start system remote controller or request switch. The security system indicator will go out, indicating that the security system is disarmed.

How to Stop the Alarm

Should the alarm be triggered accidentally, the alarm will stop by the following operations.

- Press the engine switch to change the ignition mode to ON or turn the ignition switch to "ON" position in case of emergency.
- Unlock the doors using the keyless entry system transmitter, keyless push start system remote controller or request switch.

NOTE:

- *Even after the alarm has stopped, if you lock the doors using the keyless entry system transmitter, keyless push start system remote controller or request switch, the security system will be rearmed.*
- *If you disconnect the battery while the security system is in the armed condition or the alarm is actually in operation, the alarm will be re-triggered when the battery is reconnected.*
- *Even after the alarm has stopped at the end of the predetermined operation time, it will be triggered again if any of the doors, tailgate or engine hood is opened, without disarming the security system.*

Checking Whether the Alarm has Been Triggered During Parking

If the alarm was triggered and you then turn the ignition switch to "ON" position or the ignition mode is ON the security system indicator will blink rapidly for about 8 seconds and a buzzer will beep 4 times during this period. If this happens, check whether the vehicle has been broken into while you were away from it.

Security System Indication

- If any of the doors or tailgate are opened without unlocking by the keyless entry system transmitter, keyless push start system remote controller or request switch, all turn signal lights start to blink and the interior buzzer beeps intermittently. After 5 seconds, the siren will sound for about 27.5 seconds. The security system indicator continues to blink during this time.
- If the engine hood is opened, all turn signal lights blink, and the siren sounds for about 27.5 seconds. The security system indicator continues to blink during this time.

(If the shock sensor is in the enabled state)

- If the vehicle feels a shock higher than the pre-warning sensitivity, the siren sounds for about 2 seconds (pre-warning). If the vehicle feel a shock higher than the full blast warning sensitivity, the siren sounds for about 5 seconds (full

BEFORE DRIVING

blast warning). The security system indicator continues to blink during this time.

NOTE:


If you set the full blast warning sensitivity higher than the pre-warning sensitivity in the setting mode of the information display, or the vehicle feels such shock as to be able to trigger the full blast warning, the full blast warning will be triggered preferentially. In this case, the pre-warning will not be triggered.

Windows

Electric Window Controls


The electric windows can only be operated when the ignition switch is in "ON" position or the ignition mode is ON.

Driver's side




The driver's door has a switch (1) to operate the driver's window, and a switch (2) to operate the front passenger's window or there are switches (3), (4), to operate the rear left and right passenger windows, respectively.

Passenger's door / rear door




The passenger's door has a switch (5) to operate the passenger's window.



To open a window, push the top part of the switch. To close the window, lift up the top part of the switch.

The driver's window has AUTO-DOWN and AUTO-UP features for greater convenience (at toll booths or drive-through restaurants, for example). These features allow the driver to open or close the window without holding the window switch in DOWN or UP position. Press down or lift up the driver's window switch completely and release it. To stop the window before it reaches the FULL-DOWN or FULL-UP position, pull up or push down the switch briefly.

Lock switch



74TB03007

The driver's door also has a lock switch (6) for the passenger's window(s). When you push in the lock switch, the passenger's window(s) cannot be raised or lowered by

operating any of the switches (2), (3), (4) or (5). To restore normal operation, release the lock switch by pushing it again.

! WARNING

- When opening or closing a window, a part of body such as hands, legs and neck may be caught by the window and an accident may occur. When you operate a window, observe the following precautions:
 - A driver and the other passengers should be careful when opening or closing a window.
 - Do not allow a child to operate the window switches.
 - You should always lock the passenger's window operation when there are children in the vehicle. Children can be seriously injured if they get part of their body caught by the window during operation. Refer to "Window Lock Switch" in this section for details.
 - When you leave your vehicle, make sure to press the engine switch to change the ignition mode to OFF. Then, carry your key with you and take a child or children out of the vehicle.

(Continued)

! WARNING

(Continued)

- When you open or close the front passenger's window or the rear windows on the driver's side, check that the other passengers and children do not take their hands and faces outside the vehicle, before the window operation. Also, make sure to inform them that you will perform the window operation.
- When you operate the electric window controls from the outside of the window, your hands or neck may be caught by the window and an accident may occur. Do not operate the electric window controls from the outside of the window.

NOTE:

If you drive with one of the rear windows open, you may hear a loud sound caused by air vibration. To reduce the sound, open the driver's or front passenger's window, or narrow the rear window opening.

BEFORE DRIVING

Pinching Prevention Function

The driver's window is equipped with a pinching prevention function. This function detects a foreign object that is caught in the window as it is being closed by AUTO-UP feature, which allows you to close the window without holding the window switch in UP position, and stops the window from closing to prevent damage.

⚠ WARNING

The function may not detect the object depending on shape, size, hardness and position of the object caught by the closing window. This may cause severe injury.

Be very careful when opening or closing the windows.

⚠ CAUTION

- The pinching prevention function does not operate while you are holding the window switch in UP position.
- The pinching prevention function may not detect an object caught in the window just before the window is fully closed.

NOTE:

Even if you cannot close the window by the AUTO-UP feature because there may be something wrong with the pinching preven-

tion function, you can close the window by holding the window switch in UP position. If you drive in extreme off-road condition, the pinching prevention function may operate accidentally because the window reacts to vehicle jolting.

Pinching prevention function initialization

When you disconnect and reconnect the lead-acid battery or replace the fuse, the function will be deactivated. In this condition, the AUTO-DOWN feature will be deactivated, while the AUTO-UP feature may remain activated. The pinching prevention function needs to be initialized.

To initialize the pinching prevention function, use the following procedure:


- 1) Turn the ignition switch to "ON" position or press the engine switch to change the ignition mode to ON.
- 2) Open the driver's window fully by holding the window switch in DOWN position.
- 3) Close the driver's window by holding the switch in UP position, and keep holding the switch for 2 seconds after the window is fully closed.
- 4) Check the driver's window to see if the AUTO-DOWN/UP feature works.

⚠ WARNING

As the pinching prevention function will not operate until its initialization is completed, an accident may occur. Make sure to perform the pinching prevention function initialization.

If the AUTO-DOWN/UP feature will not work after initialization, there might be something wrong with the pinching prevention function. Have your vehicle inspected by Maruti Suzuki authorized workshop.

Headlight Leveling Switch



75RM008

Level the headlight beam according to the load condition of your vehicle by turning this switch. The chart shows the appropriate switch position for different vehicle load conditions.

For Petrol Model


Vehicle Load Condition	Halogen headlight	LED headlight
Switch Position		
Driver only	0	0
Driver + 1 passenger (in front seat)	0	0
Driver + 4 passengers, no cargo	1.5	1
Driver + 4 passengers, cargo added	2.5	1.5
Driver + full cargo	4	3

For CNG Model


Vehicle Load Condition	Halogen headlight
Switch Position	Halogen headlight
Driver only	0
Driver + 1 passenger (in front seat)	0
Driver + 4 passengers, no cargo	1.5
Driver + 4 passengers, cargo added	NA
Driver + full cargo	NA

BEFORE DRIVING

Lighting Control Lever Automatic Light Operation (if equipped)



55TB301



55T030190

Your vehicle's lighting system is controlled by two main systems: the lighting control lever and the auto-on headlight system (when the lighting switch is in "AUTO" position). The two systems work together to operate your lights as shown in the following chart:

ON: Lights ON

LIGHT: When it is light around the light sensor (5).

DARK: When it is dark around the light sensor (5).

Lighting switch position	Main lights to be operated	Ignition switch in the "LOCK" or "ACC" position / Ignition mode LOCK (OFF) or ACC		Ignition switch in the "ON" position / Ignition mode ON	
		LIGHT	DARK	LIGHT	DARK
(1) OFF	Position lights, Tail lights	—	—	—	—
	Headlights	—	—	—	—
(2) AUTO (if equipped)	Position lights, Tail lights	—	—	—	ON
	Headlights	—	—	—	ON
(3) ⚡	Position lights, Tail lights	ON	ON	ON	ON
	Headlights	—	—	—	—
(4) ⚡	Position lights, Tail lights	ON	ON	ON	ON
	Headlights	ON	ON	ON	ON

To turn the lights on or off, twist the knob on the end of the lighting control lever. There are four positions:

OFF (1)

All lights are off.

AUTO (2) (if equipped)

This function works when the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON. The headlights and position lights are turned on and off automatically according to the amount of outside light detected by a sensor. They go out automatically when you turn the ignition switch to "ACC" or "LOCK" position or change the ignition mode to ACC or LOCK (OFF) by pressing the engine switch.

The light sensor (5) for sensing the amount of outside light is installed on the passenger's seat side of instrument panel.

CAUTION

If the light sensor area of the windshield is covered with mud, ice, or other similar substances, the headlights and position lights may be turned on even when it is still light outside.

NOTE:

- Avoid covering the light sensor area of the windshield with a sticker. The sticker may impair the performance of the sen-

sor and make the system unable to control operation of the lights correctly.


If you turned the ignition switch to "ON" position or changed the ignition mode to ON by pressing the engine switch and "AUTO" position remains selected, the headlights and position lights come on automatically as it gets dark outside, even with the engine not running. Leaving the lights lit for a long time may lead to a completely discharged battery.

3 (3)

Front position lights, tail lights, license plate light and instrument lights are on, but headlights are off.

4 (4)


Front position lights, tail lights, license plate light, instrument lights and headlights are on.



55TB302

With the headlights on, push the lever forward to switch to the high beams (main beams) and pull the lever toward you to switch to the low beams. When the high beams (main beams) are on, a light on the instrument cluster will come on. To momentarily activate the high beams (main beams) as a passing signal, pull the lever slightly toward you and release it when you have completed the signal.

Auto-on headlight system (if equipped)



55T030190

The auto-on headlight system automatically turns on all lights that are operated by the lighting switch, when the following three conditions are all met.

Conditions for auto-on headlight system operation:

- It is dark around the light sensor (5).

BEFORE DRIVING

- 2) The lighting switch is in "AUTO" position.
- 3) You turn the ignition switch to "ON" position or press the engine switch to change the ignition mode to ON.

This system is activated by a signal from the light sensor (5) on the passenger side of instrument panel. Do not cover the sensor (5). Otherwise, the system will not work correctly.

⚠ WARNING

It takes about 5 seconds for the light sensor to react to a change in lighting conditions. To help avoid an accident due to reduced visibility, turn on your headlights before driving into a tunnel, parking structure, etc.

NOTE:

The light sensor reacts even to infrared rays, so it may operate incorrectly when there are strong infrared rays.

Light Reminder Buzzer

The interior buzzer continuously beeps if you open the driver's door without turning off the headlights and position lights. This function is triggered under the following condition:

The headlights and/or position lights are on even after the ignition switch is turned off, or the engine switch is pressed to change the ignition mode to LOCK (OFF).

The buzzer stops sounding when you turn off the headlights and position lights.

NOTE:

A message is indicated on the information display in the instrument cluster while the buzzer is sounding.

Daytime Running Light (D.R.L.) System (if equipped)

When the engine is started, the daytime running lights are turned on by this system.

Conditions for D.R.L. system operation

- 1) The engine is running.
- 2) Headlights are off.

NOTE:

Brightness of the daytime running lights is different from the brightness of the position lights, but it is not a malfunction.

Guide Me Light (if equipped)

Guide me light has two functions of "To home" and "To car" for improving your visibility in the dark.

"To home" function

Even after you leave the car, the ground will be illuminated for a short while with this function. You can turn on the front position lights and the headlights in the low beam setting for about 10 seconds after the ignition switch is turned to "LOCK" position or the engine switch is pressed to change the ignition mode to LOCK (OFF).

To set the function:

- 1) Turn the lighting switch to "AUTO" position.
- 2) Turn the ignition switch to "LOCK" position or press the engine switch to change the ignition mode to LOCK (OFF).
- 3) Pull the lighting control lever toward you once and open the driver's side door within 60 seconds. Or pull the lighting control lever toward you once while the driver's side door is open.

To cancel the function:

- Perform any of the following operations.
- Pull the lighting control lever toward you once.
 - Turn the ignition switch to "ACC" or "ON" position or change the ignition mode to ACC or ON by pressing the engine switch.
 - Turn the lighting switch to any other position than "AUTO" position.

NOTE:

- When the "To home" is functioning, the front fog lights (if equipped), rear fog light (if equipped) and the headlights (high beam) are not turned on.
- Lighting time of the "To home" function can be changed on the information display. Refer to "Information display" in "INSTRUMENT CLUSTER" section.

"To car" function

Before you get in the vehicle, the ground will be illuminated for a short while to easily lead the driver to the vehicle. If UNLOCK button of the keyless push start system remote controller is pressed while the lighting switch is positioned in "AUTO", the front position lights and the headlights in the low beam are turned on for 10 seconds.

This function will operate only when it is dark outside the vehicle.

To cancel the function:

- Perform any of the following operations.
- Lock the doors by using the keyless push start system remote controller, the request switch or the key in the driver's door lock.
 - Change the ignition mode to ACC or ON by pressing the engine switch.
 - Turn the ignition switch to ACC or ON position or the engine switch is pressed to change the ignition mode to ACC or ON.
 - Turn the knob at the end of the lighting control lever to any other position than AUTO position.

NOTE:


- When the "To car" is functioning, the front fog lights (if equipped), rear fog light (if equipped) and the headlights (high beam) are not turned on.
- Lighting time of the "To car" function can be changed on the information display. Refer to "Information display" in "INSTRUMENT CLUSTER" section.

Turn Signal Control Lever

You can use the turn signal control lever when the ignition switch in "ON" position or the ignition mode ON.

Turn Signal Operation

With the ignition switch in "ON" position or the ignition mode ON, move the lever upward or downward to activate the left or right turn signals.



55TB303

- Move the turn signal control lever (1) as follows:
 - Turning left: Move the lever upward.
 - Turning right: Move the lever downward
- When you move the lever, the turn signal lights as well as the turn signal light indicators on the instrument cluster will flash simultaneously.
- When you move the lever to its original position, the turn signal lights as well as


BEFORE DRIVING

the turn signal light indicators on the instrument cluster will be turned off.

NOTE:

If the angle by which you turn the steering wheel is small, the lever will not return automatically to its original position. In this case, return the lever to its original position manually.

Lane change signal



55TB304

Move the lever partially upward or downward to when turning leftward or rightward and hold the lever in the moved position.

- The turn signal and its indicator flash while the lever is held at the moved position.
- The turn signal and its indicator flash 3 times even if you returned the lever immediately after the activation.


NOTE:

- The turn signal and its indicator can be set whether they flash 3 times after the turn signal lever is returned via the information display. Refer to "Information display" in "INSTRUMENT CLUSTER" section.

mation display. Refer to "Information display" in "INSTRUMENT CLUSTER" section.

- You can customize the setting for the number of flashing times of the turn signal and its indicator (1 to 4 times). Please ask Maruti Suzuki authorized workshop for the customization.

Hazard Warning Switch



55TB0302

You can use the hazard warning switch to warn the other drivers of possible risk of traffic hazard when you park your vehicle in case of emergency.

- Push the hazard warning switch to activate the hazard warning lights. All the turn signal lights as well as both turn signal indicators will flash simultaneously.
- Push the switch again to turn off the hazard warning switch.
- The instrument panel in the above figure is a typical example; the actual equipment depends on the vehicle type.

NOTICE

If you use the hazard warning switch for many hours with the engine stopped, the lead-acid battery may run out.

Do not use the hazard warning switch for many hours with the engine stopped.

Windshield Wiper and Washer Lever

When the ignition switch in "ON" position or the ignition mode ON, you can use the wiper/washer lever.

CAUTION

In cold weather, the sprayed washer fluid on the glass may get frozen and it may cause poor visibility to a driver. Use the defroster to warm the glass and spray the washer fluid. Refer to "Heating And Air Conditioning" in the "OTHER CONTROLS AND EQUIPMENT" section.

NOTICE

- If you use the wipers with the glass dried, the glass and the wiper blade rubbers may be damaged. When the glass is dry, use the washer fluid and then use wipers.
- If you operate the wipers with the wiper blades stuck on the glass, the wiper blade rubbers may be damaged or the wipers may be broken. When the wiper blades are stuck on the glass, do not operate the wipers.
- If you use the washer when the washer fluid cannot be sprayed enough, the washer pump may be broken. When the washer fluid cannot be sprayed enough, turn off the washer switch.

When the operative wipers suddenly stop

When the wipers are under heavy load such as covered by snow and the temperature of the wiper motor becomes high, the breaker will be activated and the wipers will temporarily stop to protect the wiper motor from overheating.


If this happens, perform the following operations:

- 1) Stop the vehicle in a safe place, and turn the ignition switch to "ACC" or "LOCK" position or press the engine switch to change the ignition mode to ACC or LOCK (OFF).
- 2) Move the wiper lever and switch to "OFF" position.
- 3) Remove obstacles such as snow on the wipers.
- 4) After a while, when the temperature of the wiper motor becomes low enough, the breaker will be reset automatically and you can use the wipers.

If you cannot use the wipers after a while, there may be another problem. Ask Maruti Suzuki authorized workshop to have the wipers inspected.

BEFORE DRIVING


Windshield Wipers



55TB305

You can operate the windshield wipers by moving the lever (1) upward or downward.


MIST	Temporary operation only while the lever is up
OFF	Off
INT	Intermittent operation
LO	Low speed operation
HI	High speed operation



55TB306

If the lever is equipped with "INT TIME" control, turn the control forward or backward to adjust the intermittent wiper operation to the desired interval.

Windshield Washer



55TB307

If you pull the lever (1) toward you, the windshield washer fluid will be sprayed and the windshield wipers will automatically operate a few times.


⚠ WARNING

- To prevent windshield icing in cold weather, turn on the defroster to heat the windshield before and during windshield washer use.
- Do not use radiator antifreeze in the windshield washer reservoir. It can severely impair visibility when sprayed on the windshield, and can also damage your vehicle's paint.

NOTICE

To help prevent damage to the windshield wiper and washer system components, you should take the following precautions:


- Do not continue to hold in the lever when there is no windshield washer fluid being sprayed or the washer motor can be damaged.
- Do not attempt to remove dirt from a dry windshield with the wipers or you can damage the windshield and the wiper blades. Always wet the windshield with washer fluid before operating the wipers.
- Clear ice or packed snow from the wiper blades before using the wipers.
- Check the washer fluid level regularly. Check it often when the weather is bad.

Rear Window Wiper

55TB308

You can operate the rear window wiper by twisting the lever (2) as shown in the illustration.

ON	Normal operation
INT	Intermittent operation
OFF	Off

Rear Window Washer

55TB309


- If you twist the lever (2) in the direction of and align it to (washer) position above "ON" position, the rear window washer fluid will be sprayed and the rear wiper will operate simultaneously. If you release your hand from the lever, it will return to "ON" position.
- If you twist the lever (2) in the direction of and align it to (wiper) position below "OFF" position, the rear window washer fluid will be sprayed and the rear wiper will operate simultaneously. If you release your hand from the lever, it will return to "OFF" position.

NOTICE

Clear ice or snow from the rear window and rear wiper blade before using the rear wiper. Accumulated ice or snow could prevent the wiper blade from moving, causing damage to the wiper motor.

BEFORE DRIVING


Horn



52RM20420

Press the horn button of the steering wheel to sound the horn. The horn will sound with the ignition switch in any position or any ignition mode.

Heated Rear Window Switch



55T030300

While the engine is running or the engine automatically stops by the ENG A-STOP system, you can use the heated rear window switch as the defogger for the rear window glass.

Refer to "ENG A-STOP System (Engine Auto Stop Start System) (if equipped)" in the "OPERATING YOUR VEHICLE" section.

- If you push the rear defogger switch, the rear window glass will be heated and the indicator light (1) will turn on. To turn off the defogger, push the switch again.
- The defogger will automatically turn off after the defogger remains on for 15 minutes to prevent discharging of the lead-acid battery.
- If you turn the ignition switch to "ACC" or "LOCK" position or press the engine

switch to change the ignition mode to ACC or LOCK (OFF) with the defogger on, the defogger will not automatically operate even if you start the engine again.

NOTICE


The heated rear window use a large amount of electricity. If you do not turn off the switch after the window and mirrors have become clear, the battery may run out. To protect the lead-acid battery, turn off the switch shortly after the window and mirrors have become clear.

Also, do not use the defogger to melt snow or dry rain water.

NOTE:

- When you wipe the interior side of the rear window glass, use a soft cloth dampened with water and wipe the glass along the heat wires, not to damage the heat wires and the terminals.
- The defogger will work only when the engine is running.

INSTRUMENT CLUSTER



59RN04640

Instrument Cluster (Type A)	4-1
Information Display (Type A)	4-4
Instrument Cluster (Type B)	4-14
Information Display (Type B)	4-17
Warning and Indicator Lights	4-42


INSTRUMENT CLUSTER

Instrument Cluster (Type A)

- (1) Speedometer
- (2) Tachometer
- (3) Information display

- (4) Trip meter selector knob
- (5) Indicator selector knob
- (6) Warning and indicator lights

- (7) Fuel gauge
- (8) Temperature gauge



74TB04019

NOTE:

For vehicle fitted with CNG fuel system, refer to the supplementary owner's manual.

Speedometer

The speedometer indicates vehicle speed in km/h.

Speed Alert System

The speed alert system gives audible warning for alert of over-speed to driver. When vehicle speed exceeds about 80 km/h, primary level warning with two beeps will sound every minute. When the vehicle speed exceeds about 120 km/h, secondary level warning with continuous beeps will sound.

If the vehicle speed is slowed down to about 118 km/h, primary warning will resume. If the vehicle is slowed down to about 78 km/h, speed alert warning will stop. This buzzer does not indicate any malfunction in vehicle.

Tachometer

The tachometer indicates engine speed in revolutions per minute.


NOTICE

Never drive the vehicle with the engine revving in the red zone or severe engine damage can result.

Keep the engine speed below the red zone even when downshifting to a lower gear position.

Refer to "Downshifting maximum allowable speeds" in "OPERATING YOUR VEHICLE" section.

Fuel Gauge



66T020300

When the ignition switch is in "ON" position or the ignition mode is ON, this gauge gives a rough indication of the amount of fuel in the fuel tank. "F" stands for full and "E" stands for empty.

If the fuel meter indicator shows only one segment to "E", refill the tank as soon as possible.

NOTE:

If the last segment blinks, it means that the fuel is almost empty.

If the low fuel warning light (1) comes on, refill the fuel tank immediately.

NOTICE

To minimize the possibility of damage to catalytic converter or other components of the vehicle, avoid driving the vehicle near empty fuel tank level.

NOTE:


The activation point of the low fuel warning light (1) varies depending on road conditions (for example, slope or curve) and driving conditions because of fuel movement in the tank.

Refer to "Low fuel warning light" in "Warning and indicator lights" in this section for details.

The mark (2) indicates that the fuel filler door is located on the left side of the vehicle.

INSTRUMENT CLUSTER

Temperature Gauge



74TB0401

When the ignition switch is in "ON" position or the ignition mode is "ON", this gauge indicates the engine coolant temperature. Under normal driving conditions, the indicator should stay within the normal, acceptable temperature range between "H" and "C". If the indicator approaches "H", overheating is indicated. When the engine overheats, the Engine Coolant Temperature Light (1) will be ON. Follow the instructions for engine overheating in "EMERGENCY SERVICE" section

NOTICE

Continuing to drive the vehicle when engine overheating is indicated can result in severe engine damage.

Brightness Control



52RS20090

When the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, the instrument panel lights come on.

Your vehicle has a system to automatically dim the brightness of the instrument panel lights when the position lights or headlights are on.


When the position lights and/or headlights are on, you can adjust the meter illumination brightness.

To increase the brightness of the instrument panel lights, turn the indicator selector knob (1) clockwise.

To reduce the brightness of the instrument panel lights, turn the indicator selector knob (1) counterclockwise.

WARNING

Do not adjust the brightness of the instrument panel lights while driving. Otherwise, you could lose control of the vehicle.



55TB406

NOTE:

- If you do not turn the knob within several seconds of activating, the brightness control display will be canceled automatically.*
- When you reconnect the lead-acid battery, the brightness of the instrument panel lights will be reinitialized. Readjust the brightness according to your preference.*


NOTE:

If you adjust to the maximum brightness level when the position lights or headlights are on, the following functions will be canceled.

- The function which automatically dims the brightness of instrument panel lights*
- The function which operates with the brightness control, except maximum brightness level*


Information Display (Type A)

Information display is shown when the ignition switch is turned to "ON" position or the ignition mode is ON.



55TB405

- (1) Trip meter selector knob
 (2) Indicator selector knob



55TB407

- (3) Information display

The information display shows the following information.

Display (A)
 Fuel gauge

Display (B)
 Trip meter / Odometer / Fuel consumption / Driving range

Display (C)
 Thermometer (if equipped)

Display (D)
 Selector position (for automatic transmission vehicles) / Gear position (for automatic transmission vehicles) / Gearshift indicator (for manual transmission vehicles)

Display (E)
 Temperature gauge

Display (F)
 Parking sensor indication and door open indication (if equipped)

Display (G)
 Clock

Display (H)
 Energy flow (If equipped)

INSTRUMENT CLUSTER

Clock

The display (G) shows the time.

To change the time indication:

- 1) Push the trip meter selector knob (1) and the indicator selector knob (2) together.
- 2) To change the hour indication, turn the indicator selector knob (2) left or right repeatedly when the hour indication blinks. To change the hour indication quickly, turn and hold the indicator selector knob (2). To set the hour indication, push the indicator selector knob (2) and the minute indication will blink.
- 3) To change the minute indication, turn the indicator selector knob (2) left or right repeatedly when the minute indication blinks. To change the minute indication quickly, turn and hold the indicator selector knob (2). To set the minute indication, push the indicator selector knob (2).


To select 12/24H format, refer to "Setting mode" in this section.

⚠ WARNING

If you attempt to adjust the display while driving, you could lose control of the vehicle.
Do not attempt to adjust the display while driving.

Thermometer (if equipped)

The display (C) shows the thermometer. The thermometer indicates the outside temperature.




If the outside temperature drops to freezing condition, the mark (a) will appear on the display.

NOTE:


- The outside temperature indication is not the actual outside temperature when driving at low speed, or when stopped.
- If there is something wrong with the thermometer, or just after the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, the display may not indicate the outside temperature.

When the display (B) shows the driving range, you can change the unit of temperature.

To change the unit of temperature, while pushing and holding the trip meter selector knob (1), turn the indicator selector knob (2).



Selector position (for Automatic Transmission vehicles) / Gear position (for Automatic transmission vehicles) / Gearshift Indicator (for manual transmission vehicles)



Selector position (for automatic transmission vehicles) /

Gear position (for automatic transmission vehicles)

The display (D) shows the transmission selector position (16) or the gear position (17).

- When the manual mode is not in use, the display shows the selector position.
- When using the manual mode, the display shows the current gear position.

For details on how to use the transmission, refer to "Using transmission" in "OPERATING YOUR VEHICLE" section.

Manual mode indicator

(for automatic transmission vehicles)

When you are using the manual mode, the display shows the manual mode indicator (18).


Gearshift Indicator (for manual transmission vehicles)

Refer to "Gearshift indicator" in "OPERATING YOUR VEHICLE" section.

Trip Meter / Odometer / Fuel Consumption / Driving Range

The display (B) shows one of the following indications; trip meter A, trip meter B, odometer, instantaneous fuel consumption, average fuel consumption or driving range.

To switch the display indication (B), push the trip meter selector knob (1) or the indicator selector knob (2) quickly.



55T040230

	Push the trip meter selector knob (1).
	Push the indicator selector knob (2).

(b) Trip meter A

(c) Trip meter B

(d) Odometer

(e) Instantaneous fuel consumption

(f) Average fuel consumption

(g) Driving range

! WARNING

If you attempt to adjust the display while driving, you could lose control of the vehicle.

Do not attempt to adjust the display while driving.

NOTE:

- Indications will change when you push and release a knob.
- The display shows estimated values. Indications may not be the same as actual values.

INSTRUMENT CLUSTER

Trip meter

The trip meter can be used to measure the distance traveled on short trips or between fuel stops.

You can use the trip meter A or trip meter B independently.

To reset the trip meter, push and hold the trip meter selector knob (1) until the display shows 0.0.

NOTE:

The indicated maximum value of the trip meter is 9999.9. When you run past the maximum value, the indicated value will return to 0.0.

Odometer

The odometer records the total distance the vehicle has been driven.

NOTICE

Keep track of your odometer reading and check the maintenance schedule regularly for required services. Increased wear or damage to certain parts can result from failure to perform required services at the proper mileage intervals.

Instantaneous fuel consumption

The display shows the value of instantaneous fuel consumption only when the vehicle is moving.

NOTE:

- The display does not show the value unless the vehicle is moving.*
- Depending on the vehicle's specification, the fuel consumption units of initial setting are indicated as L/100km or km/L.*
- For "L/100km" setting, the indicated maximum value of instantaneous fuel consumption is 30. No more than 30 will be indicated on the display even if the actual instantaneous fuel consumption is higher.*
- For "km/L" setting, the indicated maximum value of instantaneous fuel consumption is 50. No more than 50 will be indicated on the display even if the actual instantaneous fuel consumption is higher.*
- The indication on the display may be delayed if fuel consumption is greatly affected by driving conditions.*
- The display shows estimated values. Indications may not be the same as actual values.*
- For "L/100km" or "km/L" setting, you can change the units that instantaneous fuel consumption is displayed in. Refer to "Average fuel consumption" in this section.*

Average fuel consumption

If you selected average fuel consumption the last time you drove the vehicle, the display shows the last value of average fuel consumption from previous driving when the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON. Unless you reset the value of average fuel consumption, the display indicates the value of average fuel consumption which includes average fuel consumption during previous driving.


To reset the average fuel consumption, push and hold the indicator selector knob (2) for a while when the display shows the average fuel consumption.

NOTE:

When you reset the indication or reconnect the negative (-) terminal to the lead-acid battery, the value of average fuel consumption will be shown after driving for a while.

(For "L/100km" or "km/L" setting)

To change the unit of average fuel consumption, while pushing and holding the trip meter selector knob (1), turn the indicator selector knob (2).



NOTE:

When you change the units that average fuel consumption is displayed in, the instantaneous fuel consumption units will be changed automatically.

Driving range

If you selected driving range the last time you drove the vehicle, the display indicates "----" for a few seconds and then indicates the current driving range when the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON.

The driving range shown in the display is an indicative unit of the approximate distance you can drive until the fuel gauge indicates "E", based on current driving conditions and current fuel level in the fuel tank.

When the low fuel warning light comes on, the display "----" will appear.

If the low fuel warning light comes on, fill the fuel tank immediately regardless of the value of driving range shown in the display.

When you refuel, the driving range is updated. However, if you only add a small amount of fuel, the correct value will not be displayed.

NOTE:

- If you refuel when the ignition switch is in "ON" position or the ignition mode is ON, the driving range may not indicate the correct value.
- When you reconnect the negative (-) terminal to the lead-acid battery, the value of driving range will be shown after driving for a while.
- If there are substantial changes in the driving pattern or vehicle usage, the displayed range may vary significantly.

Fuel Gauge

The display (A) shows the fuel gauge.

Refer to "Fuel gauge" in this section.

Parking Sensor Indication and Door Open Indication (if equipped)

The display (F) shows the parking sensor indication and door open display indication.

Individual door and tail gate is indicated when the respective door or tail gate is not closed properly.

Refer to "Parking Sensor" in the "Operating your vehicle" section.

INSTRUMENT CLUSTER

Energy flow (if equipped)

The state of SHVS operation can be checked on the information display. For details, refer to "SHVS (Smart Hybrid Vehicle by Suzuki)" in "OPERATING YOUR VEHICLE" section.

Information display	Description
 66T040080	When the vehicle is running, ISG (Integrated Starter Generator) assists engine power as an electric motor
 66T040090	When the vehicle is powered by the engine
 66T040100	When decelerating your vehicle, the ISG generates electricity without engine power
 66T040110	When the engine automatically stops by the ENG A-STOP system

Setting Mode

In the setting mode, you can set up and customize the following functions.

Indication	Functions
  	12-hour format "CL - 12h"    
  	Central door locking system "d1"    
  	Automatic door locking function "d2"    
  	Automatic door unlocking function "d3"    
  	Door locking and unlocking siren "d5"    
  	Additional flashes of the turn signal "L2"    
  	Lighting time of the "To car" function "G1" (if equipped)    

INSTRUMENT CLUSTER

Indication	Functions
 SECUR-Y  <i>S2</i> 	Shock sensor "S2"
 <i>S3</i> 	Pre-warning sensitivity of the shock sensor "S3"
 <i>S4</i> 	Full blast warning sensitivity of the shock sensor "S4"
 AC  <i>norNRL</i> 	"Normal" engine auto stop setting for Auto A/C operation "norNRL"
 <i>ECo</i> 	"Economy" engine auto stop setting for Auto A/C operation "ECo"
 <i>CoNf</i> 	"Comfort" engine auto stop setting for Auto A/C operation "CoNf"
 EnECha  <i>En-on</i> 	Enable the deceleration energy regenerating indicator light "En-on"
 <i>En-off</i> 	Disable the deceleration energy regenerating indicator light "En-off"
 dEFAUL  <i>dE-on</i> 	Initialization setting "dE-on"
 <i>End</i> 	Exit the setting mode "End"

	Turn the indicator selector knob (2).
	Push the indicator selector knob (2).

NOTE:

Depending on vehicle's specifications, some items may not be displayed.

How to use the setting mode:

- 1) When the ignition switch is in "ON" position or the ignition mode is ON, and the vehicle is stationary.
- 2) Push and hold the indicator selector knob (2) until the display shows "ELoEL".
- 3) Turn and/or push the indicator selector knob (2) to select a function that you want to set up according to the chart in the previous page.
- 4) Turn and/or push the indicator selector knob (2) to register settings of the following functions.

SEL
d1-SL2

68PM00272

NOTE:

- As shown in the above illustration, "SEL" indicates on the display of currently setting item.
- To go back to the higher level display during operation, turn the indicator selector knob (2) to display "BRCH" or "-BR" and then push the indicator selector knob (2).

Time indication of clock "EL"

- EL-12h: 12-hour format (default setting)
- EL-24h: 24-hour format

Central door locking system "d1"

- d1-SL1: Unlock all doors by turning the key once
- d1-SL2: Unlock all doors by turning the key twice (default setting)

Automatic door locking function "d2"

- d2-SL1: Disable the automatic door locking function
- d2-SL2: Lock all doors when the vehicle speed reaches 15 km/h (default setting)
- d2-SL3: (For automatic transaxle vehicle) Lock all doors when the gearshift lever is in other than "P"

Automatic door unlocking function "d3"

- d3-SL1: Disable the automatic door unlocking function

- d3-SL2: Unlock all doors when the key is pulled out from the ignition switch (default setting)
- d3-SL3: (For automatic transaxle vehicle) Unlock all doors when the gearshift lever is moved to the "P" from other position.

Door locking and unlocking siren "d5"

- d5-SL1: Siren sounds when the doors (including the tailgate) are locked or unlocked by using the keyless entry system transmitter (default setting)
- d5-SL2: Siren does not sound when the doors (including the tailgate) are locked or unlocked by using the keyless entry system transmitter

Additional flashes of the turn signal "L2"

- L2-SL1: Turn signal flashes three times after the turn signal lever is returned (default setting)
- L2-SL2: Disable the additional flashes of turn signal

Lighting time of the "To car" function "G1" (if equipped)

- G1-SL1: Disable the "To car" function
- G1-SL2: 10 seconds (default setting)
- G1-SL3: 15 seconds
- G1-SL4: 20 seconds
- G1-SL5: 25 seconds

INSTRUMENT CLUSTER

Lighting time of the “To home” function “*G2*” (if equipped)

- *G2-SL1*: Disable the “To home” function
- *G2-SL2*: 10 seconds (default setting)
- *G2-SL3*: 15 seconds
- *G2-SL4*: 20 seconds
- *G2-SL5*: 25 seconds
- *G2-SL6*: 30 seconds

Shock sensor “*S2*”

- *S2-SL1*: Enable the shock sensor
- *S2-SL2*: Disable the shock sensor (default setting)

Pre-warning sensitivity of the shock sensor “*S3*”

- *S3-L00*: Disable the pre-warning
- *S3-L01* to *L15*:
Adjust the pre-warning sensitivity of shock sensor (Lowest sensitivity level is L01 and highest is L15, and default setting is L14)

Full blast warning sensitivity of the shock sensor “*S4*”

- *S4-L00*: Disable the full blast warning
- *S4-L01* to *L15*:
Adjust the full blast warning sensitivity of shock sensor (Lowest sensitivity level is L01 and highest is L15, and default setting is L09)

Engine auto stop setting for Auto A/C “*AC*” (if equipped)

- *norNRL*: Set engine auto stop condition occurrence frequency in between that of “economy” and “comfort” (default setting)
- *ECo*: When “economy” is selected, engine auto stop condition is eased, compared with “normal”. As engine auto stop condition will occur more frequently, the stop time will be longer, leading to reduction of fuel consumption.

CoNF: When “comfort” is selected, engine auto stop condition becomes severe, compared with “normal”. As engine auto stop condition will occur less frequently, the stop time will be shorter, leading to more comfortable cabin condition by air conditioner.

Deceleration energy regenerating indicator light setting “*EnEChR*” (if equipped)

- *En-on*: Enable the deceleration energy regenerating indicator light
- *En-off*: Disable the deceleration energy regenerating indicator light

Initialization setting “*dE-on*”

dE-on: Initialize all settings

Initialization setting “*dE-on*”


- *dE-on*: Initialize all settings

How to exit the setting mode:

Switch the display to show “*End*” and then push the indicator selector knob (2).

Instrument Cluster (Type B)

- 1. Speedometer
- 2. Tachometer
- 3. Fuel gauge
- 4. Temperature gauge
- 5. Information display
- 6. Trip meter selector knob
- 7. Indicator selector knob
- 8. Warning and indicator lights



55TB412

INSTRUMENT CLUSTER

Speedometer

The speedometer indicates vehicle speed.

Speed Alert System

The speed alert system gives audible warning for alert of over-speed to driver. When vehicle speed exceeds about 80 km/h, primary level warning with two beeps will sound every minute. When the vehicle speed exceeds about 120 km/h, secondary level warning with continuous beeps will sound.

If the vehicle speed is slowed down to about 118 km/h, primary warning will resume. If the vehicle is slowed down to about 78 km/h, speed alert warning will stop. This buzzer does not indicate any malfunction in vehicle.

Tachometer

The tachometer indicates engine speed in revolutions per minute.


NOTICE

Never drive the vehicle with the engine revving in the red zone or severe engine damage can result.

Keep the engine speed below the red zone even when downshifting to a lower gear position.

Refer to "Downshifting maximum allowable speeds" in "OPERATING YOUR VEHICLE" section.

Fuel Gauge



55T040120

When ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, this gauge gives a rough indication of the amount of fuel in the fuel tank. "F" stands for full and "E" stands for empty.

If the indicator approaches a low level (near "E") on fuel gauge, refill the tank as soon as possible.

NOTE:

The indicator moves a little depending on road conditions (for example, slope or curve) and driving conditions because of fuel movement in the tank.

If the low fuel warning light (1) comes on, refill the fuel tank as soon as possible.

NOTICE

- To minimize the possibility of damage to catalytic converter or other components of the vehicle, avoid driving the vehicle near empty fuel tank level.


NOTE:

The activation point of the low fuel warning light (1) varies depending on road conditions (for example, slope or curve) and driving conditions because of fuel movement in the tank.

Refer to "Low fuel warning light" in "Warning and indicator lights" in this section for details.

The mark (2) indicates that the fuel filler door is located on the left side of the vehicle.

Temperature Gauge




55T040130

When the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, this gauge indicates the engine coolant temperature. Under normal driving conditions, the indicator should stay within the normal, acceptable temperature range between "H" and "C". If the indicator approaches "H", overheating is indicated. Follow the instructions for "Engine trouble: Overheating" in "EMERGENCY SERVICE" section.


NOTICE

Continuing to drive the vehicle when engine overheating is indicated can result in severe engine damage.



55TB406

Brightness Control



56RM02010

Your vehicle has a system to automatically dim the brightness of the instrument panel lights when the position lights or headlights are on.

When the position lights and/or headlights are on, you can adjust the meter illumination brightness.

To increase the brightness of the instrument panel lights, turn the indicator selector knob (1) clockwise.

To reduce the brightness of the instrument panel lights, turn the indicator selector knob (1) counterclockwise.

WARNING

Do not adjust the brightness of the instrument panel lights while driving. Otherwise, you could lose control of the vehicle.

NOTE:

- If you do not turn the knob within several seconds of activating, the brightness control display will be cancelled automatically.
- When you reconnect the lead-acid battery, the brightness of the instrument panel lights will be reinitialized. Readjust the brightness according to your preference.

NOTE:


If you adjust to the maximum brightness level when the position lights or headlights are on, the following functions will be canceled.

- The function which automatically dims the brightness of instrument panel lights
- The function which operates with the brightness control, except maximum brightness level

INSTRUMENT CLUSTER


Information Display (Type B)

The information display is shown when the ignition mode is "ON".



55TB411

1) Information display



55TB410

(2) Trip meter selector knob
(3) Indicator selector knob

The information display shows the following information.

Display (A)

Clock

Display (B)

Thermometer (If equipped)

Display (C)


Warning and indicator messages / Fuel consumption / Driving range / Average Speed / Driving time / Total idling stop time and Total idling fuel saved (if equipped) / Clock and date / Motion (if equipped) / Torque and power / Accelerator and brake (if equipped) / Cruise control (if equipped) / Energy flow (if equipped), Intersection guidance

Display (D)

Selector position / Gearshift indicator (if equipped)

Display (E)

Odometer / Trip meter



74TB0408

When the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, the message display shown in the above illustration will appear on the display for several seconds.

Some warning and indicator messages may appear on the display when the ignition switch to "ACC" or "LOCK" position or change the ignition mode to ACC or LOCK (OFF)

Clock

The display (A) shows the time.

To set the clock, follow "Setting mode" instructions in this section.

WARNING


If you attempt to adjust the display while driving, you could lose control of the vehicle.

Do not attempt to adjust the display while driving.

Thermometer (if equipped)

The display (B) shows the thermometer.

The thermometer indicates the outside temperature.



52RM21050

If the outside temperature nears freezing condition, the message shown in the above illustration will appear on the display.

To change the temperature unit between $^{\circ}\text{C}$ and $^{\circ}\text{F}$, follow "Setting mode" instructions in this section.

NOTE:


- The outside temperature indication is not the actual outside temperature when driving at low speed, or when stopped.*
- If there is something wrong with the thermometer, or just after the ignition switch is turned "ON" or pushed to "ON" mode, the display may not indicate the outside temperature.*

Fuel Consumption / Driving Range / Average Speed / Driving Time / Total Idling Stop Time and Total Idling Fuel Saved (if equipped) / Clock and Date / Motion (if equipped) / Torque and Power / Accelerator and Brake (if equipped) / Energy flow (if equipped)

When there are no warning or indicator messages on the display (C), you can select one of the following indications to appear on the display: instantaneous fuel consumption, average fuel consumption, driving range, average speed, driving time, total idling stop time and total idling fuel saved (if equipped), clock and date, motion, torque and power, accelerator and brake (if equipped) or no indication.

WARNING

If you attempt to adjust the display while driving, you could lose control of the vehicle. Do not attempt to adjust the display while driving.



55TB401

INSTRUMENT CLUSTER

- (a) Instantaneous fuel consumption / Average fuel consumption / Driving range
- (b) Instantaneous fuel consumption / Average fuel consumption / 5-minute average fuel consumption
- (c) Average speed / 5-minute average speed / Driving time
- (d) Total idling stop time and total idling fuel saved (if equipped)
- (e) Clock and date
- (f) Motion (if equipped)
- (g) Torque and power
- (h) Accelerator and brake (if equipped)
- (i) Energy flow (if equipped)
- (j) No indication

To switch the display indication, push the indicator selector knob (3) quickly.


NOTE:

The value of instantaneous fuel consumption, average fuel consumption, driving range, average speed, total idling fuel saved (if equipped), motion (if equipped), torque and power, accelerator and brake and energy flow (if equipped) shown on the display are affected by the following conditions;

- road condition
- surrounding traffic condition
- driving condition
- vehicle condition
- a malfunction which causes the malfunction indicator light to come on or blink

Instantaneous fuel consumption

The display shows instantaneous fuel consumption with a bar graph only when the vehicle is moving.



52RM21070

(4) Instantaneous fuel consumption

NOTE:


- The display does not show the bar graph unless the vehicle is moving.
- Depending on the vehicle's specification, the fuel consumption units of initial setting are indicated as L/100km, km/L or MPG.
- For "L/100km" setting, the indicated maximum value of instantaneous fuel consumption is 30. No more than 30 will be indicated on the display even if the actual instantaneous fuel consumption is higher.

- For "km/L" setting, the indicated maximum value of instantaneous fuel consumption is 50. No more than 50 will be indicated on the display even if the actual instantaneous fuel consumption is higher.
- For "MPG(UK)" setting, the indicated maximum value of instantaneous fuel consumption is 80. No more than 80 will be indicated on the display even if the actual instantaneous fuel consumption is higher.
- The indication on the display may be delayed if fuel consumption is greatly affected by driving conditions.
- The display shows estimated values. Indications may not be the same as actual values.

Average fuel consumption / 5-minute average fuel consumption / 1-driving cycle average fuel consumption

Average fuel consumption from previous reset and 5-minute average fuel consumption, and 1-driving cycle average fuel consumption are shown.

(Average fuel consumption)



(5) Average fuel consumption

If you selected average fuel consumption the last time you drove the vehicle, the display shows the last value of average fuel consumption from previous driving when the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON. Unless you reset the value of average fuel consumption, the display indicates the value of average fuel consumption based on the average fuel consumption during previous driving.

NOTE:

When you reconnect the negative (-) terminal to the lead-acid battery, the value of average fuel consumption will be shown after driving for a period of time.

You can select the timing to reset the value of average fuel consumption by one of the following three methods;


- Reset after refuel: the value of average fuel consumption will be reset automatically by refueling.
- Reset with trip meter A: the value of average fuel consumption will be reset automatically by resetting trip meter A.
- Reset manually: the value of average fuel consumption will be reset by pushing and holding the indicator selector knob (3) when the display indicates the average fuel consumption.

To change the timing to reset the value of average fuel consumption, refer to "Setting mode" in this section.

NOTE:


If you add only a small amount of fuel when you select "Reset after refuel", the average fuel consumption value may not be reset.

(5-minute average fuel consumption)



(6) 5-minute average fuel consumption

(1-driving cycle average fuel consumption)




(7) 1-driving cycle average fuel consumption

INSTRUMENT CLUSTER

You can check transition of average fuel consumption every 5 minutes from 15 minutes before up to now. Also, you can check transition of average fuel consumption the past 3 driving cycles. Time indication and driving cycle indication can be changed. For details, refer to "Setting mode" in this section.

Driving range



(8) Driving range

If you selected driving range the last time you drove the vehicle, the display indicates "___" for a few seconds and then indicates the current driving range when the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON.

The driving range shown in the display is an indicative unit of the approximate dis-

tance you can drive until the fuel gauge indicates "E", based on current driving conditions and current fuel level in the fuel tank.

When the low fuel warning light comes on, the display "___" will appear.

If the low fuel warning light comes on, fill the fuel tank immediately regardless of the value of driving range shown in the display.

When you refuel, the driving range is updated. However, if you only add a small amount of fuel, the correct value will not be displayed.


NOTE:

- If you refuel when the ignition mode is "ON", the driving range may not indicate the correct value.
- When you reconnect the negative (-) terminal to the lead-acid battery, the value of driving range will be shown after driving for a period of time.
- If there are substantial changes in the driving pattern or vehicle usage, the displayed range may vary significantly.

Average speed / 5-minute average speed

Average speed from previous reset and 5-minute average speed are shown.

(Average speed)



(9) Average speed

If you selected average speed the last time you drove the vehicle, the display indicates the last value of average speed from previous driving when the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON. Unless you reset the value of average speed, the display indicates the value of average speed which includes average speed during previous driving.


To reset the value of average speed, push and hold the indicator selector knob (3) for about 2 seconds when the display indicates an average speed. The display

shows “---” and then indicates a new average speed after driving for a short time.

NOTE:

When you reconnect the negative (-) terminal to the lead-acid battery, the value of average speed will be shown after driving for a period of time.


(5-minute average speed)



(10) 5-minute average speed

You can check transition of 5-minute average speed every 5 minutes from 10 minutes before up to now.

Driving time




(11) Driving time

Driving time from previous reset is shown. To reset the driving time, push and hold the indicator selector knob (3) for about 2 seconds when the display indicates a driving time. The display shows “---” and then indicates a new driving time after driving for a short time.

NOTE:

- *Disconnection of the lead-acid battery negative (-) terminal will reset the indication of the driving time.*
- *The indicated maximum value of driving time is 99:59:59. No more than this value will be indicated on the display until you reset the driving time.*

Total idling stop time and total idling fuel saved (if equipped)



(12) Total idling stop time

(13) Total idling fuel saved

The display shows the total length (in hours, minutes and seconds) of engine stopping time and the total amount (in milliliters) of fuel conservation by ENG A-STOP system since the indication was reset.

- To reset the total idling stop time and the total idling fuel saved, push and hold the indicator selector knob (3) for a while when the display shows the total idling stop time and the total idling fuel saved.

NOTE:

- *The indicated maximum value of the total idling stop time is 99:59:59 and this value is fixed until it is reset.*


INSTRUMENT CLUSTER

- When you reconnect the negative (-) terminal to the lead-acid battery, the value of the total idling stop time and the total idling fuel saved will be reset.

Clock and date

Date and time are shown. For the setting procedure, refer to "Setting mode" in this section.

Motion (if equipped)



52RM218

The meter indication is different depending on whether the vehicle is stopped or running.

G (acceleration of gravity) position applied to the vehicle body while driving is shown by a globe (14).

When the vehicle is stopped, historical data of G positions applied to the vehicle body during the driving is shown as a graph (15).

G position history graph at the vehicle stopped can be changed to indicate or hide. For details, refer to "Setting mode" in this section.

! WARNING

Do not look in the display intensively while driving. Doing so may result in an unexpected accident.

NOTE:

- If G position history graph at the vehicle stopped has been set in indication mode, the graph (15) is shown for several seconds when you turn the ignition switch to "LOCK" position or change the ignition mode to "LOCK" (OFF) after driving.
- The graph is shown approximately and the actual movement may differ.

Torque and power

Present engine torque and power are shown.

Accelerator and brake (if equipped)

Present accelerator pedal depressing degree and brake line pressure are shown. The display is selectable to indicate or not to indicate. For details, refer to "Setting mode" in this section.


Energy flow (if equipped)

The state of Smart Hybrid operation can be checked on the information display. For details, refer to "Smart Hybrid" in "OPERATING YOUR VEHICLE" section.

Information display	Description
 74TB0409	When the vehicle is running, ISG (Integrated Starter Generator) assists engine power as an electric motor.
 74TB04010	When the vehicle is powered by the engine.
 74TB04011	When decelerating your vehicle, the ISG generates electricity without engine power.
 74TB04012	When the engine automatically stops by the ENG A-STOP system.

Information shown after driving


When you turn the ignition switch to "LOCK" position or press the engine switch to change the ignition mode to "LOCK" (OFF), the following information appears for several seconds on the information display.



53SB2036

INSTRUMENT CLUSTER

Intersection Guidance (When using Android Auto^{TM*1} or Apple CarPlay^{*2} on infotainment system)



59RN04710

The display shows the direction of your driving and the distance, working with the infotainment system.

NOTE:

- A slight time lag may occur between the intersection guidance on the information display and the guidance from the infotainment system.
- Switch the intersection guidance to ON or OFF while the guidance from the infotainment system is displayed.
 - A time lag may occur between ON display and OFF display of the intersection guidance.
 - For the functions and operations of the infotainment system, refer to the supplementary manual, provided along with it.

- You can display or hide the intersection guidance by changing the setting (customization). For details, refer to "Setting Mode" in this section.


*1: Android AutoTM may not be available in your country or region.

For details about Android AutoTM, refer to <http://support.google.com/androidauto>

*2: Apple CarPlay may not be available in your country or region.

For details about Apple CarPlay, refer to <https://www.apple.com/ios/carplay/>

Light switch position display (if equipped)




74TB04013

The display indicates the position of lighting switch selected for exterior light.

The display can be set as ON/OFF by changing the setting (customization).

For details, refer to "Setting Mode" in this section.

Selector position (for automatic transmission vehicles) / Gear position (for automatic transmission vehicles) / Gearshift Indicator (for manual transmission vehicles)



74TB04014

Selector position (for automatic transmission vehicles) / Gear position (for automatic transmission vehicles)

The display shows the transmission selector position (16) or the gear position (17).

- When the manual mode is not in use, the display shows the selector position.
- When using the manual mode, the display shows the current gear position.

For details on how to use the transmission, refer to "Using transmission" in "OPERATING YOUR VEHICLE" section.

Manual mode indicator (for automatic transmission vehicles)

When you are using the manual mode, the display shows the manual mode indicator (18).

NOTE:

For Auto Gear Shift models, the manual mode indicator will only appear when the gearshift lever is in "M".

Drive mode indicator (for Auto Gear Shift vehicles)

When the gearshift lever is in "D", the display shows the drive mode indicator (16).

For details on how to use the transmission, refer to "Using transmission" in the "OPERATING YOUR VEHICLE" section.

Gearshift Indicator (for manual transmission vehicles)

Refer to "Gearshift indicator" in "OPERATING YOUR VEHICLE" section.

Odometer / Trip Meter

The display (E) shows the odometer and trip meter.

The odometer records the total distance the vehicle has been driven.

The trip meter can be used to measure the distance traveled on short trips or between fuel stops.

You can use trip meter A or trip meter B independently.

To switch the display indication (E), push the trip meter selector knob (2) quickly.

To reset the trip meter, push and hold the trip meter selector knob (2) for few seconds when the display shows the trip meter.


NOTICE

Keep track of your odometer reading and check the maintenance schedule regularly for required services. Increased wear or damage to certain parts can result from failure to perform required services at the proper mileage intervals.

Setting Mode

When the ignition switch is in "ON" position or the ignition mode is ON and the vehicle is stationary, you can enter into the setting mode of the information display by pushing and holding the indicator selector knob (3) for few seconds.

- To select the setting item that you want to change, turn the indicator selector knob (3) left or right.
- To change the setting, push the indicator selector knob (3).
- To exit the setting mode, select "Back" and push the indicator selector knob (3).



74TB04015

NOTE:

The currently selected setting item is surrounded by a frame.

INSTRUMENT CLUSTER

NOTE:

- If you push and hold the indicator selector knob (3) to enter into the setting mode when the display (D) shows average fuel consumption, average speed, driving time, total idling stop time and total idling fuel saved (if equipped), the value will be reset simultaneously. If you do not want to reset the value, push the indicator selector knob quickly to switch the indication of the display.
- If you turn the ignition switch, press the engine switch or start to move the vehicle when the display is in the setting mode, the setting mode will be cancelled automatically.

Distance unit

(Odometer / trip meter / driving range / average speed distance unit setting)

You can change the units in which odometer / trip meter / driving range / average speed distance is displayed.

Fuel economy

(Fuel consumption unit setting)

You can change the units that fuel consumption is displayed in.

Language

You can change the language of the information display.

Fuel reset

(Average fuel consumption reset setting)

You can change when the value of average fuel consumption is reset.

Temperature (Temperature unit setting)

You can change the units that temperature is displayed in.

- To change the temperature unit, select "Temperature" in "Setting mode". Then, select "°C" or "°F".

NOTE:

When you change the units that temperature is displayed in, the automatic heating and air conditioning system (if equipped) temperature display units will be changed automatically.

Set sensors

(Parking sensor setting) (if equipped)

The parking sensor can be switched between the normal mode and trailer mode.

Clock setting (if equipped)

(Adjusting the clock)

- Adjust the clock by selecting "Clock setting" in "Setting mode". Then, select "Adjust clock".
- To change the hour indication, turn the indicator selector knob (3) left or right repeatedly when the hour indication blinks. To change the hour indication quickly, turn and hold the indicator selector knob (3). To set the hour indication, push the indicator selector knob (3) and the minute indication blinks.
- To change the minute indication, turn the indicator selector knob (3) left or right repeatedly when the minute indication blinks. To change the minute indication quickly, turn and hold the indicator selector knob (3). To set the minute indication, push the indicator selector knob (3).

repeatedly when the minute indication blinks. To change the minute indication quickly, turn and hold the indicator selector knob (3). To set the minute indication, push the indicator selector knob (3).

(Selecting 12H / 24H format)

- Switch the time indication between 12-hour and 24-hour format by selecting "Clock setting" in "Setting mode". Then, select "12H" or "24H".

(Adjusting the date)

- Adjust the date by selecting "Clock setting" in "Setting mode". Then select "Adjust date".
- To adjust year, month and day, operate the indicator selector knob (3) in the same way as adjusting the clock.

Door lock (Door lock setting)

(Door unlock)

- All Doors:
Unlock all doors by keyless push start system remote controller or request switch once
- Driver Door:
Unlock all doors by keyless push start system remote controller or request switch twice (default setting)

(Auto lock)

- Manual Lock:
Disable the automatic door locking function
- Speed Syncro:
Lock all doors when the vehicle speed reaches 15 km/h (default setting)

- Shift Syncro: (if equipped)
Lock all doors when the gearshift lever is in other than "P" position.

(Auto unlock)

- Syncro Off:
Disable the automatic door unlocking function (default setting for the vehicle with the keyless push start system)
- IG-OFF Sync:
Unlock all doors when the engine switch is pressed to change the ignition mode to LOCK (OFF) (default setting for the vehicle without the keyless push start system)
- Shift Syncro: (if equipped)
Unlock all doors when the gearshift lever is moved from other position to "P" position.

(Alarm)

- You can turn off or on the siren sound when the door(s) is(are) locked or unlocked.

(Door mirror) (if equipped)

- ON:
Enable the mirror auto retract function (default setting).
- OFF:
Disable the mirror auto retract function.

Lights**(Foot lights setting)
(if equipped)**

The foot lights can be programmed for interlocked operation with either lighting

control or door operation and for no lighting.

(Lane change setting)

The turn signal and its indicator can be set whether they flash three times even if you return the turn signal control lever shortly after operating it.

- To change the lane change setting, select "Lane Change" in "Setting mode". Then, select "ON" or "OFF".
- If you want to change the number of flashing, consult a Maruti Suzuki authorized workshop.

Guide me light setting (if equipped)

You can change the lighting time of "To car" function or "To home" function.

Antitheft**(Shock sensor system setting)**

You can change the on/off of the shock sensor.

(Shock sensor P setting)

You can adjust the pre-warning sensitivity of shock sensor.

(Shock sensor F setting)

You can adjust the full blast warning sensitivity of shock sensor.

IS A/C**(ENG A-STOP system setting)
(if equipped)**

- When using the automatic heating and air conditioning system (if equipped),

you can select one of the following engine auto stop settings.

- Standard
- Economy
- Comfort

- When "Economy" is selected, engine auto stop condition is eased, compared with "Standard". As engine auto stop condition will occur more frequently, the stop time will be longer, leading to reduction of fuel consumption.
- When "Comfort" is selected, engine auto stop condition becomes severe, compared with "Standard". As engine auto stop condition will occur less frequently, the stop time will be shorter, leading to more comfortable cabin condition by air conditioner.

Display item**("Car color" setting)**

You can change the car color of the information display.

("Calendar dis" setting)

You can select whether you show the calendar on the information display or not.

("Calendar form" setting)

You can change the calendar form of the information display.

To change the calendar form, select "Calendar form" in "Display item". Then, select the display order of date, month and year.

INSTRUMENT CLUSTER

(“Fuel eco hist” setting)

Transitional indication of average fuel consumption can be switched to time indication and driving cycle indication.

(“Motion hist” setting) (if equipped)

Indication of G position history graph at the vehicle stopped can be selected to enable or disable.

(“Idling disp” setting)

Display of ENG A-STOP operation with ignition mode LOCK (OFF) is selectable to indicate or not to indicate.

(“Idling warn” setting)

You can switch whether the information display shows the warning and indicator messages related on the ENG A-STOP system.

(“Regen disp” setting) (if equipped)

You can choose that deceleration energy regenerating indicator light comes on or does not come on.

(“Parking sensors” setting) (if equipped)

Display of “Parking sensors” is selectable to indicate or not to indicate.

(“Intersection” setting) (if equipped)

Display of “Intersection” is selectable to indicate or not to indicate.

(“Lights” setting) (if equipped)

You can change ON/OFF of Light switch position display.

Animation

(“warning” setting)

Display of “Animation (warning)” is selectable to indicate or not to indicate.

Head-up Display setting (if equipped) (Vehicle speed)

You can change ON/OFF of the vehicle speed.

(Gear position)

You can change ON/OFF of the gear position.

(Clock)

You can change ON/OFF of the clock.

(Intersection guidance) (working with the infotainment system)

You can change ON/OFF of the intersection guidance.

(Air conditioning system)

You can change ON/OFF display of the air conditioning system.

(High temperature warning message)

You can change ON/OFF of the high temperature warning message.

Default

(Initialization setting)

If you select “YES” and push the indicator selector knob (3), all settings will be reinitialized.

Warning and Indicator Messages

The display shows warning and indicator messages to let you know about certain vehicle problems.

In some cases, the external or internal buzzer may also sound at the same time to alert you.

If warning and indicator messages appear on the display, follow the messages.

Master warning indicator light



68PM00278

When the display shows warning and indicator messages, the master warning indicator light may also blink.

NOTE:


- When the problem that causes a message to appear is corrected, the message will disappear.
- If a message is displayed, and other problems requiring a message occur, the message for each of the problems will be alternately displayed about every 5 seconds.
- When you push and hold the indicator selector knob (3) for about 2 seconds while a message is displayed, the message will disappear temporarily. If the

problem that caused the message is not corrected, the message will appear again after 5 seconds. When you push and hold the indicator selector knob (3) for about 2 seconds while a message is displayed, the message will disappear temporarily. If the problem that caused the message is not corrected, the message will appear again after 5 seconds.

INSTRUMENT CLUSTER

Warning and indicator messages

All models

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
 74TB04016	Blinks (only while vehicle is in motion) 	Beep (one time from interior buzzer; only while vehicle is in motion)	A door, tailgate or engine hood is not properly closed. Stop the vehicle in a safe place and close the door, tailgate or engine hood properly. (#1)
 52RS005	Blinks 	Continuous beep (from interior buzzer)	The parking brake is not released. Stop the vehicle in a safe place and release the parking brake.

(#1) This message will disappear after a while even if the problem that caused the message to appear is not corrected.

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
 52RM21170	Blinks 	Continuous beep (from interior buzzer)	The headlights and/or the position lights are left on. Turn them off.
 52RM21180	Off	Beep (one time from interior buzzer)	Fuel level is low. Refill it as soon as possible. (#1)

(#1) This message will disappear for a while even if the problem that caused the message to appear is not corrected.

INSTRUMENT CLUSTER

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
 52RM21190	Off	Off	The road may be icy. Drive very carefully. (#1)



(#1) This message will disappear for a while even if the problem that caused the message to appear is not corrected.


Vehicle with keyless push start system

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
 52RM21210	Off	Off	This message is displayed when ACC position is selected as the ignition mode. (#1)
 52RM21220	Off	Off	The brake pedal (for Auto Gear Shift model) or the clutch pedal (for manual transmission models) is depressed. Press the engine switch to start the engine.


(#1) This message will disappear for a while even if the problem that caused the message to appear is not corrected.

INSTRUMENT CLUSTER

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
 SERVICE STEERING LOCK SYSTEM 52RM21230	Blinks 	Beep (one time from interior buzzer)	<p>There is a problem with the steering lock system. Have your vehicle inspected by a Maruti Suzuki authorized workshop.</p>
 SERVICE START SYSTEM 52RM21240	Blinks 	Beep (one time from interior buzzer)	<p>There is a problem with the immobilizer/ keyless push start system. Also, the vehicle battery voltage may be decreased. When the message is displayed even if you start the engine with normal voltage of the vehicle battery, have your vehicle inspected by a Maruti Suzuki authorized workshop.</p>

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
 55T040090	Blinks 	By certain conditions, you will hear a sound from interior and/or exterior of the vehicle.	The remote controller may be outside the vehicle or its battery may be discharged. Bring the remote controller in the vehicle or touch the engine push start switch with the remote controller. If the message still appears, replace the remote controller battery.
 55T040100			

INSTRUMENT CLUSTER

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
 52RM21270	Off	Off	This message is displayed when "ON" position is selected as the ignition mode. (#1)
 55T040020	Blinks 	Beep (one time from interior buzzer)	The steering lock is not disengaged. While lightly turning the steering wheel in both directions, press the engine switch again.

(#1) This message will disappear for a while even if the problem that caused the message to appear is not corrected.

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
 KEY FOB LOW BATTERY 55T040110	Off	Off	The remote controller battery is about to become flat. Replace the battery. (#1)
Manual Transmission  PRESS BRAKE AND CLUTCH TO START 52RM21300	Off	Off	The engine switch is pressed without depressing the brake and clutch pedals. Try again as instructed by the message.

(#1) This message will disappear for a while even if the problem that caused the message to appear is not corrected.

INSTRUMENT CLUSTER

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
Automatic transmission  PRESS BRAKE SHIFT TO P TO START 52RM21310	Off	Off	The engine switch is pressed with the gear-shift lever in a position other than "P" or "N" and depressing the brake pedal. Try again as instructed by message.
Automatic transmission  GEARSHIFT NOT IN PARK 52RM21320	Off	Off	The engine switch is pressed with the gear-shift lever in a position other than "P". Try again as instructed by the message.

Vehicle with ESP® system

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
 52RM21340	Blinks 	Beep (one time from interior buzzer)	There may be a problem with ESP® system. Have your vehicle inspected by a Maruti Suzuki authorized workshop.
Hill hold control system  52RM21350	Blinks 	Beep (one time from interior buzzer)	There may be a problem with hill hold control system. Have your vehicle inspected by a Maruti Suzuki authorized workshop.

INSTRUMENT CLUSTER

Vehicle with gasoline particle filter (GPF) (if equipped)

Warning and indicator message	Master warning indicator light	Sound	Cause and remedy
 74TB0403	Blinks 	Beep (one time from interior buzzer)	There may be a problem with the gasoline particulate filter. Have your vehicle inspected by a Maruti Suzuki authorized workshop.
 74TB0404	Blinks 	Beep (one time from interior buzzer)	You should regenerate the GPF. Refer to "Gasoline Particulate Filter (GPF)" in the "OPERATING YOUR VEHICLE" section.

Warning and Indicator Lights

NOTE:

If warning and indicator lights blink or come on, the corresponding messages may be shown on the information display.

Brake System Warning Light



82K170

Three different types of operations exist depending on the vehicle's specification.

- 1) The light comes on briefly when the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON.
- 2) The light comes on when the parking brake is engaged with the ignition mode ON.
- 3) The light comes on when under either or both of above two conditions.

The light also comes on when the fluid in the brake fluid reservoir falls below the specified level.

The light should go out after starting the engine and fully releasing the parking brake, if the fluid level in the brake fluid reservoir is adequate.

The light also comes on together with the ABS warning light when the rear brake force control function (proportioning valve function) of the ABS system fails.

If the brake system warning light comes on while you are driving the vehicle, it may mean that there is something wrong with the vehicle's brake system. If this happens, you should:

- 1) Pull off the road and stop carefully.

⚠ WARNING

Remember that stopping distance may be longer, you may have to push harder on the pedal, and the pedal may go down farther than normal.

- 2) Test the brakes by carefully starting and stopping on the shoulder of the road.
- 3) If you determine that it is safe, drive the vehicle cautiously at low speed to the nearest Maruti Suzuki authorized workshop for repairs or tow the vehicle to the nearest Maruti Suzuki authorized workshop for repairs.

⚠ WARNING

If any of the following conditions occur, you should immediately ask a Maruti Suzuki authorized workshop to inspect the brake system.

- If the brake system warning light does not go out after the engine has been started and the parking brake has been fully released.
- If the brake system warning light does not come on when the engine switch is pressed to change the ignition mode to ON.
- If the brake system warning light comes on at any time during vehicle operation.

NOTE:

Because the brake system is self-adjusting, the fluid level will drop as the brake pads become worn. Replenishing the brake fluid reservoir is considered normal periodic maintenance.

NOTE:

(Parking Brake Reminder Buzzer)

A buzzer sounds intermittently to remind you to release the parking brake if you start the vehicle without releasing the parking brake. Make sure that the parking brake is fully released and the brake system warning light turns off.

INSTRUMENT CLUSTER

Seat Belt Reminder Light



80J221

When the driver and/or front passenger do (does) not buckle his or her seat belt, this light will come on and/or blink.

For details about the seat belt reminder, refer to "Seat Belt Reminder" in "FOR SAFE DRIVING" section.

NOTE:

Along with the seat belt reminder light, a reminder message shall also come on the information display (if equipped), for unrestrained driver and/or front passenger.

Rear Passenger's Seat Belt Reminder Light

Type A



74TB04020

Type B



74TB04021

Reminder light for rear passengers to fasten their seat belts. For details of the seat belt reminder, refer to "Seat Belt Reminder" in "FOR SAFE DRIVING" section.

Airbag Warning Light



63J030

This light blinks or comes on for several seconds when the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON so you can check if the light is working.

The light will come on and stay on if there is a problem in the airbag system or the seat belt pretensioner system.

⚠ WARNING

If the airbag warning light does not blink or come on briefly when the engine switch is pressed to change the ignition mode to ON, stays on for more than 6 seconds, or comes on while driving, the airbag system or the seat belt pretensioner system may not work properly, which could result in serious injury in the event of a crash. Have both systems inspected by a Maruti Suzuki authorized workshop.

Low Fuel Warning Light



54G343

If this light comes on, refuel the fuel tank as soon as possible.

When this light comes on, a ding sounds once to remind you to refuel.

If you do not refuel, a ding sounds every time when the ignition switch is turned "ON" or pushed to "ON" mode.

NOTE:

- *The activation point of this light varies depending on road conditions (for example, slope or curve) and driving conditions because of fuel moving in the tank.*
- *When this light comes on, low fuel warning message is displayed on the information display.*

For details, refer to "Warning and Indicator Messages" in this section.

Anti-lock Brake System (ABS) Warning Light



80J127

When the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, the light comes on briefly so you can check that the light is working.

If the light stays on, or comes on when driving, there may be something wrong with the ABS.

If this happens:

- 1) Pull off the road and stop carefully.
- 2) Turn the ignition switch to "LOCK" position or change the ignition mode to LOCK (OFF) by pressing the engine switch and then start the engine again.

If the warning light comes on briefly then turns off, the system is normal. If the warning light still stays on, the system will be something wrong.

If the light and the brake system warning light stay on, or come on simultaneously when driving, your ABS system is equipped with the rear brake force control function (proportioning valve function) and there may be something wrong with both the rear brake force control function and anti-lock function of the ABS system.

If one of these happens, have the system inspected by a Maruti Suzuki authorized workshop.

If the ABS becomes inoperative, the brake system will function as an ordinary brake system that does not have this ABS system.

For details of ABS system, refer to "Anti-Lock Brake System (ABS)" in the "OPERATING YOUR VEHICLE" section.

INSTRUMENT CLUSTER

High Engine Coolant Temperature Warning Light (red color) (if equipped)



54G344

When the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, this light comes on briefly so you can check that the light is working. If this light blinks while driving, it means the engine is running hot. If the light stays on after blinking, then the engine is overheating. To avoid actual overheating, if this light blinks or stays on while driving, follow the instructions in the "If the Engine Overheats" of "EMERGENCY SERVICE" section.

NOTICE

Continuing to drive the vehicle when engine overheating is indicated can result in severe engine damage.

Malfunction Indicator Light



80J222

Your vehicle has a computer-controlled emission control system. A malfunction indicator light is provided on the instrument panel to indicate when it is necessary to have the emission control system serviced. The malfunction indicator light comes on when the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON to let you know the light is working and goes out when the engine is started.

If the malfunction indicator light comes on or blinks when the engine is running, there is a damage in the emission control system.

Bring the vehicle to a Maruti Suzuki authorized workshop to have the damage fixed.

WARNING

If this light blinks, stop your vehicle immediately in a safe place to avoid catalyst's melting problem since there may be a misfire in the engine.

- Do not drive or stop over such as withered grasses.

Drive slowly if required to move the vehicle.

Also, if this light comes on when the engine is running, there is a problem with the automatic transmission system. Ask a Maruti Suzuki authorized workshop to have the system inspected.

NOTICE

Continuing to drive the vehicle when the malfunction indicator light is on or blinking can cause permanent damage to the vehicle's emission control system, and can affect fuel economy and driveability.

Electric Power Steering Light



80J408

This light comes on when the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, and goes out when the engine is started.

If this light comes on while driving, the power steering system may not work properly. Have the system inspected by a Maruti Suzuki authorized workshop.

NOTE:

- Following operations of the steering wheel while parking or driving at a very low speed may have steering effort bigger gradually. This is not a malfunction of the steering system, but the power steering control system limits the power assist in order to prevent them from overheating.

- The steering wheel is operated very often.
- The steering wheel is kept in a fully turned position for a long while.

When the power steering control system cool down, the power steering system back to the original condition.

However, repeating these operations could cause the power steering system damaged.

- If the power steering system does not work properly, you will feel heavier to steer but you still will be able to steer.
- If the steering is operated, you may hear a noise. This is normal and indicates that the power steering system works properly.

Engine Oil Pressure Warning Light



80J223

This light comes on when the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, and goes out when the engine is started. The light will come on and remain on if there is insufficient oil pressure. If the light comes on when driving, pull off the road as soon as you can and stop the engine.

Check the oil level and add oil if necessary. If there is enough oil, the lubrication system should be inspected by a Maruti Suzuki authorized workshop before you drive the vehicle again.

NOTICE

- If you operate the engine with this light on, severe engine damage can result.
- Do not rely on the engine oil pressure warning light to indicate the need to add oil. Be sure to periodically check the engine oil level.

INSTRUMENT CLUSTER

Charge Warning Light



80J226

This light comes on when the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, and goes out when the engine is started. The light will come on and remain on if there is something wrong with the battery charging system. If the light comes on when the engine is running, the charging system should be inspected immediately by a Maruti Suzuki authorized workshop.

Cruise Control Indicator Light (if equipped)



64MM02015

When the cruise control is on, this light will be on.

"SET" Indicator Light (if equipped)

SET

65D474

When a cruising speed of the cruise control is set, this light will be on.

Depress Brake Pedal Indicator Light (Auto Gear Shift models)



76MH0A047

Refer to "Auto Gear Shift" in the "OPERATING YOUR VEHICLE" section for details.

Transmission Warning Light (AGS / AT models)



80J219

When the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, this light comes on for several seconds so you can check that the light is working.

If this light comes on when the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, there is a problem with the Auto Gear Shift / Automatic Transmission system.

If this light comes on or blinks, stop the vehicle in a safe place and contact a Maruti Suzuki authorized workshop. If the light comes on or blinks again after the light goes out, have the system inspected by a Maruti Suzuki authorized workshop.

If the light comes on, it may become followings:

- The transmission gear will not change even if you shift the gearshift lever.
- The transmission gear will change to "N" automatically when the vehicle speed becomes less than 10 km/h, also the "N" indicator in the instrument cluster will blink and the interior buzzer will sound.
- The engine will stall automatically when the vehicle stops.
- The engine will not start.

If the above occurs, have the system inspected by a Maruti Suzuki authorized workshop.

NOTE:

If the Auto Gear Shift clutch temperature becomes too high, this light will blink. Stop the vehicle in a safe place and let the system cool down.

Immobilizer / Keyless Push Start System Warning Light



80JM122

When the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, the light comes on briefly so you can check that the light is working.

If this light blinks or stays on, there is a problem with the system.

If this light still blinks or stays on even if you start the engine with normal voltage of the vehicle battery, ask a Maruti Suzuki authorized workshop to have the system inspected.

Open Door Warning Light



54G391

This light remains on until all doors (including the tailgate) are completely closed.

If any door (including the tailgate) is open when the vehicle is moving, a ding sounds to remind you to close all doors completely.

INSTRUMENT CLUSTER

Turn Signal Indicators



59RN04690

When you turn on the left or right turn signals, the corresponding green arrow on the instrument panel will blink along with the respective turn signal lights. When you turn on the hazard warning switch, both arrows will blink along with all of the turn signal lights.

NOTE:

If any abnormality of the turn signals is observed, such as fast blinking, there may be a malfunction in the turn signal system. Ask your Maruti Suzuki authorized workshop to inspect the system.

Main Beam (High beam) Indicator Light



80J212

This indicator comes on when headlight main beams (high beams) are turned on.

Illumination Indicator Light



64J045

This indicator light comes on while the position lights, tail light and/or the headlights are on.

ESP® OFF Indicator Light

57L30045

When the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, this light comes on briefly so you can check that the light is working.

When the ESP® OFF switch is pushed to turn off the ESP® systems (other than ABS), the ESP® OFF indicator light comes on and stays on.

For details of the ESP® systems, refer to "Electronic Stability Program (ESP®)" in the "OPERATING YOUR VEHICLE" section.

ESP® Warning Light

52KM133

ESP® is a registered trademark of Mercedes-Benz Group.

This light blinks 5 times per second when one of the following systems is activated.

- Stability control system
- Traction control system

If this light blinks, drive carefully.

When the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, the light comes on briefly so you can check that the light is working. If the light stays on, or comes on when driving and remains on, there may be something wrong with the ESP® systems (other than ABS). You should have the system inspected by a Maruti Suzuki authorized workshop.

For details of the ESP® systems, refer to "Electronic Stability Program (ESP®)" in the "OPERATING YOUR VEHICLE" section.

 WARNING

The ESP® systems cannot prevent accidents. Always drive carefully.

Low Engine Coolant Temperature Light (blue color) (if equipped)

54G344

When the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, this light comes on and stays on if the engine is cold, and goes off after the engine warms up.

If this light still stays on after the engine warms up, there is a problem with the sensor.

Have your vehicle inspected by a Maruti Suzuki authorized workshop.

INSTRUMENT CLUSTER

ENG A-STOP Indicator Light (if equipped)



72M00032

When the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, this light comes on briefly to let you know the light is working.

When the engine stops automatically, this light comes on.

For details, refer to "ENG A-STOP System (Engine Auto Stop Start System) (if equipped)" in the "OPERATING YOUR VEHICLE" section.

ENG A-STOP OFF Indicator Light (if equipped)



62R0352

When the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON, this light comes on briefly if the system works properly.

When you push the ENG A-STOP OFF switch, this light comes on.

If this light blinks when driving, there may be something wrong with the ENG A-STOP system. You should have the system inspected by a Maruti Suzuki authorized workshop.

For details, refer to "ENG A-STOP System (Engine Auto Stop Start System)" in the "OPERATING YOUR VEHICLE" section.

Gasoline Particulate Filter (GPF) warning light (if equipped)



74TB0405

This Gasoline Particle Filter (GPF) warning light comes on for several seconds when the ignition switch is turned to the "ON" position or the engine switch is pressed to change the ignition mode to "ON" so you can check that light is working. If the light comes on when driving, the GPF is nearly clogged. To go out the warning light, the vehicle must stay in motion until regeneration has been completed.

The process normally takes about 25 minutes.

The optimum condition to end the process are achieved by keeping the vehicle in motion at a speed of 50 km/h (31 mph) or higher, and an engine speed higher than 2,000 rpm.

If you drive your vehicle until the light goes out, the regeneration of the GPF will be completed.

For details of the GPF, refer to "Gasoline Particulate Filter" in the "OPERATING YOUR VEHICLE" section.

NOTICE

Be sure to regenerate the GPF when the GPF warning light comes on. Failure to regenerate the GPF will cause the vehicle malfunction due to the clogged filter.

Deceleration Energy Regenerating Indicator Light (if equipped)



74TB04017

When the ignition switch is turned to “ON” position or the engine switch is pressed to change the ignition mode to “ON”, this light comes on briefly so you can check that the light is working.

When the deceleration energy regenerating function is working, this light comes on.

For details, refer to “SHVS (Smart Hybrid Vehicle by Suzuki)” in “OPERATING YOUR VEHICLE” section.

Master Warning Indicator Light (if equipped)



74TB04018

When the ignition switch is turned “ON” or pushed to “ON” mode, this light comes on briefly so you can check that the light is working.

When the information display shows warning and indicator messages, this indicator light may also blink.

For details, refer to “Information display” in this section.

OPERATING YOUR VEHICLE




59RN05760

Daily Inspection Checklist	5-1
Ignition Switch (Vehicle without Keyless Push Start System) (if equipped)	5-3
Engine Switch (Vehicle with Keyless Push Start System) (if equipped)	5-5
Immobilizer System	5-6
Pedal	5-8
Keyless Push Start System (if equipped)	5-9
Starting / Stopping Engine (Vehicle without Keyless Push Start System) (if equipped)	5-12
Starting / Stopping Engine (Vehicle with Keyless Push Start System) (if equipped)	5-13
Parking Brake Lever	5-17
Precaution for Parking	5-19
Using Transmission	5-21
Gearshift Indicator (if equipped)	5-36
SHVS (Smart Hybrid Vehicle by Maruti Suzuki) (for K10C engine) (if equipped).....	5-38
ENG A-STOP System (Engine Auto Stop Start System) (for K12N engine) (if equipped)	5-40
ENG A-STOP System (Engine Auto Stop Start System) (for K10C engine) (if equipped)	5-52
Cruise Control (if equipped)	5-64
SUZUKI SAFETY SUPPORT (if equipped)	5-66
Parking Sensors	5-99
Rearview Camera (if equipped).....	5-104
Electronic Stability Program (ESP®).....	5-106
Braking	5-111
Anti-lock Brake System (ABS)	5-112

OPERATING YOUR VEHICLE

Daily Inspection Checklist

Before Driving



59RN05750

- 1) Check that the windows, mirrors, lights and reflectors are clean and unobstructed.
- 2) Visually check the tyres for the following points:
 - the depth of the tread groove
 - abnormal wear, cracks and damage
 - loose wheel nuts
 - existence of foreign material such as nails, stones, etc.Refer to "Tyres" in "INSPECTION AND MAINTENANCE" section for details.
- 3) Look for fluid and oil leakage.

NOTE:

It is normal for water to drip from the air conditioning system while and after use.

- 4) Check that the hood is fully closed and latched.
- 5) Check the headlights, turn signal lights, brake lights and horn for proper operation.
- 6) Adjust the seat and head restraint.
- 7) Check the brake pedal feeling and the adjustment condition for the parking brake lever or pedal.
Refer to "Brake" in "INSPECTION AND MAINTENANCE" section for details.
- 8) Adjust the mirrors.
- 9) Check that you and all the passengers have properly fastened the seat belts.
- 10)Check that all the warning lights come on as the ignition switch is turned to "ON" position.
- 11)Check all the gauges.
- 12)Check that the brake system warning light turns off when the parking brake is released.

Once a week, or each time you fill your fuel tank, or before a long distance driving (like highway driving) perform the following under-hood checks:

- 1) Engine oil level
- 2) Coolant level
- 3) Brake fluid level
- 4) Battery fluid (acid) level
- 5) Windshield washer fluid level
- 6) Hood latch operation

Pull the hood release lever inside the vehicle. Check that you cannot open the hood further without releasing the secondary latch. Close the hood securely after checking for proper latch operation. See the item "All latches, hinges and locks" of "Chassis, body and others" in "Maintenance Schedule" in "INSPECTION AND MAINTENANCE" section for lubrication schedule.

⚠ WARNING

Check that the hood is fully closed and latched before driving. If it is not, it can fly up unexpectedly during driving, obstructing your view and resulting in an accident.

Once a month, or each time you fill your fuel tank, check the tyre pressure using a tyre pressure gauge. Also check the tyre pressure of the spare tyre.

When You Notice the Following Symptoms




80J009

CAUTION

If you keep using your vehicle in the following conditions, malfunction and an accident may occur. Consult a Maruti Suzuki authorized workshop.

- Leaked oil or other liquid appears on the ground below the vehicle.
- Brake fluid level is low.
- There are unusual odors, sounds or vibrations.
- The feeling of operating the steering wheel or the brakes is different than usual.

Check the Tyre Pressure




55T090020

- Periodically check and adjust the tyre pressure. The specified tyre pressure for the tyres of this vehicle can be confirmed by checking the tyre information label (1) affixed to the opening of the driver's door.
- Driving with insufficient tyre pressure can cause the sides of the tyre to wear, in addition to decreasing fuel efficiency.

WARNING

- Driving with extremely low tyre pressure can cause a tyre blowout (bursting) and may result in an accident. Do not drive with extremely low tyre pressure.



69RHS173

- If the specified tyre pressure is not maintained, the full performance of the vehicle cannot be achieved and the following could occur, leading to accidents or malfunctions. Adjust the tyre pressure as specified.

- Decreased driving stability
- Longer distance required for braking

(Continued)

OPERATING YOUR VEHICLE


⚠ WARNING

(Continued)

- Accurate tyre rotation speed cannot be detected, which interferes with the following functions:
 - ABS
 - Electronic stability program (ESP®)

To adjust the tire pressure, refer to "Tyres" in "INSPECTION AND MAINTENANCE" section.

Check the Exhaust Pipe




80J011

Periodically check the exhaust pipes for holes or cracks.

⚠ WARNING

If leaks in exhaust pipes are present, exhaust gas could enter the vehicle and possibly cause carbon monoxide poisoning. If you feel that something is abnormal, consult a Maruti Suzuki authorized workshop.

Ignition Switch (Vehicle without Keyless Push Start System) (if equipped)




68PH00310

The ignition switch has the following four positions:

LOCK

This is the normal parking position. It is the only position in which the key can be removed.

Manual transmission



55T050010

- Manual transmission vehicles:**

You must push in the key to turn it to "LOCK" position. It locks the ignition, and prevents normal use of the steering wheel after the key is removed.

- Auto Gear Shift vehicles:**

The gearshift lever must be in "N" (Neutral) to turn the key to "LOCK" Position. It locks the ignition and prevents normal use of the steering wheel and gearshift lever.

To release the steering lock, insert the key and turn it clockwise to one of the other positions. If you have trouble turning the key to unlock the steering wheel, try turning the steering wheel slightly to the right or left while turning the key.

ACC

Accessories such as the radio can operate, but the engine is off.

ON


This is the normal operating position. All electrical systems are on.

START

This is the position for starting the engine using the starter motor. The key should be released from this position as soon as the engine starts.

Ignition key reminder

A buzzer sounds intermittently to remind you to remove the ignition key if it is in the ignition switch when the driver's door is opened.



55T050020

! WARNING

- Never return the ignition switch to "LOCK" position and remove the ignition key while the vehicle is moving. The steering wheel will lock and you will not be able to steer the vehicle.

(Continued)

! WARNING

(Continued)

- Always return the ignition switch to "LOCK" position and remove the ignition key when leaving the vehicle even only for a short time. Also do not leave children alone in a parked vehicle. Unattended children could cause accidental movement of the vehicle or could tamper with power windows. They also could suffer from heat stroke in warm or hot weather. These could result in severe injury or even death.

NOTICE

Do not leave the ignition switch in "ON" position if the engine is not running as the lead-acid battery will discharge.

OPERATING YOUR VEHICLE

Engine Switch (Vehicle with Keyless Push Start System) (if equipped)



74TB05021


LOCK (OFF)

This mode is for parking the vehicle. When this mode is selected by pressing the engine switch and then any door (including the tailgate) is opened or closed, the steering will be locked automatically.

ACC

Press the engine switch to select this ignition mode to use such electric equipment as the audio system, outside rearview mirrors and accessory socket with the engine off. When this position is selected, the

information display in the instrument cluster shows the following message.




74TB05003

ON

- **With the engine off**

You can use such electric equipment as the power windows and wipers with the engine off. When this ignition mode is selected by pressing the engine switch, the information display in the instrument cluster shows the following message.



74TB05004

- **With the engine on**

All electric equipment is operational. The vehicle can be driven when you have

selected this ignition mode by pressing the engine switch.

START

Manual transmission vehicles:

Provided you have the keyless push start system remote controller with you, the engine automatically starts when you press the engine switch to select this ignition mode after shifting to "N" (Neutral) and depressing the brake and clutch pedals.

Auto Gear Shift vehicles:

Provided you have the keyless push start system remote controller with you, the engine automatically starts when you press the engine switch to select this ignition mode after placing the gearshift lever in "N" (Neutral) position and depressing the brake pedal.

NOTICE


Do not leave the engine switch in ACC or ON mode when the engine is not running. Avoid using the radio or other electric accessories for a long time when the engine switch is in ACC or ON mode when the engine is not running, otherwise the lead-acid battery may discharge.

NOTE:

- *The steering will be unlocked when you press the engine switch to change the*

ignition mode from LOCK (OFF) to ACC or ON.

- You do not need to keep the engine switch pressed until the engine starts.
- In the presence of strong radio wave or noise, you may not be able to change the ignition mode to ACC or ON or to start the engine using the engine switch. In this case, the information display in the instrument cluster will show the following message.



74TB05005

Unreleased Steering Lock Warning

If the steering lock remains engaged when you press the engine switch to change the ignition mode to ON, the information display in the instrument cluster shows the following message and you cannot start the engine. If this happens, press the engine switch, turning the steering wheel to right or left.



NOTE:

The steering lock may not be released and the immobilizer/keyless push start system warning light turns on if some load is applied on the steering wheel. If this happens, turn the steering wheel system to the right or left to relieve it from the load before you press the engine switch again to change to the desired ignition mode.

Immobilizer System

This system is designed to help prevent vehicle theft by electronically disabling the engine starting system.

The engine can be started only with your vehicle's original immobilizer ignition key or keyless push start system remote controller, which has an electronic identification code programmed in it. The key or remote controller communicates the identification code to the vehicle when the ignition switch is turned to "ON" position or the engine switch is pressed to change the ignition mode to ON. If you need to make spare keys or remote controllers, see a Maruti Suzuki authorized workshop. The vehicle must be programmed with the correct identification code for the spare. A key made by an ordinary locksmith will not work.

In the case you can start the engine, when you turn the ignition switch to "LOCK" position or press the engine switch to change the ignition mode to ON, the immobilizer system will be released and the immobilizer/keyless push start system warning light will turn on for about 2 seconds and then it will turn off.

When you turn the ignition switch to "LOCK" position or press the engine switch to change the ignition mode to LOCK (OFF), the immobilizer system will operate.

OPERATING YOUR VEHICLE

NOTICE

If the immobilizer system is modified or removed, it cannot be properly operated. Do not modify or remove the immobilizer system.

NOTE:
This immobilizer system is maintenance-free.

Immobilizer/Keyless Push Start System Warning Light



80JM122

If the immobilizer/keyless push start system warning light blinks when the ignition switch is in "ON" position or the ignition mode is ON, the engine will not start.

NOTE:
If the immobilizer/keyless push start system warning light blinks or comes on, a message may be shown on the information display.

For vehicles without a keyless push start system

If this light blinks, turn the ignition switch to "LOCK" position, and then turn it back to "ON" position.

If the light still blinks after the ignition switch is turned back to "ON" position, there may be something wrong with your key or with the immobilizer system. Ask a Maruti Suzuki authorized workshop to have the system inspected.

For vehicles with a keyless push start system

If this light blinks, change the ignition mode to LOCK (OFF), and then change it back to ON. Also refer to "If the master warning indicator light blinks and the engine cannot be started" in "Starting / stopping engine (vehicle with keyless push start system) (if equipped)" in "OPERATING YOUR VEHICLE" section.

If the light still blinks after the ignition mode is changed back to ON, there may be something wrong with your key or with the immobilizer system. Ask a Maruti Suzuki authorized workshop to have the system inspected.

The immobilizer/keyless push start system warning light may also blink if the remote controller is not in the vehicle when you close the door or attempt to start the engine.

NOTE:

- If you lose your immobilizer ignition key or remote controller, ask a Maruti Suzuki authorized workshop as soon as possible to deactivate the lost one, and to make a new key or remote controller.
- If you own other vehicles with immobilizer keys, keep those keys away from the ignition switch or the engine switch when using your Maruti Suzuki vehicle. Otherwise, the engine may not be started because they may interfere with your Maruti Suzuki vehicle's immobilizer system.
- If you attach any metal objects to the immobilizer key or remote controller, it may not start the engine.

NOTICE

The immobilizer key and remote controller are sensitive electronic instruments. To avoid damaging them:


- Do not expose them to impacts, moisture or high temperature such as on the dashboard under direct sunlight.
- Keep them away from magnetic objects.

Ignition Key Reminder (if equipped)

A buzzer sounds intermittently to remind you to remove the ignition key if it is in the ignition keyhole when the driver's door is opened.


Pedal

Manual transmission



80J2121

Auto Gear Shift / Automatic transmission



80J2122

Clutch Pedal (1)

A clutch pedal is used to disengage the driving force to the wheels when starting the engine, stopping, or shifting the gear-shift lever. Depressing the pedal disengages the clutch.

⚠ WARNING

Do not drive with your foot resting on the clutch pedal. It could result in excessive clutch wear, clutch damage, or unexpected loss of engine braking.

Brake Pedal (2)

Your vehicle is equipped with either front and rear disc brakes or front disc brakes and rear drum brakes. Depressing a brake pedal applies both sets of brakes.

You may hear occasional brake squeal when you apply the brakes. This is a normal condition caused by environmental factors such as temperature, humidity, snow or dust, etc.

Auto Gear Shift - You may hear occasional sound when you release brake pedal while vehicle is in "D" (Drive) mode and about to move. This is a normal phenomenon.

⚠ WARNING

If brake squeal is excessive and occurs each time the brakes are applied, you should have the brakes checked by a Maruti Suzuki authorized workshop.

⚠ WARNING

Do not apply brakes continuously or rest your foot on the brake pedal. This will result in overheating of the brakes which could cause unpredictable braking action, longer stopping distances, or permanent brake damage.

Accelerator Pedal (3)

An accelerator pedal controls the speed of the engine. Depressing the accelerator pedal increases power output and speed.

NOTE:


Your vehicle is equipped with Brake Override System. If you depress both the accelerator pedal and the brake pedal simultaneously, the engine power output may be suppressed.

OPERATING YOUR VEHICLE

Keyless Push Start System (if equipped)

Provided the keyless push start system remote controller is within the interior workable area, you can use the engine switch for starting the engine and selecting an ignition mode (ACC or ON). In addition, the following functions can be used:

- Keyless entry function. Refer to "Keyless Push Start System Remote Controller" in "BEFORE DRIVING" section for details.
- Locking and unlocking doors (including the tailgate) using a request switch. Refer to "Keyless Push Start System Remote Controller" in "BEFORE DRIVING" section for details.
- Immobilizer (anti-theft) function. Refer to "Immobilizer System" in this section for details.



81M40230

(1) Interior workable area

The interior workable area is defined as all the interior spaces except for the space on the instrument panel or in the luggage compartment.


NOTE:

- Even when the remote controller is in the interior workable area, if it is in any of the following conditions, you may not be able to start the engine or select the ignition modes, and the remote controller outside warning may be given.
 - The remote controller's battery is low.
 - The remote controller is affected by strong radio wave or noise.
 - The remote controller is in contact with or covered by a metallic object.
 - The remote controller is in the secluded stowages such as the glove box or a door pocket.
 - The remote controller is in the sun visor pocket or on the floor.
- Even when the remote controller is outside the interior workable area, if it is in any of the following conditions, you may be able to start the engine or select the ignition mode. The remote controller outside warning may not be given at that time.
 - The remote controller is outside the vehicle but very close to a door.
 - The remote controller is on the instrument panel.

Engine Switch Illumination

The engine switch is illuminated (lit) in the following situations:

- When the engine is off and the driver's door is open, or for 15 seconds after the driver's door is closed. The illumination will fade out after 15 seconds passed.
- While the headlights and/or the position lights are on, the illumination will turn on. The illumination will go out when the headlights and the position lights are turned off.



82K253

NOTE:

To save the lead-acid battery, the illumination will be automatically turned off when both of the following conditions are simultaneously met:

- The headlights and the position lights are turned off.
- 15 minutes has elapsed since opening the driver's door.


Selection of Ignition Modes

Press the engine switch to select ACC or ON mode as follows when you use an electric accessory or check the operation of instrument cluster without running the engine.

NOTE:

When selecting the ignition modes, the information display in the instrument cluster show certain messages. Refer to "Information Display" in the "INSTRUMENT CLUSTER" section.

- 1) Bring the keyless push start system remote controller with you and sit in the driver's seat.




82K254

- 2) Manual transmission – Without depressing the clutch pedal, press the engine switch (1).

Auto Gear Shift – Without depressing the brake pedal, press the engine switch (1).


Every time you press the engine switch, the ignition mode changes as follows.

Auto Gear Shift Manual transmission



68PH00322


Automatic transmission



57L31006

If the master warning indicator light  blinks and the ignition modes cannot be selected

Your keyless push start system remote controller may not be sensed as being within the interior workable area (refer to the related explanation in this section). Try again after checking that you have the remote controller with you. If the ignition modes still cannot be selected, the battery of the remote controller may be discharged. To select an ignition mode, you must then use the following method:




63R40050

- 1) Manual transmission – Without depressing the clutch pedal, push the engine switch (1).

Auto Gear Shift – Without depressing the brake pedal, press the engine switch (1).

OPERATING YOUR VEHICLE

- Automatic Transmission - Without depressing the brake pedal, press the engine switch (1).
- 2) Within about 10 seconds while the master warning indicator light blinks and the information display in the instrument cluster shows the following message, touch the engine switch with the lock switch end of the remote controller (2) for about 2 seconds.




While the master warning indicator light blinks, the immobilizer/keyless push system warning light will come on for about 5 seconds.

If you still cannot select the ignition modes, there may be the other problem such as the discharged lead-acid battery. In this case, consult a Maruti Suzuki authorized workshop.

NOTE:


- You may customize the system to cause the interior buzzer to sound once for warning that remote controller is out of sensing range. For this customization, consult a Maruti Suzuki authorized workshop.*
- If the battery of the remote controller is almost discharged, the information display in the instrument cluster shows the following message when you press the engine switch to change the ignition mode to ON. Refer to "Information Display" in "INSTRUMENT CLUSTER" section for details. For details on replacing the battery, refer to "Keyless Push Start System Remote Controller" in "BEFORE DRIVING" section.*



Remote Controller Outside Warning

When either of the following conditions is met, the system causes the remote controller outside warning by sounding the interior and exterior buzzers. At the same time, the immobilizer/keyless push start system warning light comes on, the master warning indicator light blinks and the information display in the instrument cluster will show the corresponding message.

- Any door is opened and then closed while the remote controller is not inside the vehicle and the engine is running or the ignition mode has been changed to ACC or ON by pressing the engine switch.
- The remote controller is not inside the vehicle when you attempt to start the engine after changing the ignition mode to ACC or ON by pressing the engine switch.



- (1) Immobilizer/keyless push start system warning light (blinks)
- (2) Master warning indicator light (blinks)

If the warning is given, place the remote controller inside the vehicle as soon as possible.


- Any attempt to start the engine will fail while the warning is active. The message appearing in the information display in the instrument cluster will also indicate this condition. Refer to "Information Display" in the "INSTRUMENT CLUSTER" section for details.
- Normally, the immobilizer/keyless push start system warning light should go out and the master warning indicator light should stop blinking shortly after the remote controller is brought back inside the vehicle. If they remain lit and blinking, change the ignition mode to LOCK (OFF) by pressing the engine switch and then perform the engine starting operation. Refer to "Starting / Stopping Engine (Vehicle with Keyless Push Start System) (if equipped)" in this section.

NOTE:

Always keep the remote controller with you as the driver.

Starting / Stopping Engine (Vehicle without Keyless Push Start System) (if equipped)

Starting Engine



74TB05030

- 1) Check that the parking brake is set fully.
- 2) Turn off such loads as the headlights and air conditioning system to facilitate starting of the engine.

- 3) Manual transmission vehicles:
Shift into "N" (Neutral). Hold the clutch pedal and brake pedal fully depressed.
Auto Gear Shift vehicles:
Shift into "N" (Neutral) and depress the brake pedal. Hold the brake pedal while starting the engine.
Automatic Transmission:
Check that the gearshift lever is in "P" (Park) position and keep depressing the brake pedal fully.
- 4) With your foot taken off the accelerator pedal, crank the engine by turning the ignition key to "START". Release the key immediately after the engine has started.

OPERATING YOUR VEHICLE

NOTICE

- Release the key immediately after the engine has started or the starter can be damaged.
- For protection of a lead-acid battery and a starter motor, do not use the starter motor by turning the key to "START" for more than 12 seconds at a time. If the engine does not start, turn the key to "LOCK" position and wait for more than 30 seconds before trying again. If the engine does not start after several attempts, consult a Maruti Suzuki authorized workshop.
- Do not try to start the engine by pushing or towing the vehicle, or coasting down a hill. This starting method could result in damage to the catalytic converter or damage to other parts.

NOTE:

Auto Gear Shift vehicles:

If the engine cannot be started, make sure the gearshift lever is in "N" before restarting the engine.


Stopping Engine

⚠ WARNING

Except in cases of emergency, do not stop the engine while the vehicle is in motion. If you stop the engine while the vehicle is in motion, the steering wheel will lock and you will not be able to steer the vehicle. This may result in an accident. Avoid stopping the engine while driving.

Starting / Stopping Engine (Vehicle with Keyless Push Start System) (if equipped)

Starting Engine



74TB05029

- 1) Check that the parking brake is set fully.
- 2) Turn off such loads as the headlights and air conditioning system to facilitate starting of the engine.
- 3) Manual transmission vehicles:
Shift into "N" (Neutral). Hold the clutch pedal and brake pedal fully depressed.


Auto Gear Shift vehicles:

Shift into "N" (Neutral) and depress the brake pedal. Hold the brake pedal while starting the engine.

Automatic Transmission:

Check that the gearshift lever is in "P" (Park) position and keep depressing the brake pedal fully.

- 4) The "PUSH START SWITCH" message will appear in the information display in the instrument cluster.



82K254

- 5) With your foot taken off the accelerator pedal, push the engine switch (1). When the engine is started, the starter motor will automatically stop.

- Even if you fail to start the engine, the starter motor will stop turning automatically after approximately 12 seconds. In this case, press the engine switch to select LOCK (OFF) mode and restart the engine.

- If there is a problem with the system, the engine will not start automatically even if the switch is pressed. In case the starter motor does not turn or stops immediately, start the engine by the following procedure.
 - a. Press the engine switch to select the ON mode.
 - b. Perform the above procedure 1 to 3.
 - c. Keep the engine switch pressed until the engine starts. Release your finger from the engine switch after the engine has started.

NOTICE

- If the engine does not start, press the engine switch to select LOCK (OFF) mode and wait for more than 30 seconds before trying again, for protection of a lead-acid battery and a starter motor. If the engine does not start after several attempts, consult a Maruti Suzuki authorized workshop.
- Do not try to start the engine by pushing or towing the vehicle, or coasting down a hill. This starting method could result in damage to the catalytic converter or damage to other parts.

NOTE:

- You do not need to keep the engine switch pressed to start the engine.

- **Manual transmission vehicles:**

The engine of a manual transmission vehicle will not start unless the clutch pedal is depressed.

- **Auto Gear Shift vehicles:**

If the engine cannot be started, make sure the gearshift lever is in "N" before restarting the engine.

- *During the engine starting procedure, messages on the information display will help you. Refer to "Information display" in "INSTRUMENT CLUSTER" section for details.*
- *When the engine stalls in intersection and railway crossing etc., restart the engine by usual procedure.*

Stopping Engine

- Depress the engine switch to stop the engine after the vehicle stopped completely.
- If the engine remains stopped for a while after it was stopped unexpectedly or was raced before stopping, a clicking sound may be heard from around the engine when it is restarted. This is not a malfunction. Always let the engine idle before stopping it.

OPERATING YOUR VEHICLE

⚠ WARNING

Except in cases of emergency, do not stop the engine while the vehicle is in motion. If you stop the engine while the vehicle is in motion, the steering wheel will lock and you will not be able to steer the vehicle. This may result in an accident. Avoid stopping the engine while driving.

Emergency Stop

In case of emergency, you can stop the engine by quickly pushing the engine switch more than 3 times, or pushing and holding the engine switch for more than 2 seconds while the vehicle is in motion.

NOTE:

Except in cases of emergency, do not stop the engine while the vehicle is in motion. The steering and braking operation will require more effort when the engine is stopped. Refer to "Braking" in this section.


If the Master Warning Indicator Light ⚠ Blinks and the Engine cannot be Started

Your keyless push start system remote controller may not be sensed as being within the interior workable area (refer to the related explanation in this section). Try again after checking that you have the remote controller with you. If the engine cannot be started, the battery of the remote controller may be discharged. To start the engine, you must then use the following method:

1) Manual Transmission - Shift to "N" (Neutral) and fully depress the clutch pedal. Hold the clutch and brake pedal fully depressed.


Automatic Transmission - Check that the gearshift lever is in "P" (Park) position and keep depressing the brake pedal fully.

Auto Gear Shift - Shift to "N" (Neutral) and fully depress the brake pedal. Hold the brake pedal fully depressed.



63R40050

2) If the following message is shown on the information display in the instrument cluster, press the engine switch (1).



74TB05008

3) Within about 10 seconds while the master warning indicator light blinks and the information display in the instrument cluster shows the following message, touch the engine switch with

the lock switch end of the remote controller (2) for about 2 seconds.



74TB05009

While the master warning indicator light blinks, the immobilizer/keyless push system warning light will come on for about 5 seconds.

If you still cannot start the engine, there may be the other problem such as the discharged lead-acid battery. In this case, consult a Maruti Suzuki authorized workshop.

NOTE:

- You may customize the system to cause the interior buzzer to sound once for warning that remote controller is out of sensing range. For this customization, consult a Maruti Suzuki authorized workshop.
- If the battery of the remote controller is almost discharged, the information display in the instrument cluster shows the following message when you press the engine switch to change the ignition

mode to ON. Refer to "Information Display" in "INSTRUMENT CLUSTER" section for details. For details on replacing the battery, refer to "Keyless Push Start System Remote Controller" in "BEFORE DRIVING" section.



74TB05010

Gasoline Particulate Filter (GPF) (For K10C Engine Model)

The GPF filters off the soot particles in the exhaust gas, so the GPF could get clogged depending on the driving condition. The GPF is cleaned by the regenerating function that combusts the soot particles in the GPF by raising the exhaust gas temperature during driving or idling.

When a certain amount of soot particles is accumulated in the GPF, the GPF will regenerate automatically to avoid clogging the filter. Therefore, you may hear a little louder engine sounds and/or the exhaust gas temperature could be higher due to combustion of the soot particles.

CAUTION

Keep away from the exhaust pipe when the engine is running. If the GPF is regenerating, the exhaust gas temperature could be higher.

OPERATING YOUR VEHICLE

GPF warning light



74TB0405

If the GPF warning light comes on when driving, the GPF is nearly clogged. You should regenerate the GPF when the GPF warning light comes on. To go out the warning light, the vehicle must stay in motion until regeneration has been completed.

The process normally takes about 25 minutes.

The optimum condition to end the process are achieved by keeping the vehicle in motion at a speed of 50 km/h (31 mph) or higher, and an engine speed higher than 2,000 rpm.


However, you should drive carefully and within the legal speed limit, and should take in to consideration the surrounding traffic condition.

If you drive your vehicle until the light goes out, the regeneration of the GPF will be completed.

NOTICE

Be sure to regenerate the GPF when the GPF warning light comes on. Failure to regenerate the GPF will cause a vehicle malfunction due to the clogged filter.

Parking Brake Lever



55T050220

- (1) To set
- (2) To release
- (3) To release

The parking brake lever is located between the front seats. To set the parking brake, depress the brake pedal and pull the parking brake lever all the way up. To release the parking brake, depress the brake pedal and pull up slightly on the parking brake lever, push the button on the end of the lever with your thumb, and lower the lever to its original position.

⚠ WARNING

- Never drive your vehicle with the parking brake on: rear brake effectiveness can be reduced from overheating, brake life may be shortened, or permanent brake damage may result.
- If the parking brake does not hold the vehicle securely or does not fully release, have your vehicle inspected immediately by a Maruti Suzuki authorized workshop.
- Always set the parking brake fully before leaving your vehicle or it may move, causing injury or damage. When parking, check that the gearshift lever is in one of the following positions:
 - 1st gear or “R” (Reverse) for manual transmission vehicles.
 - “D”, “M” or “R” for Auto Gear Shift vehicles. Also, check the instrument cluster to make sure that the transmission is engaged in “1” or “R” position.

Remember, even though the transmission is in gear or in Park, you must set the parking brake fully.

(Continued)

⚠ WARNING

(Continued)

- When parking the vehicle in extremely cold weather, the following procedure should be used:
 - 1) Set the parking brake.
 - 2) Manual transmission – turn off the engine, then shift into reverse or first gear.
Auto Gear Shift – shift into reverse or first gear and check the gear position indicator in the instrument cluster to make sure that the transmission is engaged in 1st or reverse, then turn off the engine.
 - 3) Get out of the vehicle and put chocks under the wheels.
 - 4) Release the parking brake.
When you return to your vehicle, first set the parking brake, and then remove the wheel chocks.
- Do not leave cigarette lighters, spray cans, soft drink cans or plastic articles (such as glasses, CD cases, etc.) in sun-heated vehicle. The temperature inside the vehicle may cause as follows:
 - Gas may leak from a cigarette lighter or spray can and may lead to a fire.
 - The glasses, plastic cards or CD cases, etc. may deform or crack.
 - Soft drink cans may fracture.

NOTE:

(For Auto Gear Shift Model)

For details on how to use the gearshift lever to park the vehicle, refer to “Parking” in “Auto Gear Shift” in this section.

Parking Brake Reminder Buzzer

A buzzer sounds intermittently to remind you to release the parking brake if you start the vehicle without fully releasing the parking brake. Check that the parking brake is fully released and the brake system warning light turns off.

OPERATING YOUR VEHICLE

Precaution for Parking

When Moving the Vehicle

When moving the vehicle, start the engine.

⚠ WARNING

If you coast with the engine off, stronger force than normal is required when turning the steering wheel or depressing the brake pedal, resulting in an accident.
Do not coast on a downhill slope with the engine off.

When Taking a Nap in the Vehicle



69RHS172

Do not take a nap in the vehicle with the engine running.

⚠ WARNING

- Exhaust gases can enter the vehicle due to surrounding conditions and wind direction, possibly causing carbon monoxide poisoning.
- The gearshift lever could change unintentionally, or the accelerator pedal could be depressed accidentally, causing an accident.
- If you were to accidentally step on the accelerator pedal while you are asleep, the engine and the exhaust system could overheat, resulting in danger of fire.

With the Engine Running, the Cooling Fan (Radiator Fan) may Rotate Suddenly

The cooling fan (radiator fan) in the engine compartment may automatically stop and rotate depending on the conditions of the engine coolant temperature.

⚠ WARNING

If you get close to a rotating cooling fan (radiator fan), your hands, hair and clothing may get caught in it, resulting in personal injury.
With the engine running, even when the cooling fan (radiator fan) stops, it may automatically rotate. Therefore, do not get close to the cooling fan (radiator fan).

When You Park the Vehicle Outside on a Snowy Day

⚠ WARNING


- When you park the vehicle under the eaves or the trees, fallen snow may hit the vehicle's roof and it may be dented.
Do not park the vehicle under the eaves or the trees on a snowy day.
- If you park the vehicle outside on a snowy day, the wiper arms may be deformed and the wiper blades may be frozen on the windshield, because of the weight of snow.
When you park the vehicle outside, raise the wiper arms.

Do not Park the Vehicle Near Flammable Materials



69RHS174

When Leaving the Vehicle, Stop the Engine and Lock Doors



69RHS054

Even when leaving the vehicle for a short time, do not leave cash or valuables inside, as there is a risk of theft.

⚠ WARNING

- If you park the vehicle near flammable materials, the exhaust pipes and exhaust gas will get hot, resulting in danger of fire.
Do not park the vehicle near flammable materials such as dry grass, paper waste and plywood.

- #### ⚠ WARNING
- If you leave the vehicle unattended with the engine running, problems such as fire or theft can occur.
Do not leave the vehicle unattended with the engine running.

OPERATING YOUR VEHICLE

Do not Leave the Computer and the Mobile Phone in the Vehicle

There is the possibility of theft, or these items could become damaged due to moisture, humidity or temperature change.

Do not Leave Lighters and Eye-glasses in the Vehicle



69RHS175

⚠ WARNING


- As the inside of the vehicle becomes hotter when parking in areas where strong sunlight causes increased temperature, there is the danger of spontaneous ignition of lighters or spray cans, fire due to explosion, the deformation or cracking of eyeglasses, plastic cards or CD cases, or the rupture of carbonated beverage cans. When parking in those areas, do not leave lighters, spray cans, plastic products (eyeglasses, plastic cards, CD cases, etc.) or carbonated beverage cans in the vehicle.
- When items get pushed around or when the seats are moved, it is possible that gas could escape and lead to a fire. Do not place accessories such as lighters or spray cans with exposed operating parts in the glove box, in storage compartments, between the seats, on the floor, etc.

Using Transmission

⚠ WARNING

Do not hang any items on the gearshift lever and do not use the gearshift lever as a handrest. Otherwise, it could prevent proper operation of the gearshift lever and cause its malfunction, resulting in an accident.

Manual Transmission



56RM03002

Starting off

To start off, depress the clutch pedal all the way to the floor and shift into 1st gear. After releasing the parking brake, gradually release the clutch. When you hear a change in the engine's sound, slowly press the accelerator while continuing to gradually release the clutch.

Shifting

All forward gears are synchronized and provide quiet and easy shifting. Always depress the clutch pedal all the way to the floor before shifting gears. Keep the engine speed from rising into the red zone of the tachometer.

Downshifting maximum allowable speeds

For K12N(DOHC) engine models

Downshifting	km/h
2nd to 1st	20
3rd to 2nd	80
4th to 3rd	125
5th to 4th	170*

For K10C(DITC) engine models

Downshifting	km/h
2nd to 1st	20
3rd to 2nd	80
4th to 3rd	125
5th to 4th	175*

***NOTE:**

You may not accelerate to the maximum allowable speed because of the driving situation and/or the vehicle condition.

WARNING

- Reduce your speed and downshift to a lower gear before going down a long or steep hill. A lower gear will allow the engine to provide braking. Avoid riding the brakes or they may overheat, resulting in brake failure.
- When driving on slippery roads, slow down before downshifting. Excessive and/or sudden changes in engine speed may cause loss of traction, which could cause you to lose control.

NOTICE

- Do not downshift to a lower gear at the speed faster than the maximum allowable speeds for the next lower speed, or severe damage to engine and transmission can result.
- Before engaging reverse gear [R], check that the vehicle is completely stationary and gear lever is in neutral [N] position. After depressing clutch pedal fully, shift to [R].
- To help avoid clutch damage, do not use the clutch pedal as a foot-rest while driving or use the clutch to keep the vehicle stationary on a slope. Depress the clutch fully when shifting.
- When shifting or starting off, do not race the engine. Racing the engine can shorten engine life and cause negative effect to smooth shifting.

NOTE:

If it is difficult to engage reverse gear [R], follow below procedure.

- Put gear lever in neutral [N] position.
- Release clutch pedal once.
- Again depress the clutch pedal and shift from [N] to [R].

OPERATING YOUR VEHICLE

Automatic Transmission

Gearshift lever




55TB501

The gearshift lever is designed so that it cannot be shifted out of "P" position unless the ignition mode is ON and the brake pedal is depressed.

WARNING

Always depress the brake pedal before shifting from "P" (Park) (or "N" (Neutral) if the vehicle is stationary) to a forward or reverse gear, to help prevent the vehicle from moving unexpectedly when you shift.

The gearshift lever has a lock mechanism to help prevent accidental shifting. Shift the gearshift lever as follows:



55TB502

(1) Knob button

	Shift with the knob button (1) pushed in and the brake pedal depressed.
	Shift with the knob button (1) pushed in.
	Shift without the knob button (1) pushed in.

NOTE:

- Always shift the gearshift lever without pushing in the knob button (1) except when you shift from "P" to "R", from "D" to "M" or "L", from "N" to "R" or from "R" to "P". If you always push in the knob button (1) when shifting the gearshift lever, you could shift into "P", "R", "M" or "L" by mistake.
- If driver's or passenger's knee hits the gearshift lever while driving, the lever could move and the gear could be changed unexpectedly.

Use the gearshift lever positions as described below:

P (Park)

Use this position to lock the transmission when the vehicle is parked or when starting the engine. Shift into Park only when the vehicle is completely stationary.

R (Reverse)

Use this position to reverse the vehicle from stop. Make sure that vehicle is completely stationary before shifting into Reverse.

NOTICE

Do not shift the gearshift lever into "R" while moving forward, or the transmission may be damaged. If you shift into "R" when the vehicle speed is over 10 km/h, the transmission will not shift into reverse.

N (Neutral)

Use this position for starting the engine if the engine stalls and you need to restart it while the vehicle is moving. You may also shift into Neutral and depress the brake pedal to hold the vehicle stationary during idling.

D (Drive)

Use this position for all normal driving.

With the gearshift lever in "D" range you can get an automatic downshift by pressing the accelerator pedal. The higher the vehicle speed is, the more you need to press the accelerator pedal to get a downshift.

M (manual mode)**(models with manual mode)**

Use this position for driving in the manual mode. Refer to "Manual mode" later in this section for details on how to use the manual mode.

NOTE:

If you move the gearshift lever to a lower gear while driving faster than the maximum allowable speed for the lower gear, the transmission will not actually downshift until your speed drops below the maximum speed for the lower gear.

CAUTION

If you cannot press the engine switch firmly, the engine may not start.

Even if you shift the gearshift lever into "R" or "D" position without the engine running, the vehicle does not move.

If you try to move your vehicle under the above-mentioned condition, the vehicle may move in unexpected directions on a slope, etc. This may cause an accident. When starting the engine, press the engine switch firmly. Also, make sure that the engine is running by checking engine sound or warning and indicator lights.

NOTICE

- Do not shift the gearshift lever into "R" while moving forward, or the transmission may be damaged. If you shift into "R" when the vehicle speed is over 11 km/h, the transmission will not shift into reverse.

- Be sure to take the following precautions to help avoid damage to the automatic transmission:

- Make sure that the vehicle is completely stationary before shifting into "P" or "R".
- Do not shift from "P" or "N" to "R", "D" or "M" when the engine is running above idle speed.
- Do not rev the engine with the transmission in a drive position ("R", "D" or "M") and the front wheels not moving.
- Do not use the accelerator to hold the vehicle on a hill. Use the vehicle's brakes.

NOTE:

When you shift the gearshift lever into "P" and stop the engine before depressing the parking brake pedal, if you try to restart the engine and shift the gearshift lever into the position other than "P", it may reduce gearshift lever capability, or unusual sound and shock may occur. However, this is not abnormal.


OPERATING YOUR VEHICLE

Manual mode


(models with manual mode)

The automatic transmission can shift gears automatically. When using the manual mode, you can shift gears in the same manner as conventional manual transmission.

To use the manual mode, shift the gearshift lever from "D" to "M".



55TB503



55TB504

(1) Manual mode indicator

(2) Gear position

The information display shows the manual mode indicator and the current gear position.

NOTE:

- *The indicated gear position in the information display when you shift from "D" to "M" is the gear position that was selected automatically when the gearshift lever was in "D".*
- *You can change to the manual mode temporarily by pulling the shift paddle on the steering wheel toward you when the gearshift lever is in "D".*

Shifting in the manual mode

You can shift gears from 1st to 6th depending on driving speed.


NOTE:

- *When the driving speed becomes slow, the gear shifts down automatically, and when the vehicle stops, the gear position will be in 1st gear without shifting the gearshift lever.*
- *In Manual mode, even if the engine is redlined, the gear is not shifted up automatically.*

NOTE:

When you change gear, sometimes the transmission may not shift to the desired gear but a buzzer sounds instead. This is to maintain good driveability and to protect the transmission.

Using the shift paddle



55TB505

To shift up, pull "+" side shift paddle, located on right side of the steering wheel, toward you. When you release your finger from the switch, the switch will return to the original position.

To shift down, pull "-" side shift paddle, located on left side of the steering wheel, toward you. When you release your finger from the switch, the switch will return to the original position.

NOTE:


- To shift gears continuously, release your finger from the shift paddle, then pull the shift paddle again. You cannot shift gears continuously while holding the shift paddle toward you.*
- When you pull the both “+” and “-” shift paddle simultaneously, the gear may not shift.*

Canceling the manual mode

To cancel the manual mode, shift the gearshift lever from “M” to “D”.

Temporary manual mode


Pull the shift paddle toward you when driving with the gearshift lever in “D”. The information display shows the manual mode indicator and the current gear position.



(1) Manual mode indicator
(2) Gear position

The temporary manual mode will be canceled automatically in the following situations.

- When you press and hold the accelerator pedal for a certain period of time without shifting gears.
- When driving speed becomes slow.
- In case of high accelerator pedal input temporary manual mode is not canceled.
- In case of no accelerator pedal input temporary manual mode cancellation happens only when driving speed becomes slow.

If you cannot Shift Automatic Transmission Gearshift Lever out of “P” (PARK)

74TB05022

The automatic transmission vehicles have an electrically operated park-lock feature. If the vehicle's lead-acid battery is discharged, or there is some other electrical


failure, the automatic transmission cannot be shifted out of Park in the normal way. Jump starting may correct the condition. If not, follow the procedure described below. This procedure will permit shifting the transmission out of Park.

- 1) Be sure the parking brake is firmly applied.
- 2) If the engine is running, stop the engine.
- 3) Make sure the ignition mode is ON or ACC.
- 4) Remove the cover (1) by using a flat-bladed screwdriver covered with a soft cloth as shown.
- 5) With the release button (2) pushed by the key or the flat end rod, push the knob button (3) and shift the gearshift lever to the desired position.

This procedure is for emergency use only. If repeated use of this procedure is necessary, or the procedure does not work as described, take the vehicle to a Maruti Suzuki authorized workshop.

OPERATING YOUR VEHICLE

Auto Gear Shift



Auto Gear Shift is a 5-speed forward/reverse transmission.

Auto Gear Shift has the basic features of conventional manual transmission, but clutch operation and transmission gear shifting are controlled electronically.

NOTICE

Do not depress both the brake pedal and accelerator pedal simultaneously.

This can cause damage or overheating to the clutch.

NOTE:

When you open the driver's door, the Auto Gear Shift systems run automatically and you may hear an operating noise. This sound does not indicate malfunction.

Depress brake pedal indicator



This light will come on if you do not depress the brake pedal in the following situations.


- When starting the engine.
- When the engine is on and the gearshift lever is shifted from "N" position to "D", "M" or "R" position.
- When the ignition switch is in "ON" position or the ignition mode is "ON", and the engine is off, the gearshift lever is shifted into any position.

This light will also come on if one of the gears cannot be engaged and the system is unable to re-try shifting when you shift the gearshift lever from "N" position to "D", "M" or "R" position.

Starting the engine

When starting the engine, always place the gearshift lever in the "N" position and depress the brake pedal firmly. The engine cannot be started unless the gearshift lever is in the "N" position and the brake pedal is depressed.

If you parked vehicle with gear engaged on last time (if you can see "1" or "R"), shift into "N" (Neutral) and depress the brake pedal. Hold the brake pedal while starting the engine. You can hear buzzer in short time.



CAUTION

For the vehicles with the keyless push start system, if you cannot press the engine switch firmly, the engine may not start. Even if you shift the gearshift lever into "R" or "D" position without the engine running, the vehicle does not move.

If you try to move your vehicle under the above-mentioned condition, the vehicle may move in unexpected directions on a slope, etc.

This may cause an accident.

When starting engine, press engine switch firmly. Also, make sure that the engine is running by checking engine sound or warning and indicator lights.

NOTE:

- If you start the engine without the gearshift lever in the "N" position, the gear position indicator in the instrument cluster will blink.
- When the engine restarts automatically after engine A-Stop, the gear position indicator in instrument cluster may display "N" temporarily. This is a normal phenomenon.

Clutch operation

You can select either the Drive (D) mode or the Manual (M) mode or the Reverse (R) mode. Since this vehicle controls clutch operation electronically in either mode, you do not need to operate the clutch.

Creeping function

This vehicle has a creeping function that helps the vehicle to start smoothly by engaging the clutch. When the gearshift lever is in any of the positions "D", "M" or "R", and you release your foot from the brake pedal, the vehicle starts slowly without depressing the accelerator pedal. However, creep is not possible in manual (M) mode with 2nd gear engaged. The creeping function is disabled if you depress the brake pedal or pull up the parking brake lever.

NOTE:

If the driver's door is opened and/or the parking brake lever is engaged with the gear in the "M", "D" or "R" position, the creeping function will not operate.

Parking and Stopping the vehicle

Auto Gear Shift does not have a parking position. Park the vehicle with a gear engaged. Make sure that the gearshift lever is "D", "M", or "R".

Also, check the instrument cluster to make sure that the transaxle is engaged in "1" or "R" position.

NOTICE

The vehicle will become inoperative if you continue to operate the vehicle with the gearshift lever in between each shift positions.

Drive (D) mode

When the Drive (D) mode is activated, the most appropriate gear position is automatically selected upon operation of the accelerator pedal and variation of vehicle speed.

Normal driving:

- 1) Start the engine as instructed in "Starting the engine" in this section.
- 2) With your foot on the brake pedal, shift the gearshift lever to the "D" position.

When the gearshift lever is shifted to the "D" position, the gear will be shifted to 1st.



55RM03009

OPERATING YOUR VEHICLE

NOTE:

- If 1st gear cannot be engaged even though the gearshift lever has been shifted from the "N" to the "D" position, the system will re-try shifting automatically. This will take some time, noise may be heard from the gears, and shifting gear shock may occur. However, they do not indicate malfunction.
 - The "N" indicator will flash, the depress brake pedal indicator will come on and a warning buzzer (long pulse sound) will sound if any of the following cases occur;
 - If you shift the gearshift lever from the "N" to the "D" position without depressing the brake pedal
 - If the system is unable to re-try shifting You should depress the brake pedal and shift the gearshift lever to "N" position, then shift to "D" again.

- Release the parking brake and brake pedal.
- Depress the accelerator pedal slowly.

⚠ WARNING

- While driving the vehicle, do not shift the gearshift lever to the "N" position. The engine brake may not work and you may get involved in an unexpected accident. If you return the gearshift lever from "N" to "D" because of unintended shifting, the gear position will be shifted according to the current vehicle speed.
- Always keep your foot on the brake pedal while stopped with the engine running. This operation prevents the vehicle from moving due to unintended activation of the creeping function.

NOTICE

Do not operate the system as described below. The life cycle of the clutch may be reduced.

- Using the accelerator pedal to hold the vehicle on an uphill slope with the gearshift lever in the "D" or "M" position. If you perform this operation for a certain period of time, a warning buzzer will sound.
- Shifting the gearshift lever to the "D", "M" or "R" position while racing the engine.
- Driving at low speed using a high gear.
- Holding the vehicle on an uphill slope using the creeping function. If you perform this operation for a certain period of time, a warning buzzer will sound.

NOTICE

If the gearshift lever cannot shift into any position, or the gear is changed to "N" position automatically when the vehicle speed becomes less than 10 km/h, there may be a systematic malfunction. In this case, ask a Maruti Suzuki authorized workshop to inspect the Auto Gear Shift system as soon as possible.

Starting off on an uphill/downhill:

CAUTION

The hill hold control system will not activate while the parking brake is engaged.

Uphill

- 1) Apply the parking brake firmly so that the vehicle does not roll backwards.
- 2) Shift the gearshift lever to the "D" position while depressing the brake pedal. Make sure that the gear position indicator in the instrumental cluster displays 1st gear.
- 3) Release the brake pedal and depress the accelerator pedal gradually, and when the vehicle starts to move, release the parking brake and depress the accelerator pedal to start off.

NOTICE

On an uphill slope, never hold the vehicle at a stop using only the accelerator pedal or the creeping function. If you perform this operation for a certain period of time, a warning buzzer will sound, and in some cases the engine will stall. This can also cause excessive damage to the clutch.

Downhill

- 1) Depress the brake pedal and shift the gearshift lever to the "D" position. Make sure that the gear is in 1st by checking the gear position indicator.
- 2) Release the brake pedal and depress the accelerator pedal slowly. Even if the accelerator pedal is not depressed, the clutch will be engaged when the vehicle speed increases.

Using engine braking:

When driving on a downhill slope, downshifting is recommended. So you can use engine braking.

By placing the gearshift lever in the "M" position, the Manual (M) mode is selected, and you can shift to a lower gear manually. For details of downshift operation, refer to "Upshift and downshift" in the "Manual (M) mode".

Manual (M) mode


The gears are not shifted automatically. To shift the transmission, the driver must operate the gearshift lever to the "+" or "-" direction.

NOTE: When the vehicle is slowed down in Manual mode the gears are shifted down automatically only when the engine speed is very low.

As for conventional manual transmission vehicles, releasing the accelerator pedal a little may help the transmission to shift smoothly.


Upshift and downshift:

Upshifting



56RH00309


Pull the gearshift lever to the "+" direction and release it. Every time the lever is operated, the transmission is upshifting 1 step in the order of 1st → 2nd → 3rd → 4th → 5th gear.



76MH0A059


OPERATING YOUR VEHICLE

Downshifting



56RH00310

Push the gearshift lever to the “-” direction and release it. Every time the lever is operated, the transmission is downshifted in the order 5th → 4th → 3rd → 2nd → 1st gear.



76MH0A061

The gear position is displayed on the gear position indicator. The gear position indicator shows the transmission gear position. Before starting off, always make sure transmission is engaged in 1st or reverse gear and gear position indicator is showing the intended gear, then depress the accel-

erator pedal. It is possible to start vehicle in 2nd gear using manual mode, from stop condition.

NOTE:

- Always use 1st gear while starting off an uphill slope otherwise you can damage the clutch.
- To downshift smoothly, the engine runs fast in some cases. This is done intentionally by the system and is not malfunction.
- When driving down a hill, downshift and use the engine braking appropriately. If necessary, continuous downshifting is possible. However, if downshifting more than 3 steps, gear shifting will take more time.
- When the gear is shifting, a noise can be heard in some case. This is not malfunction.

! WARNING

- Be careful when accelerating, upshifting, downshifting or braking on a slippery surface. Sudden acceleration or engine braking could cause the vehicle to spin or skid. While starting off on a slippery or snowy roads, please use 2nd gear (if required).
- To drive down a long or steep hill, reduce your speed and downshift. Remember, if you ride the brakes excessively, they may overheat and fail.
- While driving the vehicle, do not shift the gearshift lever to “N” position. The engine brake may not work and you may get involved in an unexpected accident. If you return the gearshift lever from “N” to “M” because of unintended shifting, the gear position will be shifted according to the current vehicle speed.
- Do not apply the parking brake while driving. Otherwise, it could cause a skid and you may get involved in an unexpected accident.

NOTICE

- If the gearshift lever cannot shift into any position, or the gear is changed to "N" position automatically when the vehicle speed becomes less than 10 km/h, there may be a systematic malfunction. In this case, ask a Maruti Suzuki authorized workshop to inspect the Auto Gear Shift system as soon as possible.
- The manual (M) mode does not upshift even if the engine speed reaches the rev-limit.
- The system will not allow shifting up or down to a gear that would cause engine over-revving or under-revving.
- If frequently driving at low speed using a high gear position, the life cycle of the clutch may be reduced.
- Frequent downshifting (more than 3 positions consecutively) causes the reduction of transmission life.

Starting off:

- Start the engine as instructed in "Starting the engine" in this section.
- With your foot on the brake pedal, shift the gearshift lever to the "M" position. When the gearshift lever is shifted to the "M" position, the gear will be shifted to 1st. Before starting off, always make sure that the intended gear is engaged by checking the gear position indicator, then depress the accelerator pedal.

NOTE:

- If 1st gear cannot be engaged even though the gearshift lever has been shifted from the "N" to the "M" position, the system will re-try shifting automatically. This will take some time, noise may be heard from the gears, and shifting gear shock may occur. However, they do not indicate malfunction.*
- The "N" indicator will flash, the depress brake pedal indicator will come on and a warning buzzer (long pulse sound) will sound if any of the following cases occur;*
 - If you shift the gearshift lever from the "N" to the "M" position without depressing the brake pedal.*
 - If the system is unable to re-try shifting.*

You should depress the brake pedal and shift the gearshift lever to "N" position, then shift to "M" position again a few seconds later.

- Release the parking brake and brake pedal. Depress the accelerator pedal slowly for smooth starting.

! WARNING

Always keep your foot on the brake pedal while stopped with the engine running. These operations prevent the vehicle from starting due to unintended activation of the creeping function.

NOTICE

Do not operate the system as described below. The life cycle of the clutch may be reduced.

- Using the accelerator pedal to hold the vehicle on an uphill slope operation with the gearshift lever in the "M" or "D" position. On a downhill slope, operation with gearshift lever in "R" position. If you perform this operation for a certain period of time, a warning buzzer will sound.**
- Shifting the gearshift lever to the "M", "D" or "R" position while racing the engine.**
- Driving at low speed using a high gear.**
- Stopping on a slope using the creeping function. If you perform this operation for a certain period of time, a warning buzzer will sound.**

OPERATING YOUR VEHICLE

Starting off on an uphill/downhill slope:

Uphill

- 1) Apply the parking brake firmly so that the vehicle does not roll backwards.
- 2) Shift the gearshift lever to the "M" position while depressing the brake pedal. Make sure that the gear position indicator in the instrumental cluster displays 1st gear.
- 3) Release the brake pedal and depress the accelerator pedal gradually, and when the vehicle starts to move, release the parking brake and depress the accelerator pedal to start off.

NOTICE


On an uphill slope, never hold the vehicle at a stop using only the accelerator pedal or creeping function. If you perform this operation for a certain period of time, a warning buzzer will sound, and in some cases the engine will stall. This can also cause excessive damage to the clutch. In case the warning buzzer is on, shifting to 2nd gear will not be possible in manual mode. Always use 1st gear while starting off on a uphill slope. Otherwise you may damage the clutch.

Downhill

- 1) Depress the brake pedal and shift the gearshift lever to the "M" position. Make sure the gear position indicator to make sure that the gear is in 1st.
- 2) Release the brake pedal and depress the accelerator pedal slowly. Even though the accelerator pedal is not depressed, the clutch will be engaged when the vehicle speed increases.

Backing up

After the vehicle has stopped completely, depress the brake pedal and shift the gearshift lever to the "R" position. Depress the accelerator pedal slowly as when starting off in 1st gear. Before backing up, make sure that reverse gear is selected by checking the gear position indicator.



76MH0A062

NOTE:

- If reverse gear cannot be engaged even though the gearshift lever has been shifted from the "N" to the "R" position, the system will re-try shifting automatically. This will take some time, noise may be heard from the gears, and shifting gear shock may occur. However, they do not indicate malfunction.
- The "N" indicator will flash, the depress brake pedal indicator will come on and a warning buzzer (long pulse sound) will sound if any of the following cases occur;
 - If you shift the gearshift lever from the "N" to the "R" position without depressing the brake pedal.
 - If the system is unable to re-try shifting.You should depress the brake pedal and shift the gearshift lever to "N" position, then shift to "R" position again a few seconds later.
- The system will not allow shifting to the "R" position if the vehicle speed is over about 3 km/h. If the gearshift lever is operated under this condition, the "N" indicator in the instrument cluster will blink. However, when the vehicle speed drops below about 3 km/h, the gear will be shifted to reverse. Make sure that the vehicle has stopped completely before shifting to the "R" position.

NOTICE

On a downhill slope, never hold the vehicle at a stop using only the accelerator pedal or the creeping function. If you perform this operation for a certain period of time, a warning buzzer will sound, and in some cases the engine will stall. This can also cause excessive damage to the clutch.

Stopping

The vehicle can be stopped by depressing the brake pedal regardless of the gear position. This is because the clutch is automatically disengaged to prevent the engine from stopping.

- If the gearshift lever is in the "D" position, the gear will be downshifted to 1st when the vehicle stops.
- If the gearshift lever is in the "M" position, the gear will be automatically downshifted to 1st when the vehicle is stopped.

! WARNING

- When stopping, for example, at a traffic light, be sure to depress the brake pedal firmly. For your safety, apply the parking brake, too, when stopping on a hill.
- When racing the engine, make sure that the gear is in the "N" position by checking the gear position indicator. If the accelerator is operated with the gear in any other position, the vehicle may move resulting in an unexpected accident.
- Do not leave your vehicle unattended while the engine is running.
- When leaving the vehicle, stop the engine and park the vehicle with a gear engaged. If you need to leave the vehicle with the engine running, apply the parking brakes firmly, and shift the gearshift lever to the "N" position. Otherwise, the vehicle may move unexpectedly and may cause an accident.

NOTICE

- On a slope, never hold the vehicle at a stop using only the accelerator pedal or the creeping function. If you perform this operation for a certain period of time, a warning buzzer will sound, and in some cases the engine will stall. This can also cause excessive damage to the clutch.
- If the gearshift lever is operated more than necessary, the system may not allow operation of the gearshift lever for a certain period of time, and the gear may not be shifted appropriately. Therefore, do not operate the gearshift lever if not necessary.

OPERATING YOUR VEHICLE

Parking

Unlike an automatic transmission, Auto Gear Shift does not have a parking position. The vehicle can be parked with the gearshift lever at "D" or "R" position. Remember, even though the transmission is in gear, you must set the parking brake firmly. Park the vehicle with a gear engaged.

- 1) Apply the parking brake firmly.
 - 2) While depressing the brake pedal, shift the gearshift lever to the "R" position on a downhill slope, and to the 1st position in the drive (D) mode or the "M" position in the manual (M) mode on an uphill slope and confirm the gear position by checking the gear position indicator.
 - 3) Stop the engine.
 - 4) In the case of uphill/downhill slope, release the parking brake and brake pedal slowly in order to check the gear is engaged.
 - 5) After check the vehicle stopped by the gear engaged, Apply the parking brake and the brake pedal firmly again.
 - 6) Get out of the vehicle and put chocks under the wheels.
- When you return to your vehicle, you must remember to remove the wheel chocks.

NOTE:

- After Ignition is OFF , the gear in the transmission does not change even if you shift the gearshift lever in any position with or without brake pedal

pressed. Always shift the gearshift lever before stopping the engine.

- Check the transmission gear position by looking at the gear position indicator, then turn the ignition switch to "LOCK" position or press the engine switch to change the ignition mode to "LOCK" (OFF), to stop the engine. Release the brake pedal after a few seconds.

⚠ WARNING

- If the gear is not engaged properly and completely before the ignition switch is turned to "LOCK" position or the engine switch is pressed to change the ignition mode to "LOCK" (OFF), the vehicle may not be parked with the gear engaged. Always confirm the gear position by checking the gear position indicator when parking.
- On a downhill slope, the gear should be put in reverse, and in 1st gear on an uphill slope. In case of uphill/downhill slope, after checking the vehicle stopped by the gear engaged, put the chocks under the wheels. Otherwise, the vehicle may move, and cause an unexpected accident. If the gear is left in the "N" position, the vehicle cannot be parked with a gear engaged.

Parking cancel

Depress the brake pedal, turn the ignition switch to the "ON" position or press the engine switch to change the ignition mode to "ON", and shift the gearshift lever to the "N" position. The gear will be disengaged.

Warning functions

A warning buzzer will sound or the indicator will blink under the following conditions.

Warning buzzer

- The clutch is heated due to excessive load.
- The creeping function is being activated for a long period of time.

NOTICE

In the above cases, pull over to the side of the road and stop the engine, and then ask a Maruti Suzuki authorized workshop to inspect your vehicle. Otherwise, the clutch disc may be damaged.

- The ignition switch is turned to "LOCK" position or the engine switch is pressed to change the ignition mode to "LOCK" (OFF) with the gear in 2nd, 3rd, 4th or 5th. In this case, turn the ignition switch to "ON" position or press the engine switch to change the ignition mode to "ON", and shift the gearshift lever in the "N" position, shift it to the "D" or "M" or "R" position, then turn the ignition switch

to "LOCK" position or press the engine switch to change the ignition mode "LOCK" (OFF).

- During a stop, if the driver's door is opened with the gearshift lever in the "R", "D" or "M" position while the engine is running and brake pedal is released for some time, gear is disengaged automatically for safety.

"N" indicator blinking

When the gear indicator lamp blinks "N", you should depress the brake pedal and shift the gearshift lever to "N" position.


"1" indicator blinking

When the gear indicator lamp blinks "1", you should depress the brake pedal and shift the gearshift lever to "N" position, then shift to "D" or "M" position again a few seconds later.

"R" indicator blinking

When the gear indicator lamp blinks "R", you should depress the brake pedal and shift the gearshift lever to "N" position, then shift to "R" position again a few seconds later.

Gearshift Indicator (if equipped)



72RH4027

In the following case, the gearshift indicator is indicated in the information display when the ignition switch is in the "ON" position or the ignition mode is "ON".

- When the gearshift lever is in a position other than "N" (Neutral).

The electronic control system monitors driving condition (such as vehicle speed and/or engine revolution), and it recommends gearshift for your driving with indications on display.

If UP/DOWN arrow and the gear position other than currently selected are indicated on the display while driving, we recommend you to shift up or down the gear to indicated position. It is the optimal gear position for a driving condition that reduces the over revolution and stress to the engine, and improves fuel consumption.

NOTE:

When cruise control system SET indicator is ON, Gear Shift Indicator may not be displayed.

For details on how to use the transmission, refer to "Using Transmission" in this section.

WARNING

The gearshift indicator is designed to indicate optimal gear position for your driving, however, a driver will not be relieved from the duty of care of driving operation or gear change with this indicator.

To drive safe, do not gaze the gearshift indicator, pay attention to your driving situation and shift up or down if necessary.

OPERATING YOUR VEHICLE

NOTE:

- The gearshift indicator is not indicated when the gear position is in "N" (Neutral).
- If you depress the clutch pedal while UP/DOWN arrow is indicated, the indication will disappear.
- In ordinary driving, UP arrow will disappear when you release your foot from the accelerator pedal.
- The indication of gearshift indicator timing may differ depending on the vehicle condition and/or driving situation even in the same vehicle speed and engine revolution.
- If ESP® system is working, the gear shift indicator will disappear temporarily.

Example of the gearshift indicator

Indication	Description
 74TB05031	Lower gear position is selected for the vehicle speed and/or engine revolution. Changing to a higher gear position is recommended. <ul style="list-style-type: none">• In this case, shifting up to 4th gear position is recommended.
 74TB05032	Current gear position is optimal for the vehicle speed and/or engine revolution. <ul style="list-style-type: none">• In this case, 3rd gear position is the best.
 74TB05033	Higher gear position is selected for the vehicle speed and/or engine revolution. Changing to a lower gear position is recommended. <ul style="list-style-type: none">• In this case, shifting down to 2nd gear position is recommended.

SHVS (Smart Hybrid Vehicle by Suzuki) (for K10C engine) (If Equipped)

SHVS has an Integrated Starter Generator (ISG) instead of conventional generator to get a better fuel consumption.

Integrated Starter Generator (ISG) is a generator which incorporates a motor function.


The ISG has the following 3 functions.

- Deceleration energy regenerating function
- Engine power assist function
- Starter motor function

WARNING

Dripping engine oil, brake fluid and coolant, etc. to the ISG may cause a fire or malfunction. Do not spill them when pouring.

Deceleration Energy Regenerating Function



55TB507

While decelerating your vehicle, the ISG generates electricity without engine power. This reduces engine loads and improves fuel consumption.


While decelerating your vehicle, deceleration energy regenerating function will be activated when the following conditions are satisfied.

- Gearshift lever is not in "N" (Neutral).
- Clutch pedal is not depressed.
- Inside temperature of lead-acid battery is in normal condition.
- Lithium-ion battery is not fully charged and inside temperature is in normal condition. etc.

NOTE:

The deceleration energy regenerating function may not work depending on vehicle conditions.

Engine Power Assist Function



55TB508

While the vehicle is running, ISG assists engine power as a motor in the following limited condition. This reduces engine loads and improves fuel consumption.

While the vehicle is running with the engine speed at approximately 3900 rpm or less, engine power assist function will be activated when all of the following conditions are satisfied.

- SHVS system and ENG A-STOP system are working properly. (ENG A-STOP OFF indicator light is not blinking.)
- Clutch pedal is not depressed.
- ESP® is not activated.
- Accelerator pedal is excessively depressed.


OPERATING YOUR VEHICLE

- Lead-acid battery and lithium-ion battery are fully charged and each inside temperature is in normal condition.
- Engine coolant temperature is in normal condition.
- ISG inside temperature is in normal condition.

NOTE:

- The engine power assist function may not work depending on vehicle conditions.
- The engine power assist function may not work while the battery capacity is being checked right after the engine start, and so on.
- The subjective feeling of the horn sound, head lamp illumination and A/C blower speed is likely to be different during vehicle take off, deceleration energy regeneration function and engine power assist function operation.

Starter Motor Function



55TB509


After the engine auto stop by the ENG A-STOP system, the engine will be restarted using a cranking power of the ISG.

The starting with the ISG is quiet compared with starting by the conventional starter motor.

NOTE:

When you restart the engine by pushing the engine switch, the conventional starter motor is used and you will hear a gear engagement sound.

Lithium-ion Battery Indication




55TB5010

The segments in the lithium-ion battery indicator (1) give an approximate indication of the charge of the lithium-ion battery. The number of segments that appear in the indication increases or decreases with the charge of the lithium-ion battery.

NOTE:

The indicator gives an approximate indication. The indication may be delayed or differ from the actual charge of the lithium-ion battery under certain conditions, for example, when the outside temperature is low. Also, the minimum segment is 1 bar and the bar will never be 0. Even when 1 bar is shown, the battery level may be close to be flat.

Deceleration Energy Regenerating Indicator Light



74TB05001

When the deceleration energy regenerating function is working, the deceleration energy regenerating indicator light (1) comes on.

NOTE:

If the gearshift lever is in the "N" (Neutral) position, this light does not come on.

ENG A-STOP System (Engine Auto Stop Start System) (for K12N engine) (if equipped)

The ENG A-STOP system (engine auto stop start system) automatically stops the engine while waiting briefly at a traffic light, etc., and automatically restarts the engine afterward. This system helps reduce emissions, improve fuel consumption and lower engine noise.

This system stops the engine temporarily under specific conditions. Before parking the vehicle for an extended period of time or leaving the vehicle, properly apply the parking brake and stop the engine with the engine switch.

Once the specific conditions are met, the engine will stop automatically after the vehicle has stopped. However, the engine will not be stopped automatically until confirmation of the system function is finished.

NOTE:

If your vehicle is equipped with automatic heating and air conditioning system, you can change the automatic engine stop condition via the information display. Refer to "Information display" in "INSTRUMENT CLUSTER" section.

CAUTION

- Do not get out of the vehicle while the engine is automatically stopped by the ENG A-STOP system. Doing so may lead to an accident.
 - Manual transmission vehicle – If the driver's seat belt is unfastened and the driver's door is opened, the engine will stall.
 - Auto Gear Shift vehicle – If the driver's seat belt is unfastened, even if the brake pedal is pressed down, or the driver's door is opened, the engine will be restarted to warn you that the engine was stopped automatically by the ENG A-STOP system.
- If the engine does not restart automatically after having been stopped automatically by the ENG A-STOP system, push the engine switch to start the engine. Trying to move the vehicle when the engine has not yet restarted requires a strong force to turn the steering wheel or depress the brake pedal, potentially leading to an accident.

OPERATING YOUR VEHICLE

NOTICE


The vehicle equipped with this system uses a dedicated high-performance battery that supports ENG A-STOP system. Accordingly, observe the instructions listed below. If these instructions are not observed, the system may not actuate properly or the battery may die prematurely.

- When replacing the battery, use a Maruti Suzuki genuine battery specified in the Specification.
- Do not draw power from the battery terminals for electrical products.

Automatic Stopping / Restarting of the Engine

Manual transmission vehicle

- 1) With the brake pedal depressed, decelerate the vehicle.



55TB5016

- 2) After the vehicle has stopped with the clutch pedal depressed and the gearshift lever shifted to "N", and then release the clutch pedal, the engine will stop automatically.

The ENG A-STOP indicator light (green) (1) will come on.

- The ENG A-STOP system will not stop the engine automatically if all the automatic engine stop conditions are not met. For details, refer to "Automatic engine stop conditions" in this section.
- During the automatic engine stop, the engine may shut down, accompanied by

an interior buzzer or restarted, to ensure safety.

For details, refer to "Points to note during the automatic engine stop" in this section.

NOTICE

During the automatic engine stop condition,

- Do not shift the gearshift lever to a position other than "N" without depressing the clutch pedal. If the gear shift lever is in a position other than "N", the engine will not restart automatically even if the clutch pedal is depressed.

NOTE:


During the automatic engine stop, electric equipment will be in the following conditions:

- The audio and other electrical component can be used during the automatic engine stop, but the air conditioner will switch to the fan mode.
- If the vehicle is equipped with automatic heating and air conditioning system, the fan speed will be limited during the automatic engine stop (only in the auto control mode) to keep the cabin air-conditioned for a longer time.

NOTE:

For manual transmission vehicles, if the engine stalled by a rapid clutch operation, the engine will restart with the gear posi-

tioned "N" (neutral) and the clutch pedal depressed.



55TB5017


- 3) Depressing the clutch pedal will restart the engine and ENG A-STOP indicator light (green) (1) will go off.

While the engine is stopped automatically, depressing the clutch pedal will restart the engine consuming fuel. Therefore, for fuel economy, it is recommended to depress the clutch pedal just before the vehicle start.

- Without depressing the clutch pedal, the engine may restart automatically if the automatic engine restart conditions are met. For details, refer to "Automatic engine restart conditions" in this section.

Auto Gear Shift vehicle

- 1) With the brake pedal depressed, stop the vehicle.



55TB5018

- 2) While depressing the brake pedal, place the gearshift lever in "D" or "N" position. "ENG A-STOP" indicator light (green) (1) in the instrument cluster will illuminate and the engine will stop automatically.


- The ENG A-STOP system will not stop the engine automatically if all the automatic engine stop conditions are not met. For details, refer to "Automatic engine stop conditions" in this section.
- During the automatic engine stop, the engine may shut down, accompanied by an interior buzzer or restarted, to ensure safety.

For details, refer to "Points to note during the automatic engine stop" in this section.

NOTE:

During the automatic engine stop, electric equipment will be in the following conditions:

- The audio and other electrical component can be used during the automatic engine stop, but the air conditioner will switch to the fan mode.
- If the vehicle is equipped with automatic heating and air conditioning system, the fan speed will be limited during the automatic engine stop (only in the auto control mode) to keep the cabin air-conditioned for a longer time.



55TB5019

- 3) Remove your foot from the brake pedal. "ENG A-STOP" indicator light (green) (1) in the instrument cluster will be

OPERATING YOUR VEHICLE

turned off and the engine will restart automatically.

When restarting the engine, you can prevent the vehicle from creeping ahead and rolling downward on an uphill slope, by keeping force on the brake pedal temporarily.

NOTE:

When the engine is restarted automatically, the following conditions may be found as the hill hold control system (if equipped) is activated, but this is not a malfunction.

- You may hear a sound from the engine room.
- As brake pedal becomes heavy, it may be difficult for you to depress it.

NOTE:

When the engine does not restart automatically when the brake pedal is released, an interior buzzer will sound and the engine will come out of the automatic engine stop mode and shut down. The ENG A-STOP indicator light (green) will go off.

The engine is not stopped automatically if you stop without depressing the brake pedal, for example, by using engine braking.

Precautions of When the Engine is Stopped Automatically

⚠ WARNING

Do not perform any of the following operations while the engine has been stopped automatically. This may result in an accident.

	Operation/Vehicle Condition	Solution
Common	<p>Engine hood opened</p> <ul style="list-style-type: none"> • The interior buzzer sounds intermittently. • After the engine is stopped automatically, it stalls. • The ENG A-STOP indicator light (green) goes off. 	<p>To restart the engine, follow the procedure below.</p> <ol style="list-style-type: none"> 1) Set the parking brake firmly, and then place the gearshift lever in the "N" position. 2) Securely close the engine hood. 3) Turn the ignition switch or press the engine switch to restart the engine.
Manual transmission	<p>Driver's seat belt unfastened and driver's door opened</p> <ul style="list-style-type: none"> • The interior buzzer sounds 5 times. • After the engine is stopped automatically, it stalls. • The ENG A-STOP indicator light (green) goes off. 	<p>Before starting the vehicle, close the door and buckle the seat belt. In addition, before getting out of the vehicle, follow the procedure below.</p> <ol style="list-style-type: none"> 1) Set the parking brake firmly, and then place the gearshift lever in the "N" position. 2) When the vehicle will be stopped for a long time or when you will leave the vehicle unattended, turn the ignition switch or press the engine switch to stop the engine.
Auto Gear Shift	<p>Driver's seat belt unfastened, or driver's door opened</p> <ul style="list-style-type: none"> • The interior buzzer sounds. • The engine does not start 2 seconds. • The ENG A-STOP indicator light (green) will go off and engine will stall. 	<p>Before driving, close the door and buckle the seat belt. In addition, before getting out of the vehicle, follow the procedure below.</p> <ol style="list-style-type: none"> 1) Set the parking brake firmly, and then place the gearshift lever in the "N" position. 2) When the vehicle will be stopped for a long time or when you will leave the vehicle unattended, turn the ignition switch or press the engine switch to stop the engine.

NOTE:

*The following indicator lights in the instrument cluster do not come on when the engine is stopped automatically.
Malfunction indicator light, electric power steering light, oil pressure light, charging light*

OPERATING YOUR VEHICLE

Operating Conditions of ENG A-STOP System

Standby conditions

If all of the following conditions are met while driving, the automatic engine stop will be permitted.

When the engine is started*

Common	<ul style="list-style-type: none">The engine is started with the engine hood securely closed.
--------	---

*: If the engine is started according to the procedures for the Jump-starting Instructions in "EMERGENCY SERVICE" section, the standby conditions are not met.

When driving

Common	<ul style="list-style-type: none">The ENG A-STOP OFF switch has not been pressed to deactivate the ENG A-STOP system.The battery is fully charged and the temperature inside the battery is within the specified range (#1).The engine has warmed up and the engine coolant temperature is within the specified range.The driver is wearing seat belts.The driver's door is completely closed.No electronically controlled system besides the ENG A-STOP system is issuing a signal to inhibit stopping of the engine (#2) <p><Automatic heating and air conditioning system></p> <ul style="list-style-type: none">The temperatures at air-conditioner outlets are sufficiently low in the cooling mode or sufficiently high in the heating mode.The defroster is turned off.
Auto Gear Shift	<ul style="list-style-type: none">The gearshift lever is in the "D" or "N" position.

#1: If the vehicle has not been in use for an extended period of time or the audio or other electrical component was used for an extended period of time while the engine was stopped, the battery may have discharged and it may take some time before the standby mode is achieved.

#2: If any of the warning and indicator lights affecting the ENG A-STOP system come on, the engine will not be stopped automatically.

Conditions to stop the engine automatically

If all of the following conditions, the ENG A-STOP indicator light (green) in the instrument cluster will illuminate when the vehicle is stopped and the engine will stop automatically.

Common	<ul style="list-style-type: none">• The ABS or ESP® system has not been activated• Brake booster vacuum pressure is normal
Manual transmission	<ul style="list-style-type: none">• The gearshift lever is in "N" position• The clutch pedal is released
Auto Gear Shift	<ul style="list-style-type: none">• The vehicle is not stopped on a steep hill• The gearshift lever is in "D" or "N" position• The brake pedal is depressed appropriately (#)

#: The engine may not be stopped automatically if the brake pedal was depressed lightly or strongly.

The engine may not stop automatically when the brake pedal is depressed lightly.

In this case, when the brake pedal is depressed additionally, the engine may stop automatically.

The driver can operate whether the engine stops automatically or not depending on how hard the brake pedal is pressed.

OPERATING YOUR VEHICLE

Conditions to restart the engine automatically


If any of the following vehicle conditions occur or operations are performed while the engine is stopped automatically, the engine is restarted automatically and the ENG A-STOP indicator light (green) goes off.

Common	<ul style="list-style-type: none">• The clutch pedal is depressed (for manual transmission vehicle).• When the brake pedal is released (for Auto Gear Shift vehicle).• The ENG A-STOP OFF switch is pressed to deactivate the ENG A-STOP system.• The battery has discharged substantially (#).• A malfunction of the system is detected (#).• The negative pressure of the brake booster has dropped (#).• The vehicle starts to move on a slope, etc. (#).• Some time (2 minutes or so) has elapsed after the start of the automatic engine stop (#). <p><Automatic heating and air conditioning system></p> <ul style="list-style-type: none">• The temperatures at air conditioner outlets have changed considerably after the automatic engine stop to the point of affecting the cooling/heating performance (#).• The temperature selector has been turned considerably to the COOL side in the cooling mode or to the HOT side in the heating mode (#).• The defroster is turned on (#)
Manual transmission	<ul style="list-style-type: none">• The clutch pedal is depressed.
Auto Gear Shift	<ul style="list-style-type: none">• The accelerator pedal depressed• The gearshift lever is put in "R" or in "M" position• After the gearshift lever is shifted to "N", it is returned to "D"• The driver releases the seat belt• The driver's door is opened

#: The ENG A-STOP indicator light (green) will blink and then go off

ENG A-STOP OFF Switch

The ENG A-STOP system can be deactivated.



55TB5020

- To deactivate the system, press the ENG A-STOP OFF switch (1) to turn on ENG A-STOP OFF light (2).
- To activate the system once again, press the switch (1) again to turn off the indicator.
- Every time the engine is stopped manually, the system is enabled again and the ENG A-STOP OFF light (2) goes off.

NOTE:

Pressing the ENG A-STOP OFF switch (1) during the automatic engine stop will restart the engine automatically and the ENG A-STOP OFF light (2) will come on.

ENG A-STOP OFF Indicator Light

- When you push the ENG A-STOP OFF switch, this light comes on.



56RM03012

- The ENG A-STOP OFF indicator light (orange) in the speedometer comes on or blinks in the following cases as well, and not only to warn you that the ENG A-STOP system is deactivated. If it blinks, have the vehicle serviced by an authorized SUZUKI dealer or a qualified workshop.
 - If the system is operating normally when the engine switch is pressed to change the ignition mode to ON, the indicator light comes on for approximately 2 seconds, then goes off.
 - If there is something wrong with the system, or if it is time to replace the engine component (starter motor) or the lead-acid battery, the indicator light will blink when the engine switch is pressed to change the ignition mode to ON. (The ENG A-STOP system will not work properly.)

NOTE:


If the indicator light blinks when the engine has stopped automatically by the ENG ASTOP system, the engine may restart or stall.

OPERATING YOUR VEHICLE


Information Message (if equipped)

The information display shows the messages to let you know certain problems of the ENG A-STOP system.

Information message	Sound	Cause and remedy
 52RM30650	Off	<p>The ENG A-STOP system cannot stop the engine automatically because one of the following conditions is met.</p> <ul style="list-style-type: none">• The engine is started with the hood open.• The temperature of the vehicle battery is either low or high.• The vehicle battery performance is low.• The blower speed selector is set to the ON mode and the inside of the vehicle has not sufficiently cooled and warmed (for the vehicle with automatic air conditioning).• The defrost switch is set to the ON mode (for the vehicle with automatic air conditioning).• During or after the ABS or ESP® system is activated, and the vehicle is stopped.• The brake booster vacuum pressure is low.• The accelerator pedal is depressed.• The clutch pedal depressed or the gearshift lever is in a position other than "N" (Neutral) (for manual transmission vehicle).• The driver's door is opened.• The driver's seat belt is unfastened.• The engine hood is opened.• The engine has warmed up and the engine coolant temperature is out of range of the specified limit.• The ENG A-STOP system is issuing a signal to inhibit stopping of the engine.• The gearshift lever is in a position other than "D" or "N" (for Auto Gear Shift vehicle).

Information message	Sound	Cause and remedy
 ENGINE RESTARTING	Off	<p>The engine is restarting automatically because one of the following automatic engine restart conditions is met.</p> <ul style="list-style-type: none"> • The temperatures at air conditioner outlets have changed considerably after the automatic engine stop to the point of affecting the cooling/heating performance. • The lead-acid battery has discharged substantially. • Some time has elapsed after the start of the automatic engine stop.
 RESTARTED	Beep (10 times from interior buzzer)	<p>The engine restarted automatically.</p> <ul style="list-style-type: none"> • The door is opened or seat belt is unfastened on the driver's side.(for auto gearshift vehicle). • The negative pressure of the brake booster has dropped.
 RESTART ENGINE	Beep (2 times from interior buzzer)	<p>For vehicle without keyless push start system, while the engine is stopped automatically, if the hood is opened and the engine does not restart automatically, and then the engine stalls, this message appears in the display when the hood is closed to prompt the engine start.</p>
	Beep (5 times from interior buzzer)	<p>For manual transmission vehicle without keyless push start system, while the engine is stopped automatically, if the driver's door is opened and the driver's seat belt is unfastened, and then engine stalls, this message appears in the display when the driver's door is closed and the driver's seat belt is fastened to prompt the engine start.</p>

OPERATING YOUR VEHICLE

Information message	Sound	Cause and remedy
 52RM30670	Off	<p>The engine restarted automatically because the following automatic engine restart condition is met.</p> <ul style="list-style-type: none">• When the vehicle coasts down a slope.• The defroster is turned on.

ENG A-STOP System (Engine Auto Stop Start System) (for K10C engine) (if equipped)

The ENG A-STOP system (engine auto stop start system) automatically stops the engine while waiting briefly at a traffic light, etc., and automatically restarts the engine afterward. This system helps reduce emissions, improve fuel consumption and lower engine noise.

This system stops the engine temporarily under specific conditions. Before parking the vehicle for an extended period of time or leaving the vehicle, properly apply the parking brake and stop the engine with the engine switch.

Once the specific conditions are met, the engine will stop automatically after the vehicle has stopped. However, the engine will not be stopped automatically until confirmation of the system function is finished.


NOTE:

If your vehicle is equipped with the auto air conditioning system, you can change the automatic engine stop condition via the information display. Refer to "Information display" in "BEFORE DRIVING" section.

 CAUTION	NOTICE
<ul style="list-style-type: none"> • Do not get out of the vehicle while the engine is automatically stopped by the ENG A-STOP system. Doing so may lead to an accident. <ul style="list-style-type: none"> – Manual transmission vehicle – If the driver's seat belt is unfastened or the driver's door is opened, the engine will restart. – Automatic transmission vehicle – If the driver's seat belt is unfastened, even if the brake pedal is pressed down, or the driver's door is opened, the engine will be restarted to warn you that the engine was stopped automatically by the ENG A-STOP system. • If the engine does not restart automatically after having been stopped automatically by the ENG A-STOP system, push the engine switch to start the engine. Trying to move the vehicle when the engine has not yet restarted requires a strong force to turn the steering wheel or depress the brake pedal, potentially leading to an accident. 	<p>The vehicle equipped with this system uses a dedicated high-performance lead-acid battery that supports ENG A-STOP system. Accordingly, observe the instructions listed below. If these instructions are not observed, the system may not actuate properly or the lead-acid battery may die prematurely.</p> <ul style="list-style-type: none"> • When replacing the lead-acid battery, use a Maruti Suzuki GENUINE battery specified in the Specification. • Do not draw power from the lead-acid battery terminals for electrical products.

OPERATING YOUR VEHICLE

Lithium-ion Battery



68PM00368

- (1) Battery (lead-acid battery)
- (2) Lithium-ion battery

This lithium-ion battery is used exclusively for the vehicle equipped with SHVS, and located below the front left side seat.

- Just like a battery (lead-acid battery), the lithium-ion battery also discharges gradually.

To prevent the lithium-ion battery from dying, you must charge the lithium-ion battery by driving continuously for at least 30 minutes once a month.

- The lithium-ion battery is maintenance-free.
- To replace or dispose of the lithium-ion battery, consult a Maruti Suzuki authorized workshop.

⚠ WARNING


Wrong handling of the lithium-ion battery may result in fire, electric shock or system malfunction. Accordingly, observe the instructions listed below:

- Do not dismount or disassemble the lithium-ion battery.
- Do not let the lithium-ion battery come in contact with water or other liquids.
- Do not apply strong impact on the lithium-ion battery.
- Do not step on the lithium-ion battery or put articles on the lithium-ion battery.
- Do not disconnect the lithium-ion battery terminals or draw power from the terminals for electrical products.

Automatic Stopping/Restarting of the Engine

Manual transmission vehicles

- 1) With the brake pedal depressed, decelerate the vehicle.



55TB5016

- 2) After the vehicle has stopped with the clutch pedal depressed and the gear-shift lever shifted to "N", and then release the clutch pedal, the engine will stop automatically.

The ENG A-STOP indicator light (green) (1) will come on.

- The ENG A-STOP system will not stop the engine automatically if all the automatic engine stop conditions are not met.

For details, refer to the section, "Operating Conditions of ENG A-STOP System".

- During the automatic engine stop, the engine may shut down, accompanied by an interior buzzer or restarted, to ensure safety.

For details, refer to the section, "Precautions of When the Engine is Stopped Automatically".


NOTICE

During the automatic engine stop, do not shift the gearshift lever to a position other than "N" without depressing the clutch pedal. If the gearshift lever is in a position other than "N", the engine will not restart automatically even if the clutch pedal is depressed.

NOTE:

During the automatic engine stop, electric equipment will be in the following conditions:

- The audio and other electrical component can be used during the automatic engine stop, but the air conditioner will switch to the fan mode.*
- If the vehicle is equipped with an auto air conditioner, the fan speed will be limited during the automatic engine stop (only in the auto control mode) to keep the cabin air-conditioned for a longer time.*



55TB5017

- 3) Regardless of whether the vehicle has stopped or not, depressing the clutch pedal will restart the engine and ENG A-STOP indicator light (green) (1) will go off.

While the engine is stopped automatically, depressing the clutch pedal will restart the engine consuming fuel. Therefore, for fuel economy, it is recommended to depress the clutch pedal just before the vehicle start.

- Without depressing the clutch pedal, the engine may restart automatically if the automatic engine restart conditions are met.

For details, refer to the section, "Automatic engine restart conditions".

For details, refer to the section "Hill Hold Control System".

NOTE:


When the engine is restarted automatically, the following conditions may be found as the hill hold control system is activated, but this is not a malfunction.

- You may hear a sound from the engine room.*
- As brake pedal becomes heavy, it may be difficult for you to depress it.*

OPERATING YOUR VEHICLE

Automatic transmission vehicles

- 1) Depress the brake pedal to decelerate while the gearshift lever is in the "D" position will automatically stop the engine before the vehicle is stopped (approximately 9 km/h or less). At the same time, the ENG A-STOP indicator light (green) will remain on.
 - The engine is not stopped automatically if all of the conditions to stop the engine automatically are not met, even if the brake pedal is pressed down to decelerate.For details on the conditions for automatically stopping the engine, refer to "Conditions to Stop the Engine Automatically" in this section.
- To ensure safety when the engine is stopped automatically, the interior buzzer may sound and the engine will stall, or the engine may be restarted.




NOTE:

- *The engine is not stopped automatically when decelerating without depressing the brake pedal, for example, by using engine braking.*
- *The engine may be stopped automatically when the vehicle is stopped, even if the engine is not stopped automatically before stopping the vehicle (approximately 9 km/h or less).*
- *Electrical components, such as the navigation system or audio system, can be used while the engine has been stopped automatically, however, the air conditioner switches to the ventilation position.*

For the automatic heating and air conditioning system, airflow is limited (only under automatic operation) when the engine is stopped automatically, in order to improve the cooling and heating performance.

- 2) When you remove your foot from the brake pedal, regardless of whether it is before or after stopping the vehicle, the engine is restarted and the ENG A-STOP indicator light (green) goes off.
 - The engine is restarted automatically if the conditions to restart the engine automatically are met, even if the brake pedal is depressed.For details on the conditions for automatically restarting the engine, refer to "Conditions to Restart the Engine Automatically" in this section.



NOTE:

The hill hold control system is activated when the engine is restarted automatically.

Precautions of When the Engine is Stopped Automatically

⚠ WARNING

Do not perform any of the following operations while the engine has been stopped automatically. This may result in an accident.

	Operation/Vehicle Condition	Solution
Common	<p>Engine hood opened</p> <ul style="list-style-type: none"> • The interior buzzer sounds 2 times. • After the engine is stopped automatically, it stalls. • The ENG A-STOP indicator light (green) goes off. 	<p>To restart the engine, follow the procedure below.</p> <ol style="list-style-type: none"> 1) Set the parking brake firmly, and then place the gearshift lever in the "N" position (for manual transmission) or "P" position (for automatic transmission). 2) Securely close the engine hood. 3) Turn the ignition switch or press the engine switch to restart the engine.
Manual transmission	<p>Driver's seat belt unfastened or driver's door opened</p> <ul style="list-style-type: none"> • The ENG A-STOP indicator light (green) blink 5 times, then goes off. 	<p>Before starting the vehicle, close the door and buckle the seat belt. In addition, before getting out of the vehicle, follow the procedure below.</p> <ol style="list-style-type: none"> 1) Set the parking brake firmly, and then place the gearshift lever in the "N" position. 2) When the vehicle will be stopped for a long time or when you will leave the vehicle unattended, turn the ignition switch or the press the engine switch to stop the engine.
	<p>Gearshift lever shifted to a position other than "N" without depressing the clutch pedal</p> <ul style="list-style-type: none"> • The interior buzzer sounds 2 times. • After the engine is stopped automatically, it stalls. • The ENG A-STOP indicator light (green) goes on. 	The gearshift lever is placed returned to the "N" position.

OPERATING YOUR VEHICLE

	Operation/Vehicle Condition	Solution
Automatic transmission	Driver's seat belt unfastened, or driver's door opened <ul style="list-style-type: none">• The engine is restarted automatically.• The ENG A-STOP indicator light (green) blinks 5 times, then goes off.	Before driving, close the door and buckle the seat belt. In addition, before getting out of the vehicle, follow the procedure below. <ol style="list-style-type: none">1) Set the parking brake firmly, and then place the gearshift lever in the "P" position.2) When the vehicle will be stopped for a long time or when you will leave the vehicle unattended, press the engine switch to stop the engine.

NOTE:

The following indicator lights in the instrument cluster do not come on when the engine is stopped automatically.

- *Malfunction indicator light, electric power steering light, oil pressure light, charging light*

Operating Conditions of ENG A-STOP System

Standby conditions

If all of the following conditions are met while driving, the automatic engine stop will be permitted.

When the engine is started	<ul style="list-style-type: none"> The engine is started with the engine hood securely closed.
When driving	<p>Common</p> <ul style="list-style-type: none"> The ENG A-STOP system is not deactivated (OFF) (For details, refer to "ENG A-STOP OFF Switch" in this section.) The battery is charged more than a certain amount, and the temperature inside the battery is within the specified range. (#1) The engine coolant temperature is within the specified range. The driver's seat belt is fastened. The driver's door is securely closed. The engine hood is securely closed. There is no signal to prevent stopping the engine from any electronic control systems other than the ENG A-STOP system (#2) The transfer lever is in "2H" position <p>< Automatic heating and air conditioning system></p> <ul style="list-style-type: none"> The air from the outlets is sufficiently cooled while cooling or sufficiently warmed while heating. The defroster is turned off.
Automatic transmission	<ul style="list-style-type: none"> The gearshift lever is in the "D" or "N" position. (#3) The manual mode is not in use. There is no signal to prevent stopping the engine from any electronic control systems other than the ENG A-STOP system.

#1: If the battery is discharged, for example, if the vehicle has not been used for a long time or electrical components, such as the navigation system or audio system, have been used for a long time while the engine was stopped, it may take some time until the system can be in standby.

#2: If any of the warning and indicator lights affecting the ENG A-STOP system come on, the engine will not be stopped automatically.

#3: The system will be in standby even though the gearshift lever is in "N" position, however, the engine will be stopped automatically when the vehicle is stopped, instead of when it is decelerating (approximately 9km/h or less) before stopping.

OPERATING YOUR VEHICLE

Conditions to stop the engine automatically

If all of the following conditions are met while the standby conditions are met, the engine is stopped automatically when the vehicle is decelerating before stopping or when the vehicle is stopped.

When decelerating before stopping	Auto-matic transmission	<ul style="list-style-type: none">The ABS or ESP® system has not been activated.Brake booster vacuum pressure is normal.The brake pedal is sufficiently depressed. (#)The vehicle is decelerating to a speed of approximately 9 km/h or less.The accelerator pedal is not depressed.The vehicle is not being driven on a steep hill.The brake is not applied abruptly.
When the vehicle is stopped	Common	<ul style="list-style-type: none">The ABS or ESP® system has not been activated.Brake booster vacuum pressure is normal.
	Manual transmission	<ul style="list-style-type: none">The gearshift lever is in "N" position.The clutch pedal is released.
	Auto-matic transmission	<ul style="list-style-type: none">The brake pedal is sufficiently depressed. (#)The accelerator pedal is not depressed.The vehicle is not stopped on a steep hill.

#: The engine may not be stopped automatically if the brake pedal was depressed lightly or strongly.

Conditions to restart the engine automatically

If any of the following vehicle conditions occur or operations are performed while the engine is stopped automatically, the engine is restarted automatically and the ENG A-STOP indicator light (green) goes off.

Common		<ul style="list-style-type: none"> • The ENG A-STOP system is deactivated (OFF). • The battery continues to be discharged. (#1) • A malfunction was detected in this system. (#2) • Brake booster vacuum pressure is low. (#1) • The temperature of the air from the outlets changes greatly, or the cooling and heating performance is insufficient. (#1) • The temperature selector was greatly set toward COOL while cooling or greatly set toward HOT while heating. (#1) • The defroster is turned on. (#1)
Manual transmission		<ul style="list-style-type: none"> • The clutch pedal is depressed.
Automatic transmission		<ul style="list-style-type: none"> • The foot is removed from the brake pedal. (#3) • The accelerator pedal is depressed. • The gearshift lever is placed in the "P", "R" or "M" position.
When decelerating	Automatic transmission	<ul style="list-style-type: none"> • The engine hood was opened. • The gearshift lever is placed in the "N" position. • The slope of the road suddenly changes. (#1)
When the vehicle is stopped	Common	<ul style="list-style-type: none"> • The driver's seat belt is unfastened. (#1) • The driver's door is opened. (#1) • The vehicle is moving along a slope. (#1) • Some time (about 2 minutes) has passed since the engine was stopped automatically. (#1)
	Automatic transmission	<ul style="list-style-type: none"> • After the gearshift lever is placed in the "N" position, it is returned to the "D" position.


#1: After the ENG A-STOP indicator light (green) blinks, it goes off. Also, the interior buzzer may sound at the same time.

#2: Depending on the situations of malfunction, it is a normal restart or the restart as #1.

#3: The engine may be restarted automatically when the brake pedal is depressed lightly. In this case, when the brake pedal is depressed again, the engine is stopped automatically and the ENG A-STOP indicator light (green) comes on again.

OPERATING YOUR VEHICLE

ENG A-STOP OFF Switch (If Equipped)



55TB5020

The ENG A-STOP system can be deactivated.

- To deactivate the system, press the ENG A-STOP OFF switch (1) to turn on ENG A-STOP OFF light (2).
- To activate the system once again, press the switch (1) again to turn off the indicator.
- Every time the engine is stopped manually, the system is enabled again and the ENG A-STOP OFF light (2) goes off.

NOTE:

Pressing the ENG A-STOP OFF switch (1) during the automatic engine stop will restart the engine automatically and the ENG A-STOP OFF light (2) will come on.

ENG A-STOP OFF Light (If Equipped)



56RM03012

This indicator comes on in the information display.

- This indicator comes on when the ENG A-STOP system is deactivated.
- The indicator blinks when the engine switch is pressed to change the ignition mode to ON, if one of the conditions listed below is met.

The ENG A-STOP system or the SHVS system does not actuate correctly while the indicator is blinking. Have the system inspected by a Maruti Suzuki authorized workshop.



- There may be something wrong with the ENG A-STOP system or the SHVS system.
- An engine component (ISG) or the lead-acid battery is due for replacement.

NOTE:



If the indicator blinks during the automatic engine stop, the engine may shut down

Information Message

The information display shows the messages to let you know certain problems of the ENG A-STOP system.

Information message	Cause and remedy
 IDLING STOP UNAVAILABLE	<p>The ENG A-STOP system cannot stop the engine automatically because something of the actuation conditions is not met. For details, refer to "Operating Conditions of ENG A-STOP System" in this section.</p>
 ENGINE RESTARTING	<p>The engine is restarting automatically because one of the following automatic engine restart conditions is met.</p> <ul style="list-style-type: none"> • The temperatures at air conditioner outlets have changed considerably after the automatic engine stop to the point of affecting the cooling/heating performance. • The lead-acid battery has discharged substantially. • Some time has elapsed after the start of the automatic engine stop.
 RESTARTED	<p>The engine restarted automatically because one of the following automatic engine restart conditions is met.</p> <ul style="list-style-type: none"> • The negative pressure of the brake booster has dropped.

OPERATING YOUR VEHICLE

Information message	Cause and remedy
 76TM050012	<p>The engine restarted automatically because one of the following automatic engine restart conditions is met.</p> <ul style="list-style-type: none"> • The defroster is turned on. • The driver's seat belt is released. • The driver's door is opened. • The vehicle is started to move on a slope, etc.
 76TM050016	<p>The engine shut down because one of the following operations is performed during the automatic engine stop.</p> <ul style="list-style-type: none"> • The hood is opened. • For Manual transmission vehicle, the driver's door is opened with the driver's seat belt is unfastened. <p>Restart the engine by usual operation. Refer to "Starting / Stopping Engine or Hybrid System" in this section for details.</p>
Manual transmission  76TM050017	<p>The gearshift lever is shifted to a position other than "N" (Neutral) position without depressing the clutch pedal during the automatic engine stop. To restart the engine, place the gearshift lever in "N" (Neutral) position and depress the clutch pedal.</p>

Cruise Control (if equipped)

The cruise control system allows you to maintain a steady speed without keeping your foot on the accelerator pedal. The controls for operating the cruise control system are on the steering wheel.


You can use the cruise control system under the following conditions:

- For manual transmission vehicle, the gear position is in 3rd, 4th or 5th.
- For Auto Gear Shift vehicle / Automatic Transmission vehicle, the gearshift lever is in "D" position or the gear position is in 3rd, 4th or 5th, in the manual mode.
- The vehicle speed is about 40 km/h or higher.

WARNING

To help avoid loss of vehicle control, do not use the cruise control system when driving in heavy traffic, on slippery or winding roads, or on steep downhills.


Setting Cruising Speed Cruise control switch



56RM03017

- (1) Cruise switch
- (2) "CANCEL" switch
- (3) "RES +/SET -" switch


Instrument cluster Type A



52RS30170

- (4) Cruise indicator light
- (5) "SET" indicator light

Instrument cluster Type B



55T050080

- (6) Cruise indicator
- (7) "SET" indicator
- (8) Set speed indication

OPERATING YOUR VEHICLE

- 1) Turn on the cruise control system by pushing cruise switch (1). When the cruise indicator light (4) (for instrument cluster type A), cruise indicator (6) (for instrument cluster type B) comes on, you can set cruising speed.
- 2) Accelerate or decelerate to the desired speed.
- 3) Push down the "RES +/SET -" switch (3), "SET" indicator light (5) (for instrument cluster type A), "SET" indicator (7) (for instrument cluster type B) comes on. Also, set speed indication (8) (for instrument cluster type B) comes on at the same time. Take your foot off the accelerator pedal and the set speed will be maintained.

⚠ WARNING

If the cruising speed is set by accident, you cannot decelerate or could lose control of the vehicle. This could lead to an accident, resulting in severe injury or death.

Turn off the cruise control system and check that cruise indicator light (4), cruise indicator (6) or (8) is off when the system is not in use.

NOTE:

Established cruising speed may differ a little from the speed meter indication depending on the road conditions.

Changing Speed Temporarily

When the cruising speed is maintained, you can temporarily accelerate or decelerate.

To accelerate, depress the accelerator pedal. When you take your foot off the pedal, your vehicle will return to the set speed.

To decelerate, depress the brake pedal. The set speed will be canceled and "SET" indicator light (5), "SET" indicator (7) will go off.

To resume the previously set speed, push up the "RES +/SET -" switch (3) and turn on "SET" indicator light (5), "SET" indicator (7) again when vehicle speed is above 40 km/h. The vehicle will accelerate to the previously set speed and maintain its speed.

NOTE:

For Automatic Transmission vehicle / Auto Gear Shift vehicle, when the cruising speed is maintained, you cannot decelerate by using the engine brake even if you downshift from higher gear to 3rd in the manual mode.

To decelerate while the cruise control is on, depress the brake pedal or push down the "RES +/SET -" switch (3).

Changing Cruising Speed

Using the accelerator pedal

To reset at a faster cruising speed, accelerate to the desired speed using the accelerator pedal and push down the "RES +/SET -" switch (3). The new speed will be maintained.

Using the brake pedal

To reset at a slower cruising speed, decelerate to the desired speed using the brake pedal and push down the "RES +/SET -" switch (3). The new speed will be maintained.

NOTE:

When the brake pedal is depressed, "SET" indicator light (5), "SET" indicator (7) will go off until you reset the cruising speed.

Using "RES +/SET -" switch

To reset at a faster cruising speed, press repeatedly or hold push up the "RES +/SET -" switch (3). Vehicle speed will steadily increase. When you release the switch, the new speed will be maintained.

To reset at a slower cruising speed, press repeatedly or hold push down the "RES +/SET -" switch (3) until the vehicle has slowed to the desired speed, and then release the switch. The new speed will be maintained.

NOTE:

- You can adjust the set speed by approximately 1 km/h by pushing “RES +/SET –” switch quickly.
- When the current vehicle speed is about 10 km/h or more faster than the previously set speed, the cruising speed cannot be decreased even if the “RES +/SET –” switch (3) is pushed down.
- When the current vehicle speed is about 10 km/h or more slower than the previously set speed, the cruising speed cannot be increased even if the “RES +/SET –” switch (3) is pushed up.

Cancelling Cruise Control

“SET” indicator light (5), “SET” indicator (7) will go off and the cruise control will be canceled temporarily with the following conditions:

- Push “CANCEL” switch (2).
- Depress the brake pedal.
- For manual transmission, depress the clutch pedal.
- For Auto Gear Shift model, down-shift from 3rd to 2nd gear in the manual mode.
- The vehicle speed falls more than about 20 percent from the set speed.
- Any time the vehicle speed falls below 40 km/h.
- When the vehicle skids and ESP® is activated.

To resume the previously set speed, push up the “RES +/SET –” switch (3) and turn on “SET” indicator light (5), “SET” indicator (7). The vehicle speed must be above 40 km/h when the vehicle is not under the above conditions.

To turn off the cruise control system, push cruise switch (1) and check that the cruise indicator light (4), cruise indicator (6) is off.


Also, if the malfunction indicator light in the instrument cluster comes on or blinks, the cruise control system will be turned off.

NOTE:

If you turn off the cruise control system, the previously set speed in the memory is cleared. Reset your cruising speed again.

**SUZUKI SAFETY SUPPORT
(if equipped)****Head-up Display**

Head-up display (HUD) will show the information such us the current vehicle speed and the gear position in the driver's front vision.



55T050290

- (1) Display
- (2) Cover
- (3) Light-received surface
- (4) Mirror
- (5) Down switch
- (6) Up switch
- (7) Brightness control switch
- (8) HUD (Head-up display) switch

OPERATING YOUR VEHICLE

⚠ WARNING

- Do not continue to look at the head-up display while driving. Otherwise, you may not find the vehicle, pedestrians or obstacles in front of you. This could result in an accident.
- Adjust the display brightness and position to your preference not to obstruct a safe driving. If adjustment is not performed properly, it could result in an accident.
- Operate the head-up display while the vehicle is stopped. If you attempt to operate the display while driving, you may not look ahead carefully. This could result in an accident.

⚠ CAUTION

When the head-up display is moving, do not put your hands closer to it. Your hands may get caught in it and get injured.

NOTICE

- Performing the following points may prevent the proper operations of the head-up display and result in its malfunction. Observe these points.
 - Do not adjust the display angle by your hands. Do not open or close the cover by your hands.
 - Do not place any object or drink on the cover, its peripheral part and the light-received surface.
 - Do not place stickers, etc. to the display, the inside of the cover and the light-received surface.
 - Do not shine a strong light on the light-received surface.
- If you drop any object inside the cover, carefully pick it up not to injure the part such as the mirror.
- Ask a Maruti Suzuki authorized workshop, if you drop any object inside the place where the head-up display is stored and you cannot pick up the object or the head-up display is stuck inside.
- Do not wipe the HUD cover forcefully. When you wipe it off, use a soft cloth.

NOTE:


- If you wear your sunglasses, you may have trouble seeing the displayed information. In this case, adjust the brightness or take your sunglasses off.
- You may have trouble seeing the displayed information in the following cases.
 - On a rainy day or a day with strong sunlight
 - When driving on snowy roads or when a wet road is shining after the rain
 - When the headlights from your vehicle is reflected to the vehicle in front of you at night
 - When the position of the vehicle in front of you and the displayed information get overlapped
 - Depending on the driving posture
- Under the very cold condition, the vehicle speed on the speedometer and the one on the head-up display may differ a little.
- When the head-up display gets hot, such as after parking the vehicle under the blazing sun, the displayed information may temporarily become dark for its protection. When the head-up display gets hotter, the displayed information will temporarily disappear and the message will be shown on the information display of the instrument cluster.
 - When the temperature becomes low, the above condition will be canceled. However, if the above condition is

kept, ask a Maruti Suzuki authorized workshop.

- You can turn off the message on the information display in high temperature by changing the setting (customization). For details, refer to "Setting Mode" in "INSTRUMENT CLUSTER" section.

Activation of the head-up display

When you press the engine switch to ON mode and the engine starts, the head-up display will automatically appear and the following information will be displayed as necessary.



- (1) Vehicle speed
- (2) Standard display
- (3) Gear position indicator (for Auto Gear Shift vehicles) (if equipped)
- (4) Clock
- (5) Cruise indicator (if equipped)

(6) "SET" indicator (if equipped)

When you press the engine switch to ACC or LOCK (OFF) mode, the head-up display will be automatically stored.


NOTE:

- Even if you stop the engine, the display setting will be stored.
- The vehicle speed on the head-up display and the one on the speedometer may differ a little.
- You can turn off a part of the information by changing the setting (customization).

Operation of the head-up display

Operate the head-up display while the vehicle is stopped. You cannot adjust the brightness and the displayed position while driving.

Head-up display operation switch



(1) Down switch

(2) Up switch

(3) Brightness control switch

(4) HUD (Head-up display) switch


ON / OFF operation of the head-up display

If you press and hold the HUD (Head-up display) switch (4) with the engine on, you can make the head-up display appear or store.

NOTE:

If you store the head-up display inside by operating the HUD (Head-up display) switch and stop the engine, the head-up display will not appear automatically on the next engine start.

ON / OFF operation of the intersection guidance display (When using Android Auto™*1 or Apple CarPlay*2 on infotainment system)



- (5) The intersection guidance display
(The above image is an example of Apple CarPlay.)

OPERATING YOUR VEHICLE

NOTE:

- For ON / OFF operation of the intersection guidance display, you need to change the setting on the information display. For details, refer to "Setting Mode" in "INSTRUMENT CLUSTER" section.
- The intersection guidance display on the head-up display and the one on the navigation system may differ a little.

*¹: Android Auto™ may not be available in your country or region.

For details about Android Auto™, refer to <http://support.google.com/androidauto>


*²: Apple CarPlay may not be available in your country or region.

For details about Apple CarPlay, refer to <https://www.apple.com/ios/carplay/>


Brightness control

Brightness of the display will be automatically adjusted depending on the surrounding conditions. You can adjust the brightness to your preference by the following steps.

- 1) Press the brightness control switch (3).
- 2) To make the display brighter, press "▲" of the up switch (2). To make the display darker, press "▼" of the down switch (1).



55T050770



55T050780

NOTE:

- You can adjust brightness of the display from -10 to +10 (21 levels) by the brightness control switch.
- Depending on brightness which was automatically adjusted, you may not be able to make the display brighter or darker.
- Regardless of the driver's seat conditions, brightness may be automatically changed in the following conditions.
 - When driving in a tunnel or around its gateway
 - When driving on a road where there is a structural object over your head

Adjustment of the displayed position

Press the down switch (1) or up switch (2) to adjust the displayed position of the head-up display.


NOTE:

• You can adjust the displayed position of the head-up display from -12 to +12 (25 levels) by the up/down switch.

Displayed information of the head-up display

Activation / ending of the head-up display

When turn the ignition switch to "ON" position or you press the engine switch to ON mode, the head-up display will automatically activate and the following images will be displayed by turns.




55T050790

Standard display of the head-up display

Every time you press the HUD (Head-up display) switch, the displayed information will be changed as follows.

- The following images are typical examples; they depends on the vehicle type.



(1) Vehicle speed

(2) Instantaneous fuel consumption


(3) Tachometer

NOTE:


- Even if you stop the engine, the display setting will be stored.
- The vehicle speed on the head-up display and the one on the speedometer may differ a little.

When operating the air conditioner


If you operate the air conditioner with instantaneous fuel consumption, tachometer displayed, the following images will be displayed.



When you press "AUTO" switch, "AUTO" and the set temperature will be displayed for a certain time.



When you operate the temperature selector, the set temperature will be displayed for a certain time.



When you operate the blower speed selector, the blower speed will be displayed for a certain time.

NOTE:

- When the vehicle speed is displayed in standard display of the head-up display, the air conditioner setting will not be displayed.
- You can hide the information of air conditioner by the setting mode on the information display. For details, refer to "Setting Mode" in "INSTRUMENT CLUSTER" section.

OPERATING YOUR VEHICLE

Interrupt display

When there is the information to tell you and you press the engine switch to ON mode, the following interrupt display will appear. Depending on the type of the display, a buzzer may sound at the same time.

- The following images are typical examples; they depends on the vehicle type.

Display	Buzzer	Description
 55T050810	Chime (Once) (Only when one of the doors is not completely closed)	When one of doors, the bonnet or the fuel lid is not completely closed, the interrupt display will appear. For the vehicles with the power sliding door, if you are driving your vehicle, stop the vehicle in a safe place and close the door completely.
 55T050820	3 beeps repeating at short intervals	When the parking brake is not released while driving, the interrupt display will appear. Stop the vehicle in a safe place and release the parking brake.
 55T050830	Chime (Once)	When the fuel level is low, the interrupt display will appear. Refill the fuel tank as soon as possible.

Display	Buzzer	Description
 FASTEN SEATBELT 55T050840	Beeping at short intervals	The driver does not wear his/her seat belt. Stop the vehicle in a safe place and wear your seat belt. The front passenger does not wear his/her seat belt. Wear the seat belt.
 ICE POSSIBLE DRIVE WITH CARE 55T050850	-	When outside temperature nears freezing, this interrupt display will appear.
 55T051030	Off	The intersection guidance is displayed. (When using Android Auto™ or Apple CarPlay on infotainment system) For details, refer to "ON / OFF operation of the intersection guidance display" in this section.

NOTE:

To turn off the intersection guidance display (When using Android Auto or Apple CarPlay on infotainment system), you can change the setting on the information display. For details, refer to "Setting Mode" in "INSTRUMENT CLUSTER" section.


OPERATING YOUR VEHICLE

360 View Camera (if equipped)

The 360 view camera is the function which shows visual image for the surrounding of your vehicle on the infotainment system screen, using the front camera, the side camera (left and right) and the back camera. This helps the driver improve visibility when the driver tries to park your vehicle, go by an oncoming vehicle in a narrow road or start the vehicle with poor visibility for left and right sides of the vehicle.

- Use the infotainment system which corresponds with the 360 view camera.

Camera positions



55TB5022

- (1) Back camera
- (2) Front camera
- (3) Side camera (under left and right outside rearview mirrors)

- Each camera in the above figure is a typical example; the actual equipment depends on the vehicle type.

⚠ WARNING

- The 360 view camera cannot reduce the driver's duty of care for driving operation. Use the 360 view camera only to provide driving assistance.
- The 360 view camera has limits and it may not show a person or an obstacle. Drive your vehicle slowly confirming the safety of the backward and the surrounding conditions by directly checking with your eyes and mirrors. If you drive your vehicle only by checking the 360 view camera, an accident may occur.
- The cameras are precision instruments. Do not apply excessive force to the cameras, disassemble them and modify them. Also, do not pour hot water to the cameras and poke them with a stick to remove mud or frozen snow on the cameras. Doing so may damage the cameras and cause a fire and malfunction.
- Do not use the 360 view camera, when the outside rearview mirrors are folded and any of front doors and the tailgate is not closed. The image of the surrounding area may not be displayed properly and an accident may occur.

NOTICE

If you use the 360 view camera for a long period of time with the engine stopped, the lead-acid battery could run out. Do not use the 360 view camera for a long period of time with the engine stopped.

NOTE:

- *Rough indication lines of vehicle width will be displayed more widely, compared with an actual vehicle width. Drive your vehicle by directly checking the safety of the surrounding conditions.*


OPERATING YOUR VEHICLE

How to use the 360 view camera

3D view mode function

The 360 view camera will display the image of the surroundings with a view from the outside or the inside of the vehicle.

- 1) Press the engine switch to change the ignition mode to ON.
- 2) After the opening image was displayed, 3D view mode will be automatically displayed on the screen.



The 360 view camera will display the image of the surroundings with a view from the outside of the vehicle.

The 360 view camera will display the image of the surroundings with a view from the inside of the vehicle.

- 3) For switching the current image to the image with a different view, touch the image switching button (1) on the screen. For temporarily stopping the rotation of 3D view mode, touch the temporary stop or replay button (2). For restarting the rotation of 3D view mode, touch the button (2) again.

74TB05012


NOTE:

- For manual transmission vehicle, if you press the camera switch (3) when the gearshift lever is in other than “R”, parking brake is applied, and the vehicle is stopped, you can display 3D view mode.
- For Auto Gear Shift vehicle, if you press the camera switch (3) when the gearshift lever is in “N” position, the parking brake is applied and the vehicle is stopped, you can display 3D view mode.
- You can change the display screen of 3D view mode by changing the setting.
- When you press the camera switch while the opening image is displayed, 3D view mode will end. If you display 3D view mode, follow the procedure below.
3D view mode → Press the camera switch → Change the mode of display → Press the camera switch → End of 3D view mode
- When the engine switch is in ACC mode, 3D view mode will not be displayed on the screen.


OPERATING YOUR VEHICLE

Displaying the forward of the vehicle

- 1) Press the engine switch to change the ignition mode to ON.
- 2) Manual transmission vehicle:
Shift the gearshift lever into a position other than "R" while the parking brake is released or the vehicle is in motion.
Auto Gear Shift vehicle:
There are following cases.
 - Shift the gearshift lever into a position other than "R" or "N".
 - Shift the gearshift lever into "N" when the parking brake is released or the vehicle is in motion.
- 3) Press the camera switch (1). "Top image and forward image" (default setting) will be displayed.



- 4) Every time you touch the image switching button (2), the image will be changed as follows:



55TB050360

(a) Top image and forward image (Default setting)

The 360 view camera will display the surrounding image and the forward image.

(b) Forward wide image

The 360 view camera will display the forward image widely.

(c) Side image and forward image

The 360 view camera will display the image under the front passenger's seat and the forward image.


- When you press the camera switch, the current image will be changed to the previous image.
- Even when you do not press the camera switch, the current image will be changed to the previous image by the following methods:
 - When 3 minutes passed after you press the camera switch
 - When you operate the infotainment system
 - When the vehicle speed becomes over about 10 km/h
- When the vehicle speed becomes over about 10 km/h and you press the camera switch, you can display the side image on the screen. When the vehicle speed becomes about 10 km/h or less, the forward image will be displayed on the screen.

NOTE:

- *For manual transmission vehicle, you can adjust the image quality and set up the initial display image when the gearshift lever is in other than “R”, parking brake is applied and the vehicle is stopped.*
- *For Auto Gear Shift vehicle, you can adjust the image quality and set up the initial display image when the gearshift lever is in “N” position, the parking brake is applied and the vehicle is stopped.*
- *When the engine switch is in ACC mode, the camera image will not be displayed.*

Displaying the backward of the vehicle

- 1) Press the engine switch to change the ignition mode to ON.
- 2) Shift the gearshift lever into "R" (Reverse). "Top image and backward image" (default setting) will be automatically displayed.
- 3) Every time you touch the image switching button (1), the image will be changed as follows:



(a) Top image and backward image (Default setting)

The 360 view camera will display the surrounding image and the backward image.

(b) Backward wide image

The 360 view camera will display the backward image widely.

(c) Side image and backward image

The 360 view camera will display the image under the front passenger's seat and the backward image.

When you shift the gearshift lever other than "R", the camera image will return to the previous one.

NOTE:


- *The backward image of the 360 view camera is displayed as the top priority out of all the images. However, when the infotainment system itself is being activated, the backward image will not displayed.*
- *For manual transmission vehicle, you can adjust the image quality and set up the initial display image when the gearshift lever is in other than “R”, parking brake is applied and the vehicle is stopped.*
- *For Auto Gear Shift vehicle, you can adjust the image quality and set up the initial display image when the gearshift lever is in “N” position, the parking brake is applied and the vehicle is stopped.*
- *When the engine switch is in ACC mode, the camera image will not be displayed.*

OPERATING YOUR VEHICLE

Error display on the screen

When there is an abnormality in the camera system, the following mark will be displayed on the screen.


Consult a Maruti Suzuki authorized workshop to have the camera system inspected.



74TB05013

(1) Error mark of camera system

Front and rear traffic alert



(1) Detected vehicle

While you park the vehicle in a parking lot or drive the vehicle at a very low speed, if a person or a vehicle moves from the outside to the center in the detection area of the 360 view camera, the buzzer of detection (the default setting is in OFF state) from the speaker will sound and the support indicator (2) for checking left and right directions will come on. This function informs the driver of necessity to confirm safety and evasive action such as depressing the brake pedal.

When you reverse the vehicle, the information (3) which is detected by the rear parking sensors will be displayed as well as the interior buzzer of detection sounds and the support indicator (2) for checking left and right directions comes on.

WARNING


The front and rear traffic alert cannot detect all the moving objects. Directly check safety of the surroundings with your eyes.

NOTE:

You can change the setting of the front and rear traffic alert.

OPERATING YOUR VEHICLE

Examples which the front and rear traffic alert does not activate




Situations where the front and rear traffic alert does not activate

- When a person or a vehicle approaches from front or straight behind of your vehicle *¹
- When a person or a vehicle does not move *²
- When a person or a vehicle move from the center to the outside on the screen *³
- When you do not park the vehicle in a parking lot or you do not drive the vehicle at a very low speed
- When there is a long distance between a person or a vehicle to your vehicle
- When a moving object is not displayed on the screen
- When the detected target object overlap with strong light of sunshine and headlights
- When there is a big difference of camera image between a bright place and a dark place on the screen


Situations where the front and rear traffic alert may not activate

- When a person or a vehicle approaches parallel to your vehicle^{*4}




55T050410

- When a small object such as a ball is moving
- When a moving object such as a bicycle gets across at a high speed
- When a camera lens is dirty by spider's web or mud
- When a camera lens is misted




55T050400

- When visibility is poor due to snow, rain or fog
- When a camera lens is directly exposed to light from the sun or headlights



55T050420

- When it is difficult to detect a person or a vehicle which gets across at night, because there is no street lamp
- When the body color of a vehicle or the cloths of a person that gets across is similar to the background



55T050430

- When a person or a vehicle moves at a higher place than the space which you try to park your vehicle
- When a tailgate is opened
- When a strong impact is applied to a camera and its peripheral part and the installed position of the camera is misaligned
- When the detection area is misaligned by inclination on the road


Situations where the front and rear traffic alert may activate by chance

- When a person or a vehicle steps away parallel from your vehicle^{*5}
- When a labarum outside of a convenience store or a street tree swings in the wind
- When there is a wall or a shutter which has running wavy pattern, fences, white lines, a metal lid such as a grating cover
- When the lights from signs, the turn signal lights or the reversing lights of a vehicle or your vehicle are flashing nearby
- When waterdrop or white smoke runs on a camera lens
- When the road is wet and shiny or there are puddles after the rain
- When the brightness is changed by shadow of trees or buildings
- When your vehicle is severely inclined
- When a strong impact is applied to a camera and its peripheral part and the installed position of the camera is misaligned
- When the detection area is misaligned by inclination on the road

OPERATING YOUR VEHICLE

How to understand the displayed items on the screen

The following guide lines and buttons will be displayed on the screen.
The guide lines would provide a rough indication for your driving operations.



55T050510

- Each displayed item in the above figure is a typical example; it depends on the vehicle type.

No.	Displayed item	Contents
(1)		This shows the position of your vehicle.

No.	Displayed item	Contents
(2)		This shows that the forward of your vehicle is displayed and the front and rear traffic alert is activated.
		This shows that the backward of your vehicle is displayed and the front and rear traffic alert is activated.
		This shows that the front and rear traffic alert is not activated.
		
		
		This shows that you increases the vehicle speed and the front and rear traffic alert is not activated.

OPERATING YOUR VEHICLE

No.	Displayed item	Contents
(2)		This shows that there is abnormality in the front and rear traffic alert. Consult a Maruti Suzuki authorized workshop to have the function inspected.
		
(3)		This shows that the top image and forward image are displayed.
		This shows that the top image and backward image are displayed.
		This shows that the forward wide image is displayed.
		This shows that the backward wide image is displayed.

No.	Displayed item	Contents
(3)		This shows that the side image and forward image are displayed.
		This shows that the side image and backward image are displayed.

No.	Displayed color	Item name	Contents
(4)	Green or yellow or red	Indication detected from the rear parking sensors	When the rear parking sensors detects a wall or an obstacle is reversing, this icon is displayed.
(5)	Yellow	Indication of the support for checking left and right directions	When a person or a vehicle moves from the outside to the center in the detection area of a camera, this icon is displayed.
(6)	Green	Guide line for the course	In conjunction with your operations of the steering wheel, this shows the guide line of predicted course when your vehicle moves forward or backward.*

OPERATING YOUR VEHICLE

No.	Displayed color	Item name	Contents
(7)	Red	Guide line for the distance	This shows the guide line of the position where is about 0.5 m (1.6 ft) forward or backward from the center of bumper front-end or bumper back-end
(8)	Yellow		This shows the guide line of the position where is about 1 m (3.3 ft) forward or backward from the center of bumper front-end or bumper back-end.
(9)	Light blue		This shows the guide line of the position where is about 2 m (6.6 ft) forward or backward from the center of bumper front-end or bumper back-end.

*: When the steering wheel is in straight position, the top image and the guide line for the course of forward/backward movement will not be displayed.

(10)	Purple	Guide line for the vehicle width (vertical line)	This shows the guide line of the position where is slightly outside of the vehicle width (including the width of outside rearview mirrors).
		Guide line for the vehicle width (horizontal line)	This shows the guide line of the position where is the most front-end of the vehicle.

- As each guide line is displayed towards road surface, the distance from your vehicle to an obstacle such as the parked vehicle near your vehicle is not accurately displayed. Also, as the top image is displayed by processing the image based on a flat road surface, the position of an obstacle (such as the bumper of the other vehicle) where is higher than the road surface is not accurately displayed.
- Trapezoidal guide lines for the distance and the vehicle width which are displayed on the screen are rough indications and they depend on the actual distance and vehicle width.
- If you modify suspensions or replace a tyre by the undesignated tyre, the guide lines and the top image will not be accurately displayed.
- The buttons on the screen are displayed by pressing.

⚠ CAUTION

- The top image is the quasi-image which combines and processes several images from the cameras on the outside rear-view mirrors, the forward of your vehicle and the backward of your vehicle. Therefore, the top image may be displayed as follows:
 - A steric object is displayed as if it is fell down.
 - If the position of a steric object is higher than the road surface, the object is displayed farther away or it is invisible.
 - A steric object is not displayed out of the screen or its position is misaligned.
- A steric object on the forward image or the backward image may not be displayed on the top image.
- On the top image, the lines on the road may be misaligned on the frame of screen or these lines may look bended. The farther distance from your vehicle there is, the much misalignment the lines have.
- When the position of a camera is misaligned, the images or the guide lines may be misaligned. Ask a Maruti Suzuki authorized workshop to have the camera inspected.
- On a snowy road or a slippery road surface, the guide line for the course and the actual course may be different.
- As the icon of vehicle on the top image is displayed by a computer graphics, it is different from color, shape and size of the actual vehicle. Therefore, the position between your vehicle and the road surface or obstacles may be different from the actual position.
- On the top image, the brightness of the image from each camera may vary depending on brightness conditions.
- After an image is switched to the other image, it may be displayed late. Until the 360 view camera is completely displayed, the image may be temporarily distorted.
- The camera of the 360 view camera uses a special lens. Therefore, the displayed distance and the actual distance may look different and the target object may be displayed as a distorted image. The farther distance from your vehicle there is, the much tendency these situations have.
- As the wide image displays a large range, it displays a significantly-distorted image. Also, the distance on the wide image looks different from the actual distance.

NOTE:

When you activate the infotainment system or there is abnormality on the touch panel, you cannot operate the buttons. In this case, wait for a while. Or, press a camera switch to go back to the original displayed screen, press a camera switch again and operate the buttons while the screen is displayed.

If you cannot operate the buttons by performing the above procedure, Consult a Maruti Suzuki authorized workshop.

OPERATING YOUR VEHICLE


Difference between the camera image and the actual road surface

The position and distance which the guide lines on the screen shows vary depending on the number of passengers, the load capacity, the inclination and situation on the road surface. Directly check safety of the surroundings with your eyes.

When there is an uphill slope on your movement direction

You will see the guide line for the distance in front of the actual distance.

Backward image (Example):



(1) Red, the point which the guide line for the distance (about 0.5 m [1.6 ft]) shows


(2) Yellow, the point which the guide line for the distance (about 1.0 m [3.3 ft]) shows

(3) Light blue, the point which the guide line for the distance (about 2.0 m [6.6 ft]) shows

When there is an downhill slope on your movement direction

You will see the guide line for the distance in the back of the actual distance.

Backward image (Example):



(1) Red, the point which the guide line for the distance (about 0.5 m [1.6 ft]) shows


(2) Yellow, the point which the guide line for the distance (about 1.0 m [3.3 ft]) shows

(3) Light blue, the point which the guide line for the distance (about 2.0 m [6.6 ft]) shows

When there is an steric object near your vehicle

In this case, the distance from your vehicle to the steric object may be different from the actual distance.

Example 1:



In the illustration, the guide line for the course (1) does not touch the body of the displayed truck. However, if the body of this truck protrudes on the actual course which your vehicle will go, a collision may occur.

Example 2:



In the illustration, the top image (2) shows that there is a little distance between your vehicle and the body of the displayed truck. However, the actual distance is shorter than the displayed distance and a collision may occur.


Displayed areas on the screen

- The areas of next image will be displayed on the screen. However, the areas around and under the front bumper and the rear bumper will not be displayed.
- The areas above a camera will not be displayed. If an obstacle is high or the upper part of an obstacle protrudes, such as a sign, the upper part will not be displayed on the screen.
- A feeling of distance on the image of the 360 view camera is different from the actual distance.
- If there is an obstacle such as a parked vehicle on the areas which are displayed on the screen, it may be displayed different from the actual distance.
- The backward image may be inverted on the screen, which is the same as you look the image on the inside rearview mirror or the outside rearview mirrors.
- As the front camera and the back camera are installed on the places which are a little misaligned from the center of your vehicle, the forward image and the backward image will be displayed with a little misaligned positions.

The image of view area by the 360 view camera

CAUTION


The specified areas will become blind spots which will not be displayed on the screen. Make sure to directly check the safety with your eyes.



55T050940

- The areas under the front bumper and the rear bumper or the ground surface which is indicated in the below illustration may not be displayed on the screen.

OPERATING YOUR VEHICLE



55TB5023

- On the top image, an object near the edge of areas which a camera displays and an object which is higher than the road surface may not be displayed on the screen.

NOTE:

- The image of the 360 view camera may be a little different from the actual color.
- If a moving object is displayed on the screen, its accidental image may be displayed as well.
- Under the following situations, it may be difficult for the driver to see the image of the 360 view camera. However, it is not malfunction.
 - At night, on a rainy day or at a dark place
 - When the area around a camera is hot or cold under the blazing sun or the cold condition, or when humidity is

high on a rainy day (A camera lens may be fogged)

- When strong light directly streams to a camera (White vertical lines may be displayed on the image)
- Under the lights such as the fluorescent light (The image on the screen may flicker)
- When the outside air temperature is low (The screen may get dark)
- When you park your vehicle for a long time with the engine on (Noise may be displayed on the image)
- When a camera lens is dirty or when snow or waterdrop is attached to a camera lens

Change of setting

You can adjust the image quality or change the setting of the 360 view camera and the front and rear traffic alert.

WARNING

If you do not change the setting in a safe place where there is nothing around your vehicle, an accident may occur.

Change the setting in a safe place where there is nothing around your vehicle.


NOTICE

If you change the setting for a long time with the engine off, the lead-acid battery may run out.
Change the setting with the engine on.

Adjusting the image quality


When you adjust the image quality, perform the following procedure:

- Set the parking brake firmly.
- Press the engine switch to change the ignition mode to ON.



55TB5029

- After the opening image is finished, press a camera switch (2)



- 4) 3D view mode image will be displayed. Press the button (2) for adjusting the image quality.
- 5) Adjust brightness and contrast of the image to your preference.


NOTE:

- The figure of the set brightness varies depending on ON/OFF condition of the light.
- Refer to the owner's manual of infotainment system for details.

Setting of the 360 view camera and the front and rear traffic alert

When you change the setting, perform the following procedure:


- 1) Set the parking brake firmly.
- 2) Press the engine switch to change the ignition mode to ON.



- 3) After the opening image is finished, press a camera switch (1).



- 4) 3D view mode image will be displayed. Press the button (3) for the setting.




- 5) Touch the indication (4) to perform the setting of the 360 view camera. Change the setting to your preference. To switch to the different page, press ▲ or ▼.

OPERATING YOUR VEHICLE

- The image in the above figure is a typical example; it depends on the vehicle type.

Indication	Function
Guideline display 74TB05015	You can select one of the following guide lines: <ul style="list-style-type: none">Hiding guide linesDisplaying rudder-interlocked guide linesDisplaying fixed guide lines
Front view default screen 74TB05016	As the image to check the forward area of your vehicle, you can select one of the following images: <ul style="list-style-type: none">Top image and forward image (default setting)Forward wide imageSide image and forward image
Rear view default screen 74TB05018	As the image to check the backward area of your vehicle, you can select one of the following images: <ul style="list-style-type: none">Top image and backward image (default setting)Backward wide imageSide image and backward image
Opening display 74TB05020	You can select to display or hide 3D view mode which is automatically displayed on activation.
Front screen automatic display 74TB05019	When you shift the gearshift lever from "R" to the other position than "P", you can select to display or hide the camera image which is automatically displayed.



74TB05017

- 6) Touch the indication (5) to perform the setting of the front and rear traffic alert. Change the setting to your preference.
 • The image in the above figure is a typical example; it depends on the vehicle type.

Indication	Function	
Front and rear traffic alert 59RN05550	You can select ON/OFF condition of the front and rear traffic alert.	
Detection level 59RN05560	You can select one of the following detecting levels. High: Normal level Low: Low level	
Notification sound 59RN05570	You can select ON/OFF condition of sound (buzzer) for the above-mentioned function. (The default setting is in OFF state.)	

OPERATING YOUR VEHICLE

Handling a camera

CAUTION

When you strike a camera or its periphery, the image may not be displayed properly. Ask a Maruti Suzuki authorized workshop to have the camera inspected.

NOTE:

- When you replace a camera with new one, adjustment is necessary. Ask a Maruti Suzuki authorized workshop for adjustment.
- Do not attach any object which prevents the camera's activation to the camera and its periphery. You cannot attach the backlit license plate.

When you doubt malfunction of camera

When the error mark of camera system is displayed on the screen

When the error mark  is displayed on the screen, there is abnormality in the camera system.

- If the error mark does not disappear, ask a Maruti Suzuki authorized workshop to have the camera system inspected.

When the image quality on the 360 view camera is poor

- When a camera lens is dirty, you may have difficulty to see the image. If water-drop, snow or dirt is attached to the camera lens, wash it with water and wipe it off with a soft cloth. If the camera lens is heavily dirty or wax is attached to the camera lens, use a mild detergent.
- When reflected light from strong sun or strong headlights from the vehicle behind your vehicle streams directly to a camera, white lines may be displayed on the image and you may have difficulty to see the image. However, this is not malfunction.

When the image and the guide lines are misaligned

In the following case, the image and the guide lines will be misaligned. However, this is not malfunction.

- Your vehicle is tilted due to the number of passengers and baggage.

License Information

The software in the 360 view camera includes open software. The license information is as follows:

[T-Kernel]

This Product uses the Source Code of T-Kernel under T-License granted by the T-Engine Forum (www.tron.org).

[OpenGL ES]

SGI FREE SOFTWARE LICENSE B (Version 2.0, Sept. 18, 2008)

Copyright (C) [dates of first publication] Silicon Graphics, Inc. All Rights Reserved.
Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice including the dates of first publication and either this permission notice or a reference to <http://oss.sgi.com/projects/FreeB/> shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL SILICON GRAPHICS, INC. BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Except as contained in this notice, the name of Silicon Graphics, Inc. shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization from Silicon Graphics, Inc.

OPERATING YOUR VEHICLE

Parking Sensors

Instrument cluster (Type A)



55T050090

Instrument cluster (Type B)



55T050860

(1) Symbol representing an obstacle detected by parking sensor*

* This symbol shows that an obstacle is located on the right rear of vehicle.

- The parking sensor system uses ultrasonic sensors to detect obstacles near the rear bumper. If obstacles are sensed while you are parking or moving the vehicle slowly, the system warns you by sounding a buzzer and displaying symbols representing the obstacles on the information display in the instrument cluster.
- The system emits an ultrasonic wave and the relevant sensor detects the return of the wave reflected by an obstacle. The system measures the time taken by the ultrasonic wave to reach the obstacle and return from it, from which it determines the obstacle's position.
- The parking sensor function can be used when you turn the ignition switch to "ON" position or the engine switch is pressed to change the ignition mode to "ON", the gearshift lever is in the "R" position. This function is helpful in the following cases: pulling over to the curb; parallel-parking the vehicle; steering the vehicle into a garage; driving along an alley; and moving slowly in a place with obstacles.

WARNING

- The parking sensor warns you of obstacles with buzzers and by showing you the location of the obstacles on the information display. However, you must still pay full attention yourself while driving.
- The sensors can detect obstacles only within a limited area and only when the vehicle is moving within a limited speed range. So, in tricky areas, you must move the vehicle slowly while checking around it using your direct vision or rearview mirrors. There is increased risk of an accident if you control the vehicle relying only on the parking sensor.

NOTICE


Parking sensors are only for driver's assistance.

NOTE:

When the gearshift lever is shifted to the "R" position, a buzzer will sound once.

OPERATING YOUR VEHICLE

Sensor Locations



55TB5024

(1) Rear center sensors (2 places)

(2) Rear corner sensors (2 places)

Working sensors

The sensors work depending on the gearshift lever position as follows:


Gearshift lever position		Manual transmission		Auto Gear Shift		Parking brake lever
		R	N, 1st – 5th	R	N, D or M	
Rear sensors	Center	On	Off	On	Off	No relation
	Corner	On	Off	On	Off	No relation

NOTICE

- Avoid hitting the sensor areas or directing the nozzle of a high-pressure car washer onto the sensor areas. Otherwise, the sensors may be damaged.
- If the bumper hits a hard object, the sensors on it may not work properly. If this occurs, have the sensors inspected by a Maruti Suzuki authorized workshop.

OPERATING YOUR VEHICLE

Approximate areas where obstacles can be detected



55T050580

- An obstacle within about 20 cm (8 in) from a sensor or just below a sensor is not detectable.
- The sensors can detect obstacles such as a wall up to about 1.5 m (5 ft) from the rear of vehicle.

! WARNING

- Under the following conditions, the parking sensor system may not work normally because the sensors cannot detect obstacles correctly.
 - Sensors are covered with mud, ice or other materials (Such materials must be removed for normal operation).
 - Sensors are wet from water splashes or heavy rain.
 - Sensors are covered by a hand, sticker, accessory, etc.
 - There is an accessory or other object attached within the sensor's sensing area.
 - Items such as tow hooks, commercially available corner poles, radio antenna, etc. are installed on the bumper.
 - The height of the bumper is changed due to alteration to the suspension or other causes.
 - The sensor areas are extremely hot from direct sunlight or cold due to freezing weather.
 - The vehicle is on a rough surface, slope, gravel road or grass field.
 - The vehicle is at a steep angle.

(Continued)

! WARNING

(Continued)


- Sensors have intercepted ultrasonic noise from another vehicle's horn, engine, air braking system (large vehicles), or parking sensor.
- Obstacles are too close to the sensors.
- Sensors are at an angle to a highly reflective object such as glass (Ultrasonic waves are not reflected back from the obstacle).
- Sensors may not be able to correctly detect the following types of obstacles:
 - Objects made of a thin material like wire netting and ropes.
 - Square-shaped curbstones or other objects with sharp edges.
 - Tall objects with a large upper part like a road sign.
 - Low-profile objects such as curbstones.
 - Sound-absorbing objects such as cotton and snow.

NOTE:

- *Thin poles or obstacles lower than the sensors may become undetectable as the vehicle moves closer to them even if they have been detected from longer distances.*

- The system may calculate the distance to a road sign or similar obstacle to be shorter than the actual distance.

Obstacle Indication by Parking Sensor Instrument cluster (Type A)



55T050100

- (1) Obstacle detected by rear center sensors
- (2) Obstacle detected by rear corner sensors

Upon detecting an obstacle, the parking sensor causes an interior buzzer to sound and a symbol representing the obstacle appears on the information display in the instrument cluster.


- A different symbol is displayed depending on the direction and distance of the obstacle.
- A buzzer located behind the rear seat sounds when a sensor at the rear detects an obstacle.
- Warnings when obstacles are detected by rear sensors

Distance (approx.)		Buzzer	Symbol
Center sensors	60–150 cm (24–59 in)	Short beeps at long intervals	Three lines
	45–60 cm (18–24 in)	Short beeps at short intervals	
	35–45 cm (14–18 in)	Short beeps at very short intervals	
	Less than 35 cm (14 in)	Continuous beep	

NOTE:

- Symbols are displayed with a short delay after the detection of obstacles.
- If the system detects multiple obstacles simultaneously, the display shows all of their positions using the corresponding symbols. However, the buzzers will sound only for the nearest obstacles.

Instrument cluster (Type B)



55T050870

OPERATING YOUR VEHICLE

Warning and Indicator Messages

Vehicle with Instrument Cluster (Type A)

If there is a problem or warning regarding the parking sensor system, a buzzer and the status of the indicator on the parking sensor inform it. Follow its instruction.

- The buzzer sounds intermittently. The indicated sensor is contaminated. Wipe it clean with a soft cloth. If the buzzer does not stop after wiping, there may be problem with the parking sensor system. Have your vehicle inspected by a Maruti Suzuki authorized workshop.

Vehicle with Instrument Cluster (Type B)

If there is a problem or warning regarding the parking sensor system, a message is displayed on the information display in the instrument cluster, and a symbol blinks and the buzzer sounds. If a message is displayed, follow its instruction.

Message	Symbol	Probable cause and remedy
	Two blinking lines in a sensor location	There may be a problem with the parking sensor system. Have your vehicle inspected by a Maruti Suzuki authorized workshop.
	One blinking line in a sensor location	The indicated sensor is contaminated. Wipe it clean with a soft cloth.

Rearview Camera (if equipped)

When the gearshift lever is shifted to "R" position while the ignition switch is in "ON" position or the ignition mode is "ON", the rearview camera system automatically shows the view behind the vehicle on the display.

⚠ WARNING

The distance viewed in the rearview camera may differ from the actual distance according to the condition of road or the load the vehicle is carrying. Since the camera display area is also limited, backing up by only looking at the display may cause an accident or a crash with an object.

The rearview camera cannot replace the driver's attention. The driver alone is responsible for parking and similar driving maneuvers.

- Use the rearview camera only to provide driving assistance.
- Always drive carefully confirming the safety of the rear and the surrounding conditions by looking directly with your eyes and using the rear view mirror.
- Check that the trunk lid is securely closed when backing up.

NOTICE


If you use the rearview camera for a long time when the ignition switch is in "ON" position or the ignition mode is ON, but the engine is not running, the battery may discharge.
Do not leave the ignition switch in "ON" position or the ignition mode to ON for a long time when the engine is not running.

NOTICE

The rearview camera is a precision instrument. If you strike the camera, it may be broken and cause damage resulting in a catch fire or a malfunction.

- Do not strike the camera.
- Do not remove snow or mud on the camera lens with a stick.

Rearview Camera Location



55TB5025

(1) Rearview camera

The rearview camera is installed on the tailgate.

NOTICE

If water enters the rearview camera, it may cause a malfunction or catch fire.

- Do not use high pressure water around the camera.

NOTICE

This lens is hard coated to prevent damage or discoloration. Damage or discoloration of lens may obscure the image.

- Do not use a brush to clean lens.
- Do not use alcohol, benzene or thinner to clean the lens.
- Do not use wax on the camera lens.

NOTE:

If body wax gets on the camera lens, wipe off the wax with a clean cloth dampened with mild detergent diluted with water, and then wipe the lens with a dry cloth.

OPERATING YOUR VEHICLE

How to use rearview camera

- 1) Turn the ignition switch to "ON" position or press the engine switch to change the ignition mode to "ON".
- 2) Shift the gearshift lever in "R" position.
 - The display automatically shows the view behind the vehicle.
 - When the gearshift lever is shifted from "R" to another gearshift lever position, the display returns to the previous display.


NOTE:

The rearview camera display has first priority in any display mode. However, the rearview camera display does not show the rear view while the system is initializing.


Display Range of Rearview Camera

The rearview camera display shows the area behind the rear end of the bumper. The display cannot show objects which are close to the bumper or under the bumper. The rearview camera display cannot show obstacles which are higher than the camera. Upper parts of tall objects such as road signs cannot be viewed on the display.

Display range of rearview camera



74TB05026



55T050620

(1) Display range


NOTE:

- Images shown on the display from the rearview camera are reversed images (mirror images).
- The colors of objects on the rearview camera may differ from the actual object colors.
- The rearview camera display may be difficult to see under the following conditions, but this is not a system malfunction.
 - In dark areas, on a rainy day or at night.
 - When the temperature around the lens is too high/low, or the camera is wet such as on a rainy day or during periods of high humidity (dew condensation may occur on the camera lens).
 - When a foreign object such as mud or a drop of water is stuck around the camera lens.
 - When strong light directly enters the camera (vertical lines may be seen on the display).
 - Under fluorescent light (The display may flicker).
 - When the outside temperature is low (the image on the display may be darkened).

Rearview camera screen indication

The distance viewed in the rearview camera may differ from the actual distance according to the condition of the road or the load the vehicle is carrying.


Uphill incline behind the vehicle



- (1) Object
- (2) Actual distance
- (3) Distance on the display

When there is an uphill incline behind the vehicle, the object shown on the display appears farther away than the actual distance.

Downhill incline behind the vehicle



- (1) Object
- (2) Actual distance
- (3) Distance on the display

When there is a downhill incline behind the vehicle, the object shown on the display appears closer than the actual distance.

If the rear view from the rearview camera is not shown or there is a poor image

- If the rear view from the rearview camera is not shown.
 - Check that the ignition switch is in "ON" position or the ignition mode is "ON".
 - Check that the gearshift lever is shifted to "R" position.
- If the image from the rearview camera is poor.
 - Check that the camera lens is not dirty.
 - Check that light from the sun or the beam of the headlights from the vehicle behind is not shining directly into the lens.

If the rearview camera system is still not working properly after checking the above, have the system inspected by a Maruti Suzuki authorized workshop as soon as possible.

Electronic Stability Program (ESP®)

ESP® is a registered trademark of Mercedes-Benz Group.

The Electronic Stability Program (ESP®) helps to control the vehicle during cornering if front wheels or rear wheels skid. It also assists you in maintaining traction while accelerating on loose or slippery road surfaces. It does this by regulating the engine's output, and by selectively applying the brakes. In addition, ESP® helps to avoid skidding by controlling braking pressure.

⚠ WARNING

The ESP® cannot enhance the vehicle's driving stability in all situations and does not control your vehicle's entire braking system. The ESP® cannot prevent accidents, including those resulting from excessive speed in turns, or hydroplaning. Only safe and attentive drive can prevent accidents.

The capabilities of an ESP®-equipped vehicle must never be used as a substitute for careful driving.

OPERATING YOUR VEHICLE

The ESP® has the following systems:

Anti-lock Brake System (ABS)

Refer to "Anti-lock Brake System (ABS)" in this section.

Brake Assist System

Refer to "Brake Assist System" in this section.

Traction Control System

The traction control system automatically helps prevent the spinning of wheels when the vehicle is started or accelerated on slippery road surfaces. The system operates only if it senses that some of the wheels are spinning or beginning to lose traction. When this happens, the system operates the front or rear brakes and reduces engine power to limit wheel spin.

Stability Control System

The vehicle stability control system helps provide integrated control of systems such as anti-lock brakes, traction control, engine control, etc. This system automatically controls the brakes and engine to help prevent the vehicle from skidding when cornering on a slippery road surface or when turning the steering wheel abruptly.

⚠ WARNING

Always check the surrounding conditions and drive the vehicle in a safe manner, as controlling the vehicle by ESP® has limits and ESP® may not function properly depending on the surrounding conditions.

⚠ CAUTION

- Observe the following points. Otherwise, ESP® may not operate properly or it may result in a malfunction.
 - Adjust the tyre pressure as specified.
 - When replacing tyres, use the same tyres with the size, type, and tread patterns.
 - Do not use the tyres which have excessively worn conditions.
 - Do not modify the suspension or the brake and do not change vehicle height or suspension hardness.
 - Do not drive the vehicle with suspension or brake excessively deteriorated.
 - Do not modify the engine or the muffler.
 - Do not install LSD (limited slip differential).
- When you install the snow chains, ESP® may not operate properly.

NOTE:

- If you perform the following operations, you may hear an operation sound or a clicking sound. This means that the ESP® system is in the self-check mode and this does not indicate a malfunction.
 - When ignition switch is turned to the "ON" position or pressing the engine switch to change the ignition mode to "ON"
 - When releasing your foot from the brake pedal, after the ignition switch is in "ON" position or the ignition mode is "ON" with the brake pedal depressed
 - When starting the engine
 - When starting the vehicle after starting the engine
 - When engine revolutions is high and ESP® operates, you may feel the change of engine revolutions or vibration of vehicle body. However, this is normal.

ESP® Warning Light

55TB5026

- If there is a problem in the ESP® system with the ignition switch in "ON" position or the engine switch in ON mode, this light will come on. While this light comes on, the following situations will occur. In this case, ask a Maruti Suzuki authorized workshop for inspection.
 - The following functions will not work:
 - Traction control system
 - Stability control system
 - ENG A-STOP system (if equipped)
 - Hill hold control system may not work.
 - ABS will work.
 - Depending on the malfunction condition, brake assist system may not work.


- If any of the following situations occurs, this light will blink at very short intervals of 0.2 seconds.
 - Traction control system is activated when starting or accelerating the vehicle
 - Stability control system is activated when making a sharp turn or whirling round
- If the system is in normal condition, when you turn the ignition switch to "ON" position or press the engine switch to change the ignition mode to ON, this light will come on for about 2 seconds and then come off.

CAUTION

If this light blinks at very short intervals, there is high possibility that the vehicle will be stuck or skid on a slippery road surface. In this case, drive the vehicle very carefully.

NOTE:

While this light comes on, traction control system and stability control system will not be activated. However, you can use ABS.

ESP® OFF Switch

55TB5027

- In the following situation, keep pressing the ESP® OFF switch until the ESP® OFF indicator light in the instrument cluster comes on. Traction control system and stability control system will not work.
 - When placing the vehicle on the tester for automobile inspection, traction control system and stability control system needs to be deactivated.
 - If your vehicle is stuck and you try to get out of the stuck condition, traction control system may not be suitable.
- If you perform the following operations, the ESP® OFF indicator light will come off. Also, traction control system and stability control system will return to be in the activated condition.
 - Pressing the ESP® OFF switch again

OPERATING YOUR VEHICLE

- Stopping the engine and then restarting the engine
- If you would like to perform normal driving after escaping from the stuck condition, press the ESP® OFF switch again. This will allow the ESP® OFF indicator light to come off and the vehicle will return to the original condition. Traction control system and stability control system will not be activated automatically. (except when stopping the engine and then restarting the engine)

NOTE:

For safety reasons, even if you press the ESP® OFF switch, ABS and brake assist system will not be deactivated.

ESP® OFF Indicator Light



55TB5028

- If you press and hold the ESP® OFF switch with the ignition switch is in “ON” position or the ignition mode is “ON”, this light will come on.
 - While this light comes on, traction control system and stability control system will not work.
- If the system is in normal condition, when you turn the ignition switch to “ON” position or press the engine switch to change the ignition mode to ON, this light will come on for about 2 seconds and then come off.

Hill Hold Control System

The hill hold control system is designed to assist you in starting to move up hills. When you start to move up a hill, the system helps to prevent the vehicle from rolling downward (for approximately 2 seconds) while you move your foot from the brake pedal to the accelerator pedal.

⚠ WARNING

- Always check the surrounding conditions and drive the vehicle in a safe manner by depressing the brake pedal as necessary, as controlling the vehicle by the hill hold control system has limits and the system may not function properly depending on the surrounding conditions.
- If you do not depress the brake pedal firmly enough, the hill hold control system may not work.
- If you release your foot from the brake pedal for more than 2 seconds, the hill hold control system will be canceled. If so, the vehicle may roll downward, which can result in an accident depending on the degree of a slope. Also, the engine may stall and the power assist for the steering and brakes will not work so steering and braking will be much harder than usual which can result in an accident or vehicle damage. After you release your foot from the brake pedal, accelerate the vehicle to move up immediately.

NOTE:

- If there is a problem with the hill hold control system, the ESP® warning light in the instrument cluster may come on and the hill hold control system may not work. Also, ENG A-STOP system (if equipped) may not work. In this case, consult a Maruti Suzuki authorized workshop.
- If you move up an excessively sharp slope, a frozen road or a mud track, or depending on laden weight, the vehicle may roll downward when you start the vehicle.
- If you move up an excessively sharp slope, a frozen road or a mud track and the hill hold control system activates, the tyres may be locked and the vehicle may not be controlled properly.

Activation conditions for the hill hold control system

The hill hold control system activates to prevent the vehicle from rolling downward for about 2 seconds if your foot is moved from the brake pedal when the following conditions are all met.


- The gearshift lever is in the forward gear or reverse position.
 - The parking brake is released.
 - The vehicle is on an upward slope.
 - The brake pedal is depressed firmly.
- For the vehicles with ENG A-STOP system (if equipped), the hill hold control system is activated when the engine is restarted after being stopped automatically, even if the previous conditions are not met.

NOTE:

When the hill hold control system is activated, you may hear a sound coming from the engine, or you may feel hardness of the brake pedal. These are normal and do not indicate a malfunction.

OPERATING YOUR VEHICLE

Braking



59RN05770

The distance needed to bring any vehicle to a halt increases with the speed of the vehicle. The braking distance needed, for example, at 60 km/h will be approximately 4 times greater than the braking distance needed at 30 km/h. Start to depress the brake pedal when there is plenty of distance between your vehicle and the stopping point, and slow down gradually.

⚠ WARNING

If water gets into the brake devices, brake performance may become poor and unpredictable. After driving through water or washing the underside of the vehicle, test the brakes while driving at a slow speed to see if they have maintained their normal effectiveness. If the brakes are less effective than normal, dry them by repeatedly applying the brakes while driving slowly until the brakes have regained their normal effectiveness.

NOTE:

While braking you may hear operational noise due to friction between brake disc/drum and brake lining. This is a normal phenomenon and does not indicate any abnormality or affect normal functioning of the vehicle.

Power-assisted Brakes

Your vehicle has power-assisted brakes. If power assistance is lost due to a stalled engine or other failures, the system is still fully operational on reserve power and you can bring the vehicle to a complete stop by pressing the brake pedal once and holding it down. The reserve power is partly used up when you depress the brake pedal and reduces each time the pedal is pressed. Apply smooth and even pressure to the pedal. Do not pump the pedal.

⚠ WARNING

Even without reserve power in the brake system, you can still stop the vehicle by pressing the brake pedal harder than normally required. However, the stopping distance may be longer.

Brake Assist System

When you slam the brakes on, the brake assist system determines it to be an emergency stop and provides more powerful braking for a driver who cannot hold down the brake pedal firmly.

NOTE:

If you quickly and forcefully depress the brakes, you may hear clicking sound by the brake assist system operation. This is normal and indicates that the brake assist system is activated properly.

Anti-lock Brake System (ABS)

ABS will help you avoid skidding by electronically controlling braking pressure. It will also help you maintain steering control when braking on slippery surfaces or when braking hard.

The ABS works automatically, so you do not need any special braking technique. Just push the brake pedal down without pumping. The ABS will operate whenever it senses that the wheels are locking up. You may feel the brake pedal move a little while the ABS is operating.

⚠ WARNING

- Always check the surrounding conditions and drive the vehicle in a safe manner, as controlling the vehicle by ABS has limits and the system may not function properly depending on the surrounding conditions.
- If tyre grip performance is over the limit or hydroplaning occurs, ABS cannot work properly.

NOTE:

- If the ABS system is activated, you may hear a clunking noise and/or feel pulsating in the brake pedal. This is normal and indicates that the brake fluid pressure is being controlled properly.
- You may hear an operation sound when you start the engine or after the vehicle

begins to move. This means that the above systems are in the self-check mode. This sound does not indicate a malfunction.

Braking Distance

ABS is not designed to shorten the stopping distance.

⚠ WARNING

- In the following situations, the braking distance required for a vehicle with ABS may be slightly greater than the one required for a vehicle without ABS, resulting in an accident. Drive the vehicle slowly and maintain ample distance between your vehicle and the vehicle in front of you.
 - When driving on rough roads such as unpaved or stone-paved roads
 - When driving on gravel roads or fresh snow roads
 - When driving over bumps on the roads such as joint seams
 - When passing over metal plates such as manholes
 - When snow chains are installed

NOTE:

- When applying sudden brake or applying brake on slippery roads, the braking distance required for a vehicle with ABS is almost the same as the one required for a vehicle without ABS.
- If you would like to suddenly apply brake, just push the brake pedal down firmly without pumping. Otherwise, the longer braking distance will be required.
- The ABS will not work if vehicle speed is under about 9 km/h. This depends on the road conditions.

Vibration and Sound during ABS Operation

When strongly depressing the brake pedal, you might feel vibration of the brake pedal, the steering wheel, and the vehicle body. This is due to ABS operation, and does not indicate a malfunction; continue strongly depressing the brake pedal at this time.

NOTE:

Immediately after starting the engine and beginning to drive, you might temporarily hear a motor sound. This means that the systems are in self-check mode. This sound does not indicate a malfunction.

OPERATING YOUR VEHICLE


Tyres

⚠ WARNING

ABS detects each wheel rotation speed via a sensor. If tyres or wheels other than those specified in the owner's manual are used for size, type, tread pattern, or if worn conditions of tyres are different, the correct wheel rotation speed cannot be detected and ABS will not work properly. This may result in an accident. When replacing tyres, use the tyres with the size, type which are specified in this owner's manual. Also, do not use the tyres which are excessively worn.


Situations where ABS may Activate by Chance when Applying Brake

- When driving on slippery roads




69RHS150

- Manholes



69RHS151


- Metal plates in construction zones



69RHS152


- Gravel roads

- When driving over joints in roads and other height differences




69RHS153

- Joints in roads



69RHS154

- Height differences in roads
- When driving on rough roads



74TB05037

- Cobblestone

ABS Warning Light



69RHS155

- Bumpy roads



74TB05002


If there is a problem in the ABS system with the ignition switch in "ON" position or the engine switch in ON mode, this light will come on.

Braking Assist

This function assists you in applying more force when operating the brake. When sudden braking is applied, the time until the ABS comes into full effect is shortened.

- If you do not depress the brake pedal firmly, braking assist will not operate.
- Brake assist is not a device that provides control beyond the original braking performance.

ADVICE FOR YOUR DRIVING




60G409

When Driving	6-1
Off-road Driving	6-8
Improving Fuel Economy	6-9
Stuck Vehicle	6-10
Precaution for Handling Vehicle	6-11
Running-in	6-15
Catalytic Converter	6-15

ADVICE FOR YOUR DRIVING

When Driving




59RN02300

⚠ WARNING

- Wear your seat belts at all times. Even though airbags are equipped at the front seating positions, the driver and all passengers should be properly restrained at all times, using the seat belts provided. Refer to "Seat belts and child restraint systems" section for instructions on proper use of the seat belts.
- Never drive under the influence of alcohol or other drugs. Alcohol and drugs can seriously impair your ability to drive safely, greatly increasing the risk of injury to yourself and others. You should also avoid driving when you are tired, sick, irritated or under stress.

Start Driving after Carefully Checking the Surrounding Circumstances

Be sure to always fully check the safety of the surrounding circumstances before beginning to drive.



69RHS176

⚠ CAUTION

You cannot check the safety of the surrounding circumstances enough only by the 360 view camera, the rear parking sensors and the inside mirror. When moving the vehicle forward or backward, check the safety of the surrounding circumstances by directly checking with your eyes.

Do not Race the Engine, and Do not Avoid Fast Starts and Rapid Acceleration Just after Engine Start


Refer to "Avoid Fast Starts, Rapid Acceleration and Hard Braking" and "Do not Race the Engine" in the "Improving Fuel Economy" section.

Do not Concentrate on a Mobile Phone or Navigation System



55T060040

Do not Reach Through the Steering Wheel



69RHS178

Do not Drive with Your Foot on the Brake Pedal

⚠ CAUTION

Driving with your foot resting on the brake pedal could cause brake parts to become worn out more quickly than normal or cause brake components to overheat, making them less effective.

⚠ WARNING

- Do not operate a mobile phone, etc. while driving. Being distracted by phone operation could lead to an accident.
- Do not operate navigation/audio equipment, etc. while driving. Otherwise, there is the danger of an accident due to being distracted.

⚠ WARNING

Reaching through the steering wheel could interfere with steering wheel operation and result in an accident.

When Depressing the Accelerator Pedal and the Brake Pedal Simultaneously

NOTE:

If you depress both the accelerator pedal and the brake pedal simultaneously while driving, the engine power output may be suppressed.

ADVICE FOR YOUR DRIVING

Do not Shift the Gearshift Lever into "N" (Neutral) while Driving



69RHS180

▲ CAUTION

Do not put the gearshift lever into the "N" (Neutral) position while driving, except in times of emergency, as this disengages engine braking, which could result in an accident.

NOTE:

Non-usage of vehicle for long duration may cause gradual rusting on brake disc surface as it is made of cast iron. This may result in noise/vibration. The same has no bearing on functioning of the vehicle. Regular driving of vehicle may prevent/remove rust, thus reducing the noise and vibration.

What Should You Do in Case of Malfunction or Emergency?

- **Warning light turns on**

Stop immediately in a safe place and take corrective action.

For details, refer to "Warning Lights and Indicators" in the "QUICK GUIDE" section or "Warning and indicator messages" in the "INSTRUMENT CLUSTER".

- **You feel strong shock from under the floor**

Immediately stop in a safe place and check whether there is brake fluid leakage or fuel leakage, and also check whether there is any abnormality in the exhaust pipe, etc. If any abnormality is found, consult with a Maruti Suzuki authorized workshop.

- **Sudden tyre puncture**

Grasp the steering wheel firmly, carefully apply the brake, slowly reduce speed, and stop in a safe place.

- **You feel that the brake pedal is heavy to use**

Via engine vacuum pressure, the vehicle utilizes a brake booster to reduce the force necessary for depressing the brake pedal. If this engine vacuum pressure decreases, you may feel as if the brakes require more force than usual to depress, but this is not abnormal. Depress the brake pedal as strongly as you need to.

- **Metallic screeching sound is heard from the brakes**

Promptly consult with a Maruti Suzuki authorized workshop. The disk brake pads (Maruti Suzuki genuine parts) are designed to emit a creaking/screeching sound as a function to warn the wear, as they have almost reached usage limit and replacement timing.


▲ WARNING

The brakes could be losing their ability to function normally, which could result in an accident. If you hear a metallic creaking/screeching sound, do not continue driving.

Use Engine Brake on a Long Downhill Slope

Use engine braking(*) in tandem with regular braking when driving on a long downhill slope. Release the accelerator pedal and shift down according to vehicle speed, release the accelerator pedal and shift down according to vehicle speed.


Manual transmission vehicles



55T060010

For manual transmission vehicle, shift down to a lower gear one by one.


Automatic transmission vehicles



74TB06001

For automatic transmission vehicle, shift the gearshift lever into "M" (manual mode) first. Then, pull “-” side of the shift paddle to shift down to an appropriate gear position.

Auto Gear Shift vehicles



55T060020

For Auto Gear Shift vehicle, shift the gearshift lever into "M" (manual mode) first. Then, pull “-” side of the shift paddle to shift down to an appropriate gear position.


*: Engine braking is a braking effect that occurs when you release your foot from the accelerator pedal while driving. The lower the gear, the greater the effect of engine braking becomes.

WARNING

Continuously depressing the brake pedal could cause the brakes to overheat, possibly rendering them ineffective.

ADVICE FOR YOUR DRIVING


When Side Wind Is Strong



72J20330

At a tunnel exit, on a bridge, or when a large truck passes you, your vehicle might be blown slightly sideways by side wind. Do not panic. Firmly grasp the steering wheel, gradually reduce speed, and regain your intended course.

Drive Slowly on a Slippery Road Surface



59RN06030

Do not Drive on Puddles at High Speed



69RHS182

CAUTION

When driving on wet, icy, or snowy roads, etc., refrain from sudden movements, such as sudden starting, acceleration, braking, turning or abrupt engine braking. Otherwise, there is the danger of an accident due to loss of traction.

CAUTION

When driving on puddles or on wet road surfaces at high speed, a thin surface of water is built between the wheels and the road surface, and the wheels may float. This is called as hydroplaning, which leads to a loss of control in the steering wheel and the brakes and possibly results in an accident.

Check Brake Effectiveness after Driving on Puddles or Washing a Vehicle



72J20360

- After verifying the safety of the surroundings, depress the brake pedal several times at low speed and check the brake effectiveness.
- If the brake effectiveness is still poor, depress the brake pedal at low speed gently and repeatedly until the brake effectiveness is fully recovered, to dry the brake equipment.

When Encountering a Flooded Area



61M0075

Avoid driving in a flooded area or a deep puddle. If driving in a flooded area is unavoidable, go slowly in the lowest gear. In case that you have driven in a flooded area, stop the vehicle in a safe and non flooded place while checking the brake effectiveness. Then, ask Maruti Suzuki authorized workshop to check the following inspection items.

- Function of brake
- Function of electrical components
- Changes of oil level and quality for engine, transmission and differential. In case that the oil is turbid whitely, water has been mixed in the oil and an oil change is required.
- Lubricant condition of the bearings, suspension joints, etc.

NOTICE

Avoid driving in a flooded area or a deep puddle. It may cause an engine stall, short in electrical components, engine and transmission damages, etc.


ADVICE FOR YOUR DRIVING

Highway Driving

When driving at highway speeds, pay attention to the following:


- Stopping distance progressively increases with vehicle speed. Apply the brakes far enough ahead of the stopping point to allow for the extra stopping distance.
- On rainy days, hydroplaning can occur. Hydroplaning is the loss of direct contact between the road surface and the vehicle's tyres due to a water film forming between them. Steering or braking the vehicle during hydroplaning can be very difficult, and loss of control can occur. Keep speed down when the road surface is wet.
- At high speeds, the vehicle may be affected by side winds. Therefore, reduce speed and be prepared for unexpected buffeting, which can occur at the exits of tunnels, when passing by a cut of a hill, or when being overtaken by large vehicles, etc.

Driving on Hills Manual transmission vehicles



55T060010


Automatic transmission vehicles



74TB06001

ADVICE FOR YOUR DRIVING

Auto Gear Shift vehicles



55T060020

- When driving on steep hills, the vehicle may begin to slow down and show a lack of power. If this happens, you should shift to a lower gear so that the engine will again be operating in its higher power range. Shift rapidly to prevent the vehicle from losing momentum.
- When driving down a hill, the engine should be used for braking by shifting to the next lower gear.

⚠ WARNING

Do not hold the brake pedal down too long or too often while going down a steep or long hill. This could cause the brakes to overheat, resulting in reduced braking efficiency. Failure to take this precaution could result in loss of vehicle control.

NOTICE

When descending a downhill, Never turn the ignition key to “LOCK” position or press the engine switch to change the ignition mode to LOCK (OFF). Emission control system damage may result.

Off-road Driving

Do not Drive in the Field Covered with Grown Grass



69RHS181

Do not drive in the field covered with grown grass. If you drive in the field covered with grass, it may cause accident or fire or vehicle damage by getting caught in grown grass.

⚠ WARNING

If loose grass, etc. becomes entangled in drive train parts or exhaust pipes, drive train components might become damaged or fire may result.

ADVICE FOR YOUR DRIVING

Improving Fuel Economy

NOTE:

Fuel economy (mileage) of the vehicle may vary due to several factors i.e. driving habits-gear change pattern, usage of A.C, Air pressure in the tyres, wind speed, traffic conditions, fuel quality-non adulterated standard fuel, maintenance of vehicle, road conditions, braking etc.

The following instructions will help you improve fuel economy.

Keep Tyre Pressures Correct

Under-inflation of the tyres can waste fuel due to increased running resistance of the tyres. Keep your tyres inflated to the correct pressure shown on the label on the driver's side door or the driver's door lock pillar.

Keep Weight to a Minimum

The heavier the load is, the more fuel the vehicle consumes. Unload any unnecessary luggage or cargo.

Avoid Excessive idling

If you park your vehicle for more than one minute, stop the engine and start it again later. When warming up a cold engine, do not allow the engine to idle or apply full throttle until the engine has reached operating temperature. Allow the engine to warm up by driving.

Avoid Fast Starts, Rapid Acceleration and Hard Braking

Avoid fast starts

Fast starts away from lights or stop signs will consume fuel unnecessarily and shorten engine life. Start off slowly.

Avoid unnecessary stops

Avoid unnecessary deceleration and stopping. Try to maintain a moderate, steady speed whenever possible. Slowing down and then accelerating again uses more fuel.

Keep a steady cruising speed

Drive at a constant speed that road and traffic conditions will permit.

Do not Race the Engine



69RHS060

Revving the engine only consumes extra fuel and has no benefit.


NOTICE

Immediately after starting, the engine is often not yet fully warmed up. Therefore, revving the engine, starting to drive suddenly, or rapid acceleration can cause engine failure.

Drive with an Appropriate Gear for Vehicle Speed

Running the vehicle at a high engine rotation speed by using a low-speed gear will result in poor fuel economy. Use the correct gear according to the vehicle speed.

Keep the Air Cleaner Clean



59RN06050

If the air cleaner is clogged with dust, there will be greater intake resistance, resulting in decreased power output and increased fuel consumption.

Stuck Vehicle

If your vehicle gets stuck in snow, mud or sand, follow the directions below:

- Shift the transmission back and forth between a forward range (or first gear for manual transmission) and reverse. This will create a rocking motion which may give you enough momentum to free the vehicle. Press gently on the accelerator to keep wheel spinning to a minimum wheel rpm. Remove your foot from the accelerator while shifting. Do not race the engine. Excessive wheel spin will cause the tyres to dig deeper, making it more difficult to free the vehicle.

NOTE:

You may have to turn the ESP® system off in order to allow spinning the wheels.

- If your vehicle remains stuck after a few minutes of rocking, we recommend you to consult a Maruti Suzuki authorized workshop or a roadside assistance service. If a towing service is not available in an emergency, your vehicle may be temporarily towed by a towing cable or chain secured to the towing eye either on the front or rear of the vehicle. Refer to "Towing by Using Towing Eye" in the "EMERGENCY SERVICE" section.

! WARNING

- Do not allow anyone to stand near the vehicle when you are rocking it, and do not spin the wheels faster than an indicated 40 km/h on the speedometer. Personal injury and/or vehicle damage may result from spinning the wheels too fast.



55T060070

- In addition to following the driving tips in this section, it is important to observe the following precautions.
 - Check that your tyres are in good condition and always maintain the specified tyre pressure. Refer to "Tyres" in "INSPECTION AND MAINTENANCE" section for details.

(Continued)

⚠ WARNING

(Continued)

- Do not use tyres other than those specified by Maruti Suzuki. Never use different sizes or types of tyres on the front and rear wheels. For information regarding the specified tyres, refer to the tyre information label located on the driver's door lock pillar.
- Never use oversized tyres or special shock absorbers and springs to raise (jack up) your vehicle. This will change the handling characteristics. Oversized tyres may also rub against the fender over bumps, causing vehicle damage or tyre failure.
- After driving through water, test the brakes while driving at a slow speed to see if they have maintained their normal effectiveness. If the brakes are less effective than normal, dry them by repeatedly applying the brakes while driving slowly until the brakes have regained their normal effectiveness.

NOTICE

Do not continue rocking the vehicle for more than a few minutes. Prolonged rocking can cause engine overheating or transmission damage.

Precaution for Handling Vehicle

Do not Apply Strong Force to Exterior Parts

NOTICE

Do not apply strong force to the body panel, spoiler, front and rear bumper, side skirts, etc. These forces can cause damage to these exterior parts.

Be Careful of Uneven Road Surface

NOTICE

In the following cases, the bumper or the lower part of the vehicle could get damaged. Ensure proper care.

- Entering the areas where there is uneven road surface, such as road shoulder
- Driving on roads with grooves, bumps or potholes

Do not Modify Your Vehicle Illegally



69RHS184

⚠ WARNING

- If you modify your vehicle illegally, there is a danger of a fire or an accident. Illegal modifications might adversely affect handling, performance or durability. Also, this could even violate laws and ordinances.

Do not install unsuitable parts to your vehicle or do not make your own adjustments or wiring.

(Continued)

⚠ WARNING

(Continued)

- Do not use wheels or wheel nuts other than specified Maruti Suzuki genuine products. Doing so could lead to accidents, such as nuts loosening and the wheel coming off while driving. Also, fuel consumption and driving stability could worsen, or it could result in other malfunctions.

NOTICE

(Continued)

- Only a troubleshooting device designed for inspection and maintenance for this model can be connected to the vehicle's onboard diagnostics system. Connecting a device other than that specified could hinder the functioning of electronic components and cause battery runout, etc.

NOTICE

- When installing or removing electrical equipment such as radio equipment, navigation, audio equipment or electronic toll control equipment, consult with a Maruti Suzuki authorized workshop. Also, do not operate electrical equipment directly from the battery terminals or connect ground wires directly. Otherwise, there is a danger of hindering the functioning of electronic components, causing fire, malfunction, battery runout, etc.

(Continued)

When Installing, Removing and Repairing Parts**⚠ WARNING**

The SRS airbag system and the seat belt pretensioner system could activate unexpectedly or could be rendered ineffective if the parts that affect their functions are adjusted or arranged. In the following cases, these systems will be adversely affected. Consult with a Maruti Suzuki authorized workshop beforehand.

- When removing the steering wheel and conducting repairs around the steering wheel, etc.
- When conducting repairs around the center console, around the instrument cluster, under the front seats or to electrical wiring
- When installing audio equipment, etc.
- When conducting sheet metal painting or repairs around the dashboard
- When replacing the front seats or conducting repairs around the seats
- Repairs around the front pillar, the back pillar or the roof side
- When conducting repairs around the center pillar

ADVICE FOR YOUR DRIVING

Be Careful When Placing Accessories



69RHS185

⚠ WARNING

Do not attach accessories to the window glasses. Accessories and suction cups could hinder vision, or a suction cup could act as a lens and cause a fire. Also, if an airbag is activated, such accessories could be ejected outward within the vehicle, possibly resulting in injury.

When Spilling Drinks or Liquids

⚠ WARNING

Do not allow liquids to spill, splash or spray inside the vehicle. The following items could malfunction, or fire could result. In the case of spilling drinks, etc., promptly consult with a Maruti Suzuki authorized workshop.

- SRS airbag system
- Audio equipment
- Electrical parts such as switches and wiring
- Movable parts such as the gearshift lever or seat belt buckles

NOTICE


The sensor of the seat belt reminder is built into the front passenger's seat cushion.

If you spill liquid such as soft drinks or juice, the sensor of the seat belt reminder may be damaged.

If you spill any liquid on the seat cushion, immediately wipe it with a soft cloth.

When Replacing Engine Oil

Replace engine oil regularly



54M3143

- For K12N(DOHC) Engine-If the vehicle is normally used, replace the engine oil and filter every 15,000 km or every 12 months, whichever is earlier.
- For K10C(DITC) Engine-If the vehicle is normally used, replace the engine oil and filter every 10,000 km or every 12 months, whichever is earlier.
- When the vehicle is used under severe driving conditions, the engine oil and filter replacement is required earlier than the case that the vehicle is normally used.

NOTICE


Observe the periods designed for the engine oil and filter replacement. Degraded oil or clogged filters can cause engine malfunction or abnormal noise. For replacement, consult with a Maruti Suzuki authorized workshop.

Specification and viscosity of engine oil

As performance factors such as fuel consumption depend on the engine oil used, use oil that satisfies the specifications in the following Table 1 and Table 2. Using Maruti Suzuki genuine oil is recommended.

Table 1

Specification	Oil quality
API(*1) / ILSAC(*2)	SP / GF-6



**Table 2
For K12N(DOHC) Engine
For India**

Specification	All vehicles
Viscosity: SAE(*3)	0W-16

Except For India

Specification	All vehicles
Viscosity: SAE(*3)	0W-20, 5W-30,0W-16

**For K10C(DITC) Engine
For India**

Specification	All vehicles
Viscosity: SAE(*3)	5W-30

Except For India

Specification	All vehicles
Viscosity: SAE(*3)	5W-30,10W-30, 10W-40

*1: The API standard is determined by the American Petroleum Institute and represents the quality grade of engine oil.

*2: The ILSAC standard is an engine oil standard for automobiles, established by the International Lubricant Specification Advisory Committee, and is based on the API standard while indicating

even higher performance specifications such as for fuel conservation and durability.

*3: SAE viscosity is a standard that determines the viscosity of lubricating oil. The number on the left side (the number with a "W") means the viscosity at low temperature. The smaller this figure is, the stronger the oil resistance to coldness is and the better the engine start capability is. The number on the right side means the viscosity at high temperature. The larger this figure is, the stronger the oil resistance to heat is and the better the engine protection performance is.

ADVICE FOR YOUR DRIVING


Running-in

NOTICE

The future performance and reliability of the engine depends on the care and restraint exercised during its early life. It is especially important to observe the following precautions during the first 960 km of vehicle operation.

- After starting, do not race the engine. Warm it up gradually.
- Avoid prolonged vehicle operation at a constant speed. Moving parts will break in better if you vary your speed.
- Start off from a stop slowly. Avoid full throttle starts.
- Avoid hard braking, especially during the first 320 km of driving.
- Do not drive slowly with the transmission in a high gear.
- Drive the vehicle at moderate engine speeds.
- Do not tow a trailer during the first 960 km of vehicle operation.

Catalytic Converter



The purpose of the catalytic converter is to minimize the amount of harmful pollutants in your vehicle's exhaust. Use of leaded fuel in vehicles equipped with catalytic converters is prohibited, because lead deactivates the pollutant-reducing components of the catalyst system.

The converter is designed to last the life of the vehicle under normal usage and when unleaded fuel is used. No special maintenance is required on the converter. However, it is very important to keep the engine properly tuned. Engine misfiring, which can result from an improperly tuned engine, may cause overheating of the catalytic converter. This may result in permanent heat damage to the catalytic converter and other vehicle components.

NOTICE

To minimize the possibility of catalytic converter or other vehicle damage:

- Maintain the engine in the proper operating condition.
- In the event of an engine malfunction, particularly one involving engine misfire or other apparent loss of performance, have the vehicle serviced promptly.
- Do not turn off the engine or interrupt the ignition when the transmission is in gear and the vehicle is in motion.
- Do not try to start the engine by pushing or towing the vehicle, or coasting down a hill.
- Do not idle the engine with any spark plug wires disconnected or removed, such as during diagnostic testing.
- Do not idle the vehicle for prolonged periods if idling seems rough or there are other malfunctions.
- Do not allow the fuel tank to get near the empty level.



59RN06060

⚠ WARNING

Be careful where you park and drive; the catalytic converter and other exhaust components can get very hot. As with any vehicle, do not park or operate this vehicle in areas where combustible materials such as dry grass or leaves can come in contact with a hot exhaust system.

When Driving Hybrid Vehicle

For economical and ecological driving, pay attention to the following points:

Shift lever operation

Shift the shift lever to D when stopped at a traffic light, or driving in heavy traffic etc.

Shift the shift lever to P when parking.

When using the N, there is no positive effect on fuel consumption.

In the N, the gasoline engine operates but electricity cannot be generated.

Also, when using the air conditioning system, etc., the hybrid battery (traction battery) power is consumed.


Warming up before driving

Since the gasoline engine starts up and cuts out automatically when cold, warming up the engine is unnecessary. Moreover, frequently driving short distances will cause the engine to repeatedly warm up, which can lead to excess fuel consumption.

Accelerator pedal/brake pedal operation

- Drive your vehicle smoothly. Avoid abrupt acceleration and deceleration. Gradual acceleration and deceleration will make more effective use of the electric motor (traction motor) without having to use gasoline engine power.
- Avoid repeated acceleration. Repeated acceleration consumes hybrid battery (traction battery) power, resulting in poor fuel consumption. Battery power can be restored by driving with the accelerator pedal slightly released.

OTHER CONTROLS AND EQUIPMENT



60G407

7

Fuel Filler Opening	7-1
Refueling	7-2
Hood	7-4
Sun Visor	7-6
Interior Light	7-7
Accessory Socket	7-10
Drink Holder	7-11
Storage Area	7-12
Assist Grips	7-14
Footrest	7-15
Door Pocket	7-15
USB Socket (if equipped)	7-16
USB Charging Socket (if equipped)	7-16
Front Seatback Pocket (if equipped)	7-17
Luggage Compartment Hook	7-17
Luggage Compartment Cover (if equipped)	7-17
Heating and Air Conditioning System	7-18
Automatic Heating and Air Conditioning System (Climate Control)	7-20
Installation of Radio frequency Transmitters	7-27
Audio Function	7-27
Remote Audio Controls (if equipped)	7-28
Suzuki Connect (if equipped)	7-29
Roof Rail	7-30
Wireless Charger (if equipped)	7-30

OTHER CONTROLS AND EQUIPMENT

Fuel Filler Opening

Make sure to read "Refueling" in this section.


⚠ WARNING

Be sure to observe the following points when refueling. Otherwise, gasoline may catch a fire from fuel and it may cause a fire.

- Always stop the engine first.
- Close all the doors and windows when refueling.
- As gasoline is highly flammable, open sparks such as lit cigarettes are strictly prohibited.

A fuel filler door is located on the left rear side of the vehicle. The fuel filler door can be unlocked by pulling up the opener lever (1) located on the outboard Position of instrument Panel and locked by simply closing the door.


Fuel Filler Cap




57L51093

- To open the fuel filler cap, turn it counter-clockwise.
- To close the fuel filler cap, turn it clockwise until you hear more than 2 clicks.

Fuel Filler Door



55TB07002



74TB07005

NOTE:

The cap holder (1) holds the fuel filler cap (2) by hooking the groove (3) when refueling.

⚠ WARNING

- If you open the fuel filler cap suddenly, fuel may be under pressure and may spray out. Loosen the fuel filler cap slowly. After air deflating sound stops, open the fuel filler cap.
- If fuel spills out, an accident such as a fire may occur. Also, if you leave spilled fuel as it is, it may cause paint staining, discoloration or cracking. Be careful not to spill out fuel. If you spill it out, wipe it off with a soft cloth.
- If the fuel filler cap is not closed securely, it may cause fuel leakage or a fire. After refueling, close the fuel filler cap until you hear more than 2 clicks.
- If you use the fuel cap other than a genuine Maruti Suzuki cap, it may cause fuel leakage. Do not use the fuel cap other than a genuine Maruti Suzuki cap.

Refueling**Watch Out for Fire**

69RHS186

⚠ WARNING

Be sure to observe the following points when refueling. Otherwise, gasoline may catch a fire from fuel and it may cause a fire.

- Always stop the engine first.
- Close all the doors and windows when refueling.
- As gasoline is highly flammable, open sparks such as lit cigarettes are strictly prohibited.

When Refueling at a Self-service Gas Station**⚠ WARNING**

When refueling at a self-service gas station, be sure to observe the following points.

- If substantial static electricity is accumulated within your body, a spark could ignite fuel vapors and possibly cause burns. Before opening the fuel filler cap, discharge any static electricity* that might have accumulated in your body, by touching a metal part of the vehicle body or the gas pump machine. In addition, do not re-enter the vehicle while refueling, as static electricity could be charged to your body again.
- Do not allow others who have not discharged their static electricity to come close to the fuel filler opening.

*Take special care when air is dry, as this can cause your body to become charged with static electricity more easily. In addition, wearing layers of clothing can generate static electricity due to the friction of the fibers.

(Continued)

OTHER CONTROLS AND EQUIPMENT

⚠ WARNING


(Continued)

- If you open the fuel filler cap suddenly, fuel may be under pressure and may spray out. Loosen the fuel filler cap slowly. After air deflating sound stops, open the fuel filler cap.
- If you do not insert the fuel filler nozzle securely into the fuel filler opening, fuel may spill out. Insert the fuel filler nozzle securely into the fuel filler opening until it stops.
- Pull the gas pump filler nozzle lever until it stops.

(Continued)

⚠ WARNING

(Continued)



69RHS070

- If you continue to refuel after the automatic stop to top up the tank, fuel could overflow. When the automatic stop function of gas pump filler nozzle is activated, stop refueling.

*Depending on the type of gas pump machine being used, the automatic stop function could activate early and refueling might not be possible. Please follow the instructions of the employees at the gas station.

(Continued)

⚠ WARNING

(Continued)

- If fuel spills out, an accident such as a fire may occur. Also, if you leave spilled fuel as it is, it may cause paint staining, discoloration or cracking. Be careful not to spill out fuel. If you spill it out, wipe it off with a soft cloth.
- If the fuel filler cap is not closed securely, it may cause fuel leakage or a fire. After refueling, return the fuel filler nozzle to its original position and close the fuel filler cap until you hear more than 2 clicks.
- Fuel contains substances harmful to the human body. Do not breathe in vaporized fuel.
- In addition, be sure to observe all the warnings posted at the gas station.

Use Unleaded Gasoline Only

NOTICE

Using leaded gasoline, low-quality gasoline or other types of fuel (such as alcohol and diesel oil) can cause harmful effects to the engine and fuel delivery system. Do not use fuel other than unleaded gasoline.

Hood

⚠ WARNING

- As the hood is heavy, if a child tries to open or close it, the child may get injured. Do not allow a child to open or close the hood.
- As the engine compartment becomes hot, it may cause burns. When opening the hood, do not allow a child to come close to the hood.
- If you leave any tool or cloth in the engine compartment, it may cause a malfunction. Also, as the engine compartment becomes hot, it may result in vehicle fire. Do not leave any tool or cloth for inspection or cleaning in the engine compartment.

⚠ CAUTION


If you come close to a running drive belt or a cooling fan (radiator fan), hands, hair, clothing, etc. may be caught and you may get injured. When the engine is running, keep away from the drive belt or the cooling fan (radiator fan).

Opening the Hood



55TB07005

- Pull up the hood release lever (1) located under the driver's side instrument panel in the outboard position (Left of the fuel lever). This will disengage the hood lock halfway.



55TB07006

- Push the under-hood release lever (2) sideways with your finger, as shown in the illustration. While pushing the lever, lift up the hood.

⚠ CAUTION


The under-hood release lever can be hot enough to burn your finger while the engine is running or right after the engine stopped.

If you try to open the hood while the engine is running or right after the engine stopped, touch the under-hood release lever after it becomes cool enough.

NOTICE

If you lift up the hood with the wiper arms raised, the wiper arms and the hood may get damaged.
Do not lift up the hood with the wiper arms raised.

OTHER CONTROLS AND EQUIPMENT



55TB07007

- 3) While holding the hood, pull the prop rod (3) out from the holding clip (4), and then insert the end of the rod into the designated hole (5).


⚠ CAUTION

- The prop rod can be hot enough to burn your finger while the engine is running or right after the engine stopped. If you would like to use the prop rod while the engine is running or right after the engine stopped, touch the prop rod after it becomes cool enough.
- If the prop rod slips out, you may get caught in the closing hood. Insert the end of the prop rod into the hole securely.
- The prop rod may slip out when the hood is blown by wind. If this occurs, you may get caught in the closing hood. Be very careful when you open the hood on a windy day.

NOTE:

When you pull out the prop rod from the holding clip, hold the ✕ part.

Closing the Hood



55TB07008

- 1) Lift up the hood slightly and remove the prop rod from the hole. Put the prop rod back into the holding clip.
- 2) Lower the hood to about 20 cm above the hood latch, and then let it drop down. Check that the hood is securely latched after closing.

⚠ WARNING


If the hood is not fully closed, it can fly up unexpectedly during driving, obstructing your view and resulting in an accident. Check that the hood is fully closed and latched before driving.

CAUTION

When closing the hood, the occupant's body such as hands may get caught in the hood and get injured. Also, pushing on the hood from the top may damage it.


When closing the hood, check that no part of the occupant's body such as hands is in the path of the hood.

Sun Visor



The sun visors can be pulled down to block glare coming through the windshield, or they can be unhooked and turned to the side to block glare coming through the side window.

Card Holder (if equipped)



- (1) Hook
- (2) Mirror cover
- (3) Card holder


You can put a card in the card holder (3) on the back of the sun visor.

NOTICE

If you park your vehicle outdoors in direct sunlight in hot weather, the inside of the vehicle will become hot. The heat may distort or crack a card. When you park your vehicle outdoors in direct sunlight or in hot weather, do not leave plastic cards in the card holder.

OTHER CONTROLS AND EQUIPMENT

Vanity Mirror (if equipped)



70K178

(4) Vanity mirror

To use the vanity mirror (4) on the back of the sun visor, pull up the mirror cover (2).

⚠ WARNING


- If you use the vanity mirror while driving, you may lost control of the vehicle, resulting in an accident. Do not use the vanity mirror while driving.
- Do not place any object on the location where an airbag is stored or come close to the location where airbag is stored, when using a vanity mirror. Doing so may cause the airbag to deploy and cause serious injury due to the impact of airbag.

Interior Light

NOTICE

If you turn on the interior light for a long time with the engine stopped, the lead-acid battery may discharge. Do not turn on the interior light for a long time with the engine stopped.

Front (if equipped)



55T070010

Push the switch to turn on the light and push it again to turn off the light.


NOTE:

If your vehicle is equipped with the keyless push start system or the keyless entry system, the light will automatically be turned off to prevent the lead-acid battery from discharging when the following conditions are simultaneously met:

- The ignition switch is in the "LOCK" position, or the ignition mode is "LOCK" (OFF).

- The hazard warning lights, the position lights and the headlights are off.
- After 15 minutes of the light on.

Center



55T070020

This light switch has three positions which function as described below:

ON (a)

The light comes on and stays on regardless of whether the door is open or closed.

NOTE:

If your vehicle is equipped with the keyless push start system or the keyless entry system, the light will automatically be turned off to prevent the lead-acid battery from discharging when the following conditions are simultaneously met:

- The ignition switch is in the "LOCK" position, or the ignition mode is "LOCK" (OFF).


- The hazard warning lights, the position lights and the headlights are off.
- After 15 minutes of the light on.

DOOR (b)


- The light comes on when the door is opened. After closing all doors, the light will remain on for 15 seconds and then fade out. If you insert the key, or press the engine switch to change the ignition mode to "ACC" or "ON" during this time, the light will start to fade out immediately. After removing the key from the ignition switch or press the engine switch to change the ignition mode to "LOCK" (OFF), the light will turn on for 15 seconds and then fade out.
- When the ignition switch is in LOCK position, or the ignition mode is "LOCK" (OFF), to prevent the lead-acid battery from discharging, the light will automatically be turned off when a period of 15 minutes has elapsed after any of the doors (including the tailgate) is opened and other operations are not done.

OFF (c)

The light remains off even when the door is opened.

**Luggage Compartment Light
(if equipped)**

68PM00510



68PM00511

When you open the tailgate with the luggage compartment light switch in the "ON" position (1), the light comes on for about 15 minutes.


When the luggage compartment light switch is in the "OFF" position (2), the light remains off regardless of whether the tailgate is open or close.

NOTE:

The number of doors involved in the lighting operation of the interior light depends on the vehicle specification. If there is a switch (rubber protrusion) at the door opening as shown, the door is involved in the lighting operation. The tailgate is also involved in this operation even without the rubber protrusion.

OTHER CONTROLS AND EQUIPMENT

Vanity Mirror Light (If equipped)



55T070030

The vanity mirror light (1) comes on when the mirror cover is opened.

Courtesy Lights (If equipped)



55T070490

Each front door has a courtesy light on its inside bottom. It lights automatically when the door is opened.

NOTE:

If you leave any door open, the light will automatically be turned off after about 15 minutes to prevent the battery from discharging.

Front Footwell Lights (If equipped)



55TB07009

A footwell light is provided in the leg space in front of each front seat. The light comes on when the door is opened. After closing all doors, the light will remain on for about 15 seconds and then fade out. If you turn the ignition switch to "ACC" or "ON" position or press the engine switch to change the ignition mode to ACC or ON during this time, the light will start to fade out immediately.

NOTE:

- You can change the footwell lights operation via the information display. Refer to "Information Display" in the "INSTRUMENT CLUSTER" section.
- The light will automatically be turned off to prevent the lead-acid battery from discharging when all of the following conditions are simultaneously met for 15 minutes or more:
 - The ignition switch is in the "LOCK" position, or the ignition mode is LOCK (OFF).
 - If footwell lights setting mode is in lighting control mode and headlamp or position lamp is off.
 - If any door is open.

Glove Box Light (If equipped)

Refer to "Glove Box" in this section.

Accessory Socket

Center Console



55TB07010

or the engine switch is in ACC or ON mode.

This socket can be used to provide 12 volt/120 watt/10 ampere power for electrical accessories. Check that the rubber cap remains on the socket when the socket is not in use.

When using the accessory socket, open the rubber cap (1).

NOTICE

- To prevent the fuse from being blown, when using sockets at the same time, do not exceed the total combined power capacity of 12 volt/120 watt/10 ampere.
- Use of inappropriate electrical accessories can cause damage to your vehicle's electrical system. Check that any electrical accessories you use are designed to plug into this type of socket.
- Check that the cap remains on the socket when the socket is not in use.
- When the ignition switch is in "LOCK" position or the ignition mode to LOCK (OFF) during using the accessory socket, the following accidents may occur;

- the audio or navigation system does not turn off.
- the keyless entry system does not work, etc.

If they occur, disconnect the item from the accessory socket and check whether the electrical equipments work properly.

If the problem persists, ask a Maruti Suzuki authorized workshop to have the system inspected.

Floor Console (if equipped)




55TB07011

The accessory socket will work when the ignition switch is in "ACC" or "ON" position

OTHER CONTROLS AND EQUIPMENT

Drink Holder

Floor Console




55T070070

(1) Floor console drink holder


Door

Front



55T070080

Rear



55T070090

(2) Bottle holder

NOTE:


Maruti Suzuki recommends to use maximum 1 liter capacity of bottle.

WARNING

- Be careful and use a lid for a drink not to spill out liquid. Spilling out hot liquid can cause burn injury. In addition, if liquid spills out on the following parts, it may cause a fire or a malfunction and an airbag system may not work properly.
 - Navigation system, audio system or the relevant switches
 - Wiring or electrical components under the floor
 - Moving part of the gearshift lever or the seatbelt buckle
- If you place a long drink container, sharp-edged, hard or breakable objects in the drink holders, these objects may be thrown out, resulting in personal injury and hindering your view. In the driver's side drink holder or the front passenger's side drink holder, you can place a can, a cup or a plastic bottle.
- Do not place a long drink container in the driver's side drink holder. The container may hinder your view, resulting in an accident.

NOTE:

- If you place the keyless remote controller in a drink holder or a bottle holder, it may not be detected.
- If you spill or drop liquid accidentally, have your vehicle inspected by a Maruti Suzuki authorized workshop.

Storage Area

74TB07001

- (1) Glove box
- (2) Floor console tray
- (3) Driver's side pocket
- (4) Front armrest with console box (if equipped)

Each item in the figure is a typical example; the actual equipment depends on the vehicle type.

OTHER CONTROLS AND EQUIPMENT

⚠ WARNING

- If any object gets caught in the brake pedal or the accelerator pedal, you may not operate the pedal properly, resulting in an accident. If you use a storage area without a lid, do not place the object which may fall out while driving.
- If there is any object within the area where the front passenger's airbag could inflate, the object may be thrown out or the front passenger's airbag may not inflate properly. Do not place a big object on the instrument panel tray.

⚠ CAUTION


If you use a storage area with a lid, do not drive the vehicle with the lid open. In acceleration, a sudden braking or an collision, your body may be hit by the lid or the object which falls out from the storage area.

NOTE:


If you place the keyless remote controller in any of storage areas, it may not be detected.

Using Storage Area with a Lid

Glove box



74TB07002



55T070050


The glove box light (If equipped) stays on while the lid is open.

- To open the glove box, pull the latch lever (1).
- To close it, push the lid until it is latched securely.

⚠ WARNING

- Never drive with the glove box lid open. It could cause injury if an accident occurs.
- Do not leave cigarette lighters or spray cans in the glove box. If a cigarette lighter or spray can is in a place such as the glove box, it may light accidentally when luggage is loaded, causing a fire.

Front armrest with console box (if equipped)



55T070650

Use this stowage for keeping small items. Open the compartment by raising the top lid while keeping the lever (1) up.


NOTICE

To avoid damage to the armrest, do not lean on it or allow a child to sit on it.

NOTE:

Always close the lid after you put something into or take something out of the box.

Assist Grips




80J1233

Assist grips are provided for convenience. Pull the assist grip (1) towards you.

NOTICE

To avoid damaging the assist grip and the molded headlining, do not hang down the assist grip.

Coat Hooks



55T070060

You can hang clothing on the coat hooks. These hooks are not designed for large or heavy items and are located with rear right assist grip.

! WARNING

If your vehicle is equipped with side curtain airbags, do not hang sharp items like a hanger on the coat hook. When hanging the clothes, hang them on the hook without using a hanger.


NOTICE

To avoid breaking the hook, do not hang items heavier than the following weight.

Coat hook: 2 kg

OTHER CONTROLS AND EQUIPMENT


Footrest



Use the footrest as a support for your left foot only.

Door Pocket

Front



Rear



Each pocket is provided for holding light and soft things such as gloves, newspapers or magazines.


CAUTION

- If an accident occurs, objects such as bottles, cans, etc. in the door pocket can injure the occupants. Do not put hard or breakable objects in the door pocket.
- If you grab and pull the door pocket, it may be broken, resulting in personal injury. When closing a door, do not grab and pull the door pocket.

NOTE:

If you place the keyless remote controller in a door pocket, it may not be detected.

USB Socket (if equipped)



74TB07003

Open the cover (1), and then connect your portable digital music player, etc. to this socket to enjoy music through the vehicle's audio system. Refer to the supplementary manual for details.

⚠ WARNING

If foreign material enters the USB socket, a malfunction or a short circuit may occur.

Always close the cover when the USB socket is not in use.

USB Charging Socket (if equipped)


When the ignition switch is in "ACC" or "ON" position, or the ignition mode is ACC or ON, you can charge your mobile device such as your smart phone by using the connecting cable (commercial item).

Left side socket (1)

The standard capacity is 5 V / 2.4 A (12 W) for one socket and USB Type-A can be used.

Right side socket (2)

The standard capacity is 5 V / 3.0 A (15 W) for one socket and USB Type-C can be used.



55TB070390

Open the cover to use the USB charging socket.

⚠ WARNING

When the USB charging socket is not in use, close the cover. If any foreign material enters the USB charging socket, it may cause a malfunction or short circuit.

NOTICE


Do not charge your mobile device for a long period of time, while the engine is stopped. Otherwise, the lead-acid battery may run out.

NOTE:

- The USB charging socket should be used only for charging.
- For some models, charging may pause. However, this is not a malfunction.
- Depending on the vehicle conditions such as the following examples, charging may temporarily pause.
 - When the inside temperature of the vehicle is high after parking the vehicle under the blazing sun
 - When the engine is started

OTHER CONTROLS AND EQUIPMENT

Front Seatback Pocket (if equipped)




55T070210

This pocket is provided for holding light and soft things such as gloves, newspapers or magazines.

CAUTION

- If an accident occurs, objects such as bottles, cans, etc. can injure the occupants in the rear seat. Do not put hard or breakable objects in the pocket.
- If you put sharp or heavy objects in the pocket, the seat may be damaged. Do not put sharp or heavy objects in the pocket.

Luggage Compartment Hook



55T070630

You can hang the shopping bag or other suitable objects on the hook. This hook is not designed for large or heavy items.

NOTICE

To avoid breaking the hook, do not hang items heavier than the following weight.
Shopping hook: 1 kg

Luggage Compartment Cover (if equipped)



55TB07013


Luggage or other cargo placed in the luggage compartment is hidden from view by a luggage compartment cover.

WARNING

Do not carry items on top of the luggage compartment cover, even if they are small and light. Objects on top of the cover could be thrown about in an accident, causing injury, or could obstruct the driver's rear view.


Heating and Air Conditioning System

Air Outlet



1. Windshield defroster outlet
2. Side defroster outlet
3. Side outlet
4. Center outlet
5. Floor outlet
6. Rear outlet (if equipped)

Center outlet




Move the knob (1) vertically or horizontally to adjust the direction of airflow as desired.

CAUTION

Prolonged exposure to hot air from the heater or air conditioner could result in low temperature burns. All vehicle occupants, particularly children, the elderly, those with special needs, individuals with delicate skin, and sleeping individuals, should maintain sufficient distance from the air outlets to prevent prolonged exposure to hot airflow.

OTHER CONTROLS AND EQUIPMENT


Side outlet and rear outlet (if equipped)



74TB07004

CAUTION

Prolonged exposure to hot air from the heater or air conditioner could result in low temperature burns. All vehicle occupants, particularly children, the elderly, those with special needs, individuals with delicate skin, and sleeping individuals, should maintain sufficient distance from the air outlets to prevent prolonged exposure to hot airflow.



55T070120


NOTE:

- For side outlet, if the front door windows are fogged, adjust to direct wind from the side outlets towards the front door windows. This will allow you to remove fog more quickly.
- The airflow from the rear outlet can be increased by fully moving the center outlet knob (1) to the inner side.

When open, air comes out regardless of the air flow selector position. Move the knob (2) vertically or horizontally, to adjust the direction of airflow as desired. The side outlet opens when you turn the dial (3) upward and closes when you turn it downward.

Automatic Heating and Air Conditioning System (Climate Control)


Description of Controls



55T070130

- (1) Temperature selector
- (2) Blower speed selector
- (3) Air intake selector
- (4) Air flow selector
- (5) Defrost switch
- (6) Air conditioning switch
- (7) "OFF" switch
- (8) "AUTO" switch
- (9) Display

Temperature selector (1)



55T070140


Push upper part or lower part of the temperature selector (1) to adjust the temperature. The display (9) shows the selected temperature.

NOTE:

If you push the temperature selector (1) until "HI" or "LO" appears on the display, the climate control system will operate at maximum heating or cooling. The temperature of the air from the outlets may change suddenly while "LO" or "HI" is displayed, but this is normal.

OTHER CONTROLS AND EQUIPMENT

Blower speed selector (2)




55T070150

The blower speed selector (2) is used to turn on the blower and to select blower speed.

If the "AUTO" switch (8) is pushed, the blower speed will vary automatically as the climate control system maintains the selected temperature.

Air intake selector (3)



55T070160

Push the air intake selector (3) to change between the following modes.

If the "AUTO" switch (8) is pushed, the air intake will vary automatically as the climate control system maintains the selected temperature.

NOTE:

When you select the recirculated air mode, the automatic operation system is deactivated if you push the "AUTO" switch (8).

RECIRCULATED AIR (a)

When this mode is selected, inside air is recirculated. At the same time, the indicator light (10) will turn on. This mode is suitable when driving through an area with polluted air such as a tunnel, or when attempting to quickly cool down the vehicle or to reduce unwanted odor from entering the vehicle.


FRESH AIR (b)

When this mode is selected, outside air is introduced. At the same time, the indicator light (10) will turn off.

The fresh air position (b) and recirculated air position (a) are selected alternately each time the air intake selector is pushed.

NOTE:


If you select the recirculated air position (a) for an extended period of time, the air in the vehicle may become contaminated. Therefore, you should occasionally select the fresh air position (b).

Air flow selector (4)

55T070170


Push the air flow selector (4) to change among the following functions. The indication of the selected mode appears on the display.

If the "AUTO" switch (8) is pushed, the air flow will vary automatically as the climate control system maintains the selected temperature.

Ventilation (c)

74TB07006

Temperature-controlled air comes out of the center, side and rear (if equipped) outlets.


Bi-level (d)

74TB07007

Temperature-controlled air comes out of the floor outlets and cooler air comes out of the center, side and rear (if equipped) outlets. When the temperature selector (1) is in the fully COLD position or fully HOT position, however, the air from the floor outlets and the air from the center, side and rear (if equipped) outlets will be the same temperature.

OTHER CONTROLS AND EQUIPMENT


Heat (e)



74TB07008

Temperature-controlled air comes out of the floor outlets and the side outlets, also comes out of the windshield defroster outlets and also comes slightly out of the side defroster outlets.


Heat and defrost (f)



74TB07009

Temperature-controlled air comes out of the floor outlets, the windshield defroster outlets, the side defroster outlets and the side outlets.


Defrost switch (5)



59RN07170

Push the defrost switch (5) to turn on the defroster. At the same time, the indicator light (11) will turn on.

Defrost




74TB07010

Temperature-controlled air comes out of the windshield defroster outlets, the side defroster outlets and the side outlets.

NOTE:

When the defrost switch (5) is pushed to turn on the defroster, the air conditioning system will come on and the fresh air position (b) will be selected automatically. In very cold weather, however, the air conditioning system will not turn on.

Air conditioning switch (6)

59RN07190

The air conditioning switch (6) is used to turn on and off the air conditioning system only when the blower is on. Push in the switch to turn on the air conditioning system. At the same time, "A/C" will appear on the display and the indicator light (12) will turn on.


Push in the switch again to turn off the air conditioning system. At the same time, "A/C" will go off and the indicator light (12) will turn off.

Models with idling stop system

When the engine is stopped automatically, the air conditioner switches to the ventilation position (a).

NOTE:

- If the cooling and heating performance is insufficient when the engine is stopped automatically, push the idling stop system OFF switch to deactivate the idling stop system. (The engine is restarted automatically, and the cooling and heating performance is restored.)
- If the windshield and/or front door windows are fogged, push the defrost switch. (When the defrost switch is pushed, the engine is restarted automatically and the defroster is turned on.)

System Operating Instructions**Automatic operation**

55T070180

You can let the climate control system work automatically. To set the system for fully-automatic operation, follow the procedure below.

- 1) Start the engine.
- 2) Push the "AUTO" switch (8).
- 3) Set the desired temperature by pushing the temperature selector (1).

The blower speed, air intake and air flow are controlled automatically to maintain the set temperature. However, the air flow is not changed to the defrost position automatically.

OTHER CONTROLS AND EQUIPMENT

NOTE:

When you select the recirculated air mode, the automatic operation system is deactivated if you push the "AUTO" switch (8).

You can use the air conditioning switch (6) to manually turn the air conditioner on or off according to your preference. When you turn the air conditioning switch off, the climate control system cannot lower the inside temperature below outside temperature.


To turn the climate control system off, push the "OFF" switch (7).

NOTE:


If the "AUTO" on the display blinks, there is a problem in the heating system and/or air conditioning system. You should have the system inspected by Maruti Suzuki authorized workshop.

NOTE:

- To find the temperature at which you are most comfortable, start with the 25°C (75°F) setting.
- If you push the temperature selector (1) until "HI" or "LO" appears on the display, the climate control system will operate at maximum heating or cooling and the blower will run at full speed.
- To avoid blowing cold air in cold weather or hot air in hot weather, the system will delay turning on the blower until warmed or chilled air is available.
- If your vehicle has been left in the sun with the windows closed, it will cool faster if you open the windows briefly.
- Even under the automatic operation, you can set individual selectors to the manual mode. The manually selected functions are maintained, and the other functions remain under automatic operation.
- If the windshield and/or the front door windows are fogged, push the defrost switch (5) to turn on the defroster, or push the air flow selector (4) to change the air flow to the heat and defrost position (f) to defog the windows.
- To return the blower speed selector (2), air intake selector (3), and air flow selector (4) to automatic operation, push the "AUTO" switch (8).



55T070340



55T070350

Be careful not to cover the interior temperature sensor (13) located on the climate control panel, or the solar sensor (14) located at the top of the driver's side dashboard. These sensors are used by the automatic system to regulate temperature.

Manual Operation

You can manually control the climate control system. Set the selectors to the desired positions.



55TB07003

NOTE:

If you need maximum defrosting, take the following procedure:

- 1) Push the defrost switch (5) to turn on the defroster (the air conditioning system will come on and the fresh air position (b) will be selected automatically).
- 2) Set the blower speed selector to HIGH.
- 3) Adjust the temperature selector to the "Hi" indication on the display.
- 4) Adjust the side outlets so the air blows on the side windows.

Maintenance

If you do not use the air conditioner for a long period, such as during winter, it may not give the best performance when you start using it again. To help maintain optimum performance and durability of your air conditioner, it needs to be run periodically. Operate the air conditioner at least once a month for one minute with the engine idling. This circulates the refrigerant and oil and helps protect the internal components.

Your air conditioner is equipped with air filters. Clean or replace them as specified in "Maintenance Schedule" in the "INSPECTION AND MAINTENANCE" section. Have this job done by a Maruti Suzuki authorized workshop as the lower glove box must be lowered for this job.

NOTE:

Your vehicle uses the air conditioning refrigerant HFC-134a, commonly called R-134a. R-134a replaced R-12 around 1993 for automotive applications. Other refrigerants are available, including recycled R-12, but only R-134a should be used in your vehicle.

NOTICE

Using the wrong refrigerant may damage your air conditioning system. Use R-134a only. Do not mix or replace the R-134a with other refrigerants.

How to Use Air Conditioning System Effectively

Parking under the blazing sun

After parking for a long time under the blazing sun, the interior temperature can become very high. Use the air conditioning system, with the windows or doors opened to ventilate the interior.

OTHER CONTROLS AND EQUIPMENT

Installation of Radio frequency Transmitters

We recommend that you always ask a Maruti Suzuki authorized workshop about frequency band, max output power, antenna position at vehicle and specific conditions for installation and/or use before installing a radio transmitter in your vehicle. Such equipments may cause the electronic control system to malfunction if they are incorrectly installed or they are not suited for the vehicle.

NOTICE

Improper installation of mobile communication equipment such as cellular telephones, CB (Citizen's Band) radios or any other wireless transmitters may cause electronic interference with your vehicle's ignition system or any other electrical systems resulting in vehicle performance problems. Consult a Maruti Suzuki authorized workshop for advice.

Audio Function

When Using Audio System with Appropriate Volume not to Disturb Safe Driving

- When playing music or other audio, if a mobile phone is used inside or nearby the vehicle, noise may be heard from the speakers. This does not indicate a malfunction.
- Navigation and audio equipment may not function properly if they are interfered with unauthorized radio waves.
- For further information about the features of the navigation or audio equipment, refer to the instruction manuals.

! WARNING

If you operate the navigation or audio equipment, you may be distracted by them, resulting in an accident.
Do not operate the navigation or audio equipment while driving.

NOTICE

While the engine is stopped, using the navigation or audio equipment for a long period of time may cause the lead-acid battery to run out.
Do not use the navigation or audio equipment for a long period of time while the engine is stopped.

NOTE:


Due to poor quality of FM/AM signal, some disturbance/noise may be heard from speakers. It is recommended to switch off the tuner system to prevent the said disturbance/noise in the speaker.

Remote Audio Controls (if equipped)

Controlling basic functions of the audio system is available using the switches on the steering wheel.

The remote audio switches are available when the engine switch is in ACC or ON mode.

- For operation of an audio system or a navigation system, refer to the supplementary manual, provided along with it.
- The operating procedure may be different depending on an audio system or a navigation system.



55TB07004

(1) Volume switch
(2) Mute switch

- (3) "MODE" switch
- (4) Select switch
- (5) Hands-free switch
- (6) Voice recognition switch

Volume Switch (1)

You can adjust volume with this switch.

- To increase the volume, press "+" side.
- To decrease the volume, press "-" side.
- The volume will continue to increase or decrease until this switch is released.

Mute Switch (2)

To mute this sound, press the switch (2).

"MODE" Switch (3)

Every time you press this switch, the audio modes such as radio, etc. will be switched in order.

Depending on a navigation system or an audio systems, you can turn on the system by pressing this switch, even when the equipment itself is turned off.

Select Switch (4)

Every time you press this switch, you can select broadcast station or music according to your preference, along with the currently selected mode.

Hands-free Switch (5)

You can use this switch for the equipment which has the hands-free function. To use the function, you need to set up for the equipment. Refer to the supplementary manual for details.

OTHER CONTROLS AND EQUIPMENT

Voice Recognition Switch (6)*

You can use this switch for the equipment which has the voice recognition function. To use the function, you need to set up for the equipment. Refer to the supplementary manual for details.

*: When using Apple CarPlay® or Android Auto™ on infotainment system

Apple CarPlay® may not be available in your country or region.

For details about Apple CarPlay, visit the following site:

<http://www.apple.com/ios/carplay>

Android Auto™ may not be available in your country or region.

For details about Android Auto, please refer to the Google support site:

<http://support.google.com/androidauto>

Suzuki Connect (if equipped)

Suzuki Connect is an advanced Telematics solution that offers Connected car features related to Vehicle Alerts & Notifications, Safety & Security, Trips & Location & Remote Vehicle Operation.

Refer to *MARUTI SUZUKI* website for below details:

1. Feature & Vehicle applicability
2. Terms & Conditions
3. FAQs
4. Suzuki Connect App Manual
5. Help & Contact us
6. Suzuki Connect Alexa Skill Manual

NOTE:

- Application services are subject to change. It is recommended to install the latest updates from Google Play/Apple App store for optimal experience.
- Application functioning is subject to network availability & also depends on Smartphone hardware & OS performance.
- Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates.

The communication device equipped with your vehicle includes free/open source software.

The license information and/or source code for free/open source software is available at the following URL:

<https://www.denso-ten.com/support/source/oem/sg1/>

Roof Rails



55TB07016

NOTICE


Do not load cargo on roof. The roof garnish is not intended for load carriage and it is for aesthetics only.

Wireless Charger (if equipped)

Smart phone equipped with wireless charging function, can be charged by placing it on the charging area, provided the device is Qi certified as per Wireless Power Consortium. Wireless Charger can support only one smart phone at a time. The Wireless Charger cannot be used with a smart phone that is larger than the charging area. Additionally, depending on the smart phone, the Wireless Charger may not operate properly. Refer to the operation manual of the smart phone.

Wireless charger uses inductive charging technology to charge the smart phones. Inductive charging system are less efficient than conventional charging through cable. As a result, user may experience higher device temperature during charging.

The “Qi” Symbol



55TB07018

The “Qi” symbol is a trademark of the Wireless Power Consortium.

- 1) Wireless charger
- 2) Indicator light



55TB07015

OTHER CONTROLS AND EQUIPMENT

⚠ WARNING

Caution while driving

- When charging a smart phone while driving, for safety reasons, the driver should not operate the portable device.

Caution regarding interference with Electronic Devices

- People with implantable cardiac pacemakers, cardiac resynchronization therapy pacemakers or implantable cardioverter defibrillators, as well as any other electrical medical device, should consult their physician about the usage of the Wireless Charger. Operations of the Wireless Charger may have an affect on medical devices.

(Continued)

⚠ WARNING

(Continued)

To prevent damage or burns

- Observe the following precautions. Failure to do so may result in the possibility of fire, equipment failure or damage, or burns due to heat.
- Do not put any metallic objects between the charging area and the portable device while charging. Do not attach metallic objects, such as aluminum stickers, to the charging area.
- Do not cover the Wireless Charger with a cloth or other object while charging.
- Do not attempt to charge portable devices which are not compatible with the Qi wireless charging standard.
- Do not disassemble, modify or remove the Wireless Charger.
- Do not apply force or impact to the Wireless Charger.
- Do not spill liquid such as water, drinks, etc. over the Wireless Charger or the smart phone.

⚠ CAUTION

Phones which are having magnetic array (for alignment / to fix with chargers) may have different charging performance / may get heat up depending upon the type of phones.


NOTICE
<p>Conditions in which the Wireless Charger may not operate correctly In the following situations, the wireless charger may not operate correctly:</p> <ul style="list-style-type: none"> • When a smart phone is fully charged. • When there is a foreign object such as metal objects between the charging area and a smart phone. • When dust and other debris are on the charging pad. • When a smart phone becomes hot while charging. • When a smart phone is placed on the wireless area with its charging surface facing up. • When a smart phone is not centered on the charging area. • When the vehicle is near a TV tower, electric power plant, gas station, radio station, large display, air-port or other facility that generates strong radio waves or electrical noise. <p>(Continued)</p>

NOTICE
<p>(Continued)</p> <ul style="list-style-type: none"> • When the smart phone is in contact with, or is covered by any of the following metallic objects: <ul style="list-style-type: none"> - Any object such as cards, cigarette boxes etc. that contains aluminum foil - Metallic wallets or bags - Coins - Metal hand warmers - Media such as CDs and DVDs • When wireless keys (that emit radio waves) other than those of your vehicle are being used nearby. • Vehicle Smart Key FOB operation might be impacted due to wireless charging function. Keep the Key FOB away from the Wireless Charger to avoid situation where vehicle is unable to detect the Key FOB. • If in situations other than above the Wireless Charger does not operate properly Wireless Charger may be malfunctioning. In this case, please refer Error/Malfunction table. <p>(Continued)</p>

NOTICE
<p>(Continued)</p> <p>To prevent failure or damage to data Do not bring magnetic cards, such as a credit card, or magnetic recording media, close to the wire- less charger while charging. Otherwise, data may be erased due to the influence of magnetism.</p> <p>Additionally, do not bring precision instruments such as wrist watches, close to the Wireless Charger, as such objects may malfunction.</p> <p>To prevent vehicle battery discharge Do not use the Wireless Charger for a long period of time, with engine stopped. Prolong charging may impact the vehicle battery health.</p>

OTHER CONTROLS AND EQUIPMENT

Using the Wireless Charger



To start wireless charging, place a Smart phone equipped with wireless charging function at the center of Wireless Charger. Firmly close all the doors (including the tailgate) and turn the ignition mode to ACC/IGNON. If the vehicle is in ACC OFF mode, wireless charging is not possible.

Place a Smart phone on the Wireless Charger (1) with its charging surface facing down.

While charging, the indicator light (2) (blue) will be illuminated.

If charging does not begin, place the smart phone at the center of the charging area.

When charging is complete, the operation indicator light (2) (green) will illuminate.

NOTE:

- You can choose to turn the wireless charging function ON or OFF in the user settings mode on the Infotainment/Head Unit. For more details, refer to the manual of the Infotainment/Head Unit.
- Charging might take few seconds to initiate depending on a portable device or a smart phone.
- If a certain amount of time has elapsed since charging completed and the portable device has not been moved, the wireless charger will restart charging.
- If the portable device is moved within the charging area, charging will stop temporarily and then restart.
- Non compatible/Non Qi certified smart phones may generate FOD/error alerts
- The surface of the portable device or smart phone may slightly heat up during charging process which is normal.

Wireless charger indicator light status

Indicator light*	Description
Off	Wireless Charger OFF
Amber	Wireless Charger activated and ready to charge
Blue	Charging in progress
Green**	Charging completed

*: Indicator light intensity may vary depending on the vehicle/ weather condition.

**: Depending on the smart phone, the indicator light may not turn green even after charging completion.

Error / malfunction status

Indicator light	Description**	Measure
Red blinking	Presence of any foreign object (metallic object) or the mobile is displaced from the charging area.	Remove the foreign object including phone cover (having metallic content) Align the phone at the center.
	Smart phone temperature is too high.	Turn off the Wireless Charger, remove the phone and wait for some time for get it cool.
	Wireless Charger temperature is too high.	Turn off the Wireless Charger and wait for some time for get it cool.
	Wireless Charger is not able to communicate with the vehicle	Contact your nearest Maruti Suzuki authorized workshop if error persists.
Red continuous	1) Non compatible device/ an object having high metallic content placed on Wireless Charger 2) Non-recoverable failure might have occurred.	1) Remove the object or device and restart the vehicle. 2) Contact your nearest Maruti Suzuki authorized workshop if error persists.

**: Go to Wireless Charger screen in the Infotainment screen to see the details of error / malfunction.

OTHER CONTROLS AND EQUIPMENT

NOTE:

- If there is communication loss between Infotainment System & Wireless Charger, Wireless Charger screen may not be visible. In this case contact your nearest Maruti Suzuki authorized workshop. Indicator Unit may indicate Red Blinking/Red Continuous alert based on the communication between the Smart phone and Wireless Charger.
- Indicator Unit may indicate Red Blinking/Red Continuous alert based on the communication between the Smart phone and Wireless Charger.

The wireless Charger can be operated when

The vehicle is in ACC ON mode.

Smart phones that can be charged

Smart phones compatible with the Qi wireless charging standard can be charged by the Wireless Charger. How-ever, compatibility with all devices which meet the Qi wireless charging standard is not guaranteed.

If a cover or accessory is attached to the Smart phone

Do not charge a Smart phone if a cover or accessory which is not Qi compatible is attached. Depending on the type of cover and/or accessory attached (e.g. if a cover is very thick or has metal ring attached to the cover), it may not be possible to charge the Smart phone. If the Smart phone is placed on the charging area and does not charge, remove the cover and/or accessories.

If interference is heard in AM radio broadcasts while charging

Some noise may be heard while using the Wireless Charger.

The wireless charging function gets interrupted when any of the following condition is encountered

- Vehicle is in ACC off mode.
- When vehicle battery is too low.
- When the engine switch / the power switch is pressed or the brake / the clutch is pressed during cranking of the vehicle. Charging will be reinitiated once the vehicle is successfully cranked or the brake / the clutch is released.
- If in situation other than the above, Wireless Charger will not operate till the key search event is happening.
- Depending on the vehicle drive mode condition, charging might be impacted.
- When any of the vehicle door (including the tailgate) is opened or the Key Fob is taken out of the vehicle. Charging will be initiated once all doors are closed and the Key Fob is inside the vehicle.
- The Wireless Charger is turned off in the user settings screen on the Infotainment.
- When temperature increases abnormally inside the wireless Charger or the smart phone gets overheated.
- When interior temperature of Wireless Charger goes beyond the set temperature, charging will stop. Once the temperature comes within the operating range, charging function will resume.

- When the smart phone is displaced during vehicle running condition, charging may be impacted.
- The vehicle is parked at a place where there is strong electromagnetic waves or noises such as FM/AM station, TV station, electric power plant etc.
- For certain smart phones, wireless charging speed may vary and charging may stop due to their own protection mechanisms defined by smart phone manufacturer.
- For certain smart phones charging stop alert may be displayed depending on smart phone manufacturer and it should not be considered as a malfunction of the Wireless Charger.
- User may face intermittent /No charging issue based on the smart phone size/ position and it should not be considered as malfunction of the Wireless Charger.
- Forceful insertion of smart phone may damage the Wireless Charger.

When the smart phone placed on Wireless Charger is connected to USB cable
It charges by means as defined by the smart phone manufacturer. Based on the above indicator LED status will get change and user may get different Malfunction/Error alerts

Cleaning the wireless charger

WARNING

Do not let the Wireless Charger get wet. Failure to do so may cause the charger to become hot and cause burns or could cause electric shock resulting in death or serious injury.

- Do not use oil, grease, alcohol, benzene or thinner for cleaning the charging pad.
- Do not cover the charging pad with towels, clothing, or other objects while charging etc.
- Do not spray aerosols which may come in contact with the charging pad surface.

VEHICLE LOADING AND TOWING

Vehicle Loading	8-1
Trailer Towing	8-1



54G215

VEHICLE LOADING AND TOWING

Vehicle Loading

Your vehicle was designed for specific weight capacities. The weight capacities of your vehicle are indicated by the Gross Vehicle Weight Rating (GVWR) and the Permissible maximum Axle Weight (PAW, front and rear). The GVWR and PAW (front and rear) are listed in the "SPECIFICATIONS" section.

GVWR – Maximum permissible overall weight of the fully loaded vehicle (including all the occupants, accessories and cargo plus the trailer nose weight if towing a trailer).

PAW – (Front and Rear) Maximum permissible weight on an individual axle.

Actual weight of the loaded vehicle and actual loads at the front and rear axles can only be determined by weighing the vehicle. Compare these weights to the GVWR and PAW (front and rear). If the gross vehicle weight or the load on either axle exceeds these ratings, you must remove enough weight to bring the load down to the rated capacity.

⚠ WARNING

- Never overload your vehicle. The gross vehicle weight (sum of the weights of the vehicle, all the occupants, accessories, cargo plus trailer nose weight if towing a trailer) must never exceed the Gross Vehicle Weight Rating (GVWR). In addition, never distribute a load so that the weight on either the front or rear axle exceeds the Permissible maximum Axle Weight (PAW).
- Always distribute cargo evenly. To avoid personal injury or damage to your vehicle, always secure cargo to prevent it from shifting if the vehicle moves suddenly. Place heavier objects on the floor and as far forward in the cargo area as possible. Never pile cargo higher than the top of the seat backs.

Trailer Towing

Your vehicle was originally designed to carry people and a normal amount of cargo, not to tow a trailer.

INSPECTION AND MAINTENANCE



60G410

Maintenance Schedule	9-2
Periodic Maintenance Schedule	9-2
Drive Belt	9-6
Engine Oil and Filter	9-6
Engine Coolant	9-11
Air Cleaner	9-13
Spark Plugs	9-14
Gear Oil	9-14
Clutch	9-15
Brakes	9-15
Steering Wheel	9-19
Tyres	9-19
Battery	9-22
Fuses	9-24
Headlight Aiming	9-27
Bulb Replacement	9-28
Wiper Blades	9-34
Windshield Washer Fluid	9-37
Air Conditioning System	9-37
Preparation Before Winter Season	9-38



59RN05750

⚠ WARNING

Take extreme care when working on your vehicle to prevent accidental injury. Carefully observe the following precautions:

- To prevent damage or unintended activation of the airbag system or seat belt pretensioner system, check that the lead-acid battery is disconnected and the ignition switch has been in "LOCK" position or the ignition mode has been in LOCK (OFF) position for at least 90 seconds before performing any electrical service work on your Maruti Suzuki vehicle. Do not touch airbag system components, seat belt pretensioner system components or wires.

The wires are wrapped with yellow tape or yellow tubing, and the couplers are yellow for easy identification.

- Do not leave the engine running in garages or other confined areas.

(Continued)

⚠ WARNING

(Continued)

- When the engine is running, keep hands, clothing, tools, and other objects away from the fan and drive belt. Even though the fan may not be moving, it can automatically turn on without warning.
- When it is necessary to perform service work with the engine running, check that the parking brake is set fully and the transmission is in Neutral.
- Do not touch ignition wires or other ignition system parts when starting the engine or when the engine is running, or you could receive an electric shock.
- Be careful not to touch a hot engine, exhaust manifold and pipes, muffler, radiator and water hoses.
- Do not allow smoking, sparks, or flames around fuel or the battery. Flammable fumes are present.

(Continued)

⚠ WARNING

(Continued)

- Do not get under your vehicle if it is supported only with the portable jack provided in your vehicle.
- Be careful not to cause accidental short circuits between the positive and negative battery terminals.
- Keep used oil, coolant, and other fluids away from children and pets. Dispose of used fluids properly; never pour them on the ground, into sewers, etc.

Maintenance Schedule

The following table shows the timing when you should perform regular maintenance on your vehicle. This table shows in kilometers and months when you should perform inspections, adjustments, lubrication and other services.

⚠ WARNING

MARUTI SUZUKI recommends that maintenance on your Maruti Suzuki vehicle should be performed by Maruti Suzuki authorized workshop.

Periodic Maintenance Schedule

NOTICE

Whenever it becomes necessary to replace parts on your vehicle, it is recommended that you use genuine MARUTI SUZUKI replacement parts or their equivalent.

“C”: Clean

“R”: Replace or Change

“I”: Inspect, clean, adjust, lubricate or replace as necessary

“L”: Lubricate

“T”: Tighten to Specified Torque

“O”: Rotate

NOTE:

- This table includes services as scheduled up to 80,000 km mileage. Beyond 80,000 km, carry out the same services at the same intervals respectively.
- For free inspection the cost of materials and consumables to be borne by customer.

INSPECTION AND MAINTENANCE

Interval: This interval should be judged by odometer reading or months, whichever comes first.				FREE INSPECTION			PERIODIC MAINTENANCE AT COST							
		km (x1000)		1	5	10	20	30	40	50	60	70	80	
		months		1	6	12	24	36	48	60	72	84	96	
ENGINE														
1-1.	Water pump drive belt (Wear)	K12N	-	-	I	I	I	I	I	I	I	I	R	
		K10C(DITC)	-	-	I	I	R	I	I	R	I	I		
1-2.	Engine Coolant SUZUKI LLC: Super (Blue) (#1,2)	First time only:	Replace at 100000 km or 60 months whichever comes first.											
		Second time and after:	Replace every 40000 km or 24 months whichever comes first.											
1-3.	Engine oil, engine oil filter and drain plug gasket (Level, Leakage)	I	I	R	R	R	R	R	R	R	R	R	R	
1-4.	Cooling system hoses and connections (Leakage and Damage)	I	I	I	I	I	I	I	I	I	I	I	I	
1-5.	Engine mounting and manifold fixing (Loose Damage)	-	-	I	-	I	-	I	-	I	-	I	-	
1-6.	Exhaust system (Noise, Leakage etc.)	-	I	-	I	-	I	-	I	-	I	-	I	
1-7.	Positive crank case ventilation system (Hoses, Connections and Valve)	-	I	-	I	-	I	-	I	-	I	-	I	
IGNITION														
2-1.	Ignition wire (Damage, Deterioration)	-	-	-	I	-	I	-	I	-	I	-	I	
2-2.	Spark plug	Petrol	K12N	Replace every 100000 km or 84 months whichever comes first										
		K10C(DITC)	-	-	-	-	-	-	-	R	-	-	-	
		CNG	K12N	Replace every 50000 km or 48 months whichever comes first										
FUEL														
3-1.	Air cleaner filter element	Paved-road			Clean every 5000 km. Replace after every 40000 km									
		Dusty Condition			Clean every 2500 km or as required. Replace after every 40000 km									
3-2.	Fuel tank cap, fuel lines and connections (Leakage and Damage)	-	I	-	-	-	-	I	-	-	-	-	I	
3-3.	Fuel filter	Replace every 100000 km or 120 months whichever comes first												
3-4.	Fuel Injector (Inspection, Cleaning)	K10C(DITC)	-	-	I	I&C	I	I&C	I	I&C	I	I&C		
		K12N	-	-	-	-	-	-	-	-	-	-	-	

#1: Perform the engine coolant level check under the daily inspection in the "OPERATING YOUR VEHICLE" section.

The same type of coolant that is filled at the time of a brand new car should be used when you add or replace the coolant. Refer to "Engine coolant" in this section.

#2: Do not add SUZUKI LLC: Standard (Yellow) Coolant or distilled water or others when your vehicle is originally filled with SUZUKI LLC: Super (Blue) Coolant.

#3: When your vehicle is originally filled with SUZUKI LLC: Standard (Yellow) Coolant, follow the maintenance schedule of SUZUKI LLC: Standard (Yellow) Coolant.

INSPECTION AND MAINTENANCE

Interval: This interval should be judged by odometer reading or months, whichever comes first.		FREE INSPECTION					PERIODIC MAINTENANCE AT COST						
		km (x1000)	1	5	10	20	30	40	50	60	70	80	
		months	1	6	12	24	36	48	60	72	84	96	
CLUTCH AND TRANSMISSION													
4-1.	Clutch pedal (Play)												
4-2.	Clutch Fluid (Level, Leakage)												
4-3.	Clutch slipping (Dragging or Excess Damage)												
4-4.	Manual / Auto Gear Shift (AGS) - Transmission oil (Level, Leakage)												
4-5.	Gear shifter (Operation)												
4-6.	AGS Actuator oil (Level, Leakage)	AGS model											
4-7.	Automatic Transaxle Fluid (Level, Leakage)		-	-	-		-		-		-		
4-8.	Hose, Automatic Transaxle Cooler (Leakage & Damage)												
DRIVE SHAFT													
5-1.	Drive shaft noise												
5-2.	Drive shaft boot (Damage)		-										
Brake													
6-1.	Brake fluid (Level, Leakage)												
6-2.	Brake pedal (Pedal - carpet clearance)												
6-3.	Parking brake lever and cable (Play, Damage)												
6-4.	Brake disc and pad (Wear)		-										
6-5.	Brake drum and shoes (Wear)		-	-									
6-6.	Master cylinder, wheel cylinder, caliper piston (Fluid leakage, Boot/Seal damage)												
6-7.	Brake hoses and pipes (Fluid leakage, Damage)												
WHEEL													
7-1.	Tyres (Air pressure, Abnormal wear, Crack and Rotation)			I&O	I&O	I&O	I&O	I&O	I&O	I&O	I&O	I&O	
7-2.	Wheels (Damage)												
7-3.	Front/Rear wheel bearing (Loose, Damage)												
FRONT / REAR SUSPENSION													
8-1.	Suspension strut (Oil leakage, Damage)												
8-2.	Suspension arms / Knuckle support and Torsion rods (Loose, Damage)		-										

INSPECTION AND MAINTENANCE

Interval: This interval should be judged by odometer reading or months, whichever comes first.				FREE INSPECTION			PERIODIC MAINTENANCE AT COST					
		km (x1000)		1	5	10	20	30	40	50	60	70
		months		1	6	12	24	36	48	60	72	84
8-3.	Rear spring (Damage)		I	I	I	I	I	I	I	I	I	I
8-4.	Shock absorbers (Oil leakage, Damage)		I	I	I	I	I	I	I	I	I	I
8-5.	All bolts and nuts (Loose)	-	T	T	T	T	T	T	T	T	T	T
STEERING												
9-1.	Steering wheel (Play, Loose)		I	I	I	I	I	I	I	I	I	I
9-2.	All rods and arms (Loose, Damage, Wear)		I	I	I	I	I	I	I	I	I	I
9-3.	Tilt / Telescopic (if equipped) steering (Operation)		I	I	I	I	I	I	I	I	I	I
ELECTRICAL												
10-1.	Battery - Electrolyte (Level, Leakage) and voltage		I	I	I	I	I	I	I	I	I	I
10-2.	Wiring harness connection (Loose, Damage)	-	I	I	I	I	I	I	I	I	I	I
10-3.	Lighting system (Operation, Stains, Damage)		I	I	I	I	I	I	I	I	I	I
10-4.	Wiper (Operation)		I	I	I	I	I	I	I	I	I	I
10-5.	Horn (Operation)		I	I	I	I	I	I	I	I	I	I
10-6.	USB (if equipped), USB charger (if equipped) and accessory socket (Operation)	-	I	I	I	I	I	I	I	I	I	I
BODY												
11-1.	All chassis bolts and nuts (Tighten)	-	I	T	T	T	T	T	T	T	T	T
11-2.	All latches, hinges and locks (Function)	I	I&L	I&L	I&L	I&L	I&L	I&L	I&L	I&L	I&L	I&L
ROAD TEST												
12-1.	Operation of Brakes, gear shifting and speedometer		I	I	I	I	I	I	I	I	I	I
12-2.	Body and chassis noise		I	I	I	I	I	I	I	I	I	I
AIR CONDITIONER												
13-1.	Check belt tension		I	I	I	I	I	I	I	I	I	I
13-2.	Tighten compressor mounting bolt	-	T	T	T	T	T	T	T	T	T	T
13-3.	All hose joint (Check, Tighten)		I	I	I	I	I	I	I	I	I	I
13-4.	Check functioning of recirculating flap		I	I	I	I	I	I	I	I	I	I
13-5.	Clean condenser with low pressure water	-	C	C	C	C	C	C	C	C	C	C
13-6.	Check belt for frayed edges		I	I	I	I	I	I	I	I	I	I
13-7.	Check all mounting bolts		I	I	I	I	I	I	I	I	I	I
13-8.	Air conditioner filter element		I	I	I	I	R	I	I	R	I	I

Drive Belt

⚠ WARNING

When the engine is running, keep hands, hair, clothing, tools, etc. away from the moving fan and drive belts.

The drive belts tension is adjusted automatically. If the belt is too loose, insufficient battery charging, engine overheating, poor power steering, poor air conditioning, or excessive belt wear can result.

The belts should also be examined to ensure that they are not damaged.


If you need to replace or adjust the belt have it done by your Maruti Suzuki authorized workshop.

Engine Oil and Filter

Specified Oil


- K12N model

For India



(1) Preferred

Except for India



1) Preferred

For India, be sure that the engine oil you use comes under the quality classification of as listed below.

- API SN, SP
ILSAC GF-6


Except for India, be sure that the engine oil you use comes under the quality classification as listed below.

- API SN, SP
• ILSAC GF-6

SAE 0W-16 (1) is the best choice for good fuel economy and good starting in cold weather.

• K10C(DITC) model


For India



(1) Preferred

INSPECTION AND MAINTENANCE

Except for India



1) Preferred

For India, be sure that the engine oil you use comes under the quality classification of as listed below.

- API SN, SP
- ILSAC GF-6

Except for India, be sure that the engine oil you use comes under the quality classification as listed below.

- API SN, SP
- ILSAC GF-6

Select the appropriate oil viscosity according to the above chart.


SAE 5W-30 (1) is the best choice for good fuel economy and good starting in cold weather.

NOTE:


- The replacement timing varies with the type of engine oil that you choose. Refer to "Maintenance schedule" in this section for corresponding maintenance schedule.
- We recommend that you use MARUTI SUZUKI genuine oil. To purchase it, see a Maruti Suzuki authorized workshop.


Oil Level Check

• K12N model



• K10C (DITC) model





52D084

It is important to keep the engine oil at the correct level for proper lubrication of your vehicle's engine. Check the oil level with the vehicle on a level surface. The oil level indication may be inaccurate if the vehicle is on a slope. The oil level should be checked either before starting the engine or at least 5 minutes after stopping the engine.

Pull out the oil dipstick, wipe the oil off with a clean cloth, insert the dipstick all the way into the engine, and then remove it again. The oil on the stick should be between the upper and lower limits shown on the stick. If the oil level indication is near the lower limit, add enough oil to raise the level to the upper limit.


NOTICE

Failure to check the oil level regularly could lead to serious engine trouble due to insufficient oil.

- 1) When the GPF warning light comes on, drive at a speed of 50 km/h (31 mph) or higher for more than 25 minutes to regenerate the GPF properly. For details, refer to "Gasoline particulate filter (GPF)" in the "OPERATING YOUR VEHICLE" section.
- 2) When the oil change request light blinks, change the engine oil and oil filter, and reset the oil life monitoring system. To reset the oil life monitoring system, consult a Maruti Suzuki authorized workshop.

When the engine oil level exceeds the MAX level on the dipstick, consult a Maruti Suzuki authorized workshop.

Refilling




55T090140

Remove the oil filler cap and pour oil slowly through the filler hole to bring the oil level to the upper limit on the dipstick. Be careful not to overfill the oil. Too much oil is almost as bad as too little oil. After refilling, start the engine and allow it to idle for about a minute. Stop the engine, wait about 5 minutes and check the oil level again.


INSPECTION AND MAINTENANCE

Changing Engine Oil and Filter

Drain the engine oil while the engine is still warm.



2) Remove the oil filler cap.



- 3) Remove the screws (1), and then remove the engine under cover (2).
- 4) Place a drain pan under the drain plug.
- 5) Using a wrench, remove the drain plug and drain the engine oil.

⚠ CAUTION

The engine oil temperature may be high enough to burn your fingers when the drain plug is loosened. Wait until the drain plug is cool enough to touch with your bare hands.

Tightening torque for drain plug:
35 Nm (3.6 kg·m, 25.8 lb·ft)

⚠ WARNING

Engine oil can be hazardous. Children and pets may be harmed by swallowing new or used oil. Keep new and used oil and used oil filters away from children and pets.

Repeated, prolonged contact with used engine oil may cause skin cancer.

Brief contact with used oil may irritate skin.

To minimize your exposure to used oil, wear a long-sleeve shirt and moisture-proof gloves (such as dish-washing gloves) when changing oil. If oil contacts your skin, wash thoroughly with soap and water.

Launder any clothing or rags if it is with oil.

Recycle or properly dispose of used oil and oil filters.


- 6) Reinstall the drain plug with new gasket. Tighten the plug with a wrench to the specified torque.

NOTE:


Ask a Maruti Suzuki authorized workshop for changing engine oil and filter if you have difficulties.

Oil Filter Replacement

- 1) Remove the screws (1), and then remove the engine under cover (2).
- 2) If it is difficult to change the oil filter, remove the whole undercover.
- 3) Using an oil filter wrench, turn the oil filter counterclockwise and remove it.
- 4) Using a clean rag, wipe off the mounting surface on the engine where the new filter will be seated.
- 5) Smear a small amount of engine oil around the rubber gasket of the new oil filter.
- 6) Screw the new filter by hand until the filter gasket contacts the mounting surface.



- (3) Loosen
- (4) Tighten

Tightening (viewed from filter top)

- (5) Oil filter
(6) 3/4 turn

NOTICE

To tighten the oil filter properly, it is important to accurately identify the position at which the filter gasket first contacts the mounting surface.

- 7) Tighten the filter as specified below from the point of contact with the mounting surface (or to the specified torque) using an oil filter wrench.

Tightening torque for oil filter:
3/4 turn or
14 Nm (1.4 kg-m, 10.3 lb-ft)

NOTICE

To prevent oil leakage, check that the oil filter is tight, but do not overtighten it.

INSPECTION AND MAINTENANCE

Refilling with Oil and Oil Leakage Check


- Pour oil through the filler hole and install the filler cap.
For the approximate capacity of the oil, refer to "Recommended fuel / lubricants and capacities (approx.)" in "SPECIFICATIONS" section.
- Start the engine and carefully check the oil filter and the drain plug for leakage. Run the engine at various speeds for at least 5 minutes.
- Stop the engine and wait about 5 minutes. Check the oil level again and add oil if necessary. Check for leakage again.

NOTICE

- When replacing the oil filter, it is recommended that you use a genuine MARUTI SUZUKI replacement filter. If you use an aftermarket filter, check that it is of equivalent quality and follow the manufacturer's instructions.
- Oil leakage from the periphery of the oil filter or drain plug indicate incorrect installation or gasket damage. If you find any leakage or are not sure that the filter has been properly tightened, have the vehicle inspected by a Maruti Suzuki authorized workshop.

Engine Coolant

Coolant Level Check



Check the coolant level at the reservoir tank, not at the radiator. With the engine cool, the coolant level should be between "FULL" and "LOW" marks. If the coolant level is below "LOW" mark, coolant should be added.

Coolant addition and replacement

When you add the coolant, remove the reservoir tank cap and add coolant until the reservoir tank level reaches "FULL" mark while the engine is cool. Never fill the reservoir tank above "FULL" mark.

Since special procedures are required for coolant replacement, ask a Maruti Suzuki authorized workshop for this job.

WARNING

Swallowing engine coolant can cause severe injury or death. Inhaling coolant mist or vapors or getting coolant in your eyes could result in severe injury.

- Do not drink antifreeze or coolant solution. If swallowed, do not induce vomiting. Immediately contact a poison control center or a physician.
- Avoid inhaling coolant mist or hot vapors. If inhaled, remove to a fresh air area.
- If coolant gets in the eyes, flush with water and seek medical attention.
- Wash thoroughly after handling coolant.
- Keep engine coolant out of the reach of children and pets.

NOTICE

When putting the cap on the reservoir tank, line up the mark on the cap and the mark on the tank. Failure to follow this can result in coolant leakage.

Selection of Coolant

To maintain optimum performance and durability of your engine, use MARUTI SUZUKI genuine coolant or equivalent.

This type of coolant is the best for cooling system for the following reasons:

- The coolant helps maintain proper engine temperature.
- It gives proper protection against freezing and boiling.
- It gives proper protection against corrosion and rust.

Failure to use the proper coolant can damage your cooling system. A Maruti Suzuki authorized workshop can help you select the proper coolant.

NOTICE

To avoid damaging your cooling system:

- Always use a high quality ethylene glycol base non-silicate type coolant diluted with distilled water at the correct mixture concentration.
- Do not add extra inhibitors or additives. They may not be compatible with your cooling system.
- Do not mix different types of base coolants. Doing so may result in accelerated seal wear and/or the possibility of severe overheating and extensive engine/transmission damage. In case of coolant mix-up

(Continued)

NOTICE


(Continued)

have your vehicle inspected by a Maruti Suzuki authorized workshop.

NOTE:

Maruti Suzuki highly recommends the use of Maruti Suzuki genuine coolant. Maruti Suzuki genuine coolant has been specially formulated for your Maruti Suzuki product and contributes to the desired vehicle performance and ideal driving experience.

Depending on the production period of your vehicle, the coolant type filled at the time of a brand new car differs. There are two coolant types, SUZUKI LLC: Super (Blue) Coolant and SUZUKI LLC: Standard (Yellow) Coolant. You can check the original coolant type in your vehicle by the color of the coolant in the reservoir tank (Refer below figure).



55T090201

Coolant Color	Coolant Type
Blue	Suzuki LLC : Super
Yellow	Suzuki LLC : Standard

NOTE:

The same type of coolant that is filled at the time of a brand new car should be used when you add or replace the coolant.

SUZUKI LLC: Super (Blue) Coolant:

NOTICE

- This coolant is already diluted to the proper percentage. Do not dilute with distilled water additionally. Doing so may result in the possibility of freezing and/or overheating coolant.
- Do not add SUZUKI LLC: Standard (Yellow) Coolant or distilled water or others when your vehicle is originally filled with SUZUKI LLC: Super (Blue) Coolant. If such a case occurs, then get the vehicle inspected by a Maruti Suzuki authorized workshop.

INSPECTION AND MAINTENANCE

SUZUKI LLC:Standard (Yellow) Coolant:


NOTICE

- The concentration of the mixture to be used shall be 30% antifreeze and 70% distilled water. Do not use straight coolant nor plain water.
- If the lowest ambient temperature in your area is expected to be -15°C (5°F) or below, use higher concentrations up to 60% following the instructions on the antifreeze container. Concentrations greater than 60% will cause overheating conditions.
- When your vehicle is originally filled with SUZUKI LLC: Standard (Yellow) Coolant, follow the maintenance schedule of SUZUKI LLC: Standard (Yellow) Coolant in this section. In case you replace with Suzuki LLC: Super (Blue) Coolant, then get the vehicle inspected by a Maruti Suzuki authorized workshop.

Air Cleaner


If the air cleaner is clogged with dust, there will be greater intake resistance, resulting in decreased power output and increased fuel consumption.

K12N model




- Unclamp the side clamps (1).
- Hold up the air cleaner upper case (2).
- Remove the element from the air cleaner case. If it appears to be dirty, clean or replace it with a new one.
- Reinstall the air cleaner case securely.

K10C(DITC) model



- Remove the bolts (1) and lift the air cleaner case (2) directly above.



- Unclamp the side clamps and remove the element from the air cleaner case. If

the element appears to be dirty clean the element or replace it with a new one as per periodic maintenance schedule.
 3) Clamp the side clamps securely.

Spark Plugs

Spark Plug Replacement and Inspection

Since special procedures, materials and tools are required, it is recommended that you trust this job to a Maruti Suzuki authorized workshop.


Gear Oil

Manual Transmission Oil / Auto Gear Shift oil


When adding gear oil, use gear oil with the appropriate viscosity and grade as shown in the chart below.

We highly recommend you use:
"MARUTI GENUINE GEAR OIL 75W" for manual transmission oil / auto gear shift oil.

Manual transmission oil / Auto Gear Shift oil



Gear Oil Level Check



68PH00712

1. Oil filler and level plug
(For K12N model)
2. Oil filler and level plug
(For K10C(DITC) model)

To check the gear oil level, use the following procedure:

- 1) Park the vehicle on a level surface with the parking brake applied. Then, stop the engine.
- 2) Remove the oil filler and level plug.
- 3) If gear oil flows from the plug hole, the oil level is correct. Reinstall the plug. If gear oil does not flow from the plug hole, add oil through the filler plug hole until oil flows a little from the plug hole.

Tightening torque for oil filler and level plug

- Manual transmission (1)**
21 Nm (2.1 kg-m, 15.5 lb-ft)
Auto Gear Shift (1)
21 Nm (2.1 kg-m, 15.5 lb-ft)

CAUTION

After driving the vehicle, the gear oil temperature may be high enough to burn you. Wait until the oil filler and level plug are cool enough to touch with your bare hands before inspecting gear oil level.

NOTICE

When tightening the plug, apply the following sealing compound or equivalent to the plug threads to prevent oil leakage.

MARUTI SUZUKI Bond No. "1217G"


Gear Oil Change

Since special procedures, materials and tools are required, ask a Maruti Suzuki authorized workshop for this job.

INSPECTION AND MAINTENANCE

Clutch

Clutch Pedal




54G274

Clutch pedal play "d": MAX 10 mm

Measure the clutch pedal play by moving the clutch pedal with your hand and measuring the distance it moves until you feel slight resistance. The play in the clutch pedal should be less than the specified values. If the play is more than the above, or clutch dragging is felt with the pedal fully depressed, have the clutch inspected by a Maruti Suzuki authorized workshop.

Clutch Fluid




55TB0904

Check the clutch pedal for smooth operation and clutch fluid level from time to time. If clutch dragging is felt with the pedal fully depressed, have the clutch inspected by a Maruti Suzuki authorized workshop. If the clutch fluid level is near "MIN" line, fill it up to "MAX" line with DOT3 or SAE J1703 brake fluid.

Brakes

Brake Fluid



55TB0904

Check the brake fluid level by looking at the reservoir in the engine compartment. Check that the fluid level is between "MAX" and "MIN" lines.

NOTICE

Clutch fluid is supplied from brake fluid reservoir. If your clutch fluid level is increased or near the "MIN" line, there is a possibility of clutch or brake fluid leakage or abnormal wear of clutch.

Have your vehicle inspected immediately by a Maruti Suzuki authorized workshop.

⚠ WARNING

- Failure to follow the guidelines below can result in personal injury or serious trouble in the brake system.
 - If the brake fluid in the reservoir drops below a certain level, the brake warning light on the instrument cluster will come on (the engine must be running with the parking brake fully disengaged). Should the light come on, immediately ask a Maruti Suzuki authorized workshop to inspect the brake system.
 - A rapid fluid loss indicates leakage in the brake system. In this case, immediately ask a Maruti Suzuki authorized workshop to inspect the brake system.
 - Do not use any fluid other than DOT3 or SAE J1703 brake fluid. Do not use reclaimed fluid or fluid that has been stored in old or open containers. It is essential that foreign particles and other liquids are kept out of the brake fluid reservoir.

(Continued)

⚠ WARNING

(Continued)

- Brake fluid is harmful or fatal if swallowed, and harmful if it comes in contact with skin or eyes. If swallowed, do not induce vomiting. Immediately contact a poison control center or a physician. If brake fluid gets in eyes, flush eyes with water and seek medical attention. Wash thoroughly after handling. Solution can be poisonous to animals. Keep out of reach of children and animals.

NOTE:

- The fluid level can be expected to gradually fall as the brake pad and/or shoe wear.
 - Brake fluid absorbs water over time and brake fluid with high water content may cause vapor lock or brake system malfunction.
- Replace the brake fluid according to the maintenance schedule in this owner's manual.


NOTICE

- If your brake fluid level is near the "MIN" line, there is a possibility of brake pad and/or shoe wear and brake fluid leakage. In this case, ask a Maruti Suzuki authorized workshop to inspect the brake system.
- Brake fluid can damage painted surfaces. Be careful when refilling the reservoir.

INSPECTION AND MAINTENANCE

Brake Pedal

Check brake pedal stroke. If the stroke is so large, have the brake system inspected by a Maruti Suzuki authorized workshop. If you doubt the brake pedal is at its normal height, check it as follows:



Minimum distance between brake pedal and floor carpet "a"

53 mm

With the engine running, measure the distance between the brake pedal and floor carpet when the pedal is depressed with approximately 30 kg of force. The minimum distance required is as specified. Since your vehicle's brake system is self-adjusting, there is no need for pedal adjustment.


If the pedal to floor carpet distance as measured above is less than the minimum distance required, have your vehicle

inspected by a Maruti Suzuki authorized workshop.

NOTE:

- When measuring the distance between the brake pedal and floor wall, be sure not to include the floor mat or rubber on the floor carpet in your measurement.
- Measure the distance at the brake pedal's side facing toward the driver's door.

EXAMPLE



CAUTION


If you experience any of the following problems with your vehicle's brake system, have the vehicle inspected immediately by a Maruti Suzuki authorized workshop.

- Poor braking performance
- Uneven braking (brakes not working uniformly on all wheels)
- Excessive pedal travel
- Brake dragging

WARNING

If the brake pad lining becomes worn and it has reached its minimum thickness, squealing noise sounds during braking.


If you hear this noise, have the vehicle inspected immediately by a Maruti Suzuki authorized workshop. Continued driving with this condition can cause an accident.

Parking Brake

55T090270


Ratchet tooth specification "b":
4th – 9th
Lever pull force (1):
200 N (20 kg)

Check the parking brake for proper adjustment by counting the number of clicks made by the ratchet teeth as you slowly pull up on the parking brake lever to the point of full engagement. The parking brake lever should stop between the specified ratchet teeth and the rear wheels should be securely locked. If the parking brake is not properly adjusted or the brakes drag is suspected even after the lever has been fully released, have the parking brake inspected and/or adjusted by a Maruti Suzuki authorized workshop.

Brake Discs and Brake Drums**Brake disc**

55T090650

Brake location	Minimum thickness "a"
Front wheels	18.0 mm

Brake drum


55T090660

Brake location	Maximum inner diameter "b"
Rear wheels	202 mm

If the measured thickness or inner diameter of the most worn part falls below or exceeds the value indicated above, the parts should be replaced with a new one. The measurement involves disassembling each brake and requires the use of a micrometer or caliper, which must be done according to the instructions described in the relevant service manual or available from the relevant repair information site.

INSPECTION AND MAINTENANCE

Steering Wheel




55T090090

Steering wheel play "c": 0–30 mm

Check the free play of the steering wheel by gently turning it from left to right and measuring the distance that it moves before you feel slight resistance. The play should be between the specified values.

Check that the steering wheel turns easily and smoothly without rattling by turning it all the way to the right and to the left while driving very slowly in an open area. If the amount of free play is not as specified or you find anything else to be wrong, an inspection must be performed by a Maruti Suzuki authorized workshop.

Tyres



55T090020

The front and rear tyre pressure specifications are listed in the tyre information label (1). Both front and rear tyres should have the specified tyre pressure.

Note that the value does not apply to the compact spare tyre, if equipped.


Tyre Inspection

Inspect your vehicle's tyres at least once a month or before long trip by performing the following checks:

- 1) Measure the air pressure with a tyre gauge. Adjust the pressure if necessary.

WARNING

- Air pressures should be checked when the tyres are cold or you may get inaccurate readings.
- Check the tyre pressure from time to time while inflating the tyre gradually, until the specified pressure is obtained.
- Never under-inflate or over-inflate the tyres.
Under-inflation can cause unusual handling characteristics or can cause the rim to slip on the tyre bead, resulting in an accident or damage to the tyre or rim.
- Over-inflation can cause the tyre to burst, resulting in personal injury.
- Over-inflation can also cause unusual handling characteristics which may result in an accident.



74TB09003

(1) Indicator location mark

- 2) Check that the depth of the tread groove is more than 1.6 mm. To help you check this, the tyres have molded-in tread wear indicators in the grooves. When the indicators appear on the tread surface, the remaining depth of the tread is 1.6 mm or less and the tyre should be replaced.
- 3) Check for abnormal wear, cracks and damage. Any tyres with cracks or other damage should be replaced. If any tyres show abnormal wear, have them inspected by a Maruti Suzuki authorized workshop.

⚠ CAUTION

Hitting curbs and running over rocks can damage tyres and affect wheel alignment. Have tyres and wheel alignment checked periodically by a Maruti Suzuki authorized workshop.

- 4) Check for loose wheel nuts.
- 5) Check that there are no nails, stones or other objects sticking into the tyres.

⚠ WARNING

- Your MARUTI SUZUKI vehicle is equipped with tyres which are all the same type and size. This is important to ensure proper steering and handling of the vehicle. Never mix tyres of different size or type on the four wheels of your vehicle. The size and type of tyres used should be only those approved by MARUTI SUZUKI as standard or optional equipment for your vehicle.

(Continued)

⚠ WARNING

(Continued)

- Replacing the wheels and tyres equipped on your vehicle with certain combinations of aftermarket wheels and tyres can significantly change the steering and handling characteristics of your vehicle.
- Therefore, use only those wheel and tyre combinations approved by MARUTI SUZUKI as standard or optional equipment for your vehicle.


NOTICE

- Replacing the original tyres with tyres of a different size may result in false speedometer or odometer readings. Check with a Maruti Suzuki authorized workshop before purchasing replacement tyres that differ in size from the original tyres.
- Replacing a tyre with one of a different size, or using different brands among the four tyres can result in damage to the drive train.

INSPECTION AND MAINTENANCE


Tyre Rotation

4-tyre rotation



65D459

5-tyre rotation



55T090680

To avoid uneven wear of your tyres and to prolong their life, rotate the tyres as illustrated. Tyres should be rotated every 10000 km. After rotation, adjust front and rear tyre pressures to the specification listed on your vehicle's Tyre Information Label.

Wheel Balancing

If the vehicle vibrates abnormally on smooth road, have the wheel balanced at a Maruti Suzuki authorized workshop.

Wheel Alignment

In case of abnormal tyre wear or pulling towards one side, have the wheel aligned at a Maruti Suzuki authorized workshop.

Tubeless Tyres

The vehicle is equipped with Tubeless Tyres. In tubeless tyre, a thin layer of butyl rubber is used for lining the inside of the tubeless tyre. This layer is to prevent air loss and fulfilling the purpose of tube. The air pressure is maintained by the sealing between tyre bead and wheel rim. Tubeless tyres are having advantage of slow air loss and preventing sudden deflation while driving.


Care and maintenance tips for tubeless tyres

- 1) Always maintain recommended inflation pressure. Driving continuously at low inflation pressure can lead to tyre damage.
- 2) In case any leakage is found, check for any nail penetration/valve core damage or rim bent. Damaged wheel must not be used.
- 3) In case tyre has run at low pressure, it must be inspected for any defect.
- 4) Whenever new tyre is fitted, replace the valve.
- 5) If continuous high speed driving is required, increase tyres pressure by 5 psi over recommended inflation pressure.
- 6) Never run the tyre beyond TWI (Tread wear indicator). The tyre is recommended to be replaced when the remaining tread has worn to this point. The indicators are spaced across the tread around the tyre marked by a triangular symbol (TWI).
- 7) Always prefer tubeless tyre mounting machine. In case of manual mounting-tyre/wheel rim damage may occur.
- 8) In case of any problem, please get in touch with a Maruti Suzuki authorized workshop.

Battery

⚠ WARNING

- Batteries produce flammable hydrogen gas. Keep flames and sparks away from the battery or an explosion may occur. Never smoke when working near the battery.
- When checking or servicing the battery, disconnect the negative cable. Be careful not to cause a short circuit by allowing metal objects to contact the battery posts and the vehicle at the same time.
- To avoid harm to yourself or damage to your vehicle or battery, follow the jump-starting instructions in "EMERGENCY SERVICE" section if it is necessary to jump-start your vehicle.
- Diluted sulfuric acid spilled from battery can cause blindness or severe burns. Use proper eye protection and gloves. Flush eyes or body with ample water and get medical care immediately if suffered. Keep batteries out of reach of children.



59RN09430

For maintenance-free battery (cap-less type), you need not add water. For traditional type battery, which has water filler caps, the level of the battery solution must be kept between the upper level line "MAX" (1) and the lower level line "MIN" (2) at all times. If the level is found to be below the lower level line (2), add distilled water to the upper level line (1). You should periodically check the battery, battery terminals, and battery hold-down bracket for corrosion. Remove corrosion using a stiff brush and ammonia mixed with water, or baking soda mixed with water. After removing corrosion, rinse with clean water.

If your vehicle is not going to be driven for a month or longer, disconnect the cable from the negative terminal of the battery to help prevent discharge.

⚠ WARNING

If the battery is used with battery level being less than the lower level line "MIN" (2), it may cause reduced battery life, an exothermic heat, or an explosion by hydrogen gas occurring from the battery. Do not use the battery with battery level being less than the lower level line "MIN" (2).

NOTICE

- If the battery liquid is added more than the upper level line "MAX" (1), liquid may leak by vibrations during driving or liquid may spray out in some case depending on the condition of battery charging. These may cause damage to the parts near the battery. If the battery liquid overspills, immediately wash away with water. Do not add the battery liquid more than the upper level line "MAX" (1).

(Continued)

INSPECTION AND MAINTENANCE

NOTICE


(Continued)

- If your vehicle is equipped with the ENG A-STOP system and the battery which is exclusive for the ENG A-STOP system is used, only use the specified type of battery for ENG A-STOP system. Refer to "SPECIFICATIONS" section for details. Otherwise, you could damage your vehicle, and the ENG A-STOP system could not be available. If a vehicle battery has to be replaced, consult a Maruti Suzuki authorized workshop.

NOTE:

The battery liquid is consumed when the battery is used. If the level is found to be less than the center of upper level "MAX" (1) and lower level "MIN" (2), add distilled water till it reaches the upper level line "MAX" (1).

Replacement of the Battery



68PM00711

To remove the battery:

- 1) Disconnect the negative cable (1).
- 2) Disconnect the positive cable (2).
- 3) Remove the retainer nuts (3) and remove the retainer (4).

To install the battery:

- 1) Install the battery in the reverse order of removal.
- 2) Tighten the bracket bolt and battery cables securely.

NOTE:

- When the battery is disconnected, some of the vehicle's functions will be initialized and/or deactivated. These functions must be required to reset after the battery is reconnected.
- Do not disconnect the battery terminals for at least one minute after the ignition switch is turned off, or the engine switch is pressed to change the ignition mode to "LOCK" (OFF).


WARNING

Batteries contain toxic substances including sulfuric acid and lead. They could have potential negative consequences for the environment and human health. Used batteries must be disposed of or recycled according to applicable rules or regulations and must not be disposed of with ordinary household trash. Make sure not to tip over the battery when you remove it from the vehicle. Otherwise, sulfuric acid could run out and you might get injury.

NOTICE

After stopping the engine, controller and system are operated for a while. Therefore, before removing the battery, wait for more than one minute after turning the ignition switch to "OFF" or changing the ignition mode to "LOCK" (OFF).

(Battery label)



(5) Crossed-out wheeled bin symbol

(6) Chemical symbol of "Pb"

The crossed-out wheeled bin symbol (5) located on the battery label indicates that the used battery should be collected separately from ordinary household trash. The chemical symbol of "Pb" (6) indicates the battery contains more than 0.004% lead.

By ensuring the used battery is disposed of or recycled correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate trash handling of the battery. The recycling of materials will help to conserve natural resources. For more detailed information about disposing of or recycling the used battery, consult a Maruti Suzuki authorized workshop.

Fuses

Your vehicle has three types of fuses, as described below:

Main fuse

The main fuse takes current directly from the lead-acid battery.


Primary fuses

These fuses are between the main fuse and individual fuses, and are for electrical load groups.

Individual fuses

These fuses are for individual electrical circuits.

To remove a fuse, use the fuse puller provided in the relay box cover.




(1) Fuse puller

(2) Spare fuse

INSPECTION AND MAINTENANCE


Fuses in Engine Compartment



55TB0906


- (3) Main fuse box
- (4) Relay box

Main fuse box



55TB09013

Relay box



56RS00705

MAIN FUSE / PRIMARY FUSE


(1)	120 A	FL1
(2)	100 A	FL2
(3)	80 A	FL3
(4)	100 A	FL4
(5)	50 A	FL5
(6)	30 A	Starter motor
(7)	40 A	Blower fan
(8)	40 A	Battery
(9)	40 A	ABS motor
(10)	40 A	Ignition switch
(11)	30 A	B/U

(12)	-	Blank
(13)	25 A	H/L HI2
(14)	-	Blank
(15)	25 A	ABS solenoid
(16)	15 A	Headlight (Left)
(17)	15 A	Headlight (Right)
(18)	30 A	DCDC
(19)	30 A	Radiator fan
(20)	30 A	T/M Pump
(21)	-	Blank
(22)	7.5A	CNG VLV
(23)	20A	Fuel pump
(24)	20 A	Front fog light
(25)	10 A	Transmission 2
(26)	50 A	Ignition switch 2
(27)	15 A	Transmission
(28)	15 A	FI
(29)	10 A	CPRS R
(30)	-	Blank
(31)	5A	CNG IG1
(32)	5 A	Starter Signal
(33)	7.5A	CNG

(34)	200A	FL6
(35)	-	Blank

The main fuse, primary fuses and some of the individual fuses are located in the engine compartment. If the main fuse blows, no electrical component will function. If a primary fuse blows, no electrical component in the corresponding load group will function. When replacing the main fuse, a primary fuse or an individual fuse, use a genuine MARUTI SUZUKI replacement.

To remove a fuse, use the fuse puller provided in the relay box. The amperage of each fuse is shown in the back of the relay box cover.



55T090620

! WARNING

If the main fuse or a primary fuse blows, have your vehicle inspected by a Maruti Suzuki authorized workshop. Always use a genuine MARUTI SUZUKI replacement. Never use a substitute such as a wire even for a temporary repair, or extensive electrical damage and a fire can result.


NOTE:

Check that the relay box always carries spare fuses.

Fuses Under Dashboard



74TB09001




55T090590

INSPECTION AND MAINTENANCE

PRIMARY FUSE		
(1)	30 A	Power window
(2)	10 A	Meter
(3)	15A	Ignition coil
(4)	5A	Ignition-1 signal 2
(5)	20 A	Shift lever
(6)	10 A	Charging
(7)	10 A	Steering lock 2
(8)	20 A	Door Lock
(9)	15 A	Steering lock
(10)	10 A	Hazard
(11)	5A	A-STOP controller
(12)	10A	Rear fog lamp*
(13)	5 A	ABS / ESP® control module
(14)	15A	Seat heater*
(15)	5A	Ignition-1 signal 3
(16)	10 A	Dome light-2
(17)	5 A	Dome light
(18)	15 A	Radio
(19)	5 A	CONT
(20)	5 A	Key-2

(21)	20 A	Power window timer
(22)	5 A	Key
(23)	15 A	Horn
(24)	5 A	Tail light (Left)
(25)	10 A	Tail light
(26)	10 A	Air bag
(27)	10 A	Ignition-1 signal
(28)	10 A	Back up light
(29)	5 A	ACC-3
(30)	20 A	Rear defogger
(31)	10 A	Heated mirror*
(32)	15 A	ACC-2
(33)	5 A	ACC
(34)	10 A	Wiper
(35)	5 A	Ignition-2 signal
(36)	15 A	Washer
(37)	25 A	Front wiper
(38)	10 A	Stop light

* Feature not available in the vehicle



55T090630


WARNING

Always replace a blown fuse with a fuse of the correct amperage. Never use a substitute such as aluminum foil or wire to replace a blown fuse. If you replace a fuse and the new one blows in a short period of time, you may have a major electrical problem. Have your vehicle inspected immediately by your Maruti Suzuki authorized workshop.

Headlight Aiming

Since special procedures are required, ask a Maruti Suzuki authorized workshop for this job.

Bulb Replacement



55TB09012

No.	ITEM: Lights	WATT-AGE	BULB No.
(1)	Headlight	12V60W	HB3
(2)	Headlight* ¹	LED	–
(3)	Front Turn Signal light	12V21W	PY21W
(4)	Position light	12V5W	W5W
(5)	Front Turn Signal light, Position light and Daytime Running Light (D.R.L.) ¹	LED	–
(6)	Rear Turn Signal Light ¹	LED	–
(7)	Brake light ¹	LED	–
(8)	Reversing light ¹	LED	–
(9)	Tail light ¹	LED	–
(10)	High mount stop light ¹	LED	–
(11)	License plate light ¹	LED	–
(12)	Side Turn Signal light	12V5W	WY5W
(13)	Side Turn Signal light ¹	LED	–

INSPECTION AND MAINTENANCE

If you need to replace the following bulbs indicated in the above table, consult a Maruti Suzuki authorized workshop.

*1: Since the lights are non-disassembled type, you cannot replace a bulb. Replace the target assembly if any bulb is defective.

▲ CAUTION

- Light bulbs can be hot enough to burn your finger right after turning off lights. This is true especially for halogen headlight bulbs. Replace the bulbs after they become cool enough.
- The headlight bulbs are filled with pressurized halogen gas. They can burst and injure you if they are hit or dropped. Handle them carefully.
- To avoid injury by sharp-edged parts of the body, wear gloves and a long-sleeved shirt when replacing light bulbs.

NOTICE

- The oils from your skin may cause a halogen bulb to overheat and burst when the lights are on. Grasp a new bulb with a clean cloth.
- Frequent bulb replacement indicates the need for an inspection of the electrical system. This should be carried out by a Maruti Suzuki authorized workshop.
- During bulb replacement always use same bulb number as used in vehicle which is imprinted on the said bulb/unit and/or mentioned in this section.

NOTE:

The inner surface of lens such as the headlights or the rear combination lights may be clouded or dew condensation may occur by driving on a rainy day or washing the vehicle. This is a temporary phenomenon caused by temperature difference between the inside and the outside of the lights. (This is the same phenomenon as the windows are clouded on a rainy day.) Also, it sometimes seems that water gets into the lights because of water drop on the edge of the lens. This is a temporary phenomenon caused by water adherence to the outside of the lights.

The above-mentioned phenomena are not vehicle malfunction.

However, if water is piled up in the lights or large waterdrop adheres to the inner surface of lens, have your vehicle inspected by a Maruti Suzuki authorized workshop.

Non-disassembled Type Lights

Since the lights shown below are non-disassembled type, you cannot replace a bulb. Replace the target assembly if any bulb is defective.

If you need to replace the assembly, ask your Maruti Suzuki authorized workshop.


- Headlight (LED type) (if equipped)
- Position light and Daytime running light (LED type) (if equipped)
- Tail/brake light (LED type)
- Side turn signal light/hazard warning light on outside rearview mirrors (if equipped)
- High mount stop light
- Front Turn Signal Light (LED type)
- Rear Turn Signal Light
- License Plate Light

Headlights

LED headlights


Since special procedures are required, we recommend you take your vehicle to your Maruti Suzuki authorized workshop for light replacement.

Halogen headlights



55TB09011

(1) Headlight (high/low beam)




55TB0903

Disconnect the coupler (2) by pushing the lock release. Turn the bulb (3) counter-clockwise and remove it.


Side Turn Signal Light

Fender type (if equipped)



68PM00736


- 1) Remove the light housing (1) by sliding to left with your finger.



68PM00717

- 2) Turn the bulb holder (2) clockwise and pull it out from the light housing.

INSPECTION AND MAINTENANCE



- (4) Removal
(5) Install


3) To remove and install the bulb of the side turn signal light (3), simply pull out or push in the bulb.

Front Turn Signal Light and Front Position Light


Vehicle with the LED

For vehicle with the LED, Front turn signal light and front position light replacement, we recommend you to take your vehicle to the Maruti Suzuki authorized workshop as special procedure for the same is required.

Vehicle with the bulb



- 1) Open the engine hood. To remove the bulb holder of the front turn signal light or the front position light from the light housing, turn the holder counterclockwise and pull it out.



Outside Rearview Mirror Type (if equipped)

LED module is used. Since special procedures are required, we recommend you take your vehicle to your Maruti Suzuki authorized workshop for LED module replacement.

- (3) Removal
 (4) Installation

2) To remove the bulb of the front turn signal light (1) from the bulb holder, push in the bulb and turn it counterclockwise. To install a new bulb, push it in and turn it clockwise. To remove and install the bulb of the front position light (2), simply pull out or push in the bulb.

Daytime Running Light (D.R.L.) (if equipped)

For DRL replacement, we recommend you to take your vehicle to the Maruti Suzuki authorized workshop as special procedure for the same is required.

Rear Combination Light

For Rear Combination Light replacement, we recommend you to take your vehicle to the Maruti Suzuki authorized workshop as special procedure for the same is required.


License Plate Light

Since special procedures are required, it is recommended that you take your vehicle to a Maruti Suzuki authorized workshop for light replacement.

High Mount Stop Light


Since special procedures are required, it is recommended that you take your vehicle to a Maruti Suzuki authorized workshop for light replacement.

Interior Light Front (if equipped)



55T090450

- 1) To prevent scratches, insert a commercially available flat-blade screwdriver covered with a soft cloth into the notch (1), and then remove the lens (2).




55T090040

- (3) Removal
 (4) Install

- 2) Pull the bulb out and then insert a new one.
 3) After replacing the bulb, install the front interior light lens in the reverse order of removal.


Center



55T090460

- 1) To prevent scratches, insert a commercially available flat-blade screwdriver covered with a soft cloth into the notch (1), and then remove the lens (2).


INSPECTION AND MAINTENANCE



55T090050


- (3) Removal
- (4) Installation
- 2) Pull the bulb out and then insert a new one.
- 3) After replacing the bulb, install the center interior light lens in the reverse order of removal.

Luggage compartment (if equipped)



55T090470

- 1) To prevent scratches, insert a commercially available flat-blade screwdriver covered with a soft cloth into the notch (1), and then remove the lens (2).




55T090040

- (3) Removal
- (4) Install

- 2) Pull the bulb out and then insert a new one.


- 3) After replacing the bulb, install the luggage compartment light lens in the reverse order of removal.

Courtesy light (if equipped)



55T090480

- 1) To prevent scratches, insert a commercially available flat-blade screwdriver covered with a soft cloth into the notch (1), and then remove the lens (2).

Wiper Blades

59RN09450

If the wiper blades become brittle or damaged, or make streaks when wiping, replace the wiper blades.


To install new wiper blades, follow the procedures below.

NOTICE


To avoid scratching or breaking the window, do not let the wiper arm strike the window while replacing the wiper blade.

NOTE:

Some wiper blades may be different from the ones described here depending on vehicle specifications. If so, consult a Maruti Suzuki authorized workshop for proper replacement method.



55T090040

Glove box light (if equipped)

74TB09004

- (3) Removal
- (4) Install
- 2) Pull the bulb out and then insert a new one.
- 3) After replacing the bulb, install the courtesy light lens in the reverse order of removal.

- 1) Press inward on both sides of the glove box and pull frontward and then unclamp it.
- 2) To remove and install the bulb of the glove box light (1), simply pull out or push in the bulb.

Front footwell lights (if equipped)

Since special procedures are required, we recommend you take your vehicle to your Maruti Suzuki authorized workshop for light replacement.


INSPECTION AND MAINTENANCE

For Windshield Wipers




55TB0908

- 1) Hold the wiper arm away from the window.




59RN09240

- 2) Squeeze lock (1) towards wiper arm (2) and remove the wiper frame from the arm as shown.



59RN09250


- 3) Unlock the lock end of the wiper blade and slide the blade out as shown.



59RN09260

(3) Retainer


- 4) If the new blade is provided without the two metal retainers, move them from the old blade to the new one.



59RN09270

- (A) Up
(B) Down

NOTE:
When you install the metal retainers (3), make sure the direction of metal retainers as shown in the above illustration.




(4) Locked end


- 5) Install the new blade in the reverse order of removal, with the locked end positioned toward the wiper arm. Make sure the blade is properly retained by all the hooks. Lock the blade end into place.
- 6) Reinstall wiper frame to arm, making sure that the lock lever is snapped securely into the arm.

NOTICE

Fit the stopper side (5) of the wiper blade rubber in the driver's seat side. Otherwise, the wiper blade rubber may be misaligned while the wiper operates.

For Rear Window Wiper


- 1) Hold the wiper arm away from the window.
- 2) Remove the wiper frame from the arm as shown.



- 3) Slide the blade out as shown.

NOTE:

Do not flex the wiper blade frame end more than necessary. If you do, it can break off.




(1) Retainer

- 4) If the new blade is provided without the two metal retainers, move them from the old blade to the new one.
- 5) Install the new blade in the reverse order of removal. Make sure the blade is properly retained by all the hooks.
- 6) Reinstall wiper frame to arm in the reverse order of removal.

INSPECTION AND MAINTENANCE

Windshield Washer Fluid



68PM07022

Check that there is washer fluid in the tank. Refill it if necessary. Use a good quality windshield washer fluid, diluted with water as necessary.

⚠ WARNING

- Do not use radiator antifreeze in the windshield washer reservoir. This can severely impair visibility when sprayed on the windshield, and also can damage your vehicle's paint.
- Do not add washer fluid when the engine is hot or operating as washer fluid contains alcohol and may catch fire if spilled on the engine, etc.

NOTICE


- Damage may result if the washer motor is operated with no fluid in the washer tank.
- Avoid use of hard water to prevent building of lime scale on the vehicle.

Air Conditioning System

If you do not use the air conditioner for a long period, such as during winter, it may not give the best performance when you start using it again. To help maintain optimum performance and durability of your air conditioner, it needs to be run periodically. Operate the air conditioner at least once a month for one minute with the engine idling. This circulates the refrigerant and oil and helps protect the internal components.


Air Conditioner Filter Replacement

Since special procedures are required, ask a Maruti Suzuki authorized workshop for this job.



74TB09002

- 1) To approach the air conditioner filter, remove the glove box by pressing both sides of the glove box inward and pulling it out.



55T090070

- 2) Remove the cover (1) and pull out the air conditioner filter (2).

NOTE:

- When you install a new filter, check that the UP mark (3) faces upward.
- When you install the cover, check that the UP mark (4) faces upward.

Preparation Before Winter Season

Windshield Washer Fluid

To prevent windshield washer fluid from freezing, dilute it by the ratio according to outside temperature.

Lead-acid Battery

Check the liquid measure and the specific gravity of lead-acid battery. When it becomes cold, the battery performance gets worse. Also, it becomes difficult to start the engine by the weak battery. Refer to "Battery" in the "INSPECTION AND MAINTENANCE" section.


Engine Coolant

To prevent the inside of engine from corroding and freezing, use the designated engine coolant. Refer to "Specifications" in the "SPECIFICATIONS" section.

NOTE:

To check the concentration of engine coolant or replace it, ask a Maruti Suzuki authorized workshop.

Winter Tyres and Chocks



55T090670

- (1) Winter tyre
(2) Chock

Winter tyres and chocks are necessary to drive on the snow roads or the frozen roads.

INSPECTION AND MAINTENANCE

Before Your Driving

Snow on the Roof



80J308

Remove snow on the roof before your driving. If you do not remove it, snow may fall during your driving and it may hinder your view.

Frozen Wiper Blades




65P60060

Melt ice by pouring lukewarm water. After melting it, wipe off water to prevent refreezing. If you operate the wiper blades

forcedly when ice stays freezing, the wiper rubbers may be damaged and the wiper blades may be broken.


Snow and Frost on the Window Glasses



82K261

Use the plastic board (1). You can remove snow and frost not to damage the window glasses.

Frozen Outside Rearview Mirrors




65P60070

Melt ice by pouring lukewarm water. After melting it, wipe off water to prevent refreezing. If you operate the outside rearview mirrors forcedly when ice stays freezing, the outside rearview mirrors may be broken.

NOTICE

- For the outside rearview mirror folding switch, check if you can move the mirrors by your hands first. Then, operate the switch. If you repeat to operate the switch when ice stays freezing, the mirrors may be broken.
- For the remote folding mirrors, deactivate the function of the remote folding mirrors in the cold condition where the outside rearview mirrors are frozen. If you repeat to operate them when ice stays freezing, the mirrors may be broken.

Frozen Doors

65P60080

Pour lukewarm water except the keyhole on the door. After opening the door, wipe off water. If you open the door forcedly when ice stays freezing, the rubbers around the door may be come off and broken.

Snow Attaching to Shoes

80J312

Remove snow attaching to shoes before getting in your vehicle. If you do not

remove it, you may slip when operating the pedals and the window glasses may mist easily because of high humidity inside the vehicle.


When Parking the Vehicle Outside

80J315

NOTICE

- If you park the vehicle under eaves or trees, the roof of the vehicle may be dented by accumulated snow or fallen snow.
When it is snowing, do not park the vehicle under eaves or trees.
- If you park the vehicle outside when it is snowing, the wiper arms may be deformed or the wiper blades may be frozen on the windshield by snow weight. Raise the wiper arms away from the windshield when parking the vehicle.

EMERGENCY SERVICE



60G411

Towing by Tow Truck	10-1
Towing by Using Towing Eye	10-2
Tyre Changing Tool	10-4
Jacking Instructions	10-6
Flat tyre repair kit (if equipped)	10-11
Jump-starting Instructions	10-14
Running Out of Battery	10-16
If You Get a Flat Tyre While Driving	10-16
Engine Trouble: Starter Does not Operate	10-16
Engine Trouble: Does not Start	10-17
Engine Trouble: Overheating	10-17
Warning Triangle	10-18

EMERGENCY SERVICE

Towing by Tow Truck

If you need to have your vehicle towed, contact a professional service. Maruti Suzuki authorized workshop can provide you with detailed towing instructions.

WARNING

For vehicles equipped with the dual camera brake support, if your vehicle is towed with the engine on, press the dual camera brake support OFF switch and turn off the dual camera brake support. If not, an accident related to the system being turned on may occur.

NOTICE

To help avoid damage to your vehicle during towing, proper equipment and towing procedures must be used.

2-wheel Drive (2WD) Manual Transmission or Auto Gear Shift

Manual transmission vehicles or Auto Gear Shift may be towed using either of the following methods.

- Being towed from the front:
Lift the front wheels and keep the rear wheels on the ground. Before the vehicle is towed, make sure that the parking brake is released.
- Being towed from the rear:
Lifted and the front wheels on the ground, provided the steering and drive-train are in operational condition. Before towing, check that transmission is in neutral, the steering wheel is unlocked (vehicle without keyless push start system - the ignition key should be in "ACC" position) (vehicle with keyless push start system - the ignition mode is ACC), and the steering wheel is secured with a clamping device designed for towing service.


NOTICE

- After shifting the Auto Gear Shift gearshift lever to the "N" position, always check the gear position indicator in the instrument cluster shows the "N" position to make sure that the transmission is disengaged.
If the transmission cannot be put in neutral, turn the key from "LOCK" to "ON" position or press the engine switch to change the ignition mode to ON, and move the Auto Gear Shift gearshift lever from "N" to "D", "M" or "R", then back to "N" again. Then turn the key from "ON" to "LOCK" position or press the engine switch to change the ignition mode to LOCK (OFF).
These procedures may help put the transmission in neutral. If the transmission still cannot be put in neutral, you cannot tow the vehicle without using a towing dolly.
- The steering column is not strong enough to withstand shocks transmitted from the front wheels during towing. Always unlock the steering wheel before towing.

Towing by Using Towing Eye

Hanging Point of a Towing Cable

Hang a towing cable on a towing eye.
The towing eye is provided on the front of the vehicle for use in emergency situations or sea shipping purposes.




- 1) Remove the cover (1) by using a jack handle (2) covered with a soft cloth (3) as shown in the illustration.

NOTICE


Do not apply excessive force as it may damage the cover strap.

NOTE:

We recommend that you fasten the cover with tape to prevent damage during towing.




- 2) Install the towing eye (4) by hand.



- 3) To tighten the towing eye (4), turn it clockwise by using a wheel Wrench (5) until the towing eye (4) is securely installed.

NOTICE

- Observe the following instructions when using the towing eye (4). Otherwise, the towing eye or the vehicle body may break and cause serious injury or damage:
 - Avoid pulling the vehicle to get out of severe snowy, muddy or sandy conditions.
 - Avoid sudden starts or erratic driver performance which could cause excessive stress on the towing eye.
- In such cases, we recommend that you contact a professional service.
- Do not use the towing eye (4) for towing another vehicle or transporting your vehicle by a car carrier trailer, etc.



55TB1004

NOTICE

- Your vehicle was originally designed to carry people and a normal amount of cargo, not to tow a trailer.
- The frame hook (6) is provided on the rear of the vehicle for use in emergency situations and sea shipping purposes only. Do not use the frame hook for towing another vehicle, being towed by another vehicle or transporting your vehicle by a car carrier trailer, etc. Otherwise, the frame hook or the vehicle body may break and cause serious injury or damage.

Towing by Using a Rope

- Hang a towing cable on a towing eye horizontally, so that the hanging side would be the same for the towing vehicle and the towed vehicle if possible.
- Keep the engine running.
 - When you cannot start the engine, press the engine switch to change the ignition mode to the position other than LOCK (OFF).
 - Turn the steering wheel to left and right to check that the steering lock is released.

⚠ WARNING

If you drive the vehicle without the engine running, it may cause an accident.

When your vehicle is towed by using a rope, observe the following instructions.

- Do not press the engine switch to change the ignition mode to LOCK (OFF). Otherwise, the steering wheel will be locked and not be turned.

(Continued)

⚠ WARNING

(Continued)

- Depress the brake pedal more firmly than usual, as the brake booster does not work.
- Operate the steering wheel with more force, as the power steering system does not work.

NOTICE

If you cannot release the steering lock, you cannot operate the steering wheel and it may cause an accident. If you cannot release the steering lock because of malfunction and running out of the lead-acid battery, do not perform towing by using a rope.

- Shift the gearshift lever into "N".

NOTE:

- If you cannot shift the gearshift lever into "N", towing by using a towing cable is not possible. Consult a Maruti Suzuki authorized workshop.
- If you cannot shift the gearshift lever from "P" to the other position with the engine running and the brake pedal depressed, because of malfunction and running out of the lead-acid battery, cancel the shift lock system referring to "Canceling the Shift Lock System" in the "OPERATING YOUR VEHICLE" section.

- 4) During towing, make sure that a towing cable is not slack. To avoid a collision, carefully drive your vehicle checking the brake lights of the front vehicle.
- To warn the driver of a following vehicle, turn on the hazard warning lights of the towed vehicle.


WARNING

If you continuously depress the brake pedal on a long or steep down-hill slope, the brakes could overheat and become ineffective.
When there is a long or steep down-hill slope, do not perform towing by a rope. Make a request of a tow truck.

NOTICE

- If a strong impact is applied to a towing eye or a towing cable by sudden starting etc., the towing eye or the vehicle body may be damaged.
When the vehicle needs to be towed, do not apply a strong impact to a towing eye or a towing cable by sudden starting etc.
Do not accelerate suddenly.
- If the vehicle unavoidably needs to be towed by a rope, tow your vehicle on paved roads. Do not exceed the vehicle speed of 30 km/h and do not drive the vehicle for longer than 30 km to protect the transmission.

Tyre Changing Tool



74TB01003

- (1) Jack
(2) Wheel brace
(3) Jack handle
(4) Towing eye

NOTE:


For vehicle fitted with CNG fuel system, refer to the supplementary owner's manual.

The tyre changing tools are stowed in the luggage compartment.
Refer to "Luggage Compartment" in "QUICK GUIDE" section.

When using the jack, check that there is no deformation or damage on the jack.
Also, check that there is no dirt on the screw part and grease is applied on it.

The tyre changing tools are stowed in the luggage compartment, below luggage compartment boards.


To remove the luggage compartment board easily, lift the board from the hole provided on the board and pull it out.



55TB1006

To remove the jack (1), turn its shaft counterclockwise by using jack handle (3) and pull the jack out of the storage bracket.

EMERGENCY SERVICE



55RM08003

NOTE:

If you are facing difficulty to use the jack handle (3) alone, use jack handle (3) and wheel wrench (2) together as shown in the illustration for removal of jack.

To stow the jack (1), place it in the storage bracket and turn the shaft clockwise until the jack is securely held in place.


NOTICE

To avoid damaging the storage bracket, do not expand the jack excessively.



55TB1007

To stow the jack (1), place it in the storage bracket (5) and turn the shaft clockwise with the hand.



74TB07013

After temporarily tightening the jack till it contacts the jack holder bracket, turn the shaft approximately 90° to 180° by using


jack handle (3) to securely hold the jack in place.

WARNING

After using the tyre changing tools, be sure to stow them securely or they can cause injury if an accident occurs.


CAUTION

The jack should be used only to change wheels. It is important to read the jacking instructions in this section before attempting to use the jack.



68PM08007

To remove the spare tyre, turn the bolt (7) counterclockwise and remove it.



68PM08008

Return the spare tyre back into the luggage compartment in the reverse order of removal and tighten its bolt (7) clockwise as shown in the above illustration.

While replacing tyre with alloy wheel make sure to remove the wheel cap before keeping the tyre in the trunk.

NOTICE

Make sure that the spare tyre is fixed securely on the floor. Loosely fixed tyre may cause noise during driving and damage paint on vehicle body.


Jacking Instructions

- 1) Place the vehicle on level, hard ground.
- 2) Set the parking brake firmly and shift into "R" (Reverse) if your vehicle has a manual transmission or Auto Gear Shift.

! WARNING


- Shift into "P" (Park) when you jack up the vehicle.
- Never jack up the vehicle with the transmission in "N" (Neutral). Otherwise, unstable jack may cause an accident.

- 3) Turn on the hazard warning switch if your vehicle is near traffic.




59RN10010

- 4) Block the front and rear of the wheel diagonally opposite to the wheel being lifted.




59RN10120



59R80200

- 5) Position the jack at an angle as shown in the illustration and raise the jack by turning the jack handle clockwise until the jack-head groove fits around the jacking bar boss (1)beneath the vehicle body.



81PN117

- 6) Continue to raise the jack slowly and smoothly until the tyre clears the ground. Do not raise the vehicle more than necessary.



⚠ WARNING

- Use the jack only to change wheels on level, hard ground.
- Never jack up the vehicle on an inclined surface.
- Never raise the vehicle with the jack in a location other than between the frame bosses near the wheel to be changed.
- Make sure that the jack is raised at least 25 mm (1 inches) before it contacts the boss. Use of the jack when it is within 25 mm (1 inches) of being fully collapsed may result in failure of the jack.
- Do not use wooden blocks or similar objects as a jack underlay.
- No person should place any portion of their body under a vehicle that is supported by a jack. Never place your hands or feet under the raised vehicle when it is supported by a jack.
- Never run the engine when the vehicle is supported by the jack and never allow passengers to remain in the vehicle.

Raising Vehicle with Garage Jack

- Apply the garage jack to one of the points indicated below.
- Always support the raised vehicle with jack stands (commercially available) at the points indicated below.

- (1) Front
- (2) Rear
- (3) Jack stand
- (4) Garage jack
- (5) Jacking point for garage jack



- (a) Specified position of jack stand for the front side
 (b) Specified position of jack stand for the rear side

NOTICE

If you use the jack stand (2) in the condition that it touches the side skirt (6), the side skirt may be broken or damaged.

When using the jack stand, make sure that it does not touch the side skirt.

NOTE:

For more details, consult a Maruti Suzuki authorized workshop.

EMERGENCY SERVICE

Changing Wheels

⚠ WARNING

Never change a wheel in traffic lane. Always move the vehicle off the road on level, hard ground away from traffic for changing a wheel. For any further assistance contact your nearest Maruti Suzuki authorized workshop.

To change a wheel, use the following procedure:

- 1) Prepare the jack and tools.
- 2) Loosen, but do not remove the wheel nuts.
- 3) Jack up the vehicle (follow the jacking instructions in this section).


⚠ WARNING

- Shift into "R" (Reverse) for a manual transmission or Auto Gear Shift vehicle when you jack up the vehicle.
- Never jack up the vehicle with the transmission in "N" (Neutral). Otherwise, unstable jack may cause an accident.

⚠ CAUTION


Immediately after the vehicle has been driven, the wheels, the wheel nuts and the area around the brakes might be extremely hot. Touching these areas may cause burn injury. Do not touch these areas, immediately after the vehicle has been driven.

- 4) Remove the wheel nuts and wheel.



84S08170


- 5) Clean any mud or dirt off from the surface of the wheel (1), hub (2), thread part (3) and surface of the wheel nuts (4) with a clean cloth. Clean the hub carefully; it may be hot from driving.
- 6) Install the new wheel and replace the wheel nuts with their cone shaped end facing the wheel. Tighten each nut snugly by hand until the wheel is securely seated on the hub.

**Tightening torque for wheel nuts****100 Nm (10.2 kg-m, 74.0 lb-ft)**

- 7) Lower the jack and fully tighten the nuts with a wrench in numerical order as shown in the illustration.

WARNING


Use genuine wheel nuts and tighten them to the specified torque as soon as possible after changing wheels. Incorrect wheel nuts or improperly tightened wheel nuts may come loose or fall off, which can result in an accident. If you do not have a torque wrench, have the wheel nut torque checked by an authorized Maruti Suzuki authorized workshop.



Return the spare tyre back into the luggage compartment in the reverse order of removal and tighten its bolt (1) clockwise as shown in the above illustration.

NOTICE


Make sure that the spare tyre is fixed securely on the floor. Loosely fixed tyre may cause noise during driving and damage paint on vehicle body.

Full Wheel Cover (if equipped)

(1) or (2) Flat end tool

Your vehicle includes two tools, a wheel wrench and a jack crank, one of which has a flat end.

Use the tool with the flat end with soft cloth (3) to remove the full wheel cover, as shown above.



When installing the cover, make sure that it is positioned so that it does not cover or foul the air valve.

EMERGENCY SERVICE

Flat tyre repair kit (if equipped)

The flat tyre repair kit is stowed in the luggage compartment.

Refer to "LUGGAGE COMPARTMENT" in "ILLUSTRATED TABLE OF CONTENTS" section.

⚠ WARNING

Failure to follow the instructions in this section for using the flat tyre repair kit can result in an increased risk of loss of control and an accident.

Carefully read and follow the instructions in this section.

IMPORTANT


The flat tyre repair kit cannot be used in the following cases. Consult a Maruti Suzuki authorized workshop.

- Cuts or piercing in the tyre tread larger than approx. 4 mm.
- Cuts in the tyre side wall.
- tyre damage caused by driving with considerably reduced tyre pressure or even with deflated tyre.
- The tyre bead completely unseated outside of the rim.
- The rim damaged.
- The valve damaged.

Small punctures in the tyre tread, caused by a nail or a screw, can be sealed with the flat tyre repair kit.

Do not remove nails or screws from the tyre during an emergency repair.

Flat tyre repair kit contents



74TB01004

- (1) Air compressor
- (2) Sealant bottle
- (3) Speed restriction sticker (with sealant bottle)
- (4) Filler hose
- (5) Power plug
- (6) Air hose

⚠ WARNING


Flat tyre repair kit sealant is harmful if swallowed, or if it comes in contact with skin or eyes. If swallowed, do not induce vomiting. Give plenty of water (if possible charcoal slurry) and seek medical attention immediately. If sealant gets in eyes, flush eyes with water and seek medical attention. Wash thoroughly after handling. Solution can be poisonous to animals. Keep out of the reach of children and animals.

NOTICE

Replace the sealant before expiry date indicated on the label of the sealant bottle. To purchase new sealant, see your Maruti Suzuki authorized workshop.

Emergency repair

- 1) Place the vehicle on level, hard ground. Set the parking brake firmly and shift into "P" (Park) if your vehicle has an automatic transaxle, or shift into "R" (Reverse) if your vehicle has a manual transaxle. Turn on the hazard warning flasher if your vehicle is near traffic. Block the front and rear of the wheel diagonally opposite of the wheel being repaired.
- 2) Take out the sealant bottle and the compressor.
- 3) Screw the bottle into the socket of the compressor.
- 4) Unscrew the valve cap from the tyre valve.
- 5) Connect the filler hose of the sealant bottle to the tyre valve.
- 6) Connect the power plug of the compressor to the accessory socket. For a manual transmission vehicle, shift from "R" (Reverse) into "N" (Neutral). Start the engine. Switch on the compressor. Inflate the tyre to the required air pressure (*).



74TB01005

- (1) tyre valve
- (2) Filler hose
- (3) Compressor
- (4) Power plug

NOTICE

Do not operate the compressor for longer than 10 minutes. It can cause overheating of the compressor.

If the tyre cannot be inflated to the required air pressure within 5 minutes, move the vehicle a few meters back and forth to spread the sealant over the entire tyre. Then, inflate the tyre again.

If the tyre still cannot be inflated to the required air pressure, the tyre may be severely damaged. In this case, the flat tyre repair kit cannot provide the neces-


EMERGENCY SERVICE

sary seal. consult with a Maruti Suzuki authorized workshop.

NOTE:

If the tyre is over-inflated, deflate air by loosening the filler hose.

- 7) Switch off the compressor. Pull out the power plug from the accessory socket.
- 8) Disconnect the filler hose of the sealant bottle from the tyre valve.
- 9) Push the release button on side and detach the sealant bottle.



74TB01007

(5) Release button

10)Affix the speed restriction label from the sealant bottle in the driver's field of view.

11)Make a short drive immediately after inflating the tyre to the required air pressure. Drive carefully with a maximum speed of 80 km/h (50 mph).

12)Carry on driving carefully to the nearest Maruti Suzuki authorized workshop or a tyre repair shop.

⚠ WARNING

Do not affix the speed restriction label to the air bag. Also do not affix it to the warning light indicator or to the speedometer.

13)After driving for up to 10 minutes, check the tyre pressure with the pressure gauge of the compressor. If the air pressure indicates more than required air pressure (*), the emergency repair is completed. But, if the air pressure indicates less than the required air pressure (*), correct the tyre pressure to the required air pressure (*). If the tyre pressure has dropped below 130 kPa (1.3 bar), the flat tyre repair kit cannot provide the necessary seal. Do not use the tyre and consult with a Maruti Suzuki authorized workshop.

⚠ WARNING

Check the tyre pressure and confirm the completion of the emergency repair after driving for up to 10 minutes.

NOTICE

Have the tyre renewed at the nearest Maruti Suzuki authorized workshop. When reusing the sealed tyre, consult a tyre repair shop.

The wheel can be reused after wiping sealant off completely with cloth in order to prevent rust, but the tyre valve must be renewed.

Dispose of the sealant bottle at a Maruti Suzuki authorized workshop or in accordance with your regional codes and practices.

After using the sealant bottle, replace it with a new bottle from a Maruti Suzuki authorized workshop.

Using compressor to inflate a tyre

- 1) Place the vehicle on level, hard ground. Set the parking brake firmly and shift into "P" (Park) if your vehicle has an automatic transaxle, or shift into "R" (Reverse) if your vehicle has a manual transaxle.
- 2) Take out the compressor.
- 3) Unscrew the valve cap from the tyre valve.
- 4) Connect the air hose of the compressor to the tyre valve.
- 5) Connect the power plug of the compressor to the accessory socket. Start the engine. Switch on the compressor. Inflate the tyre to the required air pressure (*).

NOTICE

Do not operate the compressor for longer than 10 minutes. It can cause overheating of the compressor.

NOTE:

(*) Air pressure mentioned in tyre information label, located on the driver's door lock pillar.

Jump-starting Instructions

⚠ WARNING


- Never attempt to jump-start your vehicle if the lead-acid battery appears to be frozen. Batteries in this condition may explode.
- When making jump lead connections, check that your hands and the jump leads remain clear from pulleys, belts or fans.
- Lead-acid batteries produce flammable hydrogen gas. Keep flames and sparks away from the battery or an explosion may occur. Never smoke when working near the battery.
- If the booster battery you use for jump-starting is installed in another vehicle, check that the two vehicles are not touching each other.
- If your lead-acid battery discharges repeatedly, for no apparent reason, have your vehicle inspected by a Maruti Suzuki authorized workshop.
- To avoid harm to yourself or damage to your vehicle or battery, follow the jump-starting instructions below.
If you are in doubt, call for qualified road service.

NOTICE

Your vehicle should not be started by pushing or towing. This starting method could result in permanent damage to the catalytic converter. Use jump leads to start a vehicle with a weak or flat battery.

- 1) Use only a 12-volt lead-acid battery to jump-start your vehicle. Position the good 12-volt lead-acid battery close to your vehicle so that the jump leads will reach both batteries. When using a battery installed on another vehicle, check that two vehicles do not touch each other. Set the parking brakes fully on both vehicles.
- 2) Turn off all vehicle accessories, except those necessary for safety reasons (for example, headlights or hazard lights).

EMERGENCY SERVICE



55T100150

3) Connect jump leads as follows:

1. Connect one end of the first jump lead to the positive (+) terminal of the discharged battery (1).

2. Connect the other end to the positive (+) terminal of the booster battery (2).
3. Connect one end of the second jump lead to the negative (-) terminal of the booster battery (2).
4. Make the final connection to an unpainted, heavy metal part (i.e. engine mount bolt (3)) of engine cylinder head in the vehicle with the discharged battery (1).

WARNING

Never connect the jump lead directly to the negative (-) terminal of the discharged battery, or an explosion may occur.

CAUTION

Connect the jump lead to the engine mount bolt securely. If the jump lead disconnects from the engine mount bolt because of vibration at the start of the engine, the jump lead could be caught in the drive belts.

- 4) If the booster battery you are using is fitted to another vehicle, start the engine of the vehicle with the booster battery. Run the engine at moderate speed.
- 5) Start the engine of the vehicle with the discharged battery.
- 6) Remove the jump leads in the exact reverse order in which you connected them.

Running Out of Battery

In the following cases, the lead-acid battery is running out.

- The starter does not engage when attempting to turn on the engine. Or, the starter rotation is too weak to make the engine start.
- The headlight illumination is extremely low or the horn volume is low.

If You Get a Flat Tyre While Driving

Firmly hold the steering wheel and carefully apply the brakes to slow down the vehicle and stop it in a safe place.

Engine Trouble: Starter Does not Operate

- 1) Try turning the ignition mode to START with the headlights turned on to determine the lead-acid battery condition. If the headlights go excessively dim or go off, it usually means that either the lead-acid battery is discharged or the battery terminal contact is poor. Recharge the lead-acid battery or correct battery terminal contact as necessary.
- 2) If the headlights remain bright, check the fuses. If the reason for failure of the starter is not obvious, there may be a major electrical problem. Have the vehicle inspected by a Maruti Suzuki authorized workshop.

EMERGENCY SERVICE

Engine Trouble: Does not Start

Make sure that your vehicle has enough fuel and battery.

If the engine does not start under very cold condition, press the accelerator pedal all the way to the floor and hold it while cranking the engine.

Refer to "Starting / Stopping Engine (Vehicle without Keyless Push Start System) (if equipped)" or "Starting / Stopping Engine (Vehicle with Keyless Push Start System) (if equipped)" in "OPERATING YOUR VEHICLE" section.

If the engine still does not start have your vehicle inspected at a Maruti Suzuki authorized workshop.

- Do not operate the starter motor for more than 12 seconds.

NOTE:

If the engine refuses to start, the starter motor automatically stops after a certain period of time. After the starter motor has automatically stopped or if there is anything abnormal in the engine starting system, the starter motor runs only while the engine switch is held pressed.

Engine Trouble: Overheating

The engine could overheat temporarily under severe driving conditions. If the high engine coolant temperature warning light comes on as overheating or the engine coolant temperature gauge indicates overheating during driving:

- 1) Turn off the air conditioner.
- 2) Take the vehicle to a safe place and park.
- 3) Run the engine at a normal idle speed for a few minutes until the high engine coolant temperature warning light goes off or the indicator is within the normal, acceptable temperature range between "H" and "C".

⚠ WARNING


If you see or hear escaping steam, stop the vehicle in a safe place and immediately turn off the engine to cool it. Do not open the hood when steam is present. When the steam can no longer be seen or heard, open the hood to see if the coolant is still boiling. If it is, you must wait until it stops boiling before you proceed.

If the high engine coolant temperature warning light does not go off or the temperature indication does not come down to within the normal, acceptable range:

- 1) Turn off the engine and check that the water pump belt and pulleys are not damaged or slipping. If any abnormality is found, correct it.
- 2) Check the coolant level in the reservoir. If it is found to be lower than "LOW" line, check radiator, water pump, radiator hoses and heater hoses for leakage. If leakage that may cause overheating is found, do not run the engine until these problems have been corrected.
- 3) If leakage is not found, carefully add coolant to the reservoir and then the radiator, if necessary. (Refer to "Engine coolant" in "INSPECTION AND MAINTENANCE" section.)

NOTE:

If engine overheats and you are not sure what to do, contact a Maruti Suzuki authorized workshop.




79J007

⚠ WARNING


- It is hazardous to remove the radiator cap when the water temperature is high, because scalding fluid and steam may be blown out under pressure. The cap should only be taken off when the coolant temperature has lowered.
- To help prevent personal injury, keep hands, tools and clothing away from the engine cooling fan and air-conditioner fan. These electric fans can automatically turn on without warning.

Warning Triangle




55T100010

In case of vehicle break-down or during emergency stopping, where, your vehicle could become a potential traffic hazard, keep the warning triangle, provided with your vehicle, on the road free from any obstacles behind your vehicle so as to warn the approaching traffic, at an approximate distance of 50-100 m. The reflecting side of the triangle should face the oncoming traffic. Please activate the hazard warning lamps before alighting the vehicle to keep the warning triangle.




55T100020

- Remove the warning triangle carefully from the cover as shown by arrow (1).
- Open both the reflector arms as shown by arrow (2) and lock the arms with each other with the clip provided in the right arm. Open the bottom stand in counter clock-wise direction as shown by arrow (3). Position the warning triangle behind the vehicle on a plain surface.
- Reverse the removal procedure for keeping inside the cover.



55T100030

APPEARANCE CARE



60G412

Corrosion Prevention	11-1
Cleaning Exterior	11-2
Cleaning Interior	11-6

APPEARANCE CARE

Corrosion Prevention

It is important to take good care of your vehicle to protect it from corrosion. Listed below are instructions for how to maintain your vehicle to prevent corrosion. Please read and follow these instructions carefully.

Important Information about Corrosion

Common causes of corrosion

- 1) Accumulation of road salt, dirt, moisture or chemicals in hard-to-reach areas of the vehicle underbody or frame.
- 2) Chipping, scratches and any damage to treated or painted metal surfaces resulting from minor accidents or abrasion by stones and gravel.
- 3) Any or all of the below mentioned points:
 - Continuous exposure to sunlight
 - Hard water & sea water coming in contact with vehicle.
 - Foot rubbing (skirting).

Environmental conditions which accelerate corrosion

- 1) Road salt, dust control chemicals, sea breeze or industrial pollution will all accelerate the corrosion of metal.
- 2) High humidity will increase the rate of corrosion particularly when the temperature range is just above the freezing point.

- 3) Moisture in certain areas of a vehicle for an extended period of time may promote corrosion even when other body sections are completely dry.
- 4) High temperatures will cause an accelerated rate of corrosion to parts of the vehicle which are not well-ventilated to permit quick drying.

This information illustrates the necessity of keeping your vehicle (particularly the underbody) as clean and dry as possible. It is equally important to repair any damage to the paint or protective coatings as soon as possible.

How to Help Prevent Corrosion

Wash your vehicle frequently

The best way to preserve the finish on your vehicle and to help avoid corrosion is to keep it clean with frequent washing.

Wash your vehicle at least once during the winter and once immediately after the winter. Keep your vehicle, particularly the underside, as clean and dry as possible. If you frequently drive on salted roads, your vehicle should be washed at least once a month during the winter. If you live near the ocean, your vehicle should be washed at least once a month throughout the year.

For washing instructions, refer to "Cleaning Exterior" section.

Remove foreign material deposits

Foreign materials such as salts, chemicals, road oil or tar, tree sap, bird droppings and industrial fall-out may damage the finish of your vehicle if it is left on painted surfaces. Remove these types of deposits as quickly as possible. If these deposits are difficult to wash off, an additional cleaner may be required. Check that any cleaner you use is not harmful to painted surfaces and is specifically intended for your purposes. Follow the manufacturer's directions when using these special cleaners.

Repair finish damage

Carefully examine your vehicle for damage to the painted surfaces. Should you find any chips or scratches in the paint, touch them up immediately to prevent corrosion from starting. If the chips or scratches have gone through to the bare metal, have a qualified body shop make the repair.

Keep passenger and luggage compartments clean

Moisture, dirt or mud can accumulate under the floor mats and may cause corrosion. Occasionally, check under these mats to ensure that this area is clean and dry. More frequent checks are necessary if the vehicle is used for off-road driving or in wet weather.

Certain cargos such as chemicals, fertilizers, cleaners, salts, etc. are extremely corrosive by nature. These products should be transported in sealed containers. If they are spilled or leaked, clean and dry the area immediately.

Park your vehicle in a dry, well-ventilated area

Park your vehicle to save it from continuous exposure to direct sunlight. Do not park your vehicle in a damp, poorly-ventilated area. If you often wash your vehicle in the garage and place it there in wet condition, your garage may be damp. The high humidity in the garage may cause or accelerate corrosion. A wet vehicle may corrode even in a heated garage if the ventilation is poor.

⚠ WARNING

Do not apply additional undercoating or rust preventive coating on or around exhaust system components such as the catalytic converter and the exhaust pipes. It may catch a fire if the undercoating substance becomes overheated.

Cleaning Exterior


For Keeping the Paintwork Beautiful

To keep your vehicle's beautiful appearance for a long term, daily care is important.

- For parking and storing the vehicle, we recommend garages with good ventilation and locations with roofs.
- The following situations may cause rusting and discoloration of the paint. Wash your vehicle promptly.
 - When driving in coastal areas or on roads sprayed with antifreeze agent (Wash the underside of the vehicle and around the wheel wells especially)
 - When bird droppings, dead insects, sap, iron dust, soot or smoke residue, coal tar, etc., adhere to the paint or when the vehicle gets wet with acid rain
 - When the vehicle is dirty with dust or mud
- Give the vehicle a wax about once a month or whenever the water-repelling ability of the painted surfaces has declined. Follow all instructions on the package of the wax (sold separately).

NOTE:

Do not use wax on plastic parts that are not coated. Waxing these surfaces could result in a whitened or uneven appearance.



80J302

- Chips from flying rocks, scratches, etc. can cause rust. Repair these areas as soon as possible.

NOTICE

- When repairing scratches on painted surfaces, consult a Maruti Suzuki authorized workshop. Using an inappropriate material for repair could cause damage to the paint.
- It is important that your vehicle be kept clean and free from dirt. Failure to keep your vehicle clean may result in fading of the paint or corrosion to various parts of the vehicle body.

APPEARANCE CARE

Washing

⚠ WARNING

- Never attempt to wash and wax your vehicle with the engine running.
- When cleaning the underside of the body and fender, where there may be sharp-edged parts, wear gloves and a long-sleeved shirt to protect your hands and arms from being cut.
- After washing your vehicle, carefully test the brakes before driving to check that they have maintained their normal effectiveness.

NOTICE



84S09240

- When washing or waxing the vehicle, do not lean on the vehicle body or do not push it hard.
This might cause it to deform.

(Continued)

NOTICE

(Continued)



55T110010

- When washing or waxing the vehicle, do not put your foot on the door opening.
This might cause it to damage.

Washing by hand



80J303

When washing the vehicle, park it in the place where direct sunlight does not fall on it as much as possible and follow the instructions below:

- 1) Flush the underside of body and wheel housings with pressurized water to remove mud and debris. Use plenty of water.



68PM09005

- 2) Rinse the body to loosen the dirt. Remove dirt and mud from the body exterior with running water. You may use a soft sponge or brush. Do not use hard materials which can scratch the paint or plastic. Remember that the headlight covers or lenses are made of plastic in many cases.

NOTICE

When washing the vehicle:

- Avoid directing steam or hot water of more than 80°C (176°F) on plastic parts.
- To avoid damaging engine components, do not use pressurized water in the engine compartment.

NOTICE

To avoid damage to the paint or plastic surface, do not wipe the dirt off without ample water. Follow the above procedure.

- 3) Wash the entire exterior with a mild detergent or car wash soap using a sponge or soft cloth. The sponge or cloth should be frequently soaked in the soap solution.

NOTICE

When using a commercial car wash product, observe the cautions specified by the manufacturer. Never use strong household detergents or soaps.

- 4) Once the dirt has been completely removed, rinse off the detergent with running water.
- 5) Wipe off the vehicle body with a wet chamois or cloth and allow it to dry in the shade.
- 6) Check carefully for damage to painted surfaces. If there is any damage, touch up the damage following the procedure below:
 1. Clean all damaged spots and allow them to dry.
 2. Stir the paint and touch up the damaged spots lightly using a small brush.
 3. Allow the paint to dry completely.

APPEARANCE CARE

Washing by an automatic car wash

NOTICE

If you use an automatic car wash, check that your vehicle's body parts, such as antenna, cannot be damaged. If you are in doubt, consult the car wash operator for advice.

Washing by a high-pressure cleaner

NOTICE

If you use a high-pressure cleaner, keep away the nozzle from your vehicle sufficiently.

- Pointing the nozzle to the surrounding parts of camera can allow water to enter the camera. This may cause a fire, malfunction, dew condensation, etc.
- For vehicle with 360 view camera or rear view camera, do not point to the nozzle to the camera.
- Bringing the nozzle to your vehicle too close or pointing the nozzle to the opening of front grill or bumper etc. can cause damage and malfunction of the vehicle body and parts.
- Pointing the nozzle to door glasses and door frames can allow water to enter the cabin.

Caring for the Windshield

If an oil film, etc. adheres to the windshield and the windshield wipers cannot clean it, use a glass cleaner (sold separately) to clean the windshield by hand.

Caring for Lights

Wash the lens part of light and wipe it off with a soft cloth.

NOTICE

- Do not use the detergent including organic solvent on the lens surface of the light. The lens surface may be cracked.
If you use the detergent including organic solvent, rinse it off with ample water.
- Do not wipe the lens surface by wax or a hard brush. This may damage the lens or hasten its deterioration.

Caring for Cameras

Wash the lens part of camera and wipe it off with a soft cloth. If the lens part is very dirty, use a mild detergent.

NOTICE


- Using alcohol, benzine, thinner etc. to wipe the camera may cause discoloration.
When you wipe the camera, do not use alcohol, benzine, thinner etc.
- Hard coating is used for the lens of camera not to be easily scratched. However, if you use the brush for a vehicle, it may be difficult for you to see the image on the 360 view camera.
Be very careful not to scratch the lens.
- The resin cover of the camera may be damaged if an organic solvent adheres to the camera.
Do not let organic solvent, body wax, oil film remover, or glass coating agent adhere to the product.
- If the camera is subjected to a sudden temperature change, it may be damaged.
Do not expose the camera to sudden temperature changes such as melting frozen snow with hot water.

Caring for Aluminum Wheels

NOTE:

- Do not use an acidic or alkaline detergent, or a cleaner containing petroleum solvent to wash aluminum wheels. These types of cleaners will cause permanent spots, discoloration and cracks on the finished surface and damage to the center cap.
- Do not use a bristle brush and a soap containing an abrasive material. These will damage the finished surface.

Waxing



74TB011001

After washing the vehicle, waxing and polishing are recommended to further protect and beautify the paint.

- Only use waxes and polishes of good quality.
- When using waxes and polishes, observe the precautions specified by the manufacturers.

Cleaning Interior

- Clean out any dirt, sand, etc. using a vacuum cleaner, or wipe off the surfaces using a soft cloth moistened with cold or lukewarm water. If the interior is left dirty, scratches can occur.
- Quickly clean off any liquids such as those from air fresheners or spilled beverages by using tissue paper or a soft cloth. Leaving spilled liquids can cause staining, discoloration or cracking.

⚠ WARNING

- Do not spray the interior with water or other liquids. If the navigation equipment, audio components, switches, wiring under the floor, or other electrical parts become wet, there is a risk of fire or malfunction, and the SRS airbag system could fail to function normally.
If you pour water or spill a drink in the vehicle, consult a Maruti Suzuki authorized workshop as soon as possible for inspection.

APPEARANCE CARE

NOTICE

- Do not use chemical products containing the following ingredients. Doing so may cause staining, discoloration, deformation, or a deterioration in strength, etc.
 - Solvents such as benzine, gasoline, thinner, or sticker peeling agents
 - Acidic or alkaline detergents
 - Bleaches or dyes
- Do not use chemical products that include silicone for cleaning the areas around the air conditioner, electronic equipment such as the audio or navigation systems or switches. Contact with silicone may cause them to malfunction.
- Do not leave colored leather goods, furs, vinyl articles, etc. in your vehicle for long periods. Doing so could cause discoloration or deformation of the interior.

NOTE:

To prevent liquid-based air fresheners from spilling, it is recommended to fix their containers in place, or use solid-type air fresheners instead.

Vinyl Upholstery

Prepare a solution of soap or mild detergent dissolved in warm water. Apply the solution to the vinyl with a sponge or soft cloth and let it soak for a few minutes to loosen dirt.

Rub the surface with a clean, damp cloth to remove dirt and the soap solution. If some dirt still remains on the surface, repeat this procedure.

Fabric Upholstery

Remove loose dirt with a vacuum cleaner. Using a mild soap solution, rub stained areas with a clean damp cloth. To remove soap, rub the areas again with a cloth dampened with water. Repeat this until the stain is removed, or use a commercial fabric cleaner for tougher stains. If you use a fabric cleaner, carefully follow the manufacturer's instructions and precautions.

Leather Upholstery

Remove loose dirt with a vacuum cleaner. Using a mild soap or saddle soap solution, wipe dirt off with a clean damp soft cloth. To remove soap, wipe the areas again with a soft cloth dampened with water. Wipe the areas dry with a soft dry cloth. Repeat this until the dirt or stain is removed, or use a commercial leather cleaner for tougher dirt or stains. If you use a leather cleaner, carefully follow the manufacturer's instructions and precautions. Do not use solvent type cleaners or abrasive cleaners.

NOTE:

- In order to keep the leather upholstery looking good, it should be cleaned at least twice a year.
- If the leather upholstery becomes wet, immediately wipe it dry with a tissue paper or a soft cloth. Water may cause the leather to harden and shrink if it is not wiped off.
- When parking on sunny days, select a shady place or use a sunshade. If the leather upholstery is exposed to the direct sunlight for a long time, it may discolor and shrink.
- As is common with natural materials, leather is inherently irregular in grain and cowhide has spots in its natural state. These do not affect the performance of the leather in any way.

Seat Belts

Clean seat belts with mild soap and water. Do not use bleach or dye on the belts. They may weaken the fabric of the belts.

Vinyl Floor Mats

Ordinary dirt can be removed from vinyl with water or the mild soap. Use a brush to help loosen dirt. After the dirt is loosened, rinse the mat thoroughly with water and dry it in the shade.

Carpets

Remove the dirt and soil as much as possible with a vacuum cleaner. Using a mild soap solution, rub stained areas with a clean damp cloth. To remove soap, rub the areas again with a cloth dampened with water. Repeat this until the stain is removed, or use a commercial carpet cleaner for tougher stains. If you use a carpet cleaner, carefully follow the manufacturer's instructions and precautions.


Instrument Panel and Console

Remove loose dirt with a vacuum cleaner. Gently wipe dirt off with a tightly squeezed damp clean cloth. Repeat this until the dirt is removed.

NOTICE

Do not use chemical products that contain silicon to wipe electrical components such as the air conditioning system, audio, navigation system, or other switches. These will cause damage to the components.

Do not spray water or any liquid directly on instrument cluster or any other electrical or electronic components. This may cause damage and/or lead to non-functioning of the part.



68PM09004

NOTICE

- Liquids such as liquid aromatics, soft drinks or juice may cause discoloration, wrinkles, and cracking to resin-based parts and textiles. Immediately wipe it dry with tissue paper or a soft cloth.
- Do not leave leather products with color, fur or vinyl products, etc. in your vehicle for long periods. It may cause discoloration or deterioration of interior.

Inside of the Tailgate Window

NOTE:

Wipe the window along the antenna wires or heat wires by a soft cloth dampened with water to avoid damaging these wires.


Head-up Display

The surface of the display is coated, so please wipe off the dirt with a soft cloth like an eyeglass wipe.

NOTICE

- Do not use a hard cloth or detergent as it may damage the display or the surface coating.
- Do not apply too much force when wiping the display or mirror, as it may damage it.

SPECIFICATIONS




84MM01001

Vehicle Identification	12-1
FASTag (if equipped)	12-2
High Security Registration Plate (HSRP) (if applicable)....	12-3
Fuel Recommendation	12-4
Specifications	12-5


SPECIFICATIONS

Vehicle Identification

Chassis Serial Number



55TB120020




55TB1201

The chassis and/or engine serial numbers are used to register the vehicle. They are

also used to assist a Maruti Suzuki authorized workshop when ordering or referring to special service information. Whenever you have occasion to consult a Maruti Suzuki authorized workshop, remember to identify your vehicle with this number. Should you find the number difficult to read, you will also find it on the identification Label ID.

Engine Serial Number




60G128

The engine serial number is stamped on the cylinder block as shown in the illustration.

FASTag (if equipped)

As per Ministry of Road Transport and Highways, the FASTag (1) is mandatory for each vehicle for the purpose of electronic toll collection or any other purpose as may be defined by the Government of India.

In case of any damage to FASTag or replacement of front windscreen, please contact your nearest Maruti Suzuki authorized workshop.




64MM01001

NOTE:


"(1)" is a representative image of FASTag fixation.

As seen from inside of the vehicle



64MM01002

As seen from outside of the vehicle



64MM01003

NOTE:

The picture shown is for indicative purpose only. Internal structure of actual device mounted on vehicle may be different.

NOTE:

The picture shown is for indicative purpose only. Internal structure of actual device mounted on vehicle may be different.

NOTE:

- Any attempt to remove the tag from the windsreen will result in permanent damage to the tag.
- Use of chemical cleaners to clean the windsreen area where the tag is mounted can damage the tag.
- Use of any sharp objects on the tag can damage the tag.

SPECIFICATIONS


High Security Registration Plate (HSRP) (if applicable)

As per Ministry of Road Transport and Highways, every new vehicle must have HSRP.

HSRP contains;

- Front and rear HSRP, which will be fitted with 2 snap-locks each on number plate area.
- Third license plate on front windshield.


Third License Plate



(1) Third license plate

64MM01005

Third license plate - As seen from outside of the vehicle



64MM01008

- (a) HSRP issuing authority name
- (b) Vehicle registration number
- (c) Unique laser number - Front plate
- (d) Unique laser number - Rear plate
- (e) Date of 1st registration
(in DD-MM-YYYY format)
- (f) Green strips (BS6 vehicle)

NOTE:


The picture shown is for indicative purpose only. Internal structure of actual label mounted on vehicle may be different.

NOTE:

- Any attempt to remove the third license plate from the windscreen will result in permanent damage to the label.
- Use of chemical cleaners to clean the windscreen area where the label is mounted can damage the same.

- Use of any sharp objects on the label can damage the label.
- In the event of any replacement of the third license plate, may please contact the approved authority.

Third license plate - As seen from inside of the vehicle



NOTE:

The picture shown is for indicative purpose only.

NOTE:

Color of third license plate (back) is as per HSRP regulation as defined by Ministry of Road Transport and highways.

Fuel Recommendation

Petrol Engine

To avoid damaging catalytic converter, you must use unleaded petrol with an octane number (RON) of 91 or higher.

Gasoline/Ethanol blends

Blends of unleaded gasoline and ethanol, also known as gasohol, are commercially available in the country and can vary with location. Gasoline/Ethanol blend up to E20 can be used as fuel for this vehicle.

Gasoline containing MTBE

Unleaded gasoline containing MTBE (methyl tertiary butyl ether) may be used in your vehicle if the MTBE content is not greater than 15%. This oxygenated fuel does not contain alcohol.

▲ CAUTION

Use of spurious, low quality, adulterated fuel can cause damage to the engine and engine auxillaries, affect functioning of engine and degrade engine performance including but not limited to engine seizure.

NOTICE

- The fuel tank has an air space to allow for fuel expansion in hot weather. If you continue to add fuel after the filler nozzle has automatically shut off or an initial blowback occurs, the air chamber will become full. Exposure to heat when fully fuelled in this manner will result in leakage due to fuel expansion. To prevent such fuel leakage, stop filling after the filler nozzle has automatically shut off, or when initial vent blowback occurs, if using an alternative non-automatic system.
- Be careful not to spill fuel containing alcohol while refueling. If fuel is spilled on the vehicle body, wipe it up immediately. Fuels containing alcohol can cause paint damage, which is not covered under the New Vehicle Limited Warranty.

SPECIFICATIONS

Specifications

NOTE:

Specifications are subject to change without notice.

M/T: Manual transmission

ITEM: Dimensions		UNIT: mm
Overall length		3995
Overall width		1765
Overall height (Unladen)		1550
Wheelbase		2520
Track	Front*	1520
	Rear*	1530

*Same tyre in all variants.

ITEM: Mass (weight)	UNIT: kg	K12N(DOHC)	K10C(DITC)
Curb mass (weight)	M/T	965 - 975	1015 - 1030
	A/T	NA	1055-1060
	AGS	975 - 980	NA
Gross vehicle mass (weight) rating		1450	1480
Permissible maximum Axle Weight	Front	825	
	Rear	780	

SPECIFICATIONS

ITEM: Engine		
Type	K12N(DOHC)	K10C (DITC)
Number of cylinders	4	3
Bore	73.0 mm	73.0 mm
Stroke	71.5 mm	79.5 mm
Piston displacement	1197 cm ³ (1197 cc)	998 cm ³
Compression ratio	12.0 : 1	10.0 : 1

ITEM: Electrical		K12N(DOHC)	K10C (DITC)
Standard spark plug		NGK ILZKR6F11	NGK ILZKR7D8
Battery	For Petrol	ISS: M42 ^{*1} 20HR 38 AH CCA 330 A (JIS)	12V ISS N-55 20HR 45AH CCA 480A (SAE) ^{*2}
	For CNG	34B19L	
Fuses		See "INSPECTION AND MAINTENANCE" section.	

*1: Your vehicle is equipped with a lead-acid battery for exclusive use of the ENG A-STOP system.

When replacing the lead-acid battery, make sure to select the specified type for ENG A-STOP system. Consult a Maruti Suzuki authorized workshop for replacing the lead-acid battery.

*2: When battery replacement is necessary, use only N55 (Exide Conservo) battery. Else it may deteriorate performance of Smart Hybrid system.

SPECIFICATIONS

ITEM: Lights		WATTAGE	BULB No.
Interior light	Front (if equipped)	12V 5W	W5W
	Center	12V 10W	C10W
	Luggage compartment (if equipped)	12V 5W	W5W
	Courtesy light (if equipped)	12V 5W	W5W
	Glove box light (if equipped)	12V 1.4 W	T5
	Front foot well light (if equipped)	LED ^{*1}	–

- If you need to replace the following bulbs indicated in the above table, consult a Maruti Suzuki authorized workshop.

*1 Since the lights are non-disassemble type, you cannot replace a bulb. Replace the target assembly if any light is defective.

ITEM: Wheels and tyres		
Tyre size	195/60R16 89H ^{*1}	
Rim size	with steel wheels	16X6J
	with aluminum wheels	16X6J
Spare ^{*3}	Tire Size	195/60R16 89H ^{*2}
	Rim Size	16X6J
Tyre pressures	For the specified tyre pressure, see the tyre information label located on the driver's door lock pillar.	

*1: If you cannot prepare tyres with the specified load index rate and speed symbol, prepare tyres with higher load index rate and speed symbol.

*2: The spare wheel provided with Alloy wheel variant is steel wheel rim, hence follow 4 tire rotation only. (Refer section "Inspection and maintenance")

*3: If applicable: The provision of different spare wheel is as per government notification/regulation (MORTH notification vide GSR 625 (E))

SPECIFICATIONS

ITEM: Recommended fuel / lubricants and capacities (approx.)						
Fuel	See "FUEL RECOMMENDATION" section.			37 L		
Engine oil	K12N (DOHC)	For India & Except for India	Classification: API SN or SP ILSAC GF-6 Viscosity: SAE 0W-16	3.7 L (replacement with oil filter)		
	K10C (DITC)	For India	Classification: API SN or SP ILSAC GF-6 Viscosity: SAE 5W-30	2.9 L (Replacement with oil filter)		
		Except for India	Classification: API SL, SM, SN or SP ILSAC GF-6 Viscosity: SAE 5W-30			
Engine coolant	K12N(DOHC) M/T & AGS		"SUZUKI LLC: Super (Blue) Coolant" *1 "SUZUKI LLC: Standard (Yellow) Coolant" *1	4.2 L (including reservoir tank)		
	K12N CNG			4.3L (including reservoir tank)		
	K10C(DITC) M/T			4.3L (including reservoir tank)		
	K10C(DITC) A/T			4.5 L (including reservoir tank)		
Transmission oil	K10C(DITC) M/T		"MARUTI GENUINE GEAR OIL 75W"	2.6 L		
	K10C(DITC) A/T		"SUZUKI AT OIL AW-1"	6.2 L		
	K12N(DOHC)M/T & AGS		"MARUTI GENUINE GEAR OIL 75W"	1.5 L		
Brake fluid / Clutch fluid			MARUTI GENUINE BRAKE FLUID (MGBF) or DOT 3.	Refill to the proper oil level according to the instructions in "INSPECTION AND MAINTENANCE" section.		
Windshield washer fluid			—	2.0 L		
AGS actuator oil			—	0.55 L (including reservoir tank)		

*1:The recommended coolant varies depending on your vehicle. Refer to "INSPECTION AND MAINTENANCE" section.

- MARUTI SUZUKI AUTHORISED DEALER WORKSHOP : SALES, SERVICE, WARRANTY & SPARE PARTS
- MARUTI SUZUKI NEXA DEALER WORKSHOP : SALES, SERVICE, WARRANTY & SPARE PARTS
- MARUTI SERVICE MASTER (MSM) : SERVICE, WARRANTY & SPARE PARTS
- MARUTI SERVICE ZONE (MSZ) : SERVICE, WARRANTY & SPARE PARTS
- MARUTI AUTHORISED SERVICE STATIONS (MASSes) : 'A' CATEGORY MASSes (**MARKED)
Free & paid Service, Major repairs & Accidental repairs
'B' CATEGORY MASSes (* MARKED)
Free & paid Service & Major repairs
'C' CATEGORY MASSes (##MARKED)
Free & paid Service & Minor repairs
'D' CATEGORY MASSes (#MARKED)
Free Service & Minor repairs

NOTE:

Certain MASSes are not authorised to undertake Warranty jobs. Customers are requested to approach only Maruti Suzuki Authorised Dealer Workshop / Maruti Suzuki NEXA Dealer Workshop / Maruti Service Master / Maruti Service Zone for Warranty jobs.

The charges and services may vary depending upon service network and location.

For latest Service Network details kindly visit www.marutisuzuki.com or contact our regional office / area office as mentioned below.

REGIONAL OFFICE	AREA COVERED
REGIONAL OFFICE (NORTH-I) MARUTI SUZUKI INDIA LIMITED 2nd FLOOR, 157 DIVINE , RAJPUR ROAD, DEHRADUN, UTTARAKHAND - 248001 PH:- 0135-2738549	UTTARAKHAND AND PART OF U.P.
REGIONAL OFFICE (NORTH-II) MARUTI SUZUKI INDIA LIMITED SCO: 39-40, SECTOR 8C, MADHYA MARG, CHANDIGARH - 160009 PH. NO.- 0172-2780056	PUNJAB, CHANDIGARH, PANCHKULA, ZIRAKPUR, MOHALI, JAMMU AND KASHMIR & LADAKH
REGIONAL OFFICE (NORTH-III) MARUTI SUZUKI INDIA LIMITED 4TH FLOOR, SUMMIT, PLOT NO. TCG 3/3, VIBHUTI KHAND, GOMTI NAGAR – LUCKNOW - 226010	PART OF U.P.
REGIONAL OFFICE (NORTH-IV) MARUTI SUZUKI INDIA LIMITED S.C.O. 81, FIRST FLOOR, SECTOR 5, PANCHKULA (HARYANA)-134109 PH : (0172) 2590056, 2580056	PART OF HARYANA AND HIMACHAL PRADESH
REGIONAL OFFICE (EAST-I) MARUTI SUZUKI INDIA LIMITED PLOTNO ID/15, ACTION AREA II, NEW TOWN KOLKATA-700156	WEST BENGAL, SIKKIM, ANDAMAN & NICOBAR
REGIONAL OFFICE (EAST-II) MARUTI SUZUKI INDIA LIMITED 4TH FLOOR, ROHINI, OPP. HOTEL APSARA, 56, CIRCULAR ROAD, LALPUR RANCHI - 834001, JHARKHAND PH.: - 0651-2563931/61	BIHAR, JHARKHAND
REGIONAL OFFICE (EAST-III) MARUTI SUZUKI INDIA LIMITED 5A, 5TH FLOOR, PEACE ENCLAVE 724, ULUBARI, G.S.ROAD, GUWAHATI-781007 (ASSAM) TELE: 0361-2734308/10/11/12	ARUNACHAL PRADESH, ASSAM, MANIPUR, MEGHALAYA, MIZORAM, NAGALAND, TRIPURA

SERVICE NETWORK (AS ON 31.10.2023)

REGIONAL OFFICE (WEST-I) MARUTI SUZUKI INDIA LIMITED Plot No.GEN 25 + 25 B/2,TTC INDUSTRIAL AREA,PAWANE VILLAGE,THANE BELAPUR ROAD,NAVI MUMBAI- 400705 PH NO-022 45042300	PART OF MAHARASHTRA AND GOA
REGIONAL OFFICE (WEST-II) MARUTI SUZUKI INDIA LIMITED SACRED WORLD, 7TH FLOOR, NORTH BLOCK, UNIT NUMBER 708-715; JAGTAP CHOWK, WANAWADI, PUNE – 411 040 (MAHARASHTRA) PH. (020) 26856037 / 38 / 39	PART OF MAHARASHTRA
REGIONAL OFFICE (WEST-III) MARUTI SUZUKI INDIA LIMITED 211-213, 2ND FLOOR, ISCON MALL, ABOVE STAR INDIA BAZAR, SATELLITE, AHMEDABAD - 380015 PH NO - 079 - 40036660	GUJARAT, DADRA & NAGAR HAVELI, DAMAN AND DIU
REGIONAL OFFICE (SOUTH-I) MARUTI SUZUKI INDIA LIMITED 10th Floor, Block A, Global Infocity Park, No.40, Anna Nedunchalai, Kandanchavadi, Perungudi, Chennai, Tamil Nadu – 600096 PH. - 044 - 28233050 – 53	TAMILNADU AND PONDICHERY
REGIONAL OFFICE (SOUTH-II) MARUTI SUZUKI INDIA LIMITED #204, 2ND FLOOR, EMBASSY CLASSIC BUILDING,VITTLA MALLYA ROAD,BANGALORE- 560001, KARNATAKA. PH: (080) 41120018	KARNATAKA
REGIONAL OFFICE (SOUTH-III) MARUTI SUZUKI INDIA LIMITED 2ND FLOOR, TUTUS TOWERS, 32/1787 NH47- BYE PASS, PADIVATTOM, COCHIN- 682024	KERALA
REGIONAL OFFICE (SOUTH EAST-I) MARUTI SUZUKI INDIA LIMITD 101-102 FIRST FLOOR MAHAVIR CHAMBERS, LIBERTY SQUARE STANZA, HIMAYATH NAGAR, HYDERABAD-500029, TELANGANA CONTACT NO: 040-66729999	ANDHRA PRADESH, TELANGANA
REGIONAL OFFICE (SOUTH EAST-II) MARUTI SUZUKI INDIA LIMITED UTKAL SIGNATURE, UNIT NO. 605 & 606 (6TH FLOOR) NH-5, PAHAL, CUTTACK-BHUBANESWAR ROAD, BHUBANESWAR-752101, ODISHA PH. 0674-2914129, 0674-2914139 & 0674-2914229	ODISHA AND CHHATTISGARH
REGIONAL OFFICE (CENTRAL-I & II) MARUTI SUZUKI INDIA LIMITED Nelson Mandela Marg,Vasant Kunj II, Vasant Kunj, New Delhi, Delhi - 110070	DELHI
REGIONAL OFFICE (CENTRAL-III) MARUTI SUZUKI INDIA LIMITED 7TH POOJA TOWER, 3 GOPALPURA BYEPASS, TONK ROAD JAIPUR (RAJASTHAN)- 302018, CONTACT NO.: 0141-2550888	RAJASTHAN
REGIONAL OFFICE (CENTRAL-IV) MARUTI SUZUKI INDIA LIMITED 3RD FLOOR, COMMERCE HOUSE, 7 RACE COURSE ROAD INDORE (M.P) PIN CODE: 452001 CONTACT NO.: 07314069481/852/385.	MADHYA PRADESH

DETAILS OF AREA OFFICES	
Area Office Location	Area Office Address
Agra	Maruti Suzuki India Limited, 7th Floor, B-15/8, Shri Vrindavan Tower, Sanjay Place, Agra-282001 Ph:-0562-4052646/47
Bhopal	Maruti Suzuki India Limited, 522, 5th Floor Corporate Zone, Ashima Mall, Hoshangabad Road, Bhopal (M.P) Pin Code: 462 026 Contact : 0755 6051555
Calicut	Maruti Suzuki India Limited, Ground Floor, Aarpees Arcade, YMCA Cross Road, Opp. Indusind Bank, Kozhikode, Kerala -PIN 673001 Phone:- 0495-2723151
Coimbatore	Maruti Suzuki India Limited, Srivari Gokul Towers, First floor, (East wing), No.108/3, Race course, Coimbatore - 641018 Ph.- 0422-2221091
Hubli	Maruti Suzuki India Limited, Shiva Avenue, 2nd Floor, Gokul Road, Hubli - 580030, Ph: 0836-4259447
Jammu	Maruti Suzuki India Limited, Hall no: 315, A2,3rd Floor, South Block, Bahu Plaza, Jammu-180012 M: 9622066444/9622524343
Ludhiana	Maruti Suzuki India Limited, SCO No. 16/17, 4Th Floor, Fortune Chambers, Feroze Gandhi Market, Ludhiana-141001, Ph: 0161-4649764
Madurai	Maruti Suzuki India Limited, 3rd floor, ADR towers, Kalavasal, Theni Bye pass road, Madurai-625016 Ph. - 0452-4200203
Mangalore	Maruti Suzuki India Limited, F - 4,5,6, 1st Floor, Classic Gateway, Mahaveer Circle Pumpwell Mangalore – 575002 Ph. 0824 - 4112111

SERVICE NETWORK (AS ON 31.10.2023)

DETAILS OF AREA OFFICES	
Area Office Location	Area Office Address
Nagpur	Maruti Suzuki India Limited, Plot No.244, 1st Floor, Narayani House, Hill Road, Dharampeth Extension, Nagpur - 440010 (Maharashtra) Ph. (0712) 2225808
Nashik	Maruti Suzuki India Limited, Plot No.202, Rushiraj Towers, Jehan Circle, Gangapur Road, Nashik - 422 005 (Maharashtra) Ph. (0253) 6698551
Patna	Maruti Suzuki India Limited, 307-308, Vasundhara Metro Mall, Rajapur Pul, East Boring Canal Road, Patna - 800001, Bihar Phone - 0612-2559145
Raipur	Maruti Suzuki India Limited, 629-630, Magneto Offizo,Magneto The Mall, Labhandi, Raipur, Chhattisgarh, Pin - 492001 Ph.- 0771-4039643
Siliguri	Maruti Suzuki India Limited, Unit 401, 4th Floor, Quantum Siliguri, Parivahan Nagar, Matigara Siliguri - 734010 West Bengal
Surat	Maruti Suzuki India Limited, 304, Shivalik Western, Above TGB Restaurant, L.P. Savani Road, Adajan Surat - 395009
Trivandrum	Maruti Suzuki India Limited, 8th Floor, KEK Tower, Opp. Police Head Quarters, Vazhuthacadu, Trivandrum - 695010, Phone:- 0471-2322366
Udaipur	Maruti Suzuki India Limited, 302 & 303, 3rd Floor. Manglam's Fun Square, Durga Nursery Road. Udaipur, (Rajasthan) 313001
Vijayawada	Maruti Suzuki India Limited, Vaishinavi Complex, 4th Floor, Unit 2,Opposite Executive Club, Vijayawada, -530002,
Visakhapatnam	Maruti Suzuki India Limited, Door No. 10-50-58/1, 3rd Floor, Waltair Main Road, Ramnagar, Above westside store, RK Estates, Visakhapatnam-530002, Andhra Pradesh Contact No: 0891 2745299

ANDHRA PRADESH**ANANTHAPUR**

1. SRI DURGA (1BNA--01), NO.124, SOMALADODDI, ANANTHAPUR, ANDRA PRADESH - 515004 PH :9885183851.

GUNTUR

2. JAYLAXMI (GSNA--01), D.NO:199/2, OPP AUTONAGAR, NH 16, VJA - GNT SERVICE ROAD, GUNTUR, ANDHRA PRADESH - 522001 PH :9959844644.

NELLORE

3. BHARGAVI AUTO (A8NA--01), SURVEY NO 245B, CHEMUDUGANTA VILLAGE, NH-16, ADJACENT TO SRIDS KALYANA MANDAPAM, NELLORE, ANDRA PRADESH - 524002 PH :8866682222.

ONGOLE

4. JAYALAXMI (BYNA--01), SURVEY NO:194/2, BEside NH 5, MUKTHINUTHALAPADU, ONGOLE, ANDRA PRADESH - 523225 - 523225 PH :9492133433.

RAJAHMUNDRY

5. SB MOTORS (CSNA--01), D.NO:84-1-12, PADMAVATI NAGAR, BESIDE ONGC BASE COMPLEX, NH-45, RAJAHMUNDRY, ANDRAPRADESH-533106. - 533016 PH :9248727888.

SRIKAKULAM

6. VARUN MOTORS (W6NA--01), PEDDAPADU ROAD, ARASAVALLI POST, SRIKAKULAM DISTRICT, ANDHRA PRADESH - 532401 PH :9885317344.

VIJAYAWADA

7. VARUN MOTORS (26NA-26-01), OPP TO PRIYA PICKLES, BANDAR ROAD, PORANKI, VIJAYAWADA, ANDRAPRADESH-521137. - 521137 PH :6309956655.
8. PARAMASHIVA MOTORS (26NB-26-01), NO. 20-1-34, C K REDDY ROAD, AYODHYA NAGAR, VIJAYAWADA, ANDRAPRADESH- 520003. - 520003 PH :9866551078.

ASSAM**BONGAIGAON**

9. BHARATI MOTORS (7NNA--01), CHAPAGURI RD, NEAR POST OFFICE, NORTH BONGAIGAON, AMGURI, BONGAIGAON, ASSAM 783380 - 783380 PH :7002350887.

DIBRUGARH

10. VISHAL CAR WORLD (C1NA--01), MOHPUALIMORA GOHAIN GAON, A.T ROAD, DIBRUGARH, ASSAM - 786008 PH :8000900008.

GUWAHATI

11. PODDAR AUTO (09NA--01), AT ROAD KAMKHYA GATE, GUWATHI, KAMRUP-781009 -781009 PH :8085957586.
12. BIMAL AUTO (09NB--01), DREAMLAND APPARTMENT, NAHRANI PATH, DISPUR LAST GATE, GUWAHATI - 781006 (ASSAM) PH :9864074525.

JORHAT

13. RD MOTOR (G9NB--01), M/S R D MOTORS PVT LTD, DHAPKATA, NEAR TINALI, JORHAT -785006 - 785006 PH :7002099547.

SILCHAR

14. JAIN UDHYOG (J2NA--01), R.S. PATTAA NO.149, DAG NO.579, MOUZA RONGPUR, SILCHAR, ASSAM - 788009 PH :9436121557.

TEZPUR

15. RD MOTOR (T1NA--01), SOLAGAN VILLAGE, GOROMARI, SONABEEL, BEFORE MAA KALYANI PETROL PUMP, TEZPUR -784105 PH :9836972710.

TINSUKIA

16. VISHAL CAR WORLD (J4NA--01), NEXA SHOWROOM (BESIDE VISHAL BIKER'S WORLD), A.T. ROAD, LAIPULI, TINSUKIA, ASSAM -786183 PH :9864211022.

BIHAR**PATNA**

17. ALANKAR AUTO SALES AND SERVICE (15NA-15-01), 70 FEET, BYEPASS ROAD, SARISTABAD, PATNA - 800020 PH :9262899356.
18. REESHAV AUTOMOBILES (15NB-15-01), MUKDUMPUR,DIGHA,90 NO GATE, PATNA - 800012 PH :7369944132.
19. SHREEGOPAL AUTO (15NC-15-01), BHIKACHAK, ANISABAD, NEW BYEPS ROAD, OPP. SITA RAM PATH, PATNA - 800002 PH :9262853333.

PURNEA

20. SEMANCHAL MOTORS (6VNA--01), DAMKA CHOWK,KISHANGANJ ROAD, NH-31,GUAJBAGH,PURNEA,BIHAR - 854326 PH :934710055.

CHANDIGARH**CHANDIGARH**

21. AUTOPACE (FEB) (07NA--01), PLOT NO. 37, INDUSTRIAL AREA – PHASE 1, CHANDIGARH - 160002 PH :70871119796.

22. AUTOVOGUE PVT LTD (07NC--02), PLOT NO 294, INDUSTRIAL AREA PHASE 2, CHANDIGARH - 160002 PH :8725099835.

23. NAVDES AUTO (07NE--01), PLOT NO 182/11, INDUSTRIAL AREA PHASE 1, CHANDIGARH - 160002 PH :8827057534.

CHATTISGARH**AMBIKAPUR**

24. MAHAMAYA (AENA--01), AJAB NAGAR,MAHATHMA GANDHI ROAD,AMBIKAPUR - 497001 PH :9516609632.

BILASPUR

25. SATYA AUTOMOBILES (C3NB--01), PLOT NO 53, SECTOR C, SIRGINTI INDUSTRIAL AREA, BILASPUR, CHHATTISGARH - 495001 PH :6372803057.

RAIPUR

26. SPARSH (50NA-50-01), NEAR TCI GODOWN, NH-6, CHANDANIH, TATIBANDH, RAIPUR, CHHATTISGARH - 492029 PH :9266266662.
27. SKY AUTOMOBILES (50NB-50-01), NEXA MAGNETO, LABHANDH, G. E. ROAD, RAIPUR

DELHI

28. RANA MOTORS (08NE--01), B-242, OKHLA INDUSTRIAL AREA PHASE 1, OKHLA, NEW DELHI
29. TR SAWHNEY (08NN--01), C-46, OKHLA INDUSTRIAL AREA PHASE 2, OKHLA NEW DELHI PH :9953350008.

30. PLATINUM MOTORS (08NQ--01), PLOT NO-H4,BLOCK-B1,MOHAN CO-OPERATIVE INDEX,MATHURA ROAD,PIN-110044 - 110044
31. MAGIC AUTO (08NA--01), CISF GATE NO 1, D-21, CORPORATE PARK, NEAR DWARKA SEC-8 METRO STATION, NEW DELHI - 110075 PH :9873052000.

32. AAA VEHICLEADES (08NW--01), BLOCK C, NAJAFGARH ROAD INDUSTRIAL AREA, NEW DELHI, DELHI 110015 - 110015 PH :8750611111.
33. COMPETENT AUTO (08NF--01), PLOT NO-34,RAJASTHAN UDYOG NAGAR, GT AKRNAL ROAD, DELHI - 110033 PH :9932049425.

34. JAGMOHAN MOTORS (08NX--01), C133-136(PART, PHASE I, INDUSTRIAL AREA, MANGOLPURI S BLOCK, NEW DELHI, DELHI 110083 - 110083 PH :9812259000.

GOA**MARGAO (GOA)**

35. CHOWGULE INDUSTRIES (34NB-34-01), SY. NO. 267/1, NEXT TO ARLEM RTO, ARLEM, RAIA, SALCETE - (GOA) - 403720 - 403720 PH :9850966950.

PORVORIM(PANJM)

36. SAI SERVICE (34NA-34-01), EMPRESSA INDUSTRIAL CHODANKAR, SURVEY NO. 114/2, SALVADOR DO MUNDO, PORVORIM, BARADEX, GOA - 403521

GUJARAT**AHEMADABAD**

37. STAR LINE CARS (01NE--01), PLOT NO 236, GIDC, NARODA, AHMEDABAD, GUJARAT. 382 330 - 382330 PH :7436003235.

38. PEGASUS (01NG--01), PLOT NO 9, OPP RABARI COLONY BRITS STOP, CTM, NAROL - NARODA HIGHWAY, NH-8, AHMEDABAD, GUJARAT. - 380026 PH :9909020300.

39. POPULAR WHEELERS (01NC--01), T P 20, F P 78, OPPOSITE SUN SQUARE COMPLEX OFF, C G ROAD, NEAR HL COLLEGE, NAVRANGPURA GULBAI TEKRA, AHMEDABAD, GUJARAT - 380009 PH :9925203344.

ANAND

40. AMAR CARS (F7NA--01), SURVEY NO 1583, PLOT NO 144, NEAR GANESH CROSSING, ANAND SOJITRA ROAD, ANAND, GUJARAT - 388001 PH :9925407666.

BHARUCH

41. RAVIRATNA (F8NA--01), SURVEY NO 185/3, NH8, ZARDESHWAR, BHARUCH, GUJARAT. - 392001 PH :9727700823.

BHUJ

42. KD MOTORS (P5NA--01), 33, UMA PARK, BEHIND MARUTI SUZUKI SHOWROOM, MIRZAPAR HIGHWAY, BHUJ - 370040 PH :9879898799.

GANDHIDHAM

43. BM AUTO LINK (77NA-77-01), SURVEY NO 129/26, GALPADAR - ANJAR HIGHWAY, AIRPORT ROAD, GANDHIDHAM, KUTCH , GUJARAT - 372021 PH :7211120014.

Nexa Network (AS ON 31.10.2023)

GANDHINAGAR

44. NANDA AUTOMOBILES (2BNA-01), BLOCK NO 403, NR SANGATH GATEWAY, OPP RAISAN PETROL PUMP, KUDASAN, GANDHINAGAR, GUJARAT. - 362421
PH : 9687641974.

GODHRA

45. RB CARS (2CNA-01), SURVEY NO. 38/2 PAIKE 1 PAIKE 2, LUNAWADA ROAD, OPP. GIDC, GODHRA - 389001 - 389001
PH : 9925051444.

JUNAGARH

46. PERFECT AUTO SERVICES (K8NA-01), GIDC 2, RAJKOT HIGHWAY, JUNAGARH - 362037
PH : 9909022619.

MEHSANA

47. STAR LINE CARS (D1NA-01), REVENUE SURVEY NO. 342, PLOT NO.1, 4, 5 AND 6 TO 12, VILLAGE NAGALPUR, DISTRICT MEHSANA, GUJARAT - 384002

PATAN

48. STARINE CARS (Q9NA-01), ADJACENT ARENA SET UP, PATAN UNJHA ROAD, PATAN (GUJARAT) - 382465 - 382465
PH : 9909043244.

RAJKOT

49. PERFECT AUTO SERVICES (55NB-55-01), PLOT NO. 110, 111, 127 & 128, KOTHARIYA, NEAR PERFECT HOUSE, GONDAL ROAD, RAJKOT - 360004
PH : 9512033501.

SURAT

50. KIRAN MOTORS (40NB-40-01), BLOCK NO 443, FP NO 26 MOJE PALGAM, ADAJAN, SURAT, GUJARAT - 395009 - 395009
PH : 702569426.
51. AMAR CARS (40ND-40-01), SURVEY NO 139,BLOCK NO-218'A,OPPOSITE TO AWADH ARENA MALL,V.I.P ROAD BHARTHAMA,SURAT,GUJARAT - 395007
PH : 98/1388795.

SURENDRNAGAR

52. DREAM VEHICLES (LCNA-01), PLOT NO. 302, GIDC AREA, WADHWAN CITY, SURENDRNAGAR, GUJARAT. - 363035
PH : 8511104644.

VADODARA

53. KATARIA AUTO (22NA-22-01), WARD NO 11 CIRCLE SAINATH ROAD, HARINAGAR-VASNA ROAD VADODARA - 390007
PH : 9824701590.

VAPI

54. KATARIA AUTO (97NA-97-01), NEAR CROMA OUTLET, RATHOD CHAMBERS, DAMAN ROAD,CHALA VAPI - 396191
PH : 9714799985.

AMBALA

55. EAKANSH WHEELS (18NA-18-01), AMBALA-CHANDIGARH HIGHWAY ADJOINING AAJ SAMAJ VILLAGE-SADDOPUR, AMBALA PH : 8395903111.

BHIWANI

56. PASCO AUTOMOBILES (X3NA-01), NEAR HUNNAMAL PIYAU, ROHTAK ROAD, BHIWANI-HARYANA-127021 - 127021
PH : 9289192582.

FARIDABAD

57. PASCO AUTOMOBILES (58NB-58-01), 14/4, MATHURA ROAD, FARIDABAD, HARYANA - 121003
PH : 9997970229.
58. BVA AUTO (58NC-58-01), 2J/53-54, NH-2, NIT FARIDABAD, HARYANA
PH : 9911259288.
59. VIPUL MOTORS (58NA-58-01), SUB DIVISION NO-3, INDUSTRIAL PLOT NO. -34, N.I.T, FARIDABAD HARYANA - 121001
PH : 8562019252.

GURGAON

60. PREM MOTORS (95ND-95-01), PLOT NO. 5, IDC, SECTOR-16, GURGAON, HARYANA - 122001
PH : 1292565666.
61. TR SAWHNEY (95NB-95-01), CRPF CAMP ROAD, VILLAGE ULLAWAS, NR. PIONEER PARK SECTOR-62, GURGAON, HARYANA - 122001
PH : 1274254441.

HISAR

62. SARAOGI AUTOMOBILES (76NB 1-7-61), PLOT NO. 180, SECTOR 27-28, INDUSTRIAL AREA HISAR. - 125001

KAITHAL

63. EAKANSH MOTORS (UBNA-01), NH-65, OPP RKM FARM, AMBALA ROAD, KAITHAL - 136027
64. EAKANSH MOTORS (UBNA-02), KHEWAT NO -456, KHATONI - 563, KITTAS - 20/87K 01M ADJOINING NEXA SHOWROOM, AMBALA HISAR ROAD, KAITHAL - 136027
PH : 8813038777.

KARNAL

65. KARNAL MOTORS (89NA-89-01), 118-119 KM MILESTONE, G.T. ROAD, KARNAL, HARYANA - 132001

PANIPAT

66. AUTO GALLERY (D3NB-01), NANGAL KHERI, NEAR BBMB POWER HOUSE, OPP. SEC-29, PANIPAT, HARYANA - 132103
PH : 9812615000.

REWARI

67. DINCO MOTORS (U1NA-01), OPP. TULARAM STADIUM, DELHI ROAD, REWARI - 123401

ROHTAK

68. JAGMOHAN MOTORS (A6NA-01), NORTHERN BYEPASS, SUKHPUKA CHOWK, JIND ROAD, ROHTAK, HARYANA PH : 8754045446.

SIRSA

69. SHAKTI MOTORS (E4NA-01), OPP. DELHI PUBLIC SCHOOL, NH-09, HISSAR ROAD, SIRSA - 125055

SONIPAT

70. JAGMOHAN AUTOMOBILES (J5NB-01), SONIPAT MURTHAL ROAD NEAR ASR CNG PUMP - 131001

HIMACHAL

KANGRA

71. KANGRA VEHICLEADES (D9NA-01), VPO-HATWAS, NAGROTA BAGWAN, DISTRICT-KANGRA, HIMACHAL PRADESH - 176047
PH : 7018145653.

JAMMU & KASHMIR

JAMMU

72. JAMKASH VEHICLES (33NB-33-01), NH-1A BYE PASS OPPOSITE CHANNI HIMMAT, JAMMU (J&K)

73. JAMMU MOTORS (33ND-33-01), KHASRA NO. 421, TOPE SHERKHANIA, AKHNOOR ROAD, OPPOSITE BEST PRICE, JAMMU, JAMMU & KASHMIR - 180016

SRINAGAR

74. PEAKS AUTO (12NA-12-01), DR. ALI JAN ROAD, SOURA, SRINAGAR PIN - 190011. - 190011
PH : 07062285604.

JHARKHAND

BOKARO

75. HINDUSTAN AUTO AGENCY (B5NA-01), KHATA NO. 752, PLOT NO. 7792, NH-32, CHAS, BOKARO. - 827013
PH : 9304807318.

DEOGHAR

76. PREMSONS (SGWN-01), PLOT NO 318/319 UNDER THANA NO 583, MAHESHWARA MOUJA DEOGHAR - 814112
PH : 9835507004.

DHANBAD

77. RELIABLE (S2NA-52-01), RELIABLE INDUSTRIES NEXA WORKSHOP AMAGHATA, BY PASS ROAD SUGIADH,PIN - 828109 - 828109
PH : 7992470853.

HAZARIBAGH

78. PREMSONS (Y9NA-01), PREMON MOTOR UDYG PVT LTD ,NEXA SHOWROOM NEXT TO GST OFFICE,ARYA NAGAR,HURHURU,HAZARIBAGH,JHARKHAND 825301 - 825301
PH : 9835507004.

JAMSHEDPUR

79. MOTOR WORLD (31NB-31-01), NS-6, 2ND PHASE, ADITYAPUR INDUSTRIAL AREA, JAMSHEDPUR - 831013
80. PEBCO MOTORS (31NA-31-01), KANDRA ROAD, ADITYAPUR INDUSTRIAL AREA, JAMSHEDPUR - 831013
PH : 9334183260.

RANCHI

81. SUDHA MOTORS (51NB-51-01), KATHALMORE, OPP. MANER DHABA, RANCHI - 834005
82. PREMSONS (51NC-51-01), PLOT NO 2651/2652, KHATA NO 239, MAUJA, VILLAGE BARAGAI , BARIATU MAIN ROAD, RANCHI, JHARKHAND - 834009
PH : 9334811248.

KARNATAKA

BANGALORE

83. MANDOVI MOTORS (02NJ-01), SURVEY NO.32/2,ALLALASANDRA, YELAHANKA NORTH, BANGALORE, KARNATAKA - 560064
PH : 9513729888.
84. KALYANI MOTORS (02NI-01), SURVEY NO.17/2, KENCHENAHALLI VILLAGE, RAJARAJESHWARI NAGAR, MYSORE ROAD,BANGALORE, KARNATAKA - 560032
PH : 9845049626.

85. SURAKSHA CAR CARE (02NF-01), 2/6, BERTEN AGRAHARA, OPP TO METRO CASH & CARRY, HOSUR MAIN ROAD, ELECTRONIC CITY, BANGALORE, KARNATAKA - 560100
PH : 9845047393.

86. PRATHAM MOTORS (02NK-01), 120,SARJAPUR MAIN ROAD,DODDAKANAHALLI, VARTHUR HOBLI, BANGALORE EAST, KARNATAKA- 560035. - 560035
PH : 9884000579.

87. VARUN MOTORS (02NG-01), NO.23/A, INDUSTRIAL SUBURB, 2ND STAGE, TUMKUR ROAD,YESHWANTPUR, BANGALORE, KARNATAKA- 560022. - 560022
PH : 8971888885.

88. VARUN MOTORS (02NM-01), 37/56 NAGAVARA VILLAGE,HEBBAL RING ROAD, BANGALORE - 560024
PH : 9513394753.

89. KALYANI MOTORS (02NN-01), 152/7, OUTER RING ROAD, DODDA BANASWADI, HORAMAVU, KI PURAM HOBALI, BANGALORE - 560043. - 560043
PH : 9900020454.
90. BIMAL AUTO AGENCY INDIA PVT LTD (02NL-01), NO. 1, 3 RD BLOCK, 2ND STAGE, NAGARBHAVI,OUTER RING ROAD, BANGALORE - 560072.
91. BIMAL AUTO AGEONY INDIA PVT LTD (02NC-01), SY.NO.9/04, NEAR KATAMANALLUR GATE, KANNAMANGALA, KADUGODI MAIN ROAD, SANNATAMMANHALI, BENGALURU, KARNATAKA - 560067.
PH : 9742260137.
- BELGAUM**
92. SHANTESA MOTORS (E8NA-01), PLOT NO. 6/B, R.S NO. 34, BOUXIDE ROAD, KANGRALI B K, BELGAUM, KARNATAKA-590010. - 590010 PH : 9538195381.
- BIJAPUR**
93. CHAVAN MOTORS (KTK) PRIVATE LIMITED (T7NA-01), #262, RANE MADRAS ROAD RING ROAD, NEAR SESHDARIPURAM COLLEGE HEBBAL MYSORE - 566109
PH : 879957100.
- DAVANGERE**
94. SHRUTI MOTORS (S1NA-01), #323/1A, OLD PB ROAD AVARAGERE, DAVANGERE - 577003
- HASSAN**
95. VENKAT MOTORS (C8NA-01), VENKAT MOTORS, #200/46/2,D.M HALLI,NEAR GUHEKALAMMA TEMPLE,B.M ROAD ,HASSAN - 573201
- HUBLI**
96. LEKHYA MOTORS (73NA-73-01), OPP TO APMC 2ND GATE, ESHWAR NAGAR, HUBLI-DHARWAD ROAD, HUBLI-580025. - 580025
PH : 9513777265.
- MANGLORE**
97. MANDOVI MOTORS (45NA-45-01), SUMIT APARTMENT BUILDING, AIRPORT ROAD, MARY HILL, MANGLORE - 574142
PH : 9845133077.
- mysore**
98. FRIENDLY MOTORS (25NB-25-01), PLOT NO.262, HEBBAL INDUSTRIAL AREA, MYSORE, KARNATAKA- 570016. - 570016
PH : 9845011686.
99. MANDOVI MOTORS PRIVATE LIMITED (25NA-01), MANDOVI MOTORS PRIVATE LIMITED NEXA SERVICE #90/7,DATTAGALLI RING ROAD, R.T.NAGAR JUNCTION, MYSURU - 570023
100. KALYANI MOTORS PVT LTD (25NC-01), KALYANI MOTORS PVT LTD - 570016
- SHIMOGA**
101. SHRUTI MOTORS (B7NA-01), 217/215/91/79/1, OPP TO FOREST OFFICE, SHANTI NAAGARA, HONNALI ROAD, SHIMOGA,KARNATAKA - 577201
PH : 9895966666.
- KERELA**
- CALICUT**
102. AM MOTORS (47NA-47-01), 18/1472, OPP TO COMTRUST EYE HOSPITAL,SRAMBKKAL PARAMBA,MINI BYPASS,JAIL ROAD JUNCTION,PUTHIYARA POST,CALICUT, KERALA-673004. - 673004
PH : 7708833966.
103. POPULAR VEHICLES (47NB-47-01), BYPASS SERVICE ROAD, BEHIND JAYA ARCADE, THONDAYADU, CALICUT, KERALA - 673017
PH : 9946104660.
- COCHIN**
104. INDUS MOTOR (27NC-27-01), NH 47,THAIKATTUKARA PO,THAIKAVU, ALUVA, COCHIN - 683106 - 683106
PH : 9747508822.
105. SAI SERVICE (27NA-27-01), 723/7.6.18,OPP TO HOTEL AARYAS, SEAPORT-AIRPORT, POOJARY VALAVU, KANAYANNOOR TALUK, THIRRAKKARA NORTH, COCHIN-682021. - 682021
PH : 9645106193.
- KAYAMKULAM**
106. SAI SERVICE (8LNA-01), S.NO 111/48, KP ROAD, KAYAMKULAM, KERALA - 695052
PH : 9288024222.
- KOLLAM**
107. SARATHY AUTOCARS (C7NA-01), NH-47 BEY PASS ROAD, AYATHIL,P.O KOLLAM DIST, KERALA STATE PIN 691021 - 691021
PH : 984659456.
- TRIVANDRUM**
108. INDUS MOTOR (16NB-16-01), OPPOSITE EVM ASHOK LEYLAND,ALUMOOD JN,NH 47,KANNIYAPURAM, TRIVANDRUM - 695301. - 695301
PH : 9656685678.
- MADHYA PRADESH**
- BHOPAL**
109. RAJURP MOTOR JUNCTION (A UNIT OF RMJ MOTORS PVT LTD) (03NC-01), 42, 6_BLOCK, BHEL INDUSTRIAL ESTATE, HABIBGANJ, HOSHANGABAD ROAD, BHOPAL (M.P.)
- INDORE**
110. PATEL MOTORS (53NA-53-01), 1105/1528/5/2, MIN-1 AND 1105/1528/4/5, GRAM: KHAJRANA, DISTRICT: INDORE, KANADIA ROAD, INDORE (M.P.) - 452016
PH : 7771002581.
111. OCEAN MOTORS (53NB-53-01), BICHOLI MARDANA NEAR SAMPATH PALACE OPP HOTEL PRIDE - 452001
112. RANA MOTORS (53ND-53-01), LASUDIA MORI, DEWAS NAKA, INDORE, PIN CODE 452010 - 452010
PH : 9933055539.
113. RUKMANI (53NC-53-01), RUKMANI MOTORS NEXA SERVICE,FOOTHI OTHI SQUARE,OPP.DASTOOR GARDEN,INDORE - 452002
PH : 9755512100.
- JABALPUR**
114. STANDARD MOTORS (54NC-54-01), KHARSA NO-529/1/1, NEAR TRIPURI CHOWK GARHA JABALPUR M. P. - 482003
PH : 9773543358.
- SAGAR**
115. ADINATH CARS (G1NA-01), KHASRA NO 155, P H NO. -77, BAHERIA GADGAD, SAGAR JABALPUR ROAD, SAGAR - 470004, MADHYA PRADESH, INDIA - 470004
PH : 9752447690.
- SATNA**
116. CITY CARS (D7NA-01), BEHIND NEXA SHOWROOM, 66/2, AMOUDHA, PANNA ROAD, SATNA, MADHYA PRADESH - 485001
PH : 6262230999.
- UJJAIN**
117. RUKMARANI (YUG) (3WNA-01), 59/1, DEWAS ROAD, ADARSH NAGAR, NAGZIRI, UJJAIN - 456664
PH : 9755512100.
- MAHARASHTRA**
- AHMEDNAGAR**
118. KANKARIYA AUTOMOBILES (A5NA-01), SH-60,NEWASA ROAD ,NAGARDEOLE,AHMEDNAGAR,MAHARASTRA - 414601
PH : 9403961522.
- AMARAVATI**
119. ASPA BANDSONS (F2NA-01), F32/1 MIDC , AURANGABAD NAGPUR EXPRESS HIGHWAY, AMRAVATI, MAHARASHTRA - 444607
PH : 9130041513.
- AURANGABAD**
120. AUTOMOTIVE MANUFACTURER LTD (21NB-21-01), PLOT NO : L-3 / 1, BETWEEN GARWARE & WOCKHARDT LTD, JALGAON ROAD, MIDC CHIKALTHANA,AURANGABAD PIN : 431006, MAHARASHTRA - 431006
PH : 9970499273.
121. PAGARIYA AUTO (21NA-21-01), OPP AIRPORT, NEXT TO INDIAN OIL PETROL PUMP, JALNA ROAD, AURANGABAD, MAHARASHTRA - 431006
PH : 8888859502.
- BARAMATI**
122. MAHALAXMI AUTO (7RNA-01), BHIGWAN ROAD, SHIV NAGAR, BARAMATI (MAHARASHTRA) PH : 9850994014.
- CHANDRAPUR**
123. BARBATE AUTO (H3NA-01), PLOT NO 15-18, OUT OF SURVEY NO 144, 15/5, MAUZA BADOLI, NAGPUR CHANDRAPUR HIGHWAY, CHANDRAPUR, MAHARASHTRA - 440025 PH : 8380887666.
- JALGAON**
124. MANRAJ AUTO (C4NB-01), P 93, MIDC, R L CHOWK, AJANTA ROAD, JALGAON, MAHARASHTRA - 425003 - 425003
- KHARGHAR**
125. SIMRAN MOTORS (AACN-01), 60/72, JAWAHAR COOPERATIVE INDUSTRIAL ESTATE, KALAMBOLI, KHARGHAR, MUMBAI, MAHARASHTRA - 410209
- KOLHAPUR**
126. SAI SERVICE (38NA-38-01), 1243/66, E WARD, SHIVAJI UDHYAMNAGAR, KOLHAPUR - 416001 PH : 9923208401.
- MUMBIAI**
127. SAI SERVICE (05NB-01), JOSEPH CARDIJN TECHNICAL SCHOOL , KHASHABA JADHAV MARG , OFF DR. AMBEDKAR ROAD , DADAR (EAST) MUMBAI, MAHARASHTRA - 400014
128. SHIVAM MOTORS (05ND-01), PLOT NO SILVER HOUSE, 110 MIDC, ROAD NO 13, MAROL, ANDHERI (EAST), MUMBAI, MAHARASHTRA - 400069
129. KTS AUTOMOTORS (05NH-01), UNIT NO A1, PANNALAL COMPOUND, LBS KANTILAL MAGANLAL ESTATE, L.B.S MARG, BHANDUP (W), MUMBAI - 400078
130. SHIVAM AUTOZONE (05NE-01), PLOT NO. 1 & 2, RAMCHANDRA LANE EXTN., KANCHPADA, OFF LINK ROAD, MALAD-WEST. - 400064 PH : 9870938888.
- NAGPUR**
131. BARBATE AUTO (20NA-20-01), 37/2, MANISH NAGAR, BESA T POINT, BESA ROAD NAGPUR 440025 - 440025
- NANDED**

Nexa Network (AS ON 31.10.2023)

132. SEVA AUTOMOBILES (68NA-68-01), AIRPORT ROAD,SANGVI - 431605 PH :7065026520.

NASHIK

133. SEVA AUTOMOBILES (37NA-37-01), PLOT B-17, MIDC, AMBAD, NASIK, MAHARASHTRA - 422010 PH :8975762303.

NAVI MUMBAI

134. AUTOMOTIVE MANUFACTURER LTD (39NB-39-01), NERUL, MUMBAI PUNE HIGHWAY, NAVI MUMBAI - 400706 PH :9769206120.

PUNE

135. KOTHARI WHEELS (19NB-19-01), GATE NO 1605, OLD 1099, KESNAND ROAD, WAGHOLI, TAL-HAVELI, DISTRICT - PUNE, MAHARASHTRA - 412207 PH :7721865000.

136. EXCEL AUTOVISTA (19NG-19-01), SURVEY NO 982/A/P, NEW PUNE - MUMBAI HIGHWAY, NEAR BALEWADI STADIUM, BANER TALUKA, PUNE - 411045.

137. SEHGAL AUTO RIDERS (19NE-19-01), SURVEY NO 63/2, SHEWALEWADI, MANJARI BUDRUK, PUNE SOLAPUR HIGHWAY, PUNE, MAHARASHTRA - 412307 PH :9158000049.

138. WONDER CARS (19ND-19-01), PLOT NO 52/1 BLOCK F2, MIDC PIMPRI, PUNE - 411019 PH :9850094151.

139. MAHALAXMI AUTO (19NI-19-01), NEAR SADGURU PETROL PUMP, PUNE NASHIK HIGHWAY, AT KURALI, KHED TALUKA, CHAKAN - 410501 PH :9923582024.

140. SAI SERVICE (19NC-19-01), SINHAGAD ROAD, NEAR NANDED CITY, VADGAON KHURD, PUNE, (MAHARASHTRA) PH :9923308333.

RATNAGIRI

141. JAGRUT MOTORS (G3NA-01), 410/6/1B, SALVI STOP, SHIVAJI NAGAR MAIN ROAD RATNAGIRI, MAHARASHTRA - 415612 PH :9820039626.

SHOLAPUR

142. CHAVAN MOTORS (B1NA-01), SURVEY NO. 534/4, BALE PUNE ROAD, SOLAPUR, MAHARASHTRA - 413224 PH :8888881314.

THANE

143. EXCEL AUTOVISTA (39NA-39-01), MOHAN MILL COMPOUND, GHODBUNDER ROAD , THANE , MAHARASTHRA - 400607 PH :9967331726.

144. EXCEL AUTOVISTA (39NA-39-02), NEAR ARIHANT COMPOUND, KALHER, BHIWANDI, THANE - 400607 PH :9967331726.

NAGALAND

DIMAPUR

145. PROGRESSIVE MOTORS (32NA-32-01), OPPOSITE AIRPORT, N.H.39. DIMAPUR KOHIMA ROAD, DIMAPUR OPPOSITE AIRPORT, N.H.39, DIMAPUR KOHIMA ROAD, - 797115 PH :7669223736.

ODISHA

BERHAMPUR

146. SKY AUTOMOBILES (E2NA-01), PLOT NO 373/229 & 373/1204, AMABAPUA MOUZA, BRAHMAPUR (ODISHA) - 760007

ROURKELA

147. ORBIT MOTORS (87NA-87-01), PLOT NO 5G/3, VED VYAS, SUNDARGARH, ROURKELA - 769041 PH :9165071234.

SAMBALPUR

148. ODYSSEY MOTORS (D4NA-01), SAMBALPUR, CHOWK, REMED, ODISHA 768006 - 768006

PUNJAB

AMRITSAR

149. JAYCEE MOTORS (17NA-17-01), JAYCEE MOTORS, VERKA BYE PASS, OUTSIDE ASHBERRY HOMES, VILLAGE VALLAH, AMRITSAR, PUNJAB - 143501

BHATINDA

150. TARA (70NA-70-01), KHASRA NO. 3534, NEAR ITI CHOWK, MANSA ROAD, BHATHINDA, PUNJAB - 151001 PH :8437019666.

JALLANDHAR

151. LOVELY AUTO (35NA-35-01), NH 1 GT ROAD, PRAGPUR, JALANDHAR PUNJAB
152. MARWAHA AUTOS (35NC-35-01), KHASRA NO - 16450, SITUATED AT RAJA GARDEN, KAPURTHALA RD, JALANDHAR - 144001 PH :9915944600.

LUDHIANA

153. GULZAR (62NE-62-01), PLOT NO 2662 NEAR SILVER ARC MALL, AARTI CHOWK, LUDHIANA, PUNJAB - 141003 PH :9814839777.
154. HOSHIPUR AUTO (62NG-62-01), S-46/1616/1, G.T. ROAD, DHOLEWAL CHOWK, LUDHIANA, PUNJAB - 141003 PH :8872501234.

155. MARWAHA AUTOS (62NH-62-01), FEROZEPUR RD, AMAN PARK, NEW SUNDER NAGAR, LUDHIANA, PUNJAB - 141012 PH :8872000357.

156. LOVELY AUTOS (62NF-62-01), NEAR SAMRALA CHOWNK, MOTI NAGAR, LUDHIANA - 141010 PH :9875999161.

MOHALI

157. CM AUTO SALES (L1NA-01), B-64A, INDUSTRIAL AREA, PHASE-7, MOHALI

NAWANSOHALI

158. LOVELY AUTOS (J7NA-01), VPO LANGROYA, CHANDIGARH ROAD, NAWANSOHALI - 144514 PH :9915028682.

PATHANKOT

159. PATHANKOT VEHICLEADS (A7NA-01), PLOT NO.-C-30, INDUSTRIAL GROWTH CENTRE, VILL. CHACELI, PATHANKOT - 145023 PH :7527006800.

RAJASTHAN

AJMER

160. NAVNEET MOTORS (B2NA-01), PLOT NO 7-8,RIICO INDUTRIAL ESTATE MAKHPURA NASIRBAD ROAD,AJMER(RAJASTHAN)-PIN CODE-305002 - 305002 PH :9414149149.

ALWAR

161. FORTUNE CAR (F9NA-01), 6TH MILESTONE VILLAGE JATIYANA,OPP. PETROL BEHORR ROAD ALWAR - 301001 PH :9982341741.

BHILWARA

162. CHAMPION CARS (E3NA-01), NEXA SUKHADIA CIRCLE, CHAMPION CARS, AJMER ROAD, BHILWARA - 311001 PH :9001027933.

BIKANER

163. AUDI MOTORS (71NA-71-01), PLOT NO. F-189, SRI GANAGANAGAR ROAD, OPPOSITE RAC-3RD, BICHHWAL INDUSTRIAL AREA , BIKANER 334001 - 334001 PH :988722786.

CHITTORGARH

164. TECHNOY (K9NA-01), PLOT NO-28, OLD RIICO INDUSTRIAL AREA, CHITTORGARH, RAJASTHAN - 312001

JAIPUR

165. K P AUTOMOTIVES (11NB-11-01), PLOT NO.3-4,MANGAL RIICO INDUSTRIAL AREA NEAR KANAKPURA RAILWAY STATION,SIRS ROAD - 302034 PH :7412059823.

166. SATNAM MOTORS (11ND-11-01), D-27, KLM, ROAD NO-3,SIKAR ROAD, VISHWAKARMA INDUSTRIAL AREA, JAIPUR, RAJASTHAN-302023 - 302023 PH :9649373311.

JHUNJHUNU

167. AUDI MOTORS (FNNA-01), NEAR TVS TWO WHEELER SHOWROOM ROAD NO 3 GUDHA MOD, RAJASTHAN 333001 - 333001 PH :7970066402.

JODHPUR

168. AUDI MOTORS (65NA-65-01), 14 A, HEAVY INDUSTRIAL AREA, ITI CIRCLE, SARASH DAIRY ROAD, JODHPUR - 334001 PH :7300077394.

169. LMU AUTO (65NB-65-01), B-8, C-9,10, MIA, BASNI, PHASE-1 JODHPUR - 342009 PH :7412087320.

170. LMU SERVICES (65NB-65-02), PLOT NO.-61, GERU MARKET, BHADWASIYA FRUIT MANDI, JODHPUR, RAJASTHAN - 342001 PH :8094011126.

KOTA

171. BHATIA & CO. (61NA-61-01), G-11A, AUTOMOBILE ZONE, IPIA, NEAR DAKANIYA RAILWAY STATION, KOTA - 324005 PH :8094011126.

SIKAR

172. JAMU (K7NA-01), THAR PETROL PUMP,JAIPUR ROAD,SIKAR - 332001 PH :9414037515.

UDAIPUR

173. TECHNOY (49NB-49-01), OPP. NAND BHAWAN, GOVERDHAN VILLAS , UDAIPUR

TAMIL NADU

CHENNAI

174. PILLAI & SONS (14NC-14-01), DOOR NO.46, MEDAVAKKAM MAIN ROAD, KEELAKATTALAI, CHENNAI, TAMILNADU - 600117 PH :9994950505.

175. POPULAR VEHICLES (14NB-14-01), 69/A & 69/B, SAMAYAPURAM MAIN ROAD, PORUR, CHENNAI,TAMILNADU - 600116 - 600116 PH :9842289111.

176. KHIVRAJ MOTORS (14NA-14-01), PLOT NO.21, AMBIT IT PARK ROAD, AMBATTUR INDUSTRIAL ESTATE, CHENNAI-600058 - 600058 PH :9626099999.

177. VISHNU CAR (14NC-14-01), SURVEY NO 219, ADJOINING HP PETROL PUMP, POONAMALLE HIGH ROAD, KATTUPAKKAM, CHENNAI, TAMIL NDU - 600056 PH :7339359111.

178. ABT (14NJ-14-01), NO123, KANNIGAPURAM, VELACHERY MAIN ROAD, BEHIND RACE COURSE, GUINDY, CHENNAI, TAMIL NADU - 600032
PH :9994444303.
179. VISNU CAR (14NG-14-02), POONAMALLE HIGH ROAD, ARUMBAKKAM, KOYAMBEDU, CHENNAI, TAMIL NADU - 600056
PH :755033622.
- COIMBATORE**
180. AADHI CARS (41NB-41-01), OLD KALIAPPAA KALYANAMANDAM, PREMISES, KAVUNDAMPALAYAM, COIMBATORE, TAMIL NADU - 622707
PH :9003977577.
181. SREE SARADHAMBAL (41NA-41-01), 18/1472, S.N.R COLLEGE ROAD, NAVAI INDIA, COIMBATORE, AND TAMILNADU-641004. - 641004
PH :9790004271.
- ERODE**
182. SREE SARADHAMBAL (H7NA-01), NO.75, NEAR SURABI NURSERY, PERUNDURAI ROAD, ERODE, TAMILNADU-638011. - 638011
PH :9786022272.
- HOSUR**
183. SRI AMMAN CARS (7QNA-01), NEAR CATER PILLAR WARE HOUSE, SEETHA RAMNAGAR,NH-44,OPP TO ANAND ELECTRONICS,HOSUR, KRISHNAGIRI DISTRICT, TAMILNADU - 635109
PH :9841033464.
- KARAIKUDI**
184. MEENAKSHI AUTOZONE (HXNA-01), T S NO 624/1, DOOR NO. 5, 1ST STREET, SUBRAMANIAPURAM, KARAIKUDI, TAMIL NADU - 630001
PH :9940094881.
- MADURAI**
185. ASIR (42NA-42-01), 176, MAIN ROAD, KAMARAJAR ROAD, MADURAI, TAMIL NADU – 625001 - 625001
- NAGERCOIL**
186. ATHEN CARS (S5NA-01), NO. G. 3/9, NO. 1197, NELSON COMPOUND, KP ROAD, PARVATHIPURAM, NAGERCOIL, TAMILNADU - 629003
PH :9751196436.
- PONDICHERRY**
187. SHENBAKA CARS (96NA-96-01), RS NO 50/5A, PONDICHERRY CUDDLORE MAIN ROAD ,KIRUMAMBKKAM, BAHOOR COMMUNE:PONDICHERY - 607402
PH :7338322220.
188. THRIVENI CARS (A2NA-01), 2/6, KANDHAMPPATTY,BYE PASS ROAD, SALEM, TAMILNADU - 636005
PH :9786022272.
189. SM CAR (A2NB-01), S NO 131/1A,BYPASS ROAD, NEAR INDIAN OIL ASSOCIATION, PETROL BUNK, KONDALAMPATTY, SALEM - 636010
PH :7094440010.
- THANJAVUR**
190. PILLAI & SONS (E7NA-01), SURVEY NO 237/1, NEELAGIRI THAKUR THOTTAM, VALLAM ROAD, THANJAVUR, TAMIL NADU - 613403
PH :9443261465.
- TRICHY**
191. PLA MOTORS (23NA-23-01), TS NO 29P,31P & 32P,36P, NEW WARD "E", NEW BLOCK NO.27, ANNA NAGAR, TRICHY, TAMILNADU - 620017. - 620017
PH :8110099991.
- TRIPUR**
192. SHASHTI (Y7NA-01), 16A-1,SHREE PADMINI GARDENS, KANGAYAM RD, TIRUPPUR, TAMIL NADU - 641604
PH :9942903310.
- VELLORE**
193. SRI GANESH CARS (C6NA-01), 96/6, CHENNAI-BANGALORE HIGHWAY, NH-46, PERUMUGAI VELLORE, TAMILNADU - 632009
PH :9884722126.
- TELANGANA**
- HYDERABAD**
194. KALYANI MOTORS (10NE-10-01), SURVEY NO.184, KARMAGAT VILLAGE, BESIDE KHARMANCHAT HANUMAN TEMPLE, R.R DISTRICT, HYDERABAD, TELANGANA - 500079
PH :9347121212.
195. VARUN MOTORS (10NB-10-01), B-54, CO.INDUTRIAL ESTATE, BALANAGAR, HYDERABAD, TELANGANA - 500037
196. GEM MOTORS (10NH-10-01), D.NO.8-96, SURVEY NO.128/2 & 129, TYAGARAYANANAGAR COLONY, KOTHAPET, HYDERABAD, TELANGANA - 500084
PH :9912345899.
197. JAYABHERI AUTO (10ND-10-01), HNO. 2-40/64, SURVEY NO 23 TO 28, JUBILEE GARDENS, KOTHAGUDA, HYDERABAD, TELANGANA-500032. - 500032
198. VARUN MOTORS (10NB-10-02), H.NO. 8-2-120/2, PLOT NO. 83A,83B, ROAD NO. 2, BESIDES SBI BANK, BANJARA HILLS, HYDERABAD - TELANGANA - 500033
PH :9885610555.
199. SAI SERVICE (10NC-10-01), SURVEY NO 78, ADJACENT TO HP PETROL PUMP, GOPANAPALI, GACHIBOWLI, HYDERABAD -500046. - 500046
PH :9966377888.
200. RKS (10NI-10-01), SY NO:42, PET BASHEERABAD, QUTHBULLAPUR, MEDCHAL MANDAI, HYDERABAD - 500014
201. ADARSHA AUTOMOTIVE (10NG-10-01), PLOT NO 6/F, 54, SURVEY NO. 204, PRAGATI NAGAR, BALANAGAR, KUKATPALLY, HYDERABAD - 500072
202. ADARSHA AUTOMOTIVE, SHAMSABAD (10NG-02), SHAMSABAD, NH44, HYDERABAD, TELANGANA - 501218 - 501218
PH :8297116633.
- KARIMNAGAR**
203. ADARSHA AUTOMOTIVE (N6NA-01), 8-6-301, BY PASS ROAD, AUTO NAGAR, KARIMNAGAR, TELANGANA - 505001
PH :9847073265.
- MAHBUBNAGAR**
204. JAYARAMMA AUTO (WPNA-01), CHRISTIANPALLY, BHOOPTOOR ROAD, MAHBUBNAGAR, TELANGANA - 509001
PH :8096990074.
- MANCHERIAL**
205. ADARSHA AUTO (CMNA-01), SURVEY NO-417,BELLAMPALLI MANCHERIAL ROAD ,MANCHERIAL,TELANGANA - 504208
PH :9133329709.
- NIZAMABAD**
206. VARUN MOTORS (1HNA-01), 1-51/4/D/4 MADAHAVA NAGAR,HYDERABAD ROAD NIZAMABAD, TELANGANA,503230 - 503230
PH :9542222486.
- SECUNDERABAD**
207. MITHRA AGENCIES (10NK-10-01), USHA MAYURI THEATER, OPP TO SPENCERS MARKET, MUSHEERABAD, SECUNDERABAD, ANDRAPRADESH-500020. - 500020
208. AUTO FIN (K6NB-01), PLOT NO.6, SURVEY NO.267/1 & 267/2, BOWENPALLY, BALANAGAR MAIN ROAD, SECUNDERABAD, TELANGANA - 500011
PH :8886144551.
209. VARUN MOTORS (K6NC-01), VARUN MOTORS,2ND CROSS ROAD,SAINIKPUR,SECUNDERABAD PH :779960094.
- WARANGAL**
210. ADARSHA AUTOMOTIVE (D5NA-01), H.NO: 23-6-132, HUNTER ROAD, OPP TO CITIZENS CLUB, WARANGAL, TELANGANA - 506007
PH :8978944414.
- UTTAR PRADESH**
- AGRA**
211. MADHUSUDAN MOTORS (66NA-66-01), ADJOINING HEMA PETROL PUMP, EIT MANDI, BODLA, AGRA
- ALIGARH**
212. CLML (B6NA-01), PLOT NO. 5/129, GT ROAD, RAM NAGAR COLONY, SARSON, ALIGARH, UTTAR PRADESH. - 202002
PH :9639775522.
213. CLML (B6NA-02), VILL KARSUA, PALWAL-DELHI ROAD, ALIGARH PIN 202140 - 202140
PH :9358373099.
- BARIELY**
214. CORAL (56NA-56-01), DELHI RAMPUR ROAD, IN FRONT OF MINI BYPASS, CB GANJ, BARIELLY, UP - 243001
PH :9359101010.
- GHAZIABAD**
215. ROHAN MOTORS (59NA-59-01), KHASRA NO 46, DELHI MEERUT ROAD MEERUT ROAD INDUSTRIAL AREA, MORTA, GHAZIABAD, UTTAR PRADESH 245101 - 245101
PH :8178839830.
216. J J IMPEX (5982-59-N1), PLOT NO C, J J IMPEX (DELHI) LIMITED, 224, SITE-1, INDUSTRIAL AREA, BULANDSHAHAR ROAD INDUSTRIAL AREA, GHAZIABAD, UTTAR PRADESH 201003 - 201003
- GORAHPUR**
217. SMART WHEELS (72NA-72-01), ARAZI NO. 623, 624 & 625, GULHARIA BAZAR, MEDICAL COLLEGE ROAD, GORAHPUR, UTTAR PRADESH - 273009
PH :8222002147.
- GREATER NOIDA**
218. MSM (JJ IMPEX) (T283-N1), MARUTI SERVICE MASTERS, NEXA SERVICE, PLOT NO 02, ECOTECH 12, GREATER NOIDA, GAUTAM BUDDHA NAGAR, UTTAR PRADESH - 201009
- HARDOI**
219. CONCEPT (QENA-01), PLOT NO. 1609 & 1605, GUNGABUX PURVA, BILGRAM RD, HARDOI, UTTAR PRADESH - 241001
PH :7607696666.
- JHANSI**
220. SURI (60NA-60-01), SHIVPURI - JHANSI ROAD, OPPOSITE HANSRAJ MODERN SCHOOL, JHANSI, UTTAR PRADESH - 284003
PH :7705000558.
- KANPUR**

Nexa Network (AS ON 31.10.2023)

221. KTL (29NB-28-01), ARAZI NO. 352, SINGHPUR
KACHHAR, BITHOOR ROAD, NORTHERN
RAILWAY COLONY, KANPUR, UTTAR
PRADESH - 208017
PH :7408409312.

LUCKNOW

222. ANAND MOTORS (13NC-13-01), GATA NO. 1062
PARGANA RAJA BIJLI PASI VILLAGE
AURANGABAD, SHAHEED PATH (OPPOSITE TO
RAMABAI AMBEDKAR MAIDAN), LUCKNOW,
UTTAR PRADESH - 226012

223. KTL AUTOMOBILE PVT LTD (13ND-13-01), PLOT
NO - 513, VILL HARIHARPUR BINAUR, OPP
ANSAL API, AMAR SHAHEED PATH, LUCKNOW -
227105
PH : 7311190503.

MATHURA

224. UMA MOTORS (H8NA-01), PLOT NO 222,
MAHOLI, NEAR KIRAN HOSPITAL, MATHURA -
281004
PH :9997385999.

MEERUT

225. TR SAWHNEY (48NB-48-01), 1183/17 RITHANI,
ZONE - A, SECTOR 4 NEAR PETROL PUMP,
MEERUT, UTTAR PRADESH - 250103
PH :18002704142.

NOIDA

226. FAIR DEAL (A1ND-01), A-107, SECTOR-5.
NOIDA - 201301
PH :9810542222.

227. MOTOR CRAFT (59NB-59-01), C 42 SECTOR 57,
NOIDA, UTTAR PRADESH - 201301

RAIBARELY

228. KTL AUTOMOBILE PVT LTD (HSNA-01), 1481,
NEAR KATHWARA BUS STAND, LUCKNOW
RAIBARELI HIGHWAY, HARCHANDPUR,
RAIBARELI - 229303
PH :7311190503.

SAHIBABAD

229. MSM (M983-N1), MARUTI SERVICE MASTERS,
NEXA SERVICE, PLOT NUMBER 58/4, SITE 4,
SAHIBABAD INDUSTRIAL AREA, - 201010
PH :9711474930.

SHAHJHANPUR

230. SUMITRA DS (W2NA-01), SH25 , RETI ROAD
SHAHJAHANPUR

UTTARAKHAND

HALDWANI

231. NAINITAL MOTORS (J6NA-01), 5TH KM RAMPUR
ROAD, JEETPUR NEGI, NEAR AMAR UJALA
PRINTING PRESS, HALDWANI, UTTARAKHAND -
263139

ROORKEE

232. SHAKUMBARI (H2NA-01), 5 KM MILESTONE
,NH-58,ROORKEE-DELHI ROAD, NEAR HOTEL
GODWARI,ROORKEE, UTTARAKHAND - 247667

RUDRAPUR

233. AKANKSHA AUTOMOBILES (RUDRAPUR) PVT.
LTD. (U4NB-01), KASHIPUR ROAD, OPPOSITE
GREEN PARK COLONY, VILLAGE DIBIBA,
TEHSIL BILASPUR, RAMPUR, UTRAKHAND -
244901

WEST BENGAL

ASANSOL

234. BEEKAY AUTO (F6NA-01), NH-2 CHANDA
MORE, POST KALI PAHARDI, JAMMUARIA
DISTRICT WEST BARDHAMAN - 713339
PH :9932049425.

HOWRAH

235. MACHINOTECHNO (X7NA-01), 109, 1, UPPER
FORESHORE RD, CHOURA BUSTEE, SHIBPUR,
HOWRAH, WEST BENGAL 711102 - 711102
PH :9830081632.

JALPAIGURI

236. PODDAR AUTO (XYNA-01), ASSAM MORE BUS
STOP, SH12A, JALPAIGURI, WEST BENGAL
735102 - 735102
PH :8945533002.

KHARAGPUR

237. BHANDARI AUTOMOBILES (G7NA-01),
CHOWRANGEE, PLOT NO-138 & 139, O T ROAD,
KHARAGPUR - 721301
PH :7603076061.

KOLKATA

238. JYOTE MOTORS (06ND-01), MIRANIA ROAD,
ARUPOTA ON BASANTI HIGHWAY., - 700105
PH :9074158220.

ANDAMAN AND NICOBAR ISLANDS	DIGIPUR	10. VARUN MOTORS (SJH1-01), DO-NO : 5/116, SURVEY NO -59,CHALAMAYYA NAGAR, RAILWAY STATION ROAD, NEAR SMP BAJAJ SHOWROOM, ANNAPURAM, EAST GODAVARI DISTRICT, ANDHRA PRADESH. - 533406 PH :9885288339.	CHIRALA	19. JAYALAKSHMI AUTOMOTIVES PVT. LTD (G502-04), 9-1-92, CHURCH ROAD,CHIRALA. - 523157 PH :7331151661.	GUNTAKAL	29. SRI DURGA AUTOMOBILES PVT. LTD. (BJA1-01), SURVEY NO. 407. D. NO. 20/342-19, BELLARY ROAD, GUNTAKAL, DIST.-ANANTPUR, ANDHRA PRADESH. - 515801 PH :8886603336.	
1. AGENCY HOUSE (A & N ISLANDS) PVT. LTD. (PU01-01), MADHUPUR VILLAGE,TEHSIL, DIGIPUR,NORTH ANDAMAN - 744202 PH :271056.							
PORTBLAIR			CHITTOOR	20. BHARGAVI AUTO PVT. LTD. (A801-03), 22-241-A,KATTAMANCHI TIRUPATI ROAD,CHITTOOR, - 517001 PH :8463955558.	GUNTUR	30. JAYALAKSHMI AUTOMOTIVES PVT. LTD (G502-01), D-N-8-24-31,MANGALAGIRI ROAD,GUNTUR - 522001 PH :7893117111/0863-2211000.	
2. AGENCY HOUSE (A & N ISLANDS) PVT. LTD. (E102-01), GARACHRAMA, PORT BLAIR - 744105 PH :251980, 253586, 211590.			21. VARUN MOTORS (SHT1-01), SURVEY NO: 33-9/A, RAVULAGADDA VILLAGE,BESIDE GOVT DEGREE COLLEGE,ARAKU,VISHAKAPATNAM,ANDHRAPRadesh - 531151 PH :9885317344.	31. JAYALAKSHMI (G502-05), 1-14-114, OPP. HINDU COLLEGE, BANDLAMUDI GARDENS, AMARAVATI ROAD, GUNTUR-522003, AP - 522203 PH :984131133/962555555.			
3. AGENCY HOUSE (A & N ISLANDS) PVT. LTD. (E102-02), NAYAGEN, PORTBLAIR - 744101 PH :227104, 211682.			CHODAVARAM	32. JAYALAKSHMI AUTO (G502-06), SURVEY NO 509, D NO 25-11-50 TOWN, WARD NO 22, OPPOSITE ITC BUILDING, R AGRAHAM, NAGARAPALAM ROAD,GUNTUR. - 522004 PH :8374847777.			
RANGAT			CUDDAPAH		HANUMAN JUNCTION	33. SANTOSH MOTORS (SHB1-01), SY NO. 569/1 BESIDES NH5, VELURU VILLAGE, BAPULAPADU MANDAL, HANUMAN JUNCTION KRISHNA DISTRICT PIN 521105 - 521115 PH :9703633755.	
4. AGENCY HOUSE (A & N ISLANDS) PVT. LTD. (E102-03), NIMBUTULLA, PO RANGAT, DIST. MIDDLE ANDMAN. - 744201 PH :211546.			22. MSA MOTORS (C201-03), K.T. BYE PASS ROAD,CUDDAPAH,ANDHRA PRADESH. - 516001 PH :7396685628.		HINDUPUR	34. SRI DURGA AUTOMOBILES PVT. LTD. (B01-02), PLOT NO.83, NEAR RELIANCE PETROL BUNK, BYE PASS ROAD, HINDUPUR - 515201 PH :9100902697.	
ANDHRA PRADESH			23. REDDY & REDDY MOTORS (1E01-01), OLD NH-ROAD,BESIDES C R REDDY WOMEN'S COLLEGE OLD NH-5,ELURU, - 534001 PH :9705311566.		ICHAPURAM	35. JAYABHERI AUTOMOTIVES (SNN1-01), SURVEY NO 50-14, D. NO 3-1/C, BONDAPALLI MANADALAM, GAJAPATHINAGARAM, ANDHRA PRADESH. - 535270 PH :9885576602.	
AMALAPURAM			ENKIPADU, VIJAYAWADA	24. VARUN MOTORS (2603-08), SURVEY NO 2077, 2077BZ, 20715B, D-NO 8-103, NEAR SHIVALAYAM TEMPLE, ENIKEPADU, VIJAYAWADA, KRISHNA DISTRICT, ANDHRA PRADESH - 521108 PH :9885517111.			36. JAYABHERI AUTOMOTIVES PVT. LTD. (GL1-01), SURVEY NO. 105/3, 105/4 AND 22/7, ICCHAPURAM, BALAKRISHNAPURAM PANCHAYAT,MUNIBHADRA VILLAGE,ANDHRA PRADESH. - 532312 PH :9394006666, 8142933666.
5. S.B. MOTOR CORPORATION (BTS1-01), #241/2B, BESIJE BAPUJI PRIMARY SCHOOL MAIN ROAD, OPP. RR NAGAR, BANDARULANKA, AMALAPURAM, EAST GODAVARI (DIST) - 533201 PH :8374303303.			GAJAPATINAGARAM	25. JAYABHERI AUTOMOTIVES (SNN1-01), SURVEY NO 50-14, D. NO 3-1/C, BONDAPALLI MANADALAM, GAJAPATHINAGARAM, ANDHRA PRADESH. - 535270 PH :9100818111.		JAGGAIAHPET	37. VARUN MOTORS PVT. LTD. (2603-02), D NO. 1-621,AUTONAGER 1ST LANE,GUDIVADA - 521301 PH :9885615138.
AMARAVATI			GAMBHEERAM	26. JAYABHERI AUTOMOTIVES PVT. LTD. (BQ01-02), PLOT NO.40-45 & 48, GREEN INDUSTRIAL PARK, GAMBHEERAM, ANANDPURAM, VISHAKAPATNAM. - 530052 PH :9642496789.			38. VARUN MOTORS PVT. LTD. (2603-05), DOOR NO. 2-20, MUTHYALAMMA GUDI STREET JAGGAIAHPET TOWN, JAGGAIAHPET, KRISHNA DIST. - 521175 PH :9642225297/9052418111.
6. JAYALAKSHMI AUTOMOTIVES PVT. LTD. (CVB1-01), SURVEY NO. 29, TOWNSHIP-16, SECTOR-137, COLONY-539, BLOCK-2029, PLOT NO. 1, SUB-DIVISION-L40, MALKAPURAM LIMITS, MANDAL - THULLURU, AMARAVATI-CITY, DIST.-GUNTUR, ANDHRA PRADESH . - 522237 PH :8374847777.			GUDIVADA	27. VARUN MOTORS PVT. LTD. (2603-02), D NO. 1-621,AUTONAGER 1ST LANE,GUDIVADA - 521301 PH :9885615138.		JAGGAMPET	39. SR MOTORS (CDG1-01), M/S D NO 10-37, JAGGAMPETA, EAST GODAVARI DISTRICT, ANDHRA PRADES - 533435 PH :8886677759.
ANAKAPALLE			GUDUR	28. BHARGAVI AUTO PVT. LTD. (IS01-01), SURVEY NO.169/3A,GUDUR BYPASS, GUDUR RURAL, GUDUR DISTT. NELLORE, A.P. - 524101 PH :965294624, 9948627555.		JANGAREDDYGEUDEM	
7. JAYABHERI AUTOMOTIVES PVT. LTD. (DN01-01), SURVEY NO.822/1 & 2, NH-5 ROAD, ANAKAPALLE, DISTT. VISHAKHAPATNAM. - 531001 PH :7093575555.							
ANANTAPUR							
8. SRI DURGA AUTOMOBILES PVT. LTD. (IB01-01), 17/37-A,GOOTY ROAD,,ANANTAPUR - 515001 PH :9100902697.							
9. JAYALAKSHMI (IB02-01), SURVEY NO 146-3,SRI NAGAR COLONY, ANANTAPUR, ANDHRA PRADESH - 510052 PH :9177723377.							
ANNAVARAM							

Dealer Network (AS ON 31.10.2023)

38. REDDY & REDDY MOTORS (1E01-02), NEAR R&B GUEST HOUSE,ELURU ROAD,JANGAREDDYGUDEM, - 534447 PH .9912563666.
- KAikaluru**
39. SANTOSH AUTOMOTORS PVT. LTD. (CLW1-01), SY. NO. 12/77 &9, OPP. NAIDU COMPLEX, AATAPAKA, KAikaluru MANDAL, DIST. KRISHNA - 521333 PH .7799787969.
- Kakinada**
40. S B MOTORS (W701-01), D. NO. 52-10-36/3,NEAR AMAR GHATI CENTER,KARAPA ROAD, KAKINADA - 533001 PH .9885119888.
- Kanchikacherla**
41. VARUN MOTORS PVT. LTD. (GJD1-01), SURVEY NO. 51/05, DOOR NO. 13-144, 146, 13TH WARD, KANCHIKACHERLA VILLAGE AND MANDAL, KRISHNA DIST., ANDHRA PRADESH - 521180 PH .9885082822, 9885576602.
- Kandukuru**
42. JAYALAKSHMI AUTOMOTIVES PVT. LTD (BEY1-01), SURVEY NO. 414, MAHADEVAPURAM VILLAGE, O. V. ROAD, KANDUKURU MANDAL, DISTRICT – PRAKASHAM, ANDHRA PRADESH. - 523105 PH .9948131133.
- Kanigiri**
43. JAYALAKSHMI AUTOMOTIVES PVT. LTD (SCC1-01), SURVEY NO 793, PLOT NO 11,12 , KANIGIRI, PRAKASHAM DISTRICT, ANDHRA PRADESH - 523230 PH .9848131133, 9052457512.
- Kavali**
44. BHARGAVI AUTO PVT. LTD. (A801-05), KAVALI NELLORE,ANDHRA PRADESH - 524201 PH .9248702567.
- Kurnool**
45. MSA MOTORS (C201-01), AUTO NAGAR,INDUSTRIAL ESTATE, NH-7, KURNOOL - 518004 PH .9912826682.
46. ADARSHA (C202-01), SURVEY NO 105 DINNEDEVAPADU VILLAGE, KURNOOL, ANDHRA PRADES - 518001 PH .9160182222.
- Macherla**
47. JAYALAKSHMI AUTOMOTIVES PVT. LTD (CEY1-01), D.NO. 3437, 343/5-3, 15-2-3, MACHERLA, MACHERLA MUNICIPALITY. - 522426 PH .9848131133, 9705261801.
- Machilipatnam**
48. MITHRA AUTO AGENCIES PVT LTD (2604-04), NARASIMHA NAGAR, MACHILIPATNAM, ANDHRA PRADESH - 521001 PH .8886063526.
- Madanapalli**
49. BHARGAVI AUTO PVT. LTD. (AAT1-01), SURVEY NO. 762, BASIKONDA VILLAGE, MADANPALLI, CHITTOOR DISTT. ANDHRA PRADESH - 524101 PH .9959893434.
- Madhurawada**
50. JAYABHERI AUTOMOTIVES PVT. LTD. (BQ1-01), PLOT NO. 5, SURVEY NO. 4/P, KOMMADI ROAD, MADHURAWADA, VISHAKHAPATNAM, ANDHRA PRADESH - 530048 PH .8886669985.
- Malkipuram**
51. VARUN MOTORS (SEH1-01), SURVEY NO 49/6A, MALKIPURAM VILLAGE AND MANDAL, EAST GODAVARI DISTRICT, ANDHRA PRADESH - 533250 PH .9885317344.
- Mandapeta**
52. S B MOTOR CORPORATION (BJC1-01), BLOCK NO. 4, D. NO. 4-1-64, MANDAPETA, DISTRICT – EAST GOADAVARI, ANDHRA PRADESH. - 533308 PH .8886664090.
- Markapuram**
53. JAYALAKSHMI AUTOMOTIVES PVT. LTD (CCF1-01), D. NO. 4-515/12, SURVEY NO. 1167, OPP. INDUSTRIAL ESTATE, ONGOLE ROAD, MARKAPURAM, DISRT.-PRAKASAM, ANDHRA PRADESH. - 523316 PH .9848131133, 7331151674.
- Mylavaram**
54. VARUN MOTORS PVT. LTD. (GKL1-01), D NO. 2-176/2, MAIN ROAD, MYLAVARAM, KRISHNA DISTRICT, PIN-521230, ANDHRA PRADESH - 521230 PH .9885576602, 9581337222.
- Naidupet**
55. BHARGAVI (BJD1-01), M/S SURVEY NO 11-2, JUVALAPELEM VILLAGE, NAIDUPETA, ANDHRA PRADESH STATE: - 524126 PH .9248747777.
- Naakkapalli**
56. VARUN MOTORS (SFR1-01), SURVEY NO 202/3, 203/4,PEDGUMMULUR GRAM PANCHAYAT, RAYAVARAM MANDAL,NAKKAPALLI,VISHAKHAPATNAM, ANDHRA PRADESH - 531081 PH .9885317344.
- Nandigama**
57. VARUN MOTORS (CUB1-01), RE SURVEY NO. 601/1B, NH-9 ROAD, NANDIGAMA, DIST.-KRISHNA, ANDHRA PRADESH. - 521185 PH .9885576602, 7702624494.
- Nandyal**
58. MSA MOTORS (CKB1-01), SURVEY NO. 333, VUDUMALPURAM, MANDAL – NANDYAL, OPP. AUTO NAGAR, NANDYAL, DISTRICT – KURNOOL. - 518501 PH .9490666616.
- Narasaraopet**
59. JAYALAKSHMI AUTOMOTIVES PVT. LTD (G502-03), NEAR RELIANCE PETROL PUMP BUNK,VINUKONDA ROAD, NARASARAOPET, GUNTUR. - 522603 PH .7680000502/9100791343.
- Narsapuram**
60. NOVELTY REDDY & REDDY (SIU1-01), SY NO. 98/7, NARSAPURAM– CHINCHINDA BYPASS ROAD,NARSAPURAM, PALKOLLU MANDAL, WEST GODAVARI DISTRIC T,ANDHRA PRADESH - 534206 PH .9703900011.
- Narsipatnam**
61. JAYABHERI AUTOMOTIVES PVT. LTD. (WT01-01), OPP. RDO BUNGLOW, BANK COLONY, VISAKHAPATNAM ROAD, NARSIPATNAM - 531116 PH .7702333513.
- Nellore**
62. BHARGAVI AUTO PVT. LTD. (A801-01), D.NO.25/II/97 INDUSTRIAL ESTATE, A.K. NAGAR, P.B.NO.18, NELLORE.(A.P.) - 524004 PH .9248742225.
63. BHARGAVI AUTO PVT. LTD. (A801-04), A2, INDUSTRIAL ESTATE,A.K. NAGAR,NELLORE. - 524004 PH .9248727888.
64. VISHNU CARS PVT. LTD. (A802-01), FIELD NO. 628 SURVEY NO. 877/4/A AND 883/A/1A, NELLORE BIT-II, BESIDES GSR GARDENS BALAJI NAGAR, NH-16, NELLORE CITY. - 542002 PH .7337340778.
- Nuzividu**
65. VARUN MOTORS PVT. LTD. (2603-03), BESIDE R T C BUS DEPOT,OLD D M OFFICE,VIJAYAWADA ROAD, NIZVID - 521201 PH .254444, 958133722.
- Ongole**
66. JAYALAKSHMI AUTOMOTIVES PVT. LTD (8Y01-02), THROVAGUNTA COMPANY CENTRE,NH-5,GUNTUR ROAD,ONGOLE,PRAKASAM DISTRICT. - 523003 PH .970105595.
- Palakonda**
67. VARUN MOTORS PVT. LTD. (OKO1-01), SURVEY NO. 8, ANAVARAM GRAMAM, PALAKONDA, SRIKAKULAM DISTRICT, ANDHRA PRADESH. - 532440 PH .9966877033, 9885317344.
- Palasa**
68. JAYABHERI AUTOMOTIVES PVT. LTD. (BWH1-01), SURVEY NO. 63 OF VILLAGE – PURUSHOTTAPURAM, PALASA MANDAL, KASIBUGGA MUNICIPALITY, DISTRICT – SRIKAKULAM, ANDHRA PRADESH. - 532221 PH .9849054442, 8790946464.
- Parvathipuram**
69. JAYABHERI AUTOMOTIVES (BYS1-01), SY.NO. 195-1A, NEAR TBR THEATRE, NARSIPURAM, PARVATHIPURAM MANDAL, DISTRICT – VIZIANAGARAM, ANDHRAPRADESH,PINCODE – 535522 - 535522 PH .9100818111.
- Pathapatnam**
70. VARUN MOTORS (SSJ1-01), D NO 4-245,SURVEY NO 264/1A, PATHAPATNAM, SRIKAKULAM, ANDHRA PRADESH - 532213 PH .9885317344.
- Pendurthi**
71. VARUN MOTORS PVT. LTD. (BAP1-01), SURVEY NO.107/1B, VELAMPETA, ANAKAPALLI TO PENDURTHI HIGHWAY, NEAR BRIDGE, PENDURTHI DIST: VISAKPATNAM - 530047 PH .9885438455.
72. VARUN MOTORS PVT LTD (BAP1-02), SURVEY NO 240/1,2 & 241, PENDURTHI, VIZAG - 531173 PH .9703843737.
- Piduguralla**
73. JAYALAKSHMI AUTOMOTIVES PVT. LTD (BFN1-01), SURVEY NO. 897/16, PIDUGURALLA, DISTRICT – GUNTUR, ANDHRA PRADESH. - 522413 PH .9848131133, 9100787058.
- Pithapuram**
74. S B MOTORS (CTS1-01), NO. 11-2-114, 11TH WARD, KAKINADA-KATHIPUDI ROAD, PITHAPURAM, EAST GODAVRI DIST., ANDHRA PRADESH. - 533 450 PH .8886677759, 8886677754.
- Ponnur**
75. JAYALAKSHMI AUTOMOTIVES PVT. LTD (CFC1-01), PLOT NO. 4, D. NO. 213-1 VAISHNAVI NAGAR, PONNUR, GUNTUR, ANDHRA PRADESH. - 522124 PH .9849445639, 9121141913.
- Rajahmundry**

76. S.B. MOTOR CORPORATION (C501-01), OPP.FCI GOWDAM,JAILROAD,LALACHERUVU,RAJAMUDRY - 533101 PH :08885585667.
77. S B MOTORS (C501-03), D. NO. 3-243, NH-5, ROAD, HUKUMPETTA, RAJAHMUNDRY. - 533 107 PH :0888586262
78. VARUN MOTORS PVT. LTD. (CS02-01), SURVEY NO. 660, PALACHERLA VILLAGE OF RANJANAGRAM MANDAL, RAJAHMUNDRY, EAST GODAVARI DSIT. - 533102 PH :9642225289.
- RAJAM**
79. VARUN MOTORS PVT. LTD. (BLJ1-01), PLOT NO. 44, SARATHI NAGAR, RAJAMINAGAR PANCHAYAT, RAJAM, DISTRICT - SRIKAKULAM, ANDHRA PRADESH - 532127 PH :7799666998.
- RAMPACHODAVARAM**
80. VARUN MOTORS (SOK1-01), SURVEY NO 14/1,IRILAPALLY VILLAGE, RAMPACHODAVARAM,ANDHRA PRADESH - 533288 PH :988528339.
- REPALLE**
81. JAYALAKSHMI (SKA1-01), D.NO 430, BESIDE ESAR PETROL BUNK, REPALLE, DISTRICT: GUNTUR, ANDHRA PRADESH - 522265 PH :8374847777.
- S KOTA**
82. JAYABHERI (SIV1-01), SURVEY NO 113/3,MALLIPUDI MADHURA VENKATARAMANAPETA, SRUNGAVARAPUKOTA, VIZIANAGARAM, ANDHRA PRADESH - 535145 PH :9100818111.
- SOMPETA**
83. VARUN MOTORS PVT LTD (GLX1-01), KHATA NO 405,407,408 DENOTED IN SURVEY NO 241/1,MOGILIKOTUR VILLAGE, SOMPETA, SRIKAKULAM, ANDHRA PRADESH - 532284 PH :9885217344, 7382112922.
- SRIKAKULAM**
84. VARUN MOTORS PVT. LTD. (4603-09), PEDDA PADDU ROAD,ARASAVILLI (P.O.),SRIKAKULAM, - 532001 PH :9985477155.
85. JAYABHERI AUTOMOTIVE (4606-04), SURVEY NO 22/PT,22/8 AND SURVEY NO 29/12,16,17, BALAGA RURAL,SRIKAKULAM CITY, DISTRICT: SRIKAKULAM - 532001 PH :9100818111.
- SULURUPETA**
86. BHARGAVI AUTO PVT. LTD. (BZA1-01), KEERTI ENCLAVE,NEAR RTO OFFICE,NH-5,SULLURUPETA - 524121 PH :9848602345, 7997998516.
- TADA**
87. VISHNU CARS PVT.LTD. (SFW1-01), SURVEY NO 58/3,TADA, NELLORE DISTRICT - 524401 PH :9840434242.
- TANUKU**
88. NOVELTY REDDY & REDDY MOTORS PVT LTD (BAR2-01), NH-5 ROAD, NEAR WOMEN'S COLLEGE, BESIDE IOC PETROL PUMP, TANUKU, DISTT: WEST GODAVARI(ANDHRA PRADESH) - 534211 PH :9912341624.
- TENALI**
89. JAYALAKSHMI AUTOMOTIVES PVT. LTD (PE01-01), KAVI RAJA NAGAR, GUNTUR ROAD, TENALI, GUNTUR DISTT. - 522002 PH :226100/9866111788.
- THAGARAPUVALASA**
90. VARUN MOTORS PVT. LTD. (CQV1-01), SURVEY NO 11/2B,11/3,NAGARAPALEM VILLAGE, NH-16, NAGARAPALEM GRAMA PANCHAYAT LIMITS, THAGARAPUVALASA, BHEEMUNIPATNAM MANDAL, VISHAKAPATNAM - 531162 PH :9885317344, 9885280772.
- TIRUPATI**
91. BHARGAVI AUTO PVT. LTD. (A801-02), 11/66/1,TIRUPATI RENIGUNTA ROAD,TIRUPATI, - 517507 PH :7997969946.
92. BHARGAVI AUTO PVT. LTD. (A801-06), SURVEY NO. 2/3, ADJACENT TO PARK HOTEL, RENIGUNTA ROAD, TIRUPATI. - 517501 PH :7997969919.
93. VISHNU CARS (N902-01), SURVEY NO. 19/3/2A, 200' CHENNAI - TIRUPATI HIGHWAY, KOTRAMANGALAM,RENIGUNTA MANDAL, TIRUPATI - 517520 PH :9154971551.
- TIRUVURU**
94. SANTOSH AUTOMOTORS PVT. LTD. (CIM1-01), D NO. 23-1/5, OPP. AYYAPA SWAMY TEMPLE, MAIN ROAD, TIRUVURU. - 521235 PH :7799787969.
- TUNI**
95. SATLIBABU MOTORS (PVT) LTD. (KY01-01), D. NO. 65-31-151, OPP. FCI GODOWNS, NARAYANAPURAM, TUNI, EAST GODAVARI, ANDHRA PRADESH - 533401 PH :7661893888.
- VENKATAGIRIOTA**
96. BHARGAVI AUTO PVT. LTD. (CDI1-01), M/S BHARGAVI AUTOMOBILES, BESIDE INDIAL OIL BUNK,GMR FUNTION HALL,DARASALLA,PALLIKUPPAM,KUPPAM ROAD V KOTA - 517242 PH :9848602345, 7799997720.
- VENKATAPGIRI**
97. BHARGAVI AUTOMOBILES (SOL1-01), SURVEY NO 166,169/1,169/2,RTC COLONY,VENKATAGIRI, NELLORE, ANDHRA PRADESH - 524132 PH :9248747777.
- VIJAYAWADA**
98. MITHRA AUTO AGENCIES PVT LTD (2604-01), 40-17-3,PICHAIH STREET,GANDHI COLONY,VIJAYAWADA - 520001 PH :8886063507.
99. VARUN MOTORS PVT. LTD. (2603-01), 48-17-4/1,RING ROAD,VIJAYAWADA - 520008 PH :9885576602.
100. VARUN MOTORS PVT. LTD. (2603-06), SURVEY NO.561/1, 562/5 & 561/3, 562/6 KESARAPALLY,VIJAYAWADA, KRISHNA DISTRICT, A.P. - 521102 PH :8297241177.
101. SANTOSH AUTOMOTORS PVT. LTD. (2607-01), SURVEY NO. 22/3, D. NO. 16-1/2, KANURU PANCHAYAT, PENAMALURU MANDAL, VIJAYAWADA, KRISHNA DISTRICT, ANDHRA PRADESH. - 520010 PH :9209094999/7799787949.
102. VARUN MOTORS PVT. LTD. (2603-07), DOOR NO. 1-4-208 AND 1-4-208(1), I.R.S. NO. 33/3A, BHAVANIPURAM, VIJAYAWADA, MUNICIPAL CORPORATION, VIJAYAWADA, ANDHRA PRADESH. - 520012 PH :9642225291.
103. SANTOSH AUTOMOTORS PVT. LTD. (2607-02), D NO. 77-42-16A, OPP. NUNNA FIRE STATION, PRAKASH NAGAR, INNER RING ROAD, VIJAYAWADA - 520 015 PH :7799787932.
- VINUKONDA**
104. JAYALAXMI AUTOMOTIVES (SSO1-01), SURVEY NO 239/3A,237/3, VINUKONDA, PALNADU DISTRICT, ANDHRA PRADESH - 522647 PH :8374847777.
- VISHAKAPATNAM**
105. VARUN MOTORS PVT. LTD. (4603-0E), PLOT NO 88,BESIDES POLICE STATION,SRINAGAR,GAJUWAKA - 530026 PH :9703843737.
106. VARUN MOTORS PVT. LTD. (4603-08), DOOR NO. 58/2,BLOCK NO. 5,BALAJI NAGAR, OPP. ANDHRA UNIVERSITY, SIRIPURAM - 580003 PH :08912525885.
- VIZAG, VISHAKAPATNAM**
107. VARUN MOTORS PVT. LTD. (4603-0F), D-25, INDUSTRIAL ESTATE, MARRIPALLEM, BESIDES COLA MANCHU KONDA GARDENS, VISAKHAPATNAM., - 530007 PH :9885511911.
108. JAYABHERI AUTOMOTIVES PVT. LTD. (4606-01), PLOT NO. A-9, INDUSTRIAL ESTATE, VISAKHAPATNAM, ANDHRA PRADESH - 530018 PH :8886332209.
109. JAYABHERI AUTOMOTIVES PVT. LTD. (4606-02), D.NO:51-17-2 , NH-5, KRANTHINAGAR, VISAKHAPATNAM,(ANDHRA PRADESH) . - 530013 PH :7799772272.
110. VARUN MOTORS PVT. LTD. (4607-01), S. NO. 8, KAPPARADA VILLAGE, BESIDE IOCL PETROL BUNK, MANCHUKONDA GARDENS, MURALI NAGAR, NATIONAL HIGHWAY, VISAKHAPATNAM - 530007 PH :7799124243.
111. JAYABHERI AUTOMOTIVES PVT. LTD. (4606-03), SURVEY NO. 11/9/6, KURMANAPALEM, GAJUWAKA MANDAL, VIZAG, ANDHRA PRADESH. - 530046 PH :8897541234.
112. VARUN MOTORS PVT. LTD. (4603-0K), SURVEY NO. 394 & 395, PLOT NO. 7 AT VILLAGE – DUPPURITU, MANDAL – ACHUTAPURAM, DISTRICT – VISHAKAPATNAM, ANDHRA PRADESH . - 531011 PH :9966877133.
113. VARUN MOTORS PVT. LTD. (4603-0L), SURVEY NO. 408/1 OF MADHURAWADA VILLAGE, RUSHIKONDA ITI SEZ, VISAKHAPATNAM RURAL MANDAL, VISHAKAPATNAM DISTRICT, ANDHRA PRADESH . - 530045 PH :9885315344.
114. VARUN MOTORS PVT. LTD. (4603-1B), SURVEY NO. 2/A, SECTOR XI, MVP COLONY, VISAKHAPATNAM. - 530 017 PH :07901644535.
- VISSANNAPETA**
115. VARUN MOTORS (SNO1-01), RS NO. 434/10, WARD NO. 10, VISSANNAPETA, KRISHNA DISTRICT, ANDHRA PRADESH - 521215 PH :9885576602.
- VIZAG, VISHAKAPATNAM**
116. VARUN MOTORS (4603-10), SURVEY NO 228/224, WARD NO 19, AGNAMPUDI,VIZAG - 533063 PH :9885317344.
- VIZIANAGARAM**
117. VARUN MOTORS PVT. LTD. (4603-0C), OPPOSITE SUN SCHOOL, 100 FEET RING ROAD, VIZIANAGARAM, VIZIANAGARAM - 535001 PH :8886721213.

Dealer Network (AS ON 31.10.2023)

118. JAYABHERI AUTOMOTIVES PVT. LTD.
(N801-01), PLOT NO.B-1,DOOR
NO.8-32-1,SURVEY NO.108/12A & 109/2A,
INDUSTRIAL ESTATE, VANTITHADI
AGRAHARAM VILLAGE, VIZIANAGARAM,
ANDHRA PRADESH - 535001
PH : 7702333514.
- YANAM**
119. SB MOTORS (CTR1-01), SURVEY NO
82-2,TALLAREVU MANDAL,YANAM, EAST
GODAVARI DISTRICT - 533463
PH : 8886677759.
- YELAMANCHILI**
120. JAYABHERI AUTOMOTIVES PVT. LTD.,
(GJR1-01), SURVEY NO. 19-1, 2, 3, 45/1, 45/23,
KOKIRAPALLI, YELAMANCHILI, NARISPATNAM,
VIZAG DIST., ANDHRA PRADESH. - 531055
PH : 9849445639, 9642502345.
- YELESWARAM**
121. VARUN MOTORS (SQP1-01), VARUN MOTORS
P.LTD,DO-NO – 24-41,BESIDE GOLLAJI GARU
BUNK,YERRAVARAM ROAD,YELESWARAM –
533429 - 533429
PH : 9885511911.
- ARUNACHAL PRADESH**
- BHALUKPONG**
122. DY MOTORS (YT01-01), NEAR SBI UPPER
MARKET, BHALUKPONG, WEST KAMENG ,
ARUNACHAL PRADESH - 790114
PH : 8415075164.
- ITANAGAR**
123. D Y MOTORS (7502-01), LPC NO - DC/ICC/LPC,
BORUM VILLAGE, PO/PS- NAHARLAGUN,
PAPUM PARÉ DIST, ARUNACHAL PRADESH -
791100
PH : 8415075164.
- RUKSIN**
124. DY MOTORS (SHZ1-01), RUKSIN IN EAST
SIANG DISTRICT, ARUNACHAL PRADESH -
787080
PH : 8415075164.
- ASSAM**
- BAIHATA CHARIALI**
125. PALLAVI MOTORS PVT LTD (BNL1-01), DAG NO.
1042, PATTNA NO. 17, MOUZA – BORBANKHAR,
P. S. – BAIHATA CHARIALI, DISTRICT – KAMRUP,
ASSAM - 781381
PH : 9864052488.
- BARAMA**
126. MITTAL AUTOZONE (SOX1-01), VILLAGE -
BARJAR, PO & PS - BARAMA, ASSAM -781346 -
781346
PH : 8638487401.
- BARPETA**
127. BHARATI MOTORS PVT. LTD. (7N01-02),
SIMULGURI,NH-31,DISTRICT-BARPETA, ASSAM
- 781313
PH : 7002819523.
- BIJOYNAGAR**
128. PODDAR CAR WORLD (IA01-01), AT/PO -
BIJOYNAGAR, INDIAN OIL PETROL PUMP,
KAMRUP DIST., BIJOYNAGAR - 781125
PH : 9864209733.
- BISWANATHA**
129. RAMLAL DURGADUTT MOTORS PVT LTD
(BX1-01), DAG NO- 7,8,9 PERIODIC PATTNA NO -
24, REVENUE VILLAGE, BRAHMAPUTRA
CHAPORI, MOUZA - BAGHMORA - 784176
PH : 8724087940.
- BONGAIGAON**
130. BHARATI MOTORS PVT. LTD. (7N01-01),
CHAPAGURI ROAD, BONGAIGAON - 783380
PH : 7002350887/9864427537.
- CHAMATA**
131. PALLAVI MOTORS PVT LTD (CEH1-01), DAG
NO.1137, PATTNA NO.376, MOUZA –
DAHRAMPUR, CHAMATA DISTT. NALBARI,
ASSAM - 781306
PH : 9864052488.
- DHEKIAJULI**
132. RAMLAL DURGADUTT MOTORS PVT LTD
(BRX1-01), DAG NO.242, K.P. PATTNA NO.88,
VILLAGE-BHAKUMARI, MOUZA-BORCHOLA,
BESIDES-NH16, DHEKIAJULI, DISTT. SONITPUR,
ASSAM - 784110
PH : 9706568722.
- DHEMAJI**
133. SAIKIA AUTO PVT. LTD. (7P01-02), NALANIPAM
KONCH GAON,NH-52,DHEMAJI (ASSAM) -
787057
PH : 8638725209.
- DIBRUGARH**
134. JAYBEE AUTO AGENCIES PVT. LTD. (C101-01),
CHIRING CHAPARI, T.R. PHUKAN ROAD, P.O.
DIBRUGARH (ASSAM) - 786001
PH : 9954799273
135. BIMAL AUTO AGENCY (C102-01), DAG NO. 104,
GHARBANDICHUK JARUA GAON, MOUZA -
MANKHATTA KANIKAR, DIST.-DIBRUGARH,
ASSAM - 786004
PH : 9864074525, 7003901301.
- DIGBOI**
136. VISHAL CAR WORLD PVT LTD (BYD1-01),
BORBIL NO. 1, NEAR LIONS CLUB, NH-38, P.O. -
DIGBOI, DISTRICT – TINSUKIA , ASSAM. -
786171
PH : 9435860000..
- DIPHU**
137. RAMLAL DURGADUTT MOTORS PVT LTD
(1P01-01), MANJA ROAD, DILLAJI, DIPHU,
KARBI ANGLONG, ASSAM - 782460
PH : 9707556868.
- DULIAJAN**
138. JAYBEE AUTO AGENCIES PVT. LTD. (ADA1-01),
JAYBEE AUTO AGENCIES, TIPLING TINIHAL,
DULIAJAN DIST. DIBRUGARH - 786602
PH : 7002722358.
- GOALPARA**
139. BHARATI MOTORS PVT. LTD. (YN01-01), PO:
KALYANPUR, VILLAGE: SOLMARI, P/S: AGIA,
NH: 37, DISTRICT: GOALPARA, ASSAM - 781301
PH : 9101940372.
- GOLAGHAT**
140. RAMLAL DURGADUTT MOTORS PVT LTD
(J303-01), DAG NO. - 718, 684 & 706, PATTNA NO
213, 168 & 192, KUROKA GAON, P.O - MORANGI,
P.S.-GOLAGHAT, DIST: GOLAGHAT, ASSAM
PIN-785702 - 785702
PH : 7002099547.
- GORAIMARI**
141. BAJRANG CAR WORLD (A UNIT OF MAA
VAISHNAVI AUTOMOTIVE PVT. LTD.)
(GMB1-01), DAG NO- 3, KP PATTNA NO - 11,
VILLAGE- CHALABASTI, MOUZA- GORAIMARI -
783390
PH : 7002279100.
- GUWAHATI**
142. BIMAL AUTO AGENCY (901-01), JHALUKBARI,
GUWAHATI - 781014
PH : 9864074525.
143. PALLAVI MOTORS PVT LTD (902-01), DAG NO.
1&2,NEAR TO DEPTT. OF FAMILY WELFARE,SIX
MILE, KHANAPARA G.S. ROAD, GUWAHATI -
781022
PH : 9864210937.
144. PODDAR CAR WORLD PVT LTD (904-01),
HENGRAJARI, VIP ROAD, GUWAHATI - 781036
PH : 9508746340.
145. BIMAL AUTO AGENCY (903-01), CHANDMARI,
BAMUNI MAIDAN, OPP SBI NEW GUWAHATI
BRANCH, GUWAHATI - 781021
PH : 9864489722.
146. BIMAL AUTO AGENCY (901-02),
BEHARBARI,BEHIND DHOMO RESTAURANT,
NH-37, GUWAHATI - 781028
PH : 9864040406.
147. PODDAR CAR WORLD (905-01), NH-37, NEAR,
GORCHUK CHAIRALI, GUWAHATI (ASSAM) . -
781029
PH : 7002929414.
- HOWRAKHAT**
153. BAJRANG CARWORLD (SGR1-01),
HOWRAKHAT TOWN, KARBI ANGLONG, ASSAM
- 782481 / 782481
PH : 9864191169.
- JAGI ROAD**
154. RAMLAL DURGADUTT MOTORS PVT LTD
(J701-02),
JAGIROAD,MORIGAON,NALAOOW,ASSAM -
782410
PH : 9365884355.
- JORHAT**
155. RAMLAL DURGADUTT MOTORS PVT LTD
(G902-01), DAG NO. 7 & 8 OF P.P NO. 33, DAG
O. 9 OF P.P NO. 61, DAG NO. 382 OF P.P NO.
206, VILLAGE - PAKIMURI HABIGAON, MOUZA -
SARAIABHAL, JORHAT. - 785006
PH : 7002099547.
156. JAINCO AUTOTECH (G904-01), AT ROAD,
SEUNI ALI, JORHAT, ASSAM 785001 - 785001
PH : 9287957451.
- KALGACHIA**
157. MITTAL AUTO (SLB1-01), VILL - KALGACHIA, PO
- KALGACHIA , DIST BARPETA - 781319
PH : 8638487401.
- KARIMGANJ**
158. JAIN UDYOG (6901-04), STEAMER GHAT ROAD,
KARIMGANJ, ASSAM - 788710
PH : 9435179025.
- KAYAKUCHI**

159. MITTAL AUTO ZONE (-), B.B ROAD,
KAYAKUCHI, BARPETA, ASSAM - 781352
PH :8638487401.
- KHARUPATIA**
160. BIMAL (BWR1-01), VILL -BOLOGARAH, P.O –
KHARUPETIA, P.S DHULA, DIST – DARRANG,
ASSAM - 784115
PH :9864074525.
- KHATKHATI**
161. PODDAR CAR WORLD PVT. LTD. (CAZ1-01),
NEAR TELEPHONE EXCHANGE, NH-39,
KHATKHATI, DISTRICT – KARBI ANGLONG . -
782460
PH :6000900381.
- LANKA**
162. RAMLAL DURGADUTT MOTORS PVT LTD
(SDD1-01), DAG NO 95 OF PP NO 59, DAG NO
96 OF PP NO 26 & DAG NO 418 OF PP NO 73
KISAM LAKHIMPUR , MOUZA - LANKA, DIST -
HOJAI , ASSAM - 782442
PH :970755688.
- MANGALDOI**
163. PODDAR CAR WORLD (YW01-01), PUNIA,
NH-52 MANGALDOI, DISTT. DARRANG - 784115
PH :9706970132.
- MARGHERITA**
164. VISHAL CAR WORLD PVT LTD (YR01-01),
MARGERITA TOWN, BEHIND IOC PETROL
PUMP, NH-38, MARGHERITA, ASSAM - 786181
PH :9435860000.
- MORIGAON**
165. RAMLAL DURGADUTT MOTORS PVT LTD
(RB01-01), DAG NO. 423 OF PP NO. 221,
KISSAM BACHNAGHAT, MORIGAON, ASSAM -
782105
PH :9702239592.
- NAGAOA**
166. RAMLAL DURGADUTT MOTORS PVT LTD
(J01-01), KHUTIKHATIA, HAIBARGON,
NAGAOA - 782002
PH :9706007918.
167. BAJRANG CAR WORLD (A UNIT OF MAA
VAISHNAVI AUTOMOTIVE PVT. LTD.) (TJ03-01),
DAG NO. 255, 1508(N)/254(O), 1509(N)/257(O)
AND 291, PATTNA NO. 506(N)/15(O), 507(N)/15(O),
507(N)/97(O) AND 98, VILLAGE - DEODHAR,
MOUZA - PAKHIMORIA, DIST -NAGAOA . - 782002
PH :9435060474/9864191169.
168. RAMLAL DURGADUTT MOTORS PVT LTD
(J01-03), PAKHIMORIA, NEAR BHUGDI
DHABA, NAGAOA, ASSAM - 782003
PH :9706007918.
- NAHARKATIYA**
169. JAYBEE AUTO AGENCIES PVT. LTD. (C101-03),
NAHARKATIYA TOWN PART NO. 4, MOUZA –
JAYPORE, NEAR ST. MARY'S SCHOOL,
DISTRICT – DIBRUGARH, ASSAM . - 786610
PH :7002272358.
- NALBARI**
170. BIMAL AUTO AGENCY (9201-01),
CHOWKBAZAR, NALBARI HAJO ROAD, NALBARI
DIST. NALBARI - 781335
PH :7576842848.
- NORTH LAKHIMPUR**
171. SAIKIA AUTO PVT. LTD. (7P01-01), HATILING,
NH-52 ROAD, NORTH LAKHIMPUR, ASSAM -
787031
PH :8473946336.
172. SAIKIA AUTO PVT. LTD. (7P01-03), KHELMATI,
WARD NO. 14. NH-52, NORTH LAKHIMPUR,
ASSAM - 787001
PH :7002571073.
- PATHSALA**
173. PODDAR CAR WORLD PVT. LTD. (CLD1-01-),
DAG NO. 451, PATTNA NO. 151 KMP, PATHSALA,
DIST -BARPETA, ASSAM . - 781325
PH :6000900256.
- RAJGARH**
174. JAYBEE AUTO AGENCIES PVT. LTD. (CLJ1-01-),
DAG NO. 182, PP NO 140 OF 2 NO. BHAGATIA
GAON, LAT NO.11, RAJGARH,
MOUZA-TINKHONG, DISTT. DIBRUGARH,
ASSAM - 786611
PH :9954799273.
- RANGIA**
175. PODDAR CAR WORLD PVT. LTD. (6X01-01-),
RANGIA TOWN, WARD NO. 5, SHANTIPUR,
BHUTAN ROAD, NEAR POLYCLINIC HOSPITAL,
RANGIA DISTT. KAMRUP (ASSAM) - 781354
PH :8724877792.
- SILCHAR**
176. JAIN UDYOG (6901-02), KAUSHAL COMPLEX,
SONAI ROAD, SILCHAR, ASSAM - 788006
PH :9706002524.
- SIVASAGAR**
177. RAMLAL DURGADUTT MOTORS PVT LTD
(G902-02), RANGHAR CHARALI, DHAPROTA,
AT ROAD, OPPOSITE RANGHAR, SHIVASAGAR -
785640
PH :7002099547.
- SORBHOG**
178. MITTAL AUTOZONE (SGS1-01), VILLAGE
DAHALAPARA, KISMAT DWARIKA, PS
SORBHOG, SUB DIVISION- BARPETA- ASSAM . -
781317
PH :8011042222.
- TANGLA**
179. BIMAL AUTO AGENCY (CHO1-01), DAG NO.:121,
PATTNA NO.101/320, VILLAGE BULLARPARA,
MOUZA TANGLA. - 784521
PH :9954387619.
- TEZPUR**
180. RAMLAL DURGADUTT MOTORS PVT LTD
(T102-01), NEAR DON BASCO SCHOOL P.O.
NIKAMULSATRA, TEZPUR, ASSAM - 784154
PH :7240287940.
181. RAMLAL DURGADUTT MOTORS PVT LTD
(T102-02), GORAIMARI, VILLAGE - SOLGAON,
TEZPUR, ASSAM . - 784001
PH :9836036157.
- TINSUKIA**
182. VISHAL CAR WORLD PVT LTD (J401-01-),
LAIPULY, A.T ROAD, TINSUKIA, DIST -
TINSUKIA, ASSAM - 786183
PH :9435860000.
- BIHAR**
- ARARIA**
183. SEEMANCHAL MOTORS PVT. LTD. (O701-01-),
NEAR BUS STAND, JAGDISH RICE MILL
COMPOUND, HOSPITAL ROAD, FORBESGANJ,
DISTT. ARARIA, BIHAR - 854318
PH :8797096013.
- ARRAH**
184. PEARL CARS (VU01-01-), (A UNIT OF
VINDHYAVASI AUTOMOBILES PVT. LTD.),
DHANUPRA, NEAR GANPAT CHAUDHARY
DWAR, NH-30, ARRAH (BIHAR) - 802301
PH :8294634605.
- AURANGABAD**
185. KARLO AUTOMOBILES (SNG1-01-), KARLO
AUTOMOBILES PVT LTD, GT ROAD, NEAR,
RAIPURA MORE, BABHANI, AURANGABAD -
824101
PH :7019085212.
- BANKA**
186. SEEMANCHAL MOTORS PVT. LTD. (CEO1-01-),
KHATA NO. 134, KHESRA NO. 118, BEHIND
MARUTI SHOWROOM, STATION ROAD, BANKA,
BIHAR . - 813101
PH :8797096020.
- BEGUSARAI**
187. GS MOTORS PVT. LTD. (1U01-01-), HARHAR
MAHADEW CHOWK, NH 31, BEGUSARAI, BIHAR -
851101
PH :9204756206.
- BETTIAH**
188. SHREE GOPAL AUTO PVT. LTD. (O401-01-),
BEETIAH - MOTIHARI HIGHWAY , NH-28 B,
NEAR MACHALI LOK, BEETIAH (BIHAR) . - 845438
PH :9771486183.
- BHAGALPUR**
189. SEEMANCHAL MOTORS PVT. LTD. (G802-01-),
BAUSI ROAD, ALIGANJ, NEAR SAINT TRESA
SCHOOL, ALIGANJ, BHAGALPUR . - 812005
PH :8797096020.
- BIHITA**
190. REESHAV (CBY2-01), PLOT NO 1674 & 1676,
KHATA NO .- 19 & 67 AT MOUZA - MAHADEOPUR
PHULARI, P.O - BIHTA, P.S - BIHTA, DISTRICT -
PATNA - 801103
PH :7763954585.
- BIHARSHARIF**
191. REESHAV AUTOMOBILES (MG01-03), PATNA
RANCHI ROAD, NR GAGAN DIWAN SOGARA
SCHOOL, THANA-LAHERI MURARPUR,
BIHARSHARIF, DISTRICT-NALANDA, BIHAR -
803101
PH :9263632175.
- BUXAR**
192. PEARL CARS (VV01-01-), C/O DEVDHTRHA
UPPDHYA, SYNDICATE, BYE PASS ROAD,
BUXAR - 802101
PH :8294634605/8294634602.
- CHAKIA**
193. RAM KRISHNA MOTORS PVT. LTD. (CWA1-01-),
OJHA TOLA, NEW BYPASS, CHAKIA-845412,
PURVI CHAMPARAN DISTTT., BIHAR - 845412
PH :9801773716.
- CHAPRA**
194. REESHAV AUTOMOBILES (MG01-02-), 146, PLOT
NO. 381, VILLAGE RAUJA, CHAPRA PATNA
ROAD, NEAR BHIKHARI CHOWK, CHAPRA,
BIHAR - 841301
PH :7061295296.
- DANAPUR**
195. ALANKAR AUTO SALES & SERVICE PVT LTD
(1504-02-), ADJASCENT ARYA SAMAJ MANDIR,
NEAR SAGUNA MORE, DANAPUR, - 800018
PH :933689458.
- DANAPUR, PATNA**
196. ALANKAR AUTO SALES & SERVICE PVT LTD
(1504-05-), TOUZI NO. 5057, THANA NO. 35,
MOUZA - BABAKKARPUR, DANAPUR, PATNA . -
801503
PH :9334415434.
- DARBHANGA**
197. RAJKRISHNA MOTORS LLP (1V02-01-), KHATA
NO.61936, RAUSHAN CHOWK, JAIPUR, B.M.P.
-13, ROAD, DARBHANGA, BIHAR - 846009
PH :7004529271.
198. RAJKRISHNA MOTORS LLP (1V02-02-), VIP
ROAD, ALLALPATTI, DARBHANGA (BIHAR) . -
846003
PH :9693127351.
- DEHRI ON SONE**

Dealer Network (AS ON 31.10.2023)

199. PEARL CARS (1X01-02), MOUZA - KHASRA, KHATA NO. 141, PLOT NO. 186, SAAT KATDA THAN - DEHRI-ONE-SONE, DIST - ROHTAS, BIHAR - 821307
PH : 8294634602.

GAYA

200. KARLO AUTOMOBILES PVT LTD (Y601-01), BODH GAYA - 824231
PH : 7004574631/8539063615.
201. DMC CARS (A UNIT OF DHANRAAJ AGENCIES PVT LTD (Y602-01).), DHANRAAJ AGENCIES PRIVATE LIMITED, MARUTI SUZUKI ARENA SHOWROOM, OPPOSITE AIRPORT RUNWAY, GAYA-DOBHI ROAD,GAYA, PIN 823004 - 823004
PH : 9031011806/9900024001.

GOPALGANJ

202. SHREE GOPAL AUTO PVT. LTD. (O301-01), NH-28, DANAPUR, TEHSIL-MANJGARH, GOPALGANJ (BIHAR) - 800023
PH : 9771486170/9771486139.

HAJIPUR

203. REESHAV AUTOMOBILES (MG01-01), KHATA 617 & KHASHRA 354/1605, NEAR RELIANCE PETROL PUMP, M G SETU ROAD, HAJIPUR (VAISHALI) - 844101
PH : 9060945038.

JEHANABAD

204. DMC CARS (SNV1-01), KHATA NO - 80, PLOT NO -1400, MOUZA - MUTHER, PS- JEHANBAD, DIST - JEHANABAD, - 804408
PH : 9031011806/9900024001.

KATIHKAR

205. SEEMANCHAL MOTORS PVT. LTD. (O601-01), NEAR SBP VIDYA VIHAR SCHOOL, SIRSA, KATHIHKAR PURNEA ROAD, KATIHKAR - 854105
PH : 7762893700.

KISHANGANJ

206. SEEMANCHAL MOTORS PVT. LTD. (PX01-01), PASCHIM PALI ROAD, COLLEGE ROAD, THANA-KNE, WARD NO.1, KISHANGANJ (BIHAR) - 855101
PH : 8797096019.

LAKHISARAI

207. GS MOTORS PVT. LTD. (CHU1-01), TAUZI NO. 39, KHATA NO. 3, KHESRA NO. 496, MOUZA - JAINAGAR, ANCHAL - LAKHISARAI, DIST. - LAKHISARAI, BIHAR, - 811311
PH : 9204756206.

MADHUBANI

208. RAJKRISHNA MOTORS LLP (CAJ2-01), BHOWRA TOLA, BARDIBAN, MADHUBANI, BIHAR - 847211
PH : 9304491978
9693127351.

MOHANIA

209. PEARL CARS (VW01-01), MOHANIA-BUXAR ROAD ,SH-14,MOHANIA - 821109
PH : 8294634632/8294634649.

MOTIHARI

210. RAJIV AUTOMOBILES PVT LTD (T401-03), NEAR CHHATUAUNI CHOWK, BESIDE NH 28 A, MOTIHARI TOWN, BIHAR - 845401
PH : 9234609669.

MUZAFFARPUR

211. RAJIV AUTOMOBILES PVT LTD (T401-01), RAMDAYALU NAGAR, PATNA HAZIPUR ROAD, MUZAFFARPUR, BIHAR - 842002
PH : 9910347908.

212. RAM KRISHNA MOTORS PRIVATE LTD. (T402-01), KRISHNA TALKIES CAMPUS, AKHARAGHAT ROAD, MUZAFFARPUR, BIHAR. - 842001
PH : 9102173333.

213. RAJIV AUTOMOBILES PVT LTD (T401-04), Khabra POKHAR LANE NO -1, PANCHAYAT -KHABRA, CITY - MUZAFFARPUR - 843146
PH : 9234609671.

NAUGACHIA

214. SEEMANCHAL MOTORS PVT. LTD. (CFS1-01), NEAR GAYATRI PLY ROOM, NH-31, NAUGACHIA MARKET, NAUGACHIA, DISTRICT - BHAGALPUR, BIHAR - 853204
PH : 8797096014, 8797096020.

NAWADA

215. REESHAV AUTOMOBILES (MG01-04), 191 & 400, KHSARA NO. 3105 & 3102, NEAR DM'S OFFICE, PATNA-RANCHI MAIN ROAD, NAWADA, BIHAR - 805110
PH : 6206162228.

PATNA

216. VAU'S AUTOMOBILE (1503-01), BESIDES GODAVARI APPARTMENT, ASHIANA ROAD, PATNA - 800014
PH : 9771446012.

217. KARLO AUTOMOBILES PVT LTD (1502-04), NEAR BATA GUNJ, DINGA PATNA, BIHAR. - 800013
PH : 09304212119/7004573547.

218. ALANKAR AUTO SALES & SERVICE PVT LTD (1504-03), PLOT NO.118-119, BEHIND DURGA MARINE DRIVE APARTMENTS, DUJRA DEVI STHAN, ASHOK RAJPATH, PATNA - 800001
PH : 9934020200.

219. REESHAV AUTOMOBILES PVT.LTD. (1506-01), PLOT NO/15181 MOUZA NO.494, MOUZA KUMHRAR, PARGANA AZEEMABAD, KANKARBAGH, PATNA - 800004
PH : 7632995356.

220. KARLO AUTOMOBILES PVT LTD (1502-05), JAGDEOPATH , NEAR SAI CORPORATE PARK, PATNA - 801506
PH : 9264190675.

221. ALANKAR (1504-06), ALANKAR COMPOUND, BESIDE ALANKAR SUN CITY, SANDALPUR, KUMHRAR, PATNA - 800006 - 800006
PH : 9034403916.

PURNEA

222. SEEMANCHAL MOTORS PVT. LTD. (6V01-01), NH-31, NEAR MARKETING YARD, GULAB BAGH, PURNEA (BIHAR) - 854326
PH : 8797096014.

SAHARSA

223. GS MOTORS PVT. LTD. (AAP1-02), PATUAHA, NH 107 SAHARSA,BIHAR - 852201
PH : 9263638456.

SAMASTIPUR

224. RAJKRISHNA MOTORS LLP (1W02-01), KHESRA NO. 3190-95, KHATA NO. 76, HERPUR ALLOTH, SAMASTIPUR, BIHAR. - 848101
PH : 9204552405.

SASARAM

225. PEARL CARS (1X01-01), PLOT NO.7, 9 & 11, NH-2 MORE SARAI, SASARAM (BIHAR) - 821115
PH : 8294634602/8294634649.

SITAMARHI

226. RAJIV AUTOMOBILES PVT. LTD. (E001-01), DUMRA ROAD, SHANTI NAGAR, SITAMARHI. - 843301
PH : 9234609671
7280074124.

SIWAN

227. SHREE GOPAL AUTO PVT. LTD. (O501-01), CHAPRA ROAD, NEAR CHAPDHALA, NH 85, SIWAN - 841236
PH : 9771486132.

CHANDIGARH

CHANDIGARH

228. MODERN AUTOMOBILES (702-01)- 4 M.W. INDL AREA, CHANDIGARH - 160002
PH : 9646000190.

229. AUTOPACE NETWORK PVT LTD (705-01-), PLOT #112-113, INDUSTRIAL AREA, PHASE-1, CHANDIGARH - 160002
PH : 9878422201.

230. TRICITY AUTOS (9M01-02), PLOT NO 29/6, INDUSTRIAL AREA PHASE-2, CHANDIGARH - 160002
PH : 998882335.

231. NAVDESH AUTO LLP (708-01-), PLOT NO. 42, INDUSTRIAL AREA PHASE-1, CHANDIGARH. - 160002
PH : 7087035482.

CHATTISGARH

CHARODA

232. SPARSH AUTO (SIZ1-01), NH-6, OPP. RAIL NAGAR, CHARODA, BHILAI - 490025
PH : 8770554701.

GHARGHODA

233. M SOAURE (SML1-01), M/S M SOAURE,VILLAGE BHENGARI, NAVAPARA-TENDA, GHARGHODA,DISTRICT – RAIGARH CHHATTISGARH. PIN CODE: 496111 - 496111
PH : 7987690484.

KURUD

234. HDN MOTORS (SKS1-01), KHASRA NO 601/9 & 601/10, DHAMTARI-RAIUPUR ROAD, KURUD, CHHATTISGARH - 493663
PH : 7909800004.

PHULBANI

235. SKY AUTO (CEP1-01), PLOT NO. 54/533, GUDRIASHI, KHAJURAPADA,DISTRICT – KANDHAMAL ODISHA. PIN CODE: 762001 - 762001
PH : 9776900333.

CHHATTIGARH

PENDRA

236. M SOAURE (SCZ1-01) – M SQUARE MOTORS, NEAR SEMRA CLOCK MAIN ROAD, PENDRA, GOURELA PENDRA MARWAHI-495119 - 495119
PH : 7987590484.

CHHATTIGARH

AKALTARA

237. M SOAURE (SKE1-01), SHOP NO 4,5,6,7 & 8, SHRI NARAYAN COMPLEX & GODOWN, NEAR INDRA UDYAN,SEHORINARAYAN ROAD,AKALTARA-49552, CHHATTIGARH - 49552
PH : 7987590484.

AMBIKAPUR

238. MAHAMAYA AUTOCARS PVT LTD (AE01-01), MANEDRAGRABH ROAD, AMBIKAPUR, CHHATTIGARH - 497001
PH : 9877474132.

BAGBABAHR

239. HDN MOTORS (SEB1-01), M/S HDN MOTORS, BESIDE R.N RICE MILL, NEW MAHAVEER COMPLEX, MAHASAMUND ROAD, BAGBABAHR - 493449
PH : 7909800004.

BAIKUNTHPUR

240. MAHAMAYA AUTOCARS PVT LTD (CQU1-01-), WARD NO.01, KHATA NO.91/6, TEHSIL - BAIKUNTHPUR, DISTT. - KORIYA, CHATTISGARH - 497335 PH :9179350707.
- BALOD**
241. CHOUPAHAN (SFE1-01-), H.NO 185, WARD NO 25, NAYA MARKET, DALLIRAJHARA, BALOD - 491228 - 491228 PH :9837325267.
- BALODA BAZAR**
242. SKY AUTOMOBILES (5001-04-), AMBEDKAR CHOWK, RAIPUR ROAD, BALOD BAZAAR, CHATTISGARH - 493332 PH :9893307429.
- BASNA**
243. VISHWABHARTI (VT01-01-), M/S VISHWABHARTI AUTO, PADAMPUR ROAD, BASNOLI, BASNA,CHHATTISGARH - 493554 PH :6262620060.
- BEMETRA**
244. CHOUPAHAN AUTOMOBILES LLP (CBC2-01-), KHASRA NO. 88/2, CHOUPAHAN AUTOMOBILE LLP, KAWARDHA ROAD, NAVGHAD CHOWK, BEMTRA CHATTISGARH - 491335 PH :6260002222.
- BHATAPARA**
245. SPARSH AUTOMOBILES (BBJ1-01-), RAIPUR ROAD, BHATAPARA (CHATTISGARH) - 493118 PH :8921326361/ 9285505780.
- BHILAI**
246. CHOUPAHAN AUTOMOBILES LLP (8305-01-), PLOT NO.1 & 34, SHIVNATH COMPLEX, BEHIND CHOUPAHAN ESTATE, G.E. ROAD, SUPELA, BHILAI - 490023 PH :9111100140.
247. SPARSH AUTOMOBILES PVT LTD (8304-01-), R-17, INDUSTRIAL AREA, NANDNI ROAD, CHHAWANI CHOWK, BHILAI, CHHATTISGARH - 490026 PH :8779064848.
248. CHOUPAHAN AUTOMOBILES LLP (8305-02-), NH-6, DURG BYPASS ROAD, KHASRA NO. 1/14, 1/23, 1/192, VILLAGE-KATULBOD, BHILAI, TEHSIL & DISTT, DURG, BHILAI, CHHATTISGARH - 491001 PH :6262000222.
- BHILLAI**
249. SPARSH AUTOMOBILES (8304-02-), M/S. SPARSH AUTO,VEERSAVARKAR MARKET, G.E ROAD, SUPELA,BHILAI-490023 - 490023 PH :9926626662.
- BILASPUR**
250. SATYA AUTO PVT LTD (C303-01-), SECTOR C, PLOT NO. 42, SIRGITTII INDUSTRIAL AREA, BILASPUR, CHHATTISGARH - 495001 PH :9109194833.
251. SATYA AUTO PVT LTD (C303-02-), PLOT NO. 848/20, 848/26, 848/40, MOPKA BYPASS ROAD, BILASPUR, CHHATTISGARH. - 495006 PH :9977879998.
252. M SQUARE MOTORS (A UNIT OF MAHAVIR MOTORCORP PRIVATE LIMITED) (C302-01-), KHASRA NO. 420 AND 414/1, NEAR RELIANCE PETROLEUM PUMP, BESIDES TRANSPORT NAGAR GATE, RAIPUR ROAD, PARSA, BILASPUR. - 495223 PH :6262622560.
- DALLIRAJHARA**
253. CHOUPAHAN (SMZ1-01-), H.NO 185, WARD NO 25, NAYA MARKET,DALLIRAJHARA,BALOD DISTRICT-491228 - 491228 PH :6262000222.
- DEOBHOG**
254. SPARSH AUTO (SIQ1-01-), M/S SPARSH AUTOMOBILES PVT LTD SANTOSHI NAGAR,NEAR BHARAT PETROL PUMP, DHARAMGARH ROAD, DEOBHOG - 493890 - 493890 PH :9926626662.
- DHAMTARI**
255. SKY AUTOMOBILES (7V01-01-), KASRA NO.238/2, SEHARA DABRI, RAIPUR ROAD, DHAMTARI-493773 CHATTISGARH - 492009 PH :888998612.
- DURG**
256. SPARSH AUTOMOBILES PVT LTD (7W03-01-), OPP. JAINAM PLACE, BEFORE PULGAON CHOWK, PULGAON NAKA, DURG, CHHATTISGARH - 491001 PH :9840437544.
- GARIYABANDH**
257. SPARSH AUTOMOBILES (CCH1-01-), NEAR HP PETROL PUMP, RAIPUR ROAD, GARIYABANDH, CHHATTISGARH. - 756032 PH :9669638883.
- JAGDALPUR**
258. SKY AUTOMOBILES (EC01-01-), GEEDAM ROAD, JAGDALPUR, CHATTISGARH. - 494001 PH :9109996511.
- JANJIGIR**
259. SATYA AUTO PVT LTD (9N02-01-), NEAR KHOKSHA RAILWAY CROSSING, CHAMPA ROAD, NH-200, JANJIGIR - 495668 PH :7747000446.
- KANKER**
260. SKY AUTOMOBILES (5001-06-), RAZA NAGAR, SINGARBHAT, NH-30, KANKER , DISTRICT – KANKER, CHHATTISGARH - 494334 PH :8889998625.
- KAWARDHA**
261. CHOUPAHAN AUTOMOBILES LLP (D102-01-), KHASRA NO. 100/6, TALPUR BILASPUR ROAD, KAWARDHA, CHHATTISGARH. - 491 995 PH :6262000222.
- KHAIAGRARH**
262. SPARSH AUTOMOBILES PVT LTD (GMG1-01-), KHAIRAGRARH- JHALBANDHA ROAD,AMILPARA, OPP - BIJALI OFFICE, KHAIRAGRARH -491881 - 491881 PH :9926626662.
- KHARSIA**
263. SATYA AUTO (SET1-01-), M/S SATYA AUTO , BESIDE GOVT HIGH SCHOOL, RANISAGAR, KHARSIA, DISTRICT: RAIGARH, CHHATTISGARH - 496661 PH :993092051.
- KONDAGOAN**
264. SKY AUTO (SDF1-01-), - M/S SKY AUTO, NH-90 RAIPUR ROAD, NEAR INDIAN OIL PETROL PUMP, KONDAGOAN, CHHATTISGARH - 494226 PH :9425204051.
- KORBA**
265. SATYA AUTO PVT LTD (U702-01-), SHED NO. 1, INDUSTRIAL AREA, KORBA - 495681 PH :8462000861.
- MAHASAMUND**
266. SPARSH AUTOMOBILES (5002-02-), BARONDA CHOWNK, BAGBAHRA ROAD, MAHASAMUND. - ?? PH :9926280700.
- MANENDRAGARH**
267. MAHAMAYA AUTOCARS PVT LTD (AE01-02-), WARD NO.21, NH-43, AMBIKAPUR ROAD, NEAR HP PETROL PUMP, MANENDRAGARH, DISTT. KORIYA - 497442 PH :9584136234.
- MUNGELI**
268. SATYA AUTO PVT LTD (BLE2-01-), KHASRA NO. 270/2, BILASPUR ROAD, MUNGELI, CHHATTISGARH - 861468 PH :8462000844.
- PATHALGAON**
269. MAHAMAYA AUTOCARS PVT LTD (BX01-01-), KHASRA NO. 567/2, PHATALGAON, DISTRICT – JASPUR, CHHATTISGARH. - 496118 PH :7952195523.
- PITHORA**
270. SPARSH AUTOMOBILES (CCG1-01-), PLOT NO. 284/1, RAMSAGAR PARA, RAIPUR ROAD, PITHORA, CHHATTISGARH. - 761008 PH :9926280700.
- RAIGARH**
271. SATYA AUTO PVT LTD (7Y03-01-), JINDAL ROAD, RAIGARH - 496001 PH :7024398350.
- RAIPUR**
272. SKY AUTOMOBILES (5001-01-), G.E.ROAD, MOHABA BAZAR, RAIPUR. - 492010 PH :9584433102.
273. SKY AUTOMOBILES (5001-02-), K.K. ROAD, MOUDHAPARA, RAIPUR. - 492001 PH :9584460290.
274. SPARSH AUTOMOBILES (5002-01-), PACHHPADI NAKA, OPP. DUTTA DRY CLEANER, DHAMKARI, JAGDALPUR ROAD, RAIPUR. - 492001 PH :9669792000.
275. SKY AUTOMOBILES (5001-05-), NEAR R.K. MALL, KOTA ROAD, RAIPUR - 492001 PH :9893000161.
276. SKY AUTOMOBILES (5003-01-), AVANTIVIHAR ROAD, TELEBANDHA, RAIPUR (C.G) - 492006 PH :9522314155.
277. SPARSH AUTOMOBILES (5002-04-), OPP. UNION BANK, MAIN ROAD, PANDRI, RAIPUR - 492004 PH :9009666400.
278. SPARSH AUTOMOBILES (5002-05-), PLOT - 31, INDUSTRIAL ESTATE, OPP MAHESH COLD STORAGE, BHANPURI, RAIPUR - ?? PH :9977220395.
279. SKY AUTOMOBILES (5001-07-), ADJOINING WALLFORT CITY, BHATGAON, RING ROAD NO. 2, RAIPUR, CHHATTISGARH. - 492013 PH :9584460289.
280. HDN MOTORS PVT. LTD. (5005-01-), BESIDES BHARAT BENZ SHOWROOM, DURG-BHILAI ROAD, TATIBANDH, RAIPUR, CHHATTISGARH. - 492001 PH :7909800093.
281. VISHWABHARTI AUTOMOBILES PRIVATE LIMITED (5004-01-), VIDHAN SABHA ROAD, MOWA, RAIPUR DISTT. CHHATTISGARH - 492005 PH :6262620057.
- RAJIM**
282. SPARSH AUTOMOBILES (5002-03-), RAIPUR ROAD, NEAR AMMAMI PETROL PUMP, NAYAPARA, RAJIM. - 493881 PH :9669638883.
- RAJNANDGAON**
283. SPARSH AUTOMOBILES PVT LTD (LQ02-01-), NEAR HANUMAN TEMPLE, VILL-MANKI , NH-6, RAJNANDGAON, CHHATTISGARH - 491441 PH :7837518100.
- SARAIAPALLI**

Dealer Network (AS ON 31.10.2023)

284. SKY AUTOMOBILES PVT. LTD. (BUF1-01-), KHASRA NO.4825 AND 482/6, RAIPUR ROAD, SARAIPALI, DIST-MASAMUND, SARAIPALI - 493558 PH :7000723259.
- SARANGARH**
285. SATYA AUTO PVT LTD (BUC2-01-), KASRA NO. 714, 73/2, 74/2, 75/1 AND 76/2, SARANGARH BIKAS KHAND, SARANGARH, DISTT. RAIGARH. - 733751 PH :8462000841.
- SIMGA**
286. HDN MOTOR (SSZ1-01-), PLOT NO 2, WARD NUMBER 05, SHANKAR NAGAR, SIMGA, BALODA BAZAR, CHHATTISGARH - 493101 PH :9826686000.
- TILDA**
287. SKY AUTOMOBILES (CWR1-01-), KASRA NO. 29/31, TILDA, DIST.-RAIPUR, CHHATTISGARH. - 493 114 PH :9425204051.
- TITLAGARH**
288. ODYSSEY MOTORS (SOE1-01-), M/S PLOT NO 687/1216, MOUZA PIPALPADAR, TITLAGARH,BALANGIR, ORISHA - 767033 PH :9439314464.
- CHATTISGARJH**
- SHIVIRNARAYAN**
289. SATYA AUTO (SMQ1-01-), M/S SATYA AUTO,DEORI, SHIVIRNARAYA, JANJGI - CHAMPA, CHATTISGARH - PIN 495556 -495556 PH :9993092051.
- DADRA AND NAGAR HAVELI**
- SILVASSA**
290. KATARIA AUTOMOBILES PVT. LTD. (ED01-01-), NEAR ATHAL CHAR RASTA,DADAR & NAGAR HAVELI, SILVASSA - 396230 PH :9723816223.
- DAMAN AND DIU**
- DAMAN**
291. KATARIA AUTOMOBILES PVT. LTD. (104-08-), NEAR AKASWANI CENTER, RINGANWADA, NANI DAMAN , DAMAN UNION TERRITORY - 396210 PH :9924130655.
- DELHI**
292. SAYA AUTOMOBILES PVT. LTD. (808-03-), A 21-22, G.T.KARNAL ROAD, NEW DELHI - 110033 PH :47088888.
293. BAGGA LINK MOTORS PVT LTD. (811-01-), 395 PATTPAR GANJ INDL. AREA,PATPARGANJ,NEW DELHI - 110092 PH :46488830, 46488831.
294. DD MOTORS (A DIVISION OF D.D. PREM PVT LTD.) (08F1-01-), A-100 MAYAPURI,PHASE-II,NEW DELHI - 110064 PH :41845000, 49305232
295. COMPETENT AUTOMOBILES CO. LTD. (806-03-), PLOT NO.3,GAZIPUR,DELHI. - 110096 PH :45300000.
296. T.R. SAWHNEY MOTORS PVT LTD (819-01-), 33 & 34, HARICHAND MELAMAR COMPLEX, EAST GOKULPUR, WAZIRABAD ROAD, DELHI - 110094 PH :9999399104, 9999399110.
297. RANA MOTORS PVT LTD (08A1-02-), C-47,OKHLA INDUSTRIAL AREA,PHASE-II,NEW DELHI - 110020 PH :41707777.
298. T.R. SAWHNEY MOTORS PVT LTD (819-02-), B-6 INDUSTRIAL AREA, PHASE I, OPP SECTOR 18, BADLI, NEW DELHI - 110042 PH :71118333.
299. DD MOTORS (A DIVISION OF D.D. PREM PVT LTD.) (08F2-01-), 5, WAZIPUR,INDUSTRIAL AREA,ADJACENT TO WAZIPUR DEPOT,RING ROAD, NEW DELHI - 110035 PH :999900388, 8860637394, 8860637306, 8448594691.
300. ROHAN MOTORS LTD. (886-01-), F-9/8-1 MOHAN COOPERATIVE INDUSTRIAL ESTATE, MATHURA ROAD, DELHI - 110044 PH :40567900, 41679252-259.
301. MAGIC AUTO PVT. LTD. (888-01-), A-93,PHASE-2,MAYAPURI INDL AREA,DELHI - 110064 PH :41847777.
302. DD MOTORS (A DIVISION OF D.D. PREM PVT LTD.) (08F3-01-), KHASRA NO. 544/1, MUNDKA, NEW DELHI - 110041 PH :259613535, 48616500.
303. T.R. SAWHNEY MOTORS PVT LTD (819-04-), PLOT NO-508, FUNCTIONAL INDUSTRIAL ESTATE, PATPARGANJ - 110092 PH :9999044326, 9999525756.
304. MAGIC AUTO PVT. LTD. (0887-01-), PLOT NO. 6/3,MOTINAGAR,NEW DELHI - 110015 PH :43777777, 43777721.
305. SAYA AUTOMOBILES (808-2B-), KHASRA NO.2,G.T. KARNAL ROAD,OPP. GURUDUARA HARGOVIND SINGH,SIRAS PUR BADLI,DELHI - 110033 PH :27731325, 27731856.
306. RANA MOTORS PVT LTD (08A1-04-), B-6/6, OKHLA INDUSTRIAL AREA PHASE-II, NEW DELHI - 110020 PH :40877777, 26389930.
307. COMPETENT AUTOMOBILES CO. LTD. (806-06-), 650/1A, 14, SHIVAJI MARG, NAGAFGARH ROAD, NEW DELHI - 110015 PH :8377070988.
308. PREM MOTORS PVT. LTD. (08D4-01-), KH. NO.804/2,MAHIPALPUR MATA CHOWK, DELHI - 110037 PH :1011 42390000.
309. AAA VEHICLEADES PVT. LTD. (0889-03-), VILLAGE GHEVRA, KHASRA NO.87/3, 87/8 & 87/13/1, DELHI-ROHTAK ROAD, METRO PILLAR NO.616, MUNDKA, NEW DELHI - 110041 PH :9717092903.
310. RANA MOTORS PVT LTD (08A1-05-), A-8, RAJASTHAN UDYOG NAGAR, NEAR AZADPUR FRUIT MARKET, G.T. KARNAL ROAD, OPP. METRO PILLAR NO.119, DELHI. - 110033 PH :41609999, 42474444.
311. T.R. SAWHNEY MOTORS PVT LTD (08D2-01-), B-19, MAYAPURI INDUSTRIAL AREA, PHASE-1, NEW DELHI. - 110064 PH :71119333, 8999049337.
312. DD MOTORS (A DIVISION OF D.D. PREM PVT.LTD.) (08F1-02-), 9/5 KIRTI NAGAR, INDUSTRIAL AREA, NEW DELHI - 110015 PH :99990388.
313. MAGIC AUTO PVT. LTD. (08D5-01-), PLOT NO. 449 & 450, PATPARGANJ INDUSTRIAL AREA, NEW DELHI. - 110092 PH :9818741741.
314. DD MOTORS (A DIVISION OF D.D. PREM PVT.LTD.) (08F1-03-), PLOT NO. 87/1, RANAJI ENCLAVE, NAGLI SAKRAWATI, BEHIND NAGLI METRO STATION, NAJAFGARH, NEW DELHI. - 110043 PH :8448481726, 8448095528.
315. DD MOTORS (A DIVISION OF D.D. PREM PVT.LTD.) (08F5-01-), 36/22, NEAR RAMDEV CHOWK, NARELA, DELHI - 110040 PH :9999127953, 9837578740.
316. DD MOTORS (A DIVISION OF D.D. PREM PVT.LTD.) (08F1-04-), 32/19, OPP SHANTI GARDEN, DWARKA SECTOR-3, MATHILA DELHI - 110059 PH :9873173005.
317. FAIR DEAL WHEELS PVT. LTD (08E3-01-), PLOT NO.25, KHATA KHATAUNI NO.97/98, KHASRA NO.48/17, OPP. BRAHMASHAKTI HOSPITAL, BUDH VIHAR, POOTH KALAN, MAIN KANJHWALA ROAD, DELHI - 110086 PH :8448690737.
318. COMPETENT AUTOMOBILES CO. LTD. (806-07-), 232, MATHILA PHIRNI, POCKET C, SECTOR 3, DWARKA, DELHI. - 110059 PH :9582797774.
319. JAGMOHAN AUTOMOTIVES (08F6-01-), PLOT NO. 69/2, WAZIPUR INDUSTRIAL AREA, NEW DELHI, PIN-110052 - 110052 PH :9650790351.
320. RANA MOTORS (08A1-08-), B-83, GT KARNAL ROAD, INDUSTRIAL AREA, OPP. GUJRANWALA TOWN, NEAR BIKANER WALA, DELHI - 110033 PH :92289496300.
321. AAA VEHICLEADES (0889-G1-), KHASRA NO. 204, MAIN CHHATARPUR ROAD, CHHATARPUR, NEAR SAI BABA MANDIR, DELHI, PIN-110030 - 110030 PH :9829342761.
322. SHREYASH AUTOMOTIVES PRIVATE LIMITED (08F8-01-), PLOT NO.9, SSI INDUSTRIAL ESTATE, GT KARNAL ROAD, NEW DELHI. - 110063 PH :4328888.
323. SHREYASH AUTOMOTIVES PRIVATE LIMITED (08F8-02-), A-3, WAZIPUR INDUSTRIAL AREA, DELHI. - 110052 PH :42020000, 9910114255.
324. VIPUL MOTORS (08F7-01-), B-26, JHILMIL INDUSTRIAL AREA, DELHI -110095 - 110095 PH :9811233385.
- OKHLA, DELHI**
325. AAA VEHICLEADES PVT LTD (0884-01-), B243, OKHLA PHASE-1, OKHLA, DELHI - 110020 PH :8448582912.
- WAZIPUR - DELHI**
326. DD MOTORS (08F1-05-), A-90, WAZIPUR INDUSTRIAL AREA, NEW DELHI-110052 - 110052 PH :9310367233.
- GOA**
- BICHOLIM**
327. SAI SERVICE PRIVATE LIMITED (BHN1-01-), CITY SURVEY NO. 46/1, MUSLIM WADDI, BICHOLIM, GOA - 403529 PH :2385500, 9881746566.
- CANACONA**
328. CHOWGULE INDUSTRIES PVT. LTD. (IT01-01-), PLOT NO.40, CANCONA INDUSTRIAL ESTATE, SHRESTAL, CANCONA, SOUTH GOA - 403702 PH :0832-2633010/8805024916.
- CUNCOLIM**
329. SAI SERVICE PRIVATE LIMITED (3402-06-), SURVEY NO.64/7, SHOP NO.3-A-II, CANCNAMODDI, CUNCOLIM, SOUTH GOA - 403703 PH :2763062, 2763063, 9850398057.
- DHARBANDORA**
330. CHOWGULE INDUSTRIES PVT. LTD. (3408-07-), AT- KHANDEPAR- USAON, TAL-DHARBANDORA, SOUTH GOA - 403401 PH :0832-6623477/788004357.
- MAPUSA**

331. SAI SERVICE PRIVATE LIMITED (3402-05-), D-2/9,MAPUSA INDUSTRIAL ESTATE,MAPUSA, GOA , PH :22670008 8660432266.
332. CHOWGULE INDUSTRIES PVT. LTD. (3408-03-), PLOT NO. 19/20,THIVIM INDUSTRIAL ESTATE,KARASWADA, MAPUSA,GOA - 403507 PH :0832-6631666/6631608/8888817955.
- MARGAO**
333. CHOWGULE INDUSTRIES PVT. LTD. (3408-01-), OPP.DAMODAR TEMPLE,FATDOR,MARGAO, GOA - 403602 PH :0832-6623444/420/7796630235.
334. SAI POINT CARS PVT LTD (3409-01-), H.NO.17,WARD NO.5,SURVEY NO.34/3,34/4,MARGAO PONDA HIGHWAY,SONFATOR AMBORA,CAMURILIN,SALCETE ,GOA - 403722 PH :0954545826/8380013499.
335. SAI SERVICE PRIVATE LIMITED (3402-02-), SURVEY NO. 2124/VILLAGE - VERNAL,TAL : SALCETE ,NEXT TO AGNEL POLYTECHNIC, MARGAO - 403718 PH :2883000, 2791195.9834398096.
336. CHOWGULE INDUSTRIES PVT. LTD. (3408-08-), PLOT NO. M-58 AND M-59, PHASE 3B, VERNAL INDUSTRIAL ESTATE, MARGAO, VERNAL, SALCETE SOUTH GOA , GOA - 403722 PH :0832-6621800/992250800.
- PANAJI**
337. CHOWGULE INDUSTRIES PVT. LTD. (3408-02-), D.B BANDOKAR MARG,CAMPAL,PANAJI,GOA - 403001 PH :9922950798/992295701.
338. SAI SERVICE PRIVATE LIMITED (3402-07-), SHED NO.18/29, PLOT NO.5A, SURVEY NO.117/6,TELEIGAON, ST. INEZ, PANJIM, GOA-403 002 - 403001 PH :22229222/2225222,9923865179.
- PERNEM**
339. CHOWGULE INDUSTRIES PVT. LTD. (CUA1-01-), SURVEY NO. 258/1-B & 258/1-C, OPPOSITE INDUTRIAL TRAINING INSTITUTE, TALUKA - PERNEM, DIST.-NORTH GOA . - 403512 PH :8380082893.
- POLEM**
340. CHOWGULE INDUSTRIES (SHO1-01-), DULGAJ-SHELM,VILLAGE POLEM-LOLIEM ,SOUTH GOA,403728 - 403728 PH :9049555395.
- PONDA**
341. SAI SERVICE PRIVATE LIMITED (3402-03-), OFF PANJIM HIGHWAY,PONDA,GOA , - 403401 PH :2324106, 2311499, 2324120, 9518349559.
342. SAI SERVICE PRIVATE LIMITED (3402-01-), SURVEY NO: 36/1,PENHA DE FRANCE,TAL : BARDEZ, ALTO PCRVORIM,GOA - 403501 PH :2419200, 2414324, 9881746567.
- SANVORDEM**
343. CHOWGULE INDUSTRIES PVT. LTD. (BTK1-01-), SURVEY NO. 4, SUBDIVISION-3, VILLAGE - CACORA, TALUKA - CURCHOREM, SANVORDEM, DIST. - SOUTH GOA, GOA . - 403706 PH :9850477607.
- SATTARI**
344. CHOWGULE INDUSTRIES PVT. LTD. (3408-10-), SURVEY NO. 60, SUB DIV NO. 05, VILLAGE ARVALEM, VILLAGE PANCHAYAT ARVALEM, TALUKA SATTARI, NORTH GOA, GOA - 403505 PH :9923464422.
- TALEIGAO**
345. CHOWGULE INDUSTRIES PVT. LTD. (3408-06-), SURVEY NO. 122, MAHBOOS, NEAR SHANKARWADI TEMPLE, SHANKARWADI, TALEIGAO, - 403001 PH :9922950798/992295701.
- VASCO**
346. SAI SERVICE PRIVATE LIMITED (3402-04-), NEXT TO SHIKALIM CHURCH,SHIKALIM,VASCO,GOA , - 403802 PH :254258/1/2526008/2526008/985039805.
347. CHOWGULE INDUSTRIES PVT. LTD. (3408-09-), OPP BHRAMMATLAM TEMPLE, PATRONG BAINA, VASCO,GOA , - 403802 PH :0832-2500407/427/9921943608/9850986904.
- GUJARAT**
- AHMEDABAD**
348. KIRAN MOTORS LTD (102-01-), SARKHEJ - GANDHINAGAR HIGHWAY,OPP. RAJPATH CLUB,AHMEDABAD - 380054 PH :9624055445.
349. KATARIA AUTOMOBILES PVT. LTD. (104-01-), D/8 BEHIND ESI HOSPITAL,OUTSIDE DARIAPUR DARWAJA,AHMEDABAD - 380016 PH :9824543500.
350. POPULAR WHEELERS (INDIA) PVT. LTD. (105-01-), PATEL TRUST BUILDING, AVtar HALL,NAROL, NAROLA HIGHWAY,ISANPURA ROAD,AHMEDABAD - 382443 PH :61903232.
351. KIRAN MOTORS LTD (102-02-), BEHIND L&T GODOWN,SARKHEJ SANAND HIGHWAY, AHMEDABAD - 382210 PH :26891863, 26891009, 26891294.
352. KATARIA AUTOMOBILES PVT. LTD. (104-05-), NEAR KOKHRA BRIDGE,MANINAGAR - 380008 PH :7567568182.
353. KATARIA AUTOMOBILES PVT. LTD. (110-01-), BEHIND ADANAL PUMP ,NEAR MAKARBA CROSSING, MAKARBA,SG HIGHWAY - 380051 PH :7069054900.
354. POPULAR WHEELERS (INDIA) PVT. LTD. (111-01-), BESIDE SOLA ROAD BRIDGE,S. G. HIGHWAY SOLA,AHMEDABAD - 380054 PH :60581111.
355. KIRAN MOTORS LTD (112-01-), SURVEY NO. 82/1/1, NEAR H.P. PETROL PUMP, MOTERA ROAD, CHANDKHEDA, AHMEDABAD - 380005 PH :8347491800/9824023122.
356. UDAY AUTOLINK PVT. LTD. (113-01-), NEAR GALAXY SPAVIC, OPP. DASTAN FARM, S. P. RING ROAD, KATHWADA, AHMEDABAD, GUJARAT : 382430 PH :7567229999.
357. NANDA AUTOMOBILES PVT. LTD. (114-01-), SURVEY NO. 229/3, OPP. GOKULESH PETROL PUMP, NAROL , ASLALI ROAD, NAROL, AHMEDABAD, GUJARAT. - 382405 PH :3866550787 / 8460098683.
358. STARLINE CARS (AHMEDABAD) PVT LTD (115-01-), PLOT NO.103/2, NARDA CHILODA, NEAR RAILWAY CROSSING, KRISHNANAGAR ROAD, NARODA, AHMEDABAD - 382330 PH :9824610729.
359. KIRAN MOTORS LTD (112-02-), FINAL PLOT NO.33/1, NEAR SHRUSHTI LAVISH, OPP. SHYAM VILLA-II, NARODA-NIKOL ROAD, NIKOL DISTT. AHMEDABAD - 382330 PH :706968374/9173840458/7383651643/9173044104
360. KIRAN MOTORS LTD (102-04-), SURVEY NO. 245/3, TP SCHEME NO. 43, NEAR KARGIL PETROL PUMP, SCIENCE CITY ROAD, AHMEDABAD - 380060 PH :9327617447, 9327214890.
361. POPULAR WHEELERS (INDIA) PVT. LTD. (109-01-), BEHIND B. C. SHAH COLLEGE, NEAR SWAMINARAYAN PARK, VAISHALI TOWNSHIP ROAD, VASNA, AHMEDABAD, GUJARAT. - 380007 PH :9099993830.
362. PEGASUS (A UNIT OF VISUAL AUTOLINK PVT. LTD.) (129-01-), PLOT NO. 116, BOPAL - AMBLI ROAD, BOPAL, AHMEDABAD, DISTRICT - AHMEDABAD, GUJARAT. - 380058 PH :721114026, 7211130053.
363. TANU MOTORS PVT. LTD. (118-01-), SURVEY NO. 115/5/2, 115/4 & 115/6, PLOT NO. 39, SARKHEJ-SANAND ROAD, SANAND, AHMEDABAD(GUJARAT) - 382110 PH :9512009110.
- ANAKLA**
364. PEGASUS (A UNIT OF VISUAL AUTOLINK PVT. LTD.) (117-01-), PLOT NO.116 & 118/2, SARDAR Patel RING ROAD, VASTRAL, AHMEDABAD - 382418 PH :7623089000.
365. STARLINE CARS PVT. LTD. (D101-09-), SR NO - TP - 57, PLOT NO. 67, NEAR GOT A FLYOVER BRIDGE, OPP. SHANKU FARM HOUSE ,S.G. HIGHWAY, GOT A, AHMEDABAD. - 382481 PH :9824601729.
366. KATARIA AUTOMOBILES PVT. LTD. (110-02-), PLOT NO. 112, 116 & 119, SURVEY NO. 283/3.7.10, B/H SILVER STAR, BESIDE HARI VILLA BUNGLOWS, GOT A ROAD, CHANDLODIYA, AHMEDABAD. - 382481 PH :9824000378.
367. DB MOTORS PRIVATE LIMITED (119-01-), SURVEY NO. 131A, NH-8, ASLALI, OPP--OCTROI NAKA, AHMEDABAD - 382427 PH :9726031111.
368. POPULAR WHEELS (111-02-), SAVAN SQUARE, SHOP NO. 1, 2, 3, 4, 5, SERVE NO. 39/1, F.P. NO. 92, T.P. NO. 66/A, CHENPUR, NEW RANIP, AHMEDABAD. - 382427 PH :9925203344.
369. DB MOTORS PRIVATE LIMITED (119-02-), PLOT NO. 718, ASHRAM ROAD, OPPOSITE GANDHI ASHRAM, OLD VADAJ, HRIDAYA KINJ, AHMEDABAD . - 380013 PH :9909048260.
- AMBaji**
370. TANU MOTORS (SKQ1-01-), OPP KUMBHARIYA JAIN DERASAR, GIDC ROAD, AMBAJI, DIST-BANASKANTHA, GUJARAT 385110 - 385110 PH :9727709227.
- AMOD**
371. RAVIRATNA MOTORS (F801-03-), ROYAL PARK, JAMBUSAR-BHARUCH ROAD, AMOD, DISTRICT: BHARUCH, GUJARAT. - 392110 PH :9687691106/9687699383.
- ARELlI**
372. ALPHA AUTOLINK LLP (SE02-01-), LATHI BY PASS ROAD, ARELLI, GUJARAT - 365601 PH :9978538859/9978538833.
- ANAND**
373. AMAR CARS PVT. LTD. (F702-01-), JANTRA CROSSING,SOJITRA ROAD,ANAND - 388121 PH :9909960772.
374. KATARIA AUTOMOBILES PVT. LTD. (F703-01-), SURVEY NO. 189/1+2/A+3/AK 190/P, OPP. OLD JAKAT NAKA, NEAR RAILWAY OVERBRIDGE, ANAND-CHIKHODRA ROAD, ANAND, GUJARAT. - 388 120 PH :7698954466.
- ANKLAV**

Dealer Network (AS ON 31.10.2023)

375. KATARIA AUTOMOBILES (SEO 01-01), AMBICA COMPLEX, GROUND FLOOR SHOP NO. B, C AND D, ASODAR CHOKDI, TAL. ASODAR, CITY ANKLV, DIST. ANAN, PIN-388510, GUJARAT - 388510
PH : 7227917151.

ANKLESHWAR

376. RAVIRATNA MOTORS PVT LTD (P901-01), PLOT NO. 624/2/BIA, GIDC, VALIA ROAD, ANKLESHWAR - 393002
PH : 9687691063.

BAGODRA

377. NANDA AUTOMOBILES PVT. LTD. (CVQ1-01), SHOP NO. 9, 10, 11, 12, KAMDHENU COMPLEX, BAGODRA HIGHWAY, NR. SBI BANK, BAGODRA. - 382240
PH : 9727822000, 9726269111.

BALASINOR

378. AMAR CARS PVT. LTD. (CJE1-01), SR. NO. 1451, OPP. OIC PETROL PUMP, AHMEDABAD HIGHWAY (NH-47), KANTHARJINA MULVADA, VILLAGE - VADALA, TALUKA - BALASINOR, DISTRICT - MAHISAGAR, GUJARAT. - 388255
PH : 7211109960.

BARDOLI

379. DHRU MOTORS (4002-02), G.I.D.C.SURAT BARDOLI ROAD,BARDOLI. - 394601
PH : 9825413113/98797014454.

380. KATARIA AUTOMOBILES PVT. LTD. (Q106-02), BLOCK NO.13, NANDIDA CROSS ROAD, BARASADI VILLAGE, SURAT-BARDOLI ROAD, BARDOLI, GUJARAT - 394310
PH : 7698022665/9924138860.

BAREJA

381. KATARIA AUTOMOBILES PVT. LTD. (BAN1-01), 5/6/7, ADITYA COMPLEX NATIONAL HIGHWAY-8, BAREJA, TALUKA - DASKROI, DISTRICT - AHMEDABAD, GUJARAT - 382425
PH : 7046079997.

BARWALA (AHMEDABAD)

382. UDAY AUTOLINK PVT. LTD. (I401-01), OPP. HILTON HOTEL, BHAVNAGAR HIGHWAY, TA. BARWALA, DIST. AHMEDABAD - 382450
PH : 7567449999/9867767711.

BAVLA

383. KATARIA AUTOMOBILES PVT. LTD. (104-07), NEAR ESSAR PETROL PUMP, BAVLA - AHMEDABAD HIGHWAY, BAVLA - 382220
PH : 9824344889.

BECHRAJI

384. STARLINE CARS PVT. LTD. (GJM1-01), R.S. NO. 336 PAIKI, MOJE-BECHAR (BECHARAJI), TALUKA - BECHARAJI, DIST.-MEHSANA. - 384210
PH : 9909043244.

BHABHAR

385. STARLINE CARS (CWD1-01), SHOP NO. 7, 8, 9, SIDDHI VINAYAK BUSINESS HUB, R.S. NO. 225, PANJRAPOLE ROAD, BHABAR, DIS. -BANSANKANTA, GUJARAT. - 385320
PH : 9909043244, 9824601729.

BHACHAU

386. K.D. MOTORS (P501-02), SUNRISE MALL,OPP. BUS STAND,BHACHAU BHUJ ROAD, BHACHAU, GUJARAT - 370140
PH : 990953036, 9879390919.

BHANVAD

387. ATUL MOTORS JAM LLP (BND2-01), R.S. NO.439, PLOT NO.19, BHANVAD (GUJARAT) - 360510
PH : 9574005964 / 9574004714.

BHARUCH

388. RAVIRATNA MOTORS (F801-01)- NH 8, OPP YOGI PETROL PUMP,P.O. ZADESHWAR,BHARUCH - 392011
PH : 9887691044; 9687362467.

BHAVNAGAR

389. KATARIA AUTOMOBILES (C902-01), SURVEY NO 13/2, PLOT NO 301/2&3 AND 301/4&5, VERTEJ GIDC, NARI CHOKDI, RAJKOT ROAD, BHAVNAGAR. - 364004
PH : 9426168286.
390. KATARIA AUTOMOBILES (C902-02), PLOT NO-29, NR. TALAJA OCTROI CIRCLE, JAKATNAKA, AT-ADHEWADA, DIST-BHAVNAGAR, GUJARAT - 364002. - 364002
PH : 9638884422.

BHUJ

391. K.D. MOTORS (P501-01), PLOT NO. 5/6/14 UMANAGAR,MIRZAPUR HIGHWAY ROAD , BHUJ, GUJARAT - 370001
PH : 02832-2325345, 9879898799, 8780351870.
392. K.D. MOTORS (P501-03), R.S NO. 25/2, 25/3, 26/2, PLOT NO. 57 TO 61, VILLAGE - MIRZAPUR, TALUKA - BHUJ, GUJARAT. - 370001
PH : 990953124.

BODELI

393. KIRAN MOTORS LTD (0R01-01), OPP.NARMADA GUEST HOUSE,DABHOI ROAD, BODELI, TALUKA: SANKHEDA,VADODARA - 391135
PH : 9714592999.

BORSAD

394. AMAR CARS PVT. LTD. (BJM1-01), BORSAD - TARAPUR HIGHWAY, BORSAD , DISTRICT - ANAND, GUJARAT - 388540
PH : 9586477744.

BOTAD

395. KATARIA AUTOMOBILES (AP03-19), PLOT NO.13, SURVEY NO 33,34, AND 35 PAIKKI VILLAGE, HADADAD, OPP. Patel HYUNDAI SHOWROOM, PALIYAD BOTAD ROAD - 364710
PH : 9558060658.

396. STARLINE CARS (CVF1-01), 16/17, PASABHI COMPLEX, NEAR ROYAL PALACE HOTEL, MEHSANA HIGHWAY, CHANASMA. - 384220
PH : 9909043244, 9824601729.

CHANASMA

397. DB MOTORS (SJT1-01), SHOP NO 1,2,3 SWAPNIL ARCADE, GRAM-CHANDIYAL, TAL-DASKROI, DIST-AHMEDABAD, GUJARAT. - 382433
PH : 9909048301.

CHANDIYAL

398. KATARIA AUTOMOBILES PVT. LTD. (104-10), SURVEY NO. 247, TN NO. 73, OPP. PAVITRA ENCLAVE, MANSAROVER ROAD, NEAR HARI OM FARM, TRAGAD, CHANDKHEDA, AHMEDABAD. - 382470
PH : 9723302111.

CHANDRALA

399. NANDA AUTOMOBILES PVT. LTD. (GLT1-01), HIMMATNAGAR HIGHWAY NO.8, NEAR DEVANSHI PARTY PLOT, CHANDRALA, DIST-GANDHINAGAR, GUJARAT - 382320
PH : 9725062187, 9727760003.

CHANGODAR

400. PEGASUS (A UNIT OF VISUAL MOTORS PVT. LTD.) (CTD2-01), SURVEY NO.393, VILLAGE - MORAIYA, CHANGODAR, TALUKA - SANAND, SUN DISTT - AHMEDABAD. - 382210
PH : 7211120014.

CHIKHLI

401. KATARIA AUTOMOBILES PVT. LTD. (BCB1-01), SURVEY NO.461, VILLAGE-MAJIGAM, TALUKA-CHIKHALI, DISTT-NAVSARI, GUJARAT - 396521
PH : 7698953899.

CHILODA

402. PEGASUS (A UNIT OF VISUAL AUTOLINK PVT. LTD.) (GJO1-01), PLOT NO. 332, BESIDES GALLOPS TATA, NH-8, CHILODA-HIMMATNAGAR HIGHWAY, CHILODA. - 382355
PH : 7211168938, 7623039000.

CHOTILA

403. DREAM VEHICLES PVT LTD (CFI1-01), SURVEY NO. 31, PLOT NO. 1, NILKANTH SOCIETY, NH NO. 8A, AHMEDABAD-RAJKOT, AT & PO - CHOTILA, DISTRICT - SURENDRANAGAR, GUJARAT. - 363520
PH : 9227775709.

CHUDA

404. DREAM AUTOMOBILES (SOC1-01), NR. GOVT HOSPITAL, CHATARLIYA ROAD,CHUDA,SURENDRANAGAR. - 363410
PH : 9313802500.

DABHOI

405. KATARIA AUTOMOBILES PVT. LTD. (UU01-01), OPP. VEGA BUS STOP, NEAR VEGA CROSS ROAD, DABHOI-BODELI ROAD, DABHOI, TA:DABHOI, DI:VADODARA - 391110
PH : 8156000463.

DAHOD

406. R.B CARS PVT. LTD. (2C01-02), NEAR SIMANDHAR JAIN TEMPLE, OLD INDORE HIGHWAY, DAHOD - 389151
PH : 9099043715, 9727700823.

DANTIWADA

407. TANU MOTORS (SX1-01), VISHWAS COMPLEX, OPP HINGLAJ PETROL PUMP, NR. JAIN DERASAR, DANTIWADA HIGHWAY, AT-PO PANTHWADA, TALUKA-DANTIWADA, DIST-BANASKANTHA - 385545
PH : 9099404244.

DEESA

408. TANU MOTORS PVT. LTD. (Q801-03), NH-14, NR. ESSAR PETROL PUMP, RADHANPUR HIGHWAY, HANUMAN NAGAR, MALGADH, DEESA - 385535
PH : 9909006099.

DEHGAM

409. NANDA AUTOMOBILES PVT. LTD. (2B01-03), NEAR UMIYA Mataji TEMPLE, COLLEGE ROAD, AHMEDABAD ROAD, DEHGAM - 382305
PH : 234567.

DETROJ

410. PEGASUS (A UNIT OF VISUAL AUTOLINK PVT LTD) (GLC1-01), PLOT NO-61 MILKAT NO-2534, AT-DETROJ,TALUKA-DETROJ-RAMPURA-382120
-382120
PH : 7971846442.

DEVGADH BARIA

411. R.B CARS PVT. LTD. (2C01-05), BESIDE ARIHANT PETROL PUMP, PIPLOD ROAD, DEVGADH BARIA - 389380
PH : 9099049344, 6352384846, 9099043715.

DHANERA

412. TANU MOTORS PVT. LTD. (BZW1-01), 01 & 02, MARUTI NANDAN COMPLEX, NEAR ESSAR PETROL PUMP, DHANERA-DEESA HIGHWAY, DHANERA. - 385310
PH : 9909006099, 8401784018.

DHARAMPUR

413. KATARIA AUTOMOBILES PVT. LTD. (BSK1-01-), SURVEY NO 29/3P1, VILLAGE ASHURA NR. ASHURA CIRACLE, DHARAMPUR DISTT. VALSHAD, GUJARAT - 396050 PH :9723455291.

DHARI

414. ALPHA AUTOLINK LLP (GG02-01-), PLOT NO. 9, DHARI - KHAMBHA ROAD, NEAR RAILWAY FATAK DHARI , TALUKA - DHARI, DIST. - AMRELI, GUJARAT . - 365640 PH :9904549999/9978938858.

DHOLKA

415. TANU MOTORS PVT. LTD. (CQ02-01-), SURVEY NO. 722, OPPOSITE RANI RUDY MATAJI MANDIR, Dholka Kalikund Highway, Dholka, Gujarat - 382 225 PH :9512009104.

DHORAJI

416. PERFECT AUTO SERVICE (5502-09-), JETPUR ROAD, OPP. SHRINATHJI SOCIETY, DHORAJI -- 360410 PH :9099027402, 8200096917.

DHRANGADHRA

417. DREAM VEHICLES PVT LTD (IM01-01-), PLOT NO. 79, SURENDRANAGAR- DHRANGADHRA ROAD, OPP. ARMY WORKSHOP, DISTRICT-SURENDRANAGAR . - 363310 PH :9227775725.

DIYODAR

418. TANU MOTORS (SFU1-01-), NR.HP PETROL PUMP, BHESANA CROSS ROAD, BHABHAR HIGHWAY,DIYODAR-385330 - 385330 PH :9099017765.

DWARKA

419. ATUL MOTORS JAM LLP (CJG2-01-), SURVEY NO. 41, NEAR, SHRI SANTAN SEVA MANDAL, CORNER PLOT OF STATION ROAD AND HIGHWAY ROAD, DWARKA, DISTRICT – DWARKA -- . - 361335 PH :9712212900 / 9574004714.

GANDHIDHAM

420. B M AUTOLINK (7702-01-), EAST OF PLOT NO. 30-35,NATIONAL HIGHWAY, GANDHIDHAM - 370201 PH :9727725723.

421. B M AUTOLINK (7702-03-), SURVEY NO.129/26 P, GALPADAR HIGHWAY, GANDHIDHAM , DISTT.KACHCHH, GUJARAT . - 370110 PH :9727725723, 9727739550.

GANDHINAGAR

422. NANDA AUTOMOBILES PVT. LTD. (2B01-01-), 1003 SECTOR-28,GANDHI NAGAR - 382028 PH :079/23212692 / 93 / 94.

423. NANDA AUTOMOBILES PVT. LTD. (2B01-05-), PLOT NO. 805, GIDC, SECTOR-28, GANDHINAGAR . - 382028 PH :079-23212692/93/94 9727726003.

GODHRA

424. R B CARS PVT. LTD. (2C01-01-), PLOT NO. 112/11,,12-VAVDI,GODARA - DAHD HIGHWAY, GODHRA, PANCHMAHAL, GUJARAT - 389001 PH :9099043715, 9727700823.

425. R B CARS PVT. LTD. (2C01-04-), SURVEY NO.107, LUNAWADA ROAD, GIDC, GODHRA, DISTT. PANCHMAHAL-389001 . - 389001 PH :9099043715, 9727700823.

GONDAL

426. ATUL MOTORS PVT LTD (5503-05-), 8-B NATIONAL HIGHWAY, OPP. DAULAT OIL MILL, NR. NILKANTH VIRUDASHRAM, RAJKOT HIGHWAY,GONDAL - 360311 PH :9904922333.

GOZARIA

427. VIMCO MOTORS PVT. LTD. (GJN1-01-), 1597/339 P4 VISHNAGAR-GOZARIYA ROAD, GOZARIYA, DIST.-MEHSANA . - 382625 PH :7016623842.

HALOL

428. R B CARS PVT. LTD. (BKC1-01-), PLOT NO. 104/6 & 104/8, VADODARA – GODHRA HIGHWAY, NEAR NAVIJAN HOTEL, HALOL, DISTRICT – PANCHMAHAL, GUJARAT . - 389350 PH :9099043715, 9727700823.

HALVAD

429. DREAM VEHICLES PVT LTD (GX01-01-), PLOT NO.5 & 6, NAKLANKDHAM TOWNSHIP, OPP. HONEST RESTAURANT, AHMEDABAD HIGHWAY, HALVAD DISTT. SURENDRANAGAR (GUJARAT) . - 363330 PH :8238009665.

HANSOT

430. RAVIRATNA MOTORS (BGQ1-01-), AT UTRAJ, HANSOT, DISTRICT - BHARUCH. - 393030 PH :9887691063.

HIMMATNAGAR

431. KIRAN MOTORS LTD (P601-01-), NEAR G.I.D.C,MOTIPURA, HIMMATNAGAR . - 383001 PH :9824576711.

IDER

432. KIRAN MOTORS LTD (UX01-01-), SURVEY NO.69 IDAR-AMBAJI ROAD, IDAR DIST: SABARKANTHA - 383430 PH :8155994111.

JAMBUSAR

433. RAVIRATNA (SKR1-01-), SURVEY NO-2939-2954, PLOT NO-2, VILLAGE-JAMBUSAR, TALUKA-JAMBUSAR, DIST-BHARUCH. - 392150 PH :9687667595.

JAMJODHPUR

434. ATUL MOTORS (JAM LLP) (CSN3-01-), NEAR HDFC BANK, GAYATRI MANDIR ROAD, JAMJODHPUR, DIST-JAMNAGAR (GUJARAT) - 360530 . - 360530 PH :9537888988.

JAMNAGAR

435. ATUL MOTORS JAM LLP (F402-01-), SURVEY NO.422, PLOT NO. 16,17 & 19, JAMNAGAR, GUJARAT - 361001 PH :9574004710 / 9574004716.

436. STARLINE CARS PVT. LTD. (D101-02-), CHANASAMA HIGHWAY, PATAN - 384265 PH :7046046187.

437. ATUL MOTORS JAM LLP (F402-02-), C-36, MP SHAH ARUN UDYOG, SARUSECTION ROAD, JAMNAGAR . - 361002 PH :9574004704 / 9574004704.

438. ATUL MOTORS (JAM LLP) (F402-03-), OPP MADHAV BAUG1, NEAR RAILWAY OVER BRIDGE, JAMNAGAR, GUJARAT-361006. - 361006 PH :9574004709.

JASDAN

439. ATUL MOTORS PVT LTD (5503-09-), SURVEY NO. 1253, PLOT NO. 4, NEAR KALYAN PETROL PUMP, JASDAN-ATKOT HIGHWAY, JASDAN, DIST.-RAJKOT, GUJARAT. - 360050 PH :9265404142.

JHALOD

440. R B CARS PVT. LTD. (CJF1-01-), SURVEY NO. 2550B/10, 11, AT . - JHALOD, TALUKA- JHALOD, DISTRICT - DAHD . - 389170 PH :9099684363, 9099043715.

JUNAGADH

441. PERFECT AUTO SERVICES (5502-06-), SURVEY NO.45/1, PLOT NO. 214-C/D/E/F, GIDC-I, DOLATPARA, JUNAGADH . - 362001 PH :9879518052, 7043999073, 9909022618.

JUNAGARH

442. PERFECT AUTO SERVICES (5502-02-), PLOT NO. 81-82.G.I.D.C DOLATPARA,RAJKOT-JUNAGARH HIGHWAY, JUNAGARH . - 362001 PH :9099006980, 7043999073, 9909022618.

KADI

443. STARLINE CARS PVT. LTD. (D101-07-), OPP. COTTON MARKETING YARD, KADI-CHATRAL ROAD, TAL: KADI, DIST: MEHSANA - 382715 PH :8160707156.

KAKANPUR

444. RB CARS (SDN1-01-), SURVEY NO.618/2, PAKI PLOT NO. 29,30,31 AT, KAKANPUR, TAL. GODHRA, DISTRICT. PANCHMAHAL PIN-388713. - 388713 PH :9099049347.

KALAVAD

445. ATUL MOTORS JAM LLP (BNC2-01-), SANIDHYA ARCADE, NEAR SANIDHYA PARTY PLOT, KALAVAD – DHORAJI ROAD, KALAVAD. - 361160 PH :9574222111.

KALOL

446. NANDA AUTOMOBILES PVT. LTD. (2B01-02-), PLOT NO. - 162-168, GIDC,KALOL MEHSANA HIGHWAY, NEAR CHIRAG CINEMA ROAD, KALOL . - 383028 PH :220781 / 82 / 83.

KAPADVANJ

447. AMAR CARS PVT. LTD. (NC01-01-), SAMARTH SQUARE, SHOP NO. 1, MODASA KAPADVANJ ROAD, KAPADVANJ, GUJARAT-387620 - 387620 PH :9909960761.

KARJAN

448. AMAR CARS PVT. LTD. (UZ01-01-), SURVEY NO.851/77 BESIDE PMT TOOLS, KANDARI, N.H. -8, KARJAN, DISTT-VADODARA (GUJARAT) - 391210 PH :7567299666/99252462929.

KATHLAL

449. AMAR CARS PVT. LTD. (CXA1-01-), MAHAVEER AUTO SHOWROOM, NADIAD ROAD, JB PLAZA, KATHLAL, GUJARAT. - 387 630 PH :9909960761.

KESHOD

450. PERFECT AUTO SERVICES (BZY1-01-), R.S NO. 125/1, GODOWN NO. 01, SONDARA, TALUKA- KESHOD, DISTRICT – JUNAGADH; GUJARAT. - 362220 PH :7043999073.

KHAMBHAT

451. AMAR CARS PVT. LTD., (BNF1-01-), PLOT NO. 7/89, RAJMAHAL PARK, OPP. SARDAR CHATRALAY, LAL DARWAJA, GAYATRINAGAR ROAD, KHAMBAT, TALUKA KHAMBAT, ANAND DISTRICT, GUJARAT - 388620 PH :9909960772.

KHEDA

452. AMAR CARS PVT. LTD., (BNA1-01-), S.NO.708, PLOT NO.1, VILLAGE-SOKHDA, TAL: MATER, DISTT. KHEDA, GUJARAT - 387570 PH :9909960761.

KHEDBRAHMA

Dealer Network (AS ON 31.10.2023)

453. KIRAN MOTORS (CMU1-01), AMBAJI ROAD, KHEDBRAHMA, DIST. – SABARKANTHA, PIN – 383255 - 383255
PH :9824010721.
- KHERALU**
454. STARLINE CARS (SN02-01), R S NO. 4962 MAHAVIR COMPLEX, KHERALU, DIST. -MEHSANA - 384325 PH :9909043244, 9824601729.
- KIM**
455. KATARIA AUTOMOBILES PVT. LTD. (UW01-01), PLOT NO. 116-121, DAL MILL COMPOUND, OPP. SURAT JILLA SANGH, KIM CROSS ROAD, NH-8, KIM - 394110 PH :9723555185.
- KODINAR**
456. PERFECT AUTO SERVICES (A DIVISION OF PERFECT TIRETREADS PVT LTD) (CS01-01), R.S.NO.222, PLOT NO.2, 3 SHOPS, KODINAR-362720 DISTT. JUNAGADH, GUJARAT - 362720 PH :7043992893, 7043340792.
- KUKARWADA**
457. STARLINE CARS PVT. LTD (CSC1-01), SHOP NO.1741, 1742 AND PLOT NO.1752, KUKARWADA TALUKA, VIJAPUR, DISTT MAHESANA (GUJARAT) - 382830 PH :9909043244, 9824601729.
- LAVANA**
458. RB MOTORS (SLW1-01), AT PO -LAVANA, NEAR BABILYA CROSSING, MODASA ROAD, LAVANA-389230 - 389230 PH :9860999470.
- LIMBDI**
459. DREAM VEHICLES PVT LTD (BSG1-01), SURVEY NO.276/1, NEAR PANCHVATI HOTEL, LIMDI CROSS ROAD, AHMEDABAD-RAJKOT HIGHWAY, LIMDI, DISTT. SURENDRANAGAR, GUJARAT . - 363421 PH :02753-261262/ 9227775728.
- LUNAWADA**
460. R B CARS PVT. LTD. (BYN1-01), SURVEY NO.90, AT-BHAYASAR, GODHRA-LUNAWADA HIGHWAY, LUNAWADA , TALUK-LUNAWADA, DISTT-MAHISAGAR, GUJARAT. - 389230 PH :9099043715, 9727700823.
- MAHUVAA (BHAVNAGAR)**
461. KATARIA AUTOMOBILES (IV03-01), V.P., COMPLEX, BUNDER RD, NR. GAUSHALA, BARPARA, MAHUVAA, GUJARAT 364290. - 364290 PH :6357327534.
- MAHUVAA (SURAT)**
462. KATARIA (BRM1-01), BLOCK NO. 14/2, VILLAGE BUDHALESHWAR, SURAT SAPUTARA STATE HIGHWAY,TAL. MAHUVAA, DIST. SURAT - 394250 - 394250 PH :9824051060/9824094498.
- MANAVADAR**
463. PERFECT AUTO SERVICE (CUI1-01), RS NO. 13/1, 14, PLOT NO. 48, BHAKTINAGAR, TALUKA - MANAVADAR, DIST-JUNAGADH. - 362 630 PH :7043999073.
- MANDAL**
464. KIRAN MOTORS LTD (IW01-01), SURVEY NO. 708, MANDAL - DETROJ HIGHWAY, NR. RELIANCE PETROL PUMP, MANDAL , DI: AHMEDABAD, GUJARAT. - 382130 PH :9408083925.
- MANDVI**
465. K.D. MOTORS (UY01-01), PLOT NO.25,26 & 27, RAJ COMMERCIAL, SURVEY NO.246, NEAR "THE BEACH RESORT", MANDVI NALIYA ROAD, MANDVI-KUTCH - 370465 PH :9909953088, 9825353679.
- MANGROL**
466. KATARIA AUTOMOBILES PVT. LTD. (CAH1-01), PLOT NO. 12-28, MOSALI, MANGROL, DISTRICT-SURAT. - 394410 PH :6357071775.
- MANSA**
467. NANDA AUTOMOBILES PVT. LTD. (2B01-04), OPP. GIDC, VISNAGAR ROAD, MANSA, DISTRICT-GANDHINagar, GUJARAT - 382845 PH :9727921000.
- MEHMADBAD**
468. AMAR CARS PVT. LTD. (BRA1-01), PATEL FALIYA, KHATRAJ, MEHMEDABAD, DIST. -KHEDA, GUJARAT. - 387130 PH :9909960761.
- MEHSANA**
469. STARLINE CARS PVT. LTD. (D101-01), NAGALPUR HIGHWAY,MAHESANA , GUJARAT - 384002 PH :9909043635.
470. TANU MOTORS PVT. LTD. (Q801-04), SURVEY NO.78, NEAR SUNRISE AUTOMOBILES (AMW DEALER), GUJARAT STATE HIGHWAY NO.41, MEHSANA - 384002 PH :9909006076.
471. VIMCO MOTORS PVT. LTD. (D103-01), SURVEY NO. 104 & 104 PAIKI 1, AT P.O. - PALAVASANA, MEHSANNA, GUJARAT. - 384 002 PH :8909953333.
472. VIMCO MOTORS (D103-02), SHOP # 7&8, TIRUPATI SAHIBAGH MARKET, MEHSANA - RADHANPUR ROAD, NEAR SAJAH VILLA, MEHSANA - 380002. - 380002 PH :8909953333.
- METODA**
473. ATUL MOTORS PVT LTD (5503-08), PLOT NO. 2328, GATE NO. 2, METODA GIDC, METODA, TALUKA LODHIKA, DISTRICT - RAJKOT, GUJARAT - 360021 PH :8140909095, 9924688774.
- MODASA**
474. KIRAN MOTORS LTD (P601-02), SHAMLAL JI ROAD,SABARKANTHA DIST., MODASA - 383315 PH :8155995111.
- MORBI**
475. PERFECT AUTO SERVICES (5502-07), SURVEY NO. 351/2, PLOT NO. 10, DHARTI INDUSTRIAL AREA, RAJPURA ROAD, SANALA, MORBI , TEHSIL-MORBI, DISTT.-MORBI, GUJARAT. - 363641 PH :9099058044, 9925199569, 9879499088.
476. DREAM VEHICLES (LC01-03), NR. PRIME FILLINGS, PLOT-6,DHARMASIDDHI VILLAGE:MAHENDRANAGAR, TALUKA: MORBI, DIST-MORBI. - 363642 PH :7069089532.
- MOTI KHAVADI**
477. ATUL MOTORS JAM LLP (AAU2-01), PLOT NO.22 & 29, NEAR PADANA POLICE STATION, JAMNAGAR-KHAMBALIYA HIGHWAY, MOTI KHAVDI, ZANKHAR, TA: LAPUR, DIST - JAMNAGAR, GUJARAT. - 361140 PH :9574004709 / 9574004743.
- MUNDRA**
478. B M AUTOLINK (7702-02), PRAGPAR ROAD,MUNDRA,DISTRICT-KUTCH, GUJARAT. - 370421 PH :9687632631, 9978940978.
- NADIAD**
479. AMAR CARS PVT. LTD. (F702-02), NEAR RAJHANS MULTIPLEX,NADIAD-UTTARSANDA ROAD - 387370 PH :9909960761.
- NAKHATARANA**
480. KD MOTORS (CMV1-01), PLOT NO-1, RS NO-19, AT-NANA ANGIYA, TALUK-NAKHATARANA, KUTCH . - 370615 PH :9909953119.
- NALIYA**
481. KD MOTORS (SLX1-01), AT PO - SHAKTI SOCIETY, MAHARAJ NAGAR, PLOT(1), OPP. BANK OF BARODA, NALIYA, TAL-ABDASA, KUTCH. - 370655 PH :9909953119.
- NANA PONDHA**
482. AMAR CAR (SEL1-01), SHOP NO 7-11, JALASHAI SHOPPING CENTER, AT-NANA PONDHA, TALUKA-KAPRADA, DIST-VALSAD - 396126 PH :7227971155.
- NASWADI**
483. RAVIRATNA MOTORS (SCV1-01), HOUSE NO-301,302,303, IN VALPURA-RAMILNLAGAR, VILLAGE AT-NASWADI, DIST: CHOTTA UDEPUR - 391150 PH :9687691047.
- NAVSARI**
484. KATARIA AUTOMOBILES PVT. LTD. (Q701-01), PLOT NO.-891, OPP PAUVA MILL, NH-8,NEAR GANESH SISODRA CHOKDI),GANESH SISODIA NAVSARI, GUJARAT - 396463 PH :9723430012.
- NETRANG**
485. RAVIRATNA MOTORS (CUZ1-01), SURVEY NO. 184, PLOT NO. 1 & 2, VILLAGE - NETRANG, TALUKA - VALIA, DIST -BHARUCH. - 393130 PH :9687691063.
- OLPAD**
486. COMET CAR SALES & SERVICE PVT LTD (4006-02), 1906/1907, OPP. KUMBHARVAD, JUNA PURA, OLPAD - 394540 PH :9099916099.
- PADRA**
487. AMAR CARS PVT. LTD. (2205-02), NEAR WESTERN BYPASS, AT SAMIYALA, PADRA, DIST. – VADODARA, GUJARAT - 391440 PH :8980036200, 898006795.
- PALANPUR**
488. TANU MOTORS (Q801-01), OPP.DHARTI RESORT,ABU - AHMEDABAD HIGHWAY, PALANPUR - 385001 PH :9099917756.
489. STARLINE CARS PVT. LTD. (D101-08), SURVEY NO.4 & 5/2, OPPOSITE L K PETROL PUMP, PALANPUR-385001, DISTT BANASKANTHA, GUJARAT - 385001 PH :9824601793.
- PALITANA**
490. RAVIRATNA MOTORS (BGR1-01), PLOT NO. 62/6, GIDC AREA, PALEJ, DISTRICT - BHARUCH - 392220 PH :9687691044; 9687632647.
491. KATARIA AUTOMOBILES (CSD2-01), PLOT NO 15, YASOVIJAYNAGAR, NEAR RAILWAY CROSSING, PALITANA HIGHWAY, PALITANA-364270 DIST BHAVNAGAR. - 364270 PH :6357314891.

- PALSANA**
492. KATARIA AUTOMOBILES PVT. LTD. (4004-07), BESIDE SAINATH COMPLEX, KADODARA AHMEDABAD ROAD , NH-8, UMBHEL GAM,TALUKA: PALSANA KADODARA, SURAT - 382721 PH :9924446895.
- PARDI**
493. AMAR CARS (SLJ1-01), OPPOSITE MORARJI DESAI MEMORIAL HALL, SERVICE ROAD N.H-48, KILLA-PARDI, DIST-VALSAD - 396125 PH :7226800777.
- PATIDI**
494. DREAM VEHICLES PVT LTD (BFS1-01), R.S. NO.1614/2, PLOT NO.16, PATIDI TALUKA DASADA, DISTT. SURENDRANAGAR, GUJARAT - 382765 PH :9227775709.
- PAVI JETPUR**
495. PERFECT AUTO SERVICES (PK01-01), NEAR ANKUR HOTEL, OPP. DAHRESHWAR GEB STATION, PITHADI, RAJKOT HIGHWAY, JETPUR (GUJARAT) - .360370 PH :9099027402, 8200969617.
- PETLAD**
496. AMAR CARS PVT. LTD. (CMW1-01), SURVEY NO. 396/2, RANGAIPU VILLAGE, PETLAD, DIST. -ANAND . -384450 PH :9099017068.
- PORBANDAR**
497. ATUL MOTORS JAM LLP (T601-01), PLOT NO. 208, GIDC VANADA, NATIONAL HIGHWAY , PORBANDAR, DIST. PORBANDAR GUJARAT - 360577 PH :9574004746 / 7228819123.
- PRANTU**
498. KIRAN MOTORS LTD (AAI1-01), NO 6/P, OPP. VEGETABLE MARKET, PRANTU HIGHWAY, VILLAGE-KHAMALPUR, TALUKA-PRANTU, DISTT. SABARKANTHA, GUJARAT - 383205 PH :9624401888.
- RADHANPUR**
499. STARLINE CARS PVT. LTD. (BN1-01), SURVEY NO. 208/A, MOUJA – RADHANPUR, RADHANPUR MAIN ROAD, DISTRICT – PATAN, GUJARAT. - 385340 PH :9909043244, 9824601729.
- RAJKOT**
500. PERFECT AUTO SERVICES (5502-01), PERFECT HOUSE,GONDAL ROAD,VANDI,RAJKOT - 360004 PH :9879499077, 990906982, 9825304940.
501. ATUL MOTORS PVT LTD (5503-01), PLOT NO.49/1 & 2, GIDC, BHAKTI NAGAR INDUSTRIAL ESTATE, RAJKOT - 360002 PH :8140909903.
502. PERFECT AUTO SERVICES (5502-04), 150 RING ROAD,OPP. GANDHIGRAM POLICE CHOWKI,RAJKOT - 360005 PH :9925238691, 9925117104.
503. ATUL MOTORS PVT LTD (5503-02), BEHIND HP PUMP,UNIVERSITY ROAD ,NEAR SNK SCHOOL, RAJKOT - 360005 PH :83477005382.
504. ATUL MOTORS PVT LTD (5503-06), RAJKOT AHMEDABAD HIGHWAY, NR. CHANDARANA PETROL PUMP, OPP. GUJARAT SAMACHAR PRESS, AT. NAVAGAM RAJKOT - 360003 PH :9924688774.
505. PERFECT AUTO SERVICES (5502-08), R.S. NO. 50/1, 150 FEET RING ROAD, RAIL NAGAR, RONKI, RAJKOT, GUJARAT. - 360006 PH :9979861995, 9925117104.
506. KATARIA AUTOMOBILES PVT. LTD. (5504-01), S. NO. 10/1, TPS NO. - 10, KALAVAD ROAD, MOTAMAVA, RAJKOT, GUJARAT. - 360001 PH :7573870001.
- RAJAPARDI**
507. RAVIRATNA MOTORS PVT. LTD. (CAI1-01), R.S.NO.973, CTS NO. 1298, SHOPS PLOT NO.29 & 30 , MOJE RAJAPARDI, TALUKA-JHAGADIA, DISTT. BHARUCH - 393115 PH :9687691044; 9687632647.
- RAJPIPLA**
508. RAVIRATNA MOTORS PVT. LTD. (9X01-01), OPP. JALARAM SAW MILL, NEAR HARSIDDHI MATAJI TEMPLE, RAJPIPLA, DIST: NARMADA, GUJARAT - 393145 PH :9687691062/9687645880.
- RAJULA**
509. ALPHA AUTOLINK (BAK2-01), R.S NO 96/3, PLOT NO-6 & 7, HINDORNA ROAD, RAJULA CITY, TALUKA-RAJULA. - 365560 PH :9033409043.
- RAPAR**
510. B.M. AUTOLINK (SCO1-01), PARAGPAR CHAAR RASTA RAPAR GHANDHIDHAM KUTCH - 370165 PH :9727725723.
- SAMI**
511. STARLINE CARS (BNH1-01), SHOP NO. 55-56, AMBESHWAR PLAZA, SAMI-HARIJU ROAD. - 384240 PH :9909043244, 9824601729.
512. VIMCO MOTORS (BNH2-01), SURVEY NO 917, VIRA SHOPPING CENTER, AT-SAMI, TALUKA-HARIJU, DIST-PATAN, GUJARAT. - 384245 PH :8909953333.
- SANTEJ**
513. NANDA AUTOMOBILES PVT. LTD. (CXC1-01-), SUB PLOT NO. 05, SHOP NO. 3 & 4, BLOCK NO. 1162, SANTEJ, KALOL. - 380060 PH :9727822000.
- SANTRAMPUR**
514. R 8 CARS PVT. LTD. (2C01-03), NEAR PTC COLLEGE, SANT ROAD, SANTRAMPUR,DISTT.-PANCHMAHAL - 389260 PH :8980588581, 9099043715.
- SAVLI**
515. KIRAN MOTORS LTD (CFD1-01), SURVEY NO. 2592/1 PAKK12, NEAR RELIANCE PETROL PUMP, BHADRA CHOWKDI, SAVLI – TIMBA ROAD, SAVIL, TALUK - SAVLI, DISTRICT – VADODARA, GUJARAT. - 391770 PH :7984779054.
- SAYAN**
516. KIRAN MOTORS LTD (OO01-01), PLOT NO.6 TO 10 OF R BLOCK, SURVEY NO.209, VILLAGE PARIA, TALUKA: OLPAD, SAYAN - 394130 PH :815588862/966230480.
- SAYLA**
517. DREAM VEHICLES (SJM1-01), LALGURU COMPLEX, SUDAMDA ROAD, SAYLA, DISTRICT SURENDRANAGAR, GUJARAT PIN 363430 - 363430 PH :9227775709.
- SHANKESHWAR**
518. STARLINE CARS (SLY1-01), MANIBHADRA SHOPPING CENTRE, SHANKESHWAR HIGHWAY, SHANKESHWAR (GUJARAT)- DIST: PATAN - 384246 PH :9824601729.
- SHAPAR**
519. ATUL MOTORS PVT LTD (B0Z1-01), SHOP NO. 1 TO 4, SURVEY NO. 305/1, PLOT NO. 169, SHAPAR, DISTRICT – RAJKOT, GUJARAT - 360024 PH :9714008492, 9624711397.
- SIDDHPUR**
520. STARLINE CARS PVT. LTD. (CMY1-01), PLOT NO. 140-1285/7, SIDHPUR, TALUKA – VADGAM, DISTRICT – PATAN. - 384151 PH :9909043244, 9824601729.
- SINOR**
521. RAVIRATNA MOTORS PVT LTD (GML1-01-), NEAR SEVGA CHOKDI, SEVGA DABHOI ROAD, AT AND POST SEVGA, TALUKA SINOR, DIST. VADODARA, PIN-391105, GUJARAT - 391105 PH :7227055065.
- SITAPUR**
522. STARLINE CARS PVT LTD (SFV1-01), SHOP NO. 2, RUDRA ARCADE, REVENUE SURVEY NO. 129, VITHALPUR (SITAPUR) BECHARAJI – VITRAMGAM HIGHWAY, DIST. AHMEDABAD, PIN CODE: 382120 - 382120 PH :9909043244.
- SONGADH**
523. COMET CAR SALES & SERVICE PVT LTD (CWE1-01-), LAXMI PLAZA, SHOP NO. 21 & 22, SURAT DHULIYA HIGHWAY, TALUKA - SONGADH, DIST.-TAPI. - 384220 PH :9099916099.
- SUPEDI**
524. KATARIA AUTOMOBILES (SEM1-01-), SURVEY NO-4827, PAIKI PLOT NO-18, MATRAVAD ROAD, GRAM-SUPEDI, DIST - RAJKOT - 360440 PH :9409497902.
- SURAT**
525. KIRAN MOTORS LTD (4001-01-), SURAT-BARDOLI ROAD,DUMBHAL,NEAR PUNA JAKAT NAKA,SURAT . - 395010 PH :992444715/9924637898.
526. DHRU MOTORS (4002-01-), JEEVAN GANGA NAGAR,NEAR JEEVAN JYOT THEATRE,UHDNA MAIN ROAD,SURAT - 394210 PH :992515591/9925155907.
527. KIRAN MOTORS LTD (4001-02-), PANDESSA,BAMROLI ROAD,SURAT - 395002 PH :9824603880.
528. KATARIA AUTOMOBILES PVT. LTD. (4004-04-), TP NO. 6, SURVEY NO. 317/2, FINAL PLOT NO. 39, OPP SMS GARDEN, NEAR VIP ROAD, VESU, SURAT - 395007 - 395007 PH :9714612700, 9924401000.
529. DHRU MOTORS (4002-1B-), 207, NEW INDUSTRIAL ESTATE,ROAD NO.-6,UDHNA UDYOG NAGAR, SURAT - 394210 PH :0261-2272118/ 9978900862.
530. KATARIA AUTOMOBILES PVT. LTD. (4004-05-), KATARIA ARCADE,OPP. RAJHANS CINEMA,DUMAS ROAD, PIPLOD, SURAT - 395007 PH :7698022449/9624477252.
531. COMET CAR SALES & SERVICE PVT LTD (4006-01-), CHIKUWADI COMPLEX, GHB ROAD, PANDESSA, SURAT. - 394221 PH :9099915995.
532. KATARIA AUTOMOBILES PVT. LTD. (4004-08-), BLOCK NO.233, TP NO.8, OPP. SHREE LEKHA RESIDENCY, PALANPORE, ADAJAN, SURAT - 394310 PH :9924119020.
533. KIRAN MOTORS LTD (4005-01-), PLOT NO. 443, FP NO. 26 MOJE PALGAM, ADAJAN, SURAT - 395009 PH :9824611153/9824701590.

Dealer Network (AS ON 31.10.2023)

534. AMAR CARS PVT. LTD. (4009-02), PLOT NO.10&11, SURVEY NO.7 & 9, SONARAS COMPOUND, NEAR DGCVL OFFICE, KARMNATH MAHADEV TEMPLE LANE, KAPODARA, VARACHHA ROAD, SURAT - 395006 PH :7069026512.
535. COMET CAR SALES & SERVICE PVT LTD (4006-03), R. S. NO. 311, T. P. SCHEME-3, FINAL PLOT NO. 102/A, KATARGAM, SURAT, DISTRICT - SURAT, GUJARAT - 395004 PH :9099916099.
536. DHRI MOTORS (4002-03), PLOT NO.54/A, LAXMINARAYAN INDUSTRIAL ESTATE, UDHNA, SURAT-394210 - 394210 PH :9978900862.
- SURENDERNAGAR**
537. DREAM VEHICLES PVT LTD (LC01-01), 261/P, OPP MARKETING YARD,GIDC AREA,WADHWAAN CITY, SURENDERNAGAR - 363030 PH :02752-241314 / 02752-651516/ 9227775721.
538. DREAM VEHICLES (LC01-02), PLOT NO-504/B, GIDC PHASE-3, WADHWAAN, SURENDRANAGAR, GUJARAT-363030 - 363030 PH :9227775724.
- TALAJA**
539. KATARIA (BC12-01), SURVEY NO-168, DHANJIBHAI BALADIYA NI VADI, NEAR MAHUVA PALITANA CROSS ROAD, MAHUVA BHAVNAGAR HIGHWAY, TALAJA-364140. - 364140 PH :9316626475.
- TALALA**
540. PERFECT (JV01-01), SURVEY NO-55/9/1, PLOT NO-10, TALALA-VERAWAL HIGHWAY, AT-TALALA, DIST-GIR SOMNATH, 362150 - 362150 PH :8511147524.
- TANKARA**
541. ATUL MOTORS PVT LTD (BQY1-01), PLOT NO. 8/1, S. NO. 107, VILLAGE - JABALPUR, TALUKA - TANKARA, SUB DISTRICT - MORBI, DISTRICT - RAJKOT. - 363650 PH :9714008492, 9624711397.
- TARAPUR**
542. AMAR CARS PVT. LTD. (GH01-01), NEAR N K STEEL, TARAPUR ROAD, TARAPUR, DIST. -ANAND. - 388180 PH :9909960772.
- THARA**
543. TANU MOTORS PVT. LTD. (0V01-01), SHOP NO.17 & 18, SIHORI HIGHWAY, R.B. THAKKAR COMPLEX, THARA, KAKREJ TALUKA, BANASKANTHA DISTT. - 385555 PH :9909006099, 9913830329.
544. TANU MOTORS PVT. LTD. (CDM1-01), PLOT NO. 21 & 22, VAJEGADH, DEESA HIGHWAY, THARAD, DIST.-BANASKANTHA - 384220 PH :9909006099, 972419565.
- THASARA**
545. KATARIA AUTOMOBILES (SIM1-01), PLOT NO 1 & 2, GIDC THASRA, BESIDES NARMADA VASAHAT, DAKORE THASRA ROAD, GUJARAT-388250 - 388250 PH :7984092780.
- TILAKVADA**
546. RAVIRATNA (-), SURVEY NO-157, VILLAGE- MOTI KAMSONI, TALUKA-TILAKVADA, DIST-NARMADA, PIN-391120. - 391120 PH :9687691044.
- UMERGAON**
547. KATARIA AUTOMOBILES PVT. LTD. (BNB1-01), PLOT NO. 239, LORD COMPLEX, SHOP NO. B-9 AND B-10, UMERGAON, DISTRICT - VALSAD, GUJARAT. - 396170 PH :9624001794.
- UMRETH**
548. AMAR CARS PVT. LTD. (CFE1-01), R. S. NO. 30/2, NADIAD-DAKOR ROAD, UMRETH , DIST.ANAND, GUJARAT. - 388220 PH :9909960772.
- UNA**
549. PERFECT AUTO SERVICES (BFD1-01), SURVEY NO. 113, PLOT NO. 6, OPP. SWAMI VIVEKANAND VIDYALAYA, NEAR BANSIDHAR PETROL PUMP, BHAVNAGAR HIGHWAY, VAYAJUPUR, UNA, DISTRICT - GIR SOMNATH, GUJARAT. - 362560 PH :7043992893, 7043340792.
- UNJHA**
550. TANU MOTORS (Q801-02), OPP. DHANA DAL FACTORY,MEHSANA PALANPUR HIGHWAY, UNJHA - 384170 PH :9727762079.
- UPLETA**
551. PERFECT AUTO SERVICE (CH01-01), S. NO. 184/1, PLOT NO. 15-16, UPLETA, GUJARAT - 360 490 PH :909027402, 8200969617.
- VADGAM**
552. VIMCO MOTORS (CMX1-01), SURVEY NO-177, BESIDE ESSAR PETROL PUMP, VADGAM - PALANPUR ROAD, VADGAM, DIST - BANASKANTHA, GUJARAT - 385410. - 385410 PH :890953333.
- VADNAGAR**
553. VIMCO MOTORS PVT LTD (GKU1-01), SHILALEKH COMPLEX, BLOCK-D, SURVEY NO-2713, VADNAGAR-VISNAGAR HIGHWAY, NEAR FOOD PARADISE HOTEL, VADNAGAR, GUJARAT - 385355 PH :7016623842.
- VADODARA**
554. KIRAN MOTORS LTD (2201-01), 909/4,G.I.D.C.MAKARPURA,VADDODARA - 390010 PH :9624472699.
555. KIRAN MOTORS LTD (2201-02), PLOT NO.16, SUB-I NUTAN GUJ IND. ESTATE,OLD CHHANI ROAD, VADODARA - 390002 PH :9824207889.
556. AMAR CARS PVT. LTD. (2203-01), GORWA ROAD,VARODARA,GUJARAT, - 390016 PH :9081311990, 9723742425, 8980036184.
557. AMAR CARS PVT. LTD. (2203-02), KALA GHODA, OPP. KIRTI MANDIR, VADODARA, DIS: VADODARA, GUJARAT - 390001 PH :721110952.
558. KATARIA AUTOMOBILES PVT. LTD. (2204-01), 984/4, GIDC, OLD NH-8,MAKARPURA ROAD, VADODARA, GUJARAT - 390010 PH :9904033422.
559. AMAR CARS PVT. LTD. (2205-01), VARASIYA AIRPORT ROAD, OPP POONAM CINEMA, KARELIBAUG, VADODARA, GUJARAT - 390016 PH :8980006756.
560. KIRAN MOTORS LTD (2201-03), C/O ARBUDA COLD STORAGE, 823 POWER CABLE ROAD, DHARMSINH ROAD, OPP. UMA AMAR PARTY PLOT, NEAR CHHANI JAKAT NAKA, VADODARA - 390002 PH :2771122.
561. KATARIA AUTOMOBILES PVT. LTD. (2204-02), OPPOSITE SHARDA MANDIR HIGH SCHOOL, VINODA BHAVE ROAD, SALATWADA, VADODARA - 390001 PH :8156017770.
562. RAVIRATNA MOTORS PVT LTD (2206-01), SURVEY NO. 1581, MILES HOUSE, ATLADARA ROAD, VADODARA - 390012 PH :7227055065, 7227055064.
- VALOD**
563. DHRU MOTORS (CSW1-01), PLOT NO.5 TO 9, TAIYABA PARK SOCIETY, AT & PO - VALOD, TALUKA - VALOD, DISTT. - TAPI, GUJARAT. - 394640 PH :9712984522.
- VALSAD**
564. KATARIA AUTOMOBILES PVT. LTD. (104-06), SURVEY NO. 211, ATUL-ALSAAD ROAD,PARNERA,VALSAD, GUJARAT - 396020 PH :9904133306.
- VANSADA**
565. KATARIA AUTOMOBILES PVT. LTD. (Q701-02), JAMNABA PARK, VANSDA HANUMAN BARI CHAR RASTA, VANSDA-CHARAMPUR ROAD, RANI FALIYA, VANSDA, DISTRICT - NAVSARI, GUJARAT - 396580 PH :7624088188.
- VAPI**
566. KATARIA AUTOMOBILES PVT. LTD. (104-03), PLOT NO. C-29,NATIONAL HIGHWAY-8,G. I. D. C., VAPI, TAL. PARDI - 396195 PH :9924204423.
567. KATARIA AUTOMOBILES PVT. LTD. (104-09), PLOT NO. 30/4, VILLAGE BALITHA, NH-8, OPP BABA SITARAM TEMPLE, NEAR SWAMINARAYAN SCHOOL, SALAV, VAPI , DISTRICT -VALSAD, GUJARAT - 369191 PH :9723462612.
568. AMAR CARS PVT. LTD. (9701-01), SURVEY NO. 1034, 1035, NEAR WOODLAND HOTEL, NH-8, VILLAGE - BALITHA, VAPI. - 396145 PH :9327909504.
- VERALAL**
569. PERFECT AUTO SERVICES (5502-05), NR. BALIYA HANUMAN,VERALAL - JUNAGADH HIGHWAY, JUNAGADH, GUJARAT - 362265 PH :9988994550, 9898121122.
- VIJAPUR**
570. STARLINE CARS PVT. LTD. (D101-04), HIMMATNAGAR HIGHWAY, ANANDPURA CHAR RASTA, VIJAPUR - 382870 PH :9909043635.
- VIRAMGAM**
571. KIRAN MOTORS LTD (AAB1-01), SURVEY NO.319/P, NILKI CHOKDI, VIRAMGAM, DISTT: AHMEDABAD, GUJARAT. - 382150 PH :8156016222.
- VISNAGAR**
572. STARLINE CARS PVT. LTD. (D101-05), VISNAGAR-AMBaji ROAD, OPP. DHAROI COLONY, VISNAGAR, DISTT. - MEHSANA - 384315 PH :7046046174.
- VYARA**
573. COMET CAR SALES & SERVICE PVT LTD (BIY1-01), SHOP NO. 11 & 12, BLOCK NO. 175/1/A, RS NO. 113, VYARA-SURAT ROAD, VYARA, DISTRICT - TAPI, GUJARAT - 394650 PH :9099916099.
- WAGHODIA**
574. KATARIA AUTOMOBILES PVT. LTD. (BZ21-01), OPPOSITE BHARAT PETROLEUM, WAGHODIA, TALUKA - WAGHODIA, DISTRICT - VADODARA, GUJARAT. - 391760 PH :7203013712.
- WANKANER**

575. ATUL MOTORS PVT LTD (BAL1-01-), RAJKOT-WANKANER HIGHWAY, NEAR JADESHWAR CHAMBERS, NEAR INTERNATIONAL CERAMIC, WANKANER (GUJARAT) - 363621
PH :9904922333.

GUJRAT

KHERGAM

576. KATARIA AUTOMOBILES (STR1-01-), SANVIRA HAT BAZAAR, KHERGAM-DHARAMPUR HIGHWAY ROAD, SH-67, KHERGAM, PIN- 396040 - 396040
PH :9624007774.

SOJITRA

577. AMAR CARS (SMT1-01-), RAMDEV ARCADE, OPP. BUS STATION, AT – SOJITRA, DIST. - ANAND GUJARAT PIN 387240. - 387240
PH :9662357557.

HARAYANA

GURGAON

578. PASCO AUTO (9506-04-), KHASRA NO. 191/2 & 190/2, MAIN DAULATABAD ROAD, OPP. OLD BHALLA CHEMICALS FACTORY, DAULATABAD INDUSTRIAL AREA, GURGAON, HARYANA - 122006. - 122006
PH :8851227233.

KARNAL

579. MODERN AUTOMOBILES (8907-03-), 117-118 KM MILE STONE NH1, NEAR VILLAGE KAMBOPURA, GT ROAD, KARNAL - 132001
PH :7419900042.

SAMALKHA

580. RKH AUTO GALLERY (LY02-01-), GT ROAD, SAMALKHA, PANIPAT, HARYANA PIN- 132101 - 132101
PH :9053700003.

HARYANA

ADAMPUR (HARYANA)

581. SARAOGI AUTOMOBILES (P) LTD. (CWW2-01-), KEWAT NO. 663, KHAT NO. 1147, KHESRI NO. 44/21/2(1-0), MANDI ADAMPUR, TEHSIL - ADAMPUR, DIST.-HISSAR, STATE - HARYANA. - 125052
PH :8607777153.

AMBALA

582. MODERN AUTOMOBILES (1801-01-), MODEL TOWN CROSSING, G.T.ROAD, AMBALA, HARYANA . - 134003
PH :9215016044.

583. MODERN AUTOMOBILES (1801-02-), NEAR AMAR PALI RESTAURANT, G.T. ROAD, AMBALA - 134003
PH :9215016044.

584. EAKANSH WHEELS (1802-01-), STONE NO. 126, JAGADARI ROAD, VILLAGE TEPLA, AMBALA - 133001
PH :9991703000.

585. EAKANSH WHEELS (1802-03-), PLOT NO. 8, BASANT VIHAR, BEHIND SWASTIK MARBLE, NEAR MOTOR MARKET, AMBALA CITY, HARYANA - 133001
PH :8881387488.

586. TR SAWHNEY (1803-01-), JAGGI GARDEN, BALDEV NAGAR, OPPOSITE AMBALA PASSPORT OFFICE, AMBALA - 134003
PH :9990110068.

ASSANDH

587. KARNAL MOTORS PVT. LTD. (8906-04-), OPP. NEW GRAIN MARKET, KARNAL ROAD ASSANDH, DISTT. KARNAL - 272032
PH :7082111325.

BABARPUR

588. AUTO GALLERY(A UNIT OF RKH AUTOMOBILES P LTD) (CKX1-01-), G.T. ROAD, NEAR PARK RESIDENCY, SHIMLA MAULANA, BADOLI, BABARPUR, DISTT. PANIPAT - 123103
PH :7009396727.

BADHADURGARH

589. COMPETENT AUTOMOBILES CO. LTD. (2G02-01-), PLOT NO. 1202, MIE PART B, BAHADURGARH, HARYANA - 124 507
PH :8929648144.

BAPOLI

590. AUTO GALLERY(A UNIT OF RKH AUTOMOBILES P LTD) (CW1-01-), KHEWAT NO. 136, VILLAGE - JHAMBA, TEHSIL - BAPOLI, DISTRICT - PANIPAT . - 132103
PH :9053400583.

BARARA

591. EAKANSH WHEELS (NX01-01-), SH-4, KALA AMB - SHAHBAD - BARARA ROAD, BARARA - 13201
PH :9991478100.

BARWALA

592. MODERN AUTOMOBILES (BSA2-01-), KHEWAT/KHOTONI NO. 388, KHASRA NO. 46/9, 10, OPPOSITE AXIS BANK, VILLAGE BATAPUR, P.O. BARWALA, TEHSIL AND DISTT. PANCHKULA, HARYANA - 134118
PH :9896217059.

BAWAL

593. DINCO 4 WHEELS LLP (AUTO VIBES) (BBD2-01-), KHATA NO. 326 AND KHATAUNI NO. 362, OPPOSITE PRATHAM HOUSING, NH-8, BAWAL, DISTRICT - REWARI, HARYANA . - 123501
PH :7082100250.

BHIWANI

594. JAGMOHAN MOTORS PVT LTD (X301-01-), DELHI ROHTAK ROAD, NEAR RADHA SWAMI SATSANG MANDIR, BIHWANI - 127021
PH :8685005592.

BILASPUR

595. PANDIT AUTOMOBILES PVT. LTD. (BGH1-01-), NEAR GRAMIN BANK, JAGADHRI ROAD, BILASPUR, DISTRICT - YAMUNANAGAR, HARYANA - 135102
PH :9992113854.

BILASPUR (HARYANA)

596. PLATINUM MOTOCORP LLP (2L04-02-), KHASRA NO.54/67, CHOUDHARY NIHAL SINGH MARKET, BILASPUR CHOWK, NH-8, BILASPUR, DISTRICT - GURUGRAM . - 122413
PH :9953345329/9953345403.

CHARKHI DADRI

597. JAGMOHAN MOTORS PVT LTD (X301-02-), BIHWANI LOHARU ROAD, CHARKHI DADRI, BIHWANI . - 127306
PH :8059900583.

CHEEKA

598. EAKANSH MOTORS PVT. LTD. (U802-04-), MARBLE MARKET, PATIALA ROAD, CHEEKA, HARYANA . - 136034
PH :8653086000.

CHHACHHRAULI

599. PANDIT AUTOMOBILES PVT. LTD. (CQZ1-01-), HB NO. 311, NEAR MDAV SCHOOL, TEHSIL - CHHACHHRAULI, DISTRICT - YAMUNA NAGAR. - 135103
PH :9812455895.

DADRI TOE

600. COMPETENT AUTOMOBILES CO. LTD. (BVH2-01-), KHEWAT NO. - 270 MIN, KHATONI NO. - 319, DADRI TOYE, DISTT. JHAJJAR, HARYANA PIN 124103 - 124103
PH :9821308849.

DAHINA

601. DINCO 4 WHEELS LLP (AUTO VIBES) (GLH1-01-), REWARI MAHENDERGARH ROAD, NEAR RAILWAY STATION, DAHINA, REWARI - 123411
PH :7082100201.

DHAND

602. EAKANSH MOTORS (BEU1-01-), PANCHMUKHI CHOWK, KARNAL ROAD, DHAND, DISTT. KAITHAL, HARYANA . - 136020
PH :8395906111.

DHARUHERA

603. DINCO 4 WHEELS LLP (AUTO VIBES) (CRP1-01-), KHASRA NO. 57, KILLA NO. 7, SOHNA-DHARUHERA ROAD, OFF SECTOR-4A, DHARUHERA, DIST.-REWARI.
PH :7082100270.

ELLENABAD

604. SHAKTI MOTORS PVT.LTD. (E401-03-), SURERA CHOWK, NEAR CHAUDHARI MANI RAM COLLEGE, SIRSA ROAD, ELLENABAD - 125055
PH :8222900250.

FARIDABAD

605. VIPUL MOTORS PVT. LTD. (S801-01-), 27/5 KM, MAIN MATHURA ROAD, FARIDABAD - 121002
PH :2555011
2555013
97114 14556.

606. VIPUL MOTORS PVT. LTD. (S801-03-), UNIT-II, PLOT NO. 1A 196, MATHURA ROAD, FARIDABAD - 121006
PH :4286600
4286024
4286024
9311321419.

607. TCS AUTOMOBILES (5804-01-), PLOT NO-1A, SECTOR-6, FARIDABAD, - 121001
PH :4292929, 7503036200.

608. FAIR DEAL PREMIUM WHEELS PVT.LTD. (S807-01-), PLOT NO -17A, NIT INDUSTRIAL AREA, NIT FARIDABAD - 121003
PH :8448296686.

609. TCS AUTOWORLD PVT. LTD. (TCS & ASSOCIATES PVT. LTD.) (S804-02-), 20.4 KMS MILESTONE, BHASKAR COMPOUND, AMAR NAGAR, MAIN MATHURA ROAD, FARIDABAD, HARYANA . - 121003
PH :2277225; 7290082911.

610. AUTO NATION (A UNIT OF TAYAL INDIA MOTORS PVT. LTD) (S806-01-), 15/3, MATHURA ROAD, NEAR SECTOR-28, METRO STATION, FARIDABAD - 121003
PH :4180500
7290032501.

611. AUTO NATION (A UNIT OF TAYAL INDIA MOTORS PVT. LTD) (S806-02-), BYE PASS ROAD, PLOT NO. 12 SECTOR-9, FARIDABAD. - 121006
PH :74287 48467.

FARRUKHNAGAR

612. PLATINUM MOTOCORP LLP (KE01-01-), KHEVAT NO. 299, MUSTIL NO.-12, KHASRA NO.-193 AND 22/2, VILLAGE - SEHADPUR MOHAMADPUR, TEHSIL - FARRUKHNAGAR, DISTRICT - GURGAON . - 122506
PH :9599007357/9953345380.

FATEHABAD

Dealer Network (AS ON 31.10.2023)

613. SHAKTI MOTORS PVT.LTD. (2H02-01-), NH-10, SIRSA ROAD, FATEHBAD - 125050 PH :8222900217.
- GANAU**
614. JAGMOHAN AUTOMOTIVES PVT. LTD. (NA04-01-), RAILWAY ROAD, GANAUR - 131101 PH :8199911106.
- GHARAUEDA**
615. KARNAL MOTORS PVT. LTD. (8906-05-), WARD NO.-1, BEHIND GOVT. SR. SEC. SCHOOL COLONY, GHARAUEDA - 132114 PH :8222022321.
- GOHANA**
616. JAGMOHAN AUTOMOTIVES PVT. LTD. (CU03-01-), NEAR KHANPUR CHOWKIN, ROHTAK PANIPAT HIGHWAY, GOHANA, DISTT. - SONEPAT - 131301 PH :8685005521.
- GURGAON**
617. PASCO AUTOMOBILES (9506-01-), PASCO HOUSE, 6 PALAM GURGAON ROAD, INDUSTRIAL ESTATE, GURGAON - 122006 PH :09650790323/7290069623/9999239959/4952100. 618. VIPUL MOTORS PVT. LTD. (5801-02-), 504, UDYOG VIHAR, PHASE-III, GURGAON - 122001 PH :4395701 4395704 8448487921.
619. COMPETENT AUTOMOBILES CO. LTD. (9505-01-), A-25, INFOCITY, SECTOR-33, GURGAON - 122004 PH :42500002, 9582797735.
620. PASCO AUTOMOBILES (9506-02-), SECTOR 17-18, DIVIDER ROAD, GURGAON, HARYANA, - 122015 PH :07015804442/7982087767/9650701958/.
621. ROHAN MOTORS LTD. (9508-01-), 2482/84, SECTOR-52A, WAIZIRABAD VILLAGE, OPP. AARDI CITY MALL, GURGAON - 122001 PH :0886076163/8130593202/813059321/813059320 3.
622. VIPUL MOTORS PVT. LTD. (5801-04-), PLOT NO.5/22/1, SARHAUL VILLAGE,SECTOR-18, MAIN ROAD, GURGAON. (HARYANA) - 201102 PH :4395800 4395808 84484936.
623. PREM MOTORS PVT. LTD. (9511-01-), PLOT NO.101, SAINI PLAZA MARKET, OPP. H BLOCK, NEAR RAM MANDIR, PALAM VIHAR, GURGAON - 122017 PH :4337900, 7065003445.
624. PREM MOTORS PVT. LTD. (9512-01-), PLOT NO. 3, IDC, OPPOSITE SECTOR-14, GURGAON - 122001 PH :7065003373, 7065003377, 0124-4319000.
625. RANA MOTORS PVT LTD (9509-02-), PLOT NO.6, IDC, GURGAON - 122001 PH :4867777, 9873400882.
626. PASCO AUTOMOBILES (9510-01-), PLOT NO. 34/3, DINESH JAIN COMPLEX, DELHI-AJMER EXPRESSWAY (NH-8), RAJIV CHOWK, GURGAON, HARYANA - 122001 PH :9953669444/9953669222.
627. PREM MOTORS LTD. (9512-02-), PLOT NO. 122, PALAM VIHAR EXTENSION, NEAR KRISHNA CHOWK, GURGAON - 122017 PH :4337933, 7065003442.
628. PLATINUM MOTO CORP (2L04-03-), 5/13 SOHNA ROAD VILL-TIKKI ADJACENT TO POLARIS HOSPITAL GURGAON HARYANA - 122018 PH :9953345370/9899118867.
629. PREM MOTORS (9512-G1-), QILA NUMBER 8/2, MUSTAKIL NO -25, SECTOR 17-18, DIVIDING ROAD, GURGAON, - 122015 PH :8800000517.
630. PLATINUM MOTOCORP (2L04-04-), KILA NO. 15, SECTOR 93, NEAR HAYATPUR POLICE CHOWKI, HAYATPUR, GURGAON, PIN-122050, HARYANA - 122050 PH :9899118850.
- HANSI**
631. JAGMOHAN MOTORS PVT LTD (GT02-01-), G. T. HIGHWAY ROAD, MAIN ROHTAK HANSI ROAD, NEAR HOLLAND TRACTORS AGENCY & HP PETROL, HANSI - 124001 PH :8059000546.
- HISAR**
632. MODERN AUTOMOBILES (7602-01-), OPP. VIDYUT NAGAR, DELHI ROAD, HISAR, - 125005 PH :9355473000.
633. SARAOGI AUTOMOBILES (P) LTD. (7604-01-), 5TH KM STONE, SIRSAR ROAD, HISSAR, HARYANA - 125001 PH :860777043.
634. MODERN AUTOMOBILES (7602-02-), OPP. BBMB, HISSAR DELHI ROAD, HISSAR - 125001 PH :9355473000.
635. UNIQUE MOTORS PVT. LTD. (7603-01-), OPP. BHANU INDUSTRIES, DELHI ROAD, VILLAGE: SATROD, HISSAR (HARYANA) - 125006 PH :8818055535.
- HODAL**
636. ROHAN MOTORS (EE01-02-), KILA NO. 8/2(7-11), 9/5-06, 12/5-04), 13(8-0), HIGHWAY ROAD, NEAR RAILWAY BYPASS CHOWK, TEHSIL - HODAL, DIST-PALWAL PH :8930202088 ; 9413080376.
- ISMAILABAD**
637. KARNAL MOTORS PVT. LTD. (I901-01-), KHEWAT NO. 928, KHASRA NO. 2760(5-14), 2761(800), VILLAGE - ISMAILABAD, TEHSIL - PEHOW, DIST-KURUKSHETRA, HARYANA - 136129 PH :7082007138.
- ISRANA**
638. AUTO GALLERY (A UNIT OF RKH AUTOMOBILES PRIVATE LIMITED) (B02-01-), MUSHIL NO.-119, NEAR MANDI MOD, MAIN GOHANA ROAD, ISRANA - 132107 PH :9053400417.
- JHAJJAR**
639. COMPETENT (0B02-01-), PLOT NO 5, NEAR GOVT POLYTECHNIC COLLEGE, JHAJJAR-BAHADURGARH ROAD, JHAJJAR, HARYANA - 124101 PH :9999493040.
- JIND**
640. EAKANSH MOTORS PVT. LTD. (2K01-01-), ROHTAK ROAD, NATIONAL HIGHWAY-71, OPP. GRAIN MARKET, JIND, HARYANA - 126102 PH :7876008184.
- JULANA**
641. EAKANSH MOTORS PVT. LTD. (MA01-01-), JIND ROHTAK MAIN ROAD, OPP. NEW BUS STAND, JULANA, DIST. JIND, HARYANA - 126101 PH :8816802111.
- KAITHAL**
642. EAKANSH MOTORS PVT. LTD. (U802-01-), AMBALA ROAD, NH-65, KAITHAL - 136027 PH :9671788801.
- KALANAU**
643. JAGMOHAN MOTORS (SPQ1-01-), BHIWANI ROAD, KALANAU, DISTRICT ROHTAK. - 124113 PH :9812000425.
644. PANDIT AUTOMOBILES (SSN1-01-), VPO. KALANAU, DISTRICT- YAMUNANAGAR, HARYANA - 124113 PH :9053055550.
- KALAYAT**
645. EAKANSH MOTORS PVT. LTD. (BJP1-01-), NEAR BUS STAND KAITHAL-KALAYAT ROAD, VILLLAGE-KALAYAT, DISTT. KAITHAL (HARYANA) - 136117 PH :9671788801.
- KALKA**
646. MODERN AUTOMOBILES (EG02-01-), ADJOINING INDIAN OIL PETROL PUMP, RAM NAGAR, NH-22, KALKA, DISTRICT - PANCHKULA, HARYANA - 133302 PH :9896217059.
- KARNAL**
647. KARNAL MOTORS PVT. LTD. (8906-01-), 71/3 MILESTONE, G.T.ROAD, KARNAL - 132001 PH :8222022399.
648. KARNAL MOTORS PVT. LTD. (8906-02-), KHEWAT NO. 59, JHANJHARI GT ROAD, KARNAL - 132001 PH :8222022430.
649. MODERN AUTOMOBILES (8907-01-), NEAR NAMASTE CHOWK, OLD G.T.ROAD, KARNAL - 132001 PH :7419900042.
- KATHURA**
650. JAGMOHAN AUTOMOTIVES (SFJ1-01-), GOHANA MAHAM ROAD, KATHURA, GOHANA. - 131301 PH :8685005400.
- KHARKHODA**
651. JAGMOHAN AUTOMOTIVES PVT. LTD. (BU02-01-), NEAR KANYA GURUKUL MAHAVIDYALYA, DELHI ROAD, NEAR UNION BANK, KHARKHODA (HARYANA) - 131402 PH :8685005593.
- KOSLI**
652. DINCO 4 WHEELS LLP (AUTO VIBES) (CAN1-01-), OPPOSITE RAJIV GANDHI STADIUM, TEHSIL ROAD KOSLI, DISTRICT – REWARI, HARYANA - - 123302 PH :7082100202.
- KUND**
653. DINCO 4 WHEELS LLP (AUTO VIBES) (CJL1-01-), NEAR KUND BARRIER, OPP. SBI BANK, NARNAUL ROAD, VILLAGE - MANETHI, KUND, DISTRICT - REWARI, HARYANA - - 123102 PH :856998928, 97082100000.
- KUNDLI**
654. JAGMOHAN AUTOMOTIVES PVT. LTD. (GU03-01-), 34 E, SECTOR 57, PHASE 4 , KUNDLI INDUSTRIAL AREA, KUNDLI - 131001 PH :8059900518.
- KURUKSHETRA**
655. KARNAL MOTORS PVT. LTD. (8906-03-), PLOT NO. 156, INDUSTRIAL AREA, SECTOR-2, KURUKSHETRA - 136 118 PH :8222022371.
- LADWA**
656. KARNAL MOTORS PVT. LTD. (CRA1-01-), KHEWAT NO.197, KHATON NO.233, KHASRA NO.2/71/1/27/14, LADWA-KURUKSHETRA ROAD, VILLAGE - LADWA, TEHSIL THANESAR, DISTT. KURUKSHETRA - 136132 PH :7082007162.
- LOHARU**
657. JAGMOHAN MOTORS (HB02-01-), BHIWANI ROAD, OPP. ITI, CITY: LOHARU - 127201 PH :9812000425.

MADLAUDA

658. AUTO GALLERY (A UNIT OF RKH AUTOMOBILES PRIVATE LIMITED) (CFK2-01-), VILLAGE-BHALSI, ASSANDH-PANIPAT ROAD, MADLAUDA, PIN-132113, HARYANA - 132113
PH :9053400524.

MAHENDARGARH

659. PLATINUM MOTO CORP (DP01-01-), KHEWAT NO. 187, KILLA NO. 51/8, REVENUE ESTATE OF VILLAGE REWASA, DADRI ROAD, TEHSIL & DISTRICT, MAHENDRAGARH, PIN-123029, HARYANA - 123029
PH :9566136120, 9053088490.

MANDI DABWALI

660. SHAKTI MOTORS PVT.LTD. (E401-02-), SANGARI ROAD, DABWALI, DISTT.-SIRSA - 125104
PH :8222900209.

MANESAR

661. PLATINUM MOTOCORP LLP (2L04-01-), PLOT NO.282, SEC 6, IMT MANESAR DISTT. GURGAON. - 122052
PH :9953345326/9953345324/9910100341.

MEHAM

662. JAGMOHAN MOTORS PVT LTD (A601-08-), MAIN MARKET, NATIONAL HIGHWAY-10, ROHTAK-HISSAR ROAD, MEHAM, DISTRICT-ROHTAK - 124101
PH :8059900592.

MOHNA

663. TCS & ASSOCIATES PVT LTD (CRT1-01-), YAMUNA PUL ROAD , NEAR GYATRI PETROL PUMP, VPO-MOHNA,TEHSIL BALLABGARH , DISTT FARIDABAD - 121004
PH :9911573130, 8929579400.

MUSTAFABAD

664. PANDIT AUTOMOBILES PVT. LTD. (CDX1-01-), KHATUNI NO. 205/287, KHASRA NO. 39/17/2, VILLAGE - MANSURPUR, THANA - CHAPPER, MUSTAFABAD, DIST.-YAMUNA NAGAR, STATE - HARYANA - 133 103
PH :9992113854.

NARAINGARH

665. EAKANSH WHEELS (1802-02-), NH-72, AMBALA-KALA AMB ROAD, NEAR ADARSH FILLING STATION, NARAINGARH - 134203
PH :9991143700.

NARNAUL

666. PLATINUM MOTOCORP LLP (9Q02-01-), KAILASH NAGAR, REWARI ROAD, NARNAUL, HARYANA. - 123001
PH :09053088460/9582226838/9053088501/905308845 1/9053088500.

NARNAUND

667. JAGMOHAN MOTORS (SDK1-01-), KHASRA NO. 234, HANSI ROAD, NARNAUND, DISTT. HISAR, HARYANA. - 125039
PH :9812000471.

NARWANA

668. EAKANSH MOTORS PVT. LTD. (U802-03-), OPP. HAFED GODOWN-2, NH-65 AKHERAM NAGAR, NARWANA - 126116
PH :9813583100.

NUH

669. PASCO AUTOMOBILES (7L02-01-), MAIN DELHI - ALWAR ROAD, NEAR SHAHEED PARK, NH -248A, NUH, DISTRICT - MEWAT, HARYANA. - 122107
PH :9810014947.

PALWAL

670. ROHAN MOTORS LTD. (EE01-01-), SANWAL COLONY, MAIN MATHURA ROAD, NEAR SDM COURT, PALWAL - 121101
PH :304100 ; 304107/8930202060.

PANCHKULA

671. MODERN AUTOMOBILES (702-03-), PLOT NO. 318, INDUSTRIAL AREA, PHASE-2, PANCHKULA - 134113
PH :9646000165.

672. AUTOPACE NETWORK PVT LTD (705-03-), PLOT NO. 5, INDUSTRIAL AREA, PHASE-1, PANCHKULA, HARYANA. - 134113
PH :7087119847.

673. AUTO VOGUE PVT. LTD. (K303-01-), PLOT NO- 388, INDUSTRIAL AREA PHASE-1, PANCHKULA, HARYANA. - 134113
PH :8558813181.

PANIPAT

674. AUTO GALLERY(A UNIT OF RKH AUTOMOBILES P LTD) (D302-01-), KHASRA NO. 43/6, 44/9 & 10, VILLAGE – JATTIPUR, NEAR HOTEL SWARNA MAHAL, NH-1, PANIPAT, HARYANA. - 132103
PH :9053400515.

PATAUDI

675. PLATINUM MOTOCORP LLP (BY03-01-), HALI MANDI ROAD, OPPOSITE SHIV MURTI, PATAUDI, DIST. - GURGAON - 122503
PH :9953345381/9953345488/9953345330.

PEHOWA

676. KARNAL MOTORS PVT. LTD. (2M02-01-), NEAR DAV COLLEGE, AMBALA ROAD, PEHOWA. 136128 - 136128
PH :8222022464.

PUNDRI

677. EAKANSH MOTORS PVT. LTD. (BFF1-01-), KILA NO- 3/10, KHEWAT 2147 OPP. HARCHARAN FILLING STATION, KAITHAL ROAD, PUNDRI DIST. KAITHAL, HARYANA - 136026
PH :9671788801.

PUNJHANA

678. PASCO AUTOMOBILES (BIU1-01-), KILA NO. 4/2, PUNJHANA, DIST.-MEWAT, HARYANA - 122508
PH :9991300950, 8059730879.

RADAUR

679. PANDIT AUTOMOBILES PVT. LTD. (D201-02-), OPP. JMII ENGG. COLLEGE, NEAR BUS STAND, RADAUR, DISTRICT-RADAUR, HARYANA - 135001
PH :9992113854.

RAJOURD

680. EAKANSH MOTORS (SHV1-01-), MITTAL KHAL BHANDAR, RAJOURD, DISTT KAITHAL - 136044
PH :9671788801.

REWARI

681. DINC0 4 WHEELS LLP (AUTO VIBES) (U102-01-), BAWAL ROAD, NEAR BEY PASS ROAD, REWARI (HARYANA) - 123401
PH :7082100200/7082100204/7082100201.

ROHTAK

682. JAGMOHAN MOTORS PVT LTD (A601-01-), SONEPAT ROAD, ROHTAK - 124001
PH :9467465035.

683. JAGMOHAN MOTORS PVT LTD (A601-09-), SWAN GARDEN, DELHI ROAD, ROHTAK - 124001
PH :9812000357.

684. UNIQUE AUTO LEAD LLP (A602-01-), KHASRA NO- 3597 JIND ROAD, JIND CHOWK, ROHTAK, HARYANA - 124001
PH :9812259000.

SAFIDON

685. EAKANSH MOTORS PVT. LTD. (U802-05-), NEAR BRSK SCHOOL , OPPOSITE RELIANCE PETROL PUMP, PANIPAT ROAD, SAFFIDON, DISTRICT- JIND - 126112
PH :9416616603.

SAMPLA

686. JAGMOHAN MOTORS PVT LTD (NY01-01-), NEAR VASUNDARA CAFÉ, DELHI ROHTAK ROAD, SAMPLA, DISTT. ROHTAK - 124501
PH :9812000351.

SATNALI

687. PLATINUM (SLH1-01-), KHEVAT NO.605, KHATONI NO-1134 KILLA NO.167, VILL: SATNALI, NEAR BHARAT PETROL PUMP MAHENDRAGARH ROAD, HARYANA -123024 (LOCATION: MAHENDRAGARH) - 123024
PH :9910100341.

SHAHABAD

688. KARNAL MOTORS PVT. LTD. (CCR2-01-), KHEWAT NO. 460, KATONI NO. 486, KHASRA NO. 170, TEHSIL - SHAHABAD, DIST. KURUKSHETRA. - 136135
PH :8222022338.

SIRSA

689. SHAKTI MOTORS PVT.LTD. (E401-01-), DABBALI RD., SIRSA, HARYANA - 125055
PH :8222900201.

SIWANI

690. SARACGI AUTOMOBILES (P) LTD. (HA03-01-), OPP.GOVt HOSPITAL ,SIWANI BYPASS CHOWK,HISSAR ROAD ,SWANI,DIST.BHIWANI -127046 HARYANA - 127046
PH :8607777149.

SOHNA

691. PASCO AUTOMOBILES (9506-03-), 56, KILLA NO. 13 (4-10), 18(4-6), 19 (8-0), 23 (8-0), 23 (4-2), VILLAGE - ALIPUR, SOHNA GURUGRAM ROAD, TEHSIL - SOHNA , DISTRICT -GURUGRAM . - 122103
PH :08683000902/9873711127/8683000919.

SONIPAT

692. JAGMOHAN AUTOMOTIVES PVT. LTD. (J502-01-), BAHALGARH-DELHI ROAD, OPP. POWER HOUSE, SONIPAT - 131001
PH :9992200372.

693. JAGMOHAN AUTOMOTIVES PVT. LTD. (J502-02-), GAYATRI GARDEN, MURTHAL ROAD, SONEPAT (HARYANA) - 131001
PH :8650056866.

694. JAGMOHAN AUTOMOTIVES PVT. LTD. (J502-03-), 0-11 INDUSTRIAL AREA, SONIPAT, HARYANA . - 131001
PH :9812615000.

TAURU

695. PASCO AUTOMOBILES (BIV1-01-), KILA NO. 34/1/2, REWARI ROAD, TAURU, DIST.-MEWAT, HARYANA . - 122015
PH :8683000902, 9873001497, 8683000954, 9671150250, 9034926253.

TIGAON

696. TCS (5804-03-), TCS AUTOWORLD, ARYAN PLAZA, NEEMKA BHUPGARH, TIGAON-BALLABGARH ROAD, FARIDABAD, PIN-121004, HARYANA - 121004
PH :9971422444.

TOHANA

697. SHAKTI MOTORS PVT.LTD. (XP01-01-), NEAR GREEN VALLEY PUBLIC SCHOOL, RATIA ROAD, TOHANA - 125120
PH :8572800991.

TOSHAM

Dealer Network (AS ON 31.10.2023)

698. JAGMOHAN MOTORS PVT LTD (0Y01-01),
BHIWANI ROAD, TEH. TOSHAM, DIST. BHIWANI.
- 12704
PH :8059900566.

YAMUNANAGAR

699. PANDIT AUTOMOBILES PVT. LTD. (D201-01),
GOVINDPURI ROAD, JAGADRI, YAMUNANAGAR
- 135001
PH :9812455896.
700. PANDIT AUTOMOBILES PVT. LTD. (D201-03),
PLOT NO E-8, INDUSTRIAL AREA, ITI ROAD,
YAMUNA NAGAR (HARYANA) - 135001
PH :9812455896.

HIMACHAL PRADESH

ALAMPUR

701. KANGRA VEHICLEADES (RL01-01), KHASRA
NO. 1606/1582, STATE HIGHWAY
PALAMPUR-SUANPUR AT JANGAL, VILLAGE -
ALAMPUR, DIST.-KANGRA. - 176082
PH :8988002269.

BADDI

702. GOYAL MOTORS PVT LTD (7D01-04),
KHATA/KHATAUNI NO. 26/26, KHASRA NO.
93/56/32 AND 94/56/32, KITAS 2, REVENUE
MAUZA - CHAK JANGI, HADBAST NO. 203,
TEHSIL - BADDI, DISTRICT - SOLAN, HIMACHAL
PRADESH. - 173205
PH :9416076972.

BAIJNATH

703. KANGRA VEHICLEADES (BBC1-01), TASHI
JONG, PAPROLA-BAIJNATH, NH-20, KANGRA
-MANDI ROAD, TEHSIL BAIJNATH, DISTT.
KANGRA - 176115
PH :8628820603.

BANKHET

704. PATHANKOT VEHICLEADES PVT. LTD.
(BWN1-01), KHASRA NO.709, KHATA KHATOONI
NO.23, BANKHET, THE-DALHOUSIE, DISTT.
CHAMBA - 176303
PH :254186, 232036, 9418048803.

BILASPUR

705. COMPETENT AUTOMOBILES CO. LTD.
(6Y01-01), KHEWAT NO. 8/8 KHATAUNI,
KHASRA NO. 137/30, 31, MAUZA KOTHI,
PARGANA 9, P. O. - CHANDPUR, TEHSIL -
SADAR, DIST. - BILASPUR, HIMACHAL
PRADESH. - 174001
PH :7807166832, 7807800330 / 7807800440.

CHAMBA

706. KANGRA VEHICLEADES (D902-03), MOHALLA
SULTANPUR, BALU BRIDGE, CHAMBA - 176310
PH :9418059252 , 9418045778.

707. KANGRA VEHICLEADES (D902-05), KHASRA
NO. 88/9/6.1 & KHASRA NO.628/276, VILLAGE &
PO SAROO, THE. & DISTT. CHAMBA, HIMACHAL
PRADESH. - 176310
PH :9418059252 , 9418013810.

CHOWARI

708. PATHANKOT VEHICLEADES PVT. LTD.
(CWV1-01), KHATA KHATNI NO. 24/32 MIN,
KHASRA NO. 90, VILLAGE - LAHRU, P.O. -
PARCHHORE, TEHSIL - BHATTIYAT, DIST.
-CHAMBA, HIMACHAL PRADESH. - 144416
PH :8894569632.

DEHRA

709. KANGRA VEHICLEADES (D902-02), VILLAGE &
P.O. SUNHET, TEHSIL DEHRA, DIST. KANGRA -
177101
PH :9817013058.

GAGGAL

710. KANGRA VEHICLEADES (BBV1-01), NATIONAL
HIGHWAY -20, ZAMANABAD ROAD, ICHHI,
GAGGAL, DISTT. KANGRA, HIMACHAL
PRADESH. - 176209
PH :9418988832.

HAMIRPUR

711. COMPETENT AUTOMOBILES CO. LTD.
(W901-01), VILLAGE TIKKAR, P.O DIDWIN
TEHSIL & DISTT. HAMIRPUR - 177401
PH :9805510276.

INDORA

712. PATHANKOT VEHICLEADES PVT. LTD.
(BHE1-01), VILLAGE CHANDOR, PO & TEHSIL
INDORA, DISTT. KANGRA, PIN-176401,
HIMACHAL PRADESH - 176401
PH :9418008627.

JASINGHPUR

713. KANGRA VEHICLEADES (BVA1-01), HARSI
PATAN ROAD, OPP. SABJI MANDI, TEHSIL -
JAISINGHPUR, DIST. - KANGRA, HIMACHAL
PRADESH. - 176095
PH :9418477756.

JAWALI

714. PATHANKOT VEHICLEADES PVT. LTD.
(BXE1-01), VILLAGE - TIUKARI, NEAR MAHAVIR
HOSPITAL LUBH ROAD, TEHSIL - JAWALI, DIST.
-KANGRA, HIMACHAL PRADESH. - 176023
PH :9418195333.

JOGINDER NAGAR

715. COMPETENT AUTOMOBILES CO. LTD.
(BBO1-01), VILL. DHELU PO DOHAG, JOGINDER
NAGAR (P.O.) - 175015
PH :9805005754.

JWALAMUKHI

716. KANGRA VEHICLEADES (CND1-01), KHASRA
880/6/13, MAUJA BOHAN, TEHSIL JWALAMUKHI,
DISTRICT KANGRA - 176031
PH :9418488999.

KULLU

717. COMPETENT AUTOMOBILES CO. LTD.
(2Q01-01), PLOT 384, INDUSTRIAL AREA,
SHAMSHI, KULLU (HP) - 175126
PH :7018035136.

KUNIHAR

718. GOYAL MOTORS PVT LTD (BBX1-01), KHATA
NO. - 77, VILLAGE KOTHI, P.O. KUNIHAR,
TEHSIL - ARKI, DISTRICT - SOLAN, HIMACHAL
PRADESH - 173207
PH :9418312427.

MANALI

719. COMPETENT AUTOMOBILES CO. LTD.
(BKU1-01), VILL. CHOURI VIHAR (AALU
GROUND), P.O. & THESI- MANALI, DIST.
KULLU, (H.P.) - 175131
PH :9418387465.

MANDI

720. COMPETENT AUTOMOBILES CO. LTD.
(B301-01), GUTKAR INDUSTRIAL AREA, DELHI
MANDI ROAD, N.H.21 GUTKAR, MANDI - 124501
PH :9805513208/9816664891.

NADAUN

721. COMPETENT AUTOMOBILES CO. LTD.
(BXA1-01), VILLAGE JALAN, KHASRA NO.183,
PO & TEHSIL NADAUN, DISTT. HAMIRPUR,
HIMACHAL PRADESH - 177041
PH :9805737436.

NAGROTA

722. KANGRA VEHICLEADES (D902-01), MALAN,
NAGROTA - BAGWAN, KANGRA, H.P. - 176047
PH :7018268819.

NAGROTA BAGWAN

723. KANGRA VEHICLEADES (D902-06), JHIKLI
AMBARI, MOUZA AMBARI, MALAN, NAGROTA
BAGWAN, TEHSIL & DISTT. KANGRA,
HIMACHAL PRADESH - 176047
PH :7018268819.

NAGROTA SURIAN

724. KANGRA VEHICLEADES (BG1-01), KHEWAT
NO. 115, KHATAUNI NO. 127, KHASRA NO. 2037,
MAHAL BASSA, SUB TEHSIL - NAGROTA
SURIAN, DISTRICT - KANGRA. - 176027
PH :9418488999.

NALAGARH

725. GOYAL MOTORS PVT LTD (IB02-01), NEAR HP
PETROL PUMP, VILLAGE PEERTHAN, P.O &
TEHSIL NALAGARH, DISTT. SOLAN (H.P.) -
174101
PH :9418704572.

NERWA

726. GOYAL MOTORS PVT LTD (CRS1-01), KHASRA
NO. 482, VILLAGE - KEDI, TEHSIL - NERWA,
DISTRICT - SHIMLA, HIMACHAL PRADESH. -
171210
PH :9418663572.

NURPUR

727. KANGRA VEHICLEADES (D902-04), VILLAGE
JACHH, PO JASSUR, TEHSIL NURPUR, DISTT.
KANGRA - 176201
PH :9418195333, 9418041778.

PALAMPUR

728. KANGRA VEHICLEADES (2T01-01), NEAR IOC
PUMP, KANGRA MANDI ROAD, PALAMPUR,
DISTT. KANGRA, HIMACHAL PRADESH. - 176061
PH :9418226622/ 9463265072.

PAONTA SAHIB

729. GOYAL MOTORS PVT LTD (A901-02), OPP
BIBIJEET KAUR SENIOR SECONDARY SCHOOL,
SHAMSHERPUR, NH-72, PAONTA SAHIB -
173025
PH :9459210872.

RAJGARH

730. GOYAL MOTORS PVT LTD (BJX1-01), KHATA
NO. 517/505, 478/3, KHASRA NO. - 38/98
VILLAGE NERI RATAULI, P.O. RAJGARH TEHSIL
- RAJGARH, DISTRICT - SIRMAUR , HIMACHAL
PRADESH - 173101
PH :9418132472.

RAMPUR

731. GOYAL MOTORS PVT LTD (CEZ1-01), KHASRA
NO. 82/425, MINN NO. 155/396, 163/411, NAGLI,
ROHRU ROAD, RAMPUR, TEHSIL - RAMPUR,
DISTRICT - SHIMLA - 172001
PH :9459296572.

ROHRU

732. GOYAL MOTORS PVT LTD (JZ1-01-),
CHARGAON SHIMLA ROAD, ROHRU, DISTRICT
- SHIMLA - 171207
PH :9418016072.

SALOONI

733. PATHANKOT VEHICLEADES (SES1-01),
KHASRA NO. 299/174, VILLAGE. MANJEER,
TEHSIL-SALOONI, DISTT. CHAMBA, PIN-176320
HIMACHAL PRADESH - 176320
PH :9418059252.

SHAHPUR

734. KANGRA VEHICLEADES (SCR1-01), VILLAGE
MANJHGRAN, P.O. DRAMMAN, TEHSIL
SHAHPUR, DISTT. KANGRA, HIMACHAL
PRADESH - 176206
PH :9459900241.

SHIMLA

735. GOYAL MOTORS PVT LTD (A901-01-), TARADEVI, SHIMLA,(H.P.) - 171010 PH :9418663572.
- SOLAN**
736. GOYAL MOTORS PVT LTD (7D01-01-), DEON GHAT, SOLAN - 173211 PH :9418138772.
- UNA**
737. COMPETENT AUTOMOBILES CO. LTD. (QD01-01-), VILLAGE RAINSARY,P.O. JHALERA, TEHSIL & DISTRICT:UNA - 174303 PH :9805737436.
- JAMMU**
738. JAMKASH VEHICLEADES PVT. LTD (BPM1-01-), KHASRA NO. 269, LOWER MUTHI DHARMAL, DIST.-JAMMU , STATE - JAMMU & KASHMIR . - 181205 PH :7006898474.
- JAMMU & KASHMIR**
- CHOWKI CHOURA**
739. JAMU MOTORS (SDY1-01-), KHASRA NO. 37 MIN. ADJACENT TO J&K BANK, JAMMU POONCH HIGHWAY, CHOWKI CHOURA, JAMMU & KASHMIR - 185154 PH :9596975060.
- MAHANPUR**
740. JAMMU MOTORS (SPK1-01-), MAHANPUR, DISTRICT KATHUA, TEHSIL MAHANPUR - JAMMU & KASHMIR . - 184202 PH :9596975060.
- MANJAKOTE**
741. JAMKASH VEHICLEADES (SQV1-01-), NEAR PHC ROAD MANJAKOTE, TEHSIL MANJAKOTE, DISTRICT RAJOURI, J&K - 185131 PH :7006014395.
- VIJAYPUR**
742. JAMMU MOTORS (OZ02-01-), JAMMU PATHANKOT HIGHWAY, VIJAYPUR (SAMBA), J&K - 184120 PH :9596975060.
- JAMMU AND KASHMIR**
- AKHNOOR**
743. JAMMU MOTORS PVT. LTD. (2X02-01-), MAIN ROAD DASKAL, TEHSIL - AKHNOOR, DISTRICT - JAMMU - 181201 PH :9419118393.
- ANANTNAG**
744. PEAKS AUTO PVT. LTD. (2Y01-01-), NH-1A, MOUZA UROONHALL, THE & DISTT. ANANTNAG - 228165 PH :9519275151.
- ASHMUQAM**
745. PEAKS AUTOS (BOH1-01-), KP ROAD, HUTMARAH, NEAR ASHMUQAM, ANANTNAG, JAMMU AND KASHMR - 192125 PH :9519275151.
- BANDIPORA**
746. JAMKASH VEHICLEADES (KASHMIR) PVT LTD (1205-04-), AJAR BANDIPORA , J&K - 193502 PH :9149726427.
- BARAMULA**
747. JAMKASH VEHICLEADES (KASHMIR) PVT LTD (8C01-01-), VILLAGE SANGRAMA,WAGAROO, BARAMULA - 193101 PH :7889612218.
- BHADRAWAH**
748. J& K VEHICLEADES PVT. LTD (AKA1-01-), KHASRA NO.2863, LOWER SUNGLI UNIVERSITY ROAD, BHADREWAH, DISTT. DODA, J&K - 182222 PH :9419796521.
- BHASOLI**
749. JAMKASH VEHICLEADES PVT. LTD. (GLK1-01-), ZERO MORTH, BASHOLI, DISTT. KATHUA, BASHOLI, PIN-184201, JAMMU & KASHMIR - 184201 PH :9018847230.
- BUDGAM**
750. HIGHLAND AUTOMOBILES PVT.LTD (1202-04-), KHASRA NO. 208 MIN, KHEWAT NO. 9 AND KATHA NO. 55, MOUZA - PALLAR, TEHSIL AND DIST.-BUDGAM . - 191111 PH :9419019989.
- DAYALACHAK**
751. JAMKASH VEHICLEADES PVT. LTD (BFH1-01-), KHASRA NO. 183, KHEWAT NO.14, KHATANO-74, VILLAGE CHAK SAKTA, DAYALACHAK,TEHSIL & DISTT. KATHUA , JAMMU & KASHMIR - 184121 PH :88492849170.
- DODA**
752. J& K VEHICLEADES PVT. LTD (2202-01-), MINTO CAR CARE, AKHYARABAD, MAIN ROAD, DODA CITY, DODA (J&K) - 182202 PH :9419796521.
- GANDERBAL**
753. JAMKASH VEHICLEADES (KASHMIR) PVT LTD (ZAO1-01-), MALSHAIE BAGH, GANDERBAL (J&K) - 191201 PH :9419000828.
- HANDWARA**
754. JAMKASH VEHICLEADES (KASHMIR) PVT LTD (BYA1-01-), KHEWAT NO-31, KATHA NO-298, SURVEY NO: 3764/1816, MOZA BRARIPORA, TEH- HANDWARA, DIST- KUPWARA, J&K - 193221 PH :262322, 9419074012.
- JAMMU**
755. JAMKASH VEHICLEADES PVT. LTD (3306-01-), NH-1A, BYE PASS, OPP CHANNI HIMMAT, JAMMU - 180015 PH :6006801639.
756. JAMKASH VEHICLEADES PVT. LTD (3306-02-), NEAR GENERAL BUS STAND, OPP. PHE OFFICE, B.C. ROAD, JAMMU - 180001 PH :9419232404.
757. JAMKASH VEHICLEADES PVT. LTD (3306-04-), SUNJWAN, DISTT. JAMMU - 180011 PH :7006018600.
758. PEAKS AUTO JAMAU PVT. LTD. (3312-01-), GANGYAL INDUSTRIAL AREA, BEHIND COCA COLA FACTORY, JAMMU - 180010 PH :9697001125.
759. JAMMU MOTORS PVT. LTD. (3308-01-), 6, AKHNOOR ROAD, JAMMU . - 180001 PH :9419118393.
760. JAMMU MOTORS PVT. LTD. (3308-02-), PLOT NO.2, RAJPURO CHUNGII OPP AG OFFICE, AKHNOOR ROAD, JAMMU - 180002 PH :9419118393.
761. PEAKS AUTO JAMAU PVT. LTD. (3312-02-), KHASRA NO.425 & 426, KHTA NO.425 & 426, TOPE SHRKHANIAN (BACKSIDE OF BEST PRICE), AKHNOOR ROAD, JAMMU . - 180001 PH :9697001125.
762. JAMKASH VEHICLEADES PVT. LTD (3306-07-), KHETWAT NO. 25, KHATA NO. 355, KHASRA NO. 544 MIN PALOURA ROAD, JANIPUR, JAMMU . - 180007 PH :94191191502.
- KATHUA**
763. JAMMU MOTORS PVT. LTD. (3B02-01-), WARD NO.13, CHAK PARTAP SINGH HATLI MORH, NH1-A, KATHUA TEHSIL KATHUA . - 184101 PH :9419118393.
- KULGAM**
764. PEAKS AUTO PVT. LTD. (OY01-01-), NEAR GRID STATION,MAIN ROAD, KULGAM - 191202 PH :9519275151.
- KUPWARA**
765. JAMKASH VEHICLEADES (KASHMIR) PVT LTD (1205-03-), JAMKASH VEHICLEADES, NEAR GM FILLING STATION, DC OFFICE ROAD KUPWARA - 193223 PH :9622499902.
- MAGAM**
766. JAMKASH VEHICLEADES PVT. LTD (GLS1-01-), KHASRA NO. 34, MOUZA - CHICHILORA, MAGAM, GULMARG ROAD, TEHSIL - KWARIHAMA, DIST.-BARAMULLA, JAMMU & KASHMIR . - 193 401 PH :8825016046.
- PHINTER**
767. JAMKASH VEHICLEADES PVT. LTD (BHV1-01-), KHASRA NO.2293/405 AND KHEWAT NO.81/98, GURHA KALYAL, PHINTER, TEHSIL RAMKOT, DISTT. KATHUA, J&K . - 184203 PH :9419187583.
- POONCH**
768. JAMKASH VEHICLEADES PVT. LTD (AAW1-01-), VILLAGE KUNUYAN, TEHSIL HAVELI POONCH, JAMMU & KASHMIR . - 185121 PH :7006014395.
- PULWAMA**
769. PEAKS AUTO PVT. LTD. (1204-03-), MUGHAL ROAD, GUNGOO, PULWAMA - 192301 PH :9519275151.
- RAJOURI**
770. JAMKASH VEHICLEADES PVT. LTD (3306-06-), KALAKOTE ROAD, VILLAGE BADOL, RAJOURI - 185131 PH :7006014395.
- RS PURA**
771. JAMKASH VEHICLEADES PVT. LTD (3306-03-), GAGAIN MORTH, R S PURA, JAMMU . - 181102 PH :9419190370.
- SHOPIAN**
772. PEAKS AUTO PVT. LTD. (AAA1-01-), AGLAR SOFANAMAN, SHOPIAN - 192303 PH :9519275151.
- SIDHRA**
773. JAMKASH VEHICLEADES PVT. LTD (CDL1-01-), KHASRA NO.80 & KHATA NO.100, VILLAGE SIDHRA, NH1A, NEAR BHARAT PETROLEUM PETROL PUMP, TEH. & DISTT. JAMMU - 180019 PH :9419134144.
- SRINAGAR**
774. HIGHLAND AUTOMOBILES PVT.LTD (1202-01-), SONWAR, SRINAGAR - 190001 PH :9419057564.
775. JAMKASH VEHICLEADES (KASHMIR) PVT LTD (1205-01-), HYDERPURA BY PASS CROSSING, SRINAGAR . - 190015 PH :7006037255.
776. PEAKS AUTO PVT. LTD. (1204-01-), BYE PASS ROAD, NH - 1A, NEAR HOTEL SILVER STAR, SRINAGAR . - 191101 PH :9519275151.

Dealer Network (AS ON 31.10.2023)

777. JAMKASH VEHICLEADES (KASHMIR) PVT LTD (1205-05), NARBAL CROSSING, NH-1A, SRINAGAR, JAMMU & KASHMIR - 190017 PH :9796700750.
- SUNDERBANI**
778. PEAKS AUTO JAMMU PVT. LTD. (AAAM3-01-), MOUZA THANDA PANI, TEH. SUNDERBANI - 185153 PH :9697001125.
- SURANKOTE**
779. PEAKS AUTO JAMMU PVT. LTD. (TY03-01-), NEAR KNIEF KING FILLING STATION, BHARAT PETROLEUM, POONCH MUGHAL ROAD, SURANKOTE, DISTT: POONCH - 185101 PH :9697001125.
- THANA MANDI**
780. JAMKASH VEHICLEADES PVT. LTD. (SO01-01-), HASPLOTE(CHRUNG), TEHSIL THANAMANDI, DISTRICT RAJOURI - 185212 - 185212 PH :9419267607.
- UDHAMPUR**
781. JK K VEHICLEADES PVT. LTD (D801-01-), NATIONAL HIGHWAY 1A, NEAR DAK BANGLOW, UDHAMPUR - 182101 PH :7006881028.
- URI (CHAAL BONIYAR)**
782. JAMKASH VEHICLEADES (KASHMIR) PVT LTD (CCK1-01-), KHASRA NO.346/118, KEWAT NO.15, KHATA NO.30, MOUZ-CHALAL (URI), TEHSIL-BONIYAR, DISTT. BARAMULLA - 193123 PH :9419074012.
- JHARKHAND**
- BAGODAR**
783. RELIABLE INDUSTRIES PVT. LTD. (BHA1-01-), SONTURPI GT ROAD, GAIDA, BAGODAR, GIRIDHL, JHARKHAND - 825322 PH :9507102036 9835814404.
- BALIAPUR**
784. CARONE (SN11-01-), WARD NO 53, HOLDING NO - SAF3797, KANDRA SINDRI, BALIAPUR. - 828123 PH :7980074787.
- BOKARO**
785. HINDUSTAN AUTO AGENCY (B501-02-), R1, CITY CENTRE, SECTOR-4, BOKARO STEEL CITY, BOKARO - 827004 PH :9831560033/7070402002/9431128683.
786. HINDUSTAN AUTO AGENCY (B501-03-), M2, SECTOR-4, CITRY CENTRE, BOKARO STEEL CITY (JHARKHAND) - 827004 PH :9431127983/9431128683.
- CHAIBASA**
787. PEBCO MOTORS (BOY1-01-), KOLHAN TIMBER MERCHANT, NEAR RAILWAY CROSSING, TATA ROAD, CHAIBASA, DISTRICT - WEST SINGHDHUM, JHARKHAND - 833201 PH :7070449718.
- CHANDWA**
788. HILLTOP MOTORS (A UNIT OF HIRALAL MOTORS PVT LTD) (SCS1-01-), HILLTOP MOTORS, MAIN ROAD, CHANDWA, PO AND PS, CHANDWA - 829203, DIST - LATEHAR, JHARKHAND - 829203 PH :7061157502.
- CHIRKUNDA**
789. RELIABLE INDUSTRIES (CQT1-01-), PLOT NO. 109-110, KHATAN NO. 12, MOUZA NO. 251, P.S. - CHIRKUNDA, DISTRICT - DHANBAD, JHARKHAND - 828202 PH :9905937751 9835814404.
- DALTONGANJ**
790. PREMSONS MOTORS UDYOG PVT LTD (6103-02-), KACEHRI ROAD, DALTONGANJ, PALAMU - 822101 PH :9835507004.
- DEOGHAR**
791. RELIABLE INDUSTRIES (5202-03-), SHAHEED ASHRAM ROAD, JHAUNSAGARHI, DEOGHAR, - 814112 PH :6207129088 7001553251.
792. RELIABLE INDUSTRIES (KR02-01-), MOUZA - CHAKRIPAHARI, NO. 587, WARD NO. 36, DEOGHAR, JHARKHAND - 814114 PH :9835811220, 9835814404.
- DHANBAD**
793. RELIABLE INDUSTRIES (5202-01-), KATRAS ROAD, DHANBAD, JHARKHAND - 826001 PH :9835830202 7369945040.
794. RELIABLE INDUSTRIES (5202-02-), BEHIND PRABHAT KHABAR, AT: KOLAKUMSA, P.O K.G. ASHRAM, SARAIHELIA , DHANBAD - 826127 PH :8102233474 7369945043.
795. RELIABLE INDUSTRIES (5202-06-), SUGIADIH, HIRAK ROAD, SARAIHELIA, DHANBAD, JHARKHAND - 826127 PH :9334094940.
796. CAR ONE (A UNIT OF RAJHANS AUTOMOBILES PRIVATE LIMITED) (S205-01-), NH-2, GT ROAD, SAHARJORI, BARWADA, DHANBAD. - 828 109 PH :9006828000, 9835740433.
797. RELIABLE INDUSTRIES (S202-09-), TILAKRAIDIH, K G ASHRAM, NH-32, GOVINDPUR, DHANBAD, JHARKHAND - 828109 PH :9031096662.
- DUMKA**
798. RELIABLE INDUSTRIES (L701-01-), OPP DUDHANI PETROL PUMP, DEOGHAR-PAKUR ROAD,DUMKA (JHARKHAND) - 814101 PH :6205161170.
- GARHWA**
799. PREMSONS MOTOR UDYOG PVT. LTD. (VX01-01-), KHATA NO. 4, Khesra NO. 108, 109, THANA NO. 342, PIPIRAKALA, GARHWA, JHARKHAND - 822114 PH :8862828802 9835507004.
- GHATSHILA**
800. PEBCO MOTORS LTD. (AIA1-01-), PLOT NO. 68, KHASRA NO.128, MAUZA PACRA, NH-33, NEAR FULL-DUNGRI CHOWK,GHATSHILA, EAST SINGHBHUM (JHARKHAND) - 832303 PH :9308433388.
- GIRIDIH**
801. RELIABLE INDUSTRIES (5202-04-), MOHANPUR, PACHAMBA ROAD, GIRIDIH. - 815301 PH :8102924860 8102924858.
802. RELIABLE INDUSTRIES PVT. LTD (5202-08-), PLOT NO. 7, HALKA NO. 12, KHATA NO. 2, THANA NO. 266, MOUZA - CHATRO, GIRIDIH, JHARKHAND . - 815301 PH :9835835101.
- GODDA**
803. RELIABLE INDUSTRIES (5202-05-), ASANBANI CHOWK, MAIN ROAD, GODDA. - 814133 PH :6207129088.
- GUMLA**
804. PREMSONS MOTOR UDYOG PVT. LTD. (5103-04-), VANASTHALI COMPLEX PUGUCHAMPA NAGAR,NH-23,SISAI ROAD,GUMLA . - 835207 PH :9835507004.
- HAZARIBAGH**
805. HINDUSTAN AUTO AGENCY (Y901-01-), NEAR SBI MAIN BRANCH, MAIN ROAD, HAZARIBAGH. - 825301 PH :9304051949, 9263631327.
806. HINDUSTAN AUTO AGENCY (Y901-02-), MASIPIRHI, BABHANBAY, HAZARIBAGH ., JHARKHAND - 825301 PH :9216888118 9263631327..
- JAMSHPEDPUR**
807. PEBCO MOTORS LTD. (3101-01-), MEDIUM SECTOR, INDUSTRIAL AREA, ADITYAPUR, JAMSHEDPUR - 831001 PH :9308433388.
- BALICHALA, CONTRACTORS & GODOWN AREA, SONARI, JAMSHEDPUR - 831011 PH :9308433388.**
808. PEBCO MOTORS LTD. (3101-02-), 16 BALICHALA, CONTRACTORS & GODOWN AREA, SONARI, JAMSHEDPUR - 831011 PH :9308433388.
809. MOTOR WORLD (3102-01-), N.H-33, NEAR PARDHI CHOWK, MANGO, JAMSHEDPUR - 831012 PH :9431347164, 9570168342.
- JAMTARA**
810. RELIABLE INDUSTRIES (BOX1-01-), PLOT NO. 483, PARWAT BIHAR, DUMKA ROAD, JAMTARA, JHARKHAND . - 815351 PH :9835814404.
- KATRAS**
811. CAR ONE (A UNIT OF RAJHANS AUTOMOBILES PRIVATE LIMITED) (GLP1-01-), RAJHANS REFRACTORIES, OPP. LIC OFFICE, RAJGANJ ROAD, KATRAS, DISTT. DHANBAD, JHARKHAND-828114 PH :8910900556.
- KHELARI**
812. SUDHA MOTORS(A UNIT OF SUDHA BUSINESS ENTERPRISES PVT LTD) (CF01-01-), PLOT 113, MOUZA- BUBUKA, BESIDE PAHADI MANDIR, KHELARI, RANCHI - 829205 PH :6458222, 9534199997.
- KHUNTI**
813. PREMSONS MOTOR UDYOG PVT. LTD (BOL1-01-), PLOT NO. 747, KHATA NO. 2, DAHUGUTU, CHAIBASA ROAD, KHUNTI, JHARKHAND . - 835 210 PH :9835507004.
- KODARMA**
814. HINDUSTAN AUTO AGENCY (VR01-01-), AT LALMAN DIGTHU, BESIDE KRISHNA SURYA COLD STORAGE, JHUMRI TILAIYA, P.S. - TILAIYA, DISTRICT – KODERMA, JHARKHAND - 825409 PH :6201998936.
- LOHARDAGA**
815. SUDHA MOTORS(A UNIT OF SUDHA BUSINESS ENTERPRISES PVT LTD) (CX01-01-), PLOT NO. 14P, 15, 23, RIADA, LOHARDAGA, JHARKHAND. - 835302 PH :9534199997.
- MURI**
816. HILLTOP MOTORS (BVE2-01-), NEAR BANK OF INDIA, SILLI MAIN ROAD, MURI, PIN - 835102 - 835102 PH :7061157502.
- PAKUR**

817. RELIABLE (C101-01), CIO KHOKHAN
RAY,HIRANPUR,,PAKUR, MAIN
ROAD,VILL.SAHERKOL,PS PAKUR REGISTRY
OFFICE - 816107
PH :9031096662.
- RAMGARH**
818. HINDUSTAN AUTO AGENCY (AV01-01), MARAR,
RANCHI ROAD (NH-33), RAMGARH - 829122
PH :9263631345.
- RANCHI**
819. PREMSONS MOTORS UDYOG PVT LTD
(5103-01), 502, KANKE ROAD, RANCHI - 834008
PH :9304807355.
820. PREMSONS MOTOR UDYOG PVT. LTD.
(5103-03), 10/P, NAMKUM INDUSTRIAL
ESTATE,BEHIND HIGH TENSION INSULATOR
FACTORY, LOWER CHUTIA, RANCHI - 834010
PH :9262899003.
821. PREMSONS MOTOR UDYOG PVT. LTD.
(5103-05), PLOT NO.31 & 134, JHONSON MORN,
TUPUDANA INDUSTRIAL AREA, TUPUDANA,
RANCHI - 834003
PH :9835507004.
822. SUDHA MOTORS(A UNIT OF SUDHA BUSINESS
ENTERPRISES PVT LTD) (5107-02), PLOT NO.
74, OPPOSITE OTC GROUND, HEHAL, RATU
ROAD, RANCHI, JHARKHAND - 834005
PH :9534199997, 8227996660.
823. SUDHA MOTORS(A UNIT OF SUDHA BUSINESS
ENTERPRISES PVT LTD) (5107-03), PLOT NO.
39, NEAR BOOTY MORE, RANCHI-RAMGARH
ROAD, RANCHI - 835217
PH :9534199997.
824. PREMSONS MOTOR UDYOG PVT. LTD.
(5103-06), PLOT NO.14 (P) KOKAR INDUSTRIAL
AREA KOKAR, RANCHI - 834001
PH :9835507004.
825. HILLTOP MOTORS (A UNIT OF HIRALAL
MOTORS PVT LTD) (5109-01), KHATA NO. 247,
MOUZA - PUNDAG,P.S. - PUNDAG, RANCHI,
JHARKHAND - 834004
PH :7061157502.
826. HILLTOP MOTORS (A UNIT OF HIRALAL
MOTORS PVT LTD) (5109-02), NEAR KATHAL
MORE, ARGORA RANCHI RD, NEAR EKLAPBA
TOWER, DHIPATOLI, ARGORA, RANCHI - 834004
PH :7061157502.
- SIMDEGA**
827. PREMSON (BJ01-01), R,S PLOT NO 4674
UNDER KHATA NO 157, SITUATED AT VILLAGE
- GOTRA, NEAR GOUSHALA, MAIN ROAD,
SIMDEGA, JHARKHAND. - 835223
PH :9835507004.
- KARNATAKA**
- ANEKAL
828. PRATHAM MOTORS PVT. LTD (205-04),
SY#453, KAVAL HOSAHALLI, KASABA HOBLI,
ANEKAL TALUK - 562106
PH :9945540131.
- ANKOLA**
829. BHARATH AUTO CARS PVT. LTD. (FC02-01),
NEAR NARAYANA TEMPLE KAKKAR MUTTA,
BELEGULI CROSS, ANKOLA, UK DISTRICT -
581314
PH :7829567400.
- ATHANI**
830. SHANTESHA MOTORS (BWA1-01), RS NO. 605,
SHIVAGOY NAGAR, BIJAPUR ROAD, ATHANI,
DIST. - BELGAUM. - 591304
PH :8884472587.
- ATHRADI**
831. ABHARAN MOTORS PVT LTD (G601-04),
HERABETTU ROAD ATHARDI UDUPI - 576107
PH :9845472500.
- ATTIBELE**
832. SURAKSHA CAR CARE PVT. LTD. (BM11-01),
SURVY NO.227/8, SARJAPUR MAIN ROAD,
INDIAEBEL VILLAGE, OPP. TO GOLDEN
LIBERTY, ATTIBELE P.O., BANGALORE. - 562107
PH :944985665.
- BAGALKOT**
833. VIJAY MOTOWINGS (ZL01-01), 180/4-2,BELGUM
RAICHUR ROAD,NEAR APCM MARKET YARD,
BAGALKOT - 587103
PH :9481289167.
- BAGEPALLI**
834. BIMAL AUTO AGENCY INDIA PVT. LTD.
(BTV1-01), H.L. NO. 423 AND 436 SRI SATHYA
SAI NAGAR, ON NH-7, THIMAKALAPALLI
BLOCK-II, PARAGODU GRAM PANCHAYATH,
KASABA HOBLI, BAGEPALLI TALUK,
CHIKKABALLAPUR DIST. - 561 207
PH :9742458888.
- BANDHALI**
835. BIMAL AUTO AGENCY INDIA PVT. LTD.
(STB1-01), SURVEY NO: 44/11, TAVARAKERE
VILLAGE, NANDAGUDI HOBLI, BANDHALI,
HOSKOTE TALUK, BANGALORE RURAL DIST,
KARNATAKA- 562122 - 562122
PH :9513 48707.
- BANGALORE**
836. MANDOVI MOTORS PVT LTD. (201-01), 24/4,7TH
MAIN,WILSON GARDENS,BANGALORE - 560027
PH :9945235511.
837. MANDOVI MOTORS PVT LTD. (201-07), 17/A-2&
IND,SUBURB,IND STAGE,
GORANGUTEPALAYA, TUMKUR ROAD,
YESWANTHPUR, BANGALORE - 560022
PH :9945235537.
838. MANDOVI MOTORS PVT LTD. (201-05),
NO.2/106 (NEXT TO KASSIA BLDG.),17TH
CROSS,MAGADI CHORD ROAD EXTN.
VIJAYANAGAR,BANGALORE - 560079
PH :9945235529.
839. RNS MOTORS (7301-03), 2275 TUMKUR ROAD,
GURGUNTEPALYA, YESHWANTPUR,
BANGALORE - 560022
PH :9606933236.
840. BIMAL AUTO AGENCY INDIA PVT. LTD. (218-01),
NO.- 60/3, VENKATALA VILLAGE, YELAHANKA
HOBLI, BANGALORE NORTH TALUK - 560064
PH :9945541034.
841. BIMAL AUTO AGENCY INDIA PVT. LTD. (216-01),
60/2, MAHADEVPURA, WHITE FIELD ROAD,
BANGALORE - 560048
PH :99723 98105.
842. RNS MOTORS (7301-04), HOSUR
ROAD,BOMMANAHALLI MADIVALA
POST,BANGALORE - 560068
PH :9148031412.
843. MANDOVI MOTORS PVT LTD. (201-08), NO. 70
SARAKKI INDUSTRIAL LAYOUT,J.P NAGAR,3RD
PHASE, BANGALORE - 560078
PH :995423552.
844. PRATHAM MOTORS PVT. LTD (205-01), 16,
BALLANDIUR, SARJAPUR RING ROAD,
BANGALORE - 560037
PH :9945540126.
845. BIMAL AUTO AGENCY INDIA PVT. LTD. (216-02),
NO. 69/2, SARAKKI, KANAKAPURA ROAD,
BANGALORE - 560078
PH :9972398139.
846. PRATHAM MOTORS PVT. LTD (205-02),
STHANIKAMS ARCADE, OPP. ST THERESA
HOSPITAL, DR. RAJ KUMAR ROAD, A
BLOCK,RAJAJINAGAR 2 STAGE, BANGALORE -
560010
PH :9900061378.
847. KALYANI MOTORS PVT. LTD. (211-01), MYSORE
ROAD,PANTHARAPALYA,KENGRI
HOBLI,BANGALORE - 583201
PH :9538867078.
848. BIMAL AUTO AGENCY INDIA PVT. LTD. (216-03),
NO.7/1, KALANAAGRAHARA VILLAGE, MOUNT
ST. JOSEPH TRAINING COLLEGE FOR JESUITS
COMPOUND, IIMB POST, BANNERGHATTA RD. ,
BANGALORE - 560076
PH :9845166612.
849. BIMAL AUTO AGENCY INDIA PVT. LTD. (216-04),
6TH CROSS, OFF OLD AIRPORT ROAD, HAL
2ND STAGE POST, BANGALORE - 560038
PH :9972398106.
850. MANDOVI MOTORS PVT LTD. (201-0C), NO 1 TO
5, NAVODAYA HBSC, 4TH STAGE, 4TH MAIN,
RAJAJINAGAR INDUSTRIAL TOWN,
BASAWESHWAR NAGAR - 560044
PH :9945235537.
851. KALYANI MOTORS PVT. LTD. (211-04), 119/1,
11TH CROSS,MALLESHWARARAM,BANGALORE -
560003
PH :9886026519.
852. MANDOVI MOTORS PVT LTD. (201-0D), 6/8,
SHREE GANGA GARDEN, GANGA NILAYA,
HENNUR CROSS, KALYANAGAR POST - 560043
PH :9845132048.
853. MANDOVI MOTORS PVT LTD. (201-0E), SY
NO:26,AMBILIPURA VILLAGE,VATHUR
HOBLI,BANGALORE,EAST TALUK. - 560102
PH :9945235518.
854. MANDOVI MOTORS PVT LTD. (201-9B), PLOT
NO.-2571/1-2, BANNERGHATTA ROAD, N.S.
PALYA, BANGALORE - 560076
PH :9945238559.
855. KALYANI MOTORS PVT. LTD. (213-02), SY.
NO.:58/1A & 61/22, AVALAHALLI, NH-4, K.R.
PURAM, BANGALORE. - 560049
PH :9900037122.
856. SURAKSHA CAR CARE PVT LTD (280-01), 30/3
K AGRAHARA, HOSUR MAIN ROAD,
ELECTRONIC CITY, BANGALORE - 580100
PH :9449865605.
857. KALYANI MOTORS PVT. LTD. (213-03),
NO.129/4, KUNDALAHALLI VILLAGE, OPP. TO
BROOKE FIELD HOSPITAL, BROOKFIELD,
BENGALURU . - 574239
PH :9900038119.
858. SURAKSHA CAR CARE PVT. LTD. (280-02),
#64/1, BOMMANAHALLI, HOSUR MAIN ROAD,
BANGALORE - 560068
PH :9449865635.
859. KALYANI MOTORS PVT. LTD. (213-04),
250/1,BILEKAHALLI, BANNERGHATTA ROAD,
BENGALURUE - 560076
PH :9686445406.
860. BIMAL AUTO AGENCY INDIA PVT. LTD. (218-04),
PLOT NO.37/38, 2ND STAGE, PEENYA
INDUSTRIAL AREA, BANGALORE - 560058
PH :9945237213.
861. RNS MOTORS (7301-0G), 106/7, BELLARY
ROAD, NEAR IOC PETROL BUNK,
AMRUTHAHLI, NEAR HEBBAL FLYOVER,
BENGALURU (KARNATAKA) - 560092
PH :6364884767.
862. PRATHAM MOTORS PVT. LTD (205-05), #58/5
KUDLU VILLAGE, NEXT TO ZEE SCHOOL,
SARJAPUR HOBLI, ANEKAL TALUK,
BANGALORE - 560034
PH :9900058466.
863. RNS MOTORS LIMITED (7301-0H), PLOT
NO.129, KIADB INDUSTRIAL AREA, HEBBAGODI
VILLAGE, BOMMASANDRA, JIGINI LINK ROAD,
BANGALORE - 562158
PH :9538965771.

Dealer Network (AS ON 31.10.2023)

864. KALYANI MOTORS PVT. LTD. (291-02), 10/1, HEBBAL , AMANIKERE KASABA HOBLI, YOGESH NAGAR BANGLORE - 560024
PH :9740988524, 7760983887.
865. BIMAL AUTO AGENCY INDIA PVT. LTD. (286-01), #184/185, OPP. FORUM VALUE MALL, WHITE FIELD MAIN ROAD, BANGALORE - 560066
PH :9900245979.
866. SURAKSHA CAR CARE PVT. LTD. (280-04), PLOT NO. 8 & 9, NEXT TO BDA COMPLEX, 4TH BLOCK, 100 FT ROAD, KORAMANGALA, BANGALORE, KARNATAKA - 560034
PH :8884419010.
867. KALYANI MOTORS PVT. LTD. (287-01), # 10/5, NAGADEVANHALI, KENGERI, MYSORE ROAD, BANGALORE, KARNATAKA - 560056
PH :9900019961.
868. BIMAL AUTO AGENCY INDIA PVT. LTD. (216-06), PLOT NO. 82, DODDA BANASWADI MAIN ROAD, BEHIND IOC PETROL PUMP, NEXT TO AIYAPPA TEMPLE, BANASWADI, BANGALORE, KARNATAKA - 560033
PH :9738501996.
869. MANDOVI MOTORS PVT LTD. (201-0H), BBMP NO. 4C, WARD NO.83, JOLLY ESTATE, OLD MADRAS ROAD, NAGAWARAPALAYA, BANGALORE - 560093
PH :9945235533.
870. VARUN MOTORS PVT. LTD. (292-01), HNO. 72/194 & HNO. 67/2, YESHWANTPUR INDUSTRIAL SUBURB, WARD NO. 10, RAJAJI NAGAR, BANGALORE. - 560022
PH :7337634562.
871. KALYANI MOTORS PVT. LTD. (213-05), PLOT NO. 74/5, HORMAVU MAIN ROAD, NEAR BBMP OFFICE, KR PURAM HOBLI, BANGALORE. - 560043
PH :9900037114.
872. KATARIA AUTOMOBILES PVT. LTD. (294-01), NO. 5, 15TH CROSS, KOLANDAPPA GARDEN, ANEPALYA, POST -AADUGODI, BANGALORE. - 560030
PH :7349291802.
873. MANDOVI MOTORS PVT LTD. (201-01), KATHA NO.4, SITUATED ATGANAKAL DHAKALE, SRINIVASAPURA, KENGERI HOBLLI, UTTARAHALLI, BANGALORE - 560060
PH :9945235516.
874. VARUN MOTORS PVT. LTD. (292-02), BEARING NO. 27/1 & 27/2, SURVEY NO. 41/3 & 42/7 BAGALAGUNTA, HESSARGHATTAA MAIN ROAD, NEAR WIDIA SCHOOL BUS STOP, NAGASANDRA POST, BANGALORE. - 560073
PH :7338286729.
875. MANDOVI MOTORS PVT LTD. (201-0J), SITE NO. 58/1, J.S. KAVAL, MAJOR SANDEEP UNNIKRISHNAN ROAD, VIDYARANYAPURA, BANGALORE. - 560097
PH :9945235514.
876. KATARIA AUTOMOBILES PVT. LTD. (293-01), SURVEY NO. 8/3, 10/4, 10/2, VILLAGE - THALAGHATTPURA, KANAKAPURA MAIN ROAD, NEAR NANDI TOYOTA, UTTARAHALLI HOBLLI, TALUK - BENGALURU SOUTH, BANGALORE, KARNATAKA - 560109
PH :8884434340.
877. RNS MOTORS LIMITED (7301-0J), SY. NO. 11/2 & 12/1, VILLAGE - ARAKERE, BEGUR HOBLLI, BANNERGHATTA ROAD, BANGALORE - 560 076.
- 560076
PH :7760982836.
878. SURAKSHA CAR CARE PVT. LTD. (280-05), SURVEY NO.2/6, BERTENA AGRAHARA, OPP. METRO CASH & CARRY, HOSUR MAIN ROAD, BANGALORE - 560100
PH :8884471200.
879. KALYANI MOTORS PVT. LTD. (211-05), SY.NO.8/4, G.HOSAHALLI MAIN ROAD, GOLLARAHATTI, V.N POST, YESHWANTPURA HOBLLI, MAGADI MAIN ROAD, BANGALORE - 560091
PH :9900080229.
880. SURAKSHA CAR CARE (280-06), BEARING NO. 5/4-32/2, BEGUR HOBLLI, BOMMANAHALLI VILLAGE, BEGUR HOBLLI, BANGALORE, KARNATAKA - 560 068
PH :9449865665.
881. PRATHAM MOTORS PVT. LTD. (205-07), SUVEY NO. 43/1, ON SH-35, VILLAGE - YAMARE, SARJAPUR MAIN ROAD, POST - DOMMASANDRA, TALUKA - ANEKAL, BENGALURU RURAL, KARNATAKA - 562125
PH :9611834569.
882. SURAKSHA CAR CARE PVT. LTD. (280-07), SURVEY NO 10/6/2A, CHANDAPURA MUNICIPAL TOWN,MUTHASANDRA HOSUR MAIN ROAD, ANEKAL TQ, BANGALORE, KARNATAKA - 560099
PH :94498 65666.
883. KALYANI MOTORS (291-03), SURVEY NO. 194/5, HUNSEMARAMAHALLI, JALA HOBLLI, DEVANAHALLI TALUK, (YELAHANKA NEW TALUK) NEW KEMPEGOWDA INTERNATIONAL AIRPORT ROAD, NORTH
PH :9740985324.
884. MANDOVI MOTORS (201-09), MUNICIPAL NO. 133 (OLD NO S 133 & 133/1), BULL TEMPLE ROAD, BBMP WARD NO. 49, K G NAGAR, BANGALORE, KARNATAKA-560018. - 560018
PH :9945235516.
- BANGALORE (HEBBAGODI)**
885. RNS MOTORS (210-01), SURVEY NO. 48, HEBBAGODI, HOSUR MAIN ROAD,ANEKAL TALUK, BANGALORE URBAN DIST, KARNATAKA - 560 099
PH :8366938229.
- BANGALORE - KP ROAD**
886. KALYANI MOTORS (213-06), SURVEY NO. 67, NH-209, NAVARATNA GARDENS, (NEAR IOCL PETROL BUNK) DODDAKALASANDRA VILL., UTTARAHALLI HOBLLI, KONAKUNTE, KANAKAPURA-KENGERI ROAD, BANGALORE, KARNATAKA - 560062
PH :9900039844/9900073254.
- BANGARPET**
887. SURAKSHA CAR CARE PVT. LTD. (0R04-01-), 180/4 OPP. APMC YARD, KOLAR-BANGARPET ROAD, BANGARPET (KARNATAKA) - 563114
PH :9449865601.
- BANGLORE - BOMMANAHALLI**
888. VARUN MOTORS PVT LTD (292-03), SY NO: 136 (OLD NO 54/8) SANGEEGURUVANAHALLI(VP) KAMAKSHIPALAYA, WARD NO: 17, VRISHABHAVATHI NAGAR, MAGADI ROAD, BANGALORE NORTH THALUK, BANGALORE,KARNATAKA - 560079
PH :9513683052.
- BANTWAL**
889. MANDOVI MOTORS PVT LTD. (TR01-01), NH-75, PANEMANGALORE, B.C. ROAD, BANTWAL, KARANATAKA - 574231
PH :9008810123.
- BELGAUM**
890. SHANTESA MOTOR (P) LTD (E801-01), MUJAWAR COMPOUND,NEHRU NAGAR,BELGAUM , - 590010
PH :9902043711.
891. SHANTESA MOTOR (P) LTD (E801-04), PLOT NO. 8, SURVEY NO. 251/1, HAVALK ROAD CAMP, BELGAUM - 290010
PH :9588645387.
892. SHANTESA MOTOR (P) LTD (F801-03), PLOT NO. 39, RS NO. 670, CTS NO. 16/12/3, KHANAPUR ROAD, UDAYMBA, BELGAUM (SCREE SHOT ATTACHED) - 590006
PH :8884433911.
893. SHANTESA MOTORS (P) LTD (E801-06), PLOT NO. 2/1, RS NO. 29, KIADB INDUSTRIAL AREA, KIADB BAUXITE ROAD, KANGRALI BK, BELGAUM , - 590010
PH :9731396805.
- BELLARY**
894. K.P.F. PVT. LTD. (G201-01), P.B. NO. 58,BELLARY HOSPET ROAD,ALLIPURA,BELLARY - 583101
PH :9449876025.
- BELTHANGADY**
895. BHARATH AUTO CARS PVT. LTD. (4503-04-), MAIN ROAD, BELTHANGADY, BELTHANGADY TALUK DK DISTRICT - 574214
PH :9886543230.
- BHADRAWATI**
896. SHRUTI MOTORS (FB01-01-), SURVEY NO. 18/4, BH ROAD,KADADAKATTE HOBLLI, KADADAKATTE, BHADRAVATI, SHIMOGA DIST., KARNATAKA - 577229
PH :7899885404.
- BHATKAL**
897. BHARATH AUTO CARS PVT. LTD. (CEF01-01-), SURVEY NO. 157/2A, SUSGADI VILLAGE, NH66, BHATKAL, UTTARKANNADA DISTRICT, KARNATAKA - 581320
PH :9008693940.
- BIDAR**
898. LAHOTI MOTORS PVT. LTD (EX01-01-), SI 50/51,PRATAP NAGAR, UDGRIR ROAD, KIADB INDUSTRIAL AREA, NAUBAD, BIDAR - 585402
PH :8884412049.
899. LAHOTI MOTORS PVT. LTD (EX01-02-), PLOT NO. 58, NAUBAD INDUSTRIAL AREA, PRATAP NAGAR, BIDAR. - 585 401
PH :9108707709.
- BIJAPUR**
900. RNS MOTORS (7301-0L), SURVEY NO.25K1, CHITRADURGA SHOLAPUR ROAD, VIJAYPURA, BIJAPUR DISTT. KARNATAKA - 586109
PH :8861209988.
- BUDHIGERE**
901. BIMAL (SGM1-01), KHATTA NO:115,SY. NO. 12/33, MANDUR MAIN ROAD, BUDIGERE CROSS, MANDUR VILLAGE, NEXT TO IOC PETROL BUNK, BANGALORE EAST TALUK, BANGALORE . - 560049
PH :9742259528.
- BYNDOR**
902. ABHARAN MOTORS PVT LTD (BUH1-01-), 3-256 & 3-257, SOUPARNIKA COMPLEX, NH 66, VILLAGE - YEATHATRE, BYNDOR, KUNDAPUR TALUK, UDUPI DISTT. - 576214
PH :7899751777.
- CHALLAKERE**
903. SAKETH AUTOMOBILES (CKN1-01-), SITE NO. 9 & 10, SY. NO. 96/1, OPP. SUJIMALLESHWARA NAGAR, BELLARY ROAD, CHALLAKERE. - 577522
PH :9686550126.
- CHAMARAJANAGAR**
904. MANDOVI MOTORS PVT LTD. (0E01-01-), RAJ KAMAL BUILDING, SATHYAMANGALA ROAD, KUVEMPU Extension, CHAMRAJANAGAR (KARNATAKA) - 571313
PH :9845445586.
- CHANNAGIRI**

905. SHRUTI MOTORS (BUQ1-01), SURVEY NO.5, MACHANAYAKANAHALLI, OPP. FIRE STATION, CHITRADURGA ROAD, N.H.13, CHANNAGIRI DISTT. DAVANGERE - 577213
PH :7899934143.
- CHANNAPATNA**
906. KALYANI MOTORS PVT. LTD. (BSX1-01), PROPERTY NO.58, MALUR GRAMA, MALLUR HOBLI, CHANNAPATNA TALUKA RAMANAGARA DISTRICT - 562160
PH :9845066682.
- CHANNARAYAPATNA**
907. VENKAT MOTORS (HC01-01), PLOT NO. 389, 36/3, 132/1, BESIDES THIRUMALA RICE MILL, MYSORE ROAD, CHANNARAYAPATNA, DISTRICT: HASSAN, KARNATAKA - 573116
PH :8147077144.
- CHICKBALLAPUR**
908. BIMAL AUTO AGENCY INDIA PVT. LTD. (KJ02-01), NO. 169/1, AMMANI KANDAVAKARE VILLAGE, KASABA HOBLI, CHIKBALLAPURA DISTRICT - 562101
PH :974226499.
- CHICKMAGALUR**
909. SHRUTI MOTORS (B701-02), AIT CIRCLE, KM ROAD, CHIKMAGALUR - 577102
PH :9980157446.
- CHIKODI**
910. SHANTESHA MOTORS (E801-05), OPP. IOC PUMP, NEAR B.K.COLLEGE, MIRAJ ROAD, CHIKKODI, KARNATAKA - 591201
PH :7829925790.
- CHINTAMANI**
911. PRATHAM MOTORS PVT. LTD. (205-06-), SURVEY NO. 33, NEXT TO VIJAYA PU COLLEGE, OPP. GOPASANDRA LAKE, SREENIVASUPURA MAIN ROAD, CHINTAMANI, KARNATAKA - 563125
PH :7899761301.
- CHITRADURGA**
912. SAKETH AUTOMOBILES (AL01-01), NEAR VEDA COMPLEX, NH-4, M H ROAD, CHITRADURGA - 572130
PH :9686550313.
- DAVANGERE**
913. SHRUTI MOTORS (S101-01), NEAR PANCHDEVASTHANA, P. B. ROAD, DAVANGERE, KARNATAKA - 577004
PH :9880401284.
- DAVENGERE**
914. SHRUTI MOTORS (S101-02), DOOR NO. 473/1, SURVEY NO. 18/1, BESIDE GMIT COLLEGE, OPP. M&M SHOWROOM, OLD P. B. ROAD, DAVANGERE, KARNATAKA - 577001
PH :9880401284.
- DEVANAHALLI**
915. BIMAL AUTO AGENCY INDIA PVT. LTD. (WH01-01), SURVEY NO.24/1/146, 11TH WARD, BB ROAD, DEVANAHALLI, BANGALORE DISTT: - 562110
PH :9742262514.
- DHARWAD**
916. REVANKAR MOTORS PVT. LTD. (BIX1-01-), SURVEY NO.1, PLOT NO. 10, OLD PB ROAD, OPP. KVG KALYAN, SAYDAPUR VILLAGE, DHARWAD, KARNATAKA - 580001
PH :8861006707.
- DODDABALLAPUR**
917. PRATHAM MOTORS PVT. LTD. (BUA1-01-), PLOT NO. 50, ADEBANAHALLI INDUSTRIAL AREA, DODDABALLAPUR 3RD PHASE, SY. NO. 107, AREHALI GUDDADAHALLI, KASABA HOBLI TALUK - DODDABALLAPUR, DISTRICT - BENGALURU RURAL - 561203
PH :9886671687.
- GADAG**
918. RNS MOTORS (7301-05-), PLOT NO. 64, DIAGONALLY OPP. REGIONAL TRANSPORT OFFICE, HUBLI GADAG MAIN ROAD, GADAG - 582103
PH :9538925602.
- GANGAVATI**
919. MUNEER ENTERPRISES PVT. LTD. (N701-03-), JAGANMATHA COMPLEX,RAICHUR ROAD,GANGAVATI, - 583227
PH :9449870754.
- GAURIBIDANUR**
920. MANDOVI MOTORS PVT LTD. (BUY1-01-), NO.59/2/22, E DIVISION, OPP. PUSHPANJALI TALKIES, B.H. ROAD, GAURIBIDANUR TOWN, DISTT. CHIKBALLAPUR - 561210
PH :8217453513.
- GOKAK**
921. SHANTESHA MOTORS PVT. LTD. (IR01-01-), RS NO.106/3D/2A, APMC ROAD, GOKAK, BELGAUM DISTT. - 591307
PH :7829925760.
- GONIKOPPAL**
922. MANDOVI MOTORS PVT LTD. (2501-07-), KAICKERY VILLAGE,GONIKOPPAL,.. - 571213
PH :990064873.
- GUDIBANDHA**
923. BIMAL AUTO AGENCY INDIA PVT. LTD. (SGT1-01-), DOOR NO:160, 1ST WARD, OPP TO GOVERNMENT BUS STAND, BAGEPALLI ROAD, GUDIBANDA, CHICKBALLAPURA DISTRICT KARNATAKA - 561209
PH :9742261903.
- GULBARGA**
924. LAHOTI MOTORS PVT. LTD (E902-01-), LAHOTI GARDENS,Near KMF, HUMNABAD ROAD,GULBARGA - 585104
PH :9480825014.
925. LAHOTI MOTORS PVT. LTD (E902-02-), DOOR NO. 7-12-11, 2ND BLOCK, OPP. GUNJ BUS STAND, HUMNABAD ROAD, GULBARGA, KARNATAKA - 585104
PH :7619342035.
- GUNDLUPET**
926. KALYANI MOTORS PVT. LTD (BPU2-01-), ASSESSMENT NO. 2491/S. NO. 51/1, 2, 3, N.S. 11 AND ASSESSMENT NO. 2494/S. NO. 51/1 N.S. 11, MYSORE-OOTY ROAD, GUNDLUPET. - 571111
PH :9686855799.
- HAGARIBOMANAHALLI**
927. MUNEER ENTERPRISES PVT. LTD. (BUX1-01-), SITE NO.112A2 & 112A3, BLOCK NO.2, WARD NO.3, HAGARIBOMANAHALLI PANCHAYAT, BELLARY DISTRICT. - 583212
PH :9481343007.
- HALIYAL**
928. RNS MOTORS (SFM1-01-), SURVEY NO: 347P/27, DOOR NO:B1180/15 & B1180/16, HANUMAN COMPLEX, HALIYAL CIRCLE, MAIN ROAD, HALIYAL TOWN & TALUK, UTTARA KANNADA DISTRICT,KARNATAKA - 581329
PH :8284200200.
- HARAHOLI**
929. SURAKSHA (SIH1-01-), SURVEY NO. 40/4, HOSKOTE VILLAGE, HAROHALLI HOBLI, KANAKAPURA TALUK, RAMANAGARA, - 562112
PH :9449865608.
- HASSAN**
930. VENKAT MOTORS (C802-01-), NO. 326, HASSAN GROWTH CENTRE, H.N. PURA ROAD, HASSAN - 573201
PH :9844044038.
- HAVERI**
931. REVANKAR MOTORS PVT LTD (BBM1-01-), NEAR TMAE SOCIETY CAMPUS, UJARILAKAMAPUR, PB ROAD, HAVERI - 581110
PH :7022016903.
- H-CROSS**
932. BIMAL AUTO AGENCY INDIA PVT. LTD. (CRG1-01-), PART NO.1, SITE NO.36, SBT COMPLEX, HOSKOTE-BANGALORE ROAD, KARIYANAPURA, H CROSS, SHIDLAGHATTA TALUK, BANGALORE RURAL DISTT. CHIKKABALLAPURA - 562122
PH :9738948126.
- HEBRI**
933. ABHARAN MOTORS PVT LTD (BGD1-01-), SURVEY NO. 61-7C1P & 61-2P1, VILLAGE & TALUK - HEBRI, KARKALA, DIST.-UDUPI, KARNATAKA - 576112
PH :9900077605.
- HEGGADADEVANA KOTE (H D KOTE)**
934. KALYANI MOTORS PVT. LTD (CJC2-01-), SURVEY NO. 54, VILLAGE - YARAHALLI, KASABA HOBLI, TALUK - H.D.KOTE, DISTRICT - MYSORE. - 571125
PH :9686855799.
- HESSARGHATHA**
935. BIMAL (SGN1-01), SY NO 294/3 HESARAGHATTA VILLAGE YELAHANKA TALUK, BENGALURU,KARNATAKA - 560088
PH :9743658662.
- HOSDURGA**
936. SAKETH AUTOMOBILES (BWO1-01-), ASSESSMENT NO. 9310/6, PLOT NO. 6, HOSADURGA TOWN, SARASWATI BADAVANE, HOSADURGA, DIST.-CHITRADURGA, KARNATAKA - 577 527
PH :7625088946.
- HOSKOTE**
937. BIMAL AUTO AGENCY INDIA PVT. LTD. (216-05-), NO. 205/108, SITUATED AT HOSKOTE TALUK, KASABA HOSKOTE TOWN, DISTT.- BANGALORE - 562114
PH :9742281726.
- HOSPET**
938. MUNEER ENTERPRISES PVT. LTD. (N701-01-), BELLARY ROAD,SANKLAPUR,HOSPET , - 583203
PH :7619505001.
- HUBLI**
939. RNS MOTORS (7301-01-), PUNE - BANGALOR ROAD, UNKAL, HUBLI - 580025
PH :9538965902.
940. RNS MOTORS (7301-0F-), GOKUL ROAD MUREDESHWAR BHAVAN, HUBLI - 580030
PH :8891208532.
941. REVANKAR MOTORS PVT. LTD. (7303-01-), CTS NO.165/A, WARD NO.III, DESHPANDE NAGAR, HUBLI (KARNATAKA) - 580029
PH :8792008301.
- HUNSUR**

Dealer Network (AS ON 31.10.2023)

942. KALYANI MOTORS PVT. LTD (GLI2-01), M-18 & M-19, KSSIDC INDUSTRIAL ESTATE, BM BYPASS ROAD, HUNSRU, MYSORE DISTRICT, KARNATAKA - 571105
PH :9722669699.

JEWARGI

943. LAHOTI (SLI-01-), S NO: 125, PLOT NO:7, FILTER BED ROAD, OPP. BUS DEPOT, JEWARGI, KALABURGI DISTRICT (FORMERLY GULABARGA), KARNATAK-585310 - 585310 PH :9480825004.

KADABA

944. MANDOVI MOTORS PVT LTD. (BYE-1-01), SURVEY NO.-1120, KALAR, KADABA POST, DAKSHIN KANNADA DISTT., KARNATAKA - 574221
PH :9740912365.

KADUR

945. SHRUTI MOTORS (BQS1-01), SHOP NO. 1 & 2, DAGA COMPLEX, ULUKINAKALLU, NEAR PEARLS CLUB, B.H. ROAD, KADUR, DISTRICT – CHIKMAGALUR. - 577548
PH :8904823736.

KANAKAPURA

946. KALYANI MOTORS PVT. LTD. (BXV1-01-), SURVEY NO. 447/1B, KASABA HOBIL, BUDIGUPPE GRAMA, TALUKA- KANAKAPURA, DISTRICT- RAMANAGARA: KARNATAKA. - 562117
PH :9900599933.

KARKALA

947. ABHARAN MOTORS PVT LTD (G601-03-), NH-13, MANGALORE KUDREMUKH ROAD, PULKERI, KARKALA - 574104
PH :9880232666.

KARWAR

948. BHARATH AUTO CARS PVT. LTD. (8J01-01-), SURVEY NO. 459/2B, 456/2B AND 456/3, CHITTAKULA VILLAGE, KARWAR TALUKA, UTTARKANNADA DISTRICT, KARNATAKA. - 581301
PH :7829567400.

KITTUR, BELGAUM

949. SHANTESA (SFO1-01-), PLOT NO. 219, KITTUR INDUSTRIAL AREA (KIADB), POONA BANGALORE HIGHWAY (NH-4), KITTUR TOWN AND TALUK, BELGAUM DISTRICT, - 591115
PH :9731396808.

KOLAR

950. MANDOVI MOTORS PVT LTD. (201-0F-), 67/3 BANGALORE-CHENNAI HIGHWAY, KONDARAJANA HALLI, OPP HOTEL SHANTHI SAGAR, KOLAR. - 563101
PH :9740020734.

KOPPAL

951. K.P.F. PVT. LTD. (ER01-01-), SL. 283/10, NEAR MINI VIDHAN SOUDHA, KOPPAL HOSPET ROAD NH63, KOPPAL - 583238
PH :9449876027.

KRISHNARAJANAGARA (KRNAGARA)

952. KALYANI MOTORS PVT. LTD (SC02-01-), NO:D, DORNATHALLI,DODDEKOPPALU GRAMA PANCHAYAT,KASABA HOBLI, KRISHNARAJANAGARA, MYSORE DISTRICT, KARNATAKA - 571602
PH :8971159430.

KRISHNARAJAPET

953. MANDOVI MOTORS PVT LTD. (BMP1-01-), KHATA NO.3094, SY. NO.278, MYSORE CHENNERAYAPATNA ROAD (OPP. TO K.B.C. FUEL STATION), KRISHNARAJAPET TOWN, TALUK MANDYA DISTT. KARNATAKA - 571423
PH :9845132038.

KUMTA

954. BHARATH AUTO CARS PVT. LTD. (AF4-02-1), MALLYA'S COMPOUND, NH-66, ALVEKODI KALBAGH VILLAGE, KUMTA (KARNATAKA) - 581334
PH :9448979530.

KUNDAPUR

955. ABHARAN MOTORS PVT LTD (G601-02-), NH-17, THAKKATTE, KUNDAPURA - 272877
PH :9880197524.

KUNIGAL

956. SAKETH AUTOMOBILES (VQ01-01-), NEAR KRS AGRAHARAM B ROAD, KUNIGAL, TUMKUR DISTRICT, KARNATAKA - 572130
PH :9686550127.

KUSHAL NAGAR

957. MANDOVI MOTORS PVT LTD. (VN01-01-), SY NO:88,MADAPATANA,KUSHAL NAGAR,SOMVARPUR,NORTH KODAGU, KARNATAKA - 571234
PH :9900080893.

LINGASUGUR

958. MUNEER ENTERPRISES PVT. LTD. (BO01-01-), PLOT NO. 11, BASAMMA COMPLEX, RAICHUR ROAD, LINGSUGUR, RAICHUR, KARNATAKA - 584122
PH :9480830255.

MADDUR

959. MANDOVI MOTORS PVT LTD. (BMK1-01-), SURVEY NO. 802/A4B, NEAR SANJAY THEATRE, BM ROAD, MADDUR TOWN,MANDYA DISTRICT, KARNATAKA - 571428
PH :90080 31608.

MADIKERI

960. KALYANI MOTORS PVT. LTD (QX02-01-), BASAPPA THEATRE BUILDING, DASAWAL ROAD, MADIKERI KODAGU DISTRICT. - 571201
PH :9606073867.

MAGADI

961. PRATHAM MOTORS PVT. LTD. (BHX1-01-), SY NO:92/2, THIRUMALAI VILLAGE, KASABA HOBLI, MAGADI TOWN & TALUK, RAMANAGARA DISTRICT, KARNATAKA - 562120
PH :9900058483.

MANCHEНАHALЛИ

962. VARUN MOTORS (SRU1-01-), NO:1219,GOLAPPA COMPOUND, MAHESHWARI CIRCLE, MANCHEНАHALЛИ, GOWRIBIDANUR TALUK, CHIKKABALLAPUR DIST, KARNATAKA- 561211 - 561211
PH :9513979162.

MANDYA

963. MANDOVI MOTORS PVT LTD. (2501-06-), 1660/A, KALLAHALLI EXTENSION, M.C. ROAD, - 571401
PH :9611165873.

MANGALORE

964. MANDOVI MOTORS PVT LTD. (4502-01-), ARVIND BUILDING, BALMATTIA ROAD, HAMPANKATT, MANGALORE - 575001
PH :9845107701.

965. BHARATH AUTO CARS PVT. LTD. (4503-01-), NH-17, KUNTIKAN JUNCTION, DEREBAIL, NEAR A.J. HOSPITAL, MANGALORE - 575004
PH :9886785730.

966. MANDOVI MOTORS PVT LTD. (4502-03-), NO., HASSAN GROWTH CENTRE,ADYAR,N.H. -48, MANGALORE - 575007
PH :9845514146.

967. MANDOVI MOTORS PVT LTD. (4502-07-), BALLAL INDUSTRIAL ESTATE, YAYYADI, MANGALORE-KARNATAKA - 575008
PH :9880079235.

968. BHARATH AUTO CARS PVT. LTD. (4503-06-), PLOT NO. 290/1, 291/1, KODIALBALI VILLAGE, NEXT TO BHARATH BEEDI WORKS PVT. LTD., BUNTS HOSTEL, KADRI ROAD, MANGALORE, KARNATAKA - 575002
PH :9886333030.

969. MANDOVI MOTORS PVT LTD. (4502-08-), DOOR NO. 2-6/34, SUJITH BAGH LANE, YEYYADE, MANGALORE, DISTRICT – DAKSHINA KANNADA, KARNATAKA - 575008
PH :9880278077.

970. BHARATH AUTO CARS PVT. LTD. (4503-08-), S. NO. 1376/1-41, 1375/41-2-A1P1, ZA1P3, 1373/1-40, 1369/1-A2, KASABA BAZAR, KANDADAPALLI, KUDROLI, TALUK - MANGALORE, MANGALORE, KARNATAKA - 575003
PH :9886785730.

MUDBIDRI

971. BHARATH AUTO CARS PVT. LTD. (4503-03-), BHARATH BEEDI COMPOUND, NEAR ALVAR'S HOSPITAL, MOODBDI - 574227
PH :9886785430.

MUDHOL

972. VIJAY MOTOWINGS (ET01-01-), PLOT NO. 3B, IN NARS NO. 15-2, WARD NO. 5, VISHWESHWAR COLONY, LOKAPUR ROAD, MUDHOL TOWN, BAGALKOT DIST. - 587 313
PH :9606046173.

MULKI

973. BHARATH AUTO CARS PVT. LTD. (4503-05-), BHARATH BEEDI COMPOUND, NH-17 MULKI - 574154
PH :9986020730.

MURUDESHWAR

974. RNS MOTORS (7301-02-), NH-17, MANGALORE-BOMBAY ROAD, MURUDESHWAR, KARNATAKA - 581350
PH :9538965969.

mysore

975. MANDOVI MOTORS PVT LTD. (2501-01-), NO: 5 K.R.S.ROAD, MYSORE - 570005
PH :9945248860.

976. MANDOVI MOTORS PVT LTD. (2501-05-), NO.182/145C, BANNUR ROAD, SIDHARTHA NAGAR, MYSORE, KARNATAKA - 570011
PH :9845393936.

977. KALYANI MOTORS PVT. LTD (2503-01-), MANATHAVADI ROAD, VIDYARANYA PURAM, MYSORE - 570008
PH :7259225558.

978. MANDOVI MOTORS PVT LTD. (2501-08-), 217/2, HUNSUR ROAD, HINKAL POST, MYSORE, KARNATAKA - 570017
PH :9845393937.

NAGAMANGALA

979. MANDOVI MOTORS PVT LTD (SFK1-01-), SURVEY NO:3316/2327,VISHALAHAMMA COMPLEX, T B BADAVANE B M ROAD, NAGAMANGALA TOWN, MANDYA DISTRICT, KARNATAKA - 571432
PH :9845132038.

NANJANGUD

980. MANDOVI MOTORS PVT LTD (SFK1-01-), 4340/4159/4, HULLAHALLI ROAD, NANJANGUD, DISTRICT – MYSORE, KARNATAKA. - 571301
PH :9668655799.

NARASIMHARAJAPURA

981. SHRUTI MOTORS (SP1-01-), SURVEY NO # SURVEY NO.173/P KOPPA ROAD, NAGALAPURA VILLAGE,NARASIMHARAJAPURA, CHIKMAGALU R DIST., KARNATAKA - 577134
PH :8310187660.

- NARAVI**
982. MANDOVI MOTORS (SRS1-01), SURVEY NO:122/B1/DOOR NO:4/59,SHRI CHAITANYA , ARASAKATTE, NARAVI, BELTHANGADY TALUK, DAKSHINA KANNADA DIST, KARNATAKA- 574109. - 574109
PH :9740392005.
- NELAMANGALA**
983. RNS MOTORS LIMITED (BBH1-01), NO.167/2, TUMKUR ROAD, KASABA HOBLI, NH4, NELAMANGALA, BANGALORE RURAL DT., BENGALURU, KARNATAKA - 562123 PH :7259875385.
- NELYADI**
984. BHARATH AUTO CARS PVT. LTD. (BPF1-01), SURVEY NO. 97/11P AND SURVEY NO. 97/9, VILLAGE - HOSAMAJALU KAUKRADY, POST - NELYADI, TALUK - PUTTUR, DIST.-DAKSHIN KANNADA . - 574229
PH :9886072730.
- ORGAMPET**
985. BIMAL AUTO AGENCY (SRJ1-01), SITE NO:10, NEW KATHA NO. 251, ROBERTSONPET, KGF, ORGAMPET, KOLAR DIST, KARNATAKA- 563122 - 563122
PH :9513748707.
- PADUBIDRI**
986. ABHARAN MOTORS PVT LTD (CS1-01), PLOT NO. 51/20, VILLAGE – PADUBETTU, PADUBIDRI TOWN, TALUKA & DISTRICT – UDUPI, KARNATAKA . - 574111
PH :9880232999.
- PERESANDRA**
987. BIMAL AUTO AGENCY INDIA PVT. LTD (SMU1-01), SURVEY NO # NO.39.NO:113, SAMRUDHI NILAYA GROUND FLOOR, NH7, ARURU VILLAGE, PERESANDRA, CHIKKABALLAPUR DISTRICT, KARNATAKA- 562104 - 562104
PH :8660799820.
- PUTTUR**
988. BHARATH AUTO CARS PVT. LTD. (4503-02), NEAR RAIWAY STATION, HARADY, PUTTUR - 517583
PH :9886072730.
- RAICHUR**
989. MUNEER ENTERPRISES PVT. LTD. (N701-02), #12-10-64, GOUSHAL ROAD,SIYA TALAB AREA,RAICHUR . - 584101
PH :940830264.
- RAJANUKUNTE**
990. VARUN MOTORS (SLE1-01), SURVEY NO. 3/1, SITE NO. 6 , SINGANAYAKANAHALLI, RAJANKUNTE, BANGALORE NORTH TALUK, BANGALORE URBAN, KARNATAKA - 560064 PH :9513979162.
- RAMANAGARAM**
991. KALYANI MOTORS PVT. LTD. (211-02), #K1318/2034C,OPP TO ROTARY HOSPITAL,BM ROAD, RAMNAGARAM - 571511 PH :9686689907.
- RANEBNENNUR**
992. REVANKAR MOTORS (BXV1-01), SCHEDULE A-2, OPP. STUTI ENGINEERING COLLEGE, P B ROAD, RANEBNENNUR, KARNATAKA - 581115 PH :8830947883.
- SAGAR**
993. SHRUTI MOTORS (WF01-01), BESIDE HGANAPATHYAPPA PETROL BUNK (BP), B H ROAD, NH-206, SAGAR, SHIMOGA DISTT. - 577401 PH :9740014703.
- SAKLESHPUR**
994. VENKAT MOTORS (BPW1-01), SITE NO. 19, 3RD WARD, SARBATHWIPURAM, SAKLESHPUR TOWN, DISTRICT – HASSAN. - 573134 PH :7892809634.
- SARJAPURA**
995. PRATHAM MOTORS PVT. LTD. (BSY1-01), SURVEY NO. 4763, SARJAPUR TOWN, TALUKA – ANEKAL, SARJAPUR HOBLI, DISTRICT – BANGALORE URBAN, KARNATAKA . - 562125 PH :7760962890.
- SHIMOGA**
996. SHRUTI MOTORS (B701-01), K.NO 599, SHANKARMUTH ROAD, SHIMOGA - 577201 PH :9880401283.
997. SHRUTI MOTORS (B701-03), BLOCK L-1, INDUSTRIAL ESTATE, BEHIND HP PETROL BUNK, SAGR ROAD, SHIMOGA . - 577204 PH :9886829239.
998. SHRUTI MOTORS (B701-05), SURVEY NO. 41/3 & 41/4, HONNALI ROAD, SHANTHI NAGAR, SHIMOGA . - 577201 PH :9986825115.
- SIDDAPUR**
999. BHARATH AUTO CARS PVT. LTD. (BPY1-01), SURVEY NO.211, NEAR IOC PETROL BUNK, JOG ROAD, VILLAGE – HOSUR, TALUK – SIDDAPUR, DISTRICT – UTTARA KANNADA. - 581355 PH :9449402730.
- SIRISI**
1000. RNS MOTORS LTD (MQ01-01), SURVEY NO 43/B, LANDAKANALLI VILLAGE, DODNALLI GRAMA, TALUK AND HOROBALI, UTTAR KANNADA, KARNATAKA - 581402 PH :9895979023.
- SIRSI**
1001. RNS MOTORS (7301-0D), K H B COLONY, SIRSI - 581402 PH :9538925606.
- SIRUGUPPA**
1002. MUNEER ENTERPRISES PVT. LTD. (CTN1-01), SITE NO.31C/1B & PLOT NO.1, BELLARY - SIRUGUPPA MAIN ROAD, SIRUGUPPA TALUK, BELLARY DISTRICT . - 583121 PH :7619505001.
- SOMWARPET**
1003. MANDOVI MOTORS PVT LTD. (CSG1-01), SURVEY NO.130 SITUATED AT MADIKERI ROAD, NAGROOR VILLAGE, BALAGUNDU POST, SOMWARPET TALUK, NORTH KODAGU DISTT. - 571236 PH :9845115665.
- SRINIVASAPURA**
1004. SURAKSHAA CAR CARE PVT. LTD. (BUR1-01), SY NO. 40, VPRD NO. 86, PROPERTY NO. 84 & 87, CHALIDAGHANA HALLI GRAMA PANCHAYATH, PANNASAMAKANA HALLI VILLAGE, SRINIVASAPURA POST & TALUK, DIST.-KOLAR, KARNATAKA - 563 135 PH :9449865601.
- SULLIYA**
1005. MANDOVI MOTORS PVT LTD. (4502-04), ODABAI SULLIA, MANGALORE MYSORE ROAD,KARNATAKA - 574239 PH :9900002325.
- SURATHKAL**
1006. MANDOVI MOTORS PVT LTD. (4502-02), KANA ROAD, SURATHKAL - 574158 PH :9845514143.
- T. NARASIPURA**
1007. MANDOVI MOTORS (SFL1-01), KHATA NO:472473/474, OPP TO SRI RAGHAVENDRA SWAMY Mutt, CHAMARAJANAGAR ROAD, T. NARASIPURA TOWN, MYSORE DISTRICT, KARNATAKA - 571124 PH :9845132038.
- TEKAL**
1008. PRATHAM MOTORS PVT. LTD. (SUE1-01), SURVEY NO: 12, NEAR NANJUNDESHWARA PETROL BUNK, MALUR ROAD, K G HALLI, TEKAL HOBLI, KOLAR DIST., KARNATAKA-563137 - 563137 PH :9900058466.
- THIRTHAHALLI**
1009. SHRUTI MOTORS (BGR1-01), PLOT NO. 1507/2187, OPP. TO HEGDE PETROL PUMP, AGUMBE ROAD, THIRTHAHALLI . - 577432 PH :7795851011.
- THOKOTU**
1010. BHARATH AUTO CARS PVT. LTD. (QW01-01), NH-66, KAPIKAD, ULLAL,THOKOTTU, DAKSHINA KANNADA DISTT. - 575017 PH :9538796330.
- TIPTUR**
1011. SAKETH AUTOMOBILES (H101-03), BANDIHALLI INDUSTRIAL ESTATE, N.H.:206, TIPTUR, KARNATAKA - 572201 PH :9945301023.
- TUMKUR**
1012. SAKETH AUTOMOBILES (H101-01), SIRA ROAD, TUMKUR . - 572106 PH :9686550323.
- UDUPI**
1013. ABHARAN MOTORS PVT LTD (G601-01), N.H. 17, NITTUR, UDUPI . - 576103 PH :9880232999.
1014. ABHARAN MOTORS PVT LTD (G601-05), NO. 305/C, DOOR NO. 5/51A, RAILWAY STATION ROAD, INDRALI, UDUPI, DISTT. - UDUPI . - 576101 PH :9686694341.
- UJIRE**
1015. BHARATH AUTO CARS PVT. LTD. (BWT1-01), SURVEY NO.237-281, MANGALORE-CHARMADY ROAD, NEAR INDIAN OIL PETROL PUMP, SAMPIGE NAGAR, UJIRE, BELTHANGADY TALUKA, DISTT. DAKSHINA KANNADA, KARNATAKA . - 574240 PH :9886176130.
- UPPINANGADI**
1016. MANDOVI MOTORS PVT LTD. (4502-05), NR.PADMA VIDYA IOC PETROL STATION-34, NEKKILADY, UPPINANGADY . - 574241 PH :9740912365.
- VIJAYPURA**
1017. BIMAL AUTO AGENCY (BTZ1-01), DOOR NO 563, MARUTHI NAGAR, CHIKKABALLAPUR ROAD, VIJAYAPURA TOWN, DEVANAHalli TALUK, BANGALORE RURAL DISTRICT KARNATAKA . - 562135 PH :8884433996.
- VITTEL**
1018. MANDOVI MOTORS PVT LTD. (CCE1-01), DOOR NO. 1-287 (9), JISHAN COMPLEX, VITTEL TOWN, TALUKKA - BANTWAL, DISTRICT – DAKSHIN KANNADA . - 574243 PH :9008810123.
- YADGIR**

Dealer Network (AS ON 31.10.2023)

1019. LAHOTI MOTORS (SFP1-01), SURVEY NO. 101/1, GULSARAM VILLAGE, YADGIR TOWN & DISTT., SHAHPUR TALUKA, KARNATAKA & PH :9480825031.

YELLAPUR

1020. REVANKAR MOTORS PVT. LTD (CUR1-01-), PLOT NO. 4 A1A1A1 GR 5, UDYAM NAGAR, YELLAPUR POST, BALGIMANI, HUBLI-ANKOLA, YELLAPUR TOWN, UTTARA KANNADA DIST., KARNATAKA - 581359 PH :7090772121.

KERALA

ADOOR

1021. INDUS MOTOR COMPANY PRIVATE LIMITED (2702-0A), M. C. ROAD, MITHRAPURAM, ADOOR PATHANMHTITTA - 689518 PH :9745998303.

1022. AVG MOTORS LTD. (Y051-02), KOTTAMUKAL, K.P. ROAD, ADOOR PO, PATHANMHTITTA, KERALA - 691523 PH :9446355900.

ALANALLUR

1023. KVR AUTOCARS PVT LTD (CIW1-01-), BUILDING NO. 10/1050, CHANDAPPADI, MANNARKAD ROAD, POST - ALANALLUR, TALUKA - MANNARKAD, DISTRICT - PALAKKAD, KERALA. - 678601 PH :9747020582.

ALATHIYOOR

1024. A M MOTORS (E601-11), RE-SURVEY NO. 160/3, 161/7 (OLD SURVEY NO. 359/1), VILLAGE - ALATHIYOOR, TIRUR PONNAI ROAD, TALUKA - TIRUR, DIST - MALAPPURAM, KERALA. - 676102 PH :9889594000, .9072998833.

ALATHUR

1025. BRD CAR WORLD LIMITED (BRW1-01-), SURVEY NO. 456/8, 455/8, 455/9, ERATTUKKULAM, KATTUSERY VILLAGE, ALATHUR TALUKA, PALAKKAD DISTRICT, KERALA - 678682 PH :9745634999.

ALLEPPY

1026. INDUS MOTOR COMPANY PRIVATE LIMITED (2702-12), BLOCK NO. 145, RE-SURVEY NO. 79, ALAPPUZA WEST VILLAGE, AMBALAPPUZA TALUK, ALAPPUZA DIST. KERALA-699002. - 699002 PH :9745977744.

ALLEPPI

1027. POPULAR VEHICLES (E502-01-), BUILDING NO. XVIII/135, DOOR NO. 13/449, CCSB ROAD, PALACE WARD, CHUNGAM, ALAPPUZA, KERALA-688011. - 688011 PH :9778698161.

ALUVA

1028. BRD CAR WORLD LIMITED (A404-09-), RE SURVEY NO.330/7, NH-47, KUNNUMPURAM, PO-DESHAM PANCHAYATH, CHENGAMANAD, ALUVA . - 683102 PH :9745907100.

ANCHAL

1029. SARATHY AUTO CARS (BQ1-01-), SURVEY NO. 371/9, VILLAGE – IDAMULAKKAL, P.O. – ANCHAL, TALUK – PUNALUR, DISTRICT – KOLLAM. - 691306 PH :9526906665.

1030. POPULAR VEHICLE (1601-14), RE SURVEY NO 581/5, BLOCK NO 33, ANCHAL VILLAGE, NEAR ALIBIL DRIVING SCHOOL, KAITHADY JUNCTION, ANCHAL, KERALA - 691306 PH :9778698200.

ANGAMALY

1031. INDUS MOTOR COMPANY PRIVATE LIMITED (2702-0F-), ANGAMALA Y KALADY ROAD, MC ROAD, ANGAMALY - 683572 PH :9745998434.

1032. POPULAR VEHICLES & SERVICES LTD. (2701-0D-), 182-AIRPORT JUNCTION NAGAR,M. C. ROAD,ANGAMALY - 683572 PH :8086078886.

ATTINGAL

1033. POPULAR VEHICLES & SERVICES LTD. (1601-07-), PALAMKONAM, PERUNKULAM,VIA- ALAMCODE, ATTINGAL - 695102 PH :8086078788.

1034. SARATHY AUTODRIVES PVT LTD (SX05-01-), SURVEY NO. 2952/17 & 2952/4, KIZHUVILLAM VILLAGE, ATTINGAL, CHARAYINKEEZHU TALUK, TRIVANDRUM DIST., KERALA. - 695 104 PH :9526052765.

1035. INDUS MOTOR COMPANY PRIVATE LIMITED (SX01-01-), SY. NO. 54/13, 14, 15, 16, (OLD SY. NO. 22, 22/13, 16), IN BLOCK NO. 3 OF VELLOOR VILLAGE, EASTERN SIDE OF NATIONAL HIGHWAY 47, NEAR INTERNATIONAL SCHOOL, CHEMBAKAMANGALAM, KORANI PO, ATTINGAL, TRIVANDRUM DIST., KERALA. - 695104 PH :9747550888.

BALARAMPURAM

1036. POPULAR VEHICLES & SERVICES LTD. (1601-11-), POOVAR ROAD, VAZHIMUKKU, BALARAMPURAM P.O., TRIVANDRUM DISTRICT - 695501 PH :8943345922.

BHARANIKAVU

1037. SARATHY AUTO CARS (BQ1-01-), URVEY NO. 116/2 OF 4, SASTHAMKOTTA VILLAGE, BHARANIKAVU TOWN, KUNNATHOOR TALUK, KOLLAM DISTRICT, KERALA, PIN-690520 - 690520 PH :977869825565.

CALICUT

1038. INDUS MOTOR COMPANY PRIVATE LIMITED (4701-01-), MARUTI WORKSHOP, PANIKKER ROAD, CALICUT, NADAKKAVE - 673011 PH :9745998019.

1039. POPULAR VEHICLES & SERVICES LTD. (4702-02-), BEHIND MIMS, EASWARAMANGALAM ROAD, GOVINDAPURAM P.O., CALICUT - 673016 PH :9846298613.

1040. INDUS MOTOR COMPANY PRIVATE LIMITED (4701-06-), KOYA ROAD JUNCTION, PUTHIYANCADI, POST WEST HILL, CALICUT - 673005 PH :9745998020.

1041. INDUS MOTOR COMPANY PRIVATE LIMITED (4701-08-), NEAR STEEL COMPLEX, NALLALAM, CALICUT - 673655 PH :9745998018.

1042. POPULAR VEHICLES & SERVICES LTD. (4702-07-), NH-17 BYE PASS,PACHAKKIL, MALAPARAMBU P.O., KOZHIKODE, CALICUT - 673009 PH :9288012082.

1043. BIMAL AUTO AGENCY INDIA PVT LTD (4706-01-), RE SURVEY NO. 13, BUILDING NO. 5/548, KRISHNARAJA BUNTING, AREEKAD, VILLAGE AND PANCHAYATH – CHERUVANNUR, P.O. – NALLALAM, CALICUT (KOZHIKODE) , KERALA. - 673027 PH :7592898888, 7594997888.

CHALAKUDY

1044. BRD CAR WORLD LIMITED (ZJ02-01-), MURINCOOR P.O., CHALAKUDY - 680316 PH :9645176999.

1045. INDUS MOTOR COMPANY PRIVATE LIMITED (ZJ03-01-), SURVEY NO. 53/1, 53/2 & 55/1, PANAMBILLY COLLEGE JUNCTION, VILLAGE-PERAMBRA, POTTA, TALUKA CHALAKUDY, DISTT. THRISSUR, PIN-680307, KERALA - 680307 PH :9747557355.

CHALAKUDY/ CHILLAKUDY/ THRISSUR

1046. POPULAR VEHICLES & SERVICES LTD. (2701-0C-), OPPSITE CCMK HOSPITAL, VELLIKULAM ROAD, CHALAKUDY, KERALA - 680307 PH :9072609600.

CHANGANASSERY

1047. INDUS MOTORS (CNZ1-01-), BUILDING NO. 4/11, BLOCK NO. 4, RE-SURVEY NO. 224/1, VAZHAPPALLI WEST VILLAGE, CHANGANASSERY TOWN & TALUK, KOTTAYAM DIST.,KERALA - 686103 PH :9778699557.

CHANGARAMKULAM

1048. A M MOTORS (VH01-01-), MELE MANTHADAM, ALANKODE, P.O., CHANGARAMKULAM, MALAPPURAM DISTT, KERALA - 679585 PH :9895756008.

CHAVAKKAD

1049. BRD CAR WORLD LIMITED (A404-06-), ORUMANAYOOR P.O.CHAVAKKAD, DISTRICT-THRISSUR - 680512 PH :9645963399.

1050. SAI SERVICE PRIVATE LIMITED (J02-01-), SURVEY NO. 26/5, MULLANTHARA PARAMBU, OVUNGAL, KUNNAMKULAM ROAD, TALUK – GURUVAYUR, CHAVAKKAD.) - 680506 PH :9495883852.

CHENGANNUR

1051. SARATHY AUTO CARS (C701-06-), PRAVUMKOOD, THIRUVANVANDOOR P.O. CHENGANNUR TALUK, ALAPPUZA (DIST) - 689124 PH :9447002647.

1052. SAI SERVICE (UL03-01-), SURVEY NO. 276/2,11,13,13-2, NEAR BPCL PUMP AND SURVEY NO. 276/12, M C ROAD, NEAR LABHAM MAVELI STORE,CHENGANNUR PO & MUNICIPAL, CHENGANNUR VILL & TALUK, ALAPUZA DIST., KERALA-689121 - 689121 PH :9288024220.

CHERUPALLASSERY

1053. KVR AUTOCARS PVT LTD (NB01-01-), SURVEY NO. 154/4, RS NO. 154/4, VILLAGE – CHERUPALLASSERY, TALUK – OTTAPPALAM, DISTRICT – PALAKKAD - 679503 PH :9747020582, 280100.

CHERTHALA

1054. INDUS MOTOR COMPANY PRIVATE LIMITED (VL03-01-), OPPOSITE TO S.N. COLLEGE, S.N. PURAM P.O., KANJIKUZHI,CHERTHALA, ALAPPUZA-DIST. - 688552 PH :9745997633.

1055. POPULAR VEHICLES & SERVICES PVT. LTD. (VL02-01-), RE-SURVEY NO.150/2-1,4/7, BUILDING NO.KP-18/8, N.H. KANJIKUZHI VILLAGE, CHERTHALA, ALAPPUZA DISTT., - 688582 PH :9072609127.

CHINGAVANAM

1056. POPULAR (I602-01), BUILDING NO. VI 461, RE SURVEY NO. 2909, GOMATHI JUNCTION, MAVILANGU KARA, CHINGAVANAM P.O., DISTT. KOTTAYAM, KERALA - 686531 PH .9778690817.
- CHITTUR**
1057. INDUS MOTOR COMPANY PRIVATE LIMITED (BQX1-01), S.NO.7193 AND 721/1, RE SURVEY NO.671/10, VELLIYAVALLAMPATHY VILLAGE, KOZHINJAMPARA, CHITTUR, PALAKKAD DISTT. - 678555 PH .9745991560.
- CHULLIMANOR**
1058. POPULAR VEHICLES (1601-16), RE-SURVEY NO. 437, VILLAGE-ANAND, CHULLIMANOR TOWN, TALUKA-NEDUMANGAD, DIST. TRIVANDRUM, PIN-695541, KERALA - 695541 PH .9778690745.
- COCHIN**
1059. POPULAR VEHICLES & SERVICES LTD. (2701-01), PERANDOR ROAD, PUNNAKAL, ELAMAKKARA, COCHIN - 682025 PH .9846017725.
1060. INDUS MOTOR COMPANY PRIVATE LIMITED (2702-02), BEHIND COMMERCIAL SALES TAX, M.G. ROAD, COCHIN, - 682015 PH .9745998040.
1061. SAI SERVICE PRIVATE LIMITED (2705-01), 50/1 15L , CHERANALLOR ROAD,EDAPPALLY,COCHIN - 682024 PH .9645106339.
1062. SAI SERVICE PRIVATE LIMITED (2705-02), NH-47, PATHADIPALAM,EDAPPALLY,COCHIN - 682024 PH .9645105057.
1063. POPULAR VEHICLES & SERVICES LTD. (2701-04), NEAR LISI HOSPITAL, OPP.IMA BLOOD BANK, COCHIN, - 682018 PH .9846298611.
1064. INDUS MOTOR COMPANY PRIVATE LIMITED (2702-09), PALARIVATTOM KAKANAD ROAD, KAKANAD, COCHIN, - 682030 PH .9745998013.
1065. SAI SERVICE PRIVATE LIMITED (2705-08), KETTEZHUTHUM KADAVU, INTUC JUNCTION, NETTOOR, ERNAKULAM, COCHIN (KERALA) - 682040 PH .812496818.
1066. GEORGE MAJO AUTOMOBILES PVT. LTD. (2709-01), DOOR NO.5/452, 5/452A, 5/453, OLD ELOOR ROAD, ELOOR JUNCTION, NORTH KALAMASSERY, DISTRICT - ERNAKULAM, COCHIN. - 683104 PH .7559997864, 4237700.
1067. INDUS MOTOR COMPANY PRIVATE LIMITED (2702-0L), SURVEY NO. 30-A/32, KARIKKAD ROAD, THEKUMBHAGAM, PUTHIYAKAVU, TRIPUNITHURA, ERNAKULAM, KERALA - 682301 PH .9745992070.
1068. GEORGE MAJO AUTOMOBILES PVT. LTD. (2709-02), PLOT NO.2/316, NH-47, MARADU VILLAGE, KANNIKAD, NEAR SAROVARAM, KUNDANOOR, COCHIN (KERALA) - 607001 PH .7994763336.
- EDAPPAL**
1069. POPULAR VEHICLES & SERVICES LTD. (4702-05), KOZHIKODA ROAD, KAVILPADY, EDAPPAL, MALAPPURAM - 679582 PH .9946104680.
- EDA VANNAPARA**
1070. POPULAR VEHICLES (GKP1-01), SURVEY NO. 77/16-1 & 77/2-4, BUILDING NO.18/152-B, CHEEKODE VILLAGE,EDA VANNAPARA KONDTOOR ROAD, CHERUVAYOR PO, MALLAPPURAM DISTRICT, KERALA-673645 - 673645 PH .9539007323.
- FORT KOCHI**
1071. SAI SERVICE PRIVATE LIMITED (BRS1-01-), PLOT NO.83/1,2 OPPOSITE TO KUMAR PETROL PUMP, STATURE ROAD, CHULLIKAL POST, FORT KOCHI - 682005 PH .9645106330.
- GURUVAYUR**
1072. INDUS MOTOR COMPANY PRIVATE LIMITED (2702-08), KUNAMKULAM CHAVAKKAD ROAD, OPPOSITE CHOOLPURAM MOSQUE, GURUVYOR, THRISSUR - 680505 PH .9745998015.
- IRINJALAKUDA**
1073. BRD CAR WORLD LIMITED (A404-05), KARUPADANNA P.O., IRINJALAKUDA, THRISSUR - 680670 PH .9539006999.
- IRITTY**
1074. INDUS MOTOR COMPANY PRIVATE LIMITED (R002-02-), SURVEY NO. 48, BUILDING NO. 214, PERUPARAMBA, IRITTY, KANNUR, KERALA - 670703 PH .9747554929.
- IRITY**
1075. POPULAR VEHICLE (VJ02-01), RE-SURVEY NO: 14/4, 11/2, NEAR JABBAR KADAVU BRIDGE, KEEZHUR VILL., PERAVOOR ROAD, IRITTY MUNICIPAL, KANNUR DIST. KERALA. - 670703 PH .7902473741.
- KAI PAMANGALAM**
1076. SAI SERVICE PRIVATE LIMITED (2705-07), VAZHYAMBALAM PO, KAIPAMANGALAM,THRISURE - 680681 PH .8129496846.
- KALAMASSERY/ ERNAKULAM/ COCHIN**
1077. INDUS MOTOR COMPANY PRIVATE LIMITED (2702-07), KALAMASSERY, ALVA WEST, ERNAKULAM DIST, KERALA - 683106 PH .9745998012.
- KALLAMBALAM**
1078. POPULAR (QZ02-01), BUILDING NO. 5/472, NH-47, KADUVAPALLY, THOTTAKAD P.O., KALLAMBALAM, TRIVANDRUM DIST., KERALA - 695605 PH .8086078788.
- KALPETA**
1079. INDUS MOTOR COMPANY PRIVATE LIMITED (4701-0C), MEENANGADI, KAKKAVAYAL P.O., NORTH KALPETA,WAYAND - 673591 PH .9745998592.
1080. KVR (JE02-C1+), BUILDING NOS. 363, 364, 365, 366,367,368 and 369 CONSTRUCTED ON THE PLOT COMPRISED IN SURVEY NOS. 719/6, 722/3, 722/2, 722/6, 722/8, 722/10, 722/21, SITUATED AT MUTTIL NORTH VILLAGE, VYTHIRI TALUK, KALPETA SUB-DISTRICT, WAYANAD DISTRICT, KERALA. - 673 122 PH .9747021902.
- KANHAGAD**
1081. KVR CARS (3L01-02), ARANGADI, P.O. KANHAGAD, DIST. KASARGOD, - 671315 PH .9605040999.
1082. POPULAR VEHICLES & SERVICES LTD. (4702-06), HIGHWAY JUNCTION,KANHAGAD SOUTH P.O. KANHAGAD - 689641 PH .9946104685.
- KANHAGAD**
1083. INDUS MOTOR COMPANY PRIVATE LIMITED (4701-0F), SURVEY NO.491/3A1 AND 491/3A2, AJANUR VILLAGE, KANHAGAD, HOSADURGA TALUK, KASARAGOD DISTT, KERALA. - 671541 PH .9745998024.
- KANJIRAPALLY**
1084. INDUS MOTOR COMPANY PRIVATE LIMITED (7E01-02), VADAKUMBHAGAM KARAYIL, KUNNAMBHAGAM P.O. , KANJIRAPALLY - 686506 PH .9745998009.
1085. AVG MOTORS LTD. (Y903-01), NEW SURVEY NO. 187/2 (OLD SURVEY NO. 299/1, 299/11), KANJIRAPALLY VILLAGE & TALUKA, KOTTAYAM DISTRICT, KERALA - 686512 PH .8606071155.
- KANNUR**
1086. HAR CARS (K101-01), HAR AVENUE, KANNOTHUMCHAL, CHOVA POST, KANNUR - 670006 PH .9539009480.
1087. HAR CARS (K101-03), POTTIAN SHEKHARAN ROAD, MAKKANY , SOUTH BAZAR, KANNUR - 670002 PH .9539009443.
1088. INDUS MOTOR COMPANY PRIVATE LIMITED (4701-0E.), BALANKINAR JN., KATTAMPALLY,P.O, KANNUR - 690011 PH .9745998023.
1089. KVR CARS (3L01-04), CP-3-651-B, OPP. DHANRAJ TALKIES, PUTHIYATHERU, CHIRAKKAL POST, KANNUR, KERALA - 670011 PH .9656034333.
1090. POPULAR VEHICLES & SERVICES LTD. (4702-0F), PLOT NO.82/6A, NEAR CHARAPPURAM SREEMUTHU TPPAN KAVU, KAPPAD ROAD, THAZHE CHOCCA (PO), KANNUR - 670018 PH .9846062796.
- KARIKKAD**
1091. BRD CAR WORLD LIMITED (A404-02-), BRD INDUSTRIAL ESTATE,KARIKKAD, KUNNAMKULAM - 680519 PH .9995804599.
- KARUNAGAPALLY**
1092. SARATHY AUTO CARS (C701-05), K.S. PURAM,NEELIKULAM, KARUNAGAPPALLY,KOLLAM, - 690544 PH .9526691565.
1093. INDUS MOTOR COMPANY PRIVATE LIMITED (AQ03-01), SY.NO.243/1, 243/10, 243/16, 243/14, 243/15, 243/16, EDAPPALLY KOTTA JUNCTION, NEAR TITANIUM, CHAVARA POST, KARUNAGAPALLY, DISTT. KOLLAM. - 691583 PH .9745998006.
1094. SARATHY (C701-11), SURVEY NO. 15/3, SIDCO INDUSTRIAL AREA, EDAKULANGARA PO, NEAR KARUNAGAPALLY RAILWAY STATION, KARUNAGAPALLY, KERALA. - 690 562 PH .9526691565.
- KASARGOD**
1095. KVR CARS (3L01-01), ANANGUR, VIDYANAGAR (PO), NH17, KASARGOD - 671123 PH .9747021206.
1096. POPULAR VEHICLES & SERVICES LTD. (4702-0D), MUNDAKULAM, CHEMMANAD (PO), KASARGOD - 671371 PH .9946104621.
1097. INDUS MOTOR COMPANY PRIVATE LIMITED (R002-03-), 18/304A & 18/304B, SY. NO. 39/3B, RE SY. NO. 57/6, MOGRAL, MANJESHWAR TALUK, KASARAGOD, KERALA - 671541 PH .9747550747.
- KATTAPANA**

Dealer Network (AS ON 31.10.2023)

1098. INDUS MOTOR COMPANY PRIVATE LIMITED (ZN01-01), KATTAPPANA-IDUKKI KAVALA, BYE PASS ROAD, KATTAPPANA, IDUKKI (DIST.) - 685508, PH :9746743460.
1099. POPULAR VEHICLES (ZN02-01), RE-SURVEY NO. 81/3, VILLAGE & TOWN - KATTAPPANA, TALUK & DIST -IDUKKI, KERALA - 685 515 PH :9746818407.
- KAYAMKULAM**
1100. INDUS MOTOR COMPANY PRIVATE LIMITED (2702-05), KARYILAKULANGARA, KAYANKULAM P.O., ALAPPUZHA DISTT. - 690522, PH :9745998005.
1101. POPULAR VEHICLES & SERVICES LTD. (B802-01), NH 47, KOTTUKULANGARA, KAYAMKULAM P.O., ALAPPUZHA DISTT. - 690502, PH :9946105601.
- KODUNGALLUR**
1102. SAI SERVICE PRIVATE LIMITED (2705-03), NH-17,T.K.S.PURAM ,KODUNGALLOOR - 680667 PH :9645106571.
1103. INDUS MOTOR COMPANY PRIVATE LIMITED (BK02-01), RE-SURVEY NO. 116/1-6, 116/2-5, BUILDING NO. 560/A, WARD NO. VII, AALA VILLAGE, (OLD VILLAGE-SREENARAYANAPURAM), KODUNGALLUR TALUK, MADHILAKOM SRO, SANTHIPURAM PO, THRISSUR DISTT., KERALA - 680 008, PH :9747513444.
- KODUVALLY**
1104. A M MOTORS (BGX1-01), SURVEY NO-91/9, 91/10,NALLANKADY, VAWAD POST, KODUVALLY, KOZHIKODE DISTRICT, KERALA - 673572 PH :9895979023.
- KOLANCHERRY**
1105. SAI SERVICE (SJ01-01), SURVEY NO.138/7, BLOCK NO. 47, WARD-8, KOLENCHERY TOWN, NH-85, AIKARANADU NORTH VILL., KUNNATHUNADU TALUK, ERNAKULAM DIST., KERALA-682311 - 682311 PH :7356605955.
- KOLLAM**
1106. SARATHY AUTO CARS (C701-01), NH-47 BYE PASS,AYATHIL(P.O.),QUILON - 691017 PH :9744552265.
1107. POPULAR VEHICLES & SERVICES LTD. (1601-04), H & C COMPOUND, MUNDDACKAL, KOLLAM - 680006 PH :7594977550.
1108. INDUS MOTOR COMPANY PRIVATE LIMITED (1602-03), OLD SARATHY THEATRE, PUNALOOR ROAD, KOLLAM - 691005 PH :9745998004.
1109. SARATHY AUTO CARS (C701-13), SURVEY NO. 431/13-42, NEAR SN PUBLIC SCHOOL, VADAKKEVILA, AYATHIL, KILLIKKURO PO, PUNTHALATHAZHAM-PALATHARA ROAD, KOLLAM, KERALA - 691004 PH :860430765.
- KOLLAM/ QUILON**
1110. SARATHY AUTO CARS (C701-08), SURVEY NO. (SIDCO) 318/1, SHED NO. B12, UMAPANALLUR SIDCO INDUSTRIAL ESTATE, KOLLAM. - 691589 PH :9947127565.
1111. SARATHY AUTO CARS (C701-12), BUILDING NO. 15/620, SURVEY NO. 234/1, 235/2, SITHARA JUNCTION, ADICHANALLOOR VILLAGE, KOTTIYAM PO, KOLLAM DIST., KERALA. - 691571 PH :9847936165.
- KONDOTTY**
1112. INDUS MOTOR COMPANY PRIVATE LIMITED (ID02-01), SURVEY NO. 1/61, BLOCK NO. 36 (OLD SURVEY NO. 100/1), NEDIYIRUPPU VILLAGE, KONDOTTY PO, ERNAKULAM TALUKA, MALAPURAM DISTRICT, KERALA - 683573 PH :9746743178.
- KOOTHATTUKULAM**
1113. SAI SERVICE PRIVATE LIMITED (VM01-01), EDAPUTHUSURRY BUILDING, M.C. ROAD, OPP. MARYGIRI PUBLIC SCHOOL, KOOTHATTUKULAM P.O., ERNAKULAM DT. - 686662 PH :9645106258.
- KOPPAM**
1114. AM MOTORS (CUU1-01), SURVEY NOS: 331/3-6, 331/3-10, NEAR SALAFIYYA TRAINING COLLEGE, PERINTHALMANNA-PATTAMBI ROAD, KARINGANDU, VILAYUR POST, KOPPAM, PALLAKKAD DIST., KERALA-679309 - 679309 PH :9048666635.
- KOTHAMANGALAM**
1115. POPULAR VEHICLES & SERVICES LTD. (2701-08), NEAR BSNL OFFICE, THANGALAM, KOTHAMANGALAM, KERALA - 686691 PH :9846027990.
1116. INDUS MOTOR COMPANY PRIVATE LIMITED (7E01-03), PALAKKADAN BUILDING,CHANKLAM,KOTHAMANGALAM - 686691 PH :9745998479.
- KOTTAKKAL**
1117. INDUS MOTOR COMPANY PRIVATE LIMITED (4701-09), NEAR MATHRUBHUMI PRESS, P.O. KOTTAKKAL, MALAPPURAM DIST. - 676503 PH :9745998017.
1118. POPULAR VEHICLES & SERVICES LTD. (4702-03), NH-17,,CHANDAPARAMBU,,RANBATHANI P.O, MALAPPURAM, KOTTAKAL - 676510 PH :9946104631.
- KOTTARAKARA**
1119. POPULAR (S801-02), BUILDING NO. MP/207/49,20/426, 20/748, INCHAKADU, KALAYAPURAM VILLAGE, MYLOM PANCHAYATH, KOTTARAKKARA TALUKA, KOLLAM DISTRICT, KERALA- 691560 - 691560 PH :8086073466.
- KOTTARKKARA**
1120. POPULAR VEHICLES & SERVICES LTD. (S801-01), MYLOM, MC ROAD, KOTTARAKKARA, DISTT-KOLLAM, KERELA - 691531 PH :8086073466.
1121. SARATHY AUTO CARS (S802-01), WARD NO.40, MELLILLA PANCHAYATH, IPPALLOOR LOWER KARIKAM, KOTTARAKKARA DISTT. KOLLAM (KERALA) - 691531 PH :9847423365.
1122. INDUS MOTOR COMPANY PRIVATE LIMITED (S804-01), RE SURVEY NO.207/3-2, KIZHAKKEKKARA MURIYIL, KNS HOSPITAL JUNCTION, KOTTARAKKARA VILLAGE AND TALUKA, KOLLAM DISTT. - 691531 PH :9747562299.
1123. INDUS MOTOR COMPANY PRIVATE LIMITED (S804-02), RE-SURVEY NO.1413/4,1421/2,15-16,143/1-2,143/2,143/15-2,43/15-2, BEARING NOS. 25/36 & 38, KOTTARAKKARA VILLAGE, KOTTARAKKARA TALUK, KOLLAM DISTRICT, KERALA- 691506 - 691506 PH :9747562299.
- KOTTAYAM**
1124. AVG MOTORS LTD. (B801-01), ERAYILKADAVU, KOTTAYAM - 686001 PH :7510982222.
1125. INDUS MOTOR COMPANY PRIVATE LIMITED (2702-04), MULANKUZHA JN., NATTAKOM P.O., KOTTAYAM , KERALA - 686013 PH :9745989148.
1126. POPULAR VEHICLES & SERVICES LTD. (B802-01), NEAR ST. THOMAS CHURCH, S.H. MOUNT, P.O, KOTTAYAM - 686006 PH :8086073454.
1127. INDUS MOTOR COMPANY PRIVATE LIMITED (2702-0C), MANIPPUZHA, NATTAKOM P.O, KOTTAYAM - 686013 PH :9745998007.
- KOZHENCHERRY**
1128. AVG MOTORS LTD. (W801-03), KOZHENCHERRY, COLLEGE JUNCTION, DISTRICT: PATHANAMTHITTA, - 689641 PH :9446929995.
- KUNNAMKULAM**
1129. POPULAR VEHICLES & SERVICES LTD. (2701-07), CHOONDA,TRISSUR ROAD, KUNNAMKULAM, TRISSUR DIST - 680502 PH :9946105695.
- LAKKIDI PERUR**
1130. A M MOTORS (CER1-01), 217/7, 217/2, 278/2, 278/1, PALAPPURAM, P.O. OTTAPPALAM, LEKKIDI PERUR DISTT. PALAKKAD, - 679302 PH :8086305555.
- MALAPURAM**
1131. A M MOTORS (E601-01), VARANGODE, DOWNHILL, MALAPURAM, - 676519 PH :9895705325.
- MALLAPPALLY**
1132. INDUS MOTOR COMPANY PRIVATE LIMITED (I201-01), THOPPIL COMPLEX, MALLAPPALLY KOTTAYAM RD, MALLAPPALLY WEST, MALLAPPALLY (KERALA) - 689585 PH :9747541400.
- MANATHAVADY**
1133. INDUS MOTOR COMPANY PRIVATE LIMITED (IE02-01), SURVEY NO. 1/2A1, A1, B1, RY 1/21, 1/99, MYSORE ROAD, CHETTAPALAM, MANATHAVADY CITY & TALUK, WYANAD DIST., KERALA. - 670645 PH :9745997002.
- MANJERI**
1134. A M MOTORS (E601-05), THURAKKAL BYEPASS, MANJERI, MALAPURAM, KERALA - 676121 PH :9895756035.
1135. KVR AUTOCARS PVT LTD (8V02-01), CH BYE PASS ROAD, MANJERI, MALAPPURAM, KERALA - 676123 PH :9747020801.
1136. POPULAR VEHICLES & SERVICES LTD. (4702-0E), NARUKARA VILLAGE, RAJIV GANDHI BYEPASS JN., THRUKKAL, MANJERI (KERALA) - 676121 PH :8589992406.
- MANNARKAD**
1137. A M MOTORS (E601-07), NH-213, MANNARKAD, DIST -PALAKKAD - 678582 PH :9895979048.
1138. INDUS MOTOR COMPANY PRIVATE LIMITED (2702-0K), ANAKATTY ROAD, AANDIPPADAM, NELLIPUZHA-PO, MANNARKAD,KERALA - 678583 PH :9745995946.
- MAVELIKARA**

139. POPULAR VEHICLES & SERVICES LTD.
(B802-02), KONNAIYIL SUVAKO INDUSTRIAL
COMPLEX, SHED A-1., KOLLAKADAVU
INDUSTRIAL ESTATE, KOCHAL MOODU,
KALLIMEL P.O., Mavelikkara, KERALA -
690570
PH :9400052338.
140. INDUS MOTOR COMPANY PRIVATE LIMITED
(1602-07), NEAR PRATHIBA THEATRE,
PUTTHIYAKAVU, Mavelikkara - 690101
PH :9745996137.
- Mavelikkara**
141. POPULAR VEHICLES (B802-10), BUILDING NO.
10/115-A, WARD NO. 10, CHENNITHALA VILL.
AND TOWN, SHANTHIVANAM JUNCTION,
CHERUKOLE P.O., Mavelikkara TALUK,
Alappuzha DIST., KERALA- 690104. - 690104
PH :9778690833.
- MORAYUR**
142. A M MOTORS (CUJ1-01), SURVEY NO. 328/1,
VILLAGE - MORAYUR, VALENCHERY, DISTRICT
- MALAPPURAM, KERALA. - 673642
PH :8086526666.
- Muvattupuzha**
143. INDUS MOTOR COMPANY PRIVATE LIMITED
(7E01-01), NH-49, MUVTUPUZHA
KODAMANGALAM ROAD, NEAR R.K.HOSPITAL,
MUVTUPUZHA, ERNAKULAM DIST - 686661
PH :9745999801.
144. POPULAR VEHICLES & SERVICES LTD.
(2708-02), MUTHUKALLU
JUNCTION, PERUMPALLUR P.O.,
MUVATTUPUZHA, KERALA - 686673
PH :7356988840.
- nedumangad**
145. POPULAR VEHICLES & SERVICES LTD.
(Z001-01), RE-SURVEY NO. 855/29, 855/14/1
(OLD SURVEY NO. 1583/1), KARIKKUPP VILLAGE,
NEDUMANGAD TALUK, TRIVANDRUM
DIST., KERALA-695541. - 695541
PH :9846036696.
- NEYYANTINKARA**
146. INDUS MOTOR COMPANY PRIVATE LIMITED
(A01-01), INDUS MOTOR CO. PVT. LTD., OLD
M.V. THEATRE, NEAR KSRTC BUS STATION,
NEYYATINKARA, DIST. TRIVANDRUM - 695121
PH :9747544500.
- NEYYATTINKARA**
147. POPULAR VEHICLES (1601-15), BUILDING NO.
11/562, KP-IX-843, NH 47, KOTTAMOM ,
KOLLAYIL PANCHAYAT, PANVEL - KOCHI -
KANYAKUMARI HIGHWAY, KOTTAMOM,
NEYYATTINKARA, TRIVANDRUM, KERALA-
695122 - 695122
PH :9946104602.
- NILAMBUR**
148. INDUS MOTOR COMPANY PRIVATE LIMITED
(4701-04), MINERVA JUNCTION, NILAMBUR ,
KERALA - 679329
PH :9745998396.
149. INDUS MOTOR COMPANY PRIVATE LIMITED
(4701-0D), MANAVEDHAM HIGH SCHOOL
ROAD, CHANDAKUNNU - NILAMBUR PO,
NILAMBUR, MALAPPURAM DIST. - 679329
PH :9745998396.
150. POPULAR VEHICLES & SERVICES (AF02-01),
RE-SURVEY NO: 6/1 BLOCK NO. 76,
CHEMMARAN, NADUVATH PO, WANDOO
ROAD,NILAMBUR, MALAPPURAM DIST.,
KERALA - 679328
PH :7736094999.
- NILAMEL**
151. INDUS MOTOR COMPANY PRIVATE LIMITED
(DA02-01), SURVEY NO. 195/10, 195/3-1-2,
195/3-2-1, 195/8, 195/14, 195/9-1, 195/11-1,
BLOCK NO. 32, ATTINGAL MUNICIPALITY,
PAZHAYAKUNNAM VILLAGE, CHIRAYINKIL
TALUK (BORDER OF NILAMEL TOWN),
TRIVANDRUM DIST., KERALA - 695601
PH :9745993331.
152. POPULAR (DA03-01), BUILDING NO. 10/279 TO
288, M. C. ROAD, KANNANCUDU, NILAMEL PO,
KOLLAM (DIST.), KERALA- 691535 - 691535
PH :8714606483.
- OTTAPPALAM**
153. INDUS MOTOR COMPANY PRIVATE LIMITED
(PA01-01), BUILDING NO.23/667, 23/669,
PALAKKAD-OOTTAPPALAM ROAD, OTTAPPALAM
VILLAGE, OTTAPPALAM TALUKA, PALAKKAD
DISTT., KERALA. - 679101
PH :974754454.
- PALA**
154. POPULAR VEHICLES & SERVICES LTD.
(B802-04), 12TH MILE,PALA-PONKUNNAM
ROAD,PALA - 686575
PH :9072609475.
155. INDUS MOTOR COMPANY PRIVATE LIMITED
(TE01-05), OPP. ALPHONA COLLAGE
ARUNAPURAM(PO), PALA, KOTTAYAM - 686574
PH :9745998878.
156. AVG MOTORS LTD. (GN03-01), SURVEY
NO.670/1, BLOCK-21, LALAM VILLAGE,
ANTHINADU MEENCHIL, PALA, KOTTAYAM
DIST. - 686651
PH :9447137246.
157. INDUS MOTOR COMPANY PRIVATE LIMITED
(7E01-01), SURVEY NO. 176, BLOCK NO. 16,
HIGHWAY JUNCTION, ETTUUMANOR-POOJAR
HIGHWAY, CHERPUKAL, PALA, KOTTAYAM
DISTRICT - 686584
PH :9747516934.
- PALAKKAD**
158. POPULAR VEHICLES & SERVICES LTD.
(2701-09), OPP. PALANA
HOSPITAL,KODUVAYOOR ROAD,KINASSERY
P.O.,PALAKKAD - 678707
PH :9946105613.
159. INDUS MOTOR COMPANY PRIVATE LIMITED
(2702-0G), VADAKKUMURI-NH-47, KANNADI,
KUZHALMAMMAM (P.O), PALAKKAD. - 678701
PH :9745998590.
160. INDUS MOTOR COMPANY PRIVATE LIMITED
(Y202-01), DOOR NO: 5/366 & 367, NH 47,
KOOTUPATHA, CHANDRANAGAR POST,
PALAKKAD - 678007
PH :9747519500.
- PANDIKKAD**
161. AM MOTORS (CUV1-01), SURVEY NOS: 333/2-2,
333/3-2,CHOORAKAVU, PERINTHALMANNA
ROAD, NEAR INDIAN OIL PETROL PUMP,
PANDIKKAD TOWN & POST, MALAPPURAM
DISTRICT, KERALA - 676 521
PH :9539999570.
- PARAPPANANGADI**
162. AM MOTORS (CTK1-01), SURVEY NO.66/6,
66/7, KODAPPAD, POST-CHETTIPPADY,
PARPANGADI, MALAPPURAM. - 676319
PH :9895900466.
- PARAVUR**
163. POPULAR VEHICLES & SERVICES LTD.
(ZS01-01), SURVEY NO. 340/1-76,77,78, NEAR
HP PETROL PUMP, PARAVUR-MANJALI MAIN
ROAD, MANNAM PO, NORTH PARAVUR
MUNICIPAL, ERNAKULAM DIST. 683520,
KERALA. - 683520
PH :9072609638.
- PATHANAMTHITTA**
164. AVG MOTORS LTD. (W801-02), JUNNUGAPADY,
MYLAPRA ROAD, PATHANAMTHITTA. - 689671
PH :9446020987.
165. INDUS MOTOR COMPANY PRIVATE LIMITED
(1602-13)-, KUMBAZHA, PATHANAMTHITTA -
689653
PH :9745998008.
166. POPULAR VEHICLES & SERVICES LTD.
(B802-05), T.K. ROAD, NEAR
COLLECTORATE,PATHANAMTHITTA - 689645
PH :9539009734.
167. INDUS MOTOR COMPANY PRIVATE LIMITED
(1602-12), SURVEY NO. 11-13/12(1),
KARIMPANKUZHY ROAD, NEAR SAROJ GAS
AGENCY, MAKKANKUNNU, PATHANAMTHITTA,
KERALA. - 689645
PH :9745999858.
- PATHIRAPALLY**
168. POPULAR VEHICLES & SERVICES LTD.
(E502-02), BUILDING NO. X/832 TO 834, X/837
TO 838, OPP. UDAYA STUDIO, PATHIRAPALLY
TOWN, AMBALAPUZA TALUK, NH-47,
ALAPPUZA DIST., KERALA-688521. - 688521
PH :9778698169.
- PATTAMBI**
169. A M MOTORS (E601-04), SHORANUR ROAD,
PATTAMBI, DISTRICT-PALAKKAD. - 679306
PH :9567866059.
170. INDUS MOTOR COMPANY PRIVATE LIMITED
(2702-0B), PERINTHALMANNA ROAD,
THEKKUMURI, PATTAMBI - 679303
PH :9745998295.
171. A M MOTORS (E601-09), CHERPULASSERY
ROAD, KOOMBAN KALLU, KARIMPULLI, MELE -
679306
PH :9567866059.
- PAYYANUR**
172. POPULAR VEHICLES & SERVICES LTD.
(4702-04), N H 17.,EZHILODE P.O. ,PAYYANUR -
670309
PH :9946104701.
173. POPULAR VEHICLES & SERVICES LTD.
(9Z01-01), SY. NO. 218/1, CHERUTHAZHAM
VILLAGE, EZHILODE (NEAR, COLONY BUS
STOP), PAYANNUR-KANNUR NH, PAYANNUR
TALUK, KANNUR DISTRICT, KERALA - 670 309.
PH :9946104701.
- PAYYANUR**
174. INDUS MOTOR COMPANY PVT. LTD. (9Z02-01-),
SURVEY NO :289/1/1, 290/105, KARIVELLUR
PERALAM GRAM PANCHAYAT (NEAR
PALATHARA BRIDGE), PAYANUR TALUK,
KANNUR DISTRICT, KERALA- PIN-670521. -
670521
PH :9745998204.
- PERINTHALMANNA**
175. A M MOTORS (E601-03), NEAR FIRE STATION,
HOSPITAL ROAD, PERINTHALMANNA - 679322
PH :8129818235.
176. KVR AUTOCARS PVT LTD (7H01-01), SURVEY
NO. 878-15, CALICUT ROAD, NEAR ITC,
THIRURKAD, PERINTHALMANNA - 679351
PH :9747020573.
177. KVR AUTOCARS PVT LTD (7H01-06), OOTY
ROAD, PERINTHALMANNA, MALAPPURAM(DT.),
KERALA - 679322
PH :9747020837.
- PERUMBAVOOR**
178. SAI SERVICE PRIVATE LIMITED (2705-04-),
M.C.ROAD,PERUMBAVOOR,ERNAKULAM
DIST,KERALA - 683542
PH :7034258335.

Dealer Network (AS ON 31.10.2023)

1179. INDUS MOTOR COMPANY PRIVATE LIMITED
(BW03-01), SURVEY NO. 72/2-3, 72/3-3, TALUK -
KUNNATHUNADU, VILLAGE - RAYAMANGALAM,
SUB DIST.-PERUMBAAVOOR, DIST.ERNAKULAM.
- 683 541
PH .9747591803.

PIRAVOM

1180. SAI SERVICE (BQW1-01), SURVEY NO.
788/12-2-5, NEAR PIRAVOM GOVT. HOSPITAL,
PIRAVOM TOWN & MUNICIPALITY,
MUVATTUPUZHA TALUK, ERNAKULAM DIST.,
KERALA. - 686 664
PH .9645106198.

POINACHI

1181. KVR CARS (3L01-03.), CHOWKI,
MAILATTY(P.O), (VIA) UDUMA, POINACHI,
KERALA - 671319
PH .9747021026.

PUNALUR

1182. SARATHY AUTO CARS (C701-03), NH-208, Q.S.
ROAD,ELAMPAL POST,PUNALUR, KOLLAM DIST
- 691322
PH .9744400265.

1183. INDUS MOTOR COMPANY PRIVATE LIMITED
(BQ02-01), SY. NO. 48/1/42, OLD, SY. NO.
231A/324, (OLD RAMRAJ TILES FACTORY),
THALICODE, PATHANAPURAM TALUK,
PUNALUR ANCHAL ROAD. - 691 305
PH .9747638885.

QUILANDY

1184. INDUS MOTOR COMPANY PRIVATE LIMITED
(3001-01), BUILDING NO.13/53 A,
CHENGOTTUKKAVE VILLAGE, QUILANDY,
KOZHIKODE DISTT. - 673306
PH .9745997875.

RAMANATTUKKARA

1185. A M MOTORS (E601-06), NEAR RED CRESCENT
HOSPITAL, FEROKKE, CHUNGAM, CALICUT
DISTRICT, RAMANATTUKKARA. - 673632
PH .9567886144.

RANNI

1186. INDUS MOTOR COMPANY PRIVATE LIMITED
(7E01-06), CHELLAKKAD-PO,
PATHANAMTHITTA (DISTRICT), RANNI - 689677
PH .9745998737.

SASTHAMKOTTAH

1187. INDUS MOTOR COMPANY PRIVATE LIMITED
(1602-09), NO. SP IX/661, 662, 663, KADUPUZHA
ROAD, PORUVAZHY P.O., BHARANIKUVU,
SASTHAMKOTTAH, KOLLAM - , KERALA -
690520
PH .9745998849.

SHORNUR

1188. POPULAR VEHICLES & SERVICES LTD.
(2701-0E), PALAKKAD PATTAMBI ROAD,
KULAPULLY JUNCTION, VADANAMKURUSSI,
SHORNUR - 679124
PH :8589992432.

SULTHAN BATHERY

1189. POPULAR VEHICLES (VK01-01), SURVEY NO.
421/5, 421/6, BLOCK NO. 22, KRISHNAGIRY
VILLAGE, PATHIRIPALAM, KOLAGAPPARA (PO),
TALUK & TOWN - SULTHAN BATHERY,
WAYANAD DIST., KERALA. - 673 591
PH :7594775561.

TALIPARAMBA

1190. HAR CARS (K101-02), SREEKANDAPURAM
MAIN ROAD, KANNUR (DIST), KERALA,
THALIPARAMBA - 670141
PH :9539009473.

THALASSERY

1191. INDUS MOTOR COMPANY PRIVATE LIMITED
(R002-01), NETTUR POST, KODUVALLY,
THALASSERY. KANNUR DISTRICT - 670105
PH :9745998022.

THALASSERY / TELLICHERRY

1192. INDUS MOTOR COMPANY PRIVATE LIMITED
(4701-04), TEMPLE GATE, MAKKOOTAM,
THALIYI, TELLICHERRY , KERALA - 670102
PH .9747520100.

THALAYOLAPARAMBU

1193. INDUS MOTOR COMPANY PRIVATE LIMITED
(2702-0J), THODUPUZHA ROAD,
THALAYOLAPARAMBU, VAIKOM(TALUK),
DISTRICT-KOTTAYAM, KERALA - 686605
PH :9746743003.

THAMARASSERY

1194. INDUS MOTOR COMPANY PRIVATE LIMITED
(PB06-01), RE-SY. NO.44/5A, 44/6, RAROTH
VILLAGE, (NEAR CHUNGAM), THAMARASSERY
PANCHAYAT & TALUK, CALICUT DIST., KERALA.
- 673573
PH :9747553362.

1195. POPULAR (PB07-10), SURVEY NO.4/3/ BLOCK
NO:005, RAROTH VILLAGE , THAMARASSERY
TALUK, KOZHIKODE DISTRICT, KERALA -
673573
PH :9846397060.

THIRUVALLA

1196. AVG MOTORS LTD. (Y501-01), M.C ROAD,
PERUMTHIRUTHI, THIRUVALLA .
PATHANAMTHITTA DISTT - 689107
PH :9446323999.

1197. POPULAR VEHICLES & SERVICE (B802-06),
KAVUMBHAGAM P.O, THIRUVALLA,
PATHANAMTHITTA (DIST.), KERALA - 689103
PH :8086073489.

THODUPUZHA

1198. INDUS MOTOR COMPANY PRIVATE LIMITED
(7E01-04), PALA ROAD, THODUPUZHA - 685584
PH :9745998631.

1199. POPULAR VEHICLES & SERVICES LTD.
(HZ02-01), SY.NO.124/7A-1, 124/7A-2,
THODUPUZHA EHLLOOR MAIN ROAD, VILLAGE &
TOWN, THODUPUZHA, DISTT. IDUKI - 685585
PH :9072530120.

THRISSUR

1200. POPULAR VEHICLES & SERVICES LTD.
(2701-05), KUNNATHUMKARA, PARAVATTANI,
THRISSUR, KERALA - 680655
PH :6282306495.

1201. SAI SERVICE PRIVATE LIMITED (2705-06),
1730.POOTHOLE,THRISSUR,KERALA - 680004
PH :9645105051.

1202. BRD CAR WORLD LIMITED (A404-01), NH
47.BYE PASS,KONIKARRA POST,THALORE,
THRISSUR - 680031
PH :9995807141.

1203. INDUS MOTOR COMPANY PRIVATE LIMITED
(2702-0J), JYOTHI COMPLEX, GURUVAYOOR
ROAD, WEST FORT, THRISSUR - 680004
PH :9745998014.

1204. BRD CAR WORLD LIMITED (A404-07),
GURUVAYOOR ROAD, PUNKUNNAM P.O.,
PUZHAKKAL, THRISSUR - 680002
PH :9746476529.

THRITHALLUR

1205. BRD CAR WORLD LIMITED (A404-04), PO-
THRITHALLUR, NH-17, THRITHALLUR THRISSUR
- 680619
PH :9539179888.

TIRUR

1206. A M MOTORS (E601-02), SATELLITE AUTO
WORKS, PAYYANAGADI POST, TIRUR - 676101
PH :9995879706.

1207. KVR AUTOCARS PVT LTD (7H01-05), T.P
7/204-B, TANUR ROAD,MOOCHIKKAL,
MEENADATHUR P.O., TIRUR,
DISTRICT-MALAPPURAM, KERALA - 676307
PH :9747020673.

1208. A M MOTORS (E601-08), THALAKKADATHOOR
PO, MALAPPURAM,MALAPPURAM DISTT. -
676103
PH :9895705323.

1209. INDUS MOTOR COMPANY PRIVATE LIMITED
(Y403-01), SURVEY NO. 119/3, 4, 9A, OLD
MODERN PHARMACEUTICALS PVT LTD.,
THRIRANDYUO VILLAGE, CHAMBAVATTOM
ROAD, TIRUR, KERALA. - 676105
PH :9747518883.

TRIPPUNITHURA, COCHIN

1210. SAI SERVICE PRIVATE LIMITED (2705-05), HILL
PALACE ROAD,KARINGACHIRA,COCHIN -
682301
PH :9645105067.

TRIPRAYAR

1211. POPULAR VEHICLES & SERVICES LTD.
(2701-08), SURVEY NO. 2965/8, 2969/9, 2969/1,
NATTIKI VILLAGE, NEAR CIVIL STATION, POLY
JUNCTION, TRIPRAYAR TOWN, THRISSUR
TALUK & DISTRICT, KERALA-680566 - 680566
PH :9846699245.

TRIVANDRUM

1212. INDUS MOTOR COMPANY PRIVATE LIMITED
(1602-01), T.C. 24/885 THYCAUD P.O.,
THYCAUD P.O., METTUKUDA, TRIVANDRUM -
695014
PH :9745998001.

1213. POPULAR VEHICLES & SERVICES LTD.
(1601-01), C.I.T. ROAD, KILLIPALAM,
KARAMANA P.O, TRIVANDRUM - 695002
PH :9946104601.

1214. INDUS MOTOR COMPANY PRIVATE LIMITED
(1602-02), NH BYE PASS ROAD,
VEMPALAVATTOM, TRIVANDRUM - 695029
PH :9745998003.

1215. SARATHY AUTO DRIVES PVT LTD (1607-02),
KOVALAM BYEPASS,SN NAGAR, MANACAUD
(PO), TRIVANDRUM - 695009
PH :9947270665.

1216. INDUS MOTOR COMPANY PRIVATE LIMITED
(1602-05), G.G. MEDICAL COLLAGE P.O.,
MURINJAPALAM, TRIVANDRUM,
MURINJAPALAM, , 695011
PH :9745998002.

1217. POPULAR VEHICLES & SERVICES LTD.
(1601-05), OPP. ST. JUDE CHURCH,CIT ROAD,
KILLIPALAM,TRIVANDRUM - 695002
PH :9846298610.

1218. INDUS MOTOR COMPANY PRIVATE LIMITED
(1602-11), SURVEY NO. 3, TC-7/1069(9),
MARUTHAMKUZHI, SASTHAMANGALAM
VILLAGE, PTP NAGAR ROAD, KANJIRAMPARA
P.O, TRIVANDRUM - 695030
PH :9745088222.

1219. SOUTH PARK MOTORS PVT. LTD. (1604-01),
SURVEY NO. 985/3-4-5, VILLAGE -
KADAKAMPALLY, CHACKAL BYPASS, TALUKA -
TRIVANDRUM, TRIVANDRUM, KERALA. - 695029
PH :9526100008.

1220. SARATHY AUTO DRIVES PVT LTD (1607-03),
772/11, NEMOM VILLAGE, PAPPANAMCODU
INDUSTRIAL AREA, TALUKA AND DISTRICT-
THIRUVANANTHAPURAM, KERALA. - 695019
PH :9961665865.

1221. POPULAR VEHICLES (1601-12), RE-SURVEY
NO. 264-1, MANANTHALA STADIUM ROAD,
NEAR SURYAPRABHA AUDITORIUM, ULOR
VILLAGE, MANANTHALA, TRIVANDRUM DIST.,
KERALA. - 695 015
PH :9846498605.

1222. POPULAR VEHICLES (1601-17), BUILDING NO. 13/632,632-A, 633,633-A2,634-636, 6TH MILE STONE, VAZHAYILA PO, PEROORKADA, THIRUVANANTHAPURAM, KERALA - 695521 - 695521. PH : 9288022331.
1223. SARATHY AUTODRIVES PVT LTD (1607-01), SURVEY NO. 2448/4 VILL. MUTTATHARA, NH BYE PASS ROAD, KALLUMOOD JN., VALLAKADAU PO, ENCHAKKAL, THIRUVANANTHAPURAM, KERALA-695008 - 695008. PH : 9562416665.
- TRIVANDRUM-MANANTHALA**
1224. INDUS MOTOR COMPANY PRIVATE LIMITED (1602-08), NEAR MUSLIM JUMA MASJID, MUKKAM PLAMOODE, VATAPPARA-MANANTHALA M C ROAD, VATAPPARA PO, MANANTHALA,TRIVANDRUM - 695028 PH : 974540100.
- UPPALA**
1225. POPULAR VEHICLES & SERVICES LTD. (4702-0A), N.H.17, KAIKAMPA, UPPALA P.O., KASARGOD (KERALA) - 671322 PH : 8086078864.
1226. KVR CARS (4102-01), NH 17, BANDIYODE, MANGALAPADI (PO), UPPALA, KASARGOD DISTT, KERALA - 671324 PH : 9526021876.
- VADAKARA**
1227. INDUS MOTOR COMPANY PRIVATE LIMITED (4701-07), BYE PASS JN,VATAKARA-673104,CALICUT , - 673104 PH : 9745998021.
1228. POPULAR VEHICLES AND SERVICES (8S02-01), NEAR MADAPPALLY GOVT. COLLEGE, MADAPPALLY, P.O. VADAKARA, KOZHIKODE (KERALA) - 673102 PH : 8943345935.
- VALENCHARY**
1229. A M MOTORS (CKU1-01), SURVEY NO. 132/4, KOLAMGALAM, PERINTHALMANNA ROAD, VALANCHERY, DISTT-MALAPPURAM. - 676552 PH : 9745986666.
- VETTICHIRA**
1230. KVR AUTOCARS PVT LTD (7H01-03), AP IV, 75A TO G, NH-17, CHUNKAM, DIST. MALAPPURAM, VETTICHIRA . - 676552 PH : 9747020023.
- WADAKKANCHERY**
1231. BRD CAR WORLD LIMITED (A404-03), VAZHAKODE, CHELAKARA ROAD, MULLURKARA P.O., WADAKKANCHERY, THRISSUR DIST - 680583 PH : 9567869403.
- KERLA**
- EDAKKARA**
1232. KVR (GMN1-01), SURVEY NO. 1087/1C-91, VAZHIKADAVU VILLAGE, OOTY ROAD, MUNDA, EDAKKARA TOWN, NILAMBUR TALUK, MALAPPURAM DIST., KERALA - 679 331 PH : 9747020777.
- LEH**
1233. DRUK AUTOZONE (9S02-01), AIRPORT ROAD, LEH (LADAKH), DISTT. LADAKH, LEH - 194101 PH : 8082800205.
- LADAKH**
- MADHYA PRADESH**
- AGAR**
1234. UNITARA MOTORS (BJT2-01), 27, UJJAIN ROAD, NEAR MARKETING FUEL STATION, AGAR, MADHYA PRADESH (465669) - 465669 PH : 9575650883.
- ALIRAJPUR**
1235. RUKMANI MOTORS PVT. LTD. (GLY1-01), WARD NO 1, JHABUA ROAD, ALIRAJPUR, MADHYA PRADESH, MP - 457887 PH : 8889676035.
- ANUPPUR**
1236. SHUBH MOTORS PVT. LTD. (BIB1-01), NEAR HDFC BANK, TEHSIL ROAD, ANNUPUR - 484224 PH : 9752546255, 9755500145.
- ASHOK NAGAR**
1237. PREM MOTORS PVT. LTD. (DS01-02), SURVEY NO. 67/2/3, SINGAKHEDI HOUSE GUNA BYPASS NEAR RAJ MATA CIRCLE, ASHONAGAR, MADHYA PRADESH. - 473331 PH : 9926809856.
- ASHTA**
1238. JEEWAN MOTORS PVT. LTD. (BSF1-01), KHASRA NO.11/1 NEAR RELIANCE PETROL PUMP, BHOPAL ROAD, ASHTA, DISTT. SEHORE (M.P.) - 466001 PH : 9826429604 6264918307 871891122.
- BADNAWAR**
1239. PATEL MOTORS (INDORE) PVT. LTD. (BPT1-01), KHASRA NO. 21/94/1, BADNAWAR ROAD, BADI CHOPATI, OPPOSITE BSNL TOWER, BADNAWAR, DISTT. - DHAR, MADHYA PRADESH. - 474660 PH : 2322228, 9179653543.
- BADWHA / BARWAHA (BOTH NAMES ARE OK)**
1240. NIMAR MOTORS PVT. LTD. (AU01-05), NIRMAL COMPLEX, INDORE ROAD , BARWAH - 451001 PH : 7770878726, 9669569496.
- BALAGHAT**
1241. KUNAL MOTORS (U501-04), KH NO.-1/56, JHULELAL DHARSHHALA ROAD, BALAGHAT, MADHYA PRADESH - 481001 PH : 8349999181.
- BARELI**
1242. RAJURU MOTOR JUNCTION (A UNIT OF RMJ MOTORS PVT. LTD.) (I303-01), SURVEY 423/2, VILLAGE KAMTON, NH 12, BARELI, RAISEN, MADHYA PRADESH. - 464668 PH : 70909903922.
- BARI**
1243. SHUBH MOTORS PVT. LTD. (GMK1-01), 1286/2, BARIH, DIST. - KATNI, MADHYA PRADESH - 483770 PH : 9752546255.
- BARNAGAR**
1244. YUG CARS (A UNIT OF RUKMARANI CARS INDORE PVT. LTD) (BBK2-01), RUNJA ROAD ,BARNAGAR CITY, DISTRICT UJJAIN - 456771 PH : 9755512100/7898900224.
- BARWANI**
1245. NIMAR MOTORS PVT. LTD. (AU01-02), ANJAD ROAD, VILLAGE -KARAH, BARWANI, MADHYA PRADESH - 451551 PH : 7770804492, 9669569496.
- BEGAMGANJ**
1246. RAJURU MOTOR JUNCTION (A UNIT OF RMJ MOTORS PVT. LTD.) (CIL1-01), IN FRONT OF DUSHERRA MAIDAN, SAGAR BHOPAL ROAD, BEGAMGANJ, DIST - RAISEN , MADHYA PRADESH - 464881 PH : 7090997536.
- BEOHARI**
1247. SHUBH MOTORS PVT. LTD. (BKA1-01), REEVA ROAD, NEAR ARRAAR MACHINE, BEOHARI, DIST. -SHAHDOL, MADHYA PRADESH. - 484774 PH : 9755595423.
- BERASIA**
1248. RAJURU MOTOR JUNCTION (A UNIT OF RMJ MOTORS PVT. LTD.) (CKG1-01), BHOPAL ROAD, OPP. BERASIA HOSPITAL, BERASIA, DISTRICT - BHOPAL, MADHYA PRADESH. - 463106 PH : 8770593501.
- BETMA**
1249. OCEAN MOTORS PVT. LTD. (BVR1-01), OPPOSITE MPEB OFFICE, INDORE-AHMEDABAD ROAD, BETMA, DISTRICT - INDORE, MADHYA PRADESH . - 453001 PH : 7389936444.
- BETUL**
1250. KUNAL MOTORS (U501-02), BHOPAL - NAGPUR NATIONAL HIGHWAY, NEAR BADORA CHOWK,, BETUL - 460001 PH : 8349999177.
1251. KAMTHI MOTORS (KK02-01), NEAR SUNITA COLONY, ITARSI ROAD, BETUL, MADHYA PRADESH - 4600013 - 4600013 PH : 9111535777.
- BHAVRA**
1252. RUKMANI MOTORS (SPT1-01), GRAM PANCHAYAT, KALIYAVHO, OPP SUNKER MANDIR, BHAVRA TEHSIL, ALIRAJPUR DISTRICT, MADHYA PRADESH - 457882. - 457882 PH : 9755549200.
- BHITARWAR**
1253. NIKUNJ MOTORS (SRB1-01), BESIDE SAUSAR COTTON INDUSTRIES, CIVIL LINE, NAGPUR-CHHINDWARA ROAD, DABRA-BHITARWAR ROAD, BHITARWAR, MP - 474009 - 474009 PH : 9109105599.
- BHOPAL**
1254. JEEWAN MOTORS PVT. LTD. (302-01), 9E SECTOR A,INDUSTRIAL AREA, GOVINDPURA, BHOPAL - 462024 PH : 405888/ 9826017799 9826429605.
1255. SATYAM MOTORS (307-01), NH-12, SUVEESA NAGAR,HOSHANGABAD ROAD,MISROAD - 462040 PH : 6261900423.
1256. JEEWAN MOTORS PVT. LTD. (302-04), KHASRA NO. 54-65/1/1, NEAR RELIANCE FRESH,CHUNA BHATTI MAIN ROAD, INDIAN OIL PETROL PUMP, BHOPAL (M.P.) - 462036 PH : 4057988 9131364153.
1257. RAJURU MOTOR JUNCTION (A UNIT OF RMJ MOTORS PVT. LTD.) (308-01), 8A, SECTOR-C, J.K. ROAD, GOVINDPURA INDUSTRIAL AREA, BHOPAL, MADHYA PRADESH - 462023 PH : 4063529,30,31,32,33,34,35, 9926516501.
1258. DAGA MOTORS (A UNIT OF DAGA HEIGHTS) (309-01), 4/1, DAGA HEIGHTS, NEAR BUDHNA MANDIR, MAIN ROAD KOLAR ROAD, CHUNABHATTI, BHOPAL, MADHYA PRADESH. - 462016 PH : 9109900400.
- BIAORA**
1259. UNITARA (0F02-01), OLD AB ROAD, KACHNARIA, BIAORA (M.P) - 465674 PH : 9575650883.
- BIJURI**

Dealer Network (AS ON 31.10.2023)

1260. SHUBH MOTORS (SMJ1-01), GRAM - NEAR GENTRI GATE, NAGAR PALIKA PARISHAD BIJU, DISTRICT - ANUPPUR, MADHYA PRADESH - 484116 PH :9755580253.
- BINA**
1261. ADINATH CARS PRIVATE LIMITED (BHQ2-01), PLOT NO. 2/3/A/4 AMANTIGEL LAND SEMI URBAN INDUSTRIAL AREA, BINA, KHURAI ROAD (NH 26) BINA, DISTRICT - SAGAR, MADHYA PRADESH - 470113 PH :9009780047.
- BURHANPUR**
1262. NIMAR MOTORS PVT. LTD. (BRR1-01), KHASRA NO. 654/15-16, BASEMENT OF HOTEL AMBIKA RESIDENCY, OPP. PAKIZA SHOWROOM, SANJAY NAGAR, AMRAVATI ROAD, BURHANPUR, MADHYA PRADESH - 450331 PH :7694011374, 9669569496.
- CHAKGhat**
1263. CITY CARS (UNIT OF AGARWAL WHEELS) (GKQ1-01), GRAM AND POST - CHANDAI, CHAKGhat, TEHSIL - TEONTHOR, PRAGRAJ ROAD, NH 27, DIST - REWA, MP - 486226.. - 486226 PH :9754301199, 7354252525.
- CHATTarpur**
1264. ADINATH CARS PRIVATE LIMITED (B0B2-01), MAHABA ROAD, NEAR BUS STAND, CHHATARPUR, DISTT SAGAR - 471001 PH :9009785577.
- CHhanera**
1265. NIMAR MOTORS (SMX1-01), NEAR ST. STEPHEN SCHOOL, HARDA ROAD, CHHANERA (HARSUD), PIN-450001, MADHYA PRADESH - 450001 PH :9669569504.
- CHhindwara**
1266. KUNAL MOTORS (U501-03), OPP. KUNAL MOTORS SHOWROOM, LAL BAGH TIRAH, BEHIND TRUE VALUE OUTLET, NASIRABAD ROAD, CHHINDWARA(MP) - 480001 PH :9981852239.
1267. KUNAL MOTORS (U501-06), PLOT NO. 546, LAHARGAUR NEAR MULLU BABA MANDIR, NARSINGHPUR ROAD, CHHINDWARA, MADHYA PRADESH - 480002 PH :9981852239.
1268. KAMTHI MOTORS LLP (U502-01), KHASRA NO.1/53, BESIDE MMV SCHOOL, NAGPUR ROAD, VILL-SARRA, DISTT. CHHINDWARA, MADHYA PRADESH - 480001 PH :911148444/ 9111535777.
- CHitrakoot**
1269. CITY CARS (UNIT OF AGARWAL WHEELS) (GKS1-01), PILIKOTHI CHOORHA, BESIDE SINGH AUTOMOBILE- A HERO AGENCY, CHITRA ROAD, CHITRAKOOT, DISTRICT-SATNA (MADHYA PRADESH)- 485334 - 485334 PH :7089906823, 7354252525.
- DABRA**
1270. PREM MOTORS PVT. LTD. (BOR1-01), PICHHORE TIRAH, GWALIOR JHANSI ROAD, DABRA, DIST.-GWALIOR . - 475110 PH :9926809110.
- DAMOH**
1271. ADINATH CARS PRIVATE LIMITED (RD02-01), SAGAR JABALPUR BYPASS ROAD, DAMOH (M.P.) - 470661 PH :9009780035.
- DATIA**
1272. PREM MOTORS PVT. LTD. (3003-05-), NR.BHOJPURIA MOTORS, BHANDER ROAD, DATIA, MADHYA PRADESH - 475661 PH :9165012280.
- DEORI**
1273. ADINATH CARS PRIVATE LIMITED (CU01-01-), C/O VISHWANATH DIXIT, VIJAYSHRI GAS SERVICE, NEAR GOVT. HIGH SCHOOL, NARSINGHPUR ROAD,VILLAGE KHEER, DEORI DISTT, SAGAR (M.P.) - 470226 PH :7000410522.
- DEPALPUR**
1274. OCEAN MOTORS PVT. LTD. (WB01-03-), NEAR LEELA RESIDENCY,INDORE ROAD,DEPALPUR,DIST.INDORE-MP - 453115 PH :220505, 22501.
- DEwas**
1275. UNITARA MOTORS PVT LTD (3Q02-01-), SURVEY NO 255, A.B. ROAD, RASULPUR SQUARE, DEWAS, MADHYA PRADESH PIN 455001 - 455001 PH :9575650883.
- Dhamnod**
1276. KATHED MOTOCORP(A UNIT OF KATHED MOTORS PVT. LTD.) (UT01-01), KHASRA NO. 484/1/2, OLD A B ROAD, OPPOSITE HP PETROL PUMP, DHAMNOD, DIST-DHAR, MADHYA PRADESH. - 454552 PH :998158165.
- Dhar**
1277. RUKMANI MOTORS (P) LTD (5304-02-), 41/ MAGAJPURA,DHAR., - 454001 PH :0731-223500, 9755549200.
- Dindori**
1278. STANDARD MOTOCORP PVT LTD (AVA2-01-), SUKKHAR WARD 1, NEAR DHURVE PETROL PUMP,DINDORI - 481661 PH :280300,7771014728 911124709.
- Fali**
1279. OCEAN MOTORS (SGH1-01-), NH 47, NEAR GRAM - FALI, TEHSIL KHUDEL, INDORE, MADHYA PRADESH. - 452016 PH :7389936477.
- Gadarwara**
1280. STANDARD MOTOCORP PVT LTD (BOI3-01-), KHASRA NO. 130/31/A & 131/2, HALKA NO. 18/1, NO. 119, GADARWARA, DISTRICT – NARSINGHPUR. - 487551 PH :8319784336.
- Gandhwani**
1281. RANA MOTORS (S101-01-), MUKATI COMPLEX, BAGH AWALDA MAAN ROAD, TEHSIL- GANDHWANI , DIST – DHAR, MADHYA PRADESH - 454446 - 454446 PH :9109975566.
- Ganj Basoda**
1282. DAGA MOTORS (A UNIT OF DAGA HEIGHTS) (AE02-01-), LAL BAGH, BARETH ROAD, GANJ BASODA, VIDISHA, 464221. - 464221 PH :9425148584.
- Garra**
1283. KAMTHI MOTORS LLP (GJC1-01-), LALBARA ROAD, GARRA INDUSTRIAL AREA, GARRA, BALAGHAT, MADHYA PRADESH. - 481331 PH :7723020684.
- Gautampura**
1284. OCEAN MOTORS PVT. LTD. (CFW1-01-), RUNJI CHOORHA, GAUTAMPURA, TEHSIL - DEPALPUR, DISTT.-INDORE, MADHYA PRADESH. - 453220 PH :230501, 7389937314.
- Ghatiya**
1285. YUG CARS (SJW1-01-), NEAR JAGOTI SQUARE, UJJAIN – AGAR ROAD, GHATIYA, MP - 456550 - 456550 PH :9425067979.
- Goteagan**
1286. STANDARD MOTOCORP PVT LTD (BLY2-01-), JABALPUR ROAD, OPP. NEW KRISHI UPAJ MANDI, TEHSIL - GOTEAGAN, DIST. -NARSINGHPUR. - 443 001 PH :7771003774.
- Guna**
1287. PREM MOTORS PVT. LTD. (S301-01-), OPP R.T.O.,A,B. ROAD,GUNA. - 473001 PH :268015.
- GWALIOR**
1288. PREM MOTORS PVT. LTD. (3003-01-), M. L. B. ROAD,GWALIOR. - 474002 PH :9926809803.
1289. PREM MOTORS PVT. LTD. (3005-01-), SHIVPURI LINK ROAD, GWALIOR - 474002 PH :9926809803.
1290. NIKUNJ MOTORS (3006-01-), GOLE KA MANDIR SQUARE, AIRPORT ROAD, GWALIOR, MADHYA PRADESH - 474005 - 474005 PH :9407067974.
- HALALPURA - BHOPAL**
1291. DAGA MOTORS (309-02-), KHASRA NO. 80/1/K, VILLAGE - HALALPURA, TEHSIL - HUZUR, DISTRICT - BHOPAL, MADHYA PRADESH. - 462030 PH :9109900365.
- Hansa Khedi**
1292. KATHED MOTOCORP (SGI1-01-), MAIN DHARMAT ROAD, HANSA KHEDI (CHANDRAWATI GANJ), TEHSIL - SANWER, DISTRICT -INDORE, MADHYA PRADESH. - 453551 PH :9479952490.
- Harda**
1293. INFINITY CARS (A UNIT OF FOUZDAR CARS PVT. LTD) (KM01-02-), NEAR RTO,INDORE HIGHWAY ROAD,HARDA MP - 461331 PH :8889284444, 8889282222.
- Hatod**
1294. OCEAN MOTORS PVT. LTD. (BVT1-01-), 726/6, INDORE-DEPALPUR MAIN ROAD, OPP. HP GAS AGENCY, HATOD DISTT. INDORE - 453111 PH :7389936477.
- Hatta**
1295. ADHINATH MOTORS (SKK1-01-), NEAR NAVODAYA SCHOOL, DAMOH ROAD, HATTA, DISTT. DAMOH (M.P.) - 470775. - 470775 PH :900978562.
- Hoshangabad**
1296. INFINITY CARS (A UNIT OF FOUZDAR CARS PVT. LTD) (KM01-01-), 185, RAMJIBABA GROUND, HOSHANGABAD, MADHYA PRADESH - 461001 PH :8889282222.
- Ichhawar**
1297. RAJRUP MOTOR JUNCTION (A UNIT OF RMJ MOTORS PVT. LTD.) (CIIK1-01-), SEHORE NADAN ROAD, NEAR SARASWATI SCHOOL, ICHHAWAR, DISTRICT – SEHORE, MADHYA PRADESH. - 461115 PH :9399061645/ 9926516501.
- Indergarh**
1298. PREM MOTORS (SPU1-01-), NEAR KHERAPATI GARDEN, INDERGARH, MP - 475675. - 475675 PH :9926809818.

INDORE

1299. PATEL MOTORS (INDORE) PVT. LTD. (5303-01-), 428/33,NIRANJANPUR,A B ROAD,INDORE - 452010 PH :99777-03609/99777-03512.
1300. RUKMANI MOTORS (P) LTD (5304-01-), 2-3,A.B. ROAD,INDORE - 452001 PH :99071-57890/90390-88702.
1301. PATEL MOTORS (INDORE) PVT. LTD. (5303-02-), 176/1,PIPLYA RAJ,A,B ROAD ,INDORE - 452017 PH :99777-03512/99777-03260.
1302. RUKMANI MOTORS (P) LTD (5304-03-), NO. -4/5, MANORAMA GANU ,INDORE - 452001 PH :99071-57890/90390-88702.
1303. OCEAN MOTORS PVT. LTD. (5306-01-), PLOT NO.49, SCHEME NO.97, PART 4, COMMERCIAL MANDI, CAIT SQUARE, RING ROAD, INDORE, MP. - 452001 PH :6627500, 6627505.
1304. OCEAN MOTORS PVT. LTD. (5306-02-), NEAR QUEENS COLLEGE,ASHARAM BAUP ASHRAM, KHANDWA ROAD,INDORE - 452017 PH :6617505,2877505.
1305. PATEL MOTORS (INDORE) PVT. LTD. (5303-03-), M.O.G. LINES, NEAR GANGWAL BUS STAND, DHAR ROAD, INDORE (M.P.) - 452006 PH :7314293919.
1306. OCEAN MOTORS PVT. LTD. (5306-03-), 171A, 174A, 175A, 180A, 181A, 182A, BRAJESHWARI EXTENSION, PIPLIYAHANA, INDORE - 452001 PH :9685333331,7389936451.
1307. KATHED MOTOCOPRA (UNIT OF KATHED MOTORS PVT. LTD.) (5307-01-), PLOT NO. 483/22, MAIN DHAR ROAD, NEAR CHANDAN NAGAR POLICE STATION, INDORE, MADHYA PRADESH. - 452002 PH :7471111132.
1308. RANA MOTORS (5308-01-), KHASRA NO. 293/2, 299/1, TEJPUR, GADBADI PUL, A.B. ROAD, INDORE. - 452009 PH :9109795566.
1309. PATEL MOTORS (INDORE) PVT. LTD. (5303-05-), SURVEY NO. 174/5 AND 174/6, PIPLYA RAO, INDORE, MADHYA PRADESH. - 452012 PH :99777-03512/99777-03260.
1310. RUKMANI MOTORS (P) LTD (5304-04-), MANGAL COMPOUND, GODOWN NO. 11-12, VILLAGE 15/1, PIPLYA KUMAR, MR 11 RING ROAD, DEWAS NAKA, INDORE, MADHYA PRADESH. - 452010 PH :99071-57890/90390-88702.
1311. OCEAN MOTORS PVT. LTD. (5306-04-), PLOT NO. 142 AND 151, SCHEME NO. 97, PART-4, COMMERCIAL MANDI, NEAR CAT SQUARE, INDORE. - 452012 PH :7389936405.

JHABUA

1312. KTL AUTOMOBILES (5309-C1-), PLOT NO.5/RC, SCHEME NO 134,MR 10,VILLAGE KHAJRANA, DIST INDORE-452010,MADHYA PRADESH - 452010 PH :6263455899.
1313. RUKMANI MOTORS (P) LTD-C4 (5304-05-), 109, BHAWRASLA NEAR PRATAP AUTO, FRONT OF VINAYAK TOI, KANTE, SANWER ROAD, INDORE, PIN-453111, MADHYA PRADESH - 453111 PH :9109778301.
- JABALPUR**
1314. STANDARD MOTOCOP PVT LTD (5405-01-), OPPOSITE ALLAHABAD BANK DELITE TALKIES ROAD,CIVIL LINES, JABALPUR - 482001 PH :4040405 / 4040406 07771003012 07771003374.
1315. SHUBH MOTORS (5403-01-), MAHANADDA, MADAN MAHAL ROAD, JABALPUR, MADHYAPRADESH - 482001 PH :9755545549.
1316. STANDARD MOTOCOP PVT LTD (5405-02-), DEENDAYAL CHECK, DAMOH NAKA, JABALPUR - 482002 PH :4038001 9301190205 7771006920.
1317. SHUBH MOTORS PVT LTD (5403-03-), 156/5/1, 156/3KA, 156/3KHA, 156/3GHA, BEHIND OM PETROLEUM, ADHARTAL TIRAH, JABALPUR, MADHYA PRADESH - 482002 PH :9755554996.
1318. STANDARD MOTOCOP PVT LTD (5405-03-), CHIMNEY PLOT, MADAN MAHAL, NEAR GUILZAR HOTEL, JABALPUR - 482001 PH :9303568517 9300008708.
1319. MAA YATRI (AGGARWAL) (5404-01-), MOUZA KARMETA N.B. 497, P.H. NO 23/26, KHASRA NO. 497 & DIV. KHASRA NO. 486/4, DIV. SHEET NO 2, PLOT NO 63/1, JABALPUR-PATAN ROAD, JABALPUR. - 482002 PH :7489901021.
1320. STANDARD MOTOCOP PVT LTD (5405-04-), NEW WARD NO. 71, IN FRONT OF ORIENTAL COLLEGE, KATNI BYPASS, JABALPUR, MP. - 482003 PH :7800806222 9303568517.
- JAORA**
1321. PATEL MOTORS (INDORE) PVT. LTD. (P801-04-), SURVEY NO.57/11/1, RATLAM ROAD, RATLAM NAKA, OPP. KOTHARI AGRIKO, INDUSTRIAL AREA, INFRONT OF S. PAUL SCHOOL, JAORA, DIST. RATLAM, MADHYA PRADESH - 457226 PH :243399, 7089901505, 9926932221.

JHABUA

1322. PATEL MOTORS (INDORE) PVT. LTD. (AAR1-01-), INDORE AHMEDABAD ROAD, MEHGHNAGAR NAKA, JHBABA, MADHYA PRADESH. - 457661 PH :9826634449.

JOBAT

1323. RUKMANI MOTORS (SOA1-01-), BYEPASS ROAD, OPPOSITE JP COLLEGE, JOBAT, MP - 457990. - 457990 PH :6262505181.

KARERA

1324. PREM MOTORS (SMO1-01-), GRAM - JHASI ROAD, KARERA, DISTRICT - SHIVPURI, MADHYA PRADESH - 473660. - 473660 PH :9926823596. 07771003374.

KATNI

1325. SHUBH MOTORS PVT LTD (FK01-01-), KHASRA NO.850, NH-7, JHNIRAJ, INFRONT OF POLICE STATION, JABALPUR ROAD, KATNI, MADHYA PRADESH. - 483501 PH :9755515839.

KHANDWA

1326. NIMAR MOTORS PVT. LTD. (AU01-03-), BEFORE VIKAS UDYOG, INDORE ROAD, KHANDWA - 450001 PH :95755105697, 9669569496.

KHARGONE

1327. NIMAR MOTORS PVT. LTD. (AU01-01-), JETAPUR,SANAWAD ROAD,KHARGONE, - 462026 PH :9669569504, 9669569496.
1328. NIMAR MOTORS PVT. LTD. (AU01-06-), PH. NO. 35, VILLAGE - DANAPUR, TEHSIL - KHARGONE, DISTRICT - KHARGONE, MADHYA PRADESH. - 451001 PH :7694011436, 9669569496.

KHATEGAON

1329. UNITARA (BXB2-01-), NEMAWAR-INDORE ROAD, KHATEGAON, M.P. - 455336 - 455336 PH :9993406993.

KOTMA

1330. SHUBH MOTORS (D001-01-), WARD NO.7, ANNUPPUR KOTMA ROAD, DISTT. ANNUPUR, KOTMA (M.P.) - 484336 PH :9755581441.

KUKSHI

1331. OCEAN MOTORS PVT. LTD. (BIO1-01-), SURVEY NO.593/1, 593/6/1, BARWANI ROAD, TOLL KANTE KE PASS, TEHSIL-KUKSHI - 454331 PH :900978030, 7389945443, 8085999990.

LAKHNADON

1332. KAMTHI MOTORS LLP (SCL1-01-), RANI DURGAVATI CHOWK, NH-7, WARD NO. - 05, JABALPUR ROAD, LAKHNADON, MADHYA PRADESH. - 480886 PH :9285506128.

MAHESHWAR

1333. NIMAR MOTORS (SHH1-01-), OPPOSITE DEVRAJ HOTEL, MAIN MANDLESHWAR-DHAMNOD ROAD, MAHESHWAR, MP - 451224 PH :9669569504.

MAHIPUR

1334. YUG CARS (A UNIT OF RUKMARANI CARS INDORE PVT. LTD) (CWN1-01-), 264/3, BHIMAKHEDA, MAHIPUR, UJJAIN - 456443 PH :9109130402.

MAIHAR

1335. CITY CARS (UNIT OF AGARWAL WHEELS) (D702-04-), UNIT OF AGARWAL WHEELS PVT. LTD, NEAR RELIANCE PETROL PUMP, NH-7, REWA ROAD, MAIHAR (M.P.) - 485771 PH :7354252525.

MAJHAULI

1336. CITY CARS (SPN1-01-), WARD NUMBER 14, NAGAR PARISAD MAJHAULI, DIST. SIDHI (M.P.) - 486666. - 486666 PH :7970003171.

MAJHOLI

1337. SHUBH MOTORS (STJ1-01-), INDRANA ROAD, SUHANI TIRAH, MAJHOLI, MADHYA PRADESH - 483336 PH :9111155580.

MANASA

1338. PATEL MOTORS (INDORE) PVT. LTD. (BZX1-01-), 982/1, RAMPURA ROAD, MANASA, DIST. NEEMUCH, MADHYA PRADESH. - 458110 PH :9644405368.

MANAWAR

1339. OCEAN MOTORS PVT. LTD. (BVS1-01-), NEAR SHANTIKUNJ COLONY, INDORE-MANAWAR MAIN ROAD, TEHSIL - MANAWAR, DISTRICT - DHAR. - 454335 PH :7389936477.

MANDLA

1340. STANDARD MOTOCOP PVT LTD (WD02-01-), KATARA ROAD, MANDLA, DIST. MANDLA MP - 481661 PH :260600,260622 9301090184 8959280989.

MANDSAUR

Dealer Network (AS ON 31.10.2023)

1341. PATEL MOTORS (INDORE) PVT. LTD.,
(WC01-01), NEAR SHIVANA BRIDGE,RATLAM
MANDSAUR ROAD,MANDSAUR - 458001
PH :07422-400450, 220372.
1342. PATEL MOTORS (INDORE) LTD.,
(WC01-02), BLOCK 'C', SHED-5, WARD NO. 1,
INDUSTRIAL AREA, CITY - MANDSAUR,
MADHYA PRADESH - 458001
PH :07422-400450, 220372.
- MANPUR**
1343. PATEL MOTORS (INDORE) PVT. LTD., (BRL1-01-),
KHASRA NO. 302/1/3, AB ROAD, MANPUR, DIST-
INDORE - 453661
PH :9826360699.
- MAUGANJ**
1344. CITY CARS (SEY1-01-), NEAR SENGAR PETROL
PUMP, CHACK MODE WARD NUMBER 03,NH 7
.MAUGANJ, DISTT - REWA, MADHYA PRADESH
- 486331, - 486331
PH :975301199.
- MHOW**
1345. OCEAN MOTORS PVT. LTD., (WA01-01-), A.B.
ROAD, NEAR KISANGANJI POLICE STATION,
MHOW - 453441
PH :7389936478, 266211.
- MORENA**
1346. PREM MOTORS PVT. LTD., (RG01-01-), NEAR
SALES TAX BARIER SQUARE, AB ROAD
MORENA - 476001
PH :9926002791.
- NAGDA**
1347. YUG CARS (A UNIT OF RUKMARANI CARS
INDORE PVT. LTD) (CHR2-01-), PLOT NO. 17,
STATE HIGHWAY NO.17, INDORYA ROAD,
NAGDA, DISTRICT - UJJAIN, MADHYA
PRADESH - 456335
PH :9255044300/9755512100.
- NARAYANGARH**
1348. PATEL MOTORS (SFN1-01-), 1742/11,
NARAYANGARH, TEHSIL - MALHARGARH,
DISTRICT - MANDSAUR, MADHYA PRADESH. -
458553
PH :9977703907.
- NARSINGHPUR**
1349. STANDARD MOTOCORP PVT LTD (BB02-01-),
KH. NO. 8244 & 8344, NB NO.519, PC NO.
19(42), OLD 46 (NEW) MOUZA RONRA R.I.M. 2,
TEHSIL & DISTRICT - NARSINGHPUR, MADHYA
PRADESH. - 487001
PH :232757
9303513711.
- NASRULLAGANJ**
1350. JEEWAN MOTORS PVT. LTD. (CIN1-01-),
KHASRA NO. 458, VILLAGE - RALA, TEHSIL -
NASRULLAGANJ, DISTRICT - SEHORE,
MADHYA PRADESH. - 466331
PH :9826017799, 8959900110.
- NEEMUCH**
1351. PATEL MOTORS (INDORE) PVT. LTD. (P801-02-),
MHOW-NEEMUCH ROAD,NEEMUCH(MP)., -
458441
PH :9977703907.
- NIWARI**
1352. ADINATH MOTORS (SFC1-01-), ATKHASRA NO
2017/1, NEAR HDFC BANK MAIN ROAD, NIWARI,
MADHYA PRADESH - 472442 - 472442
PH :9009787562.
- PANDHURNA**
1353. KAMTHI MOTORS (SFG1-01-), SHANKAR
NAGAR, PANDHURNA, DIST. - CHHINDWARA,
MADHYA PRADESH - 480334 - 480334
PH :9111535777.
- PANNA**
1354. CITY CARS (UNIT OF AGARWAL WHEELS)
(E001-01-), KHASRA NO. 378, MOHAN RAJ
VILAS CHOURAH, BESIDE MOHAN RAJ HOTEL,
CIVIL LINE NH-75, PANNA, MADHYA PRADESH .
- 488001
PH :7354252525.
- PARASIA**
1355. KAMTHI MOTORS LLP (GKF1-01-),
KHRSADOHMAL, PARASIA, CHHINDWARA, MP -
480441
PH :9285506109.
- PATAN**
1356. MAA GAYATRI (SHP1-01-), BESIDE KRISHI UPAJ
MANDI, PATAN, PIN-463119, MADHYA PRADESH
- 483119
PH :9770415141.
- PAWAI**
1357. CITY CARS (UNIT OF AGARWAL WHEELS)
(SIX1-01-), NEAR ETORI PETROL PUMP, PANNA
ROAD, PAWAI, DIST. - PANNA, MP- 488446 -
488446
PH :9754301199.
- PETLAWAD**
1358. PATEL MOTORS (INDORE) PVT. LTD. (CJD1-01-),
NEAR H. P. PETROL PUMP, THANDLA ROAD,
PETLAWAD, DISTRICT - JHABUA, MADHYA
PRADESH. - 457773
PH :9111160868.
- PIPIARIYA**
1359. INFINITY CARS (A UNIT OF FOUDZAR CARS
PVT. LTD) (CGB1-01-), HATHWAS TIRAH,
SHOBHAPUR ROAD, PIPARIYA, MADHYA
PRADESH. - 461775
PH :888928555, 8889282222.
- PITHAMPUR**
1360. PATEL MOTORS (INDORE) PVT. LTD. (5303-04-),
254-A, SECTOR-1, INDUSTRIAL AREA,
PITHAMPUR, DISTT. DHAR - 454775
PH :9826360699.
- RAISEN**
1361. RAJRUP MOTORS (RF03-01-), OPPOSITE S P
OFFICE, NEAR ST. FRANCIS SCHOOL, VIDISHA
ROAD, RAISEN, MADHYA PRADESH. - 464551
PH :7869755501.
1362. JEEWAN MOTORS (RF02-01-), WARD NO 14,
PATANDEV, SAGAR ROAD, RAISEN, MADHYA
PRADESH - 464551
PH :9826017799.
- RAJGARH**
1363. RUKMANI MOTORS (P) LTD (GKE1-01-),
CHANDRA SHEKHAR AZAD MARG, NEAR
TRIMURTI NAGAR, RAJGARH, DIST. - DHAR, MP.
- 454116
PH :9755549200.
- RATLAM**
1364. PATEL MOTORS (INDORE) PVT. LTD. (P801-01-),
76 C,D&E,INDUSTRIAL AREA,RATLAM - 452001
PH :99269-32221/93404-31858.
1365. PATEL MOTORS (INDORE) PVT. LTD. (P801-03-),
181/17/18,DOSHI GOAN,INDUSTRIAL AREA
,JAORA ROAD,RATLAM - 457001
PH :99269-32221/93404-31858.
- REWA**
1366. CITY CARS (UNIT OF AGARWAL WHEELS)
(D702-03-), NYPASS CHURHATA,DIST. REWA -
482001
PH :7354252525.
1367. SHUBH MOTORS (5403-05-), VILLAGE -
RATHARA, TEHSIL - HUZUR, DISTRICT - REWA,
MADHYA PRADESH - 486003 - 486003
PH :9755562351.
- SADALPUR**
1368. OCEAN MOTORS (SPS1-01-), JAIN SHRI SUPER
MARKET, SERVICE ROAD, MHOW- NEEMUCH
ROAD, SADALPUR, DISTRICT DHAR (M.P.) -
454001. - 454001
PH :7389936423.
- SAGAR**
1369. ADINATH CARS PRIVATE LIMITED (G102-01-),
STATION ROAD, TILAK GANJ, SAGAR (M.P.) -
470001
PH :9009780030.
- SANWER**
1370. RANA MOTORS PVT LTD (CWX1-01-), S.NO.
356/3/1, OLD UJJAIN BYPASS ROAD, TALUKA -
SANWER, DIST.-INDORE, MADHYA PRADESH. -
453551
PH :9109975566.
- SATNA**
1371. CITY CARS (UNIT OF AGARWAL WHEELS)
(D702-05-), (A UNIT OF AGRAWAL WHEELS PVT.
LTD.), BESIDE BHASKAR PRESS, BEHIND
MARUTI SHOWROOM, WARD NO.27, AMOUDHA
KALA, PANNA ROAD, SATNA - 485001
PH :9754301199, 7354252525.
- SAUSAR**
1372. KAMTHI MOTORS (SRX1-01-), BESIDE SAUSAR
COTTON INDUSTRIES, CIVIL LINE,
NAGPUR-CHHINDWARA ROAD, SAUSAR,
DIST-CHHINDWARA, M.P. - 480106. - 480106
PH :9111535777.
- SEHORE**
1373. JEEWAN MOTORS PVT. LTD. (302-02-),
869/1/2,OFFICERS COLONY,IN FRONT OF
CHURCH GROUND,BHOPAL, INDORE ROAD -
466001
PH :2226400
9926009735.
- SENDHWA**
1374. NIMAR MOTORS PVT. LTD. (CIH1-01-), KHASRA
NO. 286/10 AND 287/14, HALKA NO. 11, VARLA
ROAD, SENDHWA, TEHSIL - SENDHWA,
DISTRICT - BARWANI, MADHYA PRADESH. -
451666
PH :7694011408, 9669569496.
- SEONI**
1375. KUNAL MOTORS (U501-05-), JYARAT NAKA,
JABALPUR NAGPUR ROAD, SEONI (M.P.) -
480661
PH :8349999269.
- SEONI MALWA**
1376. INFINITY (SRW1-01-), NEAR AXIS BANK, SEONI
MALWA, MP - 461223 - 461223
PH :8889281113.
- SHADOL**
1377. SHUBH MOTORS (MF01-01-), JAMUA, NEAR
GYAN GUPTA,BUDHAR ROAD,SHADOL, -
484771
PH :9755595423.
- SHAHPURA**
1378. STANDARD MOTOCORP PVT LTD (CRD2-01-),
KHASARA NO.17/3, BHERAV MATA MANDIR
NEAR TOLL NAKA MAIN ROAD, JABALPUR
NARSINGHPUR ROAD, SHAHPURA. - 483119
PH :7771000392.
- SHAJAPUR**

1379. UNITARA (RH03-01), LAL GHATI, A B ROAD, SHAJAPUR, MP - 465001
PH : 9993406993.
- SHAMGARH**
1380. PATEL MOTORS (INDORE) PVT. LTD. (BFZ1-01-), KHASRA NO. 1179/1, MOHALLA MAROTH, TEHSIL - SHAMGARH, DISTRICT - MANDSAUR, MADHYA PRADESH. - 458883
PH : 9753082222.
- SHIVPURI**
1381. PREM MOTORS PVT. LTD. (3003-04-), A B ROAD,SIVPURI., - 473551
PH : 9926809976.
- SHUJALPUR**
1382. UNITARA (BGP2-01-), KISHONI, OPPOSITE HP FUEL STATION, SHUJALPUR, M.P. - 465333 - 46533
PH : 9575650883.
- SHYAMPUR**
1383. DAGA MOTORS (SJX1-01-), NEAR MAHADEV RESTAURANT, NH-12, SHYAMPUR, DISTRICT - SEHORE, MADHYA PRADESH - 466651. - 466651
PH : 7909997570.
- SIDHI**
1384. CITY CARS (UNIT OF AGARWAL WHEELS) (BKML-01-), ADHYAR KHOC, NEAR GYAN DHARAMKATA, SIDHI, MADHYA PRADESH. - 486661
PH : 9754301199, 7354252525.
- SIHORA**
1385. SHUBH MOTORS PVT. LTD. (CIG1-01-), KHASRA NO. 31/1, P.H. - 11, MOUZA - GHAT SIMARIYA, TEHSIL - SIHORA, DISTRICT - JABALPUR, MADHYA PRADESH., - 483440
PH : 9755099971, 9752546255.
- SILWANI**
1386. RAJURUP (SRP1-01-), MAHAVIR COLONY, SAI KHEDA ROAD, SILVANI, DIST. RAISEN, MP - 464886 - 464886
PH : 9174000501.
- SIMROL**
1387. RUKMANI MOTORS (BZV2-01-), AMRIT SAGAR COLONY, SIMROL, DIST. - INDORE, MADHYA PRADESH - 452020 - 452020
PH : 910978301.
- SINGHOLI**
1388. PATEL MOTORS (SEO1-01-), BEGHU CHITTORGARH ROAD, SINGOLI, NEEMUCH, MP - 468228 - 468228
PH : 9977703907.
- SIRONJ**
1389. RAJURUP MOTOR JUNCTION (A UNIT OF RMJ MOTORS PVT. LTD.) (CVM1-01-), OPPOSITE BALAJI DHAM, LINK ROAD, SIRONJ, MADHYA PRADESH. - 464228
PH : 7909997585.
- SITAMAU**
1390. PATEL MOTORS (SLL1-01-), MAUKHEDA, TEHSIL - SITAMAU, DISTRICT - MANDAUR, MADHYA PRADESH - 458990 - 458990
PH : 9826360699.
- TARANA**
1391. YUG CARS (A UNIT OF RUKMARANI CARS INDORE PVT. LTD) (CHQ2-01-), HOUSE NO. 1/6, WARD NO. 10, TOTLA MARG, TARANA-UJJAIN ROAD, TARANA, MADHYA PRADESH . - 456665
PH : 9893563031/9755512100.
- TENDUKHEDA**
1392. STANDARD MOTOCOPRO PVT LTD (CRC2-01-), KHASRA NO. 49/6, MOUZA - TENDUKHEDA, DISTRICT - NARSINGHPUR. - 470880
PH : 7771014773.
- THIKRI**
1393. NIMAR CAR (SED1-01-), OPPOSITE OF SHREE BALAJI TYRE SALES & SERVICE, SHREE NAGAR, THIKRI, MADHYA PRADESH - 451660. - 451660
PH : 9109202186.
- TIKAMGARH**
1394. ADINATH CARS PRIVATE LIMITED (RE02-01-), NEAR NEW BUS STATION, OPPOSITE OF SHREE BANKE BIHARI COLONY, MAURANIPUR ROAD,TIKAMGARH, MADHYA PRADESH - 472001
PH : 9200888454.
- UDAIPURA**
1395. JEEWAN (SCI1-01-), WARD NO 3, NH-12, UDAIPURA, DIST. - RAISEN, MADHYA PRADESH - 464770
PH : 9826017799.
- UJJAIN**
1396. YUG CARS (A UNIT OF RUKMARANI CARS INDORE PVT. LTD) (3W03-01-), SURVEY NO. 59/3, DEWAS ROAD,UJJAIN - 456010
PH : 0734-2524002, 9755512100.
1397. YUG CARS (3W03-02-), 54/32, AGAR NAKA, NEAR VARDHAN HOTEL, MAKODI AAM CHAURHA, INDIA NAGAR, UJJAIN, MADHYA PRADESH. - 456001
PH : 9425067979.
- UMARIA**
1398. SHUBH MOTORS (5403-04-), 8/2 GRAM BHAGRA, KIRANTAL KHURD, UMARIA DISTRICT UMARIA (MADHYA PRADESH) - 484661
PH : 9755502682.
- VIDHISHA**
1399. DAGA MOTORS (A UNIT OF DAGA HEIGHTS) (AY02-01-), PLOT NO 59/1, VILLAGE RANGAI, VIDISHA, MADHYA PRADESH - 464001
PH : 9109990374.
- VIDISHA**
1400. RAJURUP (AY03-01-), UDAYNAGAR COLONY, NEAR OIL FACTORY, SAGAR ROAD, VIDISHA, DISTRICT-VIDISHA (M.P.) - 464001 - 464001
PH : 7869755501.
- WAIDHEN**
1401. CITY CARS (UNIT OF AGARWAL WHEELS) (D702-02-), NEAR VIJAY BANDHU PETROL PUMP, KACHANI, THE. WAIDHEN, DISTRICT, SINGRAULI,MADHYA PRADESH - 486886
PH : 7354252525.
- MAHARASHTRA**
- AHMEDNAGAR**
1402. KANKARIYA AUTOMOBILES PVT. LTD. (A501-12), SARDA MILLS,SAVEDI ROAD,AHMEDNAGAR, MAHARASTRA - 414001
PH : 7410024227.
1403. KANKARIYA AUTOMOBILES PVT. LTD. (A501-05), MIDC, AHMEDNAGAR - 414003
PH : 7447700029.
- AJARA**
1404. SAI SERVICE PRIVATE LIMITED (CIR1-01-), GAT NO. 30, PLOT NO. 24, GP MILKAT NO. 906/3, NEAR MAYUR PETROL PUMP, AJARA, DISTRICT - KOLHAPUR. - 416505
PH : 7776837717, 9673331977.
- AKLUJ**
1405. CHAVAN MOTORS DIVISION INDIA PVT LTD (B102-04-), PLOT NO. 15/A, PANCHVATI STOP,MALINAGAR ROAD AKLUJ - 413101
PH : 0217-22303/8805986848.
- AKOLA**
1406. KHANDELWAL AUTOWHEELS PVT. LTD. (F101-01-), TIRUPATI CHAMBERS,CONVENT ROAD AKOLA . - 444005
PH : 9767892552/9112220551.
1407. KHANDELWAL AUTOWHEELS PVT. LTD. (F101-02-), PLOT NO E/12-13-MIDC PHASE-2, AKOLA . - 444001
PH : 9767892552/9112220551.
- AKOT**
1408. KHANDELWAL AUTO (SMN1-01-), PLOT NO 18 & 19, SURVEY NO 6003, AKOT - AKOLA ROAD, AKOT, AKOLA (MAHARASHTRA) - 444101 - 444101
PH : 9112220551, 9767892552.
- ALEPHATA**
1409. KOTHARI AUTO WHEELS PVT LTD (CSZ2-01-), GAT NO.446, MATOSHRI PRIDE, NEAR SADHANA BANK, KALYAN ROAD, A/P - ALEPHATA, TALUKA - JUNNAR, DISTT. PUNE, PIN:412411 - 412411
PH : 8421753278.
- ALIBAUG**
1410. SIMRAN MOTORS PVT. LTD. (7501-05-), SURVEY NO. 30/1, OPP. RCF COLONY, VILLAGE - VESHLI, ALIBAUG, DISTRICT - RAIGAD, MAHARASHTRA - 402201
PH : 9223161512, 9270888786.
- AMALNER**
1411. MANRAJ MOTORS (EL01-01-), PRASAD MOTORS, RAVI NAGAR, NEAR NAYARA PETROL PUMP, DHULE ROAD, AMALNER, DIST.JALGAON-425401. - 425401
PH : #N/A.
- AMBERNATH**
1412. AHER AUTOPRIME LLP (COP1-01-), PLOT NO-24,26,27/17, MIDC, KALYAN-BADLAPUR ROAD, VILLAGE - KOHOJ, KHUNTAVLI, AMBERNATH - 421501
PH : 8422871720.
- AMRAVATI**
1413. ASPA BANDSONS AUTO PVT. LTD., SATURNA BADNERA ROAD,AMRAVATI,MAHARASTRA . - 444607
PH : 9423123665.
1414. ASPA BANDSONS AUTO PVT. LTD. (F201-05-), A/1/A, OLD BY PASS ROAD, MIDC, AMRAVATI, DIST: AMRAVATI, MAHARASTRA . - 444607
PH : 9423339601.
- APTA**
1415. K.T.S. AUTOMOTORS PVT. LTD. (582-01-), VILLAGE: APTA, OPP. APTA RAILWAY STATION, LADIWALI, DIST: RAIGAD, PANVEL (MAHARASHTRA) - 410207
PH : 9420611356/94206611326.
- ARVI**
1416. SEVA AUTOMOBILES (SMF1-01-), PLOT NO-7, SURVEY NO-32/7, MAUZA-AHMADNAGAR, WARDHA ROAD, NAGAR PARISHAD-ARVI, TEHSIL-ARVI, DIST-WARDHA - 442201
PH : 8484988769.
- AURANGABAD**
1417. AUTOMOTIVE MANUFACTURERS PVT. LTD. (2102-01-), PLOT NO. 1,P.B.NO. 716,CHIKALTHANA,AURANGABAD - 431210
PH : 9158000046.

Dealer Network (AS ON 31.10.2023)

1418. PAGARIYA AUTO PVT. LTD. (2103-01)-, OPP. OLD HIGH COURT, NEAR HOTEL ASHOKA EXECUTIVE, JALANA ROAD, AURANGABAD - 431005
PH : 02406659902.
1419. AUTOMOTIVE MANUFACTURERS PVT. LTD. (2102-03)-, C-27, MIDC, CHIKALTHANA , NIR LUPIN LABORATORIES, AURANGABAD, MAHARASHTRA - 431006
PH : 9158000059.
1420. PAGARIYA AUTO PVT. LTD. (2103-05)-, GAT NO. 46, PLOT NO. 50, NEAR MASTER COOK RESTAURANT (KALASH HOTEL) BEED BYPASS ROAD, AURANGABAD, MAHARASHTRA - 431005
PH : 9860999484/9860999468.
1421. PAGARIYA AUTO PVT. LTD. (2103-06)-, PLOT NO.A-35 MIDC, NEAR MAIN RAILWAY STATION, AURANGABAD - 431001
PH : 840886768/738729311.
- BADLAPUR**
1422. PRAKASH AUTO PVT. LTD. (9001-01)-, SHOP NO. 2, S. NO. 16, PLOT NO. 25 & 26, KRISHNA WATER SUPPLY, OPP. INDIAN OIL PETROL PUMP, MIDC ROAD, KATRAP, BADLAPUR (EAST) - 421503
PH : 8655791288/9870453155.
- BALLARPUR**
1423. TRISTRAR CARS (H302-04)-, PLOT NO.11, BEHIND ZAWERI PETROL PUMP, NEAR GURU NANAK COLLEGE, ALLAPALLI ROAD, BAMNI, TAH. BALLARPUR - DIST. - 442701
PH : 7447473304.
- BARAMATI**
1424. MAHALAXMI AUTOMOTIVES PVT. LTD. (7R01-01)-, BARAMATI- PHALTAN RD., KASBA, BARAMATI, DIST. PUNE - 413102
PH : 9881370310.
- BARSHI**
1425. CHAVAN MOTORS DIVISION INDIA PVT LTD (BBA1-01)-, GAT NO.1407/1, LATUR ROAD, NEAR ESSAR PETROL PUMP, BARSHI. - 413401
PH : 0217-229666/8378983726.
- BEED**
1426. PAGARIYA AUTO PVT. LTD. (V602-01)-, GUT NO. 61, VILLAGE - GHOSAPURI, TALUKA AND DISTRICT - BEED, MAHARASHTRA . - 431122
PH : 9834161614/02442256058/02442256056/02442256057/.
- BHANDARA**
1427. AUTOMOTIVE MANUFACTURERS PVT. LTD. (2001-03)-, JINDAL'S BLDG, NEAR NAVKAR PETROL PUMP, SAINATH NAGAR, NH-6, BANDHARA - 441904
PH : 7030932330/9673004280.
- BHIGWAN**
1428. MAHALAXMI AUTO (SMP1-01)-, GAT NUMBER-342, NEXT TO HOTEL SAGAR, PUNE-SOLAPUR HIGHWAY, BHIGWAN - 413130.
- 413130
PH : 9922979653.
- BHOR**
1429. SEHGAL AUTORIDERS PVT. LTD. (BSV1-01)-, GUT NO. 929/1, UTTRIOLI, BHOR, TALUKA - BHOR, DISTRICT - PUNE, MAHARASHTRA . - 412206
PH : 9527771016.
- BHUSAWAL**
1430. MANRAJ AUTO (C401-02)-, NATIONAL HIGHWAY 6, NEAR KHADKA ROAD CROSSING, BHUSAWAL 425201. - 425201
PH : 9422867242.
- BOISAR**
1431. SHIVAM AUTO ZONE (ES02-01)-, PLOT NO. J-240, MIDC ROAD, BOISAR, TARAPUR INDUSTRIAL, MUMBAI, PIN-401501, MAHARASHTRA - 401501
PH : 8082551155.
- BRAMHAPURI**
1432. TRISTRAR CARS PVT LTD (H302-02)-, 165, NAVEGAON, NEAR VIDYANIKETAN SCHOLL, WADSA ROAD, BRAHMAPURI, DIST: CHANDPURAH, MAHARASHTRA - 441206
PH : 774583000.
- BULDHANA**
1433. MANRAJ MOTORS PVT LTD (COU1-01)-, GAT NO. 94, PLOT NO. 11, SUNDERKHED, BULDHANA, MAHARASHTRA . - 443 001
PH : 7875051521.
- CHALISGAON**
1434. MANRAJ MOTORS PVT LTD (AAE1-01)-, SL. NO 406, PLOT NO. 2, NEAR HOTEL RANI PARK, DHULE ROAD, CHALISGAON, DIST: JALGAON, MAHARASHTRA . - 424101
PH : 8408889861.
- CHANDGAD**
1435. SAI SERVICE PRIVATE LIMITED (BTF1-01)-, GAT NO.360, G.P.M NO.157, A/P HALKARNI TALUKA CHANDGAD, DISTT. KOLHAPUR, MAHARASHTRA . - 416507
PH : 9673339103.
- CHANDRAPUR**
1436. TRISTRAR CARS PVT LTD (H302-01)-, NR. HOTEL KUNDAN PLAZA,NAGPUR ROAD,CHANDRAPUR - 442401
- 442401
PH : 9722068612.
1437. TRISTRAR CARS PVT LTD (H302-03)-, NAGPUR ROAD, CHANDRAPUR - 442401
PH : 7722068603.
- CHIPLUN**
1438. JAGRUT MOTORS PVT LTD (9A01-01)-, SURVEY NO-543, NH-17, MUMBAI-GOA HIGHWAY,AT-KALAMBATE,TAL-CHIPLUN, DIST-RATNAGIRI,MAHARASHTRA - 415605
PH : 07083687172/8308917693.
- CHOUK**
1439. SIMRAN MOTORS (SNK1-01)-, SIMRAN MOTORS PVT LTD STOCKYARD , AT WAVANDAL ,SURVEY NO- 62/2A POST- CHOWK, NEAR ARUN HOTEL, MUMBAI-PUNE HIGHWAY, TALUKA - KHALAPUR, DISTRICT - RAIGAD - 410206
PH : 8691988895.
- DAHANU**
1440. SAI SERVICE PRIVATE LIMITED (V901-03)-, DAHANU-JAWAHAR ROAD, DAHANU(E), TAL-DAHANU, DIST. TAHE - 401602
PH : 9730302821/9167980005/9594952211.
- DAPOLI**
1441. JAGRUT MOTORS PVT LTD (G301-06)-, AT/POST/DAPOLI, DAPOLI-KHED ROAD,DAPOLI,DIST RATNAGIRI . - 415712
PH : 8308816572/7447752372.
- DHAMANGAON**
1442. ASPA (SFZ1-01)-, RAMDEVBA BAGAR, ANJANISINGH ROAD, DHAMANGAON RAILWAY, DIST- AMRAVATI - 444709
PH : 9850333558.
- DHULE**
1443. SEVA AUTOMOTIVE LTD. (P301-01)-, GATE NO. 90 AWADHAN,MUMBIA AGRA ROAD,DHULE - 424001
PH : 02562-281128/29.
- DINDORI**
1444. AUTOMOTIVE MANUFACTURERS PVT. LTD. (AAF1-01)-, S.N.753, NEAR PANDAV PETROL PUMP,NASIK DINDORI ROAD, TAL. DINDORI, DISTT. NASIK - 422202
PH : 9673008622.
- DOMBIVALI**
1445. AUTOMOTIVE MANUFACTURERS PVT. LTD. (3901-02)-, PLOT NO. B-43, PHASE-1.DOMBIVALI INDUSTRIAL AREA, DOMBIVALI,DISTT-THANE, MAHARASHTRA . - 421201
PH : 8879050913/769206095/9769206101.
1446. FORT POINT AUTOMOTIVE (CARS) PVT. LTD. (3906-02)-, SURVEY NO.13, NEAR PIMPLESHWAR TEMPLE, OPP. MAHANAGAR CNG PUMP, KALYAN-SHLIPHALA ROAD, MANGAON, SONARPADA, DOMBIVLI EAST . - 421203
PH : 8422800740, 8422978490.
- GADCHIROLI**
1447. ARYA CARS (UNIT OF BARBATE AUTOMOTIVE (I) PVT. LTD) (ZK02-01)-, PLOT NO. 10, GANESH NAGAR, MUL ROAD, GADCHIROLI , MAHARASTRA - 442702
PH : 8669929188.
- GADINGALAJ**
1448. SAI SERVICE PRIVATE LIMITED (3802-04)-, 581/7B, PLON NO-12, SANKESHWAR ROAD, OPP. HOTEL NEELKAMAL, TAL. GADINGLAJ - 416502
PH : 02327-222239.
- GONDIA**
1449. ARYA CARS (UNIT OF BARBATE AUTOMOTIVE (I) PVT. LTD) (2004-02)-, ITI ROAD,NR. FULCHUR NAKA,OPP LAXMI FLOUR MILL,GONDIA - 441601
PH : 8888837023/8888859487.
1450. ARYA CARS (UNIT OF BARBATE AUTOMOTIVE (I) PVT. LTD) (2004-03)-, ITI KAWLEWADA ROAD, NEAR HIMGIRI LAYOUT, KARANA, GONDIA, MAHARASHTRA . - 441 601
PH : 8888837023/8888859487.
- GUHAGAR**
1451. JAGRUT MOTORS PVT LTD (BJV1-01)-, SURVEY NO. 23A, SHRUNGALTALI, GUHAGHAR-CHIPLUN ROAD, GUHAGAR, RATNAGIRI, MAHARASHTRA - 415703
PH : 7218547898/7447752072.
- HINGANGHAT**
1452. SEVA AUTOMOTIVE PVT. LTD. (CDZ1-01)-, PLOT NO. P-1, HINGANGHAT INDUSTRIAL AREA, NH-7, AJANTI, HINGANGHAT, TALUK - HINGANGHAT, DISTRICT - WARDHA, MAHARASHTRA . - 442301
PH : 7722067843.
- HINGOLI**
1453. PAGARIYA AUTO PVT. LTD. (IF03-01)-, PLOT NO.5.7 & 8, SURVEY NO.29/2, AKOLA BY PASS ROAD, HINGOLI . - 431513
PH : 8411961177.
- HUPARI**
1454. SAI SERVICE PRIVATE LIMITED (CIQ1-01)-, GAT NO.928/8K2, PLOT NO.7, HUPARI TO YALGUD ROAD, HUPARI, TAL-HATKANAGALE, DISTRICT - KOLHAPUR . - 416203
PH : 9923208454.
- ICHALKARANJI**
1455. SAI SERVICE PRIVATE LIMITED (4D01-01)-, GATE NO. 107 KOLHAPUR ROAD,KABNOOR,ICHALKARANJI - 416122
PH : 0230-2425282.
- INDAPUR**
1456. MAHALAXMI AUTOMOTIVES PVT. LTD. (7R01-02)-, STATE HIGHWAY NO. 151, INDAPUR - 412219
PH : 8308807314.

ISLAMPUR

1457. CHOWGULE INDUSTRIES PVT. LTD. (PJ02-01-), GATE NO.905/A/3, NEAR BOMBAY RAYAN, PUNE-BANGALORE HIGHWAY (NH-4), ISLAMPUR TALUKA : WALVA, DIST:SANGLI - 415409 PH : 02342-225757.

JALGAON

1458. MANRAJ MOTORS PVT LTD (C401-01-), AJINTA ROAD, MIDC INDL AREA, JALGAON - 425003 PH : 0257-2212120.

JALNA

1459. AUTOMOTIVE MANUFACTURERS PVT. LTD. (2102-02-), PLOT NO. 4 & 5, CTS NO. 114274-A, BALAJI COMPLEX, JALNA-AURANGABAD ROAD, JALNA - 431203 PH : 9158000063.

JATH

1460. CHOWGULE INDUSTRIES PVT. LTD. (J102-05-), PLOT NO. 12, SAWANT ESTATE, MORE COLONY, OPP. CATTLE BAZAR, SATARA ROAD, JATH, DISTRICT SANGLI, MAHARASHTRA - 416404 PH : 02344-246598.
1461. SIDHI WHEELS (BLX1-01-), GAT NO- 27/1B, POST-RAMPUR, JATH-SANGLI ROAD, TALUKA-JATH, DISTRICT-SANGLI - 416404 PH : 8956454526.

JAYSINGPUR

1462. SAI SERVICE PRIVATE LIMITED (ASA1-01-), GATE NO. 123, NEAR ACHRYA TULSI BLOOD BANK, A/P UDGAON(JAYSINGHPUR), TALUKA:SHIROL, DIST: KOLHAPUR - 416134 PH : 9673339762.

JEJURI

1463. EXCELL AUTO VISTA (SKY1-01-), GAT NO - 224, AT POST-SAKURDE, JEJURI, TALUKA-PURANDHAR, DISTRICT-PUNE, PIN-412303 - 412303 PH : 9146052651.

KALWAN

1464. SHAAN CARS PRIVATE LIMITED (BNW1-01-), GAT NO. 189, PLOT NO. 7, MALEGAON ROAD, A/P KALWAN, NASHIK - 423501 PH : 9075028780, 9689003988.

KALYAN

1465. AHER AUTOPRIME LLP (CFV1-01-), SURVEY NO.53 & 54, HIND MILL, OPPOSITE STATE BANK OF INDIA, ANDHARWADI ROAD, KALYAN, MUMBAI - 421301 PH : 98197544/8657402204/9769927505.
1466. AHER AUTOPRIME LLP (CFV1-02-), SURVEY NO.312.MOHANE ROAD, NEAR SHAHD RAILWAY STATION,SHAHAD,KALYAN - 421103 PH : 8422871720/8657402204/9833993076.

KAMSHET

1467. SEHGAL AUTO (CEA1-01-), AT NAYGAON, POST KAMSHET, TALUKA MAVAL, DISTRICT PUNE, MAHARASHTRA (410405) - 410405 PH : 8888881358.

KANKAVLI

1468. JAGRUT MOTORS PVT LTD (G301-05-), PLOT NO.32-33,SURVEY NO.-18861,MUMBIA-GOA HIGHWAY (NH-17),JANAVLI,KANKAVLI,MAHARASHTRA - 416002 PH : 7499051071/9021095805.

KARAD

1469. CHOWGULE INDUSTRIES PVT. LTD. (F303-02-), 1123, PUNE-BANGALORE ROAD, NEAR RELIANCE GAS PUMP, A/P MALKAPUR, TAL. KARAD, DISTT. SATARA - 415110 PH : 9922569835.

KARJAT

1470. SIMRAN MOTORS PVT. LTD. (7S01-03-), PANVEL-KARJAT ROAD, KARJAT, DIST. RAIGAD - 410201 PH : 8891988895, 8108181978.

1471. KANKARIYA AUTOMOBILES PVT. LTD. (GJ1-01-), KARJAT-NAGAR ROAD, KARJAT, MAHARASHTRA - 414402 PH : 9890843771.

KARMAD

1472. PAGARIYA (CEB1-01-), GAT NO-245, BHAKTI COMPLEX, BEHIND BHARAT PETROL PUMP, AURANGABAD ROAD, KARMAD - 431007. - 431007 PH : 7575077181 / 9687668929.

KARMALA

1473. CHAVAN MOTORS DIVISION INDIA PVT LTD (GJQ1-01-), GAT NO. 105, SURVEY NO. 3961, KARMALA-NAGAR ROAD, A/P- KARMALA, TALUKA - KARWALA, DIST.-SOLAPUR. - 413202 PH : 8806665691.

KAVATE MAHANKAL

1474. CHOWGULE INDUSTRIES PVT. LTD. (SC02-01-), MAHKALI BAAZAR, KAVATE MAHANKAL-JAT ROAD, KAVATE MAHANKAL, SANGLI, MAHARASHTRA - 416405 PH : 02341-222102.

KHAMGAON

1475. MANRAJ MOTORS PVT LTD (BXU1-01-), GAT NO 41, OLD SURVEY NO. 12/1A, NEAR AMRUT PETROL PUMP, AKOLA ROAD, KHAMGAON . MAHARASHTRA - 444303 PH : 07623-2500023.

KHANAPUR (SANGLI)

1476. CHOWGULE INDUSTRIES LTD (SNM1-01-), KHANAPUR VITA ROAD, KHANAPUR, TAL-KHANAPUR, DIST-SANGLI - 415307 PH : 9767899653.

KHARGHAR

1477. EXCELL AUTOVISTA PVT LTD (AAC1-01-), SURVEY NO.742/439, KOPRA VILLAGE, SECTOR-10, SION-PANVEL HIGHWAY, KHARGHAR, DIST. RAIGAD - 410210 PH : 7666703636 / 9594153308 / 8422991300 / 9320357300.

KHED

1478. JAGRUT MOTORS (COR1-01-), GAT NO - 43/B, MAUZA-BHARNE NAKA, TALUKA-KHED, DIST-RATNAGIRI - 415709 PH : 9689533472.

KHOPOLI

1479. KIRAN MOTORS (9C02-01-), PLOT NO-68, VILLAGE-MULGAON, KHOPOLI INDUSTRIAL ESTATE, KHOPOLI, TALUKA-KHALAPUR DIST-RAIGAD - 410204 PH : 8976791922, 8976791920.

KOLHAPUR

1480. SAI SERVICE PRIVATE LIMITED (3802-01-), PLOT NO. 1, E WARD, BEHIND PARVATI TALKIES, SHIVAJI UDYAMNAGAR, KOLHAPUR - 416008 PH : 0231-2661676.

1481. SAI SERVICE PRIVATE LIMITED (3803-01-), C-6, SHIROLI MIDC, MENON OPP MENON PISTONS,NH4, KOLHAPUR - 416122 PH : 0230-2468376.

1482. SAI SERVICE PRIVATE LIMITED (3802-06-), R S NO. 10/1A, PLOT NO. 28, APATE NAGAR, KALAMBA RING ROAD, KOLHAPUR, MAHARASHTRA - 416012 PH : 0231-2329494.
1483. KR MOTORS KOLKOHUR PVT LTD (3804-01-), PLOT NO. 216/2, 216/3, 216/5, NH-4, GOKUL SHIRGAON, KOLHAPUR - 416234 PH : 9850500550, 7447755504.

KONGAON

1484. PRAKASH AUTO PVT. LTD. (3903-02-), SURVEY NO.126/127,98/38,AT & POST KONGAON, - 421302 PH : 9702809668/9870453155.

KOPARGAO

1485. SHAAN CARS PRIVATE LIMITED (COV1-01-), SURVEY NO. 15/36 GAWARE PATIL ESTATE, NAGAR MANMAD HIGHWAY, NEAR ASHOKA HOTEL, KOPARGAO. - 423 601 PH : 9075028780.

KOREGAON BHIMA

1486. SAI SERVICE (BUO1-01-), GAT NO-373, VILLAGE-KOREGAON BHIMA, TALUKA-SHIRUR, DIST-PUNE. - 415501 PH : 7774997005.

KUDAL

1487. JAGRUT MOTORS PVT LTD (9B01-01-), SURVEY NO. 505, 515, A/P PINGULI, TEMBDHURI, TALUKA - KUDAL, DISTRICT - SUNDUDURG, MAHARASHTRA - 416520 PH : 8806664572/6208965235.

KUDITRE

1488. SAI SERVICE (SRV1-01-), KUDITRE FACTORY PHATA, A/P-KOPARDE, TALUKA-KARVEER, DIST-KOLHAPUR-416205 - 416205 PH : 9923208460.

KURUDWADI

1489. CHAVAN MOTORS DIVISION INDIA PVT LTD (CUF1-01-), GAT NO.:256, BYPASS ROAD, A/P KURDA, TALUKA-MADHA, DISTT. SOLAPUR. - 413208 PH : 8806665691.

KURUNDWAD

1490. SAI SERVICE PVT. LTD. (BHO1-01-), GAT NO. 250, AT POST - KURUNDWAD, TALUKA - SHUROO, DIST.-KOLHAPUR. - 416106 PH : 9873339695.

LANJA

1491. JAGRUT MOTORS (SER1-01-), GAT NO-663, TALUKA-LANJA, DIST - RATNAGIRI, MAHARASHTRA -416701 - 416701 PH : 8108718346.

LASALGAON

1492. SHAAN CARS PRIVATE LIMITED (BZM1-01-), PLOT NO. 337, LASALGAON MAIN ROAD, LASALGAON, TALUKA - NANDGAON, DISTRICT - NASHIK. - 422306 PH : 9075028780, 7720094874.

LATUR

1493. AUTOMOTIVE MANUFACTURERS PVT. LTD. (V801-01-), CITY SURVEY NO. 2960, NANDED ROAD, OPP. TIRUPATHI LODGE, LATUR - 413512 PH : 9607999095.

1494. AUTOMOTIVE MANUFACTURERS PVT. LTD. (V801-02-), PLOT NO. 28, 29, 30, SURVEY NO. 36, VARVATTI VILLAGE, LATUR - BARSHI ROAD, LATUR - 413512 PH : 9607999091/9607999092/9607999093/9607999094

LONAVALA

Dealer Network (AS ON 31.10.2023)

1495. SEHGAJ AUTORIDERS PVT. LTD. (CGA1-01), GATE NO. 1201, VILLAGE – WAKSAL, TALUKA – MAVAL, LUNAVALA, DISTRICT – PUNE, MAHARASHTRA - 410405 PH :89753/73431.
- MAHAD**
1496. SIMRAN MOTORS PVT. LTD. (7S01-04), NEAR RELIANCE PUMP, PANVEL-GOA ROAD, MAHAD, DIST. RAIGAD - 402301 PH :9870404323.
- MALEGAON**
1497. SHAAN CARS PRIVATE LIMITED (3703-02), PLOT NO. 572/81, CHANDANPUR SHIVAR, OLD MUMBAI, AGRA ROAD, DIST- NASIK, MALEGAON - 423203 PH :9922969620/9922969656.
- MANCHAR**
1498. KOTHARI AUTO WHEELS PVT LTD (CSH2-01), SOHAM NAGARL A-WING, SHOP NO.8 & 16, PUNE NASIK HIGHWAY, A/P MANCHAR, TALUKA : AMBEGAON, DISTT: PUNE, MAHARASHTRA - 410503 PH :8411003608.
- MANGALVEDHA**
1499. CHAVAN MOTORS (SQR1-01), NEAR SWARAJYA HOTEL, PANDHARPUR ROAD, CHOKAMELANAGAR, MANGALVEDHA, MAHARASHTRA, PIN-413305 - 413305 PH :8805778881.
- MANGAON**
1500. SIMRAN MOTORS PVT. LTD. (BAM1-01), SURVEY NO.97, AT-POST-NANORE, NH-17, MUMBAI-GOA HIGHWAY, MANGAON, RAIGAD, MAHARASHTRA - .402104 PH :923181120.
- MANMAD**
1501. SHAAN CARS PRIVATE LIMITED (BNX1-01), GAT NO. 113, PLOT NO. 1 AND SHOP NO. 3 & 4, NANDGAON ROAD, MANMAD, - 423104 PH :9075028780, 8888832369.
- MANOR**
1502. SAI SERVICE PRIVATE LIMITED (CRE1-01), GUT NO. 37, NEAR MSEB POWER STATION, PALGHAR MANOR ROAD, AT POST – TAKVAHAL, DISTRICT – PALGHAR, MANOR. - 401403 PH :9167988005.
- MAYANI**
1503. CHOWGULE INDUSTRIES (STQ1-01), GAT NO - 2101/1, 560/1, MAYANI VADUJI ROAD, A/P- MAYANI, TAL-KHATAV, DIST-SATARA-415102, - 415102 PH :8888866659.
- MIRA ROAD, THANE**
1504. SUPREME AUTOMOBILES (3915-01), BRILLIANT COMPLEX, WESTERN EXPRESS HIGHWAY, MIRA ROAD, THANE- 401107, - 401107 PH :8591942704.
- MIRAJ**
1505. CHOWGULE INDUSTRIES PVT. LTD. (J102-03), 42C, OPP. WHISPERING WOODS, MIDC AREA, TALUKA MIRAJ, DISTT. SANGLI, MAHARASHTRA - 416410 PH :0233-2643221,0233-264322.
- MORGAON**
1506. MAHALAXMI AUTO (SRN1-01), GAT NO-179, MORGONAON - TALUKA- BARAMATI, DIST-PUNE - 412304 PH :9850994014.
- MUMBAI**
1507. SAI SERVICE PRIVATE LIMITED (504-01), 462 SENAPATI BATAP MARG,WORLI NAKA,LOWER PAREL,MUMBAI - 400013 PH :9594952122/9594952088/9167980082.
1508. SAI SERVICE PRIVATE LIMITED (504-02), ARVIND CHAMBERS 194 ANDHERI KURLA ROAD, ANDHERI(EAST), MUMBAI - 400069 PH :43030606 /600, 95949552341 /9594952084 /9594952250.
1509. VITESSE PRIVATE LIMITED (503-01), SHAH INDL,ESTATE, PLOT 11 LINK ROAD, ANDHERI (WEST), MUMBAI - 400058 PH :02226730787/02226730280/02226730296/02261642500/02261642500.
1510. VITESSE PRIVATE LIMITED (503-02), 77 AF PALKY GULLY, OFF VEER SAVARKAR MARG, PRABHADEVI, MUMBAI - 400025 PH :24229747/24223933/9821894915.
1511. SAI & SANGI AUTO AGENCIES PVT LTD (605-01), PRAKASH MILLS COMPOUND,OFF. GLOBE MILLS PASSAGE,WORLI,MUMBAI - 400013 PH :02224925452/02224925453/02224925454.
1512. SAI SERVICE PRIVATE LIMITED (504-04), C/O SHAKTI INDUSTRIAL WIRE COMPOUND,DTTA PADA ROAD BORIVILI (EAST),MUMBAI - 400066 PH :28707000 / 9594057006 / 9594952344 / 9594952417.
1513. EXCELL AUTOVISTA PVT LTD (510-01), RESHAM SINGH COMPOUND,CST ROAD,KALINA, SANTACRUZ EAST,MUMBAI - 400098 PH :67743888,26653242, 43, 46 / 7666703636 / 9594972889 / 7715204477.
1514. AUTOMOTIVE MANUFACTURERS PVT. LTD, (3901-04), PLOT NO. 108, BAZAR WARD, KURLA(WEST) , MUMBAI - 400070 PH :02325-265553.
- MURBAD**
1523. PRAKASH AUTO PVT. LTD. (BYO1-01), SURVEY NO. 61/2, KALYAN – MURBAD ROAD, VILLAGE – DAHAGAON, TALUKA – MURBAD, DISTRICT – THANE, MAHARASHTRA - 421605 PH :798725726.
- MURGUD**
1524. SAI SERVICE PRIVATE LIMITED (AWA1-01), R.S. NO. 1884, A/P MURGUD, TALUKA: KAGAL, DIST: KOLHAPUR - 416219 PH :02325-265553.
- MURTIZAPUR**
1525. KHANDELWAL AUTOWHEELS (SHE1-01), SURVEY NO 38, MAUJA SONORI, NH 06, NEAR HOTEL DEVA, MURTIZAPUR, DISTRICT-AKOLA - 441407 PH :8484063274.
- NAGPUR**
1526. SEVA AUTOMOTIVE LTD. (2002-01), 34/3, KACHIMET AREA, NEAR VAYUSENA NAGAR BUS STOP, WADI, AMRAVATI ROAD, NAGPUR - 440023 PH :0712-6652863.
1527. AUTOMOTIVE MANUFACTURERS PVT. LTD. (2001-02), 575 KAMPTEE ROAD,NAGPUR-26, - 440026 PH :9673004226/9673004223.
1528. SEVA AUTOMOTIVE LTD. (2002-03), PLOT NO. 33A, CENTRAL MIDC, HIGNA ROAD, NAGPUR, MAHARASHTRA. - 440014 PH :0712-666444.
1529. ARYA CARS (UNIT OF BARBATE AUTOMOTIVE (I) PVT. LTD) (2004-01), NEAR PARDY NAKA (OUTSIDE), NH-6, BHANDARA ROAD,NAGPUR - 440035 PH :8888859506/8888859534.
1530. AUTOMOTIVE MANUFACTURERS PVT. LTD. (2001-05), PLOT NO. 38/1, NEAR BOUDHA VIHAR, OPP. DELHI PUBLIC SCHOOL, KAMPTEE ROAD, NAGPUR, MAHARASHTRA - 441001 PH :9168699701/9673004227.
1531. ARYA CARS (UNIT OF BARBATE AUTOMOTIVE (I) PVT. LTD) (2007-01), PLOT NO. 4, NEW COTTON MARKET, GHAT ROAD, NAGPUR, MAHARASTRA - 440018 PH :8888859542.
1532. ARYA CARS (UNIT OF BARBATE AUTOMOTIVE (I) PVT. LTD) (2007-02), PLOT NO. 131, NH-6, BHANDARA ROAD, MAHALGAON, NAGPUR, MAHARASTRA - 441202 PH :8888820312.
1533. SEVA AUTOMOTIVE PVT. LTD. (2002-04), PLOT NO.05, 12, 13A, 13B CHANDRABHAGA GRUHA NIRMAJ SAHKARI LIMITED, KH NO.45/3, CITY SURVEY NO.570, MANEWADA RING ROAD, NAGPUR, MAHARASHTRA - 440027 PH :8390446644.
1534. ARUN MOTORS (2008-01), PLOT NO-9&10, PATNI PLAZA, KHAMLA RING ROAD, SAWKAR NAGAR, NAGPUR, MAHARASHTRA - 440025 PH :7757988800/7028688800.
1535. ARUN MOTORS (2008-02), C-48/1, MIDC HINGNA MAIN ROAD, WADI, NAGPUR, PIN-440028, MAHARASHTRA - 440028 PH :7757988800.
- NALASOPARA**

1536. SHIVAM AUTO (CUH1-01), SURVEY NO. 91.92 , PLOT NO. 7, VILLAGE- DHANIV, NALASOPARA, DIST. PALGHAR, MAHARASHTRA - 401209 PH :9152001458/7777002930.	1548. SIMRAN MOTORS PVT. LTD. (3913-01), CAMEO FABRIC COMPANY, GEN 16, NEAR SULZER COMPANY, DIGHA, TTC AREA, AROLI - 400701 PH :8788582329, 83696858212.	PANVEL	1567. SAI SERVICE PRIVATE LIMITED (1901-01), BOMBAY PUNE ROAD, FUGEWADI, PUNE - 411012 PH :020-46404440/020-46404448.
NANDED	NEVASA	PARATWADA	1568. SAI SERVICE PRIVATE LIMITED (1901-02), 889/90 J.M.ROAD, DECCAN GYMKHANA, PUNE - 411004 PH :9923208347.
1537. SEVA AUTOMOTIVE LTD. (6801-01), NANDED HYDERABAD ROAD, NANDED - 431604 PH :7447415607.	1549. KANKARIYA AUTOMOBILES PVT. LTD. (BSU1-01), BELOW ADARSH GRAMIN BANK, OPP. ILAKSHI MOTORS, NEVASA PHATA, AURANGABAD ROAD, TALUKA - NEVASA, DISTRICT - AHMEDNAGAR - 414603 PH :9420494601.	1559. AUTOMOTIVE MANUFACTURERS PVT. LTD. (3901-03), PLOT NO:92/1, VILLAGE KOLAKHA, MUMBAI-GOA HIGHWAY, PANVEL, DISTT. RAIGAD - 410206 PH :9769202055/9769206045/976920618/8291467042	1569. CHOWGULE INDUSTRIES PVT. LTD. (1908-02), S.NO. 53,PUNE SATARA HIGHWAY,KATRAJ,PUNE - 411046 PH :020-66786200.
NANDURBAR	NIPAHAD	PARTHANI	1570. SAI SERVICE PRIVATE LIMITED (1901-03), S.NO.15A GIDWANI COMPOUND, KONDWA BUDRUK, HAVELI, PUNE - 411046 PH :9923208345.
1538. SEVA AUTOMOTIVE LTD. (P301-02), P NO.-324, BASIL NAGAR SHAHADA BYPASS ROAD, NEAR HOTEL KAREN GARDEN, CHAUFULLY NANDURBAR-425412 - 425412 PH :7720017528.	1550. SHAAN CARS PVT. LTD. (COX1-01), GAT NO. 99/3, RASALPUR AURANGABAD HIGHWAY, NIPAHAD, DISTRICT - NASHIK, MAHARASHTRA - 422303 PH :9075028780.	1560. ASA Bandsons Auto Pvt. Ltd. (CFZ1-01), SURVEY NO. 26/4A, RAMGAON, AMRAVATI PARATWADA ROAD, NEAR JAWARDI PHATA, PARATWADA TALUKA - ACHALPUR, DISTRICT - AMRAVATI . - 444 805 PH :8888867962.	1571. WONDER CARS PVT LTD (1903-02), 12, NPS LINES,SOLAPUR ROAD,OLD POOL GATE,CAMP, PUNE - 411001 PH :020-26332934/35.
NARAYANGAON	OSMANABAD	PATAS	1572. KOTHARI AUTO WHEELS PVT LTD (1984-01), 110A, PUNE SOLAPUR ROAD, NEAR FATIMA NAGAR, PUNE - 411039 PH :7498272309.
1539. KOTHARI AUTO WHEELS PVT LTD (FV03-01), GATE NO. 747, PUNE NASIK HIGHWAY, WARULWADI, NARAYANGAON - 410504 PH :8411003608.	1551. CHAVAN MOTORS DIVISION INDIA PVT LTD (B102-03), PLOT NO. A-53, INDUSTRIAL AREA, MIDC, OSMANABAD - 413501 PH :8888867861.	1561. PAGARIYA AUTO PVT. LTD. (LN02-01), SURVEY NO-301, PLOT NO-86/A, OPP GULMOHAR LODGE, BASMAT ROAD, PARBHANI - 431401 PH :9511864433.	1573. MY CAR (PUNE) PVT. LTD. (1907-01), SURVEY NO. 131, MUMBAI BANGALORE HIGHWAY, WAKAD, PUNE - 411057 PH :020-67922900.
NASHIK	OTUR	PEN	1574. ACE KUDALE CAR PVT. LTD. (1910-01), 36/2/C1, MANRAJ BUDRUK, PUNE-SOLAPUR ROAD, TALUKA HAVELI, DISTRICT PUNE - 412201 PH :952582454.
1540. AUTOMOTIVE MANUFACTURERS PVT. LTD. (3702-01), P-112,ADDITIONAL NASIK INDL. AREA,AMBAD, NASIK - 422010 PH :0253-6636329/ 319/12/313/314/317.	1552. KOTHARI AUTO WHEELS PVT LTD (SLG2-01), GAT NO-184/3/B, ALEPHATA-KALYAN ROAD, OPP HP PETROL PUMP, VILLAGE-OTUR, TALUKA- JUNAR, DIST-PUNE - 412409 PH :8411003608.	1562. MAHALAXMI AUTOMOTIVES PVT. LTD. (7R01-03), PUNE-SOLAPUR HIGHWAY, PATAS, TALUKA DAUND DISTT.-PUNE - 413106 PH :88888890957.	1575. CHOWGULE INDUSTRIES PVT. LTD. (1911-01), S.NO.1, NEXT TO PODAR INTERNATIONAL SCHOOL, KATRAJ BYPASS ROAD, AMBEAGON-B, TALUKA-HAVELI, PUNE - 411046 PH :02066803555/02066803350.
1541. SEVA AUTOMOTIVE LTD. (3701-01), PLOT NO. -46, MIDC, AMBAD, NASIK - 422010 PH :0253-6644444.	PABAL	1563. SIMRAN MOTORS (9101-01), AT SURVEY NO 75, PLOT NO 2, MUMBAI-GOA HIGHWAY, WADHKAL (PEN) - 402107 PH :9503381198.	1576. SAI SERVICE PRIVATE LIMITED (1901-05), NEAR NGDI-BHOSARI ROAD, CHINCHWAD, PUNE - 411019 PH :020-46605999/020-46605995.
1542. SHAAN CARS PRIVATE LIMITED (3703-01), E-3 MIDC AREA,SATPUR , NASIK,MAHARASHTRA - 422007 PH :9075028780, 9922969646.	1553. MAHALAXMI (SKB1-01), 3733, SHINALKAR WASTI, PABAL, TALUK SHIRUR, PUNE, PIN 412403 - 412403 PH :8956288087.	1564. CHOWGULE INDUSTRIES PVT. LTD. (KH02-01), PLOT NO:83/1B/1, LONAND-PUNE ROAD, PHRANANDWADI, TALUKA:PHALTAN, DISTRICT: SATARA, MAHARASTRA - 415523 PH :8888886301.	1577. SEHGAH AUTORIDERS PVT. LTD. (1913-01), SURVEY NO. 51, BAVDHAN KHURD, TAL: HAVELI, DIST: PUNE - 411021 PH :930830444, 020-4163625, 020-4163627.
1543. SHAAN CARS PRIVATE LIMITED (3703-04), 03/10, NEAR NASARDI BRIDGE, WADALA ROAD, NASIK ROAD, NASIK - 422011 PH :0253-2236080.	PAITHAN	1565. AUTOMOTIVE MANUFACTURERS PVT. LTD. (BAY1-01), GAT NO.517/P NEAR MARKET COMMITTEE, MUMBAI AGRA HIGHWAY, NH3 A/P PIMPALGAON BASWANT, TALUKA: NIPAHAD, DIST-NASHIK - 422202 PH :02550-252808.	1578. SAI SERVICE PRIVATE LIMITED (1901-06), SURVEY NO.244/1, PHASE-II, NEAR BANK OF MAHARASHTRA, HINGEWADI, TAL - MULSHI, DISTRICT-PUNE,MAHARASHTRA - 411057 PH :9923208302.
1544. SEVA AUTOMOTIVE LTD. (3701-06)- SEVA FARMS, GATE NO. 82/2, AMBE BAHULA ROAD, VILHOLI, TALUKA & DISTRICT: NASIK, MAHARASHTRA - 422010 PH :9146000709.	1554. PAGARIYA AUTO PVT. LTD. (BNQ1-01), GAT NO-277, MAUZA- PAITHAN, TALUKA- PAITHAN, DIST - AURANGABAD 431107. - 431107 PH :9922994237.	1566. PIMPLEGAON	1579. ACE KUDALE CAR PVT. LTD. (1910-02), ATLAS TANKS VESSELS, SR. NO 2322, PUNE-NASIK ROAD, KHANOBAMALI, BHOSARI, PUNE - 411039 PH :9552193904.
1545. SEVA AUTOMOTIVE PVT LTD (3701-07), PLOT NO.A-23, NICE INDUSTRIAL AREA, MIDC, SATPUR, NASIK (MAHARASHTRA) - 422006 PH :0253-6634444.	1555. SAI SERVICE PRIVATE LIMITED (TE01-01), SURVEY NO. 86/1, TEMBHODE, MANOR-MAHIM ROAD, PALGHAR, DISTRICT: THANE - 401404 PH :9167980042/9167980005/9594952211.	1567. AUTOMOTIVE MANUFACTURERS PVT. LTD. (BAY1-01), GAT NO.517/P NEAR MARKET COMMITTEE, MUMBAI AGRA HIGHWAY, NH3 A/P PIMPALGAON BASWANT, TALUKA: NIPAHAD, DIST-NASHIK - 422202 PH :02550-252808.	1580. KOTHARI AUTO WHEELS PVT LTD (1984-03), PLOT NO. 2B, D1 BLOCK, CHINCHWAD, PUNE, DIST. PUNE - 411019 PH :9168662302.
1546. SEVA AUTOMOTIVES PVT LTD (3701-08), SHOP NO. 1 & 2, SER. NO. 241/1-B-1/2, OPPOSITE NMC SCHOOL, DINDORI ROAD, MAHSRUL, NASHIK, MAHARASHTRA - 422004 PH :0253-6654444.	1556. CHOWGULE INDUSTRIES PVT. LTD. (J102-04), PLOT NO-B-3, MIDC AREA, TALUKA PALUS, DISTT. SANGLI - 416308 PH :8888870122.	PIRANGUT	
NAVI MUMBAI	PALUS	1568. MY CAR (SEC1-01), GAT NO-314, AT VILLAGE-KASAR AMBOLI, PIRANGUT, TALUKA -AMBOLI, DIST-PUNE, PIN-412108. - 412108 PH :932544613.	
1547. AUTOMOTIVE MANUFACTURERS PVT. LTD. (3901-01), D-234 MIDC TTC INDL. AREA,SHIRVANE NERUL,NEW BOMBAY, - 400706 PH :66143900/66133923/66143924.	1557. CHAVAN MOTORS DIVISION INDIA PVT LTD (B102-05), GAT NO.56, ESABAVID, PUNE ROAD, TAL-PANDERPUR, SOLAPUR - 413001 PH :774997005.	PUNE	

Dealer Network (AS ON 31.10.2023)

1581. MAHALAXMI AUTOMOTIVES PVT. LTD.
(1912-03), 59/A, MUNDHWA KHARADI ROAD,
OPP. MUNDHWA POLICE STATION, MUNDHWA,
PUNE, MAHARASHTRA - 411036
PH :8888874980.
1582. WONDER CARS PVT LTD (1903-03), PLOT
NO.52/1 BLOCK F2, MIDC, PIMPRI, PUNE. -
411018
PH :020-46608888.
1583. SAI SERVICE PRIVATE LIMITED (1901-07-),
4/A/1A, 1/3 A, SALUNKE VIHAR ROAD, BORADE
NAGAR, KONDWA, PUNE, MAHARASHTRA. -
411048
PH :9923208358.
1584. MAHALAXMI AUTOMOTIVES PVT. LTD.
(1912-04), 485/1, CNS NO.1041, OM SUPER
MARKET, GHOKALE CROSS ROAD, MODEL
COLONY, SHIVAJI NAGAR, PUNE - 411016
PH :8888842887.
1585. CHOWGULE INDUSTRIES PVT. LTD. (1908-05-),
129/B/1, NEW PUNE MUMBAI HIGHWAY,
KATRAJ DEHU ROAD BYPASS, TATHWADE,
TAL-MULASHI, DISTT. PUNE (MAHARASHTRA) -
411033
PH :020-67915700.
1586. SAI SERVICE PRIVATE LIMITED (1901-08-),
SURVEY NO. 37, HISSA NO. 2, SITUATED AT
WADGAON KHURD, NEAR NAMED CITY,
SINHAGAD ROAD, TALUKA - HAVELI, DISTRICT -
PUNE, MAHARASHTRA. - 411 041
PH :9923208312.
1587. KOTHARI AUTO WHEELS PVT LTD (1984-05-),
PLOT NO. 24/B, HADAPSAR INDUSTRIAL
ESTATE, PUNE. - 411028
PH :8411002005, 8087060432.
1588. CHOWGULE INDUSTRIES PVT. LTD. (1908-06-),
SR. NO. - 43/4/A, 7 PARVATI INDUSTRIAL
ESTATE, OPP. ADINATH SOCIETY, PUNE-
SATARA ROAD, PUNE. - 411009
PH :020-67732300.
1589. EXCELL AUTOVISTA PVT LTD (1917-01-), GATE
NO.1232, 10TH MALL, PUNE SASWAD ROAD,
VILLAGE - WADKI, TAL - HAVELI, DIST PUNE. -
412308
PH :9594632888/9146052651.
1590. KOTHARI AUTO WHEELS PVT LTD (1984-06-),
SURVEY NO.46, HISSA 9/1 (CITY SURVEY
NO.6181+6180), WADGAON SHERI, CHANDAN
NAGAR, PUNE NAGAR ROAD, TAL-HAVELI,
PUNE. - 411014
PH :8411003631.
1591. ACE KUDALE CAR PVT. LTD. (1910-03-),
SURVEY NO. 272, 1/4, NEAR MOSHI TOLL
PLAZA, MOSHI GAON, TALUKA - HAVELI,
DISTRICT - PUNE. - 412105
PH :7767814381.
1592. SUMANKIRTI CARS PVT. LTD. (1915-02-),
SURVEY NO. 9, NEAR BALEWADI SPORTS
STADIUM MUMBAI-BANGALORE HIGHWAYS,
MAHALUNGE PUNE, MAHARASHTRA. - 411045
PH :8551990106.
1593. MY CAR (PUNE) PVT. LTD. (1918-01-), GAT NO.
625, HISSA NO. 1/3/1, VILLAGE - KURULI,
TALUKA - KHED, CHAKAN, DISTRICT - PUNE. -
410501
PH :7755900000.
1594. WONDER CARS PVT LTD (1903-04-), SURVEY
NO. 20, HISSA NO. 1/1/2, THERGAON, BAL
KRISHNA MANGAL KARYALAYA, TALUKA -
MULSHI, DANGE CHOWK, PUNE - 411 033. -
411033
PH :7887883311.
- PUNE (LOHEGAON)**
1595. MAHALAXMI AUTO (1912-05-), LANE NO 9, SANT
NAGAR, BEHIND
IOCL PETROL PUMP, LOHEGAON, PUNE,
MAHARASHTRA-411047 - 411047
PH :8956045026.
- RAHATA**
1596. KANKARIYA AUTOMOBILES PVT. LTD.
(ZV03-01-), SHIRDI ROAD, SAKORI, RAHATA, -
423107
PH :8275033313.
- RAHURI**
1597. KANKARIYA AUTOMOBILES PVT. LTD.
(COZ1-01-), TRIMURTI CRANE SERVICE,
NAGAR-MAMAD ROAD, RAHURI,
MAHARASHTRA. - 413705
PH :9420036767.
- RAJAPUR**
1598. JAGRUT MOTORS PVT LTD (AHA1-01-), SURVEY
NO. 14/B, TARALWADI, RAJAPUR, DIST:
RATNAGIRI - 416702
PH :9527623663/88066665572.
- RAJGURUNAGAR**
1599. MY CAR (PUNE) PVT. LTD. (CBZ1-01-), SURVEY
NO.94, SANDBHORWADI, NEAR TUKAI MANDIR,
PUNE-NASIK HIGHWAY, TAL-KHED,
RAJGURUNAGAR DISTT. PUNE. - 410505
PH :9112231553.
- RAMTEK**
1600. SEVA AUTO (BTU1-01-), MOUZA NO 275, P H NO
24, GRAM PANCHAYAT - MANSAR,TEHSIL -
RAMTEK, DISTRICT - NAGPUR, MAHARASHTRA.
-441401
PH :7758028060.
- RATNAGIRI**
1601. JAGRUT MOTORS PVT LTD (G301-01-),
D-25,MIDC MIRJOLE,MAHARASTRA,RATNAGIRI
-415639
PH :2352228380/9130013172.
- ROHA**
1602. EXCELL AUTOVISTA (COS1-01-), SHOP NO. 1 &
2, PANCHARTANA APARTMENTS, ROHA, ROHA
KOLAD ROAD, RAIGAD - 402109
PH :9209200073.
- SANGAMNER**
1603. SHAAN CARS PRIVATE LIMITED (HE03-01-), GAT
NO. 173/4/5/6, A/P VELHALE, NASHIK PUNE
HIGHWAY, SANGAMNER , DIST AHMEDNAGAR,
MAHARASHTRA - 422605
PH :02425-259197.
- SANGLI**
1604. CHOWGULE INDUSTRIES PVT. LTD. (J102-01-),
GAT NO.243 SANGLI KOLHAPUR ROAD, OPP.
TO GAJANAN MAHARAJ MANDIR, ANKALI,
TAL-SANGLI. DISTT. SANGLI - 416416
PH :9850966605.
1605. SIDDIH WHEELS (J104-01-), SR NO. 917/2/B,
SANGLI MIRAJ ROAD, MIRAJ, DISTRICT - SAGLI.
- 416410
PH :931727001, 0233-2211610/1620/1630.
- SANGOLI**
1606. CHAVAN MOTORS DIVISION INDIA PVT LTD
(CUE1-01-), GAT NO. 276/14/A, MAIN ROAD,
KOLHAPUR HIGHWAY, A/P & TALUKA -
SANGOLA, DIST.-SOLAPUR. - 413307
PH :8806665691.
- SASWAD**
1607. CHOWGULE INDUSTRIES PVT. LTD. (1908-03-),
SOLAPUR HIGHWAY, SASWAD, DIST. PUNE -
412301
PH :02115224450/02115225210.
- SATANA**
1608. SHAAN CARS (BSW1-01-), GAT NO 322/2/A/7,
PUNDLIK NAGAR MALEGAON ROAD, AT POST
SATANA DIST NASHIK - 423301 - 423301
PH :9922969656.
- SATARA**
1609. CHOWGULE INDUSTRIES PVT. LTD. (F303-01-),
PLOT NO. B-2,OLD MIDC,SATARA - 415002
PH :9011015066/9850966823.
- SAVNER**
1610. ARYA CARS (UNIT OF BARBATE AUTOMOTIVE
(I) PVT. LTD.) (BTJ1-01-), PLOT NO.2, MADANE
LAYOUT, MOUZA GUJARKHEDI, NR. INDIAN
PETROL PUMP, NAGPUR ROAD, SAVNER
DISTT. NAGPUR. - 441107
PH :8888859546.
- SAWANTWADI**
1611. JAGRUT MOTORS PVT LTD (BBL1-01-),
SHIVSHAMBO APARTMENT, 1190, A/P
KOLGAON, SURVEY NO.187, HISSA NO.33B,
TAL-SAWANTWADI, DISTT. SINDHUDURG. -
416510
PH :9970654699, 9689533472.
- SHAHAPUR**
1612. SHIVAM AUTO ZONE (I) PVT. LTD. (BZU1-01-),
DR. DESHPANDE COMPOUND, NEAR BHATSA
COLONY, VILLAGE - GOTHEGHAR, TALUKA -
SHAHPUR, DISTRICT - THANE, MAHARASHTRA
- 421601
PH :7718893483.
- SHAHUWADI**
1613. SAI SERVICE (BFT1-01-), GATE NO. 1213, R/AT
DONOLI, TALUKA - SHAHWADI, DIST.
-KOLHAPUR. - 416 213
PH :9932208448.
- SHILTPATA**
1614. VELOX MOTORS (SGJ1-01-), SURVEY NO- 99/2B,
VILLAGE-DAIGAHR, KALYAN SHILPHATA ROAD,
NEAR DATTA MANDIR, POST-PADALE,
DIST-THANE, PIN-421204. - 421204
PH :8419984188.
- SHIRUR**
1615. MAHALAXMI AUTOMOTIVES PVT. LTD.
(1912-02-), 1023/1, NEXT INDIAN OIL PETROL
PUMP, SARADWADI, PUNE-AHMEDNAGAR
HIGHWAY, TAL: SJURU, DIST: PUNE,
MAHARASHTRA - 412210
PH :8888837082 /9011038682.
- SHIRWAL**
1616. CHOWGULE INDUSTRIES PVT. LTD. (BSD1-01-),
GAT NO.175, A/P SHINDEVADI, SHIRWAL-BHOR
ROAD, SHIRWAL, TAL KHANDALA, DISTT.
SATARA - 412801
PH :9637399003.
- SHIRIMPUR**
1617. KANKARIYA AUTOMOBILES PVT. LTD.
(LV03-01-), S.N.139/1/3, NEAR NAKA NO.4,
SANGAMNER ROAD, SHIRIMPUR DISTT.
AHMEDNAGAR - 413709
PH :9420494543.
- SIKRUPUR**
1618. EXCELL AUTOVISTA PVT LTD (GKJ1-01-), AT
POST SHIKRUPUR MALTHAN PHATA, OPP.
CHAURASIYA CHANA CENTER, PUNE NAGAR
ROAD, TALUKA SHIRUR, DIST. PUNE,
PIN-412208, PUNE - 412208
PH :9146194973.
- SILLOD**
1619. PAGARIYA AUTO PVT. LTD. (2103-04-), PLOT
NO. 1920, SURVEY NO. 386, AURANGABAD
NAKA, SILLOD, AURANGABAD - 431112
PH :8600037213.

- SINNAR**
1620. SHAAN CARS PRIVATE LIMITED (3703-03), A-24, MIDC AREA MALEGAON,SINNAR TAL- SINNAR,, - 422103
PH : 02551-230305.
- SOLAPUR**
1621. CHAVAN MOTORS DIVISION INDIA PVT LTD (B102-02-), 150, AKALKOT ROAD,OPP. SVCS HIGH SCHOOL,SOLAPUR. - 413006
PH : 0217-2606666/8805986818.
1622. CHAVAN MOTORS DIVISION INDIA PVT LTD (B102-01-), 18,39, INDUSTRIAL ESTATE,HOTAGI ROAD, SOLAPUR. - 413224
PH : 8805777881.
1623. CHAVAN MOTORS DIVISION INDIA PVT LTD (B102-06-), PLOT NO.95, IND. ESTATE, HOTAGI ROAD, SOLAPUR. - 413003
PH : 8805986826.
- TALASARI**
1624. SHIVAM AUTO ZONE (I) PVT. LTD. (BIN1-01-), SURVEY NO. 19/1 PLOT NO. 5, AT-POST – VADAVALI, NH-8, TALASARI, THANE, MAHARASHTRA - 401606
PH : 6355249143/7777002930.
- TALEGAON**
1625. MY CAR (PUNE) PVT. LTD. (4K01-01-), SR.NO.113, HISSA NO 1/3/2/A, MUMBAI PUNE OLD HIGHWAY, MAVAL, TALEGAON - 410506
PH : 9730855855.
- TALOJA**
1626. EXCELL AUTOVISTA PVT LTD (AAC1-02-), PLOT NO-9,MIDC,NAVADE,TALOJA, TAL-PANVEL ,DIST-RAIGAD - 410208
PH : 9136948195/9320357300.
- TASGAON**
1627. SIDDHI WHEELS (A UNIT OF TARALEKAR MOTORS PVT. LTD.) (GKB1-01-), SHETKARI MARKET, NEAR ISHA HOTEL, TASGAON-SANGLI ROAD, TALUKA - TASGAON, DIST -SANGLI . - 416312
PH : 8275030748.
- THANE**
1628. FORT POINT AUTOMOTIVE (CARS) PVT. LTD. (3906-01-), KOTHARI WAREHOUSE NO. 111,POKHRAJ ROAD NO. 11,MANPADA, CHATLALSAR,THANE - 400607
PH : 9594974656, 8891039873..
1629. NAVNEET MOTORS (3908-02-), B R T PLOT ,THANE (W), MAHARASHTRA - 400607
PH : 9664496732, 9167215178.
1630. VELOX MOTORS (A UNIT OF CARCRAFT AUTOMOBILES PVT LTD) (05A3-02-), NEW SURVEY NO. 17/1B, NEAR BLUE ROOF CLUB, VILLAGE - OWALE, GHODBUNDER ROAD, THANE (W) . - 400615
PH : 8104989847, 96536 88455.
- TITWALA**
1631. AHER AUTOPRIME (BYP2-01-), SURVEY NO. 23/2, SHOP NO. 3, NEAR GOVELI, TITWALA ROAD, GHOTSAI, TITWALA, PIN-421301, MAHARASHTRA - 421301
PH : 18008334369.
- TUMSAR**
1632. AML (SLV1-01-), GAT NOS. 1350/149 & 1350/150, VILLAGE TUMSAR, TO TUMSAR, DIST.- BHANDARA, STATE-MAHARASHTRA - 441912
PH : 7391075992.
- TURBHE**
1633. SAI SERVICE (504-06-), D 42, TTC INDUSTRIAL AREA, NAVI MUMBAI, PIN-400705 - 400705 PH : 022-26861111/ 897699060.
- ULHASNAGAR**
1634. PRAKASH AUTO PVT. LTD., (3903-01-), U NO-3, SHEET NO. 30, VITHALWADI STATION ROAD, ULHASNAGAR - 421003
PH : 9987992127/9870453155.
- URALI KANCHAN**
1635. EXCELL AUTOVISTA PVT LTD (GK1-01-), GAT NO-24, VILLAGE-SORTAPWADI, TALUKA -HAVELI, URULI KANCHAN, DIST-PUNE, PIN-412201 - 412201
PH : 8097452280.
- VADUJ**
1636. CHOWGULE INDUSTRIES PVT. LTD. (F303-03-), KALEVASTI, VADUJ DAHIWADI ROAD , VADUJ - 415506
PH : 8888866659.
- VAIJAPUR**
1637. PAGARIYA AUTO PVT. LTD. (BNR1-01-), NEAR SUBHASH BUNGLOW, STATION ROAD, VAIJAPUR, AURANGABAD. - 423701
PH : 9922994237.
- VASAI**
1638. SAI SERVICE PRIVATE LIMITED (V901-01-), ANDRADESH BHAVAN, SURVEY #27 A,NEAR UMELA PHATAK, VASAI (WEST), DIST. THANE, MAHARASTRA - 401202
PH : 9167980080/9167980036/9594952211.
1639. SAI SERVICE PRIVATE LIMITED (504-03-), C/O MR. KENNETH NICHOLAS D'SOUZA, SURVEY NO-89, SATIVALI ROAD, VILLAGE-WALIV, VASAI (EAST), DIST-PALGHAR, MAHARASHTRA, PIN-410208 - 401208
PH : 9167980004/9167980084/9594950000.
- VASHI**
1640. MY CAR (PUNE) PVT. LTD. (05A4-01-), A-751/2, MIDC TTC, TURBE MAHAPE ROAD, PAWANE, NAVI MUMBAI - 400 071
PH : 8104906953, 9372802861, 9326713481.
- VELHE**
1641. SUMANKIRTI CARS (SLO1-01-), MAUZA NO-492/2, A/P-VELHA, TAL- VELHA, DIST-PUNE-412212- 412212
PH : 8554981603/8550995444.
- VIKRAMGADH**
1642. SHIVAM AUTOZONE (SKV1-01-), NEAR GOVERNMENT DISPENSARY HOSPITAL, DAHANU ROAD, TEHSIL-VIKRAMGADH, DIST-PALGHAR-401605 - 401605
PH : 8082551080.
- VIRAR**
1643. SAI SERVICE PRIVATE LIMITED (V901-02-), SURVEY NO.16, AGASHI ROAD, PADMAN NAGAR, VIRAR-WEST, DISTT. PALGHAR. - 401301
PH : 9594952343/9167980036/9594952211.
- VITA**
1644. CHOWGULE INDUSTRIES PVT. LTD. (BSE1-01-), S NO. 900, HISSA NO. 1,2,3/1,2, SANGLI VITA ROAD, VITA, TALUKA - KHANAPUR, DISTRICT – SANGLI, MAHARASHTRA - 415311
PH : 8888870120.
- WAGHOLI**
1645. SAI SERVICE PRIVATE LIMITED (1901-04-), GAT NO 2406/1440, VILLAGE- WAGHOLI, TAL - HAVELI, DIST- PUNE - 412207
PH : 9923208313/9923208221/9923208133.
- WAI**
1646. CHOWGULE INDUSTRIES PVT. LTD. (BYC1-01-), GAT NO. 407, A/P SHENDURAND, MIDC ROAD, NEAR HOTEL GANDHARVA, OPP. DHOM LEFT CANAL, TAL – WAI, DISTT. SATARA - 412803
PH : 8380080501.
- WALUJ**
1647. PAGARIYA AUTO PVT. LTD. (2103-03-), E-16,WALUJ AURANGABAD - 431001
PH : 9860999466.
- WARANANAGAR**
1648. SAI SERVICE PRIVATE LIMITED (CRB1-01-), GAT NO.:112/1A, KODOLI, TALUKA: PANHALA, DIST. KOLHAPUR - 416114
PH : 9923204173.
- WARDHA**
1649. SEVA AUTOMOTIVE LTD. (2002-02-), GOPURI CHOWK, OPP. BANK OF INDIA COLONY, NAGPUR ROAD, WARDHA . - 442001
PH : 07152-253545/253525.
- WARD**
1650. SEVA AUTOMOTIVE PVT. LTD. (2002-05-), PLOT NO. 177, WARDHA-NAGPUR HIGHWAY, AT. PAVNAR, TEHSIL - WARDHA, DIST -WARDH, PIN-442111, MAHARASHTRA - 442111
PH : 7720009444.
- WARUD**
1651. ASPA BANDSONS AUTO PVT. LTD. (F201-04-), SURVEY NO. 50/3, SETURANJAGHAT ROAD, TALUKA: WARUD, DIST. AMRAWATI - 444906
PH : 7248925687.
- WASHIM**
1652. ASPA BANDSONS AUTO PVT. LTD. (F201-02-), NEAR RAILWAY CROSSING,HIGOLI ROAD,WASHIM . - 444505
PH : 9922500981/ 9146191534.
- YAVATMAL**
1653. HIMALAYA CARS (4M01-01-), OPPOSITE RAUT PETROL PUMP, DARWHA ROAD, YAVATMAL, MAHARASHTRA . - 445001
PH : 07232-249991.
- YEOLA**
1654. SEVA AUTOMOTIVES PVT LTD (BST1-01-), GAT NO. 65-A, PLOT NO. 41, AHMED NAGAR-MANMAD ROAD, NEAR TEHSIL OFFICE, YEOLA, TALUKA – YEOLA, DISTRICT – NASHIK, MAHARASHTRA. - 423401
PH : 9130033944.
- YEWAT**
1655. MAHALAXMI AUTOMOTIVES PVT. LTD. (AZA1-01-), SOLAPUR PUNE NATIONAL HIGHWAY, SAHAJAPUR, YEWAT, TALUKA: DAUND, DISTT: PUNE (MAHARASHTRA). - 412202
PH : 8308818946.
- MANIPUR**
- BISHNUPUR**
1656. EASTERN MOTORS (CSA1-01-), BISHNUPUR BAZAR, TIDIM ROAD, BISHNUPUR DISTT. MANIPUR . - 795126
PH : 8415945626.
- CHANDEL**
1657. EASTERN MOTORS (CSB1-01-), KAKCHING LAMKHAJ, AH1 (INDO BURMA ROAD), CHANDEL (MANIPUR) - 795103
PH : 8415945626.
- CHURACHANDPUR**
1658. EASTERN MOTORS (BBE1-01-), HMUIA VENG,TEDDIM ROAD, CHURACHANDPUR, MANIPUR . - 795128
PH : 03874235969, 9862555472.
- IMPHAL**
1659. EASTERN MOTORS (7401-01-), CHINGMEIRONG EAST, IMPHAL, MANIPUR . - 795 001
PH : 8415945626.

Dealer Network (AS ON 31.10.2023)

1660. EASTERN MOTORS (7401-02), NH.39,
CHINGMEIRONG, WEST, IMPHAL - 795010
PH : 98415945626.
1661. SAMADON ENTERPRISE (7402-01), 82 GHARI
MAKHA LEIKAI, IMPHAL WEST, MANIPUR - 795
140
PH : 7005987123.

JIRIBAM

1662. EASTERN MOTORS (SMG1-01), AT HILGHAT,
IMPHAL SILCHAR ROAD, JIRIBAM - 788104
PH : 98415945626.

SENAPATI

1663. EASTERN MOTORS (CNN1-01), DIST.-COUNCIL
(POULEA) VILLAGE, P.O. - SENAPATI,
SENAPATI, MANIPUR - 795 106
PH : 98415945626.

THOUBAL

1664. EASTERN MOTORS (BJL1-01), THOUBAL
ATHOKPAM KHUNOU, NEAR D.C. OFFICE
COMPLEX, THOUBAL, MANIPUR - 795138
PH : 9862662225.

UKHRUL

1665. SAMADON ENTERPRISE (SCK1-01),
KAMPHASOM, UKHRUL, MANIPUR - 795142
PH : 9774216305.

MEGHALAYA

BHAITBARI

1666. RANI MOTORS (-), NEW BHAITBARI, WEST
GARO HILLS, MEGHALAYA, (PATT A NO - 89
SONG - NEKEKONA, MOZU NO - VI- 3 LOT -
794104
PH : 8638220312.

BHOIRYMBONG

1667. RANI MOTORS (CHP1-01), VILLAGE - UMROI
MADAN, DISTRICT - RI BHOI, MEGHALAYA -
793103
PH : 9774478281.

JOWAI

1668. RANI MOTORS (3I01-01), LADTHADLABHO,
OPP. PWD OFFICE, JOWAI, DIST - JAITIA
HILLS, MEGHALAYA - 793150
PH : 7085849525.

KHLIEHRIAT

1669. BANALARI WORLD CARS (8502-03-),
JOWAI-SICHAR ROAD, MEGHALAYA,
KHLIEHRIAT - 793150
PH : 7005757760/7005569550.

MAWKYRWAT

1670. RANI MOTORS (CGR1-01), DAK BANGLA,
MAWKYRWAT, WEST KHASI HILLS, MEGHALAYA -
793114
PH : 9856005544.

MAWNGAP

1671. BANALARI WORLD CARS (CBK1-01-),
LAITYNTER, SHILLONG NONGTONG ROAD,
MAWNGAP, DIST.-EAST KHASI HILLS,
MEGHALAYA - 793121
PH : 7005757760/7005569550.

MOIRANG

1672. SAMADON (SLD1-01), MOIRANG LAISHANGBAM
LEIKAI, PO AND PS: MOIRANG, DIST-
BISHNUPUR, MANIPUR - 795133
PH : 7005987122.

MYLLIEM

1673. BANALARI WORLD CARS (CSK1-01-),
MADANING SYIEM, MYLLIEM, SHILLONG
CHERRAPUNJI ROAD, DISTT: EAST KHASI
HILLS, MEGHALAYA - 793009
PH : 7005757760/7005569550.

NONGPOH

1674. RANI MOTORS (8501-05), NEAR D.T.O. OFFICE,
G.S. ROAD, NONGPOH, RIBHOI DISTT. -
793102
PH : 9774478281.

NONGSTOIN

1675. RANI MOTORS (8501-04), OPP. IRANI PETROL
PUMP, NEW NONGSTEIN, DISTRICT-WEST
KHASI HILLS, MEGHALAYA - 793119
PH : 9856005544.

PYNURSULA

1676. BANALARI CAR WORLD (CBJ1-01-),
PHLANGSHAIN MAIN ROAD, SHILLONG DAWKI,
PYNURSULA, DISTRICT - EAST KHASI HILLS,
MEGHALAYA - 793110 - 793110
PH : 8415942700.

SHILLONG

1677. RANI MOTORS (8501-01), SUNNY HILLS,
GARIKHANA, G.S.ROAD, SHILLONG - 793014
PH : 986209400.

1678. RANI MOTORS (8501-02-), MAWBLEI, NH-44,
SHILLONG JOWAI ROAD, MEGHALAYA - 793021
PH : 8014734780.

1679. BANALARI WORLD CARS (8602-01-), MAWLAI
NONGKWAR, G.S. ROAD, SHILLONG - 793017
PH : 7005757760/7005569550.

TURA

1680. RANI MOTORS (CLF1-01-), AGILLANGRE,
ARAIMILE, PO NEW TURA, TURA - 794101
PH : 7005653791.

UMSAW

1681. BANALARI WORLD CARS (CHZ1-01-),
UMSAWKHAN RAID MAWBHUH, MYLLIEM
SYIEMSHIP, RI BHOI DISTRICT, MEGHALAYA -
793123
PH : 7005757760/7005569550.

MIZORAM

AIZAWL

1682. G.I.G. MOTORS (9103-01), EDENTHAR, AIZAWL,
MIZORAM - 796001
PH : 8974559065.

LUNGLEI

1683. GIG (YS01-01-), RAMTHAR VILLAGE, LUNGLEI,
DISTRICT-LUNGLEI, MIZORAM - 796701
PH : 8974559065.

MP

BHANPURA

1684. PATEL MOTORS (-), GAROTH RD., BHANPURA,
MADHYA PRADESH - 458775 - 458775
PH : 9826306099.

BHOPAL

1685. SRISATY SAI AUTOMOBILES PVT. LTD.
(310-01-), RAJENDRA PRASAD BHAWAN
PARISHAR, INFRONT OF OLD VIDHAN SABHA
BUILDING, PO - JAHANGIRABAD, MALVIYA
NAGAR, BHOPAL, DISTRICT - BHOPAL,
MADHYA PRADESH - 462008 - 462008
PH : 7415862390.

BICHIHYA

1686. MAA GAYATRI AUTOMOBILES (SMK1-01-),
SALPURA ROAD, ATRU, NEAR DEPUTY OFFICE,
PIN-325218, RAJASTHAN - 481995
PH : 9030143327.

NAINPUR

1687. STANDARD MOTOCORP PVT LTD (SEZ2-01-),
MANJU SAHU, MANDLA ROAD, NEAR MPEB
OFFICE, ADJOINING TO BAJAU SHOW ROOM,
NAINPUR, DISST MANDLA, MADHYA PRADESH
- 481776 - 481776
PH : 7771003374.

NIWAS

1688. STANDARD MOTOCORP (-), OPP. INDIAL OIL
PETROL PUMP, NIWAS . DISTRICT MANDLA,
MADHYA PRADESH - 483001 - 483001
PH : 7800806222.

NAGALAND

DIMAPUR

1689. PROGRESSIVE MOTORS (3201-01-), OPPOSITE
AIRPORT, N.H.39, DIMAPUR KOHIMA ROAD,
DIMAPUR - 797112
PH : 7005254089.

KOHIMA

1690. SEYIE AUTO (4N02-01-), TSIECIE, NH-29, PHEK
ROAD, KOHIMA, NAGALAND - 797001
PH : 7005867051.

MOKOKCHUNG

1691. PROGRESSIVE MOTORS (CGL1-01-),
SUNGKONMED ROAD, MOKOKCHUNG,
NAGALAND - 798601
PH : 87877325534.

WOKHA

1692. PROGRESSIVE MOTORS (SFH1-01-), NIOPEN
COLONY, WOKHA-797111, NAGALAND - 797111
PH : 9774070707.

NEW DELHI

DELHI (GTK)

1693. DD MOTORS (A DIVISION OF D.D. PREM
PVT LTD.) (08F2-02-), GROUND FLOOR, PLOT
NO. C-7, SMA CO-OPERATIVE INDUSTRIAL
AREA, GTK ROAD, AZADPUR, PIN-110033,
DELHI - 110033
PH : 9873187388.

NEW DELHI

1694. COMPETENT AUTO (806-08-), 43/12,
NAJAFGARH BAHDURGARH ROAD, NEW ANA
MANDI, NEAR JAAT BHAWAN, NAJAFGARH,
PIN-110043, DELHI - 110043
PH : 8750700420.

ODHISA

ATTAGARH

1695. TUSHI (SLZ1-01-), KHATA NO 212/420, MOUZA
- BIRAKISHOREPUR ATHAGARH, DISTRICT:
CUTTACK - 754029
PH : 7504890838.

ODISHA

ANANDAPUR

1696. JVOTE MOTORS PVT LTD (CIU2-01-), KHATA
NO. 246/407, PLOT NO. 76, P.S. - GHASIPURA,
MOUZA - SUDUSUDIA, DISTRICT - KEONJHAR,
ANANDPUR, ODISHA . - 758021
PH : 7381028525.

ANGUL

1697. ODYSSEY MOTORS PVT LTD (W101-01-), AT/P.O
KULAD (NEAR NALCO CPP PLANT), KANDASAR,
NALCO NAGAR, ANGUL (DISTT: ANGUL). -
759145
PH : 9439817308.

BALASORE

1698. JYOTE MOTORS (BALASORE) PVT. LTD
(L501-01-), PLOT NO. 276,
GANESHWARPUR-NH-5, POST-JANUGANJ VIA
REMUNA, DIST-BALASORE - 756019
PH : 7381072600.

BALUGOAN

1699. JYOTE MOTORS (CWG1-01-), M/S PLOT NO
758/31, KHATA NO
350/30, MOUZA-GOBARDHANPUR, BALUGAON,
DISTRICT-KHORDA, ODISHA-752030 - 752030
PH : 9776615001.

BAMRA

1700. ODYSSEY MOTORS (SIA1-01), M/S ODYSSEY MOTORS,NEAR SATSANG KENDRA, DUMERUNDA COLLEGE ROAD, BAMBRA, GOVINDPUR - 768221. - 768221 PH : 9439314464.
- BARGARH**
1701. ODYSSEY MOTORS PVT LTD (D401-04), AT/PO -BARGARH, NH-6, DISTT.-BARGARH, ORISSA - 768028 PH : 8908944206.
- BARIPADA**
1702. JYOTE MOTORS (BALASORE) PVT. LTD (L501-02), PLOT NO. 90/523/904, SWARUP VILLA, NH-5, BARIPADA - 757001 PH : 7381072624.
- BERHAMPUKUR**
1703. SKY AUTOMOBILES (E203-01), PLOT NO.80/1191 DHARMA NAGAR, MAIN ROAD, BERHAMPUKUR - 760002 PH : 7381266000.
1704. SKY AUTOMOBILES (E203-02), PLOT NO. 876, WESTERN ROW NH-5, KONISI HATO, VILLAGE - KONISI, BERHAMPORE, GANJAM, ODISHA. - 761008 PH : 7381266000.
- BHADRAK**
1705. JYOTE MOTORS (BALASORE) PVT. LTD (IZ01-01), PLOT NO. 14/4837, KHATA NO. 1345/1087, TRISHALPUR, CHARMPA, BHADRAK ., ODISHA - 756101 PH : 9776345311.
- BHAWANIPATNA**
1706. LEGEND CARS PVT. LTD. (SW01-02), NH-201, KESINGA ROAD, BHAWANIPATNA - 766001 PH : 9937198664.
- BHUBANESHWAR (NAYAPALLI)**
1707. JYOTE MOTORS PVT LTD (405-01), A/62, NAYAPALLI,NH-5,BHUBANESHWAR,ORISSA-751 003 - 751005 PH : 7381028525.
- BHUBANESWAR**
1708. NARAYANI MOTORS PVT. LTD. (403-01), 217, CUTTACK ROAD, JHARPARA, BHUBANESWAR - 751006 PH : 9583022031.
1709. JYOTE MOTORS PVT LTD (402-01), A-62, NAYAPALLI,NEAR CRPF SQUARE, BHUBANESWAR - 751003 PH : 7064493302.
1710. SKY AUTOMOBILES (404-01), PLOT NO. -435/1866, NEAR KITI SQUARE PATIA, BHUBANESWAR - 751022 PH : 8117823611.
1711. NARAYANI MOTORS PVT. LTD. (403-02), PLOT NO 56 AND 57,RASULGARH, BHUBANESHWAR, ODISHA - 751010 PH : 9583022046.
1712. JYOTE MOTORS PVT LTD (402-04), PLOT NO. 22 & 23, SECTOR-A, ZONE-D, MANCHESWAR INDUSTRIAL ESTATE AREA, BHUBANESHWAR. - 751010 PH : 7978910223.
1713. SKY AUTOMOBILES (404-02), KHATA NO. 457/675, PLOT NO. 543, 756, 789 AND 546, SRIVIHAR, INFRONT OF IOC OFFICE, P.S. -CHADRASHEKARPUR, BHUBANESHWAR, ODISHA - 751 024 PH : 7440011604.
- BOLANGIR**
1714. ODYSSEY MOTORS PVT LTD (D401-03), NH-201, MADHIPALI, SAMBHALPUR ROAD, BOLANGIR, ORISSA - 767001 PH : 8895418122.
- CHANDIKHOLE**
1715. SKY AUTOMOBILES (BXL1-01), PLOT NO.285/3, SHANTI MANDAP MOUZA -SUNGUDA, TEHSIL-DARPANI, PO CHANDIKHOL, DIST. -JAJPUR, ODISHA. - 755044 PH : 9776645798.
- CUTTACK**
1716. SKY AUTOMOBILES (6701-02), BHANPUR, NH-5, CUTTACK - 753011 PH : 9776645798.
1717. TUSHI MOTORS PVT. LTD. (6702-01), PLOT NO. C-14, PLOT NO.C-13,INDUSTRIAL ESTATE ,KHAPURIA TAHSIL - CUTTACK SADAR ,CUTTACK DISTRICT,BHUBANESWAR - 753001 PH : 9692912345.
- DEOGARH**
1718. ORBIT MOTORS PVT. LTD. (CBB1-01), KHATA NO. 270, OI MOUZA, DEOGARH, ODISHA - 768108 PH : 9437607865.
- DHENKENAL**
1719. SKY AUTOMOBILES (6701-04), PLOT NO-136/1103, KATHAGARA ., NEARASSAM OIL, NH-42, DHENKANAL. - 759001 PH : 7440025919.
- GANDAI**
1720. SPARSH AUTOMOBILES (SHU1-01), M/S SPARSH AUTOMOBILES ,WARD NO - 7, NEAR KRISHI UPAJ MANDI, GANDAI RAJNANDGAON ROAD,GANDAI - 491888 - 591198 PH : 9926626662.
- JAGATSINGHPUR**
1721. NARAYANI MOTORS PVT. LTD. (CFM1-01), KHATA NO. 827/221 & 827/222, PLOT NO. 1197 & 1199 NO.565, MOUZA-MARKHANDPUR, PO PUNABA, DISTT. JAGATSINGHPUR, ODISHA - 754103 PH : 9556511213.
- JAJPUR**
1722. SKY AUTOMOBILES (6701-05), P.O.JAHNA, P.S. KORAI, KEONJHAR ROAD, JAJPUR, ORRissa - 7553019 PH : 9583011010.
- JALESWAR**
1723. JYOTE MOTORS (BALASORE) PVT. LTD (BXP1-01), KHATA NO. 422/744, PLOT NO. 2304 AT P.O. - NAYABAZAR, JALESWAR, DIST.- BALASORE, ODISHA. - 756032 PH : 7381072600.
- JEYPORE**
1724. LEGEND CARS PVT. LTD. (SW01-03), SOURAGI/3065, JEYPORE,DISTT-KORAPUT,ORISSA INDIA - 764001 PH : 9437575188.
- JHARSUGUDA**
1725. ODYSSEY MOTORS PVT LTD (BJU1-01), KHATA NO. 466/502, PLOT NO. 966, JHARSUGUDA TOWN, UNIT NO. 7, SARBALAH P.S. JHARSUGUDA, ORISSA - 768201 PH : 9439548623.
- KEONJHAR**
1726. JYOTE MOTORS PVT LTD (7U01-01), NH 215, DHRUPADA, BARBIL ROAD, KEONJHAR. - 758001 PH : 7064499047.
- NAYAGARH**
1727. JYOTE MOTORS PVT LTD (402-02), PLOT NO. 1319/3750, KHANDAPADA, NAYAGARH - 752069 PH : 7064499046.
- NIMPARA**
1728. NARAYANI MOTORS PVT. LTD. (CFL1-01), PLOT NO. 345/1344, GANESH BAZAR, NIMAPARA, DISTRICT - PURI, ODISHA. - 752106 PH : 7381093622.
- PALLAHARA**
1729. ODYSSEY MOTORS PVT LTD (CHV1-01), KHATA NO. 260, PLOT NO. 998/3720, PAHALLARA, ODISHA. - 759119 PH : 9439817308.
- PARADEEP**
1730. NARAYANI MOTORS PVT. LTD. (OE01-01), PLOT NO. 1438, UDAYA VIHAR, NEAR DO CHOWKI SQUARE, PARADEEP, ODISHA. - 754141 PH : 9583022020.
- PARLAKHEMUNDI**
1731. SKY AUTOMOBILES (CLG1-01), PLOT NO. 273, KHATA NO. 78, WARD NO. 1, PARLAKHEMUNDI, GAJAPATI, ORISSA. - 761211 PH : 9776999977.
- PURI**
1732. NARAYANI MOTORS PVT. LTD. (4Q01-01), PLOT NO.1797/2449, KHATA NO.187A/32, AT. BATAMANGLA,PO HAREKRISHNAPUR, BATAGAON, PURI, ODISHA - 752002 PH : 9583022220.
- RAIRANGPUR**
1733. JYOTE MOTORS (BALASORE) PVT. LTD (CES1-01), PLOT NO.1077/2466, PURNAGHATI, RAI'RANGPUR, DISTT: MAYURBHANJ, ODISHA - 757046 PH : 7064499936.
- RAYAGADA**
1734. LEGEND CARS (YB01-01), M/S LEGEND CARS, JK PUR ROAD, KOMTALPETA, NEAR ENFIELD SHOWROOM, RAYAGADDA, ODISHA - 765001 PH : 7008771180.
- ROURKELA**
1735. ORBIT MOTORS PVT. LTD. (8701-01), VEDVYAS, NEAR PAAHADI BAR, ROURKELA,ORRISA - 769041 PH : 9437061040.
- SAMBALPUR**
1736. ODYSSEY MOTORS PVT LTD (D401-01), AINTHAPALI, SAMBALPUR, ORISSA - 768004 PH : 7381083571.
1737. APARNAA MOTORS (A UNIT OF APARNAA VAHAN) (D402-01), PLOT NO. 969/4497,PANCHGACHIA SAMBALPUR - 768019 PH : 8260966698.
1738. ODYSSEY (D401-05), ODYSSEY MOTORS, AINTHAPALI, SAMBALPUR - 768004 PH : 9692200963.
- SORO**
1739. JYOTE MOTORS (SQF1-01), PLOT NO 15/1269,KHATA NO 442, SORO, BALASORE, ODISHA STATE. - 756045 PH : 9776615001.
- SUBARNA PUR**
1740. ODYSSEY MOTORS PVT LTD (BWK1-01), KHATA NO. 32, MOUZA - SANJHINIK, SONEPUR (ALSO KNOWN AS SUBARNA PUR), DISTRICT - SUBARNPUR, ODISHA - 767017 PH : 8895418122.
- SUNDERGARH**
1741. ORBIT MOTORS PVT. LTD. (BWJ1-01), M/S ORBIT MOTORS, AT - PATRAPALI, PO SUNDERGARH, BY PASS ROAD, NEAR BJP OFFICE, SUNDERGARH - 770001 PH : 8249354447.

Dealer Network (AS ON 31.10.2023)

TANGI

1742. SKY AUTO (SKM1-01-), KHATA NO 731/18, PLOT NO.107, CHAMPAGARH NH 5, TANGI, DISTRICT – KHORDHA, - 752023
PH: 9776900333.

UDALA

1743. JYOTE MOTORS (BALASORE) PVT. LTD (CHW1-01-), MOJZA - UDALA, TOWN UNIT NO. 7, NAGBANI, TAHISL NO. 325, THANA NO. 110, DIST - MAYURBHANJ, ODISHA. - 757041
PH :8249877935.

ODISHAN

NIRGUNDI

1744. NARAYANI (403-04-), KHATA NO 251/255, PLOT NO 233, MALGOWDINI-MOJZA BLITERUA, NIRGUNDI, DISTRICT-CUTTACK, ORISSA. - 754025
PH :9583001877.

ORISSA

BHUBANESWAR

1745. NARAYANI (403-03-), KHATA NO-652, PLOT NO 4493, MAUZA PANDRA THANA-RASULGARH, BHUABNESHWAR - 751025
PH :9583001877.

KENDRAPARA

1746. JYOTE MOTORS (SF1-01-), M/S JYOTE MOTORS, KHATA NO: 351/85, PLOT NUMBER 633, MOUZA-ALBANKA, KENDRAPARA, ODISHA. - 754208
PH :9776615001.

KUCHINDA

1747. ODYSSEY MOTORS (SLN1-01-), /S ODYSSEY MOTORS, PLOT NO 146, KHATA NO 76/9, MOUZA-KUNDAPOSH, NEAR KUNDESHWAR MANDIR, KUCHINDA, SAMBULPUR. - 768222
PH :9439314464.

PADAMPUR

1748. ODYSSEY MOTORS (SFB1-01-), M/S ODYSSEY MOTORS, CHARPALI, PADAMPUR, NEAR REGENCY HOTEL, DISTRICT-BARGARH, ORISSA - 770039
PH :9439314464.

PUDUCHERRY

KARAikal

1749. SHENBAKA CARS PVT. LTD. (CCP1-01-), R. S. NO. 173/3PT, T. S. NO. 9/5, WARD, L-BLOCK, NO. 3, KARAikal NAGORE MAIN ROAD, VILLAGE - OUDUTHURAI REVENUE, NERAVY COMMUNE, KARAikal MUNICIPALITY, KARAikal. - 609602
PH :04368-227800/1/2.

MADAGADIPET

1750. SHENBAKA CARS PVT. LTD (CUD1-01-), SURVEY NO. 129/A/4/2, MADAGADIPET REVENUE VILLAGE, MADAGADIPET, PONDICHERRY - 605 107
PH :8220046178.

PONDICHERRY

1751. SHENBAKA CARS PRIVATE LIMITED (9601-01-), 133/1A, MOOLAKULAM, VILLUPURAM MAIN ROAD, PONDICHERRY - 605010
PH :0413-2293391/92/93.

PUNJAB

ABOHAR

1752. TARA AUTOMOBILES (ABOHAR) (H501-01-), SHREE GURU JAMBHESHWAR CHOWK, MALOUT SHREE GANGA NAGAR BYPASS, ABOHAR, PUNJAB - 152116
PH :9876047847.

ADAMPUR

1753. LOVELY AUTOS (CHA1-01-), KHASRA NO.10/7/1, JALANDHAR-HOSHIARPUR HIGHWAY, ADAMPUR DIST. JALANDHAR - 144102
PH :8288050777.

AJNALA

1754. SWANI MOTORS PVT. LTD. (CBP1-01-), KHASRA NO. 71, AJNALA-AMRITSAR ROAD, VILLAGE - BHARKA TARA SINGH, TEHSIL - AJNALA, DISTRICT - AMRITSAR, PUNJAB. - 143102
PH :8872001731.

AMRITSAR

1755. SWANI MOTORS LTD. (1701-01-), 81,COURT ROAD, AMRITSAR - 143001
PH :9877482175, 8872000000.
1756. JAYCEE MOTORS (1704-01-), 274 EAST MOHAN NAGAR, G.T ROAD, AMRITSAR - 143006
PH :9780038335.
1757. RISHABH FOURWHEELS PVT. LTD. (1703-01-), ADARSH SOAP COMPLEX, BATALA ROAD, AMRITSAR - 143004
PH :9914841577.

ANANADPUR SAHIB

1758. CM AUTOSALES PVT. LTD. (OF01-01-), VILLAGE MIYANPUR, NAINA DEVI ROAD, ANANDPUR SAHIB, TEHSIL ANANDPUR SAHIB, DISTT. ROPAR, PUNJAB - 140123
PH :9915022897.

APRA

1759. LOVELY AUTOS (CVW1-01-), SAMRAI CHOWK PHILLAURO ROAD, VILLAGE - APRA, TEHSIL - PHILLAURO, DIST-JALANDHAR, STATE - PUNJAB. - 144416
PH :9915020515.

AUR

1760. LOVELY AUTOS (CVY1-01-), KHATUNI NO. 479/588, KHASRA NO. 27/2004(2-18), 21/2(2-10), VILLAGE - AUR, TEHSIL - NANAWASHAR, DIST. -SBS NAGAR, STATE - PUNJAB. - 144417
PH :9915020510.

BAGHA PURANA

1761. REMIRA MOTORS PVT. LTD. (BAH2-01-), BUILDING NO.68, OPP. SHINA ENCLAVE, MOGA ROAD, BAGHA PURANA, DISTT. MOGA, PIN-142038 - 142038
PH :7087025009.

BALACHAUR

1762. LOVELY AUTOS (XV01-01-), NEAR MCDONALD - GHUGGI TOWN, VPO-GARHI KANUGO, NANAWASHAR CHANDIGARH HIGHWAY, CHANDIGARH ROAD, BALACHAUR, DISTRICT-S.B.S NAGAR, PUNJAB (NANAWASHAHR) - 144521
PH :9878427910.

BALBEHRA

1763. HIRA AUTOWORLD (SOG1-01-), NEAR HDFC BANK LTD., SAMANA ROAD, BALBEHRA - 147101
PH :9888341118.

BANGA

1764. LOVELY AUTOS (3503-03-), NAVASEHAR-JALANDHAR ROAD, BANGA - 144405
PH :9915028625.

BANUR

1765. TRICITY AUTOS PVT. LTD. (BRT1-01-), SANDHU MARKET NEAR SALES TAX BARRIER, BANUR RAJPURA HIGHWAY, BANUR, PUNJAB - 140601
PH :988882330.

BARNALA

1766. MAX AUTOMOBILES (4S02-01-), NR. HANDIYAN CHOWK,MANSA BYE PASS,BARNALA,PUNJAB - 151001
PH :285022, 9216529220.

BATALA

1767. PATHANKOT VEHICLEADEAS PVT. LTD. (A701-05-), NEAR VMS INSTITUTE, SAID MUBARAK, GT ROAD, BATALA - 143505
PH :9417900850, 9417900918.

BEGOWAL

1768. MARWAHA AUTOS (BHF2-01-), PELIA TOWN, BHADAS ROAD, WARD NO. 11, JALANDHAR ROAD, VPO. BEGOWAL, KAPURTHALA, PIN-144621, PUNJAB - 144621
PH :9779166004.

BHDSON

1769. HIRA AUTOMOBILES LTD (BAG1-01-), VILLAGE CHASWAL, NABHA ROAD, BHADSON - 147202
PH :9217048236, 9217048250.

BHAGTA BHAI KA

1770. TARA AUTOMOBILES (BHG1-01-), NEAR SARPANCH HOUSE, BHAGTA BHAI KA, DISTRICT – BHATINDA. - 151206
PH :8437030666.

BHATINDA

1771. TARA AUTOMOBILES (BHTINDA) (7002-01-), MANSA ROAD, OPP. I.T.I, BATHINDA - 151001
PH :0164-2235349, 50.

BHIKHWIND

1772. RISHABH FOURWHEELS PVT. LTD. (BPK1-01-), KHASRA NO. 67/3/2, 4/1, 7/2, 8/1, 8/2, PIND BHIKHWIND, TEHSIL – PATTI, DISTRICT – TARN TARAN, PUNJAB. - 143303
PH :9914708577.

BHOGPUR

1773. LOVELY AUTOS (BRU2-01-), KHASRA NO. 31/14, 17/2 18/2 23, MAIN JALANDHAR-PATHANKOT HIGHWAY,OPP. AJIT PALACE, BHOGPUR - 144201
PH :9872030006.

BHULATH

1774. LOVELY AUTOS (CHB1-01-), WARD NO. 1, NADALA-BEGOWAL ROAD, VPO BHULATH, DISTRICT – KAPURTHALA, PUNJAB. - 144622
PH :9876541065, 8288050777.

BILGA

1775. LOVELY AUTOMOBILES (SPM1-01-), VPO BILGA, NEAR GOVT. PRIMARY SCHOOL, TEHSIL PHILLAURO, JALANDHAR. - 144036
PH :9815069814.

CHUNNI KALAN

1776. HOSHIARPUR AUTOMOBILES (CFG1-01-), NEAR RAJINDER MOTORS, SIRHIND-CHANDIGARH ROAD, VILLAGE CHUNNI, DIST. FATEHGHAR SAHIB. - 140307
PH :248005, 9815131766.

DASUYA

1777. HOSHIARPUR AUTOMOBILES (H402-04-), OPP. CHEEMA PETROL PUMP, C.T. ROAD, DASUYA - 144205
PH :9815131766, 9872312371.

DERABASSI

1778. AUTOPACE NETWORK PVT LTD (705-02-), AT NH-2, NEAR DERABASSI, TOLL BARRIER-DERABASSI - 145057
PH :9815011669.

DEVIGARH

1779. HIRA AUTOMOBILES LTD (OG1-01-), CHANNA MOUR, PEHOWA PATIALA ROAD, DEVIGARH, DIST. PATIALA (PUNJAB). - 147111
PH :8872034118, 9217048230.

DHILWAN

1780. MARWAHA AUTOS (SGU1-01), MIANI
BAKARPUR,AMRITSAR ROAD, OPP-INDIAN OIL
PETROL PUMP, DHLIWAN DISTT KAPURTHALA -
144804
PH :9779166004.
- DORAH**
1781. GULZAR MOTORS (QC02-01), G.T. ROAD, NEAR
ARRICHAN CHOWK, DORAH, DISTT.
LUDHIANA, PUNJAB. - 141421
PH :9814191122.
- FARIDKOT**
1782. MAPSKO AUTO INDIA PVT. LTD. (4U02-01),
FARIDKOT - KOTAKPURA ROAD, FARIDKOT,
PUNJAB - 151204
PH :01639-264001,7347005020.
- FATEHGARH CHURIAN**
1783. PATHANKOT VEHICLEADES PVT. LTD.
(BA01-01), KHASA NO. 17 R, DERABABA
NANAK ROAD, FATEHGARH CHURIAN, TEHSIL -
BATALA, DIST - GURDASPUR, STATE - PUNJAB.
- 143 602
PH :9417900850 , 9875930180.
- FAZILKA**
1784. TARA AUTOMOBILES (H501-03), NH-10, NEAR
SARVHITKARI BAL VIDYA MANDIR, FAZILKA -
152116
PH :9876047847.
- FEROZEPUR**
1785. BABA AUTOS (TC01-01), MOGA ROAD,
FEROZEPUR CANTT - 152002
PH :8872013211.
- GARHSANKAR**
1786. HOSHIARPUR AUTOMOBILES (H402-02), OPP.
COURT, CHANDIGARH ROAD, GARHSANKAR,
DIST. HOSHIARPUR - 144527
PH :9815131766, 9781543131.
- GHANAUR**
1787. HIRA AUTOWORLD LLP (CVX2-01), WARD NO.
1, OPPOSITE OLD PETROL PUMP GHANAUR
PATIALA ROAD, SUB TEHSIL - GHANAUR,
TEHSIL - RAJPURA, DIST -PATIALA, STATE -
PUNJAB. - 140401
PH :9217048437.
- GHAROTA**
1788. PATHANKOT VEHICLEADES (SFF1-01),
VILLAGE AND PO GHAROTA, OPPOSITE
PUNJAB GRAMIN BANK, TEHSIL & DISTT.
PATHANKOT - 143533. - 143533
PH :8264105000.
- GHOMAN**
1789. PATHANKOT VEHICLEADES PVT. LTD.
(CUL1-01), KHEWAT NO. 36, KHATAUNI NO.
122, KHASA NO. 11/25 (7-18), VILLAGE -
BALRAMPUR ADDA, KHASA - GHOMAN. -
143514
PH :8054500130.
- GIDDARBHA**
1790. HIRA AUTOMOBILES LTD (AU1-01), NEAR
BHARU CHOWK, BATHINDA-MALOUT ROAD,
GIDDERBAH, DISTT. SRI MUKTSAR SAHIB
(PUNJAB) - 152101
PH :231510, 9217048250.
- GORAYA**
1791. LOVELY AUTOS (BJR1-01), NEAR MILAN
PALACE, G.T. ROAD, GORAYA. - 144409
PH :9417804049.
- GURDASPUR**
1792. PATHANKOT VEHICLEADES PVT. LTD.
(A701-03), V.P.O. BABRI NH-15, DIST.
GURDASPUR - 143521
PH :9417900870, 9878050710
1793. PATHANKOT VEHICLEADES PVT. LTD.
(A701-06), VPO - JEEWANWAL BABRI, NH-15,
GURDASPUR (PUNJAB) - 143521
PH :9417900870.
- HOSHIARPUR**
1794. HOSHIARPUR AUTOMOBILES (H402-01),
SINGHWALA, JALLANDHAR ROAD,
HOSHIARPUR. - 146001
PH :9815131766, 9878632537.
- JAGRAON**
1795. SANDHU AUTOMOBILES (6206-05), NATIONAL
HIGHWAY-64, JAGRAON - 142026
PH :8437025969.
- JAITU**
1796. MAPSKO AUTO INDIA PVT. LTD. (YX02-01),
NEAR CANAL, BATHINDA ROAD, JAITU,
DISTRICT - FARIDKOT. - 151202
PH :7347700520.
- JALALABAD**
1797. TARA AUTOMOBILES (H501-02), F.F. ROAD,
NEAR THANA SADAR, JALALABAD - 152024
PH :9876047847.
- JALANDHAR**
1798. LOVELY AUTOS (3503-01), DR. AMBEDKAR
CHOWK, JALANDHAR CITY - 144001
PH :9915020515.
1799. MARWAHA AUTOS (A UNIT OF INDERJIT
MARWAHA AUTOS PVT. LTD.) (3506-01), OPP
DPS SCHOOL, G.T. ROAD, JALANDHAR - 144010
PH :9779166004.
1800. LOVELY AUTOS (3505-01), KHASA NO. 24/204,
B D ENCLAVE, VILLAGE - JALANDHAR, DIST.
-JALANDHAR, PUNJAB. - 144401
PH :9676044001, 9915020515.
- JANDIALA GURU**
1801. BABA AUTOS (7C01-03), GT ROAD, NEAR TARAN
TARAN BYE PASS, JANDIALA GURU - 143115
PH :8872013029.
- JANDIALA MANJKI**
1802. LOVELY AUTOS (BJS1-01), SANT MARKET,
JANDIALA-BUNDALA ROAD, VILLAGE -
JANDIALA MANJKI, TEHSIL - NOORMAHAL,
DISTRICT - JALANDHAR, PUNJAB. - 144033
PH :7087439797.
- KAHNUWAN**
1803. PATHANKOT VEHICLEADES PVT. LTD.
(CGM1-01), KHASA NO.606, VPO-KAHNUWAN,
THE & DISTT. GURDASPUR. - 143528
PH :82889939301.
- KALA SANGHIAN**
1804. MARWAHA AUTOS (SPL1-01), MAIN CHOWK,
KALA SANGHIAN, DISTRICT KAPURTHALA,
PUNJAB - 144623
PH :9779166004.
- KALANAUAR**
1805. PATHANKOT VEHICLEADES (SJ11-01),
KALANAUAR-GURDASPUR ROAD, VILLAGE
KALANAUAR, TEHSIL AND DISTRICT
GURDASPUR, PUNJAB - 143512
PH :9417900879.
- KAPURTHALA**
1806. MARWAHA AUTOS (A UNIT OF INDERJIT
MARWAHA AUTOS PVT. LTD.) (4Z02-01), SIDHU
COMPLEX, CIRCLE ROAD - KAPURTHALA,
PUNJAB - 144602
PH :9779166004.
- KATHU NANGAL**
1807. JAYCEE MOTORS (CSP2-01), KHASA
NO.12/20/2, 21/1 KHA NO.212/186/229 GILL
Kheti STORE, GT ROAD,
VILLAGE-KATHUNANGAL, DISTT. AMRITSAR,
PUNJAB - 143502
PH :9780038335.
- KHANNA**
1808. HOSHIARPUR AUTOMOBILES (N302-01),
VILLAGE-KAUNI, NEAR GILL PETROL PUMP, GT
ROAD, KHANNA, DIST-LUDHIANA, PUNJAB. -
141401
PH :9888716261.
- KHARAR**
1809. CM AUTOSALES PVT. LTD. (7K01-03), NH-95,
MORINDA ROAD,KHANPUR, KHARAR. DIST.
MOHALI - 140301
PH :9915022878.
- KILANWALI**
1810. HIRA AUTOMOBILES LTD (BFV1-01), GT ROAD
(NH NO. 09), NEAR GURU NANAK COLLEGE,
KILANWALI, TEHSIL - MALOUT, DISTRICT -
MUKTSAR SAHIB. - 152107
PH :8872034131.
- KOTKAPURA**
1811. MAPSKO AUTO INDIA PVT. LTD. (BIS2-01),
MOGA ROAD, NEAR GREEN DHABA OPPOSITE
FUN PLAZA, KOTKAPURA, DISTRICT -
FARIDKOT - 151204
PH :7347000518.
- LALRU**
1812. AUTOPACE NETWORK PVT LTD (BRJ1-01),
VILLAGE – LALRU, DERA BASSI, SAS NAGAR
MOHALI, PUNJAB. - 140501
PH :9815011669.
- LUDHIANA**
1813. GULZAR MOTORS LTD. (6204-01), G.T.ROAD,
DHOLEWAL, OPP. MILITARY CARMP, LUDHIANA
- 141003
PH :9814160099.
1814. SANDHU AUTOMOBILES (6206-01), DHOLEWAL
CHOWK, LINK ROAD, LUDHIANA - 141203
PH :9815600095.
1815. LIBRA AUTO CAR CO. LTD (6207-01), G.T.
ROAD, NEAR AIRPORT, LUDHIANA - 141020
PH :0160-2512701, 03.
1816. LIBRA AUTO CAR CO. LTD (6207-02), G.T.
ROAD, NEAR AIRPORT, LUDHIANA. - 141020
PH :0160-25035130.
1817. LOVELY AUTO (6209-01), BABA NAND SINGH
NAGAR, NEAR AYALLI CHOWK, FEROZEPUR
ROAD, LUDHIANA - 141001 - 141001
PH :9875928451, 9875928450.
1818. LOVELY AUTOS (6209-02), GILL ROAD, NEAR
CANAL BRIDGE, LUDHIANA, PUNJAB - 141003
PH :9815069814.
1819. LOVELY AUTOS (6209-03), OPPOSITE BHAI
BALA SAHIB GURUDWARA, VILLAGE DAD,
PAKHOWAL ROAD, LUDHIANA, PIN-141001,
PUNJAB - 141001
PH :9815069814.
1820. LOVELY AUTOS (6209-04), EURO MART
COMPLEX, HAMBREN ROAD, NEAR RADHA
SWAMI SATSANG BHAWAN - 141008
PH :9815069814.
1821. MARWAHA AUTOS (A UNIT OF INDERJIT
MARWAHA AUTOS PRIVATE LIMITED)
(6210-01), GT ROAD, OPPOSITE GOYAL
HYUNDAI, VILLAGE DHANDHARI KHURD,
LUDHIANA, DISTRICT - LUDHIANA, PUNJAB -
141010
PH :8054399990.
- MACHIWARA**

Dealer Network (AS ON 31.10.2023)

1822. HOSHIARPUR AUTOMOBILES (9T03-01),
SAMRALA ROAD, MACHIWARA, NEAR SHEEVA
MARRIAGE PALACE - 141115
PH :9875900147.
- MAHLIPUR**
1823. HOSHIARPUR AUTOMOBILES (H402-05), NEAR
NEW BUS STAND, CHANDIGARH ROAD,
MAHLIPUR, DIST. HOSHIARPUR - 146105
PH :9914720424.
- MAJITHA**
1824. RISHABH FOURWHEELS PVT. LTD. (CDR1-01-),
PLOT NO.130, OPP. DANA MANDI, AMRITSAR
ROAD, MAJITHA - 143601
PH :9914841577.
- MALERKOTLA**
1825. MAX AUTOMOBILES (CCI2-01-),
MALERKOTLA-LUDHIANA MAIN ROAD, VILLAGE
- BHOGIWAL, MALERKOTLA, DIST.-SANGRUR,
PUNJAB. - 148023
PH :9814403131, .9056903131.
- MALOUT**
1826. HIRA AUTOMOBILES LTD (6302-05-), TINKONI
CHOWK, NEAR LIC BUILDING, MALOUT - 152107
PH :299524, 264724,9988417000.
- MANDI GOBINDGARH**
1827. HOSHIARPUR AUTOMOBILES (U903-01-), PLOT
GOVAL MOTORS, NEAR YES BANK, MANDI
SIRHIND ROAD, NH-1, MANDIGOBINDGARH,
PUNJAB. - 147301
PH :9815131766, .9914119292.
- MANSA**
1828. TARA AUTOMOBILES (7002-02-), BALATA ROAD,
NEAR ARVIND NAGAR, MANSA, PUNJAB -
151505
PH :01652-216042.
- MEHTA**
1829. RISHAB (CDS1-01-), KHASRA NO. 343, BABA
BAKALA ROAD, VILLAGE MEHTA CHOW,
TEHSIL : BABA BAKALA, DIST AMRITSAR,
PUNJAB - 143114
PH :7760315710.
- MOGA**
1830. REMIRA MOTORS PVT. LTD. (H602-01-),
INDUSTRIAL AREA, OPPOSITE ITI, GT ROAD,
MOGA. - 142001
PH :7087025402.
- MOHALI**
1831. NAVDESH AUTOS LLP (L105-01-), PLOT
NO.C-89, INDUSTRIAL AREA, PHASE-7, MOHALI
- 160059
PH :8872016453.
1832. CM AUTOSALES PVT. LTD. (706-03-), PLOT NO.
B-64, INDUSTRIAL AREA PHASE-7, MOHALI -
PUNJAB - 140110
PH :8284800597.
- MORINDA**
1833. CM AUTOSALES PVT. LTD. (BHH1-01-), KHASRA
NO. 1092, CHANDIGARH-SAMRALA ROAD,
MORINDA, DIST.-ROPAR, PUNJAB. - 140 101
PH :9915022811.
- MUKERIAN**
1834. HOSHIARPUR AUTOMOBILES (IP01-01-), VILL.
TALWANDI KALAN, GT ROAD, MUKERIAN -
144211
PH :9815131766, 8437919900.
- MUKTSAR**
1835. HIRA AUTOMOBILES LTD (6302-03-), BHAI
COMPLEX, MALOUT ROAD, MUKTSAR, PUNJAB
- 152026
PH :9217048250, 9056900042.
- MULLANPUR**
1836. SANDHU AUTOMOBILES (YY01-01-), OPPOSITE
DHAKA ROAD, FEROZEPUR ROAD,
MULLANPUR - 141101
PH :8437025969.
- MULLANPUR GARIBDASS**
1837. NAVDESH AUTOS LLP (CVZ2-01-), H NO. 341,
POST OFFICE - MULLAPUR GARIBDASS,
TEHSIL - MAJRI, DIST.-SAS NAGAR, STATE -
PUNJAB. - 140901
PH :8872004676.
- NABHA**
1838. HIRA AUTOMOBILES LTD (6302-06-), RADHA
SWAMI ROAD, NABHA - 147201
PH :9317000004, 9217048250.
- NAKODAR**
1839. LOVELY AUTOS (3503-04-), JALANDHAR ROAD,
NEAR MALARJI GATE, NAKODAR - 144040
PH :9915028603.
- NANGAL**
1840. CM AUTOSALES PVT. LTD. (7K01-02-),
PLOT#36 AJOLI MOR, FOCAL POINT
INDUSTRIAL AREA, NAPA NANGAL ,PUNJAB -
140126
PH :9592916811.
- NAWANSIHLAHR**
1841. LOVELY AUTOS (3503-02-), NAWANSIHLAHR
CHANDIGARH ROAD, VILL- LANGROHA, DISTT:-
NAWANSIHLAHR, PUNJAB - 144514
PH :9915028682.
- NIHAL SINGH WALA**
1842. REMIRA MOTORS PVT LTD (QB02-01-),
BARNALA ROAD, NEAR DEAR BABA SEWA
DASS, TEHSIL-NIHALSINGHWALA, DIST.-MOGA.
- 142 055
PH :7067025009.
- PATHANKOT**
1843. PATHANKOT VEHICLEADEAS PVT. LTD.
(A701-01-), NEAR MAMOON CHOWK,
DALHOUSIE ROAD, PATHANKOT. - 145001
PH :8264105000, 9417900883.
1844. PATHANKOT VEHICLEADEAS PVT. LTD.
(A701-04-), NEAR A. B. COLLEGE, PATHANKOT
- 145001
PH :9417900828 , 9417900842.
- PATIALA**
1845. HIRA AUTOMOBILES LTD (6302-01-), 13-B,
FACTORY AREA, PATIALA - 147001
PH :2360131, 2360562,9217048250.
1846. HIRA AUTOMOBILES LTD (6302-04-), C-20 &
C-45, FOCAL POINT, PATIALA, PUNJAB - 147001
PH :2232377, 9217048234, 9217048250.
1847. HIRA AUTOMOBILES LTD (6302-07-), D-1A,
INDUSTRIAL FOCAL POINT, PATIALA (PUNJAB).
- 147001
PH :2232295, 2232296, 9217048250.
1848. ATELIER AUTOMOBILES (6304-01-), VILLAGE
MITHUMERA, RAJPURA-PATIALA ROAD, NEAR
CASABA RESORT, PATIALA - 147001
PH :7527000106, 7527000111.
- PATRAN**
1849. HIRA AUTOMOBILES LTD (6302-02-), NARWANA
ROAD, PATRAN, PUNJAB. - 147105
PH :244445, 245788, 9217048250.
- PATTI**
1850. JAYCEE MOTORS (BQA2-01-), KHASRA NO.
64/19/21 KA 16/49 & KHASRA NO. 64/20 KA
29/94, NEAR RADHA SWAMI, TARN TARAN
ROAD, VILLAGE - PATTI, DISTT.-TARN TARAN,
PUNJAB. - 143416
PH :9780038335.
- PHAGWARA**
1851. MARWAHA AUTOS (A UNIT OF INDERJIT
MARWAHA AUTOS PVT. LTD.) (SC02-01-), PLOT
NO-62, INDUSTRIAL AREA, NEAR JCT BRIDGE
LUDHIANA - 141001
PH :9779166004.
- PHILLAUER**
1852. LOVELY AUTO (XU01-01-), OLD NAWANSIHLAHR
ROAD CIVIL LINE, PHILLAUER, DISTRICT
JALANDHAR - 144410
PH :9815069814.
- POHIR**
1853. LOVELY AUTOS (XS02-01-),
LUDHIANA-MALERKOTLA ROAD, NEAR SODHI
MARRIAGE PALACE, POHIR, DISTRICT
LUDHIANA, PUNJAB. - 141204
PH :9915020513.
- RAIKOT**
1854. GULZAR MOTORS PVT LTD (XT02-01-),
BARNALA BY PASS ROAD, RAIKOT - 141109
PH :9814160099.
- RAJPURA**
1855. HIRA AUTOWORLD LLP (HK02-01-), VILLAGE
BADHAK, RAJPUR PATIALA ROAD, RAJPURA -
140401
PH :244881-84, 9217048437,9217048250.
- RAMPURA PHUL**
1856. TARA AUTOMOBILES (XR01-01-), RAMPURA
-BARNALA ROAD, RAMPURA PHUL - 151103
PH :01651-266643.
- RAYYA**
1857. RISHABH FOURWHEELS PVT. LTD. (CAK1-01-),
NH-1, GT ROAD RAYYA, TEHSIL - BABA
BAKALA, DISTRICT - AMRITSAR. - 143112
PH :9914708577.
- ROPAR**
1858. CM AUTOSALES PVT. LTD. (7K01-01-),
CHANDIGARH ROPAR ROAD, ROPAR - 140001
PH :9915022802.
- SAMANA**
1859. HIRA AUTOMOBILES LTD (BFU01-01-), KEWAT
NO. 94/850, KHATUNI NO. 1427, KHASRA NO.
10/127(4-7), PATIALA SAMANA ROAD, SAMANA,
DIST.-PATIALA, STATE PUNJAB. - 147101
PH :9217048236.
- SANGRUR**
1860. MAX AUTOMOBILES (G402-01-), DHURI ROAD,
SANGRUR. - 148024
PH :01672-239627.
- SHAHKOT**
1861. LOVELY AUTOS (BHT1-01-), PUBLIC SCHOOL
ROAD, SHAHKOT, DISTRICT - JALANDHAR,
PUNJAB. - 144702
PH :8437936811.
- SIRHIND**
1862. HOSHIARPUR AUTOMOBILES (TF03-01-),
KEHWAT KHATONI NO. 802/1049 & 821/1070
KEHWAT KHAS NO. 43/1/1 (1-0), BESIDE SBI
BANK, BASSI ROAD, SIRHIND, TEHSIL AND
DISTRICT - FATEHGARH SAHIB - 140406
PH :9815131766, 7527082471.
- SULTANPUR LODHI**

1863. MARWAHA AUTOS (A UNIT OF INDERJIT MARWAHA AUTOS PVT. LTD.) (ZY02-01-), NEAR TALWADI BRIDGE, TALWANDI ROAD, SULTANPUR LODHI, DISTRICT - KAPURTHALA - 144626
PH :9779166004.

TALWANDI BHAI

1864. BABA AUTOS (GMF1-01.), FEROZEPUR ROAD, NEAR FUNISLAND, TALWANDI BHAI, DISTT. FEROZEPUR - 142050
PH :8872013002.

TALWANDI SABO

1865. TARA AUTOMOBILES (ON01-01.), TALWANDI RAMA MAIN ROAD, NEAR VILLAGE-JAJJAL, RAMAMANDI, TALWANDI SABO, BHATINDA - 1551302
PH :9646691047, 8437008666.

TALWARA

1866. HOSHARPUR AUTOMOBILES (H402-07.), DAM ROAD, NEAR KALI MATA MANDIR, VILLAGE-NAGAR, TALWARA, PUNJAB - 144216
PH :9815131766, 9781842244.

TANDA

1867. HOSHARPUR AUTOMOBILES (H402-06-), VILL.PULPUKHATA, MIANI ROAD, TANDA - 144203
PH :9815131766, 8437430400.

TARAGARH

1868. PATHANKOT VEHICLEADES PVT. LTD. (BVC1-01-), VILLAGE - RAHMIPUR, VPO-TARAGARH, TEHSIL & DISTT. PATHANKOT, HIMACHAL PRADESH - 143534
PH :9988633996.

TARN TARAN

1869. JAYCEE MOTORS (BLP2-01-), VILLAGE - KAKKA, KHANDIALI, NEAR SANDHU PETROL PUMP, AMRITSAR ROAD, TARAN TARAN, PUNJAB - 143401
PH :9780038039.

ZIRA

1870. BABA AUTOS (7C01-02-), FEROZEPUR ROAD, ZIRA - 142047
PH :8872013230.

ZIRAKPUR

1871. TRICITY AUTOS (9M01-01-), PATIALA HIGHWAY,VILLAGE - NABHA, ZIRAKPUR, PUNJAB - 140603
PH :9988882330.

RAJASHTHAN**JAIPUR**

1872. AURIC MOTORS (1116-C1-), COMMERCIAL PLOT NO. 4, COMMERCIAL BELT B, VT ROAD, NEW SANGANER ROAD, MANSAROVAR SCHEME, JAIPUR, RAJASTHAN 302020 - 302020
PH :9571105651.

RAJASTHAN**AANDHI**

1873. KP AUTO (SJX1-01-), KHASRA NUMBER 11 25 , VILL AANDHI , DISTT JAIPUR, RAJASTHAN- 303001 - 303001
PH :9549656559.

ABU ROAD

1874. NAVNEET MOTORS (OQ01-01-), PLOT NO. E-26, RIICO AMBAJI INDUSTRIAL AREA, PALANPUR HIGHWAY, ABU ROAD DISTT. SIROHI - 307026
PH :7665000644.

ACHROL

1875. KTL AUTOMOBILE PVT. LTD. (GKD1-01-), KHASRA NO. 37/1522,GRAM ANI, ACHROL, DELHI ROAD,TEHSIL - ACHROL, DISTRICT - JAIPUR, 303002 - 303002
PH :7412077022.

AHORE

1876. AURIC MOTORS (SHN1-01-), MADHOPURA, NEAR KARNAWATI HOSPITAL, AHORE, DISTRICT - JALORE, RAJASTHAN PIN CODE: 307029 - 307029
PH :8875088998.

AJMER

1877. AJMER AUTO AGENCIES PVT. LTD. (B201-01-), SRINAGAR ROAD,AJMER (RAJASTHAN) - 305001
PH :9314955201.

1878. RELAN MOTORS (B203-01-), NEAR BIRLA WATER TANK, PARABATPURA BYEPASS, AJMER - 305001
PH :98587 87000, 84400 41027.

1879. RELAN MOTORS (B203-02-), F-243 RIICO INDUSTRIAL AREA, PALRA, AJMER - 305001
PH :98587 87000, 87400 16329.

1880. AJMER AUTO AGENCIES PVT. LTD. (B201-05-), KHASRA NO.34/2, 344, 345, 347 GHUGHRA GHATI, JAIPUR ROAD, AJMER. - 305001
PH :9314955201.

AKLERA

1881. BHATIA AND COMPANY (SGK1-01-), NH-52, RAM NAGAR COLONY, AKLERA, JHALAWAR, PIN-326033, RAJASTHAN - 326033
PH :9793299971.

ALWAR

1882. MG MOTORS (F901-01-), MUKESH GENERAL FINANCE COMPANY, ROAD NO. 2, NEAR MEO BOARDING, ALWAR - 301001
PH :9001795520.

1883. MG MOTORS (F901-02-), KHASRA NO.803/198, BHUGORE TIRAH, NEAR ALWAR PUBLIC SCHOOL, JAIPUR, ALWAR - 301001
PH :9001795520.

ANOOPGARH

1884. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (BFE1-01-), PLOT NO. AMEDKAR CHARAHARA,RAILWAY STATION ROAD ,ANUPGARH (ANOOPGARH),DISTT SRI GANGANAGAR. - 335701
PH :9982638516.

ANTA

1885. BHATIA & COMPANY (A UNIT OF BHATIA CORPORATION PVT. LTD.) (CTG2-01-), KOTA-BARAN ROAD, ANTAKH, DIST.-BARAN. - 325502
PH :9413379001.

ASIND

1886. CHAMPION CARS (SID1-01-), DEV TOWERS, BEAWAR ROAD, ASIND, DISTRICT - BHILWARA, RAJASTHAN - 311302 - 311302
PH :9887063862.

ATRU

1887. SUWALKA MOTORS (SNU1-01-), JAISALMER ROAD, CHANDAN, DISTT JAISALMER RAJASTHAN - 325218
PH :8306333731.

BAGRU

1888. PREM MOTORS PVT. LTD. (US02-01-), JAIPUR-AJMER HIGHWAY, BAGRU, DISTRICT-JAIPUR - 303007
PH :01414711118,8058411181.

BALESAR

1889. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (CWO1-01-), KHASRA NO. 2167 JODHPUR JAISALMER ROAD, VILL:-BALESAR SATTA, TEH:- BALESAR , DIST:- JODHPUR (RAJ) - 342203
PH :7412087344.

BALOTRA

1890. LMJ SERVICES LTD. (6502-05-), JODHPUR BALOTRA ROAD,BALOTRA, RAJASTHAN - 344022
PH :8005898360.

BANSUR

1891. FORTUNE CARS (A UNIT OF JYOTI AUTOMOBILES PVT LTD) (BQP1-01-), KOTPUTLI ROAD, NEAR SUBHASH CHOWK, BANSUR, RAJASTHAN - 301402
PH :8875005116.

BANSWARA

1892. NAVNEET MOTORS (X903-01-), NEAR J.C. MILL,OPPOSITE AKASHWANI,DAHOD ROAD,BANSWARA - 327001
PH :02962-254546, 257596,7665000879.

BARAN

1893. BHATIA & COMPANY (A UNIT OF BHATIA CORPORATION PVT. LTD.) (6101-03-), BESIDE OJHA METAL, ATRU ROAD, BARAN - 325205
PH :8929854244.

BARMER

1894. LMJ SERVICES LTD. (6502-06-), G-216, RIICO INDUSTRIAL AREA, BARMER - 344001
PH :8005898360.
1895. LMJ SERVICES LTD. (SH01-01-), NH# 68, OPP. SADAR THANA - 344001
PH :8005898360.

BASSI

1896. PREM MOTORS PVT. LTD. (VF02-01-), MOHAN PURA BASSI, JAIPUR, RAJASTHAN - 303301
PH :01414711118,8058794151.

BAYTU

1897. LMJ SERVICES (SIT1-01-), NH-8 ,NEAR JAGDAMBA PETROL PUMP , BAYTU - 344034
PH :8094011126.

BEAWAR

1898. RELAN MOTORS (FL03-01-), PLOT NO 1, INDIRA GANDHI UDYOGPURI, AMER ROAD ,BEAWAR, RAJASTHAN . - 305202
PH :9587687000.

BEGUN

1899. BHATIA & CO (BTD1-01-), BHATIA & CO. (A UNIT OF BHATIA CORPORATION PVT LTD),IN FRONT OF GURUKUL, CHITTOR ROAD,BEGUN, TEHSIL - BEGUN, DISTRICT CHITTORGARH, 312023 - 312023
PH :9837325267.

BEHROR

1900. MG MOTORS (FO01-01-), B-168, RIICO INDUSTRIAL AREA, PHASE-II, OPP. APEX TUBE, BEHROR, DISTT: ALWAR - 301701
PH :9001795520.

BHADRA

1901. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (BIF1-01-), CHAK NUMBER-8,BARANI, NEAR HISAR BYEPASS BHADRA-BALSAMAND ROAD ,BHADRA. - 335501
PH :9166712222, 9413311745.

BHARATPUR

1902. TM MOTORS PVT. LTD. (J501-01-), BRIJ VIHAR COLONY, MADARPUR ROAD,BHARATPUR,RAJASTHAN - 321001
PH :9251423392.

BHAWANI MANDI

Dealer Network (AS ON 31.10.2023)

1903. SUWALKA MOTORS PVT LTD (SDB1-01), K.NO. 327 MANDAVI OPPOSITE SDM OFFICE JHALAWAR ROAD, BHAWANIMANDI,JHALAWAR- 326502. - 326502 PH :9414242256.	BIKANER	1914. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (7101-01), OPP. URMUL DAIRY PLANT,GANGANAGAR ROAD,BIKANER - 334004 PH :1512253984,9414138511.	CHOMU	1925. KTL AUTOMOBILES (HW02-01), KHARSA NO.695, JAIPUR SIKAR BYPASS ROAD, CHOMU, RAJASTHAN. - 303702 PH :7412077034.	1935. SHRI MANGLAM AUTO PVT. LTD. (FT03-01), KHASRA NO. 73, NEAR CHOTI DEVI SCHOOL, LADNU ROAD, DIDWANA , DISTRICT – NAGAUR. - 341303 PH :7230055924.
1904. LOHIA AUTOMOBILES (E301-01), AJMER ROAD,NEAR OCTROI POST,BHILWARA - 311001 PH :7568378555,946279233.		1915. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (7101-04), JAIPUR BYE PASS,BIKANER ., 334004 PH :1512230384,8875010507.	1926. SATNAM MOTORS (HW03-01), NEAR CM CHOPRA HOSPITAL, JAIPUR ROAD, CHOMU, DISTRICT – JAIPUR. RAJASTHAN - 303702 PH :8302090000.	1936. PREM MOTORS PVT. LTD. (BRY1-01), KHASRA NO.1107 & 1108, OPPOSITE POWER HOUSE SERVICE LANE, NH-8, DUDU. - 303008 PH :8058411181.	
1905. CHAMPION AUTOMOTIVE (UNIT OF PREM CARS PVT. LTD) (E302-01), CHITTORGARH ROAD, BHILWARA, RAJASTHAN . - 311001 PH :01482-267096,9358130064, 9358130066.		1916. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (7101-05), OPP. AVYYAPPA TEMPLE, K. K. COLONY, BIKANER - 334003 PH :7014063193,9413311949.	1927. TR SAWHNEY (MD04-01), KHASRA NO. 913/54, JAIPUR ROAD, VILLAGE RAMSARA, CHURU, PIN-331001, RAJASTHAN - 331001 PH :9782078531.	1937. NAVNEET MOTORS (4902-02), G-71, INDUSTRIAL AREA, DUNGARPUR - 314001 PH :9414104833,9414104833.	
1906. LOHIA AUTOMOBILES (E301-03)-, PLOT NO. H-11, EVERGREEN TEXTILE PARK, RIICO INDUSTRIAL AREA, PUR ROAD, BHILWARA. - 311001 PH :9667187847.		1917. DUDI AUTOMOBILES (A UNIT OF DMAS AUTOMOBILES) (7102-01), KHASRA NO. 376/33, JAIPUR ROAD, HH-11, BIKANER, RAJASTHAN. - 334001 PH :8929834417.	CHURU	1928. DANTA RAMGARH	1938. LMJ SERVICES LTD. (BBR1-01), OPPOSITE PRAKASH DINING HOTEL, FALNA - 306116 PH :8094011126.
1907. TECHNOY MOTORS INDIA PVT. LTD. (CBS1-01), NEAR RAILWAY STATION,SALUMBAR CHOURAHA, BHINDER - 313603 PH :8306111337.	BILARA	1918. LMJ SERVICES LTD. (BZB1-01), BANGANGA MOD, JODHPUR ROAD, BILARA , RAJASTHAN - 342602 PH :8104698935.	1929. JAMU AUTOMOBILES PVT LTD (CTQ1-01), KHASRA NO. 1016/56, VILLAGE - RAMGARH, TEHSIL - DATAH RAMGARH, DIST.-SIKAR. - 332703 PH :9116816905.	1939. TECHNOY MOTORS INDIA PVT. LTD. (4903-03), PLOT NO.15, FATENAGAR SANWAR ROAD, UDAIPUR-CHITTORGARH HIGHWAY NO.76, FATEHNAGAR-313205 DISTT. UDAIPUR - 313205 PH :9772564139,9772564139.	
1908. SHRI KRISHNA AUTOSALES PVT LTD (CQN1-01), KHASRA NO. 2281, KARADA CROSSING, BHINMAL, DISTRICT - JALORE, RAJASTHAN. PH :9610242790.	BORUNDA	1919. AURIC MOTORS (SNT1-01), NEAR KESARGARH PALACE, HANUMANGARH ROAD, TIBBI, DIST. HANUMANGARH, PIN-335526, RAJASTHAN - 342604 PH :943311745.	1940. PREM MOTORS PVT. LTD. (BUT1-01), KHASRA NO. 5854, 5858, 5860, 5861, VILLAGE UDAI KALAN, THE GANGAPUR CITY - 322201 PH :8058794122.		
1909. FORTUNE CARS (A UNIT OF JYOTI AUTOMOBILES PVT LTD) (9H01-01), OPP. INDAG RUBBER MAIN ROAD ,BHILWADI - 301019 PH :9214794326,8875005116.	BUNDI	1920. BHATIA & COMPANY (A UNIT OF BHATIA CORPORATION PVT. LTD.) (6101-02), SUMAN PLAZA, NEAR TEACHER'S COLONY, CHITTOR ROAD, OPPOSAITE ICICI ATM, BUNDI - 323001 PH :8929853245.	1941. LMJ SERVICES (SJ81-01), PLOT NUMBER -189 , NEAR NAGAUR RAILWAY STATION ROAD, DEGAN - 314503 PH :7230059595.	1941. LMJ SERVICES (SJ81-01), KHASRA NO. 1360/5, RATHORO KI DHANI, JODHPUR ROAD, GUDAMALANI, DISTRICT – BARMER, RAJASTHAN - 344031. - 344031 PH :8094011126.	
1910. FORTUNE CARS (A UNIT OF JYOTI AUTOMOBILES PVT LTD) (9H01-02), F-458-C,RIICO,INDUSTRIAL AREA,BHILWADI - 301019 PH :9214794326,8875005116.	CHAKSU	1921. K P AUTOMOTIVES PVT LTD (1104-03), TONK ROAD, CHAKSU - 303901 PH :0141-4071111, 4071101,8696934973.	1942. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (CGC1-01)-, BHORKI ROAD, GUDHAGORJI, DISTRICT – JHUNJHUNUN, RAJASTHAN. - 333022 PH :7412059848.	1942. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (CGC1-01)-, BHORKI ROAD, GUDHAGORJI, DISTRICT – JHUNJHUNUN, RAJASTHAN. - 333022 PH :7412059848.	
1911. FORTUNE CARS (A UNIT OF JYOTI AUTOMOBILES PVT LTD) (9H01-04)-, KHASRA NO. 656/431, ALWAR ROAD, BHILWADI. - 301019 PH :9214794326,8875005116.	CHANDAN	1922. LMJ SERVICES LTD. (SHR1-01), JAISALMER ROAD ,CHANDAN , DISTT JAISALMER ,RAJASTHAN - 345031 PH :8094011126.	1943. BHATIA & CO. (SMC1-01)-, PRATAPGARH ROAD, DHARIYAWAD , DIST. - PRATAPGARH, RAJASTHAN - 313605 - 313605 PH :9829736081.	1943. BHATIA & CO. (SMC1-01)-, PRATAPGARH ROAD, DHARIYAWAD , DIST. - PRATAPGARH, RAJASTHAN - 313605 - 313605 PH :9829736081.	
1912. AJMER AUTO AGENCIES PVT LTD (GLF1-01), KHASRA NO 39 , AJMER -BHILWARA HIGHWAY CITY -BIJAYNAGAR DISTRICT – AJMER ,RAJASTHAN - 305624 PH :8890902472.	CHIRAWA	1923. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (SY02-01)-, NEAR PILANI CIRCLE, LOHARU ROAD, STATE HIGHWAY-8, CHIRAWA - 333026 PH :01596-217163,7230081668.	1944. AURIC MOTORS (7101-06), PLOT NUMBER 13, INDUSTRIAL AREA, HANUMANGARH, RAJASTHAN. - 335512 PH :9413311745.	1944. AURIC MOTORS (7101-06), PLOT NUMBER 13, INDUSTRIAL AREA, HANUMANGARH, RAJASTHAN. - 335512 PH :9413311745.	
1913. LOHIA AUTOMOBILES (E301-02), R/O GOLDEN CORRIDOR, OPP. ASHOK LEYLAND WIS, CHITTOR-BHILWAJA HIGHWAY, BIJOLIA, DIST. -BHILWARA - 311602 PH :7568378555,7230094157.	CHITTORGARH	1924. BHATIA & COMPANY (A UNIT OF BHATIA CORPORATION PVT. LTD.) (K901-01), PLOT NO. 1001/1-1002/1, NIMBAHERA ROAD,CHITTORGARH - 312001 PH :01472 240999,9549277861.	1945. TM MOTORS PVT. LTD. (5K01-01), TM MOTORS PVT. LTD. GT ROAD DHOLPUR, RAJASTHAN. - 328001 PH :8094777862.	1945. TM MOTORS PVT. LTD. (5K01-01), TM MOTORS PVT. LTD. GT ROAD DHOLPUR, RAJASTHAN. - 328001 PH :8094777862.	
			DHOLPUR	HINDAUN	
			1946. HINDAUN		

1945. FORTUNE CARS (A UNIT OF JYOTI AUTOMOBILES PVT LTD) (S002-01-), KHASRA NO. 73, VILLAGE - PATTI NARAINPUR, NEAR HANUMAN MANDIR, HINDAUN-MAHWA ROAD, HINDAUN - 322230
PH : 7017024146, 7017024146.
- JAIPUR**
1946. VIPUL MOTORS PVT. LTD. (1102-01-), F-124A,MALVIYA INDUSTRIAL AREA,MALVIYA NAGAR,JAIPUR - 302017
PH : 9269117654,8949686508.
1947. K P AUTOMOTIVES PVT LTD (1104-01-), E-198, SANGANER INDUSTRIAL AREA,MANSAROVAR,JAIPUR - 302020
PH : 0141-4711111,4071101,6377203709, 6377203731.
1948. PREM MOTORS PVT. LTD. (1112-02-), 12 13,SUDARSHANPUA INDUSTRIAL AREA, JAIPUR - 302006
PH : 0141-4711111,8058703388 , 8058794122.
1949. SANGA AUTOMOBILES PVT. LTD. (1110-01-), SECTOR 35, PRATAP NAGAR,SANGANER, JAIPUR - 302033
PH : 9772210922.
1950. VIPUL MOTORS PVT. LTD. (1102-05-), 29, INDUSTRIAL AREA, JHOTWARA, JAIPUR - 302012
PH : 0141-3524203,9672211333.
1951. PREM MOTORS PVT. LTD. (1112-01-), PLOT NO. E101/A, VKI , JAIPUR - 302036
PH : 01414411123,8929409921.
1952. SATNAM MOTOCORP PVT. LTD. (1113-01-), PLOT NO. E-524, SITAPURA INDUSTRIAL AREA, JAIPUR - 302 022, RAJASTHAN. - 302022
PH : 1412771976,8302390000.
1953. KTL AUTOMOBILE PVT. LTD. (1115-01-), PLOT NO. 13B , JHOTWARA INDUSTRIAL AREA, JAIPUR - 302012
PH : 7412077022.
1954. PREM MOTORS PVT. LTD. (1112-03-), PLOT NO. B-12, MALVIYA NAGAR, JAIPUR - 302017
PH : 9358711550,8929409921.
1955. KTL AUTOMOBILES (1115-02-), KHASRA NO 12-1216/295, BHANKROTA, TEH SANGANER ,DISTRICT JAIPUR. - 302026
PH : 7412077007.
1956. KTL AUTOMOBILES (1115-03-), ORBIT MALL CIVIL LINES METRO STATION AJMER ROAD JAIPUR. - 302006
PH : 7412077007.
1957. K.P. AUTOMOTIVE (1104-G1-), B-1, GOVIND MARG, ADARSH NAGAR, JAIPUR - 302004 - 302004
PH : 9549656559.
1958. KTL AUTOMOBILES (1115-04-), CHOKDI HAWALI SHAHAR, SHIRKI SHAHAR, NEAR IDGHA, BILOCHOYAN MOHALLA, TRANSPORT NAGAR, DELHI ROAD, JAIPUR - 302002 - 302002
PH : 9772210922.
1959. KP AUTO (1104-G2-), PLOT NO. 4, RAJIV COLONY, RPA ROAD, OPP. RADHA SWAMI SATSANG BHAIWAN, SHASTRI NAGAR, JAIPUR 302016 . - 302016
PH : 9549656559.
1960. SANGA AUTONAUT (1117-01-), SECTOR 35, PRATAP NAGAR, SANGANER, JAIPUR, PIN-302023, RAJASTHAN - 302023
PH : 9293365847.
- JAISALMER**
1961. LMU SERVICES LTD. (5L01-01-), PLOT NO.36, 37, MAHESH REFUGEE COLONY,HDC SOCIETY, DABA ROAD, JAISALMER (RAJASTHAN) - 345001
PH : 800598360.
- JAITARAN**
1962. LMU SERVICES LTD. (BNY1-01-), KHASRA NO. 784, JAIPUR-JODHPUR BYE PASS ROAD, JAITARAN, DIST.-PALI. - 306302
PH : 9269971266.
- JALORE**
1963. SHRI KRISHNA AUTOSALES PVT LTD (VD01-01-), KHASRA NO.6809/2616, 2623, INDUSTRIAL AREA, JALORE-BHINNAL ROAD, JALORE - 343001
PH : 2973211613,9829203644.
- JAMWA RAMGARH**
1964. K P AUTOMOTIVES PVT LTD (BZL1-01-), KHASRA NUMBER-228/169,OPP UDAY AUTOMOBILES,JAIPUR ALWAR ROAD -JAMWA RAMGARH. - 303109
PH : 6377203709, 6377203731.
- JHADOL**
1965. TECHNOY MOTORS (SKO1-01-), KHASRA NO. 186/1, NH 8 NEAR ASHOK LEYLAND WORKSHOP, SARDARPURA, SOJAT, PIN-306104, RAJASTHAN - 306104
PH : 8890673099.
- JHALAWAR**
1966. BHATIA & COMPANY (A UNIT OF BHATIA CORPORATION PVT. LTD.) (6102-02-), OPP. BALAJI KI CHHATRI . KHEL CIRCULAR STADIUM, BUS STAND ROAD, JHALAWAR - 326001
PH : 9413350336.
- JHUNJHUNU**
1967. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (E01-02-), E1-2, AUTOMOBILES SERVICE SECTOR, RIICO INDUSTRIAL AREA, PHASE-2, SIKAR JAIPUR ROAD, JHUNJHUNU. - 333001
PH : 98159-250045,7412078489.
- JOBNER**
1968. PREM MOTORS PVT. LTD. (BRD1-01-), KHASRA NO. 758 & 754, BABER WALON KI DHANI, JOBNER, TEHSIL - PHULERA, DISTRICT – JAIPUR, RAJASTHAN - 303328
PH : 8058411181.
- JODHPUR**
1969. LMU SERVICES LTD. (6502-01-), PRATAP NAGAR,JODHPUR - 340002
PH : 9950496202.
1970. LMU SERVICES LTD. (6502-04-), OPP TO RFC OFFICE,NEW POWER HOUSE ROAD,JODHPUR - 342003
PH : 8094011127.
1971. SHRI KRISHNA AUTOSALES PVT LTD (6503-01-), 32-A,HEAVY INDUSTRIAL AREA,NR FCI GODOWNS, JODHPUR - 342005
PH : 2912748402,9001894669.
1972. LMU SERVICES LTD. (6502-09-), B-8,9,10, MARUDHAR INDUSTRIAL AREA, PHASE 1, BASNI, JODHPUR - 342008
PH : 8094011147.
1973. LMU SERVICES LTD. (6502-0C-), 21/PAL MAIN BALOTRA ROAD, NEAR D.P.S. CIRCLE, JODHPUR - 342002
PH : 7230057721.
1974. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (6504-01-), C-62 BASNI INDUSTRIAL AREA, PHASE-1, JODHPUR - 342005
PH : 7412059839.
1975. LMU SERVICES LTD. (6502-09-), PARSHWANATH COLONY, KAYLANA ROAD, JODHPUR. - 342 001
PH : 8696916455.
1976. LMU SERVICES LTD. (6502-10-), KHASRA NO. 35/5, BANAR ROAD, OPPOSITE VIDHYA PUBLIC SCHOOL, JODHPUR, RAJASTHAN - 342 003
PH : 7222002424.
- KAPRAIN**
1977. BHATIA & COMPANY (A UNIT OF BHATIA CORPORATION PVT. LTD.) (BGG1-01-), MEGA HIGHWAY ROAD, NEAR PETROL PUMP, KAPRAIN DISTT. BUNDI - 323301
PH : 9413379901.
- KEKRI**
1978. AJMER AUTO AGENCIES PVT. LTD. (B201-03-), KOTA SAWAR ROAD,KEKRI - 305404
PH : 9314955201.
- KAHUJUWALA**
1979. AURIC MOTORS (SJ1C-01-), DANTOR ROAD, KAHUJUWALA, DIST. - BIKANER, RAJASTHAN. - 3340323
PH : 9882299866.
- KHANDAR**
1980. PREM MOTORS (SQM1-01-), SAWAI MADHOPUR-KHANDAR RD., KHANDAR, RAJASTHAN - 322025. - 322025
PH : 8058899960.
- KHANPUR**
1981. SUWALKHA MOTORS (SMA1-01-), BYPASS CHORAYA, MEGA HIGHWAY BARAN-JHALAWAR, KHANPUR, TEHSIL – KHANPUR, DISTRICT – JHALAWAR, RAJASTHAN PIN CODE: 326038 - 326038
PH : 8306333731.
- KHERLI**
1982. MG MOTORS (BZE1-01-), KHERLI KATHUMAR ROAD, VILLAGE KHERLI, DISTT. ALWAR, RAJASTHAN - 321606
PH : 9001795520.
- KHERWARA**
1983. TECHNOV MOTORS (SEE1-01-), OPP. ATITHI PALACE, VILLAGE BADLA, NH 8,KHERWARA, TEHSIL – KHERWARA, DISTRICT – UDAIPUR, RAJASTHAN PIN CODE: 313803 - 313803
PH : 9530396845.
- KISHANGARH**
1984. AJMER AUTO AGENCIES PVT LTD (TU01-01-), R K LINK ROAD , - 305802
PH : 9314391011.
- KISHANGARH BAS**
1985. FORTUNE CARS (A UNIT OF JYOTI AUTOMOBILES PVT LTD) (H01-03-), KISHANGARH BIWADI HIGHWAY, NEAR KISHANGARH, DISTRICT ALWAR - 301405
PH : 8875007753,8875007753.
- KOTA**
1986. BHATIA & COMPANY (A UNIT OF BHATIA CORPORATION PVT. LTD.) (6101-01-), 13-16 B,INDUSTRIAL ESTATE, KOTA - 324007
PH : 8929400447.
1987. BHATIA & COMPANY (A UNIT OF BHATIA CORPORATION PVT. LTD.) (6102-01-), AUTO MOBILE ZONE,G-11/12 INDUSTRIAL AREA, KOTA - 324005
PH : 0744-2439008,2439006.9587894887.
1988. BHATIA & COMPANY (A UNIT OF BHATIA CORPORATION PVT. LTD.) (6101-04-), 3(K),CHAMBAL INDUSTRIAL AREA,KOTA,RAJASTHAN - 324007
PH : 8929400447.
1989. BHATIA & COMPANY (A UNIT OF BHATIA CORPORATION PVT. LTD.) (6101-05-), E-46, CHAMBAL INDUSTRIAL AREA, KOTA - 324007
PH : 8929400447.
1990. BHATIA & COMPANY (A UNIT OF BHATIA CORPORATION PVT. LTD.) (6101-06-), PLOT NO. E-222, ROAD NUMBER 5, INDRAPRASTHA INDUSTRIAL AREA, KOTA, RAJASTHAN. - 324005
PH : 0744-2439008,2439006.9587894887.

Dealer Network (AS ON 31.10.2023)

1991. SUWALKA MOTORS PVT. LTD. (6104-01), RIDHI SIDDHI NAGAR, KUNHARI, BUNDI ROAD, KOTA, RAJASTHAN - 324008 PH :0744-2661226,7742121212.

KOTPUTLI

1992. PREM MOTORS PVT. LTD. (MH09-01), NH-8, BUCHARA COLONY, OPP. SHAKTI VIHAR, KOTPUTLI, 303108 PH :01414711118,8058411181.
1993. PREM MOTORS PVT. LTD. (MH09-02), KHASRA NO- 636, KOTPUTLI, DIST. JAIPUR, RAJASTHAN - 303108 PH :01414711118,8058411181.

KUCHAMAN

1994. SHRI MANGLAM AUTO PVT. LTD. (VA02-01), SUDARSHAN NAGAR, BURSU ROAD, KHASRA NO.148, KUCHAMAN. - 341508 PH :7230055928.

LADNU

1995. SHRI MANGLAM AUTO PVT. LTD. (CUP1-01), KHASRA NO. 1011, SUJANGARH ROAD, LADNU - 341306 PH :7412044506.

LALSOT

1996. VIPUL MOTORS PVT. LTD. (BZF1-01), PLOT NO.22,23, KHASRA NO.1502-03, NARAYAN VIHAR, SAWAI MADHOPUR ROAD, LALSOT, RAJASTHAN - 303502 PH :9672211333.

LOSAL

1997. JAMU MOTORS (SMD1-01), LOSAL-SALASAR-DIDWANA ROAD, OPPOSITE SHIV MANDIR, WARD NO. 1, LOSAL, RAJASTHAN - 332025 - 332025 PH :9057400761.

LUNI

1998. LMJ SERVICES (SFD1-01), NEAR SBI BANK, SALASAW ROAD,LUNI, TEHSIL – LUNI,DISTRICT – JODHPUR,RAJASTHAN PIN CODE: 342802 - 342802 PH :8094011126.

MAHWAA

1999. VIPUL MOTORS PVT. LTD. (BKZ1-01), KHASRA NO.37/384, BHARATPUR ROAD BYE-PASS, N.H. -11, MAHWA, DISTT. DAUSA (RAJASTHAN) - 321608 PH :9672211333.

MAKRANA

2000. SHRI MANGLAM AUTO PVT. LTD. (CFX1-01), KHASRA NO. 609/4, NEAR BAJAJ SHOWROOM, MANGLANA ROAD, MAKRANA, DISTRICT – NAUR, - 341505 PH :7230055934.

MALPURA

2001. K P AUTOMOTIVES PVT LTD (BLB1-01), PLOT NO.07, SHRI KALYAN NAGAR COLONY, JAIPUR-KEKARI ROAD, MALPURA - 304502 PH :8696925262.

MANDALGARH

2002. CHAMPION (SHA1-01), OPP. MODEL SCHOOL, BIJOLA ROAD, MANDALGARH, DISTRICT – BHILWARA, PIN-311604, RAJASTHAN - 311604 PH :9837325267.

MERTA

2003. SHRI MANGLAM MOTORS (NG03-01), KHASRA NUMBER 1679, NH-89,MERTA,RAJASTHAN. - 341510 PH :9116007201.

NAGAUR

2004. SHRI MANGLAM AUTO PVT. LTD. (HL03-01), KHASRA NO. 1479/982 & 1478/83, BIKANER ROAD, NAGAUR. - 341 001 PH :9116008624.

NAINWA

2005. BHATIA & COMPANY (A UNIT OF BHATIA CORPORATION PVT. LTD.) (CTJ1-01), UNIARA ROAD, OPP. PETROL PUMP, NAINWA, DIST. KOTA - 323801 PH :9413379001.

NARAYANPUR

2006. FORTUNE CARS (SDV1-01), KHASRA NO. 2848, JAIPUR ROAD NEAR NARAYANPUR BYPASS VILLAGE, NARAYANPUR TEHSIL – NARAYANPUR, DISTRICT – ALWAR,RAJASTHAN PIN CODE: 301024. - 301024 PH :8875004375.

NASIRABAD

2007. AJMER AUTO AGENCIES PVT. LTD. (B201-04), CHAVANI BOARD NO:1613, HAWA CHAKKI, NASIRABAD ROAD, NASIRABAD, DISTT. AJMER - 305601 PH :9314955201.

NATHDWARA

2008. LOHIA AUTOMOBILES (X201-02-),NH-8, LAL BAG, NATHWARA, DISTRICT: RAJSAMAND - 313301 PH :8306009399.

NAWLIGARH

2009. AURIC MOTORS (SIE1-01), KHATA NO. 76, PUNIA KI DHANI, SIKAR ROAD,NAWLIGARH, DISTRICT – JHUNJHUNWU, RAJASTHAN PIN CODE: 333042 - 333042 PH :9928720360.

NEEM KA THANA

2010. JAMU AUTOMOBILES PVT LTD (K701-03), NEAR TOLL PLAZA, KOTPUTLI ROAD, NEEM KA THANA, SIKAR - 332713 PH :9116816905,9116816905.

NEEMRANA

2011. FORTUNE CARS (A UNIT OF JYOTI AUTOMOBILES PVT LTD) (OP01-01), F-42 & 42(B), PHASE-1, NEEMRANA, TEHSIL: BEHROR, DISTT. ALWAR - 301705 PH :9610715222,9636139386.

NIMBAHERA

2012. BHATIA & COMPANY (A UNIT OF BHATIA CORPORATION PVT. LTD.) (CTH1-01), PLOT NO. 7-8, 33-34, 35-36, NIMBAHERA, DIST. -CHITTORGARH. - 312601 PH :9772378681,9772378681.

NIWAI

2013. K P AUTOMOTIVES PVT LTD (BLA1-01), VANASTHALI CIRCLE, NEAR PRATEEK GAS AGENCY, TONK ROAD, NIWAI, DISTRICT – TONK - 304021 PH :8696925262.

NOHAR

2014. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (VE02-01), OPP. RAILWAY STATION, NOHAR, DISTRICT-HANUMANGARH - 335523 PH :0155-5221485,7412059821, 8875010541.

NOKHA

2015. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (IS01-01), F-46, RIICO EXTENSION, NOKHA INDUSTRIAL AREA, NOKHA DISTT- BIKANER (RAJASTHAN) - 334803 PH :7412059805.

PADAMPUR

2016. DUDI MOTORS (SGC1-01), NEAR BASANT PLACE, BHAGAT SINGH CHOWK, KARANPUR ROAD, PADAMPUR SRI GANGANAGAR 335041 - 335041 PH :8619215475.

PALI

2017. LMJ SERVICES LTD. (6502-03-), KHASRA NO. 7711, JODHPUR PALI ROAD, PALI - 306401 PH :9269971266.

PAOTA

2018. K P AUTOMOTIVES PVT LTD (BRH1-01), PATTAA SANKHYA 31, MISAL SANKHYA 89, NEAR BAMORIA PETROL PUMP, NH-8, PAOTA, RAJASTHAN. - 303106 PH :6377203709, 6377203731.

PARBATSBAR

2019. SRI MANGLAM (SKT1-01), NEAR IFL HOUSING FINANCE CO., KISHANGARGH ROAD, PARBATSBAR, DISTRICT - NAGAUR, RAJASTHAN - 341512. - 341512 PH :8740909096.

PARTAPUR

2020. NAVNEET MOTORS (BKY1-01-), AAASHAPURA CHAURHA, BHAGORA MOR, NEAR AAASHAPURA MANDIR, PARTAPUR ,RAJASTHAN - 327024 PH :9001550644.

PHALODI

2021. SHRI KRISHNA AUTOSALES PVT LTD (BQ1-01-), OPP. RCP GUEST HOUSE, NAGAUR KHICHAN ROAD, PHALODI, RAJASTHAN - 342301 PH :9116011958.

PHULEREA

2022. KTL AUTOMOBILE PVT. LTD. (CUS1-01-), KHASRA NO. 21 TO 24 AND PLOT NO. 189 IN RAM VIHAR COLONY, PANCHBHATI, PHULEREA, DISTRICT - JAIPUR, RAJASTHAN - 303338 PH :7412077022.

PINDWARA

2023. NAVNEET MOTORS (CQP1-01-), OPPOSITE WOLKEM FACTORY, SIROHI ROAD, PINDWARA, DIST. - SIROHI. - 307022 PH :7230036616,7230019849.

PIPAR

2024. LMJ SERVICES LTD. (BT1-01-), KHASRA NO. 1095, PIPAR CITY, DIST.-JODHPUR. - 342601 PH :9462616268.

PISANGAN

2025. AJMER AUTO AGENCIES PVT. LTD. (CTL1-01-), PLOT NO.11, SHIV VIHAR COLONY, MANGLIYAWAS ROAD, PISANGAN, DISTRICT – AJMER, RAJASTHAN. - 305204 PH :9314955201.

POKHRAH

2026. LMJ SERVICES (BOA1-01-), SUNDER NAGAR, TEHSIL, POKHRAN, DISTRICT – JAISALMER, RAJASTHAN. - 345021 PH :9610115660.

PRATAPGARH (RAJASTHAN)

2027. BHATIA & COMPANY (A UNIT OF BHATIA CORPORATION PVT. LTD.), (PN01-01-), CHITTORGARH-PRATAPGARH ROAD, GRAM-BAMBOTARA, PRATAPGARH (RAJASTHAN) - 312605 PH :9571274999.

RAIPIUR

2028. LMJ SERVICES LTD. (CRZ1-01-), NATIONAL HIGHWAY, PALI ROAD, VILLAGE – RAIPIUR, DISTRICT – PALI. - 306304 PH :9269971266.

RAISINGHNAVAR

2029. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (BHK1-01-), PLOT NO. H-2, INDUSTRIAL AREA, RAISINGHNAGAR, DISTRICT – SRIGANGANAGAR. - 335051 PH :9982638516.

RAJGARH

2030. MG MOTORS (IY01-01), ALWAR SIKANDRA MEGA HIGHWAY, VILLAGE DIGAWARA, TEHSIL RAJGARH DISTT. ALWAR - 301408 PH :9001795520.

2031. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (CGD1-01), NH-65, OPP. BHAGAT SINGH CHOWK, RAJGARH DISTT. CHURU - 331023 PH :9602261977.

RAJSAMAND

2032. LOHIA AUTOMOBILES (X201-01), BHILWARA ROAD,KHANKROLI,RAJSAMAND DISTT, RAJSAMAND - 313301 PH :8306009399.

RAMGANJMANDI

2033. BHATIA & COMPANY (A UNIT OF BHATIA CORPORATION PVT. LTD.) (BAZ1-01), KHAIRABAD ROAD, KHASARA NO. 753, A.S.I COLONY, RAMGANJ MANDI - 326519 PH :9414085790.

RANIWARA

2034. SHRI KRISHNA AUTOSALES PVT LTD (SGX1-01), NEAR RAILWAY GATE, BHINMAL ROAD ,RANIWARA, TEHSIL – RANIWARA, DISTRICT – JALORE, RAJASTHAN,PIN CODE: 343040 - 343040 PH :9928377669.

RATANGARH

2035. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (BHU1-01), PLOT NO. AREA F-186 INDUSTRIAL AREA, RATANGARH. - 331 022 PH :7412087301.

RAWATBHATA

2036. BHATIA & COMPANY (A UNIT OF BHATIA CORPORATION PVT. LTD.) (JQ01-01), NEAR INDIAN OIL PETROL PUMP, KOTA ROAD, RAWATBHATA , DIST. CHITTORGARH, RAJASTHAN . - 323307 PH :9587894887.

RAWATSAR

2037. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (SDA1-01), CHAK 21-22,DWD,PLOT NUMBER -10 & 11, RAWATSAR (RAJASTHAN). - 335524 PH :9166712222, 9413311745.

REENGUS

2038. JAMMU MOTORS (SGL1-01), REENGUS HIGHWAY , REENGUS DISTT. SIKAR -332404 PH :332404.

RENWAL MANJHI

2039. PREM MOTORS PVT. LTD. (GKZ1-01), KHASRA NUMBER 2286/10,OPP ROHINI NAGAR 1 ,JAIPUR BHILWARA HIGHWAY ,RENWAR,TEHSIL PHAGI JAIPUR, RAJASTHAN (303904) - 303904 PH :0141471118,9928494441.

REVDAR

2040. TECHNOY MOTORS INDIA PVT. LTD. (CRY1-01), OPP. TIRUPATI PETROL PUMP, KAROTI ROAD, REVNDAR, DISTT. SIROHI, RAJASTHAN. - 307514 PH :9116653766,9116653766.

SAGWARA

2041. TECHNOY MOTORS INDIA PVT. LTD. (CK01-01), BANSWARA ROAD, CHUNGINKA, NR. CENTRAL JAIL, SAGWARA, DUNGARPUR DISTT., RAJASTHAN - 314025 PH :02966254767,723008824.

SALUMBAR

2042. NAVNEET MOTORS (BZH1-01), GANESH GHATI, BANSWARA ROAD, SALUMBAR, DISTRICT – UDAIPUR - 313027 PH :7665887444.

SAMBHAR

2043. KTL AUTOMOBILE PVT. LTD. (CVD1-01), PLOT NUMBER -C1 NEAR SHAKUMARI PG COLLEGE , PHULERA ROAD , SAMBHAR 303604 -303604 PH :7412077022.

SANCHORE

2044. SHRI KRISHNA AUTOSALES PVT LTD (GY1-01), PLOT NO. 217, KHASRA NO. 844, 865, 867, MANMOHAN SINGH PARK, NH-15, BARMER ROAD, SANCHORE, DIST.-JALORE. - 343041 PH :9636224546.

SANGARIA

2045. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (GKK1-01), HANUMANGARH ROAD NEAR KARMA PETROL PUMP - 335035 PH :7412059827.

SANGOD

2046. BHATIA & COMPANY (A UNIT OF BHATIA CORPORATION PVT. LTD.) (GLG1-01), KHASRA NO 1637 , SANGOD BAPAPAR MAIN ROAD ,SANGOD - 325601 PH :9413353999.

SARDARSHAHAR

2047. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (BID1-01), KHASRA NO.134, MOTOR MARKET, RATANGARH SARDARSHAHAR ROAD, SARDARSHAHAR DISTT. CHURU, RAJASTHAN - 331403 PH :9799833995.

SARWAR

2048. RELAN MOTORS (SJR1-01), CHAMAN CHOURAHA, AJMER ROAD, SARWAR, DISTRICT – AJMER, RAJASTHAN 305403 - 305403 PH :9587687000.

SAWAI MADHOPUR

2049. PREM MOTORS PVT. LTD. (FY03-01), PLOT NO.14, RICO INDUSTRIAL AREA, KHERDA, SAWAI MADHOPUR - 322001 PH :0141471118,9358725409.

SAYALA

2050. AURIC MOTORS (SHM1-01), NEAR PETROL PUMP, HANUMAN MANDIR SOUTH STYLE, MAIN ROAD SAYALA, SAYALA TEHSIL – SAYALA, DISTRICT – JALORE, RAJASTHAN PIN CODE: 343022 - 343022 PH :9460739993.

SHAHPURA

2051. K P AUTOMOTIVES PVT LTD (1104-05), VILLAGE RAJPURA,GRAM PANCHAYAT BIDARA,NH-8, SHAHPURA - 303103 PH :0141-4071111, 4071101,8696934964, 9358220012.

2052. LOHIA AUTOMOBILES (CCP1-01), OPPOSITE LIC OFFICE, BHILWARA ROAD, SHAHPURA DISTT. BHILWARA - 311404 PH :7568378555,9462979238.

SHEO

2053. LMJ SERVICES LTD. (SDO1-01), NEAR RIDDI SIDDDHI HOTEL , OPPOSITE HB PETROL PUMP ,TEH SHEO, DISTT – BARMER - 335521 PH :0890411144.

SHEOGANJ

2054. NAVNEET MOTORS (SMI1-01), F 132,OPP. 33/1 KV STATION, RICO INDUSTRIAL AREA, SHEOGANJ, DISTRICT – SIROHI, RAJASTHAN - 307027 - 307027 PH :9414159146.

SIKAR

2055. JAMU AUTOMOBILES PVT LTD (K701-01), F-54, JAIPUR ROAD (NH-11),SIKAR - 332001 PH :9116816905,9116816905.

SIMALWARA

2056. NAVNEET MOTORS (SLF101-), RAJPUR PEETH ROAD, SIMALWARA, DISTRICT – DUNGARPUR, RAJASTHAN - 314403 - 314403 PH :9001550644.

SIROHI

2057. NAVNEET MOTORS (4902-03), PLOT NO. 8,BHADRANAGAR NAGAR, ANADRA ROAD, SIROHI - 307001 PH :779960989.

SIVANA

2058. LMJ SERVICES LTD. (CCO1-01), BALOTRA ROAD, SIWANA, DISTRICT - JODHPUR, RAJASHTHAN. - 344044 PH :8005989360.

SOJAT

2059. LMJ SERVICES LTD. (BWI1-01), KHASRA NO. - 186/1, NH-8, NEAR ASHOK LEYLAND WORKSHOP, SARDARPURA, SOJAT , RAJASTHAN - 306104 PH :9269971266.

SRI DUNGARGARH

2060. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (BIG1-01), 1563/1273, NH-11, MOMASAR BASS, DUNGARGARH, DISTRICT - BIKANER, RAJASTHAN. - 331803 PH :9414138511.

SRI KARANPUR

2061. AURIC MOTORS (SDL1-01), PADAMPUR ROAD, NEAR DHAN MANDI, SRI KARANPUR,TEHSIL – SRI KARANPUR, DISTRICT – SRI GANGANAGAR,RAJASTHAN, PIN CODE: 335073 - 335073 PH :8875088998.

SRI MADHOPUR

2062. JAMU AUTOMOBILES PVT LTD (BZD1-01), WARD NO.4, RINGUS ROAD, SRI MADHOPUR DISTT. SIKAR. - 332715 PH :9116816905.

SRIGANGANAGAR

2063. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (U201-01), NEW AUTOMOBILE MARKET,SURATGARH-HANUMANGARH ROAD, SRIGANGANAGAR - 335001 PH :0154-2465226,7412059837.

2064. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (U201-03), CHAK 1G CHOTI, NH15, SRIGANGANAGAR, RAJASTHAN - 335001 PH :8875911503.

SUJANGARH

2065. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (BRB1-01), KHASRA NO.459/333, SALASAR ROAD, NEAR ANAJ MANDI, SUJANGARH , DISTT. CHURU - 331507 PH :8875011561.

SULTANPUR

2066. SUWALKA MOTORS PRIVATE LIMITED (GKY1-01), KHASRA NUMBER 485, NEAR PETROL PUMP, SULTANPUR ROAD , SULTANPUR , DISTT KOTA - 325204 PH :7742121212.

SUMERPUR

2067. LMJ SERVICES LTD. (6502-08), G-14 JAKHAMATA INDUSTRIAL AREA, OPP. DASHERA GROUND, SUMERPUR - 306902 PH :8094002633.

Dealer Network (AS ON 31.10.2023)

SURATGARH

2068. AURIC MOTORS (A UNIT OF AUDI MOTORS PVT LTD) (U201-02), OPP. RELIANCE PETROL PUMP,NH-15, SURATGARH - 335804 PH : 8875012667.

THANAGAZI

2069. MG MOTORS (CFJ1-01), NEAR INDIA PETOL PUMP, THANAGAZI, ALWAR ROAD, DIST. ALWAR, PIN 301022, RAJASTHAN - 301022 PH : 9799396200.

TIBBI

2070. AURIC MOTORS (SNJ1-01), KHASRA NO.2261, NEAR T POINT , BYPASS SIKARPUR ROAD ,BULANDSHAHR - 335526 PH : 9413311745.

TINWARI

2071. LMJ (STK1-01), OPPOSITE NEW TEHSIL OFFICE, TIWARI, MATHANIA ROAD, TIWARI -342306 - 342306 PH : 809011126.

TONK

2072. K P AUTOMOTIVES PVT LTD (GM01-01), F-94, RICO INDUSTRIAL AREA, TONK , RAJASTHAN - 304001 PH : 9549651972.

TUNGA

2073. PREM MOTORS (SMB1-01), VILLAGE GVALANI, BASSI-LALSOT ROAD, TUNGA, TEHSIL- BASSI, JAIPUR - 303302 - 303302 PH : 8058998123.

UDAIPUR

2074. NAVNEET MOTORS (4901-01), 7 CITY STATION ROAD,UDAIPUR - 313001 PH : 7230046375.

2075. NAVNEET MOTORS (4902-01), S-140,MADRI INDUSTRIAL AREA,OPP. BSNL OFFICE, UDAIPUR - 313002 PH : 0294- 2494451-54,7665000881.

2076. TECHNOY MOTORS INDIA PVT. LTD. (4903-02), NH-8, GOVERDHAN VILLAS, DEVALI, NEAR JEEVAN TARA RESORT, UDAIPUR - 313002 PH : 7073466292.

2077. TECHNOY MOTORS INDIA PVT. LTD. (4903-04), KHASRA NO. 546, 547, 554 AND 555, NEAR CHITRAKOOT NAGAR, OPP. BHIRAVGARH HOTEL, SUKHER, TEHSIL - BADGAON, UDAIPUR, RAJASTHAN. - 313001 PH : 7297062111,9116101063.

VIRATNAGAR

2078. K.P. AUTOMOTIVES PVT. LTD. (SCB1-01), KHASRA NUMBER 1156,OPP HOTEL GULMOHAR ,JAIPUR ROAD ,VIRATNAGAR, DISTT JAIPUR - 303102 PH : 0141-4071111, 4071101,9358220012.

SIKKIM

GANGTOK

2079. ENTEL MOTORS (B902-01), 6TH MILE, P.O.TADONG, GANGTOK, SIKKIM - 737102 PH : 9933031828 9933032059.

JORTHANG

2080. ENTEL MOTORS (ND02-01), PIPALEY ROHTAK, NEAR JNU SCHOOL, WEST SIKKIM, JORTHANG - 737121 PH : 9733164882 993300934.

TAMIL NADU

ALANDURAI

2081. AADHI CARS PVT. LTD. (CTO1-01), NO.69/1 A, SIRUVANI MAIN ROAD, URIPALLAM PUDHUR, ALANDURAI, COIMBATORE (TAMIL NADU) - 641101 PH : 8754045816.

ALANGULAM

2082. AADHI CARS PVT. LTD. (SJF1-01), SURVEY NO. 495/7, TIRUNELVELI - TENKASI ROAD, ALANGULAM, TIRUNELVELI DISTRICT,TN - 627851 PH : 8754044143.

AMBASAMUDRAM (AMBAI)

2083. AADHI CARS PVT. LTD. (BXT1-01), DOOR NO. 2/253, SURVEY NO. 10/42, RTO OFFICE ROAD, VILLAGE - VAGAIKULAM, AMBASAMUDRAM. - 627 401 PH : 7397188858.

ANAMALAI

2084. ABT (CHE1-01), SITE NO. 6/12, NEAR ABT SAMAA KODDAM, SETHUMADAI ROAD, ANAMALAI, COIMBATORE DISTRICT, TAMILNADU - 642 104 PH : 9788174244.

ANDIPATTI

2085. ASIR (S1S1-01), SURVEY NO. 459/1A1, THENI MAIN ROAD, ANDIPATTI, THENI DISTRICT,TAMILNADU - 625512 PH : 9750372220.

ANNUR

2086. JAIKRISHNAA AUTOSALES PVT. LTD. (DN01-01), SF NO.266/1B, OTTRAPALAYAM VILLAGE, OPP. TO KG SCHOOL, ANNUR,COIMBATORE (DIST), TAMILNADU - 641653 PH : 9788850733.

ANTHYIUR

2087. SREE SARADHAMBAL AUTOMOBILES PVT LTD (CUX1-01), SURVEY NO.495/4, OLD NO.724B, KANCHI THOTTI THOTTAM, BHAVANI MAIN ROAD,ANTHYIUR. - 638501 PH : 8754086777.

ARAKKONAM

2088. GANESH CARS PVT. LTD. (BKQ1-01), SURVEY NO. 556A/3, VILLAGE - ICHIPUDHUR, TALUKA - ARAKKONAM, VELLORE. - 631003 PH : 9842345399.

ARIYALUR

2089. PILLAI & SONS MOTOR CO. (EB01-01), NO. 1/1, NEAR ULAVAR SANTHAI, JAYAMKONDAM ROAD, ARIYALUR (TAMIL NADU) - 621704 PH : 04329-228300, 944221302.

ARNI

2090. GANESH CARS PVT. LTD. (BKP1-01), DOOR NO. 1151/3, VELLORE MAIN ROAD, OPPOSITE TO HERO MOTORS SHOWROOM, RATNAMANGALAM BUS STOP, ARNI , THIRUVANMALAI, TAMIL NADU. - 632301 PH : 9585553266.

ARUPPUKKOTTAI

2091. ASIR AUTOMOBILES PVT LTD (CWF1-01-), SURVEY NO. 205/1, 5/6C, NEHIRU NAGAR, ARUPPUKKOTTAI TO MADURAI BYPASS ROAD, ARUPPUKKOTTAI, DIST.-VIRUDHUNAGAR. - 626 101 PH : 9944059911.

ATTUR

2092. S.M.CAR PVT. LTD. (QT02-01-), SF NO. 351/10A, SALEM TO CHENNAI BY PASS ROAD, APPAMASAMDURAM, ATTUR, SALEM. - 636108 PH : 07094404057.

AVADI

2093. VIJSHNU CARS PVT. LTD. (SP01-01-), SURVEY NO. 146, 147/F & 147/G, NO. 17 VILLAGE – KAVARAPALAYAM, CTH ROAD, AVADI, DISTRICT – THIRUVALLUR, CHENNAI, TAMIL NADU - 600054 PH : 7338888021, 7358024470.

AVINASHI

2094. SHASHTI CAR PVT LTD (CLK1-01-), SURVEY NO. 373/1E, THEEKU THOTTAM, NALLIGOUNDANPALAYAM, PALANGARAI, KUPOUDAMPALAYAM POST, NH ROAD, AVINASHI EAST, TIRUPPUR DISTRICT, TAMILNADU - 641654 PH : 9942903319.

BHAVANI

2095. SREE SARADHAMBAL AUTOMOBILES PVT LTD (HT01-05), NO.5/1072, LAKSHMI NAGAR, NH-47, VASAVI COLLEGE (P.O.), BHAVANI, ERODE (DIST), TAMIL NADU. - 638316 PH : 9597385777.

CHENGALPETTU

2096. AIE CARS (A UNIT OF AI ENTERPRISES PVT LTD) (BBS1-01-), PLOT NO. 98/1, PULIPAKKAM VILLAGE, CHENGALPETTU, DISTRICT-KACHEEPURAM, TAMIL NADU. - 603002 PH : 7299057387.

2097. AIE CARS (A UNIT OF AI ENTERPRISES PVT LTD) (BBS1-02-), DOOR NO. 41, GST ROAD, PULIPAKKAM, CHANGELPET, TAMILNADU - 603202 PH : 7299057387.

CHENGAM

2098. GANESH CARS PVT. LTD. (BUP1-01-), SURVEY NO. 293/3A, 3A1,VILLAGE - THUKAPETTAI, CHENGAM, DIST.-TIRUVANNAMALAI - 606 701 PH : 7397395289.

CHENNAI

2099. ABT LIMITED (1401-01-), # 355-A, GST ROAD, ALANDUR, CHENNAI, TAMILNADU - 600032 PH : 044-2254544, 42254554.

2100. KHIVRAJ MOTORS PVT LTD. (1401-01-), 623 MOUNT ROAD, CHENNAI - 600006 PH : 9043014530.

2101. CARS INDIA PVT. LTD. (1403-01-), 16 & 17 INDUSTRIAL ESTATE, AMBATTUR, CHENNAI - 600058 PH : 9952000089.

2102. CARS INDIA PVT. LTD. (1403-02-), NO.17, LATTICE BRIDGE ROAD, ADYAR, CHENNAI - 600020 PH : 044-24462020.

2103. POPULAR VEHICLES & SERVICES LTD. (1410-02-), OLD NO.155, NEW NO.123, PONRANJITHAM COMPLEX, MEDAVAKKAM MAIN ROAD, NEAR BUS TERMINUS, KEEKATTALAI, CHENNAI - 600117 PH : 9176906334, 9176906335, 9176906336.

2104. ABT LIMITED (1401-05-), A/2, BHARANI STUDIO COMPLEX, DR. BHANUMATHI KRISHNA ROAD,22, AGCOT ROAD, SALIGRAMMAM, CHENNAI - 600093 PH : 044-23650484, 23650490.

2105. ABT LIMITED (1401-06-), NO. 1 & 2, VASANTHA PRESS,ROAD, OPPOSITE MALAI HOSPITAL, ADYAR, CHENNAI - 600020 PH : 044-24465814 , 24465815.

2106. CARS INDIA PVT. LTD. (1403-03-), 4/321, OLD MAHALIKPURAM RD., KOTTIVAKKAM, CHENNAI - 600040 PH : 044-24540182 /43590913.

2107. POPULAR VEHICLES & SERVICES LTD. (1410-01), NO.11, ARUNACHALAM ROAD, SALIGRAMAM, CHENNAI - 600093 PH :9282405819, 9282348331, 8939915206.
2108. ABT LIMITED (1401-07), NO. 422, KOLAPERUMAL SCHOOL STREET, POONMA MALLE HIGH ROAD, CHENNAI - 600106 PH :044-42267628/604.
2109. CRESO (A UNIT OF NEXGEN VENTURES PVT LTD.), (1493-01), 5,THIRUMURUGAN ST, KOYAMBEDU, CHENNAI - 600107 PH :7305087055.
2110. ABT LIMITED (1411-01), 29, WALLES ROAD, OPP. ALBERT THEATER, EGMORE, AMBATTUR, CHENNAI - 600058 PH :044-42281707 / 714 / 719 / 720 / 721 / 737/.
2111. VISHNU CARS PVT. LTD. (1427-02), 176/1, LUZ CHURCH ROAD, NEAR KAMADHENU THEATRE MYLAPORE, CHENNAI - 600004 PH :0427-24661973/7475.
2112. VISHNU CARS PVT. LTD. (1427-01), NO. 91, GST ROAD ALWITONE ESTATE, BEHIND LAXMI THEATRE, PALVARAM, CHENNAI - 600043 PH :044-66813729/733888000.
2113. POPULAR VEHICLES & SERVICES LTD. (1410-03), NO. 3, 200 RING ROAD, RETTERI JUNCTION, RETTERI , CHENNAI - 600099 PH :7448814726/23/33.
2114. CARS INDIA PVT. LTD. (1403-05), PLOT NO.- 80, BABU JAGAVEGAN RAM STREET, GERUGAMBAKKAM, CHENNAI - 600112 PH :9952000079.
2115. KHIVRAJ MOTORS PVT LTD. (1404-03), SURVEY NO. A1 & A2, SIDCO INDUSTRIAL ESTATE, GUINDY, CHENNAI - 600032 PH :7299971978.
2116. ABT LIMITED (1401-0D), NO.2/170, ECR ROAD, INJAMBAKKAM, CHENNAI TAMIL NADU - 600041 PH :044-2449058 / 585 / 586.
2117. AIE CARS (A UNIT OF AI ENTERPRISES PVT LTD) (1484-01), PLOT NO.12.3 & 4, SURVEY NO.9/12, B1, A2 & B, NEELANKARAI, EAST COAST ROAD, CHENNAI - 600115 PH :7401211553.
2118. RAJALAKSHMI CARS PVT. LTD. (1486-01), OLD DOOR NO.69, NEW DOOR NO.20,GRAND NELLORE TRUNK ROAD, MADHAVARAM, CHENNAI . - 600060 PH :8939995454/8939995404.
2119. KHIVRAJ MOTORS PVT LTD. (1480-02), PLOT NO.119 & 120, ELECTRICAL & ELECTRONICS INDUSTRIAL ESTATE, PERUNGUDI, CHENNAI - 600096 PH :38414 23569.
2120. ABT LIMITED (1401-0E), NO. 1/132, RAJEEV GANDHI SALAI, SHOLINGANALLUR, DISTRICT – CHENNAI, TAMIL NADU. - 600119 PH :044-24502185 / 87 / 88 / 89.
2121. VISHNU CARS PVT. LTD. (1427-03), 4/13 LOYAL GARDEN, KALAHATHAMMAN KOVIL STREET, RAMAPURAM, CHENNAI, TAMIL NADU. - 600089 PH :8754400002 9677244332.
2122. VISHNU CARS PVT. LTD. (1487-01), NO.203 TO 206 MOUNT POONAMALLE ROAD, KATTUPAKKAM, CHENNAI - 600056 PH :9677127432.
2123. VISHNU CARS PVT. LTD. (1487-02), NO.120, MAMBAKKAM MAIN ROAD, MEDAVAKKAM, CHENNAI - 600100 PH :9840929994/ 9840944478.
2124. VISHNU CARS PVT. LTD. (1427-04), NEW S. NO. 314/1B1A, PALLAVARAM – THORAIPAKKAM RADIA ROAD, NEAR OLD CHETTINADU CEMENT GODOWN, KEELAKATTALAI, CHENNAI.. - 600117 PH :9940057775.
2125. VISHNU CARS PVT. LTD. (1427-06), PLOT NO. 4, MORISON 4 STREET, ALANDUR, CHENNAI. - 600016 PH :044-45590293.
2126. RAJALAKSHMI CARS PVT. LTD. (1486-02), OLD NO. 27, NEW NO. 22A, ALAPAKKAM MAIN ROAD, MADURAVOYAL, CHENNAI. - 600095 PH :9841427572/9500125083.
2127. CRESO (A UNIT OF NEXGEN VENTURES PVT LTD), (1493-03), PLOT NO. G30, 3RD MAIN ROAD, 9TH STREET, AMBATTUR INDUSTRIAL ESTATE, DIAGONALLY TO TELEPHONE EXCHANGE, CHENNAI. - 600058 PH :7305087033.
2128. POPULAR VEHICLES AND SERVICES LTD (1410-06), PLOT NO. 10, NEW SURVEY NO. 88/1A, 88/1C, 88/1B & 88/2B, NOOMBAL MAIN ROAD, VANAKARAM, CHENNAI. - 600 077 PH :044-61343434, 46490006/9.
2129. AIE CARS (A UNIT OF AI ENTERPRISES PVT LTD) (1484-02), PLOT NO. 1-L SIDCO INDUSTRIAL ESTATE, VILLIVAKKAM, CHENNAI, TAMIL NADU. - 600 049 PH :9841742926.
2130. VISHNU CARS PVT. LTD. (1427-07), SURVEY NO. 19/1A/2, 83/18, DOOR NO. 113, NEAR PARIMALAM THEATER, KUNDRATHUR MAIN ROAD, MANNADY THALAI, NALLUR, SAMBA THALAI, MOONRAMKATTALAI VILLAGE, ONDI COLONY, KUNDRATHUR, CHENNAI. - 600069 PH :95009 82346.
2131. VISHNU CARS PVT. LTD. (1427-08), SURVEY NO. 6/2/28, DOOR NO. 1/63, AGARAM MAIN ROAD, THIRUVANANCHERY VILLAGE, TAMBARAM TALUK, SELAIYUR, KANCHIPURAM DIST., CHENNAI ., TAMIL NADU. - 600 073 PH :8056260022.
2132. ABT LIMITED (1401-10), S. NO: 32/2, NANDAMBAAKAM, PADMINI GARDEN, CHENNAI - 600089, TN. - 600089 PH :044-22320161, 8220011558.
2133. POPULAR VEHICLES AND SERVICES LTD (1410-G1), SURVEY NO: 18/1B2A1A, NAZARATHIPET VILLAGE, POONAMALLE, CHENNAI, TAMIL NADU - 600123 - 600123 PH :7994449644.
- CHENNAI (GUINDY)**
2134. ABT (1401-11), OLD SURVEY NO: 84/1A & 85/1A, NEW TOWN SURVEY NO:1, RACE COURSE ROAD, GUINDY, CHENNAI, TAMILNADU - 600032 PH :9944437421.
- CHEYYAR**
2135. GANESH CARS PVT. LTD. (BUD1-01), NO. 16, KANCHEEPURAM ROAD, CHEYYAR, TIRUVANNAMALAI DISTT. - 604407 PH :9787669339.
- CHIDAMBARAM**
2136. VISHNU CARS PVT. LTD. (CPK1-01), SURVEY NO. 10/22 & 10/25, BHUVANAGIRI MAIN ROAD, KEERAPALAYAM, CHIDAMBARAM TOWN, CUDDALORE, TAMIL NADU. - 608 602 PH :041-44241334/7358004555.
- COIMBATORE**
2137. ABT LIMITED (4101-06), 744, PULIYAKULAM ROAD, P.N. PALAYAM, COIMBATORE - 641037 PH :9944400987.
2138. SREE SARADHAMBAL AUTOMOBILES PVT LTD (4103-1), IYER HOSPITAL PREMISES, TRICHY ROAD, COIMBATORE - 641005 PH :8220862666.
2139. ABT LIMITED (4101-05), LAKSHMI THEATRE BUILDING, T.S. NO. 119/2, TS WARD NO. 3, KEMPATTY COLONY, SOUTH UKKADAM, COIMBATORE - 641001 PH :044-4232660, 4232666.
2140. SREE SARADHAMBAL AUTOMOBILES PVT LTD (4103-3), 555, NSR ROAD, SAIBABA COLONY, COIMBATORE - 641011 PH :9047055687.
2141. ABT LIMITED (4101-08), 15/55-C, ALAGESAN ROAD (EAST), METTUPALAYAM ROAD, COIMBATORE - 641043 PH :96009 66056.
2142. JAIKRISHNAA AUTOSALES PVT. LTD. (4107-01), 8/6-C8&86-D2, METTUPALAYAM ROAD, G.N.MILLS POST, NEARJOHNHBOSCO CHURCH,COIMBATORE - 641029 PH :044-4519140.
2143. SREE SARADHAMBAL AUTOMOBILES PVT LTD (4103-07), NO.44, KANNUSAMY GOUNDER STREET, OORGOUNDER THOTTAM, SANGANUR, COIMBATORE - 641027 PH :9655219900.
2144. SREE SARADHAMBAL AUTOMOBILES PVT LTD (4103-08), SF-94, SATHY MAIN ROAD, VISWASAPURAM, SARAVANANPATTI, COIMBATORE . - 641013 PH :9585877775.
- COONOR**
2155. SREE SARADHAMBAL AUTOMOBILES PVT LTD (3G01-01), 78 E, BRINDAVAN SCHOOL ROAD, COONOR, NILGRIS DIST- TN - 643102 PH :9344870035.
- CUDDALORE**
2156. ABT LIMITED (5Q01-01), K. V. SUBRAMANIAM NAGAR, CHIDAMBARAM MAIN ROAD, CUDDALORE O. T - 607003 PH :04142-224567.

Dealer Network (AS ON 31.10.2023)

2157. VISHNU CARS PVT. LTD. (5Q02-01)- SURVEY NO. 35/8, 35/8A, 35/21, 35/6, 35/6A1A, 35/20, VILLAGE - PERIYA KANANGKUPPAM, CUDDALORE - 607 001 PH :733888413.
- CUMBUM**
2158. MEENAKSHI AUTO ZONE PVT. LTD. (CJS1-01), PATTU NO. 4388, SURVEY NO. 1003 & 1003, VILLAGE - UTHAMPURAM, SUB DIST. -CUMBUM, TAMIL NADU. - 625516 PH :9940094881.
- DEVAKOTTAI**
2159. SIVA AUTOMOTIVE TRADING PVT LTD (GKV1-01), SURVEY NO. 5/1A, MULL IGUNDU (SOMANENTHAL VILLAGE), DEVAKOTTAI TALUK, SIVAGANGAI DISTRICT,TAMILNADU - 630 303 PH :7094688870.
- DHARAPURAM**
2160. SREE SARADHAMBAL AUTOMOBILES PVT LTD (H701-04), OPP. TO ANJANEYAR TEMPLE, NEAR FIVE CORNER, MADURAI ROAD, DHARAPURAM - 638656 PH :9597550777.
- DHARMAPUR**
2161. SRI AMMAN CARS INDIA PVT. LTD. (7001-02), NEAR COLLECTOR BUNGALOW, OLD HOSUR ROAD, JETTIHALI (PO), DHARMAPURI , TAMILNADU - 636807 PH :9750938892/ 9159086222.
- DINDIGUL**
2162. PLA MOTORS (S401-01), NO. 5, TRICHY MADURAI BY PASS ROAD, NH-45, DINDIGUL - 624001 PH :7010075200.
- EDAYARPALAYAM, COIMBATORE**
2163. SREE SARADHAMBAL AUTOMOBILES PVT LTD (CJ1-01), SITE NO. 2, SY. NO. 404/1A1, THADAGAM ROAD, TVS NAGAR, EDAYARPALAYAM, COIMBATORE. - 641025 PH :9047081914.
- ERODE**
2164. SREE SARADHAMBAL AUTOMOBILES PVT LTD (H701-01), 231, PERUND, URAI ROAD, ERODE, - 638011 PH :9677798777.
2165. SREE SARADHAMBAL AUTOMOBILES PVT LTD (H701-06), SURVEY NO. 1363/3, 1363/5, 1363/6, BEHIND MANIKAVASAKAR COLONY BUS STOP, OPPOSITE TO CANARA BANK, KARUR BYPASS ROAD, SOLAR, ERODE. - 638 002 PH :638505777.
2166. SRI CITY AUTO (A UNIT OF CITY AUTO PVT LTD) (H702-01), OLD G.S. NO. 337 (1 TO 4), RS NO. 259/11A, 10,9,8, SATHY ROAD, PERIYA SEMUR VILLAGE, ERODE,TAMILNADU - 638003 PH :9171791991.
2167. SRICITY AUTO (H702-02), R.S. NO:1098/3, VINAYAGAR KOVIL STREET, TELEPHONE NAGAR, POONDURAI MAIN ROAD, ERODE, TAMILNADU - 638002 PH :9626671444
- GOBICHETTIPALAYAM**
2168. SREE SARADHAMBAL AUTOMOBILES PVT LTD (H701-03), NO. 318, CUTCHERY, GOBICHETTIPALAYAM - 638476 PH :9597560777.
- GUDIYATHAM**
2169. GANESH CARS PVT. LTD. (CQW1-01), SURVEY NO 250/1, NEAR NH-75, GANDHI NAGAR, SETHUVADAI, GUDIYATTAM. - 653803 PH :04171-290172.
- GUDUVANCHERY**
2170. VISHNU CARS PVT. LTD. (BAD1-01), 52, THAILAVARAM VILLAGE, BEHIND HOTEL PATTIKADU, GUDUVANCHERRY, KANCHEEPURAM DISTT. - 603203 PH :9500121553/ 9677122225.
- GUMMIDIPONDI**
2171. RAJALAKSHMI CARS PVT. LTD. (BIZ1-01), PLOT NO. F-13, SURVEY NO. 262/2, SIPCOT INDUSTRIAL COMPLEX, VILLAGE – PAPPANAKKUPPAM, GUMMIDIPONNDI, THIRUVALLUR - 601201 PH :044-27922060.
- HARUR**
2172. SRI AMMAN CARS PVT LTD. (AAV1-01), 429/9, HARUR SALEM MAIN ROAD, HARUR POST, DHARMAPURI, TAMIL NADU - 636903 PH :8220014360/7339071500.
- HOSUR**
2173. SRI AMMAN CARS INDIA PVT. LTD. (7Q01-01), P.O- PERANDAPALLI,NH-7, KRISHNAGIRI MAIN ROAD, HOSUR, TAMILNADU - 635109 PH :9790036377/8883259555.
- IDAPPADI**
2174. THRIVENI CAR COMPANY PVT LTD. (H01-01), SURVEY NO.330/3B1B, AVANI PERUR KILMUGAM VILLAGE, IDAPPADI DISTT. SALEM - 637101 PH :9003311488.
- KALLAKURICI**
2165. ABT LIMITED (CHG1-01), SURVEY NO. 215/4,NEAR AKT SCHOOL, DURUGAM ROAD, NEAR DOORDARSHAN BLDG, NEELAMANGALAM VILLAGE., KALLAKURICI TALUK & DIST., TAMILNADU - 606 202 PH :9047514890.
2176. S M CARS (CHG2-01), SF: 31/3B, NO. 19 EMAPPER VILLAGE, KALLAKURICI, TAMILNADU - 606213 PH :7094440010.
- KANCHEEPURAM**
2177. GANESH CARS PVT. LTD. (C601-02), ANBU NAGAR, DHIMMA SAMUDRAM POST, NEAR VELLA GATE, CHENNAI BANGALORE NH-4, KANCHEEPURAM - 631502 PH :9842306061.
- KANGAYAM**
2178. SREE SARADHAMBAL AUTOMOBILES PVT LTD (GJ1-01), NO. 407/263, TIRUPPUR ROAD, KANGAYAM TALUK & TOWN, TIRUPPUR DIST. ,TAMIL NADU - 638701 PH :7078531777.
- KARAUKUDI**
2179. ABT LIMITED (4202-05), 42-43 KOVILOOR ROAD, OPP. TNSTC DEPOT - 630302 PH :4565-232484, 232486..
2180. SIVA AUTOMOTIVE TRADING PVT LTD (HX02-01), NO. 73, SUBRAMANYAPURAM 9TH STREET, COLLEGE ROAD, KARAUKUDI, SIVAGANGA DIST, TAMILNADU-630002 - 630002 PH :7402710000.
- KARUMATHAMPATTI**
2181. SREE SARADHAMBAL AUTOMOBILES PVT LTD (CQJ1-01), SF: NO.281/B, NEAR BHARAT PETROL BUNK VILLAGE - VAGUTHANKADU, SOMANUR ROAD, KARUMATHAMPATTI TOWN, TALUK-PALLADAM, DISTT. COIMBATORE. - 641659 PH :9159210008.
- KARUNGAL**
2182. ATHEN (SGE1-01), SURVEY NO. 639/5, KARUNGAL TOWN, VILAVANCODE TALUK, KANYAKUMARI DISTRICT, TAMILNADU - 629157 PH :7094434179.
- KARUNGALPALAYAM, ERODE**
2183. SREE SARADAMBAL AUTOMOBILES PVT. LTD. (H701-08), RF. NO. 17/1, 2, CAVERI ROAD, KARUNGALPALAYAM, ERODE, TAMILNADU - 638003 PH :8098825000.
- KARUR**
2184. ABT LIMITED (K401-01), SF NO. 529/1, SALEM BY PASS,ROAD, VENGAMEDU CIRCLE, SEMMADAI - 639002 PH :04324-222261/62/63.
- KATTPADI**
2185. GANESH CARS PVT. LTD. (C601-04), 170/2B THIRUVALLAM ROAD, ARUMPARUTHI VILLAGE, KATTPADI, VELLORE DISTT. - 632004 PH :9842313139.
- KATTUMANNARKOIL**
2186. VISHNU CARS (SKG1-01), SURVEY NO. 6 & 7, PERIYAKULAM VADA KARAI, OPP TO GNANAVINAYAGAR KOIL, KATTUMANNARKOIL TOWN AND TALUK, CUDDALORE DIST., TAMILNADU - 608301 PH :7358004555.
- KELAMBAKKAM**
2187. CRESCO (A UNIT OF NEXGEN VENTURE PVT LTD) (SJ1-01), AGP MAHAL, SURVEY NO.43, OMR, 60 FEET VEERANAM HIGH ROAD, PADUR, KELAMBAKKAM, CHENGALPATTU DISTRICT, TAMIL NADU - 603 103 PH :7305087002.
- KINATHUKADAVU**
2188. AADHI CARS PVT. LTD. (BB1-01), NO.212, KAMARAJ NAGAR, SOLAVALAM PALAYAM PANJAYATH, KINATHUKADAVU DISTT. COIMBATORE (T.N.) - 642109 PH :0422-3000506/ 3000505.
- KODUMUDI**
2189. SREE SARADHAMBAL AUTOMOBILES PVT LTD (CUY1-01), SURVEY NO.548/A, KARUR MAIN ROAD, NEAR BUS STAND, KODUMUDI. - 638151 PH :8754756777.
- KOTAGIRI**
2190. AADHI CARS PVT. LTD. (BAS1-01), SURVEY NO.89/79, OOTY MAIN ROAD, KOTAGIRI, DISTT. NILGIRIS, TAMIL NADU. - 643217 PH :8754045891/ 8754045442.
- KOVILPATTI**
2191. ASIR AUTOMOBILES PVT LTD (NO01-01), OLD NO.1, NEW NO.13, SATTUR MAIN ROAD, KOVILPATTI (TAMIL NADU) - 628501 PH :4632-232220.
- KRISHNAGIRI**
2192. SRI AMMAN CARS INDIA PVT. LTD. (7Q01-03)- NH-7,NR. AAVIN DAIRY,MOTTUR,SALEM BYE PASS ROAD, KRISHNAGIRI, TAMILNADU - 635001 PH :9500202416/ 8220004270.
- KUMBAKONAM**
2193. PILLAI & SONS MOTOR CO. (E701-02), 369/2 B, KUMBAKONAM CHENNAI MAIN ROAD, KUMBAKONAM , JAVANUR - 612501 PH :0435-2442566, 2442565, 9443264696.
- MADURAI**

2194. ABT LIMITED (4202-02-), MADURAI-DINDIGAL BYE PASS ROAD,NEAR FATHIMA COLLEGE,MADURAI - 625018 PH .9994400615.
2195. ABT LIMITED (4202-04-), 09, 109A, GST ROAD, TIRUPARANKUNDRAM, MADURAI - 625005 PH .9600966164.
2196. SIVA AUTOMOTIVE TRADING PVT LTD., (4205-01-), 2C, GATE LOCK ROAD, NEAR NEW RAMNAD ROAD, MADURAI - 625016 PH .7402780000.
2197. SIVA AUTOMOTIVE TRADING PVT. LTD., (4205-02-), NO. 6-A, TPK ROAD, NEAR SAIBABA TEMPLE, ANDALPURAM, MADURAI - 625003 PH .7402788840.
2198. ASIR AUTOMOBILES PVT LTD (4206-01-), 9, CHAMBAKULAM, MELUR MAIN ROAD, MATTUTHAVANI, MADURAI, TAMIL NADU - 625007 PH .9944059911.
2199. MEENAKSHI AUTO ZONE PVT. LTD. (4207-01-), PLOT NO. 25 D. SIDCO INDUSTRIAL ESTATE, KAPPALUR, MADURAI, TAMIL NADU - 625008 PH .9442799581.
2200. MEENAKSHI AUTO ZONE PVT. LTD. (4207-02-), SURVEY NO. 238/2A, PLOT NO. 36, 37, 38, TALLAKULAM VILLAGE, SIVAGAMI NAGAR, NATHAM MAIN ROAD, MADURAI - 652 014 PH .9940224881.
- MADURANTHAKAM**
2201. AIE CARS (A UNIT OF AI ENTERPRISES PVT LTD) (CEW1-01-), SURVEY NO. 38/3 A2B, NH-45, MADURANTHAKAM, KANCHIPURAM. - 603306 PH .7401212797.
- MALLASAMUDRAM**
2202. SREE SARADHAMBAL AUTOMOBILES PVT LTD (CWY1-01-), SF NO. 194/3C, MALLASAMUDRAM MAIN ROAD, MALLASAMUDRAM TOWN, TIRUCHENGODE TALUK, NAMAKKAL DIST., TAMIL NADU - 637503 PH .9894932019.
- MALLUR**
2203. THRIVENI CAR COMPANY PVT LTD. (CDH1-01-), SURVEY NO.50/4A, AMANI AMMAPALAYAM VILLAGE, DISTT.: DADHAGAPATTY SUB REGISTRATION , MALLUR DISTT. SALEM - 636309 PH .0427-2422399.
- MANAMADURAI**
2204. ABT LIMITED (CHF1-01-), NO. 35, OLD RAMNAD ROAD, MANAMADURAI TOWN, DISTRICT – SIVGANGAI - 630066 PH .9994450331.
- MANAPPARA**
2205. PILLAI AND SONS MOTOR COMPANY (SKW1-01-), PLOT NO.262, TRICHY DINDIGUL BYPASS ROAD, VENGAIKURUCHI VILLAGE,MANAPPARA, TRICHY,TN - 621307 PH :8489900908.
- MANGALAPURAM**
2206. SREE SARADHAMBAL AUTOMOBILES PVT LTD (CLX1-01-), DOOR NO. 1/18, SURVEY NO. 75/1, ATTUR MAIN ROAD, MANGALAPURAM (POST), TALUK – RASIPURAM, DISTRICT – NAMAKKAL. - 636202 PH :709447871.
- MANNARGUDI**
2207. PILLAI & SONS MOTOR CO. (BKRI-01-), NO. 37, THIRUTHURAPOONDI ROAD, MANNARGUDI, THIRUVARUR DISTRICT, TAMIL NADU. - 614001 PH :7094411675.
- MAYILADUTHURAI**
2208. PILLAI & SONS MOTOR CO. (E701-04-), 46 VELLALAGARAM VILLAGE, MAYILADUTHURAI, TAMILNADU - 609007 PH :04364-251767, 251765, 9442141703.
- MECHERI**
2209. SM CARS (CVK1-01-), SURVEY NO. 139A/5, PATTIA NO. 653, AMANI M.KALIPATTY VILLAGE, MECHERI TOWN, METTUR TALUK, SALEMN DIST., TAMIL NADU. - 636 453 PH :7094440010.
- MELUR**
2210. SIVA AUTOMOTIVE TRADING PVT. LTD. (CHC1-01-), OLD SN. 138/1, SURVEY WARD C, BLOCK NO. 1, T.S. NO. 21/7, VILLAGE AND TOWN – MELUR, MELUR, DIST.-MADURAI. - 625109 PH :8098120000.
- METTUPALAYAM**
2211. ABT LIMITED (4101-0C-), PLOT NO. 6 TO 9,PONVIZHA NAGAR, KARAMADAI KOVAI MAIN ROAD, METTUPALAYAM - 641043 PH :95009 45094.
- METTUR**
2212. THRIVENI CARS (BUI1-01-), S.F. NO. 73/7A3C, METTUR TO BHAVANI ROAD, NEAR NATAMANGALAM BUS STOP, MADHAIYANKUTTAI (PO), METTUR TALUK, SALEM, TAMILNADU - 636452 PH :9159566999.
- MINJUR**
2213. RAJALAKSHMI CARS PVT. LTD. (BPE1-01-), PLOT NO. 27, SRI JANAI RATHINA NAGAR, VILLAGE AND TOWN – MINJUR, PONNERI – 601203 DISTRICT – THIRUVALUR. - 601203 PH :044-27933331.
- NAGAPATTINAM**
2214. PILLAI & SONS MOTOR CO. (CQCI-01-), NO.181, KEELA ANTHANAPETTAI, ANTHANAPETTAI, P.O. - MANUKOLLAI, PUTHUR, NAGAPATTINAM DISTTT. TAMIL NADU - 611106 PH :4365220250.
- NAGARCOIL**
2215. ATHEEN (S503-01-), RESURVEY NO. G.3/9-7, BUILDING NO. 254-A/3 & 4 K.P ROAD ,PARAVATHIPURAM, NAGERCOIL ,KANYAKUMARI DISTRICT TAMILNADU - 629003 PH :8012029777.
- NAKKAL**
2216. SREE SARADHAMBAL AUTOMOBILES PVT LTD (X401-01-), SURVEY NO. 1/10-11, NEAR MURUGAN TEMPLE, SALEM ROAD, NAMAKKAL - 637001 PH :937164888.
2217. SREE SARADHAMBAL AUTOMOBILES PVT LTD (X401-03-), 14/12/1 NEAR PON NAGAR, MUDALAIPATTAI, SALEM ROAD, NH-7, NAMAKKAL (TAMIL NADU) - 637001 PH :737192888.
- NATRAMPALLI**
2218. GANESH CARS PVT. LTD. (SPR1-01-), NO:8/12-1, NEAR ARJUNA SULOCHANA MAHAL, BENGALURU- CHENNAI MAIN ROAD,VELAKALNATHAM, NATRAMPALLI, TIRUPATTUR DIST. TAMIL NADU - 635854. - 635854 PH :73977 53146.
- NEGAMAM**
2219. ABT LIMITED (CHD1-01-), 68, 69, ABT BUS STAND, PALLADAM ROAD, PERIA NEGAMAM, POLLACHI, TAMIL NADU - 642120 PH :99948 76794.
- OMALUR**
2220. SRI AMMAN CARS INDIA PVT. LTD. (7Q01-04-), 123, 3B, NH-7, BANGALORE BYE PASS ROAD, KOTTAMETTUPTATTI, OMALUR, SALEM (DIST.), TAMIL NADU - 636012 PH :8220010070/8883529888.
2221. THRIVENI CAR COMPANY PVT LTD. (UM01-01-), PLOT NO. 44 & 45, PALANIYAPPA NAGAR LAYOUT, NH-7, KAMALAPURAM VILLAGE, OMALUR, DISTRICT – SALEM, TAMIL NADU - 636309 PH :4290-222711.
- OTY**
2222. SREE SARADHAMBAL AUTOMOBILES PVT LTD (4103-01-), VIJAYANAGARAM FARM ROAD, NEAR ROSE GARDEN, OTY - 643001 PH :97511 09229.
- P.N. PALAYAM, COIMBATORE**
2223. PLA MOTORS (S401-02-), NO:13-1-11C-1, WEST AVAKUDI, DINDIGUL ROAD, PALANI, DINDIGUL DISTRICT, TAMIL NADU - 624613 PH :04545-290900.
- PADAPPALAI**
2224. VISHNU CARS PVT. LTD. (CRO1-01-), SURVEY NO.3682/4/A1, 3682/2/A2, VANDALLUR-WALAJABAD MAIN ROAD, PADAPPALAI EAST, CHENNAI. - 601301 PH :8754417168.
- PALANI**
2225. PLA MOTORS (S401-02-), NO:13-1-11C-1, WEST AVAKUDI, DINDIGUL ROAD, PALANI, DINDIGUL DISTRICT, TAMIL NADU - 624613 PH :04545-290900.
- PARAMATHIVELUR**
2226. SREE SARADHAMBAL AUTOMOBILES PVT LTD (CC01-01-), SURVEY NO. 171, NEAR KONGU SCHOOL, NAMAKKAL BYPASS ROAD, PADAMUDI PALAYAM, TALUKA – PARAMATHIVELUR, NAMAKKAL , TAMIL NADU. - 638182 PH :8870666599.
- PATTUKKOTTAI**
2227. PILLAI & SONS MOTOR CO. (CJA1-01-), SURVEY NO. 85/6, 85/4, 84/6, DOOR NO.314/11, SRI JANAGALAKSHMI NAGAR, THANJAVUR ROAD, ALADIKUMULAI VILLAGE, TALUK PATTUKOTTAI, THANJAVUR. - 614615 PH :7094433074.
- PAVITHRAM**
2228. SREE SARADHAMBAL AUTOMOBILES PVT LTD (CWT1-01-), SURVEY NO. 102/1B, NAMAKKAL MAIN ROAD, PAVITHRAM - 637 021 PH :9600320881.
- PENNAGARAM**
2229. SRI AMMAN CARS INDIA PVT. LTD. (BXZ1-01-), SURVEY NO. 419/1, VILLAGE – PARUVADHANAALLI, PENNAGARAM, DHARMAPURI. - 636810 PH :9715044700.
- PERAMBALUR**
2230. PLA MOTORS (2305-04-), SURVEY NO.88/1, A3,NH45, ELAMBALUR VILLAGE, PERAMBALUR, TAMILNADU - 621212 PH :8870004960.
- PERNAMBUT**
2231. SRI AMMAN CARS INDIA PVT LTD (SRA1-01-), SURVEY NO:708, PLOT NO. 87,88 & 89, PERNAMBUT TO GUDIYATTAM ROAD, PERNAMBUT,VELLORE DISTRICT, TAMIL NADU - 635810 - 635810 PH :7094403100.
- PERUNDURAI**

Dealer Network (AS ON 31.10.2023)

2232. SREE SARADHAMBAL AUTOMOBILES PVT LTD (BTX1-01), SF NO.542/1, KOVAI MAIN ROAD, PERUNDURAI VILLAGE, PERUNDURAI DISTT. ERODE, TAMIL NADU - 638052 PH :9597490777.
- POCHAMPALLI**
2233. SRI AMMAN CARS PVT. LTD. (CUW1-01), NEW SURVEY NO. 56/15, VILLAGE – JUMBUKUTTANPATTI, POCHAMPALLI, KRISHNAGIRI - 632506 PH :9600466988.
- POLLACHI**
2234. ABT LIMITED (L301-01), NACHIMUTHU POLYTECHNIC CAMPUS, UDUMALPET ROAD, POLACHI - 642003 PH :99944 53265.
- POLUR**
2235. GANESH CARS PVT. LTD. (GLV1-01), AZHAGO COMPLEX, SURVEY NO:77/1, CUDADALOR TO CHITTOOR ROAD, POLLUR, THIRUVANNAMALAI DISTRICT,TAMILNADU - 606803 PH :9842345200.
- PUDUKOTTAI**
2236. PLA MOTORS (2305-02), NO. 10, MARIAMALAI NAGAR, ALANGUDI- THIRUMAYAM ROAD, PUDUKOTTAI - 622003 PH :04322-265568/67.
- PUNJAI PULIAMPATTI**
2237. SREE SARADHAMBAL AUTOMOBILES PVT LTD (BK01-01), SURVEY NO. 250/1, PANKAU PULIYAMPATTU MUNICIPALITY, PUNJAI PULIYAMPATTI - 638459, SATHY THALUK, ERODE - 638459 PH :6385810777.
- RAJAPALAYAM**
2238. MEENAKSHI (5V02-01), DOOR NO. 96, COTTON MARKET, TENKASI-MADRASI ROAD, RAJAPALAYAM, VIRUDHUNAGAR DIST., TAMILNADU - 626117 PH :9443785681.
- RAMANATHAPURAM**
2239. SIVA AUTOMOTIVE TRADING PVT. LTD. (DU02-01), SURVEY NO. 172/1B2C, 172/2C, VILLAGE - ACHUNTHANVAYAL, ACHUNTHANGAL GROUP, TALUK - RAMANATHAPURAM, RAMANATHAPURAM. - 623502 PH :8098110000.
- RAMESHWARAM**
2240. SIVA AUTOMOTIVE (SKI1-01), NO:2307, SURVEY NO:279/3A, RAMNAD ROAD, ARIYANKADU, RAMESHWARAM, RAMANATHAPURAM DISTRICT, TAMILNADU - 623529 PH :7402788898.
- RANIPET**
2241. GANESH CARS PVT. LTD. (CJJ1-01), SURVEY NO. 44/1, PLOT NO. 484, OPPOSITE TO THIRUMALAI CHEMICALS, SIPCOT LAYOUT OF HOUSE SITES, SIPCOTS INDUSTRIAL COMPLEX, RANIPET , TAMIL NADU. - 632403 PH :9842330388.
- RASIPURAM**
2242. SREE SARADHAMBAL AUTOMOBILES PVT LTD (BSJ1-01), SURVEY NO.4/1/b1A, MOOLAKADU VILLAGE, MASAKALIPATTI, SALEM MAIN ROAD, RASIPURAM DISTT. NAMAKKAL - 637401 PH :4286-231402/753972888.
- REDHILLS**
2243. CARS INDIA PVT. LTD. (1403-04), NO.503, G.N.T. ROAD, REDHILLS, CHENNAI - 600066 PH :9952000078.
- SALEM**
2244. ABT LIMITED (4101-03), 32 THAMANA CHETTY ROAD, ARISALPALAYAM, SALEM - 636009 PH :0427-4069688, 406999.
2245. THRIVENI CAR COMPANY PVT. LTD. (A203-01), 12/2E1, SUBRAMANIA NAGAR, 2ND GATE, JUNCTION ROAD, SALEM. - 636005 PH :0427-2440000.
2246. S.M.CARS PVT. LTD. (A204-01), SF NO. 64/2C3, ATTUR SALEM BYPASS ROAD, PINANGUKARAR THOTTAM, SELANIKANPATTY, SALEM. - 636202 PH :709448000, 703449000.
2247. THRIVENI CAR COMPANY PVT. LTD. (A203-03), SURVEY NO. 57, VILLAGE - MASINAICKENPATTY, AYOTHIAPPATINAM, AMMAPET, SALEM. - 636103 PH :0427-2291000.
2248. S M CAR PRIVATE LIMITED (A204-02), DOOR NO. 50/28, SF NO. 1/10B, SARADHA COLLEGE MAIN ROAD, ALAGAPURAM PUDHUR VILLAGE, HASTHAMPATTY, SALEM, TAMILNADU - 636007 PH :7094440053.
- SANKAGIRI**
2249. THRIVENI CAR COMPANY PVT LTD. (BTN1-01), SURVEY NO.17/1B, KCK PLAZA, KACHERIDADU, DEPUTY COLLECTOR ROAD, SALEM, SANKAGIRI (TAMIL NADU) - 637301 PH :+914283242600 +914283242601.
- SANKARANKOVIL**
2250. AADHI CARS PVT. LTD. (BXS1-01), PLOT NO. 132/H, OPPOSITE TO NEW TALUK OFFICE, TIRUVENGADAM ROAD, SANKARANKOVIL. - 627756 PH :7397728025.
- SATHY ROAD, ERODE**
2251. SREE SARADHAMBAL AUTOMOBILES PVT. LTD. (H701-09), SF NO.245, KANDHAIYAN THOTTAM, SOOLAI, SATHY ROAD, VEERAPPANPATTI, ERODE, TAMILNADU - 638004 PH :9655240486.
- SATHYAMANGALAM**
2252. SREE SARADHAMBAL AUTOMOBILES PVT LTD (BGU1-01), SURVEY NO. 51, 54 & RS NO. 37, KOTTUVERAMPALAYAM VILLAGE, SATHYAMANGALAM – 638 401, DISTRICT – ERODE, TAMIL NADU - 638401 PH :9597592777.
- SATTUR**
2253. MEENAKSHI AUTO ZONE PVT. LTD. (SDR1-01), SURVEY NO. 18/10,CHATRAPATTI VILLAGE, MADURAI KANYAKUMARI NATIONAL HIGHWAYS, SATTUR, VIRUDHUNAGAR DISTRICT,TAMILNADU - 626203 PH :9940094881.
- SEYDUNGANALLUR**
2254. ASIR AUTOMOBILES PVT LTD (S603-02), SURVEY NO. 59/3E, TIRUCHENDUR ROAD, SEYDUNGANALLUR TOWN, TALUK - SRIVAKUNTAM, TUTICORIN DIST., TAMIL NADU - 628809 PH :8349922200.
- SHOLINGUR**
2255. GANESH CARS PVT. LTD. (GLU1-01), NO:401, ARAKKONAM MAIN ROAD,OPPOSITE TVS FOUNDRARY, PANDIYANELLORE,SHOLINGHUR,WALAJA TALUK, RANIPET DISTRICT, TAMILNADU - 631102 PH :7397395259.
- SIVAKASI**
2256. MEENAKSHI AUTO ZONE PVT. LTD. (X602-01), 372 D & E, ARUNACHALAM COMPLEX, THIRUTHANGAL ROAD, SIVAKASI. - 626123 PH :4562-231281.
- SRIPERUMBUDUR**
2257. RAJALAKSHMI CARS PVT. LTD. (7B01-01), SURVEY NO. 150/1A, DOOR NO 1C, THERADI STREET, NEW VILLAGE NO 42, SRIPERUMBUDUR, KANCHEEPURAM DISTRICT, TAMIL NADU. - 602105 PH :893995469.
- SRIVILLIPUTHUR (RAJAPALAYAM)**
2258. ABT LIMITED (4202-03), NO. 10/32, PADIKKASUVAITHANPATTI , NEAR RTO OFFICE, SRIVILLIPUTHUR, VIRUDHUNAGAR, TAMIL NADU - 626125 PH :95009 05020.
- SULUR**
2259. JAIKRISHNAA AUTOSALES PVT. LTD. (4107-05), DOOR NO. 37 F, RANGANATHAPURAM, TRICHY ROAD, SULUR - 641 402 PH :0422-3199901.
- TENKASI**
2260. AADHI CARS PVT. LTD. (BXR1-01), DOOR NO. 3/50-1, SURVEY NO. 447B, TIRUNELVELI MAIN ROAD, VILLAGE – KUNARAMANALLUR, TENKASI. - 627814 PH :9500991475.
2261. AADHI CARS PVT. LTD. (BXR1-02), DOOR NO. 47, MADHALAMPARAI, TENKASHI AMBAI HIGHWAY, TENKASHI, TIRUNELVELI DIST., TAMILNADU. - 627 814 PH :9500991475.
- THAMMAPATI**
2262. SM CARS (SNH1-01), SURVEY NO # SF: 328/11, NAGIAMPATTI, THAMMAPATTI,SALEM DISTRICT, TAMILNADU - 636113 PH :7094440010.
- THANJAVUR**
2263. PILLAI & SONS MOTOR CO. (E701-01), 12A, SELVAM NAGAR, TANJAVUR, TAMILNADU - 613007 PH :04362-271723, 271724, 9443264164.
- THARAMANGALAM**
2264. THRIVENI (CSQ1-01), NO. 1/122, KATTAMPATTI, JALAKANDAPURAM, THARAMANGALAM, SALEM DIST, TAMIL NADU. - 636501 PH :9159355999/9003504760.
- THENI**
2265. MEENAKSHI AUTO ZONE PVT. LTD. (9U02-01), DOOR NO. 87/1/1, RATHINAM NAGAR, PERIYAKULAM MAIN ROAD, THENI TOWN, DISTRICT – THENI - 625531 PH :9789703881.
- THIRUMULLAI/VOYAL**
2266. CRESCO (A UNIT OF NEXGEN VENTURES PVT LTD), (CDW2-01), NO. 48, BALAJI NAGAR, NEW SIR IRVANSTADE FORD HOSPITAL, THIRUMULLAI/VOYAL DISTT. CHENNAI - 600062 PH :7305087044.
- THIRUVALLUR**
2267. KHIVRAJ MOTORS PVT LTD. (1404-04), 2151, KAKKULUR ROAD, THIRUVALLUR PH :99520 78443.
2268. KHIVRAJ MOTORS PVT LTD. (1404-05), PLOT NOS 218,219,220,225,226,227,228 AND S.NOS 18/5,18/6, EMPIRE CITY PART-3, KAKKALLUR VILLAGE, THIRUVALLUR THALUK, THIRUVALLUR - 602001 PH :97103 94818.
- THIRUVANNAMALAI**

2269. GANESH CARS PVT. LTD. (C601-03), NO-5, NH-78, KRISHNAGIRI PONDY ROAD, CHINA KANEYAR, OPP SKP ENGG. COLLEGE, THIRUVANNAMALAI - 606601 PH :9842305072.
- THIRUVARUR**
2270. PILLAI & SONS MOTOR CO. (E701-03), THANJAI NAGARI ROAD, OPP. TO S. P. OFFICE - 610001 PH :04366-250250, 9442163707.
2271. PILLAI & SONS MOTOR COMPANY (LJ01-01), NO. 9, WARD NO.4, BLOCK NO. 10, NEW SY. NO. 601/681, SUNDRAMAVILAGAM, NARSINGHAMPET, THIRUVARUR TOWN & DIST., TAMIL NADU - 610001 PH :9442163509.
- THISAYANVILLAI**
2272. AADHI CARS PVT. LTD. (CVL1-01), SURVEY NO. 240/1, 7/1, HIGHWAYS ROAD, OPP. TO VO OFFICE, SELVA MARUTHUR, THISAYANVILLAI. - 627 657 PH :97359511187.
- THUCKALAY**
2273. ATHENS (BWQ2-01), DOOR NO. 5/76B, (RE SURVEY NO-5307) THIRUVITHANCODE ROAD, KERALAPURAM, MUTHALAKURUCHI, VILLAGE – MUTHALAKURUCHI, KALKUM-TALUK, THUCKALAY, DISTRICT – KANYAKUMARI, TAMILNADU - 629174 PH :8012029888.
- THURAIYUR**
2274. PLA MOTORS (CSE1-01), D.NO.:5/300, SINGALANDHUPURAM VILLAGE, THURAIYUR DISTT. TRICHY (TAMIL NADU) - 621010 PH :9486763725.
- TIRUCHENDUR**
2275. ASIR AUTOMOBILES PVT LTD (CCJ1-01), SURVEY NO. 220/1D1A, 221/3, 221/4, 221/5, 221/5A, 221/5B, PODHIGAI NAGAR, VILLAGE-VEERAPANDIVPATINAM, THIRUCHENDUR, TUTUCORIN. - 628215 PH :7373900220.
- TIRUCHENGODE**
2276. SREE SARADHAMBAL AUTOMOBILES PVT LTD (X401-02), PLOT NO-10, OPP TO PONNUSWAMY KALYANA MANDAPAM, KOOTAPALLI COLONY, TIRUCHENGODE - 637001 PH :4288-282292.
- TIRUNELVELI**
2277. AADHI CARS PVT. LTD. (A303-01), PLOT NO. 261, MADURAI MAIN ROAD, KARAIEPURU, TIRUNELVELI, TAMIL NADU - 627357 PH :9500991610.
2278. AADHI CARS PVT. LTD. (A303-03), DOOR NO. 37, RAMNAGAR, KTC NAGAR, TIRUNELVELI, TAMIL NADU. - 627 011. PH :9500991610.
- TIRUNELVELI**
2279. AADHI CARS PVT. LTD. (A303-04), SF NO:161/4, SF NO: 893/2, NORTH BYEPASS ROAD, GALAXY HOSPITAL BACKSIDE, PALAYANKOTTAI, TIRUNELVELI, TAMILNADU - 627001 PH :95009 91479.
- TIRUPATHUR**
2280. GANESH CARS PVT. LTD. (BPD1-01), SURVEY NO.54/4, TIRUPATHUR TO KRISHNAGIRI ROAD, PALLIPET VILLAGE, TIRUPATHUR DISTT. VELLORRE - 635601 PH :9842308909.
- TIRUPATTUR (SIVAGANGAI)**
2281. ABT LIMITED (CHH1-01), DOOR NO. 8/2/29A, KARAUKUDI ROAD, TIRUPATHUR, DISTRICT – SIVAGANGAI. - 630211 PH :9994450331.
- TIRUPUR**
2282. ABT LIMITED (4101-09), NO. 4, SABHAPATHI PURAM, NEAR TMF HOSPITAL, TIRUPUR. - 641601 PH :95009 98368.
2283. SHASHTI CAR PVT LTD (Y701-01), SRI PADMINI GARDENS, KANGEYAM ROAD, OPP. ST JOSEPH SCHOOL, TIRUPUR. - 641604 PH :044-2430275/ 2430276.
- TIRUTHANI**
2284. CARS INDIA PVT. LTD. (CIC1-01), NO. 9/13, CHENNAI BY PASS ROAD, OLD CHENNAI ROAD, DISTT. THIRUVALLUR, TIRUTHANI,TAMILNADU - 631209 PH :7357773860.
- TIRUVANNAMALAI**
2285. SRI AMMAN CARS INDIA PVT LTD. (LX02-01), 2A/2, SURVEY NO. 3676/3, ANNA SALAI, TIRUVANNAMALAI-CHENNAI NH-101, TIRUVANNAMALAI TOWN AND DIST., TAMILNADU . - 602601 PH :7094471293.
- TONDI**
2286. SIVA AUTOMOTIVES (SHW1-01), SURVEY NO: 85/16, WARD 10/78, SOUTH THOUP STREET, ECR MAIN ROAD, ECR, THONDI, RAMANATHAPURAM DISTRICT, TAMIL NADU - 623409 PH :7402788820.
- TRICHY**
2287. ABT LIMITED (2302-02), 4/40, COLLECTOR, OFFICE ROAD, CANTONMENT, TRICHY - 620001 PH :0431-4221620.
2288. PLA MOTORS (2305-01), NO. 18/2, NA-45, DHEERAN NAGAR, TRICHY-DINDUGAL MAIN ROAD, TRICHY - 620009 PH :9994599777/9600950960.
2289. ABT LIMITED (2302-03), MADRAS TRUNK ROAD, MAMBALASALAI, TRICHY - 620005 PH :0431-4221555.
2290. PLA MOTORS (2305-03) 10A & B, ALEXANDRIA ROAD, CANTONMENT, TRICHY - 620001 PH :0431-2411540/530.
2291. PILLAI & SONS MOTOR CO. (Z306-01), SURVEY NO. 10B, 1/A/D, CHENNAI TRICHY BY-PASS ROAD, VILLAGE - THIRUNALLUR, TRICHY. - 620002 PH :8489900902, 9384826814.
- TUTICORIN**
2292. ASIR AUTOMOBILES PVT LTD (S603-01), SURVEY NO. 25/1B, MAPPILLAIURINI VILLAGE, ETTAYAPURAM ROAD, TUTICORIN, TAMIL NADU - 628002 PH :7373501220.
- UDUMALPET**
2293. ABT LIMITED (QR01-01), 2/3, PERIYAKOTTAI PIRIVU, S.V. MILL POST, UDUMALPET - 641226 PH :99944 41645.
- USILAMPATTI**
2294. SIVA AUTOMOTIVE TRADING PVT LTD (SNC1-01), NO. 33/1B2A, USILAMPATTI - MADURAI HIGHWAY,POTTULUPATTI PANCHAYATH, USILAMPATTI, MADURAI DISTRICT, TAMILNADU-625532 - 625532 PH :788088840.
- UTHANGARAI**
2295. SRI AMMAN CARS INDIA PVT. LTD. (CFY1-01), SURVEY NO. 10/41, 104/1B, VILLAGE – THANDIYAPANNUR, UTHANGARAI, KRISHNAGIRI. - 635304 PH :9715044600.
- UTHUKOTTAI**
2296. KHIVRAJ MOTORS PVT LTD. (CUC1-01), SURVEY NO. 442/1, NEHRU BAZZAR STREET, UTHUKOTTAI, DIST.-THIRUVALUR - 602 026 PH :7299635536.
- VALLIYUR**
2297. AADHI CARS PVT. LTD. (BXQ1-01), DOOR NO. 314/11-14, WITHIN VADAKU VALLOIOR, REVENUE VILLAGE, VADAKKU VALLOIOR PANCHAYAT, RADHAPURAM TALUK, VALLIOOR. - 627002 PH :7373091462.
- VANDAVASI**
2298. GANESH CARS PVT. LTD. (CRN1-01), SURVEY NO.272, KEELSATHAMANGALAM VILLAGE, CHETPET ROAD, VANDAVASI, TIRUVANNAMALAI, DISTT. T.N. - 604408 PH :7395802484.
- VANIYAMBADI**
2299. GANESH CARS PVT. LTD. (BJY1-01), NO. 197/1B1, NH-46 (AH-17), PETHAKALLUPALLI VILLAGE, NEAR TOLL GATE, VANIYAMBADI , VELLORE (DIST), TAMIL NADU. - 635801 PH :9842327709.
- VELLORE**
2300. GANESH CARS PVT. LTD. (C601-01), 91 NEW BY-PASS ROAD, VELLORE - 632004 PH :9842377110.
2301. SRI AMMAN CARS INDIA PVT. LTD. (C602-01), DOOR NO. 68, SURVEY NO. 667, NEAR RANGALAYA KALYANA MANDAPAM, VELLORE-KATPADI ROAD, KALINJUR VILLAGE, KATPADI TALUK, GANDHINAGAR, VELLORE DIST., TAMIL NADU. - 632006 PH :7094471320, 7094471321.
2302. SRI AMMAN CARS INDIA PVT. LTD. (C602-02), SURVEY NO. 316/3B2, 316/3B8A, 316/BB, NEAR SHELL PETROL PUMP, MELMONAVUR VILLAGE,VELLORE TALUK & DIST. ON NH48 (CHENNAI – BENGALURU HIGHWAY), VELLORE, TAMILNADU - 632010 PH :7094471320.
- VILLUPURAM**
2303. ABT LIMITED (SQ01-02), 264/1, GINGEE MAIN ROAD, AVINAMPALAYAM, VILLUPURAM - 605602 PH :04146-225509 / 225590.
- VIRUDHACHALAM**
2304. ABT LIMITED (BMA1-01), PLOT NO. 56, JUNCTION ROAD, NEAR SHANMUGA LODGE, VIRUDHACHALAM, DISTRICT – CUDDALORE, TAMIL NADU. - 606101 PH :04143-262631/262632/262633.
- VIRUDHUNAGAR**
2305. MEENAKSHI AUTO ZONE PVT LTD (SCF1-0A-), DOOR NO.6/504, SURVEY NO. 11/6, PELAMPATTI VILLAGE,VIRUDHUNAGAR MADURAI HIGH WAY,OPPOSITE TO VVV COLLEGE., TALUK & DIST. VIRUDHUNAGAR, TAMILNADU - 626001 PH :9940094881.

TAMILNADU**ALANGUDI**

2306. PLA MOTORS (SLR1-01), S. NO. 400/6-A-2, NO. 1/85, MANGALAPURAM, PUDDUKOTTAI TO ALANGUDI ROAD, NEAR KNP KALYANA MANDAPAM, ALANGUDI TOWN & TALUK, PUDDUKOTTAI DIST., TN - 622301 - 622301 PH :8870454466.

Dealer Network (AS ON 31.10.2023)

CHENNAI

2307. VISHNU CARS (1488-01), DOOR NO. 8, NP INDUSTRIAL ESTATE, JAWAHARLAL NEHRU ROAD, EKKATUTTHANGAL, CHENNAI,TN - 600032 PH :7505360444.

CHENNAI- MAMBAKKAM

2308. KHVIRAJ MOTORS (1404-G1), SURVEY NO:76/A, NO:27, PLOT NO. D-2, KEELAKOTTAYUR, VANDALUR TO KELAMBakkAM MAIN ROAD, MAMBAKKAM, CHENGALPET, CHENNAI,TN - 600127 PH :9841591558.

CHEPTEt

2309. GANESH CARS (SGY1-01), DOOR NO: 35/C, CHEPTEt TOWN, CHEPTEt TALUKA, TIRUVANNAMALAI DIST.,TAMILNADU , - 606 801 PH :98423 06337.

CHINNAMANUR

2310. ABT LIMITED (SKX1-01), SF NO. 446 /1A, WARD A, BLOCK-2, TS NO 8/15, PERIYAKULAM TO CHINNAMANUR MAIN ROAD,KEELAPOLANANDHUPARAM, CHINNAMANUR MUNICIPAL TOWN & TALUK, THENI DIST.,TN - 625515 - 625515 PH :9715863213.

DENKANIKOTTAI

2311. AMMAN CARS (SDT1-01), SURVEY NO:766/ 1B11, THABILAGOUNDAN THOTTI, DENKANIKOTTAI, KRISHNAGIRI DISTRICT, TAMILNADU - 633107 PH :9585599935.

DHARAPURAM

2312. SREE SARADHAMAL AUTOMOBILES PVT LTD (QNO1-01), SF 134/4A3, DINDIGUL BYPASS ROAD, NEAR INDIAN OIL PETROL PUMP, DHARAPURAM TOWN AND TALUKA, TIRUPPUR DIST., TAMILNADU-638656 - 638656 PH :9787853000.

GANGAVALLI

2313. THRIVENI CARS (SOS1-01), SURVEY NO # SF NO: 22/3A1A,106 ATTUR MAIN ROAD,GANGAVALLI,SALEM, TN - 636105 PH :9159722999.

KAWALKINARU

2314. AADHI CARS PVT. LTD. (CSU1-01), SURVEY NO:1943/1, SURESH COMPLEX, KANYAKUMARI BYPASS ROAD, KAVALKINARU JUNCTION, KAVALKINARU (VADAKKANKULAM), TIRUNELVELI , - 627105 PH :7339111259.

KULASEKHARAM

2315. ATHEN CARS (SIL1-01), IITE NO : 409/17A – ARANIVILAI, NEAR RANGE OFFICE, CONVENT ROAD – KULASEKARAM, KALKULAM –TALUK,KANYAKUMARI DIST. TN - 629 161 PH :7094471569.

KUMBAKONAM

2316. PILLAI AND SONS MOTOR CO. (E701-06), D. NO. HP-1, GOVT. INDUSTRIAL ESTATE, SIDCO, THIRUBUVANAM TOWN & POST, KUMBAKONAM, THANJAVUR DISTRICT, TAMILNADU - 612103 PH :8489900136.

MADURAI

2317. SIVA AUTOMOTIVE TRADING PVT LTD (4205-03), NO. 614, SURVEY NO. 32/2, 32/4, THENI MAIN ROAD, ACHAMPATHU, MADURAI, TN - 625019 PH :7402738888.

NEYVELI

2318. VISHNU CARS (CPN1-01), SURVEY NO:545/2A1A, NH-45C, OPP. NATIONAL COLLEGE KUMBAKONAM - CHENNAI HIGH WAY, NEAR NEYVELI ARCH GATE, NEYVELI T.S. KEELAKOLAI, MARUNGUR POST,PANRUTI,CUDALORE DISTRICT, TAMILNADU - 607103 PH :9384059575.

PERUMBakkAM

2319. KHVIRAJ MOTORS PVT LTD (SSL1-01), NO:1,VARALAKSHMI NAGAR, THIRUVALLUR ROAD, PERAMBakkAM,KANCHIPURAM DIST, TAMILNADU - 631402 - 631402 PH :733876693.

SIVAGANGAI

2320. ASIR AUTOMOBILES (SDC1-01), S. NO: 144/1, SIVAGANGAI-THONDI ROAD, PAIYAPURILLAIAYAL, SIVAGANGAI/TAMILNADU - 630561 PH :9750372220.

THANJAVUR

2321. PLA MOTORS FIRM (E702-01), SURVEY NO. 173/684, TRICHY-THANJAVUR ROAD, NANJIKOTTAI BYPASS, THANJAVUR, TAMILNADU - 613005 PH :9344006433/9344003877.

THIRUMAZHISAI

2322. CARZ INDIApVT.LTD (SMH1-01), DP 30, SIDCO INDUSTRIAL ESTATE, THIRUMAZHISAI , - 600124 PH :9500064259.

THOPPUR

2323. SRI AMMAN CARS (SLU1-01), SITE NO. 422 /2A, BANGALORE TO SALEM HIGH WAY, AMMANI, THOPPUR VILLAGE & TOWN,NALLAMPALLI TK, DHARMAPURI DISTRICT, - 636352 PH :9790004273.

TINDIVARAM

2324. VISHNU CARS (SDI1-01), SURVEY NO. 50/4, 50/5 & 63, NEAR RTO OFFICE, MOLASUR, TINDIVANAM, VILUPPURAM,TAMILNADU - 604102 PH :9500039023.

TIRUPPUVANAM

2325. MEENAKSHI AUTO ZONE PVT LTD (SQZ1-01), NO:21,BAKHYA NAGAR, WARD NO:1, MANDAPAM MAIN ROAD, TIRUPPUVANAM, SIVAGANGA DISTRICT, TAMIL NADU - 630611 - 630611 PH :9442799581.

UTHIRAMERUR

2326. AIE CARS (SHG1-01), SURVEY NO:383/3B-B2, UTHIRAMERUR MAIN ROAD, UTHIRAMERUR, KANCHEEPURAM DISTRICT, TAMILNADU - 603406 PH :7290957387.

VELLAkOVL

2327. SRI CITI AUTO (SGO1-01), SURVEY NO:502/C &371/D, NO. 196,197,KOVAI KARUR MAIN ROAD, VELLAkOVL, TIRUPUR DIST. , TAMILNADU - 638111 PH :9994606000.

VENGAL

2328. VISHNU CARS PVT LTD (STC1-01), NEW SURVEY NO:67/1B, 67/20, CHINMAYA NAGAR,THAMARAIPAKKAM VILLAGE, VENGAL,THIRUVALLUR DIST., TAMILNADU- 601103 - 601103 PH :9500121559.

TELANGANA

ADILABAD

2329. ADARSHA AUTOMOTIVES PVT LTD (BTM1-01), SURVEY NO:131/6 & 131/7, NH-44, ADILABAD TOWN ROAD, MAVALA, ADILABAD, TELANGANA - 504001 PH :9133307724.

ARMUR

2330. VARUN MOTORS PVT. LTD. (BBN1-01), SURVEY NO.277, ARGUL VILLAGE, JAKARANPALLY (MANDAL), ARMUR, NIZAMABAD DISTT. (A.P.) - 503224 PH :90522901888.

BASARA

2331. ADARSHA (SSY1-01), URVEY NO 59/E, RAVINDRAPUR , BASARA, NIRMAL DISTRICT, TELANGANA - 504101 PH :8886092222.

BATCHUPALLY , HYDERABAD

2332. SAI SERVICE PRIVATE LIMITED (1011-09), SURVEY NO 499/1, MIYAPUR TO BACHUPALLY ROAD,BACHUPALLY, HYDERABAD. - 500090 PH :7330771111.

BELLAMPALLY

2333. ADARSHA AUTOMOTIVES (SJZ1-01), SURVEY NO 5/31, PEDANAPALLI, BELLAMPALLY, MANCHERIAL DISTRICT, TELANGANA - 504251 PH :8886092222.

BHDRAChALAM

2334. VARUN MOTORS (CLZ1-01), H-NO 1-138/1B-OLD SARPAKA ROAD, BHDRACHALAM, BHADRADIKOTHAGUDEM, TELANGANA - 507111 PH :9885576602.

BHUPALAPALLY

2335. ADARSHA AUTOMOTIVES PVT LTD (D502-04), 6-113, JAWAHAR NAGAR, MAIN ROAD, SBH MAIN BRANCH ROAD, BHUPALPALLY, DISTRICT - WARANGAL, ANDHRA PRADESH - 506169 PH :7799790526.

BODHAN

2336. VARUN MOTORS PVT. LTD. (Q801-01), PLOT NO. 5/2, ACHANAPALLY CROSS ROAD, BODHAN, DIST.-NIZAMABAD, TELANGANA. - 503 185 PH :9885576602, 9553714189.

CHEVELLA

2337. GEM MOTORS (INDIA) PVT. LTD. (CBL1-01), SURVEY NO. 17/A, MANDAL - CHEVELLA, DISTRICT – RANGA REDDY, TELANGANA. - 510101 PH :9912899128, 9912834567.

DUBBAK

2338. AADARSHA (-), ADARSHA AUTOMOTIVE PVT LTD. OPP. BUS DEPOT, BYPASS ROAD, SIDDIPET, TELANGANA - 502108 PH :9160746633.

ETUNAGARAM

2339. WIN MOTORS (SOJ1-01), H.NO 12-412 & 12-413,AKULAVARI GHANPUR, ETURNAGARAM, MULUGU DISTRICT,TELANGANA - 506165 PH :8688828005.

GADWAL

2340. SRI JAYARAMA MOTORS PVT. LTD. (WP01-02), PLOT NO. 5 & 6, BESIDE RURAL POLICE STATION, KURNool ROAD, MAHABUB NAGAR DISTRICT, ANDHRA PRADESH - 500125 PH :8096990074, 8096996671.

GAJWEL

2341. ACER MOTORS (A DIVISION OF KRISHNAIAH MOTORS PVT. LTD) (BYU1-01), SURVEY NO. 220, VILLAGE – PRAGNAYPUR, GAJWEL, DISTRICT – MEDAK, TELANGANA . - 502311 PH :888508080, 9849017827.
- GHATKESAR**
2342. ACER MOTORS (A DIVISION OF KRISHNAIAH MOTORS PVT. LTD) (BYL1-01), 3-21, JODIMETLA, CHOURA RIGID VILLAGE GHATKESAR MANDAL, DISTRICT – RANGA REDDY . - 501301 PH :8885080875, 9849017827.
- HUSNABAD**
2343. ADARSHA AUTOMOTIVES PVT LTD (GJE1-01), SURVEY NO. 20/2E, H. NO. 12-1/4 & 12-1/A, VILLAGE & MANDAL - HUSNABAD, DIST. - SIDDIPET, TELANGANA . - 505467 PH :8886092222, 7995835552.
- HYDERABAD**
2344. THE MITHRA AGENCIES (1002-01), 1-8-670, NEAR RTC CROSS ROAD, AZAMABAD INDUSTRIAL AREA, HYDERABAD . - 500020 PH :9966838294.
2345. RKS MOTORS PVT. LTD. (1003-01), SABOC TOWERS, RAJIBHAVAN ROAD, SOMAJIGUDA, HYDERABAD . - 500482 PH :0444544443, 9010811166.
2346. RKS MOTORS PVT. LTD. (1003-02), R-4/A,IDA BLOCK, INDUSTRIAL ESTATE,UPPAL, HYDERABAD . - 500039 PH :04023434504, 9010822210.
2347. VARUN MOTORS PVT. LTD. (4603-04), B-11 CO-OPERATIVE INDUSTRIAL ESTATE, BALANAGAR, HYDERABAD . - 500037 PH :9885208555, 9985745222.
2348. VARUN MOTORS PVT. LTD. (4603-08), ADITYA NAGAR COLONY, ADITYA NAGAR COLONY, TOLICHOWKI, SHAIKPET (VILLAGE), HYDERABAD, HYDERABAD . - 500008 PH :64551700, 8886114856.
2349. VARUN MOTORS PVT. LTD. (1010-01), PLOT NO. VI / VII A & B UNDER WARD NO. 10, AUTONAGAR, VANASTALIPURAM, HYDERABAD, R. R. DISTT . - 500070 PH :9885208555.
2350. VARUN MOTORS PVT. LTD. (4603-06), SHOP NO. 31, SRIKRUPA MARKET, D.NO. 16-10-1/F/31, MALAKAPET, HYDERABAD . - 500036 PH :4553396, 4547676, 9885093360.
2351. RKS MOTORS PVT. LTD. (1003-04), 16-11-19/5/C, SALEEM NAGAR COLONY,MALAKPET (NEAR FARHAT HOSPITAL),HYDERABAD . - 500036 PH :9010811192.
2352. THE MITHRA AGENCIES (1002-03), PLOT NO. 3-4-10,NEAR MADHAPUR POLICE STATION, MADHAPUR, HYDERABAD . - 500081 PH :04023113399 0423113388 9959912702.
2353. RKS MOTORS PVT. LTD. (1003-05), 11-6-191/192 OPP. HOTEL HARSHA,PUBLIC GARDEN ROAD, NAMPALLY, HYDERABAD . - 500001 PH :9848811158.
2354. VARUN MOTORS PVT. LTD. (4603-0A), 1-11-200,SHAMALA BUILDING BEGUMPET, HYDERABAD . - 500016 PH :9885206555.
2355. THE MITHRA AGENCIES (1002-04), 8-18-138, PLOT NO. 8,NEAR MARGADASRI CHIT FUND,L.B. NAGAR RING ROAD, RR DIST,HYDERABAD . - 500074 PH :9963551265.
2356. GEM MOTORS (INDIA) PVT. LTD. (1009-01), RAGHUVENDRA SOCIETY,KONDAPUR, HYDERABAD , ANDHRA PRADESH . - 500084 PH :9912899128.
2357. GEM MOTORS (INDIA) PVT. LTD. (1009-02), 2-11, SURVEY NO: 165,172,HYDERNAGAR, KUKATPALLY, HYDERABAD, ANDHRA PRADESH . - 500072 PH :9912344538.
2358. SAI SERVICE PRIVATE LIMITED (1011-01), PLOT NO. 88, INDUSTRIAL AREA,C.I.E. GANDHI NAGAR, ,BALANAGAR, HYDERABAD . - 500037 PH :9010822755.
2359. THE MITHRA AGENCIES (1002-05), PLOT NO. 19,20 & 21,ROAD NO.10,IDA NACHARAM, HYDERABAD . - 500076 PH :04021716999 0402177999 9963551261.
2360. VARUN MOTORS PVT. LTD. (1012-01), MARUTI AUTHORISED DEALER, SURVEY NO.115, IT PARK, NANAKRAMGUDA, GACHIBOWLI, HYDERABAD . - 500008 PH :9985104860, 69997979.
2361. RKS MOTORS PVT. LTD. (1003-08), D.NO.1-10-1/285/1, OPP. VEGETABLE MARKET, ECI CROSS ROADS, KUSAIGUDA, HYDERABAD . - 500062 PH :7799779810.
2362. SAI SERVICE PRIVATE LIMITED (1011-04), H.NO.16-2-83/10/1, SAIDABAD, L.B.NAGAR, HYDERABAD . - 500059 PH :7799352000.
2363. VARUN MOTORS PVT. LTD. (4603-0G), 1-10-28/1 SY. NO.285, KUSHAIQUDA, NEAR ECI X ROADS, HYDERABAD . - 500062 PH :7799600093.
2364. VARUN MOTORS PVT. LTD. (4603-0H), PLOT NO. 1354/1, ROAD NO. 1, NEAR IOC PETROL PUMP, JUBILEE HILLS, HYDERABAD, ANDHRA PRADESH . - 500033 PH :8886322776.
2365. VARUN MOTORS PVT. LTD. (4603-0J), PLOT NO. 1-45, SY.NO:1 TO 7, GOPINATH COMPLEX, TARANAGAR, LINGAMPALLY, HYDERABAD, RANGAREDDY DISTRICT , TELANGANA STATE . - 500019 PH :8886067847.
2366. SAI SERVICE PRIVATE LIMITED (1011-07), PLOT NO.B-21 & B-34, BHEL ANCILLARY INDUSTRIAL ESTATE, RAMACHANDRAPURM, HYDERABAD . - 502032 PH :9703811411.
2367. ADARSHA AUTOMOTIVES PVT LTD (1014-01), 18-245 NEAR FLYOVER, CHANDRAYANGUTTA "X" ROAD, HYDERBAD . - 500005 PH :8142326633.
2368. RKS MOTORS PVT. LTD. (1003-09), SURVEY NO.434, 5-15-33/19, BEHIND HUDA TRUCK PARKING, KUKATPALLY, DISTT: RANGAREDDY, HYDERABAD . - 500072 PH :9010811131.
2369. SAI SERVICE PRIVATE LIMITED (1011-08), DOOR NO.7-2-C3 & C34, INDUSTRIAL ESTATE, SANATH NAGAR, HYDERABAD . - 500018 PH :7799360003.
2370. KALYANI MOTORS PVT. LTD. (1018-01), PLOT NO. A-23 & A31/1, I.D.A. NACHARAM, HYDERABAD . - 500076 PH :9100114863.
2371. GEM MOTORS (INDIA) PVT. LTD. (1009-03), SURVEY NO. 135/A & 135/AA, MANIKONDA, RAJENDRA NAGAR MANDAL, RANGAREDDY DISTRICT, HYDERABAD, TELANGANA . - 500089 PH :9912341524.
2372. ADARSHA AUTOMOTIVES PVT LTD (1014-02), H. NO. 8-6/41, RUDRA COLONY, SHAMSHABAD, HYDERABAD . - 501218 PH :9603296633.
2373. JAYABHERI AUTOMOTIVES PVT. LTD. (1017-01), PLOT NO. 113, 114, 115 IN LUMBINI ENCLAVE CB SQUARE, VILLAGE – GACHIBOWLI, SHERLINGAMPALLY MNADAL, HYDERABAD, TELANGANA STATE . - 500032 PH :9100909401.
2374. JAYABHERI AUTOMOTIVES PVT. LTD. (1017-02), SURVEY NO.11/36, PLOT NO.32, 39 & 40, NEAR N CONVENTION CENTRE, KHANAMET, HYDERABAD, SHERLINGAMPALLY MANDAL, HYDERABAD . - 500081 PH :7799916666.
- Ibrahimpatnam**
2384. PAVAN MOTORS PVT. LTD. (CSF1-01), S.NO.123/E, MPP PATELGUDA, IBRAHIMPATNAM, RANGA REDDY . - 501506 PH :8790144499.
- JAGITAL**

Dealer Network (AS ON 31.10.2023)

2385. ADARSHA AUTOMOTIVES PVT LTD (N601-04),
HOUSE NO. 1-5-216/A,OPPOSITE TO KVA
SUBSTATION, KARIMNAGAR ROAD, JAGTIAL,-
505327
PH :8886152222.

JANGAON

2386. ADARSHA AUTOMOTIVES PVT LTD (K101-01),
H.NO.339, HYDERABAD ROAD, JANGAON. -
506167
PH :7799626633.

KAMAREDDY

2387. VARUN MOTORS PVT. LTD. (KX01-01),
H.NO.11-107/1, BESIDE:GURU RAGHAVENDRA
COLONY, CHINNA MALLAREDDY VILLAGE,
KAMAREDDY. - 503111
PH :9985557570.

KARIMNAGAR

2388. ADARSHA AUTOMOTIVES PVT LTD (N601-01),
H.NO. 8-313/1, HYDERABAD ROAD,BY-PASS
JUNCTION, KARIMNAGAR - 505001
PH :8886600315.

2389. ADARSHA AUTOMOTIVES PVT LTD (N601-05),
H.NO.8-6-301/18, BY-PASS ROAD, AUTONAGAR,
KARIM NAGAR, TELANGANA. - 505001
PH :8886152222.

2390. VARUN MOTORS PVT. LTD. (N603-01),
BEARING NO. 1-813/10/2, SURVEY NO. 221 &
222, REKURTHY VILLAGE,
KARIMNAGAR-JAGTIAL ROAD, KARIMNAGAR
MANDAL & DIST. , TELANGANA. - 505 001
PH :09133376762, 8886619373.

2391. VARUN MOTORS (N603-02), SURVEY NO.
277,278/B, AREPALLY VILLAGE,
TEEGALAGUTTAPALLI GRAM PANCHAYAT,
KARIMNAGAR - 505001
PH :9885210555.

KEESARA

2392. JAYABHERI AUTO (SEI1-01), H-NO 3-56/9/6A,
SURVEY NO 5,KEESARA,
MEDCHAL-MALKAJGIRI, TELANGANA - 501301
PH :9676076666.

KHAMMAM

2393. MITHRA AUTO AGENCIES PVT LTD (2604-02),
SURV NO. 182,WARANGAL ROAD, OPP. FCI
GODOWNS,PEDA THANDA,KHAMMAM - 507003
PH :8886063527.

KHANAPUR

2394. VARUN MOTORS (SND1-01), NO:14-10A, NEAR
SAI BABA TEMPLE, OPP. GIRLS HIGH SCHOOL,
VILL & MANDAL: KHANAPUR, DIST- NIRMAL -
504203
PH :8886619373.

KODAD

2395. PAVAN MOTORS PVT. LTD (BRP2-01), SURVEY
NO. 42, KOMARBANDA REVENUE LIMITED,
KODAD , DISTRICT - NALGONDA, TELANGANA -
508206
PH :8008899995.

KOLLAUPUR

2396. SRI JAYARAMA (SHC1-01), SURVEY NO
259/AA2, 259/E2,KOLLAUPUR, NAGAR KURNNOOL
DISTRICT, TELANGANA - 509102
PH :9985880015.

KOSGI

2397. JAYARAMA (-), SY. NO. 1798/B, KOSGI TOWN,
SITUATED TANDOR ROAD KOSGI(G.P &
MANDAL), NARAYANPET DIST, TELANGANA -
509339
PH :8096990069.

KOTHAGUDEM

2398. VARUN MOTORS PVT. LTD. (2603-04), DOOR
NO. 5-354/B,LAJKSHMIDAVI
PALLIBHADRACHALAM ROAD, KOTHAGUDEM
- 507101
PH :8297168222/9052549111.

LUXITTIPIET

2399. VARUN MOTORS (SFS1-01), SURVEY NO 289/E,
NEAR BY SSI GARDENS,LUXETTIPIET,
MANCHERIAL DISTRICT, TELANGANA - 504215
PH :8297848999.

MAHABUBABAD

2400. ADARSHA AUTOMOTIVES PVT LTD (CQS1-01),
SY. NO.38/A, MAHBUBABAD REVENUE VILLAGE
AND MANDAL, MAHBUBABAD. - 506101
PH :9177746333, 7797700525.

MAHABUBNAGAR

2401. SRI JAYARAMA MOTORS PVT. LTD. (WP01-01),
PLOT NO.C1 & C2, INDUSTRIAL ESTATE,
METTUGADA, MEHBOOBNAGAR - 504001
PH :8096998846.

MAHESHWARAM

2402. ADARSHA AUTOMOTIVES PVT LTD (CQR1-01),
(BEARING #5-187, SURVEY NO.:336/A/1, VILLAGE
& MANDAL: MAHESHWARAM DISTT. RANGA
REDDY . - 501359
PH :8142326633, 9703152222.

MANCHEERIAL

2403. ADARSHA AUTOMOTIVES PVT LTD (N601-03),
BEHIND MAHINDRA TRACTORS
SHOWROOM,BEDDAPALLY ROAD,
MANCHIRIAL , DISTT. ADILABAD - 504208
PH :8886302222.

MANTHANI

2404. VARUN MOTORS (SHS1-01), SURVEY NO 1018,
H NO 16-4/D2, PLOT NO 5, LAINGADDA STREET,
MANTHANI . - 505184
PH :8886619373.

MEDAK

2405. VARUN MOTORS PVT. LTD. (KF01-01),
SY.NO.1486/A3, HYDERABAD ROAD, MEDAK
(MDL & TOWN) - 502110
PH :9154953337.

MEDCHAL

2406. AUTOFIN LIMITED (CID1-01), H. NO. 11-27/1,
SURVEY NO.401, MEDCHAL VILLAGE AND
MANDAL, DIST. - MEDCHAL. - 501401
PH :8885040020.

METAPALLY

2407. ADARSHA (BJF1-01), SURVEY NO. 40/U2
CHOULAMADHI, METPALLY PIN CODE 505325 -
505325
PH :8886092222.

MIRYALGUDA

2408. PAVAN MOTORS PVT. LTD (WR01-01), SURVEY
NO 940 &943, (OPPOSITE TO MINA
ENGINEERING COLLEGE) KARPETTALY
ADDANKI BY-PASS ROAD,MIRYALGUDA
.NALGONDA DISTRICT,ANDHRA PRADESH -
508207
PH :8790900399.

MOINABAD

2409. GEM MOTORS (INDIA) PVT. LTD. (CFN1-01),
SURVEY NO. 70, PLOT NO. 4, VILLAGE AND
GRAM PANCHAYAT - HIMAYATH NAGAR,
MANDAL - MOINABAD, DISTRICT - RANGA
REDDY . - 500075
PH :9912899128, 7997994845.

NAGARKURNOOL

2410. SRI JAYARAMA MOTORS PVT. LTD. (EV01-01),
SURVEY NO.4/A AND 45/A, UYYALWADA
VILLAGE, NAGARKURNOOL, TELANGANA -
509209
PH :8096990704.

NALGONDA

2411. PAVAN MOTORS PVT. LTD (AN01-01),
CHERALPALLY VILLAGE, NALGONDA ROAD,
NALCONDA - 508001
PH :247998790344499.

NARAYANKHED

2412. VARUN MOTORS PVT. LTD (CGI1-01), D. NO.
1-6-11/25/B/5/A/1, SY NO. 5/2, BHUMAN
COLONY, GRAM PANCHAYAT & MANDAL -
NARAYANKHED, DISTRICT - MEDAK,
TELANGANA . - 502286
PH :9885201055.

NARAYANPET

2413. SRI JAYARAMA MOTORS PVT. LTD. (BPG1-01),
SURVEY NO. 4684, MAHABUBNAGAR ROAD,
NARAYANPET TOWN, DIST.-MAHABUBNAGAR,
STATE - TELANGANA . - 509210
PH :8096997701, 7893177448.

NARSAPUR

2414. KALYANI MOTORS PVT. LTD. (SCX1-01-),
SURVEY NO 66, BLOCK
NO-19,NARSAPUR,DISTRICT:MEDAK,
TELANGANA . - 534275
PH :9100067766.

NIRMAL

2415. ADARSHA AUTOMOTIVES PVT LTD (N601-02-),
H. NO. 1-1-131, SHASTRINAGAR, MANCHIRIAL
ROAD, DIST. ADILABAD, NIRMAL - 504106
PH :8886342222.

NIZAMABAD

2416. VARUN MOTORS PVT. LTD. (1H02-01-), PLOT
NO. GP 1-57/4/1,PANGARA
BORGOAN,NIZAMABAD - 503230
PH :8297848999, 9052080444.

PALWANCHIA

2417. VARUN MOTORS PVT. LTD. (HF01-01-), SURVEY
NO.758 & 757, NEHRU NAGAR, PALWANCHIA
(NEW POLANCHA) MANDAL & TOWN,
BHADRADRI KOTHAGUDEM DISTT.,
TELANGANA . - 507115
PH :8297163222.

PARGI

2418. VARUN MOTORS PVT. LTD. (CBO1-01-), HOUSE
NO. 2-356 JANGAIAH COMPLEX, SURVEY NO.
217/EE4, JAYANTHI NAGAR COLONY, MANDAL -
PARGI, DISTRICT - RANGA REDDY . - 510501
PH :988521055, 9885200000.

PARKAL

2419. ADARSHA (SEK1-01-), SY.NO 946, H.NO 5-27,
VIKAS NAGAR, PARKAL,WARANGAL . - 506164
PH :8886742222.

PEDAPALLY

2420. ADARSHA AUTOMOTIVES PVT LTD (GKN1-01-),
SURVEY NO 142, H NO 185, RANGAMPALLI
VILLAGE, PEDDAPALLY , TELANGANA - 505172
PH :888618155, 8886672222.

RAMAGUNDAM

2421. ADARSHA AUTOMOTIVES PVT LTD (BGA1-01-),
5-6-172 SURVEY NO . - 259/B, MEDIPALLY
SHIVAR, RAMAGUNDAM MUNICIPALITY,
DISTRICT - KARIM NAGAR, ANDHRA PRADESH
- 505209
PH :8886144550.

RAMAYAMPET

2422. VARUN MOTORS PVT. LTD. (CDO1-01-),
SURVEY NO. 1626 & 1626/2 SITUATED AT
BLOCK NO. 16, RAMAYAMPET, DISTRICT -
MEDAK . - 502101
PH :9885208555, 9703803399.

SADHASHIVPET

2423. SAI SERVICE (SFQ1-01), PLOT NO. 2, SY NO. 974, GURUNAGAR COLONY, OLD BOMBAY HIGHWAY ROAD, SADASHIVPET, SANGAREDDY DIST. 502291. - 502291 PH :9966377888.
- SANGAREDDY**
2424. SAI SERVICE PRIVATE LIMITED (1011-05), H.NO.4-8-92/14/5, AHMED NAGAR, OPP.GOVT.ITAL, SANGAREDDY, MEDAK (DIST), ANDHRA PRADESH - 502001 PH :766181000.
- SATUPALLI**
2425. MITHRA AUTO AGENCIES PVT LTD (SHD1-01), SURVEY NO. 75 NEAR VIVEKANANDA STATUE,SATHUPALLI, KHAMMAM. - 507303 PH :984898312.
- SECUNDERABAD**
2426. ACER MOTORS (A DIVISION OF KRISHNAIAH MOTORS PVT. LTD) (K601-01), A1, MOTI VALLEY,TRIMULGHERRY,SECUNDERABAD. - 500015 PH :040 44554747, 8885080800.
2427. AUTOFIN LIMITED (K606-01), SURVEY NO. 33, MEDCAL ROAD, BOWENPALLY, SECUNDERABAD - 500011 PH :8885040130.
2428. VARUN MOTORS PVT. LTD. (4603-01), 1-10-176/1, BEHIND VARUN TOWERS-I, OPP. HYDERABAD PUBLIC SCHOOL, BEGUMPET, SECUNDERABAD, HYDERABAD, TELANGANA STATE. - 500016 PH :998552425.
2429. RKS MOTORS PVT. LTD (K605-01), PLOT NO. 207, TABBUND, SECUNDERABAD. - 500009 PH :9010801004.
2430. AUTOFIN LIMITED (K606-02), SURVEY NO. 177B & 178/C SITUATED AT VILLAGE - KOMPALY, MANDAL - QUTHUBULLAPUR, HYDERABAD. - 500090 PH :8885040126.
2431. PAVAN MOTORS PVT. LTD (K608-02), PLOT NO. 1-12, 749, 750, SURVEY NO. 751/2, VENKATADRI NAGAR, NEW MIRJALGUDA, MALKAJIGIRI, SECUNDERABAD, TELANGANA - 500047 PH :9121293690.
- SHAD NAGAR**
2432. SRI JAYARAMA MOTORS (P) LTD. (WS01-01), SURVEY NO.445, FAROOQ NAGAR, SHADNAGAR, MAHABUB NAGAR DISTT. ANDHRA PRADESH. - 500216 PH :8096996671.
- SHAMIRPET**
2433. RKS MOTOR PVT. LTD. (SDE1-01), SHED NO 2-242, MAJEEDPUR CROSS ROADS,SHAMIRPET, MEDCAL-MALKAJIGIRI,TELANGANA - 500078 PH :9848866618.
- SHANKARPALLY**
2434. SAI SERVICE PRIVATE LIMITED (CEX1-01), SURVEY NO. 203, HYDERABAD ROAD OPP. SM FUNCTION HALL ROAD, SHANKARPALLY, RANGA REDDY DISTT. - 501203 PH :9966377888, 9912899128, 9703811011.
- SIDDIPET**
2435. ADARSHA AUTOMOTIVES PVT LTD (CAL1-01), SURVEY 197/A, VILLAGE - PONNALA, SIDDIPET, DISTRICT - MEDAK, TELANGANA. - 502103 PH :09703716633, 9160746633.
- SIRCILLA**
2436. ADARSHA AUTOMOTIVES PVT LTD (BYW1-01), H. NO. 10-1-72, 10-1-73, 10-1-73/A1, KARIMNAGAR ROAD, SIRCILLA, DISTRICT - KARIMNAGAR, TELANGANA - 505301 PH :8886618185, 8142244131.
- SURYAPET**
2437. PAVAN MOTORS PVT. LTD (BLC1-01), SURVEY NO. 493, THALLAGADDA, SURYAPET MANDAL, NALGONDA DISTRICT, ANDHRA PRADESH. - 508213 PH :800899995, 27502750.
- TALLADA**
2438. MITHRA AUTO (SOU1-01), SURVEY NO 890/A, D.NO 7-8, NARAYANAPURAM, TALLADA, TELANGANA - 507167 PH :984898312.
- TANDUR**
2439. VARUN MOTORS PVT. LTD. (CFR1-01), H. NO. 2-1-203, 2-1-203/A & 2-1-209, PLOT NO. 45, 46, 47, SURVEY NO. 57 OF MALREDDPALLY VILLAGE, TANDUR MUNICIPALITY, VIKARABAD DISTRICT, TELANGANA - 501141 PH :8886619370.
- THORRUR**
2440. ADARSHA AUTOMOTIVES PVT LTD (BYV1-01), SURVEY NO.1 TO 5, BEARING M. NO.4-153/1, VILLAGE & MANDAL THORRUR DISTT. WARANGAL - 506163 PH :9059438007, 7799790527.
- TOOPRAN**
2441. ADARSHA (SEJ1-01), PLOT NO 7&8, SY NO 185,184,179U, NAGULAPALLY VILLAGE,TOOPRAN MANDAL,TELANGANA STATE: TELANGANA CITY: TOOPRAN PIN : 502334 CITY CATEG-O :502334 PH :921859954.
- UTNOOR**
2442. ADARSHA AUTOMOBILES (SEG1-01), OPP., KB COMPLEX, UTNOOR, DIST-ADILABAD - 504311 PH :7075792221.
- VIKARABAD**
2443. GEM MOTORS (INDIA) PVT. LTD. (BYM1-01), SHOP NO. 3-2-93/2, VILLAGE - YENNAPALLY, VIKARABAD MUNICIPALITY, VIKARABAD, DISTRICT - RANGA REDDY, TELANGANA. - 501101 PH :9912349840.
- WANAPARTHY**
2444. SRI JAYARAMA MOTORS (P) LTD. (WQ01-01), SURVEY NO.1149, KURNool ROAD, WANAPARTHY (A.P.) - 509103 PH :8096903879.
- WARANGAL**
2445. ADARSHA AUTOMOTIVES PVT LTD (D502-02), PLOT NO.10, INDUSTRIAL AREA, MULUGU ROAD, WARRANGAL - 506007 PH :8886132222.
2446. ADARSHA AUTOMOTIVES PVT LTD (D502-03), OPPOSITE TO ORUGALLU FILLING STATION, HUNAMKONDA, WARANGAL - 506001 PH :888649222.
2447. WIN MOTORS (A UNIT OF BHADRAKALI AUTOCARE PVT. LTD) (D503-01), SURVEY NO. 16, 16/A & 16/B, OPPOSITE KAKATIYA UNIVERSITY GATE-2, LASHKERSINGARAM REVENUE VILLAGE, HANAMKONDA MANDAL, WARANGAL - 506 001 PH :8688828010.
2448. WIN MOTORS (A UNIT OF BHADRAKALI AUTOCARE PVT. LTD) (D503-02), PLOT NUMBER 9,10,11 & 13/A, SURVEY NUMBER 148/A&B OF BHEEMRAM VILLAGE, WARANGAL. - 506015 PH :8688828015.
- ZAHIRABAD**
2449. SAI SERVICE PRIVATE LIMITED (BAT1-01), PLOT NO-5,NEAR IBP PETROL BUNK, NH-9,ALIPUR,ZAHIRABAD,MEDAK (DIST),ANDHRA PRADESH - 502220 PH :766000206.
- TELENGANA**
- KAGHAZNAGAR**
2450. ADARSHA AUTOMOTIVES (SCN1-01), H.NO :1-61/3,BORIGAON,KAGHAZNAGAR,KOMARAMB HEEM - 504296 PH :8886092222.
- PALAKURTHY**
2451. WIN MOTORS (SCY1-01), SURVEY NO 537/B,MANA RAOD, PALAKURTHY,JANGAON DISTRICT,TELANGANA. - 506317 PH :8688838005.
- TRIPURA**
- AGARTALA**
2452. JAIN UDYOG (6901-01), ARUNDHUTI NAGAR, OPP. INDUSTRIAL ESTATE, AGARTALA - 799003 PH :9862149275.
2453. JAIN UDYOG (6901-05), 58-B/C, INDUSTRIAL AREA ARUNDHUTI NAGAR, AGARTALA. - 799003 PH :70075 71216.
2454. JAIN UDYOG (6901-06), KHATIAN NO. 1843, MOLIA & TEHSIL - KHAYERPUR, JIRANIA SUBDIVISION, AGARTALA - 799008 PH :97746 16831.
2455. PALLAVI MOTORS (6902-01), 44 NH ROAD, DAG NO. 495, DAG NO. 1748, DAG NO. 867, POST OFFICE KHERPUR, AGARTALA (TRIPURA) - 799008 PH :9864052488.
- AMARPUR**
2456. JAIN UDYOG (CVR1-01), NEAR MOTOR STAND, AMARPUR,TRIPURA - 799101 PH :97748 45751.
- AMBASSA**
2457. JAIN UDYOG (CDT1-01), A.A. ROAD, OPPOSITE OF CHANDRI PARA HS SCHOOL, AMBASSA, DHALAI, TRIPURA. - 799289 PH :70052 88437.
- DHARMANAGAR**
2458. JAIN UDYOG (6901-03), DHARMANAGAR COLLEGE ROAD, DHARMANAGAR, TRIPURA(NORTH). - 799250 PH :97747 93164.
- UDAIPUR**
2459. JAIN UDYOG (YU01-01), DHWAJANAGAR INDUSTRIAL ESTATE,UDAIPUR,TRIPURA (SOUTH) - 799116 PH :9774020152.

UP**GREATER NOIDA**

2460. VIPUL MOTORS (T202-01), PLOT NO. 64, ECOTECH 12, GREATER NOIDA (WEST), UP. - 201009 PH :9811233385.

UTTAR PRADESH**AGRA**

2461. MADHUSUDAN MOTORS PVT LTD (6603-01), B-5 LAWYERS COLONY, BYE PASS ROAD, AGRA - 282005 PH :531102-05.
2462. MADHUSUDAN MOTORS PVT LTD (6603-02), GANESHGANJ, PRATAPPURA, AGRA - 282001 PH :9837097887.
2463. MADHUSUDAN MOTORS PVT LTD (6603-03), 6-A, VIBHAV INDUSTRIAL STATE, AGRA - 282007 PH :3299221.

Dealer Network (AS ON 31.10.2023)

2464. MADHUSUDAN MOTORS PVT LTD (6603-04),
26/253, SULTAN GANI KI PULIA, MAUZA
LASKARPUR - AGRA - 283203
PH :9837097894.
2465. KTL PVT. LTD. (6606-01), MUGHAL ROAD,
KAMLA NAGAR, AGRA - 282004
PH :3449715033, 8449715099.
2466. PREM MOTORS PVT. LTD. (6607-01-45),
OPPOSITE AGRA COLLEGE, GOKULPURA,
AGRA, UTTAR PRADESH - 282002
PH :9690010799.
2467. KTL PVT. LTD. (6608-02-), KHASRA NO. 171,
SEWLA JAT, GWALIOR ROAD, AGRA, UTTAR
PRADESH - 282001
PH :8449715099.
2468. MERAK VEHICLES (6609-01-), KHASRA NO 65 &
74, MAUZA MOHAMMADPUR, AGRA-DELHI
ROAD (NH-2), SIKANDRA, AGRA UTTAR
PRADESH-282007. - 282007
PH :9690486139.
- AKBARPUR**
2469. KTL PVT. LTD. (2801-03-), KANPUR ROAD,
AKBARPUR - 209206
PH :7408409348.
2470. SMARTWHEELS PVT. LTD. (7201-08-), TANDA
ROAD, VILL-BUDHAEEPUR, PO-KATRIYA
YAKOOPUR, AKBARPUR, DIST-AMBEDKAR
NAGAR (U.P.) - 224122
PH :7705803248.
- ALIGARH**
2471. DEV MOTORS (P) LTD (B601-01-), NEAR BANNA
DEVI, G.T.ROAD, ALIGARH - 202001
PH :521771.
2472. DEV MOTORS (B601-04-), PLOT NO 97, VILLAGE
SIKANDERPUR, BHUKRALI, GT ROAD BYE
PASS, ALIGARH - 202002
PH :7351345577.
- ALLAHABAD**
2473. AMITDEEP MOTORS (2901-01-), 26 SULEM
SARAI, G.T ROAD, ALLAHABAD - 211001
PH :8948122749, 9026111339, 7738555692,
9839890333, 9936413399.
- AMETHI**
2474. KTL AUTOMOBILE PVT. LTD. (BBB2-01-), PLOT
NO - E 32, INDUSTRIAL AREA TEKARIA,
UPSIDC, GAURIGANJ, DIST: C.S.M.NAGAR -
227409
PH :7379557377.
- AMROHA**
2475. AKANKSHA AUTOMOBILES PVT. LTD.
(A001-01-), AMROHA - JOYA ROAD, NEAR
PUNJAB NATIONAL BANK, AMROHA, UTTAR
PRADESH, PIN CODE: 244221 - 244221
PH :7247800064.
- ANPARA**
2476. STAR CARS (A UNIT OF SARASWATI VEHICLES
LLP) (NJ02-01-), KAHWA NALA, AURI-BINA
ROAD, AURI ANPARA, DISTRICT -
SONEPHADRA - 232101
PH :7052547903, 971905002, 9151154306,
9450544961.
- ANUPSHahr**
2477. SK UNIVERSE (SI01-01-), KHASRA NO. 341,
BULANDSHahr ROAD, ANOPOSHahr, DIST.
BULANSHahr, PIN-203390, UTTAR PRADESH -
203390
PH :7055118430.
- ONOLA**
2478. KAVISHA MOTORS PVT LTD (CVI1-01-),
COMMERCIAL PLOT, RAN NAGAR ROAD, NEAR
MUNICIPALITY OFFICE, TEHSIL - AONLA, DIST.,
BAREILLY, STATE: UTTAR PRADESH. - 243301
PH :07895980222, 07895980300.
- AURAI**
2479. VARANASI MOTORS PVT LTD (CBM1-01-),
KHATA / KHATANI NO. 0045, GT ROAD (EHAK
BHaura), OPP. CHINI MILL, VILLAGE & TEHSIL
AURAI, DISTT: BHADOHI, UTTAPRadesh, PIN
2221 301 - 2221301
PH :9838360662, 7617007276.
- AURAIYA**
2480. KULDEEP MOTORS (QJ01-01-), NEAR INDIAN
OIL TIRAH, KANPUR ROAD, AURAIYA. - 206241
PH :9235358444.
- AYODHYA (FAIZABAD)**
2481. SMART WHEELS (7201-03-), GHATAMPUR
MAGALSI, OPP TRIMURTI HOTEL, TEHSIL
SOHAWAL, FAIZABAD, UTTAR PRADESH -
224001
PH :7705800602.
- ZAMGARH**
2482. DEEP MOTORS (K501-01-), HARBANSHPUR
NARAILA, AZAMGARH - 276001
PH :9838072905.
- BABRALA**
2483. AKANKSHA AUTOMOBILES PVT. LTD.
(SJU1-01-), CHANDAUSI ROAD, BABRALA,
DISTRICT SAMBAL, UTTAR PRADESH. - 243751
PH :7895600005.
- BACHRAWAN**
2484. KTL AUTOMOBILE PVT. LTD. (CGX2-01-),
VISHNUPUR, PHARWAN,
RAEBARELI-LUCKNOW ROAD, DIST.
-RAEBARELI. - 229301
PH :9918451222.
- BAH**
2476. STAR CARS (A UNIT OF SARASWATI VEHICLES
LLP) (NJ02-01-), KAHWA NALA, AURI-BINA
ROAD, AURI ANPARA, DISTRICT -
SONEPHADRA - 232101
PH :7052547903, 971905002, 9151154306,
9450544961.
2485. KTL PVT. LTD. (CHI1-01-), 16B, DHOBAIR,
VILLAGE - BAH, DIST.-AGRA, UTTAR PRADESH.
- 283104
PH :705707169, 8449715033.
- BAHERI**
2486. KAVISHA MOTORS PVT LTD (BSB1-01-), KASRA
NO. 530, 531, 532, 533, NAINITAL ROAD, OPP.
RAMLILA GROUND, BAHERI, DISTRICT -
BAREILLY, UTTAR PRADESH - 243201
PH :8756000000, 7607696666.
- BAHRAICH**
2487. ANAND MOTORS AGENCIES LTD (1301-05-),
LUCKNOW ROAD, BEHRAICH, UTTAR PRADESH -
271801
PH :9519596080.
- BALLIA**
2488. DEEP MOTORS (K501-03-), MAIDEYPUR,
RAJDHANI ROAD, BALLIA - 277001
PH :9838072917.
- BALRAMPUR**
2489. ANAND MOTORS AGENCIES LTD (XB01-01-),
NEAR BALRAMPUR CHINI MILLS, GONDA
ROAD, BALRAMPUR-UTTAR PRADESH - 271201
PH :6307995976.
- BANDA**
2490. MY CAR PVT. LTD. (2803-03-), KALUKUAN,
TINDWARI ROAD, BANDA - 210001
PH :9792971223.
2491. SUMITRA DS MOTORS (SPB1-01-), PURANPUR
ROAD, BANDA, TEHSIL BANDA, THANA BANDA,
DISTT. SHAHJAHANPUR - U.P. - 242042
PH :9336408074.
- BANSI**
2492. ARBIT AUTOMOBILES PVT LTD (GMD1-01-),
KHASRA NO. 66 M, GRAM: BHAWNI, TAPPA:
KUNDARANA, PARGANA: BANSI EAST, TEHSIL
BANSI, DISTT : SIDARTHNAGAR - 272153
PH :89534 12821.
- BANTHRA**
2493. MEGA MOTORS (SGQ1-01-), KHASRA NO.1628
AMARPUR, SIKANDARPUR MARKET, BANTHRA,
KANPUR ROAD LUCKNOW - 226401
PH :9919101456.
- BARABANKI**
2494. BRIGHT 4 WHEEL SALES PVT. LTD. (1305-03-),
VILL. DHARANSIA, LUCKNOW ROAD,
NAWABGANJ, BARABANKI - 225001
PH :9838075960.
- BARAUT**
2495. TANYA AUTOMOBILES (LL02-01-), 240/2
SHAHPUR-BADOLI, DELHI SAHARANPUR ROAD,
BARAUT, BAGHPAT, UTTAR PRADESH. - 250611
PH :7055300019.
- BAREILLY**
2496. CORAL MOTORS (P) LTD. (5602-01-), STATION
ROAD, BAREILLY - 243001
PH :559191.
2497. CORAL MOTORS (P) LTD. (5602-03-), PILIBHIT
BYE PASS ROAD, EXECUTIVE CLUB CROSSING,
BAREILLY, UTTAR PRADESH - 243002
PH :0581-2554922.
2498. KAVISHA MOTORS PVT LTD (5601-01-), 4TH KM
RAMPUR ROAD, CLUTTER BUCKGANJ,
BAREILLY - 243502
PH :8756000000, 7607696666.
2499. ETERNITY MOTORS LLP (5603-01-), KHASRA
NO. 803/2, PILIBHIT BYPASS ROAD, PEER
BAHORA, OPP, FUN CITY, BAREILLY, UTTAR
PRADESH. - 243001
PH :9105555746.
- BASTI**
2500. SMARTWHEELS PVT. LTD. (7201-05-), MANORI
CHAURAHAA, DUMARIYA GANJ ROAD, BASTI -
270002
PH :286294.
2501. ARBIT AUTOMOBILES (7203-03-), SANSARPUR
FUTAHA POST GANDHI NAGAR DISTRCT
BASTI UTTAR PRADESH - 271282
PH :8953412821.
- BEHTA**
2502. MEGA MOTORS (A UNIT OF AKM MOTORS PVT.
LTD) (GM1-01-), KHASRA NO. 254, OPPOSITE
SANGAM MOTORS, KURSI ROAD, BEHTA -
226026
PH :6388901514.
- BHADOHI**
2503. VARANASI MOTORS PVT. LTD. (8402-02-),
VARNASI ROAD, BHADOHI - 221401
PH :9838360662.
- BHINGA**
2504. ANAND MOTORS (BVG1-01-),
PATNAKHGaura, BHINGA, SHRAVASTI -
271831
PH :9415013059.
- BHOJPUR**
2505. MOTORCRAFT SALES INDIA PVT LTD
(SD01-01-), OPPOSITE PRIMARY GOVERNMENT
SCHOOL, HAPUR ROAD, VILLAGE BHOJPUR,
TEHSIL - MODINAGAR, DISTRICT - GHAZIABAD.
- 201204
PH :9410038456.
- BIJNOR**
2506. SHAKUMBARI AUTOMOBILES (P) LTD
(6D01-01-), PLOT & KHASRA NO. 25/3 & 25/1
ADJACENT KHEDI CHAURAHAA, NEAR PULKIT
HOSPITAL, DELHI-BIJNOR HIGHWAY, BIJNOR,
DIST. - BIJNOR, UTTAR PRADESH. - 246701
PH :8630881409.
- BILARI**

2507. AKANKSHA AUTOMOBILES PVT. LTD.
(SDM1-01), 2KM-BILARI NH 509, NEAR SBS SCHOOL, BILARI, MORADABAD - 244001 - 244001 PH :7900600008.
- BILASPUR**
2508. AKANKSHA AUTOMOBILES PVT. LTD.
(BCN1-01), NH-87 ,OPPOSITE SHAGUN BANQUET HALL, NEAR MILTON ACADEMY SCHOOL, RAMPUR NAINITAL ROAD, BILASPUR, DISTRICT – RAMPUR. - 244921 PH :9105370007.
- BISALPUR**
2509. CORAL MOTORS PVT LTD (CXB1-01), KHASRA NO. 668, VILLAGE :BISALPUR, DISTT: PILIBHIT, UTTAR PRADESH - 262201 PH :9837891846.
- BISWAN**
2510. CONCEPT CARS LIMITED (SEW1-01-), BILIHARIYA, OPPOSITE-555, BRICK FIELD, BISWAN - 261201 - 261201 PH :7607696666.
- BUUDA**
2511. CORAL MOTORS (P) LTD. (5602-04), PLOT NO. 72, BAREILLY-MATHURA HIGHWAY, BUDAUN, UTTAR PRADESH - 132103 PH :9837891846.
- BULANDSHAHAR**
2512. SK UNIVERSE (M502-02), KHASRA NO.2261, NEAR T POINT , BYPASS SIKARPUR ROAD ,BULANDSHAHAR - 203001 PH :7055118430.
- BULANDSHAHAR**
2513. SK UNIVERSE (M502-01), KHASRA NO 561 , BHOOR, OPP PANDIT PETROL PUMP , BULANSHAHAR - 203001 PH :8919694600.
- CHAKIA**
2514. STAR CARS (A UNIT OF SARASWATI VEHICLES LLP) (CJH1-01), KATHSILA NAHER, NEAR SAINT JOHN'S SCHOOL CHAKIA, DISTRICT – CHANDAULI - 232101 PH :9450544961.
- CHANDAUSI**
2515. AKANKSHA AUTOMOBILES PVT. LTD.
(XA01-01), AZAD ROAD, NEAR ROADWAYS, CHANDAUSI (BHEEM NAGAR) - 202412 PH :7248000002.
- CHAURI CHAURA**
2516. ARBIT AUTOMOBILES (SIR1-01), ARAZI NO 561 DOMARI KHURD, CHAURI CHAURA, GORAKHPUR - 273201 PH :8953412821.
- CHIRASENPUR**
2517. KTL PVT. LTD. (BMY1-01), PLOT GHATA NO. 70, MAUJA - LALAKPUR, VILLAGE - CHIRASENPUR, DIST - KANNAUJ, UTTAR PRADES. - 209721 PH :7408409200, 9414113666.
- DALMAU**
2519. KTL AUTOMOBIELS (SGZ1-01), DALMAU ROAD, OPPOSITE BHAGIRATHI GUEST HOUSE - 229203 PH :9918451222.
- DANKAUR**
2520. MOTORCRAFT SALES (HG01-01), OPP. SHRI DRONACHARYA DEGREE COLLEGE, DANKAUR, DIST. - GAUTAM BUDH NAGAR, HARYANA. - 203201 PH :9810289355.
- DEOBAND**
2521. ATELIER AUTOMOBILES (XK02-01), OPPOSITE CIVIL COURT, MUZZAFARNAGAR HIGHWAY, DEOBAND - 247001 PH :7500220011.
- DEORIA**
2522. SMARTWHEELS PVT. LTD. (M601-01), PLOT NO. C-7, AND SHED NO. D-3, GOVERNMENT INDUSTRIAL ESTATE MEHRA, DEORIA, DIST. -DEORIA, UTTAR PRADESH. - 274001 PH :7705800602.
2523. ARBIT AUTOMOBILES (M602-01), ARAZI NO 467 MI & 607 MAJUA SONUGHAT PARGANA SALEMPUR MAJHAULI, DEORIA, UTTAR PRADESH - 274001 PH :8953412821.
- DHAMPUR**
2524. SHAKUMBARI AUTOMOBILES (P) LTD
(CPQ1-01), KHASRA NO. 205, OPPOSITE, UHSA SMARAK SCHOOL, MORADABAD ROAD, TEHSIL -DHAMPUR, MOJA - ALEHPUR, DIST-BIJNOR, UTTAR PRADESH. - 246761 PH :9675970960.
- DIBYAPUR**
2525. KULDEEP MOTORS (SLA1-01), AURAIYYA ROAD, DIBYAPUR - 206244 PH :9235258425.
- DOMARIAGANJ**
2526. SMARTWHEELS (SMW1-01), VILL & POST – CHAUHAKARA, DOMARIAGANJ, DISTT – SIDDHARTH NAGAR - 272193 PH :7705800602.
- ETAH**
2518. AGR (SMM1-01), KHASRA NO-194, CHITRASENPUR, KACHHUWA ROAD, VARANASI, PIN -221313 - 221313 PH :9889803355.
- ETAWAH**
2528. DEV MOTORS (XG02-01), GATA NO 685/4 VILL GIRORA, ETAH-KASGANJ ROAD, ETAH, UP - 207001 PH :7351345577.
- FAIZABAD**
2530. SMARTWHEELS PVT. LTD. (7201-02), SAHADAT GANJ, LUCKNOW ROAD, FAIZABAD, UTTAR PRADESH - 224001 PH :7705803245.
- FAKHARPUR**
2531. ONE UP (SRT1-01), GHASIPUR, FAKHARPUR, RAIBAHR (UP) - 271902 PH :9395275786.
- FARIDPUR**
2532. KAVISHA MOTORS PVT LTD (CEM1-01), GATE NO. 216, KASBAA SARAI, TEHSIL – FARIDPUR, DISTRICT – BAREILLY, UTTAR PRADESH. - 243503 PH :07895980222, 07895980300.
- FARRUKHBAD**
2533. MY CAR PVT. LTD. (2803-04), NEKPUR KALAN, FARRUKHBAD - 209625 PH :9792970093.
- FATEHABAD**
2534. KTL PVT. LTD. (BLQ1-01), KHASRA NO. 730/731, GRAM MAJUA, MADAYNA SKRARA MODE, FATEHABAD, DISTRICT - AGRA, UTTAR PRADESH - 283111 PH :8449710051.
- FATEHPUR**
2535. KTL PVT. LTD. (2901-04), NH-2, OPP. RTO OFFICE, KANPUR ROAD, FATEHPUR - 212601 PH :7408409383, 7408400000.
- FEROZABAD**
2536. MADHUSUDAN VEHICLES PRIVATE LTD.
(DF01-01), 746, ALI NAGAR KEJRA , NEAR RAJA KA TAL CROSSING, NH 2, FEROZABAD - 283203 PH :9690003077.
- GAJRAULA**
2537. AKANKSHA AUTOMOBILES PVT. LTD.
(XD01-01), JHANAKPUR OPPPOSITE RELIANCE PETROL PUMP, DELHI ROAD, GAJRAULA - 244235 PH :7895400003.
- GAZIABAD**
2538. ROHAN MOTORS LTD. (5904-01), 432 MUKAND NAGAR, G.T.ROAD, GHAZIABAD - 201001 PH :9971466644, 011-204170810, +911204170816, +911204170826, +911204170819.
2539. REGENT AUTOLINKS (P) LTD (5902-01), A-10/9 INDUSTRIAL AREA, SITE NO 3, MEERUT ROAD, GHAZIABAD - 201001 PH :0120-641900,904,911,8744042111,9999740464,9 71127008.
2540. ROHAN MOTORS (5904-02), PLOT NO.46, MEERUT-DELHI ROAD, MORTA, GHAZIABAD - 201102 PH :09310404354 , 9971466644.
2541. T.R. SAWHNEY MOTORS PVT LTD (5905-01), PLOT NO. 96, RAJINDER NAGAR INDUSTRIAL AREA, MOHAN NAGAR, GHAZIABAD, DISTT. - GHAZIABAD, U.P. - 201007 PH :9999052148; 9999130612.
2542. SNV AUTO (5906-01), PLOT NO. 15, SOUTH SIDE GT ROAD INDUSTRIAL AREA, GHAZIABAD, UTTAR PRADESH - 201001 - 201001 PH :9650324325.
2543. GLOBUS AUTO (5907-01), 139, PANDAV NAGAR, GHAZIABAD, PIN-201001, UTTAR PRADESH - 201001 PH :8588872804.
- GHAZIPUR**
2544. AGR AUTOMOBILES PVT. LTD. (8403-03), RKBK PETROL PUMP, NEAR BANSI BAZAR, GAZIPUR - 2333001 PH :2361136.
- GHIROR**
2545. KULDEEP MOTORS (CVA1-01), KARHAL ROAD, TEHSIL – GHIROR, DISTRICT – MAINPURI, UTTAR PRADESH. - 205121 PH :9536755555.
- GOLA**
2546. SMARTWHEELS PVT LTD (SMS1-01), NEAR KANYA INTER COLLEGE, BHARASADA, GOLA, DISTT – GORAKHPUR, UTTAR PRADESH - 273408 PH :7705800602.
- GONDA**
2547. SMARTWHEELS PVT. LTD. (7201-07), JANKI NAGAR, OPP INDIAN OIL DEPOT, BAHRAICH ROAD, GONDA, UTTAR PRADESH, - 271001 PH :7705803261.
- GORAKHPUR**
2548. SMARTWHEELS PVT. LTD. (7201-01), MOHADDIPUR, (NEAR RAMGARH TAL), GORAKHPUR (U.P.) - 273012 PH :7705803152.
2549. SMARTWHEELS PVT. LTD. (7201-06), NEAR T B HOSPITAL, LACHHIPUR, NEPAL ROAD, GORAKHPUR - 273012 PH :7705803109.

Dealer Network (AS ON 31.10.2023)

2550. SMARTWHEELS PVT. LTD. (7202-01-), PLOT NO.AL-4, SECTOR-9, GIDA, GORAKHPUR. - 273209
PH :9235401004.
2551. ARBIT AUTOMOBILES PVT LTD (7203-01-), ARAZI NO. 66/1/1 MI & 66/2/IMI , 66 MI, MAUZA - MAHEWA MUSTAKIL, NEAR FALMANDI CHOWK, TRANSPORT NAGAR, GORAKHPUR, UTTAR PRADESH . - 273016
PH :8953412821.
2552. ARBIT AUTOMOBILES (7203-1B-), MEDICAL COLLEGE ROAD, NEAR SPORTS COLLEGE, GORAKHPUR, UTTAR PRADESH - 273016
PH :8953412821.

GOSAIGANJ

2553. BRIGHT 4 WHEEL SALES PVT. LTD. (CWK1-01-), KHASRA NO. 24, VILLAGE - SHEKHANPUR, PARGANA MOHANLALGANJ, TEHSIL - MOHANLALGANJ, DIST.-LUCKNOW, UTTAR PRADESH . - 226501
PH :9838075929.

GREATER NOIDA

2554. ROHAN MOTORS LTD. (T201-01-), 63-A, UDYOG VIHAR, GREATER NOIDA, UTTER PRADESH - 201306
PH :4513739, 4513736, 4513734,
4513700/995806111.

HAIDERGARH

2555. BRIGHT 4 WHEEL SALES PVT. LTD. (CVU1-01-), PROPERTY SHOP NO. 5, 6 AND 7, VILLAGE - GOTAINA, PARGANA - HAIDERGARH, TEHSIL - HAIDERGARH, DISTRICT - BARABANKI. - 225124
PH :9935275786, 9838075929.

HAMIRPUR

2556. KTL PVT. LTD. (QH01-01-), VILLAGE RAMEDI,KANPUR ROAD, HAMIRPUR - 213031
PH :7704907587.

HAPUR

2557. ROHAN MOTORS (6G01-01-), DELHI-HAPUR ROAD, OPPOSITE SSV INTERCOLLEGE,HAPUR, DISTRICT- GHAZIABAD - 245101
PH :8476653930, 9536129292.

HARDOI

2558. CONCEPT CARS PVT. LTD. (QE01-01-), NANAK GANJ, LUCKNOW ROAD, HARDOI - 241001
PH :8756000000, 7607696666

2559. CONCEPT CARS PVT. LTD. (QE01-04-), PLOT NO. 1609 & 1605 GANGA BUX PURVA, BILGRAM ROAD, HARDOI KANPUR HIGHWAY, HARDOI, UTTAR PRADESH . - 241001
PH :7607696666, 8756000000.

HATHRAS

2560. DEV MOTORS (P) LTD (B601-03-), NEAR NAGLA UMMED, ALIGARH ROAD, HATHRAS - 204101
PH :9917435500.

IGLAS

2561. DEV MOTORS (SOD1-01-), MATHURA ROAD, IGLAS, DISTRICT ALIGARH. - 202124
PH :9837549000.

ITUNJA

2562. BRIGHT 4 WHEEL (SJDI-01-), 90M GATA GRAM MANDOLI, ITTAUNJA, LUCKNOW, UTTAR PRADESH-226203. - 226203
PH :7011462503.

JAGDISHPUR

2563. BRIGHT 4 WHEEL SALES PVT. LTD. (XC01-01-), KATHORA,MUSAIFIRKHANA,LUCKNOW SULTANPUR ROAD,JAGDISPUR-UTTAR PRADESH . - 227817
PH :9721526961, 9628374814.

JAGNER

2564. MERAK VEHICLES (SPJ1-01-), SHRI RAM GARDEN, AGRA ROAD, NEAR RADHA KRISHNA MANDHIR, JAGNER, UTTAR PRADESH, 283115 - 283115
PH :7896500400.

JALALABAD

2565. SUMITRA DS MOTORS PVT. LTD. (GJX1-01-), GRAM: SUJAWALPUR, BARIELLY ROAD, TEHSILL: JALALABAD, DIST. SHAHJHANPUR - 242221
PH :9336408074, 9897019488.

JAUNPUR

2566. KIRTIKUNJ AUTOMOBILES PVT. LTD. (6H01-01-), KANPUR AKBAR, KUTTUPUR TIRAH - 222001 PH :9554951026.

JHANSI

2567. SURI AUTOMOBILES (6001-01-), BALAJI UNNA ROAD, ANSAL COLONY, JHANSI PIN - 284002. - 284002
PH :8881811383.

2568. VELOCITY CARS (A UNIT OF BASERA VELOCITY AUTOHUB PVT. LTD) (6002-01-), PLOT NO 486, 487, 488, 489 AND 477 (PATTA NUMBERS), MAUZA - KOCHCHABHANWAR, BLOCK: BADAGAON, TEHSIL AND DISTT - JHANSI. - 284128
PH :9889440999.

KANNAUJ

2569. KTL PVT. LTD. (2801-05-), PLOT NO. - 377, AKBARPUR, KANNAUJ - 209725
PH :7408409305.

KANPUR

2570. KTL PVT. LTD. (2801-01-), 9/46, BENAJHABAR ROAD, HARSH NAGAR, KANPUR - 208002
PH :7408409341.

2571. MY CAR PVT. LTD. (2803-01-), 84/54 C, JARIB CHOWKI, NH-2, ROAD, KANPUR - 208003
PH :979270511.

2572. KTL PVT. LTD. (2801-02-), SHVAATRA KRISHNA NAGAR, G T ROAD, KANPUR - 208007
PH :7408409253.

2573. MY CAR PVT. LTD. (2803-02-), C-16, SITE-1, PANKI INDUSTRIAL AREA, KANPUR - 208022
PH :7972970086.

2574. S B CARS PVT.LTD (2806-01-), 77B , FAZAI GANZ, KANPUR - 208012
PH :2241660.

2575. MY CAR PVT. LTD. (2803-05-), 88, BLOCK-T, FACTORY AREA, FAZALGANJ, KANPUR - 208004
PH :7972970081.

2576. S B CARS PVT.LTD (2806-05-), 1/6-7 AMBEDKAR PURAM, AWAS VIKASH, KALYANPUR, KANPUR - 208017
PH :7408402525.

2577. KULDEEP MOTORS KANPUR LLP. (2808-01-), BUKHAN NO. 756, 756A, 757, BLOCK: W, YOJNA: 2, JUHI KALAN, BARRA BYE PASS, KANPUR . - 208017
PH :7076608071.

2578. KTL PVT. LTD. (2801-07-), ARAZI NO. 1110, VILLAGE BAIRI, AKBARPUR, KACHHAR, INDIRA NAGAR, KANPUR, UTTAR PRADESH - 208 026
PH :7408409379.

KARI

2579. MY CAR PVT. LTD. (CBU1-01-), ARAJU NO. 58, MAUJA - AMANPUR, TEHSIL - KARI, DIST. -CHITRAKOOT, UTTAR PRADESH . - 210205
PH :9839029868, 9792970391.

KASGANJ

2580. MADHUSUDAN VEHICLES PRIVATE LTD. (BVX1-01-), ARAJU NO. 646, SAURO ROAD, KASGANJ DISTRICT - KASGANJ, UTTAR PRADESH . - 207123
PH :9387097863, 9690003034.

KASIA

2581. ARBIT AUTOMOBILES PVT LTD (GMJ1-01-), MAUJA BHAIASHA, HETIMPUR KASIA, KUSHINAGAR, UTTAR PRADESH - 274206
PH :8953412821.

KATRA

2582. SUMITRA DS (SHY1-01-), GRAM: SAALPUR NAVADIYAM, NH24, KATRA, TEHSIL - TILHAR, SHAHJAHANPUR . - 242301
PH :9336408074.

KAUSHAMBI

2583. SARASWATI MOTORS (SLQ1-01-), ARAZI NO 1228, KORRO MANJHANPUR, KAUSHAMBI, UTTAR PRADESH, PINCODE - 212207. - 212207
PH :8090854005.

KAYAMGANJ

2584. MY CAR PVT. LTD. (CBV1-01-), BYE PASS ROAD , NEAR KHAN PETROL PUMP, VILLAGE : KAYAMGANJ, DISTT: FARUKHABAD - 209502
PH :9839029868, 9792970391.

KHAIR

2585. DEV MOTORS (SHQ1-01-), PLOT 117, ALIGARH PALWAL ROAD, VILLAGE CHAMAN NAGARIYA, KHAIR - 202138
PH :7351345577.

KHANDAULI

2586. MADHUSUDAN MOTORS PVT LTD (VVV1-01-), KHASRA NO. 97, AGRA-SADABAD, HATHRAS ROAD, OPP. HDFC BANK, VILL-KHANDAULI, TEHSIL ETHMADPUR, DIST. AGRA, UTTAR PRADESH . - 283126
PH :9837097863, 9690003034.

KHURJA

2587. SK UNIVERSE (SKP1-01-), OLD GT ROAD, KHURJA, DISTRICT: BULANDSHAHAR, UTTAR PRADESH . - 203131 - 203131
PH :7055118430.

KHUTAR

2588. SUMITRA DS MOTORS PVT LTD (CIO1-01-), VILLAGE - NARAINPUR, VIKRAMPUR GOLA ROAD, KHUTAR, DISTRICT - SHAHJAHANPUR, UTTAR PRADESH . - 242405
PH :9336408074.

KIRAOJI

2589. PREM MOTORS PVT. LTD. (BJZ1-01-), GOVIND PALACE, NEAR KIRAWALI TEHSIL, AGRA - JAIPUR HIGHWAY, KIRAWALI, DISTRICT - AGRA, UTTAR PRADESH . - 283122
PH :9690010799.

KONCH

2590. KULDEEP MOTORS (SNZ1-01-), NEW PATEL NAGAR, CITY KONCH, DISTRICT - JALAUN, UTTAR PRADESH . - 285205
PH :9839015046.

KOSI

2591. UMA MOTORS PVT. LTD. (CPV1-01-), KHASRA NO. 245, CITY - KOSI, DIST -MATHURA. - 281004
PH :9997683333, 9997511006.

KUBERPUR

2592. KTL PVT. LTD. (6606-04-), KHASRA NO.248,249,251, NAVALPUR, BHAGPUR, POST-ETHMAPUR, NH-2, KUBERPUR, AGRA, UTTAR PRADESH . - 282006
PH :8449715099.

KUNDA

2593. SARASWATI MOTORS (CBF2-01-), ALLAHABAD-LUCKNOW HIGHWAY, KUNDA, DISTRICT PRATAPGARH, - 230204
PH :8090854005.

LAKHIMPUR

2594. SUMITRA DS MOTORS PVT LTD (WB01-02-), GATA NO. 66, LRP ROAD, TOWARDS GOLA, LAKHIMPUR KHERI - 242001
PH :7522888333, 9415770000.

2595. SUMITRA DS (M301-01), GATE NO 604, PALIA ROAD, NEAR FOI WEAR HOUSE, VILLAGE - BHARDASARI, KHERI, LAKHIMPUR - 262702 PH :7522888333, 9415770000.
- LALGANJ**
2596. KTL AUTOMOBILE PVT. LTD. (CSL2-01-), JEEWAN DEEP COMPOUND, ALLAHABAD ROAD, LALGANJ, DISTT. RAIBARELLI - 229206 PH :9918451222.
- LALITPUR**
2597. SURI AUTOMOBILES (6001-03), JAHANSI SAGAR ROAD, LALITPUR - 284001 PH :9451496015.
2598. VELOCITY CARS (6J02-01), LALITPUR BYPASS ROAD, NH26 (LALITPUR-MEHRANAHI HIGHWAY), IN FRONT OF RMV COLLEGE ROAD, MAIN HIGHWAY, LALITPUR, UTTAR PRADESH - 284403 PH :9560998709.
- LUCKNOW**
2599. ANAND MOTORS AGENCIES LTD (1301-01), 11TH KMS, FAIZABAD ROAD, CHINHAT, LUCKNOW - 227105 PH :7080000462.
2600. KTL AUTOMOBILE PVT. LTD. (1311-01-), MATIYAR CHAURAHIA, CHINNHAT, FAIZABAD ROAD, LUCKNOW - 227105 PH :7408411453.
2601. ANAND MOTORS AGENCIES LTD (1301-02), 47, NEHRU ROAD, SADAR BAZAR, LUCKNOW - 226016 PH :3098257, 7080000463.
2602. BRIGHT 4 WHEEL SALES PVT. LTD. (1305-01-), 11/CP-6, VIKAS NAGAR, RING ROAD, LUCKNOW - 226022 PH :2739501.
2603. ONE UP MOTORS INDIA PVT. LTD. (1306-01-), C-16A, TRANSPORT NAGAR, KANPUR ROAD, LUCKNOW, KANPUR ROAD, LUCKNOW - 226012 PH :9918100801.
2604. KTL AUTOMOBILE PVT. LTD. (1311-02-), INDRA NAGAR, OPP. HALFAIZABAD ROAD, LUCKNOW, UTTAR PRADESH - 226016 PH :7408411478.
2605. KTL AUTOMOBILE PVT. LTD. (1311-03-), BEHIND N S KOHLI PETROL PUMP, SARDARI KHEDA, KANPUR ROAD, ALAMBAGH, LUCKNOW - 226005 PH :9918451222.
2606. ANAND MOTORS AGENCIES LTD (1301-04-), G-3, LDA MARKET, ALIGANJ, LUCKNOW - 226024 PH :4103406/407/408, 7080000464.
2607. ONE UP MOTORS INDIA PVT. LTD. (1306-03-), CHHANNILAL CROSSING, MANDIR MARG, LUCKNOW - 226005 PH :9918500451.
2608. BRIGHT 4 WHEEL SALES PVT. LTD. (1305-02-), PARGANNA MOHANNA, STP ROAD, CHATMEEL, LUCKNOW - 226021 PH :9838075960.
2609. BRIGHT 4 WHEEL SALES PVT. LTD. (1305-04-), PLOT NO: 57 TO 60, KAUSHALABAD, BADHAULI BKT, PARGANA MOHANNA, SITAPUR ROAD, BAKSHI KA TALAB, LUCKNOW - 226020 PH :7317049000.
2610. BRIGHT 4 WHEEL SALES PVT. LTD. (1305-05-), PLOT NO. 68, BUTLER GANJ, BAALU ADDA, LUCKNOW - 226001 PH :8756000000, 7607696666.
2611. MEGA MOTORS (A UNIT OF AKM MOTORS PVT. LTD) (1313-01-), CP1 (COMMERCIAL PLOT 1), VIBHAV KHAND, GOMTI NAGAR, LUCKNOW. - 226 010 PH :9935096417, 7054631666.
2612. KTL AUTOMOBILE PVT. LTD. (1311-07-), B-6/1A, AMAUSI INDUSTRIAL AREA, NADARGANJ, LUCKNOW, UTTAR PRADESH. - 226008 PH :7800007376.
2613. BRIGHT 4 WHEEL SALES PVT. LTD. (1305-06-), KHASRA NO. 418, MISHRAPUR PARGANA MAHONA, KURSI ROAD, LUCKNOW. - 226022 PH :9935275786.
2614. ONE UP MOTORS INDIA PVT. LTD. (1314-01-), KHASRA NO. 20 TO 25, 30, 35, 37, 42, 43, 45, 47, 48, 49, 67, 68, 71 & 99, RAJJABGANJ, HARDOI ROAD, LUCKNOW - 226003 PH :9821026545, 7800005200.
2615. MEGA MOTORS (A UNIT OF AKM MOTORS PVT. LTD) (1313-02-), KHASRA NO. 614, VILLAGE: BHADRUKH, VIP CHANNEL RING ROAD, DEVI KHERA, TELIBAGH (VIP ROAD), TEHSIL: SAROJINI NAGAR, LUCKNOW, UTTAR PRADESH 226002 - 226002 PH :6388901514.
- MADHOGANJ**
2616. CONCEPT CARS PVT. LTD. (BHI1-01-), KANPUR ROAD, NEAR RAILWAY CROSSING, MADHOGANJ DIST. HARDOI - 241001 PH :220016, 220064, 7607696666.
- MAHARAJGANJ**
2617. SMARTWHEELS PVT. LTD. (EI01-01-), NEAR PHARENDI TAXI STAND, NAHAR ROAD, PIPAR DEORA, MAHARAJGANJ, DIST. MAHARAJGANJ, UTTAR PRADESH. - 273303 PH :7705800602, 7705803109.
2618. KTL AUTOMOBILE PVT. LTD. (CSM2-01-), MUNNA MARKET HAIDERGARH ROAD TOWN AREA, TEHSIL - MAHARAJGANJ, DISTRICT - RAIBARELLI, UTTAR PRADESH. - 229306 PH :9918451222.
- MAHMUDABAD**
2619. CONCEPT CARS PVT. LTD. (AAN1-01-), IN FRONT OF POWER HOUSE, SIDAULI ROAD, MAHMOUDABAD (U.P.) - 261203 PH :7607696666, 8756000000.
- MAHOBA**
2620. SURI AUTOMOBILES (6001-02-), NEAR PARMANAND CHOWK, GANDHINAGAR, MAHOBA, UTTAR PRADESH. - 284001 PH :244344, 9451496015.
2621. VELOCITY MOTORS (RM02-01-), BAJRANG CHOWK, SAGAR-KANPUR HIGHWAY, MAHOBA - 210427 PH :9560989709.
- MAHOLI**
2622. CONCEPT CARS PVT. LTD. (CWS1-01-), MUSKAN TRACTORS, NEAR MELA MAIDAN, SHAHJAHANPUR ROAD, MAHSUNIYAGANJ, MAHOLI, DIST.-SITAPUR, UTTAR PRADESH. - 261141 PH :7607696666.
- MAINPURI**
2623. KULDEEP MOTORS (6E01-02-), SKP-4A, MAINPURI - 250001 PH :9235258444.
- MALIHABAD**
2624. ONE UP MOTORS INDIA PVT. LTD. (BOD1-01-), KHASRA NO. 326/1 AND 327, VILLAGE PARGANA, TEHSIL - MALIHABAD, DISTRICT - LUCKNOW, UTTAR PRADESH. - 227111 PH :9918100781.
- MANDURI**
2625. DEEP MOTORS (K501-04-), VILLAGE - BALDEV MADURI, TEHSIL - SAGRI, DISTRICT - AZAMGARH, UTTAR PRADESH. - 276138 PH :98938072902.
- MATHURA**
2626. UMA MOTORS PVT. LTD. (H801-01-), 68, MAHOLI, NEAR JAI GURUDEV TEMPLE, NH-2, KM STONE 146, MATHURA - 281004 PH :2463043/ 6290700.
- MATI**
2627. MEGA MOTORS (A UNIT OF AKM MOTORS PVT. LTD) (SCG1-01-), GATA NO 761, NEAR MATI POLICE CHOWKI, VILLAGE- MATI, PARGANA-DEWA, TEHSIL- NAWABGANJ, BARABANKI, UTTAR PRADESH - 225 003 PH :6388901514.
- MAU**
2628. DEEP MOTORS (BWK1-01-), DARI CHATTI , KHUKHUNDVA, MAU, UTTAR PRADESH. - 275305 PH :7704000552.
- MAURANIPUR**
2629. VELOCITY CARS (A UNIT OF BASERA VELOCITY AUTOHUB PVT. LTD) (GJ1-01-), BASERA CITY, MAURANIPUR - GARUTHA ROAD, MAURANIPUR, DISTT: JHANSI, UTTAR PRADESH - 284204 PH :8299202863.
- MAWANA**
2630. RADHA GOVIND AUTOMOBILES PVT LTD (CWZ1-01-), MAIN SHANTI NAGAR ROAD, MAWANA KALAN, SUBDIVISION HASTINAPUR, TEHSIL MAWANA, DISTRICT MEERUT - 250401 PH :7456001002.
- MEERUT**
2631. TANYA AUTOMOBILES PVT. LTD. (4802-01-), GOVT. INDUSTRIAL TRAINING INSTITUTE, BACHHA PARK, MEERUT - 250001 PH :9837077003.
2632. TANYA AUTOMOBILES PVT. LTD. (4802-03-), NAUCHANDI GROUND,GARH ROAD, MEERUT - 250001 PH :9837077004.
2633. RADHA GOVIND AUTOMOBILES PVT. LTD. (4807-01-), VILLAGE - BARAL, KUNDA GATE NEAR YOGI FARM HOUSE, PARTAPUR, DELHI ROAD, MEERUT. - 250002 PH :7456001030, 7456003222.
2634. TANYA AUTOMOBILES PVT. LTD. (4802-04-), MUNICIPAL NO. 9, 9/2, 9/3, 9/4, 11, 11/1, VILLAGE - ROSHANPUR DORLI, OPP. KONARK COLONY, NEAR RAJMANDIR MANDAP, ROORKEE ROAD, TEHSIL - SARDHANA, MEERUT, U.P. - 250001 PH :7900201515.
2635. TR SAWHNEY (4808-01-), MUNICIPAL NO 101, KHASRA NO 1926/ MINJUMLA & 1927/1, MAHAL LEKHRAJ MUJBITA, MAIN DELHI ROAD, MEERUT, UP - 250002 - 250002 PH :9999163125.
- MIRZAPUR**
2636. STAR CARS (6K02-01-), PILI KOTHI, STATION ROAD, MIRZAPUR, UTTAR PRADESH - 231001 PH :7052547903, 9721905002, 9151154306, 9450544961.
- MISHRIKH**
2637. CONCEPT CAR (SKJ1-01-), NEAR ARYAVART BANK, SITAPUR ROAD, MISHRIKH, SITAPUR, U.P., PINCODE: 261401 - 261401 PH :7607696666.
- MODINAGAR**
2638. MOTORCRAFT SALES PVT. LTD. (5903-02-), OPPOSITE SONIA ENCLAVE, ADJACENT SUMAN CINEMA, NH-58, MODINAGAR - 201204 PH :09557338222 & 07042427140.
- MOHANLAL GANJ**

Dealer Network (AS ON 31.10.2023)

2639. BRIGHT 4 WHEEL SALES PVT. LTD. (BWU1-01-), KHASARA PLOT NO.581, VILLAGE PURSANI, PARGANA AND TEHSIL MOHANLALGANJ, LUCKNOW DISTT., UTTAR PRADESH - 227305 PH :7571905966.

MOOSANAGAR

2640. MY CAR (SLP1-01-), VILL GAUSGANJ, POST MOOSANAGAR, KANPUR DEHAT, UTTAR PRADESH - 209208 PH :97929 70005.

MORADABAD

2641. AKANKSHA AUTOMOBILES PVT. LTD. (B401-01-), DELHI ROAD, 5TH.KM, MORADABAD (U.P.) - 244001 PH :7274800008.

2642. AKANKSHA AUTOMOBILES PVT. LTD. (B401-03-), 5TH KM DELHI ROAD, MORADABAD - 244001 PH :9568200001.

2643. AKANKSHA AUTOMOBILES PVT. LTD. (B401-04-), KHASRA NO. 569-570, VILLAGE - KAJIPURA, KANT ROAD, MORADABAD, UTTAR PRADESH - 244001 PH :7895600007.

MUZAFFARNAGAR

2644. RADHA GOVIND (H903-01-), NH -58 ,121 KM STONE, BY PASS ROAD, NEAR TRANSPORT NAGAR, MUZAFFARNAGAR - 251001 PH :9760020099, 7535007026.

NAJIBABAD

2645. SHAKUMBARI AUTOMOBILES (P) LTD (CPS1-01-), NEAR BUS STAND, BIJNORE BYPASS ROAD, NAJIBABAD, DIST.-BIJNORE, UTTAR PRADESH. - 246 701 PH :8630881459.

NARWAL

2646. MY CAR (SSB1-01-), GATA NO. 821 , KARIBGWANA ROAD , NARWAL , KANPUR, UTTAR PRADESH. - 209401 PH :9792970005.

NAUGARH

2647. SMARTWHEELS PVT. LTD. (OG01-01-), NEAR PAKARI CHAUHARA, NAUGARH ROAD, SIDDHARTHNAGAR - 272205 PH :7705803129.

NAUTANWA

2648. SMARTWHEELS PVT LTD (SDW1-01-), OPP. RAJIV GANDHI DEGREE COLLEGE, BYPASS ROAD, NAUTANWA, DISTT - MAHARAJGANJ - 273164 PH :77058 00602.

NAWABGANJ

2649. KAVISHA MOTORS PVT LTD (CHT1-01-), VILLAGE - EIDH JAGR NEAR GURUDWARA AT NH-74, TEHSIL - NAWABGANJ, DISTRICT - BAREILLY. - 262406 PH :7895980222, 07895980300.

NIGOHA

2650. BRIGHT 4 WHEELS (SGV1-01-), GATA NO 146, VILL NIGOHA, TEHSIL MOHANLALGANJ, LUCKNOW - 226302 PH :7011482503.

NOIDA

2651. ROHAN MOTORS LTD. (A102-01-), C-8/9, SECTOR - I, NOIDA - 201301 PH :4071900, 4071909, 4071931, 4071932, 4071209, 4071949/9582210152.

2652. ROHAN MOTORS LTD. (A102-02-), C-11, SECTOR-1, NOIDA, UTTAR PRADESH - 201301 PH :4071900, 209.31.32/9582210152

2653. FAIR DEAL PREMIUM WHEELS PVT LTD. (A108-01-), D-39, SEC-10, NOIDA - 201301 PH :0844829669 & 09654326008.

2654. VIPUL MOTORS PVT. LTD. (A101-02-), B-124 & B-125, SECTOR - 5, NOIDA, UTTAR PRADESH - 201301 PH :4603100/28/33/8527835888.

2655. VIPUL MOTORS PVT. LTD. (A106-01-), J-14, SECTOR-63, NOIDA, DISTT. GAUTAM BUDDH NAGAR (U.P.) - 201301 PH :4758600/01/02/8448589759.

2656. MOTORCRAFT SALES LTD. (5903-04-), PLOT NO.15, SECTOR-140, NOIDA (U.P.) - 201305 PH :09818532222 & 09971733233.

2657. MOTORCRAFT SALES (5903-05-), PLOT NO 19 ECOTECH 12 GREATER NOIDA WEST,GB NAGAR , U.P. - 201306 PH :8826312222.

ORAI

2658. S B CARS PVT.LTD (2806-02-), KANPUR ROAD, ORAI - 285001 PH :9307219303.

PADRONA

2659. SMARTWHEELS PVT. LTD. (BGJ1-01-), AARJI NO. 37 & 38, MAUJA - BELWA MISRA, TAPPA PAKDI, PARAGNA - SIDHUWA JAUBNA, TEHSIL - PADRAUNA, DIST-KUSHINAGAR, UTTAR PRADESH. - 274304 PH :7705803259.

PANWARI

2660. SURI AUTOMOBILES (SLC1-01-), PANWARI, NEAR RAM LEELA GROUND, TEHSIL KULPAHAR, DISTRICT MAHOBIA. - 210429 PH :942287690.

PAPHUNDA

2661. TANYA AUTOMOBILES (4802-05-), 354/1, MAIN HAPUR ROAD, PHAPHUNDA. - 245206 PH :9837547777.

PEPPEGANJ

2662. ARBIT AUTOMOBILES PVT LTD (GKG1-01-), GHATA NO. 466, 465 & 472, PEPPEGANJ, MOUZA - SAHABGANJ, TEHSIL - CAMPIERGANJ, DISTT: GORAKHPUR - 273165 PH :89534 12821.

PILIBHIT

2663. CORAL MOTORS (P) LTD. (ILO1-01-), BISALPUR ROAD, PILIBHIT, U.P. - 262001 PH :9837891846.

POOTH KHAS

2664. TR SAWHNEY (SSM1-01-), POOTH KHAS, ROHTA ROAD, MEERUT, UTTAR PRADESH. - 250502 PH :9997997229.

PRAYAGRAJ

2665. SARASWATI MOTORS (2904-01-), PLOT NO 24, INDUSTRIAL AREA MNIT COLLEGE, TELYARGANJ, PRAYAGRAJ, UTTAR PRADESH. - 211004 PH :8090854053.

2666. BRIGHT 4WHEELS (2905-01-), ARAZI NO 390 AND 390 AT KATKA, ANDAWA SAHSON BYPASS, PRAYAGRAJ - 211002 PH :9415324201.

PURANPUR

2667. CORAL MOTORS (P) LTD. (CAD1-01-), KHASRA NO. 768 & 770, VILLAGE - KHAMIYARI PATTI, PURANPUR - PILIBHIT ROAD, TEHSIL AND PARGANA - PURANPUR, DIST. PILIBHIT. - 262124 PH :9837891846, 9927001120.

RAIBAREILLY

2668. KTL AUTOMOBILE PVT. LTD. (HS07-01-), PLOT NO. 1550, GULLUPUR, P O KATWARA, HUJARCHANDRAPUR, RAIBAREILLY - 229303 PH :7800001601.

RAM SANEHII GHAT

2669. BRIGHT 4WHEELS (SDH1-01-), GATA NO 76, VILLAGE - BHENDUWA BRAHMANAN, TEHSIL - RAM SANEHII GHAT, BARABANKI, UTTAR PRADESH, PIN 225409 - 225409 PH :9935275786.

RAMNAGAR

2670. BRIGHT 4 WHEEL SALES PVT. LTD. (BRK1-01-), KHASRA NO. 629, VILLAGE - BUDHAWAL, TEHSIL - RAMNAGAR, DIST-BARABANKI, UTTAR PRADESH. - 225205 PH :9935275786, 9838075929.

RAMPUR

2671. AKANKSHA AUTOMOBILES PVT. LTD. (B401-02-), SHAHZAD NAGAR BAREILLY ROAD RAMPUR UTTAR PRADESH - 244901 PH :7895500007.

RAYA

2672. UMA MOTORS PVT. LTD. (BKX1-01-), CHAUDHARY PADAM SINGH MARKET, NEAR INDIA INTER COLLEGE, RAYA - MAANT ROAD, RAYA, DISTT. MATHURA (U.P.) - 281204 PH :9997683333, 9997511006.

ROBERTSGANJ

2673. STAR CAR (CTY1-01-), UMRAURA, PIMPRI ROAD, ROBERTSGANJ, UTTAR PRADESH - 231 216 PH :7052547903, 9721905002, 9151154306, 9450544961.

RUNKATA

2674. PREM MOTORS (SLS1-01-), ROYAL BANDHAN RESORT, KHASRA NO 108, NH-2, RUNKATA, AGRA - 282101 PH :7080111245.

SAHARANPUR

2675. ATELIER AUTOMOBILES (S203-01-), NEAR BARI NAHAR, AMBALA ROAD, SAHARANPUR - 247001 PH :7500250070.

2676. TANYA AUTOMOBILES PVT. LTD. (S204-01-), AAWAS VIKAS YOJNA, DELHI ROAD, SAHARANPUR, UTTAR PRADESH - 247001 PH :9837077004.

2677. CORAL MOTORS, (SGA1-01-), OPP BHARAT PETROL PUMP, BADAUN ROAD, SAHASWAN, DISTT. BADAUN - 243638 PH :9837891846.

SAHIBABAD

2678. FAIR DEAL WHEELS PVT. LTD. (80-01-), 12/6 SITE 4, INDUSTRIAL AREA, SAHIBABAD, GHAZIABAD - 110095 PH :4740409/102436, 8860088659.

2679. MOTORCRAFT SALES PVT. LTD. (5903-01-), S-7 SITE-IV, SAHIBABAD INDUSTRIAL AREA, NEAR DABUR CHOWK, SAHIBABAD - 201010 PH :4172222 / 4102222, 0995862222 & 09560605122.

2680. T.R. SAWHNEY MOTORS PVT LTD (B19-03-), 28/1/1, SITE-IV, SAHIBABAD INDUSTRIAL AREA,DISTT- GHAZIABAD, UTTAR PRADESH - 201010 PH :9995399152; 9999399143.

SALEMUR

2681. SMARTWHEELS PVT LTD (GKA1-01-), GHATA NO. 48, GRAM: DEVARP, TEHSIL: SALEMPUR, PARGANA: SALEMPU MAUJHAULI, DISTT: DEORIA - 274509 PH :7705800602, 7705803321.
- SALON**
2682. KTL AUTOMOBILES (SCP1-01-), SALON BYPASS, PARSHEDAPUR ROAD, SALON, DISTRICT RAIBARELLI, UTTAR PRADESH - 229127 PH :9918451222.
- SAMBHAL**
2683. AKANKSHA AUTOMOBILES PVT. LTD. (BGP1-01-), PLOT NO. 303, NEAR TAJ MILK FACTORY, MORADABAD SAMBHAL ROAD, SAMBHAL, UTTAR PRADESH - 244302 PH :7248000028.
- SANDILA**
2684. CONCEPT CARS PVT. LTD. (WY01-01-), PLOT NO.371, SARAY MARUPUR, LUCKNOW ROAD, SANDILA-241204 DISTT. HARDOL. - 241204 PH :8756000000, 7007696666.
- SARDHANA**
2685. RADHAGOVIND AUTOMOBILES (MM01-01-), DAURALA ROAD, NEAR RADHASWAMI SATSANG, SARDANA - 250342 PH :7456001030.
- SHAHABAD**
2686. CONCEPT CARS PVT. LTD. (AAX1-01-), VILLAGE MUJAGADH, SHAHABAD - 241124 PH :8756000000, 7007696666.
- SHAJAHANPUR**
2687. SUMITRA DS MOTORS PVT LTD (W201-01-), SITAPUR ROAD, NH-24, SHAJAHANPUR - 242001 PH :2272888333, 9415770000.
- SHAMLI**
2688. RADHA GOVIND AUTOMOBILES PVT. LTD. (XJ01-01-), KHERI KARMU, OPPOSITE POWER HOUSE, PANIPAT-KAIRANA ROAD, SHAMLI UTTAR PRADESH - 247776 PH :8979862084, 7535007010.
- SHIKOHABAD**
2689. MADHUSUDAN VEHICLES PRIVATE LTD. (XH01-01-), 2508, KATRA MIRA, MAHAMMABAD, OPP PROFESSOR COLONY, NH 2, BYE PASS ROAD, SHIKOHABAD, DISTT: FIROZABAD UTTAR PRADESH - 283203 PH :9837097894, 9690003001.
- SHIVRAJPUR**
2690. KTL PVT LTD. (STD1-01-), ARAZI NO. 67K, DUBIYANA, GT ROAD, SHIVRAJPUR, KANPUR, UTTAR PRADESH - 290205 PH :9414113666.
- SIDHUALI**
2691. CONCEPT CARS PVT. LTD. (BFO1-01-), R/O MISHRIKH ROAD NOROTTAM NAGAR, DAKSHIDI, OPP. BLOCK, SIDHUALI, SITAPUR. - 261303 PH :7607596666.
- SIKANDARA**
2692. KTL PVT LTD (SJE1-01-), YADAV MARKET, NEAR SURYA DHABA, NH-19, ETAWAH-KANPURROAD, SIKANDRA, U.P. - 209715 PH :9411136666.
- SIKANDRABAD**
2693. SK UNIVERSE (CWO1-01-), NEAR R K SCHOOL, VILLAGE - SANWALI SIKANDRABAD , DIST - BULANDSHAHAR UTTAR PRADESH, PIN 203202 - 203202 PH :7310106565.
- SIRauli GHASPUR**
2694. BRIGHT FOUR WHEELS (SMR1-01-), KHASRA 77, GRAM GHASEDIVA, POST & TEHSIL SIRauli GHASPUR, BARABANKI UTTAR PRADESH- 225207 - 225207 PH :7011482503.
- SITAPUR**
2695. CONCEPT CARS PVT. LTD. (QE01-02-), LUCKNOW-DELHI ROAD, NH-24, VILLAGE JAMMAYAPUR, SITAPUR - 261001 PH :7607696666, 8756000000.
- SIYANA**
2696. SK UNIVERSE (SIN1-01-), BULANDSHAHAR ROAD, SIYANA DIST- BULANDSHAHAR, UTTAR PRADESH PIN CODE 203412 - 203412 PH :9219634600.
- SULTANPUR**
2697. KIRTIKUNJ AUTOMOBILES PVT. LTD. (N101-01-), SHAURYAMAU, MIRANPUR, VARANSI-LUCKNOW HIGHWAY, NH-56 (FAIZABAD BYPASS) SULTANPUR - 228001 PH :227760 , 220107.
- SWAR**
2698. AKANKSHA AUTOMOBILES PVT. LTD. (COX1-01-), IN FRONT OF EIDGAH, TEHSIL - SWAR, DISTRICT - RAMPUR, UTTAR PRADESH. - 244924 PH :7900600041.
- TAMBOUR**
2699. CONCEPT CARS (SOB1-01-), NEAR INDIAN GAS GANJAR, SITAPUR ROAD TAMBOUR - 261208 PH :7607696666.
- THAKURDWARA**
2700. AKANKSHA AUTOMOBILES PVT. LTD. (KOO1-01-), 2 KM. MORADABAD ROAD, NEAR JEETA KA DHABA, SAHAB GANJ (MUNSHI GANJ), THAKURDWARA, DISTT. MBD. UTTAR PRADESH - 244601 PH :7248000040.
- TIKAITGANJ**
2701. KTL AUTOMOBILE (SNB1-01-), KANAUJA CITY, PHASE 2, MADARPUR, MOHAN ROAD, LUCKNOW. - 226013 PH :9918451222.
- TILOI**
2702. KTL AUTOMOBILE PVT. LTD. (CGY2-01-), VILLAGE PURA LANGDA, PAKAR GAON, MOHAN GUNJ, TEHSIL - TILOHI, DIST-RAIBARELI. - 229309 PH :9918451222.
- UJHANI**
2703. ETERNITY MOTORS LLP (GJK1-01-), BADAUN BYE PASS ROAD, UJHANI - 243639 PH :94122 89074.
- UNCHAHAR**
2704. KTL AUTOMOBILE PVT. LTD. (IH02-01-), ALLAHABAD LUCKNOW ROAD, NEAR PURANA PETROL PUMP, WARD NO. 5, UNCHAHAR, DISTT: RAIBARELI - 229404 PH :9918451222.
- UNNAO**
2705. S B CARS (2806-04-), HUSSAIN NAGAR BYPASS-KANPUR-LUCKNOW HIGHWAY ROAD, UNNAO,U.P. - 209801 PH :9839806451.
- VARANASI**
2706. VARANASI MOTORS PVT. LTD. (8402-01-), THE MALL, CANTONMENT, VARANASI - 221001 PH :2509068, 2509069.
2707. AGR AUTOMOBILES PVT. LTD. (8403-01-), B-38/2A, MAHMOORGANJ, GOPAL VIHAR, VARANASI - 221010 PH :2360436.
2708. VARANASI MOTORS PVT. LTD. (8402-03-), AARAJI NO 2 AND 48, G.T. ROAD, TODAPUR, MOHANSARAI, RAJATALAB, VARANASI (U.P.) - 221311 PH :2632786, 9838360662.
2709. AGR AUTOMOBILES PVT. LTD. (8403-04-), ARAZI NO. 399, 398, 400, 401,NH2 PANDITPUR, DEHAT AMANAT, TEHSIL - RAJATALAB, VARANASI - 221112 PH :98898 03355.
- UTTARAKHAND**
- ALMORA**
2710. NAINITAL MOTORS PVT LTD (J603-04-), PAWAR BHAWAN, JOSHI KHOLA RAJAPURA, PITHRAGARH ROAD, ALMORA - 263601 PH :9997194132.
- BAGESHWAR**
2711. NAINITAL MOTORS PVT LTD (J603-05-), VILL. BILOMA, SERA, BAGESHWAR, UT, BAGESHWAR - 263642 PH :9557200522.
- BAZPUR**
2712. AKANKSHA AUTOMOBILES (RUDRAPUR) PVT LTD (CGU2-01-), KHASRA NO. 96/2, VILLAGE - BHONA, ISLAM NAGAR, TEHSIL - BAZPUR, UTTARAKHAND . - 262401 PH :8929400544, 8191000204.
- CHAMPAWAT**
2713. AKANKSHA AUTOMOBILES (RUDRAPUR) PVT LTD (SF02-01-), TANAKPUR LOHAGHAT ROAD, CHAMPAWAT, UTTARAKHAND - 262523 PH :8929400545, 8191000832.
- CHANDRAPURI**
2714. SHAKUMARI AUTOMOBILES (-), KEDARNATH ROAD, BANASBARA, CHANDRAPURI, DISTRICT RUDRAPRAYAG, UTTARAKHAND - 246425 PH :9927877715.
- CHAUKHUTIYA**
2715. NAINITAL MOTORS PVT LTD (CVG1-01-), NH-58, BADRINATH ROAD, CHAUHKHUTIYA, DIST. -ALMORA, UTTARAKHAND - 263656 PH :9997026565.
- DEHRADUN**
2716. ROHAN MOTORS LTD. (5702-01-), 130/1 CHAKRATA ROAD, YAMUNA COLONY, DEHRADUN - 248001 PH :0135-2530050, 0135-2531097, 7217014647.
2717. DD MOTORS (A DIVISION OF D.D. PREM PVT.LTD) (5707-01-), 918/221, PATEL NAGAR, INDUSTRIAL AREA, DEHRADUN - 248001, PH :9368193007.
2718. ROHAN MOTORS LTD. (5702-02-), 257/2, GMS ROAD, VILL. NIRANJANPUR, ADJ TO KAMLA PALACE, DEHRADUN - 248001 PH :0135-2725376, 0135-2720342, 7217014647.
2719. FUTURE AUTO WHEELS PVT LTD (5706-01-), KHASRA NO. 8KHA, MOHABEWALA INDUSTRIAL AREA, DEHRADUN. - 248001 PH :0135-2640263, 7895956011.
2720. FUTURE AUTO WHEELS (5706-02-), MUNICIPAL NUMBER 45 AND 46, RAJPUR ROAD, DEHRADUN, PIN: 248001 - 248001 PH :976044430.
- DIDIHAT**

Dealer Network (AS ON 31.10.2023)

2721. NAINITAL MOTORS (SKN1-01), SUBHASH CHANDRA BOSE WARD, NEAR D.I.E.T. DIDIHAT, DISTT PITHORAGARH, PINCODE: 262551. - 262551
PH : 9634092692.

DOIWALA

2722. FUTURE AUTO WHEELS PVT LTD (BRI1-01), 26, MISSARAWALA, DOIWALA, DISTRICT – DEHRADUN, UTTARAKHAND. - 248140
PH : 9833473506.

GADPUR

2723. AKANKSHA AUTOMOBILES (RUDRAPUR) PVT LTD (CVS1-01), BHASIYA MOD, RUDRAPUR ROAD, GADPUR, UDHAM SINGH NAGAR, UTTARAKHAND. - 263152
PH : 8929400545, 9917467845.

GAIRSAIN

2724. ROHAN MOTORS LTD (CRH1-01), KHASRA NO. 1048, RANIKHET ROAD, OPP. GIC GROUND, GAIRSAIN, DISTRICT – CHAMOLI, UTTARA KHAND . - 264242
PH : 8126484626.

GANGOLIHAT

2725. NAINITAL MOTORS (SQX1-01), VILL- KHETIGARA, PITHORAGHAR-GANGOLIHAT ROAD, GANGOLIHAT, DISTT: PITHORAGARH - 262522
PH : 999703043.

GOPESHWAR

2726. ROHAN MOTORS LTD. (5702-03-), CHOPTA MANDAL ROAD, NEAR FOREST GATE, GOPESHWAR - 131028
PH : 9634852898.

HALDWANI

2727. NAINITAL MOTORS PVT LTD (J603-01), VILLAGE JEETPUR NEGY, 5TH KM RAMPUR ROAD, HALDWANI - 263139
PH : 7060201024.

2728. NAINITAL MOTORS PVT LTD (J603-02), KALA DUNG, NEAR ABDULLAH PETROL PUMP, HALDWANI - 263139
PH : 8126359222.

HARDIWAR

2729. SHAKUMBARI AUTOMOBILES (P) LTD (6N02-01), E-5/6, INDUSTRIAL AREA, HARDIWAR - 249407
PH : 9927870025, 8869064400.

JASPUR

2730. AKANKSHA AUTOMOBILES (RUDRAPUR) PVT LTD (BKL2-01), GANGUWALA, INFRONT OF ROOPAM CONVENT, KASHIPUR ROAD, JASPUR, UTTARAKHAND. - 244712
PH : 8192000724.

KARANPRAYAG

2731. ROHAN MOTORS LTD (CRG1-01-), BADRINATH ROAD, KARANPRAYAG, DISTRICT – CHAMOLI, UTTARAKHAND . - 246444
PH : 8126129148.

KASHIPUR

2732. AKANKSHA AUTOMOBILES (RUDRAPUR) PVT LTD (DG02-01-), BAZPUR ROAD, KASHIPUR - 244713
PH : 8929400544, 8859502626.

KHATIMA

2733. AKANKSHA AUTOMOBILES (RUDRAPUR) PVT LTD (XL02-01-), VILLAGE: CHARUBETA,NEAR RTO CHECK POST,PILIBHIT ROAD KHATIMA, U.S NAGAR,UTTRAKHAND . - 262308
PH : 8929400545, 8191000565.

KOTDWAR

2734. SHAKUMBARI AUTOMOBILES (P) LTD (6N02-02-), PLOT NO.23 & 30 INDUSTRIAL ESTATE, SITABPUR, KOTDWAR, DIS. PAURI (GARHWAL), UTTRAKHAND . - 249001
PH : 875598075, 7310106565.

LAKSAR

2735. SHAKUMBARI AUTOMOBILES (CTF1-01-), HARIDWAR ROAD, LAKSAR - 247664
PH : 9927877715.

NANAKMATA

2736. AKANKSHA AUTOMOBILES (RUDRAPUR) PVT LTD (CVT1-01-), KHATIMA ROAD, OPP GURURAMDAS HOSPITAL, NANAKMATA, U.S. NAGAR, UTTRAKHAND. - 262311
PH : 9012172084.

PITHORAGARH

2737. NAINITAL MOTORS PVT LTD (J603-03-), VILLAGE PANDA, ODSAINI, DHARCHULA ROAD, PITHORAGARH - 262501
PH : 9634092692.

PRATAPNAGAR

2738. SHAKUMBARI AUTOMOBILES (STT1-01-), NEAR AISHWARYA FILLING STATION, LAMBGAON, PRATAPNAGAR, DISTRICT TEHRI., UTTARAKHAND - 249165
PH : 9927877715.

RAMNAGAR

2739. NAINITAL MOTORS PVT LTD (XM01-01-), BASAI, KASIPUR ROAD, RAMNAGER - 244137
PH : 9639016895, 9634093404.

RANIKHET

2740. NAINITAL MOTORS PVT LTD (AXA1-01-), GANYADOLI, NEAR DRUG FACTORY, RANIKHET DISTT. ALMORA (UTTRAKHAND) - 263645
PH : 9557243222.

RISHIKESH

2741. FUTURE AUTO WHEELS PVT LTD (AAS1-01-), 640, LAXMAN JHULA ROAD, RISHIKESH. DISTT. DEHRADUN, UTTARAKHAND . - 249201
PH : 0135-2423287, 7895614411.

ROORKEE

2742. SHAKUMBARI AUTOMOBILES (P) LTD (H201-01-), 3RD KM STONE, DELHI-ROORKEE HIGHWAY, NEAR IOC PETROL BUNK, ROORKEE DISTT HARIDWAR - 247667
PH : 7055104191.

RUDRAPRAYAG

2743. ROHAN MOTORS (IK01-01-), GULABRAI-BADRINATH ROAD, RUDRAPRAYAG - 246171
PH : 8650876815.

RUDRAPUR

2744. AKANKSHA AUTOMOBILES (RUDRAPUR) PVT LTD (U404-01-), KICHHA BYE PASS ROAD, INDUSTRIAL AREA, RUDRAPUR - 263153
PH : 8929400545, 8859502864.

SELAQUI

2745. ROHAN MOTORS LTD (CRF1-01-), KHASRA NO.783, BAHADURPUR ROAD, NH-72, SELAKUI, DISTT.-DEHRADUN, UTTARAKHAND. - 248011
PH : 8006000439.

SITARGANJ

2746. AKANKSHA AUTOMOBILES (RUDRAPUR) PVT LTD (CD02-01-), PLOT NO.228/2 AND 228/6 KHATIMA ROAD, SITARGANJ, DISTT - RUDRAPUR, UTTARAKHAND. - 262405
PH : 8929400545, 8859502846.

SRINAGAR

2747. SHAKUMBARI AUTOMOBILES (ANA1-01-), SRICOTGANAGANALI, NEAR MEDICAL COLLEGE, PO- SRICOT, SRINAGAR - 246174
PH : 8755903005, 9897476897.

TEHRI

2748. DD MOTORS (A DIVISION OF D.D. PREM PVT LTD.) (QA02-01-), PLOT NO. 541, SECTOR-4E, DISTT. - NEW TEHRI - 249001
PH : 8006000914.

UTTARKASHI

2749. DD MOTORS (A DIVISION OF D.D. PREM PVT LTD.) (6I02-01-), HOTEL RAMOLA, BARETHI CHUNGI, GANGOTRI NATIONAL HIGHWAY, UTTARKASHI . - 249151
PH : 8006000922.

VIKAS NAGAR

2750. ROHAN MOTORS (R102-01-), KHASRA NO. 433/9/2, JEEVANGARH, POST OFFICE- AMBARI, CHAKRATA-BARKOT ROAD, VIKAS NAGAR. - 248198
PH : 9897507410.

UTTRAKHAND

DEHRADUN

2751. SHAKUMBARI AUTOMOBILES (5708-01-), KHASRA NO.15-ANA, MOHABBEWALA, SAHARANPUR ROAD, DEHRADUN, PIN-248001, UTTARAKHAND - 248001
PH : 9927870025, 8869064400.

PATI

2752. AKANKSHA AUTOMOBILES (RUDRAPUR) PVT LTD (SFX1-01-), LOHAGHAT- HALDWANI MAIN ROAD, NEAR PITHORAGARH CO-OPERATIVE BANK, PATI-262528 - 262528
PH : 9917467820.

WEST BENGAL

ALIPURDUAR

2753. PODDAR CAR WORLD PVT. LTD. (BZ01-01-), BIRPARA MORE, COOCH BEHAR ROAD, BESIDE GOYENKA PETROL PUMP, ALIPURDUAR, WEST BENGAL . - 736121
PH : 8945533002
9735008343
9749707070.

AMTALA

2754. BHANDARI AUTOMOBILES PVT LTD (BQH1-01-), VILLAGE - UDAYRAMPUR, P.O. - KANYANAGAR, P.S. - BISHNUPUR, AMTALA, DIST.-24 PARGANAS SOUTH, WEST BENGAL - 743 398
PH : 9903850402.

ARAMBAGH

2755. SANEI MOTORS PVT. LTD. (7T02-01-), R.S. DAG NO. 1887, R.S. KHATIAN NO. 104, HAL KHATIAN NO. 1233, MOUZA-PARUL, J.L.N. 38, R.S.NO. 3111, P.S. ARAMBAGH, DISTT. HOOGHLY, WEST BENGAL - 712601
PH : 8584050184.

ASANSOL

2756. BEEKAY AUTO PVT LTD (F601-01-), CHANDA MORE, N.H.-2, ASANSOL - 713301
PH : 9932049425,
9932049435.

BADURIA

2757. PREMIER CARWORLD (SOE1-01-), VILL- KIRTRIPUR, P.O- MANDRA, P.S - BADURIA, DIST - NORTH 24 PARGANAS, WEST BENGAL. PIN - 743438 . - 743438
PH : 9831414956.

BAGDAH

2758. SANEI MOTORS PVT. LTD. (BON1-01-), C/O, DINABANDHU TARAFDAR, S/O LATE NARENDRANATH TARAFDAR, VILLAGE – HALENCHA SOUTH, P.O. – HALENCHA COLONY, P.S. – BAGDAH, DISTRICT – NORTH 24 PARGANAS, WEST BENGAL . - 743270
PH : 8584050184.

BABHRAMPUR

2759. BEEKAY AUTO PVT LTD (DJ02-01), BOKULTALA (PASCHIM GAMINI), NH-34, BAHARAMPUR, DISTT. MURSHIDABAD. - 742101 PH :267340.
- BAJKUL**
2760. BHANDARI AUTOMOBILES PVT LTD (CAV1-01), VILLAGE – KAPTYAPA BARI, P.O. – KALJAGARH, P.S. – BHAGWANPUR, BAIKUL, DISTRICT – PURBA MIDNAPORE. - 721626 PH :9933055539.
- BALAGARH**
2761. SANEI MOTORS PVT. LTD. (BMMI-01-), DAG NO. 671, MOUZA – BARUIPARA, J L NO. 100, P.O. - BALAGARH, DIST–HOOGLY, WEST BENGAL - 712 501 PH :8584050184.
- BALURGHAT**
2762. J K WHEELS PVT. LTD. (PT01-01), BARO RAGHUNATHPUR, P.O. - BELTALA PARK, P.S. - BALURGHAT, DIST.-DAKSHIN DINAJPUR. - 733 103 PH :9064301464.
- BANDEL**
2763. SANEI (612-03), C/O G.S. LAMINATOR, BANDEL STATION ROAD, HOOGLY 712123 - 712123 PH :8336969010.
- BANKURA**
2764. BHANDARI AUTOMOBILES PVT LTD. (G701-02-), PLOT NO.-156, KH NO.-173, MITHILA MOUZA, AT/PO-BANKURA (WB) - 722101 PH :25766.
- BARASAT**
2765. PREMIER CARWORLD PVT. LTD. (XZ03-01), R.S DAG NO. 512 AND PARTY IN DAG NO. 513, MOUZA-KHILKAPUR, P.O BARASAT, POLICE STATION: DUTTA PUKUR, TOUZI NO. 146, J.L NO. 4, DISTRICT – NORTH 24 PARGANAS, WEST BENGAL - 700125 PH :3420122407.
- BARDHAMAN**
2766. BEEKAY AUTO PVT LTD (T301-03)-, NH-2, PAMRA VILLAGE ROAD, CHANDNI MORE, SATTAR MILE, BURDWAN, WEST BENGAL - 713101 PH :9932049454.
- BARJORA**
2767. BHANDARI AUTOMOBILES PVT LTD (BED1-01-), VILLAGE A.P.O. + P.S. – BARJORA, MOUZA – BARJORA, JL NO. 46, KHATIAN NO. 3380, PLOT NO. 2795, BARJORA DISTRICT – BANKURA, WEST BENGAL - 722202 PH :8016087297.
- BARRACKPORE**
2768. STARBURST MOTORS PVT LTD (BXJ1-02-), NEAR RAIL GATE, WARD NO. 24, WEST BARASAT ROAD, P.S. – TITAGARH, BARRACKPORE, DISTRICT – NORTH 24 PARGANAS, KOLKATA. - 700120 PH :8335061333.
- BARSUNDRA**
2769. BHANDARI AUTOMOBILES PVT LTD (G701-05-), PLOT NO. 610, BARSUNDRA, ISHWARDAHA, JALPAI, P.S. BHAWANIPUR, EAST MIDNAPORE. WEST BENGAL - 721654 PH :9933055539.
- BASIRHAT**
2770. BHANDARI AUTOMOBILES PVT LTD (X701-03-), RAGHUNATHPUR, TALKI ROAD, BASIRHAT NR. INDIAN PERTOL PUMP, NORTH-24 PARGANAS. - 743428 PH :8017569789.
- BELACOBA**
2771. PODDAR CARWORDL (SCU1-01), PRASANNA NAGAR, BELACOBA, BATTALA, JALPAIGURI - 735133 - 735133 PH :8945533002.
- BIRPARA**
2772. SEVOKE MOTORS (CQL1-01), BHAGAT PARA, NH - 31, MADARIHAT ROAD, BIRPARA, BESIDE TASHI HOTEL, OPP. - HIMALYAN HOTEL, P.S. - MADARIHAT, DIST - ALIPURDUAR, PIN - 735204 - 735204 PH :9800069144.
- BISHNUPUR**
2773. BHANDARI AUTOMOBILES PVT LTD (AAG1-01-), STATION ROAD, P.O+P.S. BISHNUPUR, DIST: BANKURA, WEST BENGAL - 722122 PH :9933055539.
- BOLPUR**
2774. SAINATH AUTOLINKS PVT. LTD. (4402-03-), KABI JOYDEB ROAD, NEAR BOLPUR BY PASS, BOLPUR, DIST: BIRBHUM - 731204 PH :9647444888 8927895511.
- BONGAON**
2775. STARBURST MOTORS PVT LTD (TQ02-01-), 376/D, R D B ROAD, NEAR JESSORE ROAD, BAKSHIPALLY, BONGAON, NORTH 24 PARGANAS, WEST BENGAL - 743235 PH :9748298939.
- BUDGE BUDGE**
2776. ONE AUTO PVT. LTD. (BAV1-01-), MAHESH TALA, NEAR DAKGHER KALIMANDIR, BUDGE BUDGE TRUNK ROAD, DAKGHER, WARD NO. 22, POLICE STATION-MAHESHTALA, WEST BENGAL - 700141 PH :8584878802 760404762.
- C K ROAD**
2777. BHANDARI AUTOMOBILES PVT LTD (D001-01-), P.O:SAT BANKURA, PS:GARBETA, CHANDRAKONA ROAD, DIST. PASCHIM MIDNAPORE, WEST BENGAL - 721252 PH :9933055539.
- CANNING**
2778. ONE AUTO (CEG2-01-), SUSUMAPALLY, CANNING, DIST – SOUTH 24 PARGANAS, WB - 743329 PH :8442830001.
- CHAKDAHA**
2779. BHANDARI AUTOMOBILES PVT LTD (OM01-01-), VILLAGE – PUMILA, P.O. – CHAKDAHA, DISTRICT – NADIA, WEST BENGAL - 741222 PH :9073940368, 9674735303, 9674169007.
- CHANCHAL**
2780. J K WHEELS (SSI1-01-), CHANCHAL AZAD PALLY, OPPOSITE OF PWD 2ND GATE, P.O - CHANDRAPARA, P.S - CHANCHAL, DIST - MALDA - 732123 - 732123 PH :9734963360.
- CHANDITALA**
2781. BHANDARI AUTOMOBILES PVT LTD (BPC3-01-), RS DAG NO.2986, LR DAG NO. 3150, UNDER L R KHATIAN NO.3859, MOUZA- KRISHNARAMPUR, J.L. 59, POLICE STATION- CHANDITALA, HOOGHLY, WEST BENGAL - 712702 PH :6296900498.
- CHANDRAKONA**
2782. BHANDARI AUTOMOBILES PVT LTD (D001-02-), AT. VILL. GOSAI PO+PS CHANDRAKONA TOWN, MOUZA DHARABILA, J.L.NO. 095, KHATIAN NO. 315, PLOT NO. 203 & 189, NEAR MUNIPAL GATE TOWARDS C.K. ROAD. - 721201 PH :8945526833.
- CONTAI**
2783. BHANDARI AUTOMOBILES PVT LTD (G701-03-), SERPUR BAMUNBAR,P.O MARISHDA, NEAR MECHEDA BYPASS, CONTAI, WEST BENGAL - 721401 PH :254572.
- COOCH BEHAR**
2784. PODDAR CAR WORLD PVT. LTD. (BWZ1-01-), CHAKCHAKA, NEELKUTHI BAZAR, NEAR ADA FACTORY, NH-31, COOCH BEHAR, WEST BENGAL - 736101 PH :8945533002 9735008343.
- DARJEELING**
2785. BEEKAY AUTO PVT LTD (4301-05-), MERRY VILLA, DARJEELING, DISTRICT-DARJEELING . - 734101 PH :9932049347 9932049382 7478004430.
- DHUPGURI**
2786. BEEKAY AUTO PVT LTD (BW1D-01-), MOUZA – DHUPGURI, PLOT NO. 1814, WARD NO. 16, DHUPGURI, DISTRICT – JALPAIGURI, WEST BENGAL . - 735210 PH :7477785203 9932049347 9932049382 7478004430.
- DIAMOND HARBOUR**
2787. ONE AUTO PVT. LTD. (YE01-01-), VILLAGE – CHEWRA, OPPOSITE – K.E. CARMEL SCHOOL, P.O – SARISHA HAT, P.S. – DIAMOND HARBOUR, DISTRICT – 24 PARGANAS (S) , WEST BENGAL . - 743368 PH :8584862243.
- DINHATA**
2788. BEEKAY AUTO (BWE1-01-), ADDRESS: VILLAGE - KARISHAL, MAIN ROAD, P.O- DINHATA, DIST - COOCHEBEAR, - 736135 PH :9932049347.
- DURGAPUR**
2789. SAINATH AUTOLINKS PVT. LTD. (4402-01-), PLOT NO-743, MAUZA FRIDPUR, BURDWAN, DURGAPUR - 713213 PH :9647444888 8927895511.
- FALAKATA**
2790. PODDAR CAR WORLD PVT. LTD. (CSR1-01-), DAKSHIN PARANGAPAR, KHATIAN NO. 167/1 JL NO. 60, DAG NO. 652/1159, P.S. – FALAKATA , DIST ALIPURDWAR - 735211 PH :8945533002.
- GAZOLE**
2791. JK WHEELS (SKZ1-01-), MOUZA- BAJEGAIRAL, RANIGANJ, PURBAPARA, KAMALDANGA, P.S- GAZOLE, DIST-MALDA, PIN - 732138 - 732138 PH :9734963360.
- GHATAL**
2792. BHANDARI AUTOMOBILES PVT LTD (AAD1-01-), VILL. NIMTOLA, P.O. & P.S. DASPUR, GHATAL, WEST MIDNAPORE, WEST BENGAL - 721211 PH :9933055539.
- GOPIBALLAVPUR**

Dealer Network (AS ON 31.10.2023)

2793. BHANDARI AUTOMOBILES PVT LTD (BPO1-01-), JL NO. 1103, KHATIAN NO. 1103, PLOT NO. 438, VILLAGE + P.O. + P.S. - GOPIBALLVPUR , MOUZA - GOPIBALLVPUR, WEST MIDNAPUR, WEST BENGAL. - 721506 PH :9933055539, 8170018577.
- GUMA (ASHOKNAGAR)**
2794. STARBURST MOTORS PVT LTD (BXJ1-03-), JESSORE ROAD, MANIKNAGAR, KHOSEDELPUR MORE, P.S. - ASHOKNAGAR, NORTH 24 PARGANAS, WEST BENGAL. - 743222 PH :8697731763, 8336933447.
- HALDIA**
2795. BHANDARI AUTOMOBILES PVT LTD (G701-04-), BALGHASIPUR, BHABANIPUR, PURBA MEDIANPUR, HALDIA - 721657 PH :8016082344, 9233052421.
- HOWRAH**
2796. BHANDARI AUTOMOBILES PVT LTD (X701-01-), BANKRA THANA,DOMJUR,HOWRAH. - 711403 PH :9674735304.
2797. PREMIER CARWORLD PVT. LTD. (611-02-), MOUZA – PRASASTHA, P.S. - DOMJUR, UNDER MOHARY 2 NO. GRAM PANCHAYAT, ANKURHATI, HOWRAH, WEST BENGAL. - 711302 PH :8420122402.
- JALPAIGURI**
2798. PODDAR CAR WORLD PVT. LTD. (XY01-01-), COLLEGE PARVA, SIRISHTALA, NEAR ASSAM MORE, JALPAIGURI, WEST BENGAL. - 735101 PH :8945533002.
- JAYGAON**
2799. SEVOKE MOTORS PVT. LTD. (CHS1-01-), HOUSE NO.4, WARD NO.11/22, N.S ROAD DARAGAON, P.S - JAYGAON, DISTT. ALIPURDUAR, WEST BENGAL - 736182 PH :9433825851.
- JHARGRAM**
2800. BHANDARI AUTOMOBILES PVT LTD (BUG1-01-), DAG NO.383, KHATIAN NO. JL396, WARD NO.11, RAJBATI CAMPUS, JHARGRAM, WEST BENGAL - 721507 PH :8016087297, 9933055539.
- KADAMBAGACHI**
2801. STARBURST MOTORS PVT LTD (BXJ1-04-), MOUZA - PURBA ICHAPUR, J L NO. 111, RESU NO. 131, DAG NO. 385, KHATIAN NO. L R 754, KADAMBAGACHI, P.S. - BARASAT, DIST.-NORTH 24 PARGANAS, WEST BENGAL. - 700125 PH :8336933410.
- KALIMPONG**
2802. BEEKAY AUTO (BWF1-01-), 10TH MILE, GUMBA HATTA, PO&PS -KALIMPONG, DIST - KALIMPONG, WB. - 734301 PH :9932049347.
- KALNA**
2803. BEEKAY AUTO PVT LTD (WZ01-01-), KALNA ROAD, NEAR KALNA SUB DIVISIONAL HOSPITAL, KALNA, PO+PS: KALNA, DISTT. BURDWAN, (W.B.) - 713409 PH :9932251483.
- KALYANI**
2804. STARBURST MOTORS PVT LTD (IJ01-01-), KALYANI INDUSTRIAL GROWTH CENTRE, PHASE-III, A-5 (OPP. U.I.C UDYOG, NEAR: J I S COLLEGE), KALYANI. - 741234 PH :8584040215, 8336933447.
- KHARAGPUR**
2805. BHANDARI AUTOMOBILES PVT LTD (G701-01-), BHANDARI BUILDING, JHAPATAPUR, KHARAGPUR, WEST BENGAL - 721301 PH :755537.
2806. PODDAR CARWORLD (G702-01-), RS DAG NO - 147, RS KHATIAN NO 7, MOUZA - MOBARAKCHAK, JL NO-210, PS - KHARAGPUR - 721301 PH :9831348626.
- KHATRA**
2807. BHANDARI AUTOMOBILES PVT LTD (BGZ1-01-), VILLAGE - SENAPATI, P.O & P.S - KHATRA, MOUZA-SENAPATI, JL NO.189, KHATIAN NO.659, PLOT NO.33/34, DISTT. BANKURA, WEST BENGAL - 722140 PH :9933055539.
- KOLKATA**
2808. MACHINO TECHNO SALES LTD. (601-02-), 48 A, TARATALA ROAD, KOLKATA - 700066 PH :907330177.
2809. DEWAR'S GARAGE (605-01-), (PROP. DELTA INTERNATIONAL LTD.), 14 BRITISH INDIAN STREET, CALCUTTA - 700069 PH :8584015205.
2810. MACHINO TECHNO SALES LTD. (601-01-), 21/1 DARGA ROAD, (PARK CIRCUS), CALCUTTA - 700017 PH :907330178.
2811. PREMIER CARWORLD PVT. LTD. (611-01-), AGARPARA JUTE MILL, 28-B.T.ROAD, P.O.: -KAMARHATI, DISTT.-KOLKATA - 700058 PH :8697730344.
2812. BHANDARI AUTOMOBILES PVT LTD (609-01-), BUDGE BUDGE TRUNK ROAD, NEW GOPALPUR, SARKARPOOL, MAHESHTALA, DISTT. SOUTH 24 PARGANAS, WEST BENGAL - 700143 PH :9674476000.
2813. BHANDARI AUTOMOBILES PVT LTD (609-02-), 37, GULAM JILANI KHAN ROAD, KOLKATA. - 700039 PH :9930850402.
2814. SANEI MOTORS PVT. LTD. (612-01-), 16/2 CANAL EAST ROAD, NEAR MANIKTALA POLICE STATION,KOLKATA - 700067 PH :85840510184.
2815. ONE AUTO PVT. LTD. (614-02-), 62 EAST TOPSIA ROAD, P.S. TILJALA, ARUPOTA, KOLKATA , WEST BENGAL - 700105 PH :8584878802.
2816. ONE AUTO PVT. LTD. (614-01-), JL NO.3, MOUZA-JAGADIPOTA, P.S:SONARPUR, KHEYADHA NO.2, GRAM PANCHAYAT, DISTT. SOUTH 24 PARGANAS. - 700099 PH :8584870725.
2817. DEWAR'S GARAGE (605-03-), P-27/2, TARATALA ROAD, KOLKATA - 700088 PH :8584015293.
2818. SANEI MOTORS PVT LTD (612-02-), 235, HATIYARA ROAD, SITALATALA, BAGUIATI, KOLKATA, WEST BENGAL - 700059 PH :85840510184.
2819. OSL MOTOCORP PVT LTD (616-01-), 49 DEBENDRA CHANDRA DEY ROAD, LANE BESIDE SILVER SPRING CLUB, E.M. BYE-PASS, KOLKATA - 700015 PH :8336996355, 8697982283.
2820. JYOTE MOTORS (624-01-), NAZRABAD MAIN ROAD, NAZRABAD, ANANDAPUR, NEAR BISHNU BIJOLI GARDEN, KOLKATA, PIN-700150, WEST BENGAL - 700150 PH :8334930830.
- KOLKATTA**
2821. BHANDARI AUTOMOBILES (619-C1-), PLOT NO. IID/15, ACTION AREA 2D, NEW TOWN, P.S. RAJRAHAT, KOLKATA, WEST BENGAL PIN-700156 - 700156 PH :6291042160.
- KOTULPUR**
2822. BHANDARI AUTOMOBILES PVT LTD (BIP1-01-), KHATIAN NO.644, PLOT NO.373, J L NO. 101, VILLAGE - MULDARA, P.S. + P.S. - KOTULPUR, DISTT.-BANKURA, WEST BENGAL. - 722141 PH :9930305539.
- KRISHNANAGAR**
2823. BHANDARI AUTOMOBILES PVT LTD (X701-02-), PLOT NO.-1874, MOUZA-GOBINDSARAK, J.K. NO. 94, PS-KOTWAL, OLD WARD NO. 20, LAL MOHAN GHOSH ROAD, KRISHNANAGAR - 742011 PH :9051999742.
- MADHYAMGRAM**
2824. STARBURST MOTORS PVT LTD (BXJ1-01-), 9/1, HEMANTA BOSE SARANI, BASUNAGAR, NEAR DEAF & DUMB SCHOOL, UDAYRAJPUR, MADHYAMGRAM - 700129 PH :9836075989, 8336933447.
- MALBAZAR**
2825. BEEKAY AUTO PVT LTD (BWG1-01-), CALTEX MORE, VILLAGE + P.S. - MALBAZAR AND DISTRICT - JALPAIGURI. - 735221 PH :9932049347, 9932049382, 7478004430, 7477785203.
- MALDA**
2826. J K WHEELS PVT. LTD. (L801-01-), GABGACHHI, N.H. 34, MALDA. - 732103 PH :9851520855, 9735003949.
- MATHABHANGA**
2827. BEEKAY AUTO PVT LTD (BQF1-01-), SITAKULCHI ROAD, WARD NO.9,MATHABHANGA, DISTRICT - COOCHBEHAR. - 736146 PH :7477785202, 9932049347, 9932049382, 7478004430.
- MOHANPUR**
2828. BHANDARI AUTOMOBILES PVT LTD (CIV1-01-), VILLAGE-NAYAGAON, P.O.-PAROI, P.S. -MOHANPUR, MOUZA - NAYAGAON, JL NO.395, KHATIAN NO.175/1, PLOT NO.895, DISTT. -PASCIM MIDNAPUR,W.BENGAL. - 721436 PH :9933055539.
- NAIHATI**
2829. PREMIER CARWORLD PVT. LTD. (YD01-01-), P.O. BHATPARA, GRAM-MUKTARPUR, P.S. - JAGATDAL, DIST-24 PGS (N), NAIHATI (WB) - 741323 PH :801700824.
- NAKASHIPARA**
2830. BHANDARI AUTOMOBILES PVT LTD (BMJ1-01-), L R DAG NO. 7271, UNDER L R KHATIAN NO. 6734, MOUZA - DEBAGRAM, J L NO. 60, POLICE STATION - KALIGANJ BLOCK - KALIGANJ, NAKASHIPARA, DIST.-NADIA, WEST BENGAL. - 741138 PH :9163314418.
- NAXALBALI**

2831. BEEKAY AUTO PVT LTD (CSJ1-01), MOUZA – GENI, KHATIAN NO.275, PARGANA-HATIGISHA, P.S. NAXALBARI, DISTT. DARJEELING, WEST BENGAL - 734429 PH :9932049347
9932049382
7478004430
9563370099.

PANCHLA

2832. BHANDARI AUTOMOBILES PVT. LTD. (BPI1-01-), L.R DAG NO 3274, UNDER L.R KHATIAN NO 3044, MOUZA-MALLICKBAGAN, JL NO-7, POLICE STATION – PANCHLA, DIST- HOWRAH - 711310 PH :9073664926.

PANDUA

2833. BHANDARI AUTOMOBILES PVT LTD (BOS1-01-), GT ROAD, PANDUA, NEAR KAKOLI CINEMA HALL, OPP. POWER HOUSE, HOOGLY, WEST BENGAL - 712149 PH :9073912566.

PANSKURA

2834. BHANDARI AUTOMOBILES PVT LTD (BPS1-01-), MOUZA – PASCHIM NEKRA, JL NO.98, LR NO.1154, LR NO.1156, PANSKURA, WEST BENGAL - 721139 PH :9933055539.

PURULIA

2835. SAINATH AUTOLINKS PVT. LTD. (4402-02-), PO. LAKDA, VILLAGE-DADKA , ON RANCHI ROAD, PURULIA - 723149 PH :9647444888 8927895511.

RAGHUNATHPUR

2836. BEEKAY AUTO PVT LTD (CKZ1-01-), MOUZA – BUNDLA, J.L. NO. 197, PLOT NO. 2656, KHATIAN NO. LR 207, P.O. – RAGHUNATHPUR, P.S. – RAGHUNATHPUR, DISTRICT – PURULIA. - 723133 PH :9932049425, 9932049435.

RAIGANJ

2837. J K WHEELS PVT. LTD. (BN02-01-), JL NO. 150, KHATIAN NO. 168/3 & 168/4, PLOT NO. 4158., P.S. – RAIGANJ, MUNICIPALITY – RAIGANJ, WARD NO. 11, HOLDING NO. 577/N, MOUZA – RAIGANJ, DISTRICT – UTTAR DINAJPUR. - 733134 PH :9735008842.

RAJARHAT - KOLKATA

2838. STARBURST MOTORS PVT LTD (BXJ1-05-), R.S & L.R. DAG NO. 3434, MOUZA- GOPALPUR, JL NO. -02, RS NO. -140, LR KHATIAN NO.-5638, NEW TOWN, RAJARHAT - 700136 PH :9681080301.

RANAGHAT

2839. STARBURST MOTORS PVT LTD (BBW1-01-), THANA: GANGNAPUR, ADSR OFFICE, 151 NO.MOUZA PATULI, PLOT NO.309, RANAGHAT, DISTT: NADIA - 741256 PH :8145821191, 858404215.

RUPNARAYANPUR

2840. BEEKAY AUTO PVT LTD (BWS1-01-), P.S. – SALANOUR, UNDER MOUZA – JEMARI, J.L. NO. 32, PLOT NO. 343-344, KHATIAN NO. 933, RUPNARAYANPUR, PASCHIM BARDHAMAN DISTRICT, WEST BENGAL. - 713335 PH :9932049425, 9932049435.

SABANG

2841. BHANDARI AUTOMOBILES PVT LTD (CCL1-01-), VILLAGE - PAIKAN DAKSHINBARI, P.O. - DHANWARPUR & P.S. - PINGLA, DIST. -PASCHIM MIDNAPORE, SABANG - 721166, WEST BENGAL. - 721166 PH :9933055539.

SEORI

2842. BEEKAY AUTO PVT LTD (F601-02-), RAMBADPUR, NEAR SP MORE, DIST-BIRBHUM, SEORI - 731101 PH :9932049425, 9932049406.

SHYAMPUR

2843. SANEI MOTORS PVT LTD (CAW1-01-), VILLAGE + P.O. – GOBINDAPUR, P.S. – SHYAMPUR, DISTRICT - HOWRAH, WEST BENGAL . - 711314 PH :8584050184.

SILIGURI

2844. BEEKAY AUTO PVT LTD (4301-01-), NH-31, P.O. MATIGARA,SILIGURI. - 734428 PH :9932049347
9932049382
7478004430.

2845. BEEKAY AUTO PVT LTD (4301-04-), AMAI DIGHI, PHOOL BARI STATE HIGHWAY -12, SILIGURI - 734001 PH :9932049347
9932049380.

2846. SEVOKE MOTORS PVT. LTD. (4302-01-), 233, SEVOKE ROAD,2ND MILE, SILIGURI - 734001 PH :9706010366.

2847. PODDAR CAR WORLD PVT LTD (XY01-02-), VILL. EAST DHANTALLA, FULBARI II G.P. P.O SATELLITE TOWNSHIP, DIST- JALPAIGURI - 734015 PH :8945533002.

SONADA

2848. SEVOK (SDX1-01-), RATO MATEY DARA, NEAR PETROL PUMP,P.O- SONADA, WEST BENGAL PIN - 734209 - 734209 PH :9800069144.

SONAMUKHI

2849. BHANDARI AUTOMOBILES PVT LTD (CAU1-01-), J.L NO. 77, KHATIAN NO. 360, PLOT NO. 114/287, SONAMUKHI BISHNUPUR ROAD, VILLAGE - CHURAMANIPUR, P.O. & P.S. - SONAMUKHI, WEST BENGAL. - 722207 PH :9933055539.

SREERAMPORE (SREERAMPUR)

2850. BHANDARI AUTOMOBILES PVT LTD (BBT1-01-), BANGI HATI (MADPUR) DELHI ROAD, SREERAMPUR, DISTT: HOOGHLY, WB - 712203 PH :66137505, 66137585, 9674741544.

TAMLUK

2851. BHANDARI AUTOMOBILES PVT LTD (OL01-01-), MOUZA PADUMBASAN, WARD NO 10, JL NO:144, DISTT: EAST MIDNAPUR, WEST BENGAL - 721636 PH :9933055539.

TARAKESHWAR

2852. SANEI MOTORS PVT. LTD. (YH01-01-), MOUZA BAIDYAPUR, UNDER BALIGURI(1), GRAM PANCHAYET, TARAKESHWAR, DISTT. HOOGLY, WEST BENGAL - 712410 PH :8584050184.

TOOFANGANJ

2853. PODDAR CAR (SDG1-01-), POWER HOUSE PARA, PO ANDARANFULBARI (WEST), TUFANGANI, COOCHBEHAR, PIN-736159, WEST BENGAL - 736159 PH :8945533002.

UDAYNARAYANPUR

2854. BHANDARI AUTOMOBILES PVT LTD (BOO1-01-), VILLAGE-JANGALPARA BELGRAM, PS- UDAYNARAYANPUR, DIST- HOWRAH, WEST BENGAL . - 711226 PH :9073664902.

ULUBERIA

2855. BHANDARI AUTOMOBILES PVT LTD (2401-01-), HOLDING 1242A, BANITALA, P.O+P.S: ULUBERIA, NH-6, DISTT: HOWRAH, WEST BENGAL - 711316 PH :8335052335.

DELHI

DELHI

1. MARUTI SALES & SERVICE(DELHI) (0810-08-01),
C-119, INDUSTRIAL AREA PHASE-I, NARAINA,
NEW DELHI - 110028
PH :45541113.
2. J J IMPEX (DELHI) LTD(MARUTI SERVICE
MASTERS) (0883-08-01), F-39,OKHLA
INDUSTRIAL AREA,PHASE-II,NEW DELHI -
110020
PH :41612194, 40685500.

TAMIL NADU

CHENNAI

3. J J IMPEX (DELHI) LTD(MARUTI SERVICE
MASTERS) (1485-14-01), # 9, (SP),THIRU-VI-KA
INDUSTRIAL ESTATE, GUINDY, CHENNAI -
600032
PH :044-43563366, 43563367, 9176615000.

- ARUNACHAL PRADESH**
- ITANAGAR**
1. HIBRO AUTOMOBILES (7581-75-01), D-SECTOR, DISTT: PAPUMPARE, ITANAGAR - 791111
PH :700537938.
- ASSAM**
- BARPETA**
2. ROY AUTO ENGINEERING WORKS (7Z81-7Z-01), POST OFFICE, BARPETA ROAD, MAIN ROAD , WARD NO.-4, ASSAM - 781315
PH :9954069396.
- DULIAJAN**
3. B.S. MOTORS (X881-X8-01), NO. 01, BORPOTHAR TINALI, DULIAJAN. - 786602
PH :9435719753.
- BIHAR**
- PATNA**
4. CITY AUTO SERVICES (1582-15-01), 9/1, PATLIPUTRA INDUSTRIAL ESTATE, PATLIPUTRA , PATNA - 800013
PH :934117070/821010240.
- DELHI**
5. GALAXY AUTOMOBILES (0881-08-01), 8 INDUSTRIAL AREA, TILAK NAGAR, NEW DELHI, - 110018
PH :43276666.
 6. A M AUTOMOBILES (A UNIT OF BLUE BIRD ENTERPRISES) (0891-08-01), 189-91, LAWRENCE ROAD,, DELHI - 110003
PH :48280000.
- HARYANA**
- BALLABGARH**
7. ROYAL MOTORS (9R82-9R-01), 21/5, G.T. ROAD, BALLABHGARD, DISTT-FARIDABAD - 121004
PH :4271800; 9899232536;9212142536.
- MURTHAL**
8. MURTHAL AUTO PVT. LTD. (BV81-BV-01), 44 HSIIIDC, MURTHAL - 131027
PH :9215182230.
- PANCHKULA**
9. CARE TAKER (K381-K3-01), PLOT NO. 36, INDUSTRIAL AREA, PHASE-2, PANCHKULA - 134113
PH :9914115427.
- PANIPAT**
10. VIJAY MOTORS (D381-D3-01), PLOT# 136, INDUSTRIAL AREA, PHASE-1 - 132103
PH :9896118618.
- SAHA**
- ARUNACHAL PRADESH**
- ITANAGAR**
11. PUNJAB MOTOR & ENGG WORKS (1881-18-01), NH-73, SHAHZADPUR ROAD, SAHA, DISTT.- AMBALA - 133104
PH :9896666402.
- YAMUNANAGAR**
12. HIRA MOTOR GARAGE (D281-D2-01), PLOT NO 46, SHIVAJI PARK, OPPOSITE MADHU PALACE, YAMUNANAGAR, HARYANA - 135001
PH :8950000069.
- HIMACHAL PRADESH**
- JASSUR**
13. CLASSIC MOTOR GARAGE (8H81-8H-01), TEHSEEL NOOPUR, KANGRA, JASSUR, HIMACHAL PRADESH - 176201
PH :9882217575, 9495900613.
- JAMMU AND KASHMIR**
- SRINAGAR**
14. RAHIM MOTORS (1281-12-01), SIDGO INDUSTRIAL AREA, RANGRETH, SRINAGAR - 2441384
PH :9906631702.
- JHARKHAND**
- RANCHI**
15. PODDAR MOTOR (P) LTD. (5181-51-01), 47, 48 , KOKAR INDUSTRIAL AREA, RANCHI - 834001
PH :2544661, 2542650.
- KERALA**
- COCHIN**
16. AUTOTEAM SALES & SERVICES PVT.LTD (2781-27-01), PIPELINE ROAD, PADIVATTOM, COCHIN, ERNAKULAM, COCHIN - 682024
PH :9025730007.
- PATHANAMTHITTA**
17. AGT MOTORS (W881-W8-01), AGT TOWERS, PUTHENPEEDI, OMALLUR, PATHANAMTHITTA - 689640
PH :9288117477.
- MADHYA PRADESH**
- NEEMUCH**
18. AUTO SCAN (3T81-3T-01), MHOW ROAD,NEEMUCH,MADHYAPRADESH, - 458441
PH :9425106588.
- MAHARASHTRA**
- PUNE**
19. MARUTI CARE POINT (1981-19-02), 17/1, RAHATANI, AUNDH-CHINCHWAD ROAD, OPP PCMC D' PRABHAG KARYALAY, NEXT TO HP SUBHIKA PETROL PUMP, RAHATNI, PUNE, MAHARASHTRA - 411017
PH :9689901459.
- THANE**
- PUNJAB**
20. THANAWALA MOTOR AGENCY (P) LTD (3981-39-01), B-31, OPPOSITE ITI,WAGLE ESTATE MAIN ROAD,WAGLE ESTATE,THANE - 400007
PH :9833947772, 9833947778.
- ODISHA**
- KEONJHAR**
21. KUMAR AUTOMOBILES (7U81-7U-01), DHRUPADA, KEONJHAR, ORISSA - 758001
PH :9437075366.
- PUNJAB**
- BATALA**
22. CITI AUTOMOBILES (V581-V5-01), NEAR GURUDWARA ACHARAH SAHIB, PATHANKOT JALANDHAR ROAD, BATALA, - 143505
PH :9876024243 , 9876024254.
- MOGA**
23. SM AUTO CARE CENTRE (H681-H6-01), OOP. ITI , G.T. ROAD, MOGA - 142001
PH :06136-226807.
- RAJASTHAN**
- JAIPUR**
24. KATARIA AUTOZONE PVT.LTD (1181-11-01), 1-A : NARAYANPURI,KATARIA KRISHI FARM,SIRSII ROAD,JAIPUR - 302034
PH :7427059388.
- TELANGANA**
- HYDERABAD**
25. RETOUCH (1082-10-01), H.NO. 3-67/A, B, C, D,NEW NAGOLE COLONY,NAGOLE VILLAGE, HYDERABAD,NAGOLE, HYDERABAD - 500068
PH :9848062263.
- WEST BENGAL**
- KOLKATA**
38. MANOCO SALES (P) LTD. (0681-06-01), 25/1, CHETLA CENTRAL ROAD, OPPOSITE CHETLA PARK, KOLKATA - 700027
PH :24568326, 24486568, 24568325.
- MEERUT**
30. UNIQUE CAR SCANNERS (4881-48-01), PLOT NO:514/4, SURAJ KUND ROAD, MEERUT, - 250001
PH :98537072642.
- NOIDA**
31. MOTORCRAFT INDIA PVT LTD (A181-A1-01), F-8 & 9,SECTOR-8,NOIDA - 201301
PH :08626172222 & 09971689689.
 32. MOTORCRAFT INDIA PVT LTD (A181-A1-02), C-125,SECTOR-63,NOIDA, - 201301
PH :09958732222 & 09910282222.
 33. JK MOTOR (A184-A1-01), A-25,SECTOR 9,DISTT. GAUTAM BUDD NAGAR,NOIDA - 201301
PH :0120-4052400, 9899424000.
 34. FAST TRACK AUTOCARE(INDIA) PVT. LTD., (A185-A1-01), A-13, SECTOR 63, NOIDA, G.B. NAGAR - 201301
PH :4581111, 4581131/9650631111.
- SAHIBABAD**
35. FAST TRACK SERVICES (M981-M9-01), PLOT NO 40/B/2, 3 & 4, SITE 4, INDUSTRIAL AREA, SAHIBABAD, DISTT: GHAZIABAD (U.P.) - 201010
PH :9560968111.
- UNNAO**
36. VISHAL WHEELERS PVT. LTD. (1382-KL-01), PLOT NO. 1164, KANPUR-LUCKNOW BYE PASS, UNNAO, UTTAR PRADESH, - 209801
PH :2830610,2831248.
- VARANASI**
37. PRATAP ENGINEERS (8481-84-01), S 2, 653/A-2, CLUB ROAD, VARANASI - 221002
PH :25100469, 9415203641.
- GHAZIABAD**
27. KAP AUTOMOBILES PVT. LTD. (5981-59-01), D-BLOCK SHASHTRI NAGAR,HAPUR ROAD,GAZIABAD - 201002
PH :0120-4538200, 9717629599, 9810523345.
 28. CHIRAG AUTOMOBILES (5983-59-01), PLOT NO. B1, SECTOR-3B, TRONICA CITY, GHAZIABAD - 201102
PH :9582945510, 9999107841.
- LUCKNOW**
29. K M AUTOCRAFT (1381-13-01), 76/3, BARAURA, HUSSAIN BARA, HARDOI ROAD, LUCKNOW - 226003
PH :2473369.

BATTERY LABEL SYMBOL MEANINGS

	No smoking, no naked flames, no sparks		Battery acid
	Shield eyes		Note operating instructions
	Keep away from children		Explosive gas

Prepared by

MARUTI SUZUKI INDIA LIMITED

Service Division

July, 2024

Part No. 99011M74T05-74W

Printed in India

**For 24 X 7 assistance, contact Toll Free number 1800 102 6392# / 1800 200 6392#
(NEXA)**

No STD code to be prefixed.

Service Division

MARUTI SUZUKI INDIA LIMITED

Palam Gurgaon Road, Gurgaon - 122 015 (Haryana)

www.marutisuzuki.com



99011M74T05-74W