Lighting Station Manual

Software and devices (in the order they are worked on):

1. Lighting fixtures (floor moving lights, wall washes, ceiling wash/spots, stage PAR cans, house lights)
2. DMX cabling and power
3. The lighting computer
4. ADJ MyDMX 3.0 (lighting control software)
5. The KCC Technical app (checklist, fixture status, outage reports)

Station Definition

This station runs the stage and auditorium lights for every service and event. We make sure every fixture works before the service, run the lighting cues during the service, and report anything broken afterwards. The most important rule is that the lights support the service and never distract from it: no sudden strobes, no sudden dark stages, no colour changes during prayer or ministry.

The list of devices above is organised as they are worked on: fixtures first, then the cables, then the computer and software that control them.

Items marked **[CONFIRM]** are details only the lighting lead can fill in. Replace them before this manual is handed to new crew.

Our Fixtures

Fixture	Qty	Where	Moves?	Notes
Floor lights	4	Floor	Yes	Moving. Keep their beams away from the congregation's eyes.
Wall wash lights	4 (3 active at a time)	Walls	No	3 working at a time
Top wash/spot lights	5	Ceiling	Yes	Moving wash/spot lights, the main stage and speaker lighting. **[CONFIRM wash or spot]**
Stage PAR cans	**[CONFIRM]**	Stage	No	Fixed colour and front fill
House lights	**[CONFIRM]**	Auditorium	No	Brightness of the room. Raise for announcements and dismissal, lower for worship.

The app's Fixtures page should list the same fixtures, so what the app shows and what is in the room match.

Before Service

Arrive at the call time (9:00 AM on Sundays). Open the Service Day page in the KCC Technical app and tick each item as you finish it. The Lighting Station checklist is:

1. **Power on the lighting board.** Switch on the lighting computer and its DMX interface. Never unplug the interface while MyDMX is running. **[CONFIRM: power-on order and where the switches are]**
2. **Check DMX connections.** Confirm the DMX cable runs from the interface to the first fixture and on down the chain. A loose or kinked cable is the most common cause of flickering or dead fixtures.
3. **Run the fixture test.** In MyDMX 3.0, bring each fixture up to full white, one group at a time. Walk the room and look at every fixture. Anything dark, dim or flickering goes on the outage list (see Using the KCC Technical App).
4. **Confirm colour gels are in place.** Check that gelled fixtures still have their gel and that it is not burnt or warped.
5. **Test the moving heads.** Run pan and tilt through their full range, then send them to the home position. Check that none of them hit anything or point into the congregation's eyes.

When the checklist is done, set the opening scene for pre-service and tell the Camera and Streaming stations that the lights are ready.

During Service (MyDMX 3.0)

Open MyDMX 3.0 and load the church's show file. **[CONFIRM: show file name and where it is saved]** Do not edit the show file during service. If a scene needs changing, make a copy and edit the copy after service.

Suggested scenes by part of the service. **[CONFIRM: match these to the scene names in the show file]**

Part of service	Look	Notes
Pre-service	Soft, warm wash	Fade in slowly as people arrive
Worship (fast songs)	Brighter, colour changes allowed	Change colour on song changes, not mid-line
Worship (slow songs)	Dimmer, one or two colours	Keep moving heads still
Announcements	Full front wash	Speaker's face must be clearly lit for the cameras
Prayer and ministry	Low, steady, no movement	No colour changes
Sermon	Bright front wash, stage lit evenly	Cameras need even light on the speaker
Offering	Warm, medium	Match the mood of the song
Dismissal	Bright, full wash	Return to pre-service look after people leave

While running lights:

- Follow the service flow from the order of service in the app, and watch the stage so you can anticipate song and speaker changes.
- Make changes slowly. Use fades rather than hard cuts, except for planned moments.
- Never aim moving heads at the congregation. Avoid strobe effects unless the lead has approved them. Fog and haze are allowed during services and events.
- If the speaker looks dark on camera, tell the Camera station before changing anything yourself.

After Service

1. Fade the stage to the end-of-service look and wait until people have left the room.
2. Report anything that failed or looked wrong during service in the app (outage report, see Using the KCC Technical App).
3. Save nothing over the show file unless the lead asked for a change. Close MyDMX 3.0 normally.
4. Shut down the computer from the Start menu, not the power button, then switch off the DMX interface.
5. Switch off the lighting power. **[CONFIRM: which breakers or switches]**
6. Coil cables, return loose items to their place and leave the station tidy.
7. Mark your station signed off in the app if your team uses the sign-off step.

Troubleshooting

Problem	Check first	Then
One fixture is dark	Is it plugged in and switched on?	Check its DMX address and mode match the show file, then swap the DMX cable to it. If it still fails, report an outage.
Several fixtures flicker or jump	The DMX cable run and connectors	Reseat every connector in the chain. Replace the cable if the problem moves with it.
Everything is dark in the software	Is the DMX interface plugged in and detected by MyDMX 3.0?	Unplug and replug the interface, restart MyDMX, and check that the output is switched on.
Fixture shows the wrong colour	Its gel or colour wheel	Check the fixture's mode and address, then reload the scene.
Moving head will not home or move	Is it powered and in the right mode?	Power-cycle that fixture. If it still fails, report it and use another look without it.
Software freezes	Do not unplug anything	Wait one minute. If it does not recover, restart the computer and reload the show file. Tell the lead.

If the lights cannot be fixed before service starts, tell the service lead, switch to a plain full wash (the work lights if needed), and report the fault in the app after service. Do not take fixtures apart or climb to rigging yourself.

Using the KCC Technical App

- **Service Day checklist:** open Service Day, find the Lighting station and tick items as you go. If you are scheduled on the Lighting station, it opens for you.
- **Fixtures:** the Fixtures page lists every fixture with its name, location, bulb or lamp type and status (OK or Out). Check it before service so you know what is already faulty.
- **Report an outage:** when a fixture is dark or failing, report it on its Fixtures entry. This marks it as Out and tells the admins. Include what you saw (dark, flickering, wrong colour).
- **Bulbs and lamps:** when a lamp is replaced, record it so the app tracks how many hours and replacements each fixture has used. Check Inventory before service for spare lamps. Low stock raises an alert for the admins.
- **Maintenance:** each fixture has a maintenance interval (90 days by default). The app shows what is due. Do not skip these: dusty lenses and loose connectors are the usual reasons for faults.
- **Tech request:** if the problem needs a person or a part, send it as a tech request so it is tracked and does not get lost.
- **Training:** complete the Lighting training modules in the Training Hub. Your progress shows on the station card.

Safety and Contacts

- Let lamps and fixtures cool before touching them. Many fixtures stay hot for several minutes after switching off.
- Use only a safe, stable ladder or lift, with a second person, and only if you have been trained. If a fixture needs work at height, report it instead.
- Never look into a fixture's beam. Never point moving heads at people's faces.
- Keep cables out of walkways or tape them down.
- No open flames, pyrotechnics, or anything fixed to walls, ceilings or fittings without approval.
- Do not plug extra equipment into the lighting power.

Contacts

Role	Name	Phone
Lighting lead	Isaac Ojo	587-664-3421
Technical admin	Isaac Ojo	587-664-3421
Backup	**[CONFIRM]**	**[CONFIRM]**