

Bluetooth Troubleshooting Guide

This guide helps resolve common Bluetooth connectivity issues.

Follow step-by-step instructions based on your problem.

Ensure your device has Bluetooth enabled and sufficient battery.

Keep devices within range (typically 10 meters).

Common Pairing Issues

Problem: Device not appearing in Bluetooth list.

Solution: Ensure the device is in pairing mode.

Restart Bluetooth on your phone.

Restart both devices and try again.

Repeated Pairing Popup Issue

Problem: Device keeps asking for pairing repeatedly.

Cause: Corrupted Bluetooth cache or bonding issue.

Solution:

1. Go to Settings → Bluetooth.
2. Forget the device.
3. Clear Bluetooth cache (Android).
4. Restart device and re-pair.

Connection Drops Frequently

Problem: Device disconnects randomly.

Cause: Interference or low battery.

Solution:

Keep devices close.

Turn off other nearby Bluetooth devices.

Update device firmware if available.

Advanced Troubleshooting

Reset network settings on your phone.

Check for OS updates.

If issue persists, contact support.

Provide logs and device details for faster resolution.