

## 2.5 Cancel Counter

To register the cancellation of Line Clear. It is incremented by one for every cancellation operation done which is a non-resettable type. Cancellation to be done by receiving station & CO-Op by sending station.

## 2.6 Block Telephone

For Speech Communication with SM at other end of Block Section.

## 3.0 Operations of Block Panel:

### 3.1 Method of Signaling Trains from Block Station to Block Station on an UP/DN line in a Double Line section.

- a) SM of the station intending to send a train from his station has to obtain verbal consent on block telephone or alternate means from station in advance before taking LINE CLEAR on its Block Panel. Entries of train no. to be made in registers of both stations.
- b) Before a request for IS LINE CLEAR is sent to station in advance, SM of sending station shall ensure the following near TRAIN GOING TO arrowhead on its Block Panel;
  - i) LINE CLOSED indication YELLOW &
  - ii) LINE FREE indication GREEN &
  - iii) SNK indication YELLOW.
- c) The station in advance while granting his verbal consent shall ensure the following near TRAIN COMING FROM arrowhead on its Block Panel;
  - i) LINE CLOSED indication YELLOW &
  - ii) LINE FREE indication GREEN &
  - iii) **SNK indication YELLOW &**
  - iv) SNOEK indication YELLOW

Then inserts and turns LCB key.
- d) Thereafter SM of sending station presses BELL & TRAIN GOING TO buttons.
- e) The arrowhead, TRAIN GOING TO TRAIN COMING FROM lights up green at sending/receiving station respectively.
- f) SM of sending station releases BELL & TRAIN GOING TO buttons on getting TRAIN GOING TO green indication.
- g) The sending station SM after obtaining LINE CLEAR on its Block Panel can send the train into Block Section by taking the LSS to 'OFF'. On entry of train into section, TRAIN ON LINE lights up RED at both the stations in arrowhead indication. SECTION buzzer sounds at both the stations along with ACKN indication near respective ACKN button. Pressing of ACKN button of concerned line (Despatch/Receive) will turn off the buzzer and ACKN indication.