# **Microsoft Surface Data Eraser**

Article • 01/03/2023 • 7 minutes to read • Applies to: Windows 10, Windows 11

Find out how the Microsoft Surface Data Eraser tool can help you securely wipe data from your Surface devices.

Microsoft Surface Data Eraser is a tool that boots from a USB stick and allows you to perform a secure wipe of all data from a compatible Surface device. A Microsoft Surface Data Eraser USB stick requires only the ability to boot from USB. To learn more about the data wiping capabilities and practices Microsoft uses during the service process for Surface, see Protecting your data if you send your Surface in for service .

#### (i) Important

Microsoft Surface Data Eraser uses the NVM Express (NVMe) format command to erase data as authorized in NIST Special Publication 800-88 Revision 1 .

#### Compatible Surface devices include:

- Surface Laptop Studio
- Surface Book (all generations)
- Surface Go (all generations)
- Surface Pro X (all generations)
- Surface Laptop (all generations)
- Surface Laptop Go (all generations)
- Surface Laptop SE
- Surface Studio (all generations)
- Surface Pro 2 and later
- Surface 3
- Windows 10 Pro and Enterprise on Surface Hub 2

Some scenarios where Microsoft Surface Data Eraser can be helpful include:

- Prepare a Surface device to be sent for repair.
- Decommission a Surface device from corporate or organizational use.
- Repurpose a Surface device for a new user.
- Reimage devices containing sensitive data.

# How to create a Microsoft Surface Data Eraser USB stick

After the creation tool is installed, follow these steps to create a Microsoft Surface Data Eraser USB stick. Before you begin these steps, ensure that you have a USB 3.0 stick that is 4 GB or larger connected to the computer.

- 1. Run the DataEraserSetup.msi installation file that you downloaded from the Microsoft Download Center .
- 2. Select **Build** to begin the Microsoft Surface Data Eraser USB creation process, as shown in Figure 1.




Figure 1. Begin the Microsoft Surface Data Eraser tool

3. Select **Continue** to acknowledge that you have a USB drive of at least 4 GB connected, as shown in Figure 2.





Figure 2. Confirm USB drive of at least 4 GB is connected

4. Choose x64 (for 2021+ devices only) for 2021 or newer devices, choose x64 for 2020 and older devices or ARM64 for Surface Pro X from the Architecture Selection page, as shown Figure-3. Select Continue.



5. Select the USB drive of your choice from the **USB Thumb Drive Selection** page as shown in Figure 4, and then select **Start** to begin the USB creation process. The drive you select will be formatted and any existing data on this drive will be lost.




Figure 4. USB thumb drive selection

∏ Tip

If the Start button is disabled, check that your removable drive has a total capacity of at least 4 GB.

- 6. After the creation process is finished, the USB drive has been formatted and all binaries are copied to the USB drive. Select **Success**.
- 7. When the **Congratulations** screen is displayed, you can eject and remove the thumb drive. This thumb drive is now ready to be inserted into a Surface device, booted from, and wipe any data on the device. Select **Complete** to finish the USB creation process, as shown in Figure 5.




Figure 5. Complete the Microsoft Surface Data Eraser USB creation process

8. Select X to close Microsoft Surface Data Eraser.

# How to use a Microsoft Surface Data Eraser USB stick

After you create a Microsoft Surface Data Eraser USB stick, you can boot a supported Surface device from the USB stick by following this procedure:

① Note

Surface Data Eraser on Surface Studio and Surface Studio 2 can take up to 6 minutes to boot into WinPE before disk erasure can occur.

- Insert the bootable Microsoft Surface Data Eraser USB stick into the supported Surface device.
- 2. Boot your Surface device from the Microsoft Surface Data Eraser USB stick. To boot your device from the USB stick follow these steps:
  - a. Turn off your Surface device. b. Press and hold the **Volume Down** button. c. Press and release the **Power** button. d. Release the **Volume Down** button.

∏ Tip

If your device does not boot to USB using these steps, you may need to turn on the **Enable Alternate Boot Sequence** option in Surface UEFI. You can read more about Surface UEFI boot configuration in **Manage Surface UEFI Settings** .

3. When the Surface device boots, a **SoftwareLicenseTerms** text file is displayed, as shown in Figure 5.




Figure 5. Booting the Microsoft Surface Data Eraser USB stick

4. Read the software license terms, and then close the Notepad file.

- 5. Accept or decline the software license terms by typing **Accept** or **Decline**. You must accept the license terms to continue.
- 6. The Microsoft Surface Data Eraser script detects the storage devices that are present in your Surface device and displays the details of the native storage device. To continue, press **Y** (this action runs Microsoft Surface Data Eraser and removes all data from the storage device) or press **N** (this action shuts down the device without removing data).

#### **⊗** Caution

The Microsoft Surface Data Eraser tool will delete all data, including Windows operating system files required to boot the device, in a secure and unrecoverable way. To boot a Surface device that has been wiped with Microsoft Surface Data Eraser, you will first need to reinstall the Windows operating system. To remove data from a Surface device without removing the Windows operating system, you can use the **Reset your PC** function. However, this does not prevent your data from being recovered with forensic or data recovery capabilities. See **Recovery options in Windows 10** for more information.

```
ype Accept or Decline and press Enter to continue: (Accept|Decline): accept
urface Data Eraser
is a script implementation
to erase data on Surface device
Data erase tools for the storage drives
are provided by
the Original Equipment Manufacturers of the storage drives
This script identifies
the drive manufacturer on your device
and runs the corresponding
data erase tool.
Checking storage drive make and model...
NVMe Model=NVMe Storage Device
NVMe Size=00000000000000 bytes
storage Device NVMe detected. Press Y to execute Microsoft Surface Data Eraser or N to
shut device down (Y|N): y
```

Figure 6. Partition to be erased is displayed in Microsoft Surface Data Eraser

7. If you pressed **Y** in step 6, due to the destructive nature of the data erasure process, another dialog box is displayed to confirm your choice.

8. Select Yes to continue erasing data on the Surface device.

∏ Tip

When you run Surface Data Eraser on the Surface Data Eraser USB drive, a log file is generated in the **SurfaceDataEraserLogs** folder.

# Changes and updates

Microsoft Surface Data Eraser is periodically updated by Microsoft. For information about the changes provided in each new version, see the following notes:

#### 3.48.139.0

Release Date: 21 November 2022

This version of Surface Data Eraser includes bug fixes.

#### 3.46.139.0.

Release Date: 28 October 2022

This version of Surface Data Eraser includes:

• Support for Surface Pro 9, Surface Laptop 5, and Surface Studio 2+.

# 3.45.139.0

Release Date: 7 June 2022

This version of Surface Data Eraser includes:

• Support for Surface Laptop Go 2.

#### 3.42.139.0

Release Date: 5 October 2021

This version of Surface Data Eraser includes:

 Separate option for 2021 and support for newer devices including Surface Laptop Studio, Surface Pro 8, and Surface Go 3.

# 3.39.139.0

Release Date: 13 April 2021

This version of Surface Data Eraser includes:

• Support for Surface Laptop 4

#### 2.34.139.0

Release Date: 15 January 2021

This version of Surface Data Eraser:

• Includes bug fixes

#### 3.33.139

Release Date: 9 September 2020

This version of Surface Data Eraser includes bug fixes and adds support for:

- Architecture re-design to reduce the need to update with new product releases
- Notification available for new tool updates
- Customer content additions
- Windows 10 Pro and Enterprise on Surface Hub 2

#### 3.30.139

Release Date: 11 May 2020

This version of Surface Data Eraser adds support for:

- Surface Book 3
- Surface Go 2
- New SSD in Surface Go

#### 3.28.137

Release Date: 11 November 2019

This version of Surface Data Eraser:

• Includes bug fixes

#### Version 3.21.137

Release Date: 21 October 2019

This version of Surface Data Eraser is compiled for x86 and adds support for the following devices:

• Surface Pro 7, Surface Pro X, and Surface Laptop 3

#### Version 3.2.78.0

Release Date: 4 December 2018

This version of Surface Data Eraser includes bug fixes

#### Version 3.2.75.0

Release Date: 12 November 2018

This version of Surface Data Eraser:

- Adds support to Surface Studio 2
- Fixes issues with SD card

## Version 3.2.69.0

Release Date: 12 October 2018

This version of Surface Data Eraser adds support for the following devices:

- Surface Pro 6
- Surface Laptop 2

## Version 3.2.68.0

This version of Microsoft Surface Data Eraser adds support for Surface Go.

#### Version 3.2.58.0

This version of Microsoft Surface Data Eraser adds support for the following:

• Extra storage devices (drives) for Surface Pro and Surface Laptop devices

#### Version 3.2.46.0

This version of Microsoft Surface Data Eraser adds support for Surface Pro with LTE Advanced

## Version 3.2.45.0

This version of Microsoft Surface Data Eraser adds support for the following devices:

- Surface Book 2
- Surface Pro 1 TB

#### ① Note

Surface Data Eraser v3.2.45.0 and above can be used to restore Surface Pro or Surface Laptop devices with the 1TB storage option in the scenario that the device shows two separate 512GB volumes or encounters errors when attempting to deploy or install Windows 10. See **Surface Pro Model 1796** and **Surface Laptop 1TB display two drives** for more information.

## Version 3.2.36.0

This version of Microsoft Surface Data Eraser adds support for the following devices:

- Surface Pro
- Surface Laptop

#### ① Note

The Microsoft Surface Data Eraser USB drive creation tool is unable to run on Windows 10 S. To wipe a Surface Laptop running Windows 10 S, you must first create the Microsoft Surface Data Eraser USB drive on another computer with Windows 10/11 Pro or Windows 10/11 Enterprise.