```
// The setup function runs once when you press reset or power the board:
void setup()
Serial.begin(9600); // Initialize serial communications
pinMode(13 , OUTPUT); // Initialize digital pin 13 as an output
// The loop function runs over and over again forever:
void loop()
 if (( ( Serial.available() ) > ( 0 ) ))
 {
   char inputChar = Serial.read();
   Serial.print("The received character is: ");
   Serial.println(inputChar);
   if (inputChar == 'A' )
   {
     digitalWrite(13, HIGH); // Turn the LED on by making the voltage HIGH
     delay(2000); // Wait for two seconds
   }
   else
   {
     digitalWrite(13, LOW); // Turn the LED off by making the voltage LOW
     delay(2000); // Wait for two seconds
```