SULZER

CHESTER VICTORY 360L - PERIODIC MAINTENANCE SCHEDULE

Frequency	Maintenance task	Acceptance / action
Weekly	Thoroughly clean table, T-slots, guards, slides and accessible machine surfaces.	Clean and free from swarf, coolant residue and obstruction.
Weekly	Inspect table, longitudinal/cross/vertical movement and power feeds.	Smooth travel; no abnormal sticking, noise or looseness.
Weekly	Inspect coolant level, hoses, nozzle and visible leaks.	Adequate coolant; stable flow; no damaged hose or abnormal leakage.
Monthly	Inspect spindle taper, arbor/tool-holding surfaces and drawbar/retention condition.	Clean mating surfaces; no visible damage or abnormal looseness.
Monthly	Inspect table guard and other accessible protective devices.	Secure and serviceable; safety devices function correctly.
Monthly	Inspect feed screws, ways and lubrication points.	Lubricated; smooth motion; no abnormal wear evident.
Monthly	Check work lamp, DRO display/scale condition and control switches externally.	Secure, clean and functioning; damaged electrical items referred to authorized electrician.
3 Monthly	Inspect drive condition, accessible belts/couplings and mounting fasteners.	No visible deterioration or looseness; correct defects before operation.
3 Monthly	Check machine level and foundation/anchor security.	Machine stable; fasteners secure; investigate any accuracy change.
6 Monthly	Service lubrication system and inspect lubricant condition.	Lubricant/service interval to follow the supplied machine manual and approved site standard.
6 Monthly	Inspect coolant tank and clean as required.	Tank, pump and lines clean and serviceable.
Annually	Comprehensive inspection of vertical/horizontal spindle, feed system and table movements.	Check condition, backlash, run-out/accuracy and function to approved workshop/manufacturer limits.
Annually	Inspect electrical system and safety functions.	Inspection by qualified/authorized electrical maintenance personnel.
Annually	Inspect coolant pump, work lamp, DRO, guards and 3-axis power-feed system.	All fitted systems serviceable; defects repaired before returning to service.

Safety note: Before maintenance, stop and isolate the machine from electrical power in accordance with your site lockout/tagout procedure. Do not work on moving parts or bypass fitted guards/safety devices.

Important: The accessible Chester Victory 360L product literature confirms the fitted systems and machine specification but does not state maintenance intervals. Therefore the periodic frequencies in this printable log are a practical workshop schedule, not manufacturer-specified intervals. Where the machine manual/parts list or your site procedure gives a different requirement, follow that requirement.

SULZER CONFIDENTIAL