10. TECHNICAL INFORMATION

10.1 Automatic Bin Data Zone Numbers

	Sensor 1	Sensor 2	Sensor 3	Sensor 4
Direction - Down Left count (LT)	501	504	507	510
Direction – Down Through count (T)	502	505	508	511
Direction – Down Right count (RT)	503	506	509	512
Left to Right ped movement (PD) Introduced in version 09.02.20SP1	601	603	605	607
Right to Left ped movement (PD) introduced in version 09.02.20SP1	602	604	606	608
Vector Sensor Radar (AS) near trip line	651	652	653	654
Automatic Right turn counts lane 1 (R1) Introduced in version 09.02.22SP2	701	711	721	731
Automatic Right turn counts lane 2 (R2) Introduced in version 09.02.22SP2	702	712	722	732
Automatic Thru counts lane 1 (T1) Introduced in version 09.02.22SP4	703	713	723	733
Automatic Thru counts lane 2 (T2) Introduced in version 09.02.22SP4	704	714	724	734
Automatic Thru counts lane 3 (T3) Introduced in version 09.02.22SP4	705	715	725	735
Automatic Thru counts lane 4 (T4) Introduced in version 09.02.22SP4	706	716	726	736
Automatic Thru counts lane 5 (T5) Introduced in version 09.02.22SP4	707	717	727	737
Automatic Left turn counts lane 1 (L1) Introduced in version 09.02.22SP3A	708	718	728	738
Automatic Left turn counts lane 2 (L2) Introduced in version 09.02.22SP3A	709	719	729	739
Automatic Left turn counts lane 3 (L3) Introduced in version 09.02.22SP3A	710	720	730	740

Note: *Zone numbers highlighted in red will be included in a future firmware release.*

10.2 Bin Data Structure - Vehicle and Bike Zones

This includes automatic zone numbers 701 thru 740

Data String:

051, 2019-07-23 11:45:00, 13,0,0,0,0,0,0, Video OK, LT

xxx, yyyy-mm-dd hh:mm:ss, V, x, x, x, x, x, I, Video **Status, Label**

String Definition:

xxx – Zone Detail Number

yyyy-mm-dd – Year-Month-Day

hh:mm:ss – Hour:Minute:Second

V – Volume (Count) for the bin interval

x – Not used for this firmware version

x – Not used for this firmware version

x – Not used for this firmware version

x – Not used for this firmware version

x – Not used for this firmware version

x – Not used for this firmware version

I – Amount of green time for the bin interval (seconds)

Video Status – OK or No Video

Zone Label – Automatic or user configured

10.3 Bin Data Structure - Automatic Direction Counts

This includes automatic zone numbers 501 thru 512

Data String:

504, 2019-07-23 11:45:00, 10,0,23,0,0,0,0, Video OK,C2 LT

xxx, yyyy-mm-dd hh:mm:ss, V, x, O, x, x, x, x, Video Status, Label

String Definition:

xxx – Zone Detail Number

yyyy-mm-dd – Year-Month-Day

hh:mm:ss – Hour:Minute:Second

V – Volume (Count) for the bin interval

x – Not used always zero

O – Occupancy **NOTE**: Only for the first zone number with each sensor (501, 504, 507, 510). All other zones not used, always zero.

x – Not used always zero

x – Not used always zero

x – Not used always zero

x– Not used always zero

Video Status – OK or No Video, Video GLR, Video LC

Zone Label – Automatic or user configured

10.4 Bin Data Structure - CSO and Vector Trip Line

This includes automatic zone numbers 651 thru 654.

Data String:

011, 2019-07-23 11:30:00, 25,29,6,10,5,10,300, Video OK, RT

xxx, yyyy-mm-dd hh:mm:ss, V, S, O, Csm, Cmd, Clg, I, Video Status, Label

String Definition:

xxx – Zone Detail Number

yyyy-mm-dd – Year-Month-Day

hh:mm:ss – Hour:Minute:Second

V – Volume (Count) for the bin interval

S – Average Vehicle Speed for the bin interval

O – Occupancy, expressed as a percentage for the bin interval

Csm – Volume (Count) for small vehicle classification

Cmd – Volume (Count) for medium vehicle classification

Clg – Volume (Count) for large vehicle classification

I – Amount of green time for the bin interval (seconds). **Note**: this is always zero for Vector Trip Lines

Video Status – OK or No Video

Zone Label – Automatic or user configured

10.5 Bin Data Structure - PedTrax

The system bin interval applies to the pedestrian data.

Data String:

605, 2019-08-01 00:00:00, 1, 0, 0, 6.3, 6.3, 6.3, 0, Video OK,C3 PD

xxx, yyyy-mm-dd hh:mm:ss, V, x, x, S, MaxSpd, MinSpd, I, Video Status, Zone Label

Note: *The order and content of the data string for PedTrax data is different from that of the Count or CSO zones for Vehicles and Bicycles. Count and CSO zone data is not affected by the addition of PedTrax.*

String Definition:

xxx – Zone Detail Number

yyyy-mm-dd – Year-Month-Day

hh:mm:ss – Hour:Minute:Second

V – Volume (Count) for the bin interval

x – Not used for PedTrax in this firmware version

x – Not used for PedTrax in this firmware version

S – Average Pedestrian Speed for the bin interval

MaxSpd – Speed of the fastest pedestrian for the bin interval

MinSpd – Speed of slowest pedestrian for the bin interval

I – Amount of green time or walk time for the bin interval (seconds) when logic level inputs are used.

Video Status – OK or No Video

Zone Label – Automatic or user configured

Note: *Speed data is recorded with a single decimal place, e.g., 2.8*

10.6 Log Data Structure

Each line in the log data has the following structure

Data String:

yyyy-mm-dd hh:mm:ss text string

String Definition:

yyyy-mm-dd – Year-Month-Day

hh:mm:ss – Hour:Minute:Second

text string – One of the log entries listed above

Log Data Entries

Possible Diagnostic Entries – Replace # with Camera Number

- Camera # enter alt sensor fallback
- Camera # exit alt sensor fallback
- Camera # alt sensor no data
- Camera # alt sensor interference
- Camera # alt sensor errors

- Camera # alt sensor no errors
- System running TOD config #