

1- ORGANISMES CHARGES DES SERVICES DE LA CIRCULATION

AERIENNES: CASABLANCA ACC et MARRAKECH-Ménara APP assurent la fourniture des services de la circulation aérienne dans la TMA de MARRAKECH.

2- ESPACES DELEGUES A MARRAKECH-Ménara APP :

a- Limites laterales et verticales (cf. ENR 2.1)

b- Calage altimétrique

L'altitude de transition pour la TMA de MARRAKECH-Ménara est de 6000 ft. Le niveau de transition est calculé par MARRAKECH-Ménara APP.

3- PROCEDURES:

a- Limitation de vitesse

- Sauf clairance particulière de MARRAKECH-Ménara APP la vitesse indiquée (IAS) ne devra pas excéder 250 kt en dessous du FL100.

b-Itinéraires normalisés d'arrivées aux instruments (STARs):

- Les itinéraires IFR à l'interieur de la TMA sont ceux définie à la page AD2 GMMX - 34_2_DATA.
- Sauf autorisation contraire de l'approche, les aéronefs devront se conformer aux spécifications fixées pour chaque itinéraire normalisé aux instruments.
- Les points d'entrées de la TMA doivent figurer au plan de vol pour les aéronefs en rigime IFR.

1.RELEVANT AIR TRAFFIC SERVICES:

Casablanca ACC and Marrakech Mènara APP provide air traffic control services in Marrakech Mènara TMA.

2.AIRSPACE ALLOCATED TO MARRAKECH MÈNARA APP :

a-Lateral and Vertical limits (cf ENR 2.1)

b-Altimeter setting: The transition altitude in Marrakech Mènara TMA is 6000 ft. The transition level will be calculated by Marrakech Mènara APP.

3.PROCEDURES:

a-Speed restriction:

-Except special clearance from Marrakech Mènara APP, the indicated airspeed (IAS) shall not exceed 250kts below FL 100

- b-Standard arrival routes (STAR): -IFR routes inside the TMA, are those defined in AD2 GMMX 34_2_DATA Except with other clearances, the aircraft shall comply with

- specifications set on each standard route.
 Entry points of the TMA should be included in the flight plan for ACFT under IFR rules

RNAV 1

MARRAKECH-Ménara STAR (GNSS) RWY 28

STAR 4A

(Protégés pour / Protected for CAT A, B, C, D)

ITINERAIRES:	
--------------	--

KUDAX 4A

KUDAX et suivre 221°(218.7°T) direct jusqu'à RAMIM (IAF).

OBOGA 4A

OBOGA et suivre 180° (177.4°T) direct jusqu'à RAMIM (IAF).

MABAP 4A

MABAP et suivre 155° (152.9°T) direct jusqu'à MX289. à MX289 virer à gauche 130° (127.4°T) direct jusqu'à RAMIM (IAF).

BENOV 4A

BENOV et suivre 129° (127.1°T) direct jusqu'à MX289. à MX289 suivre 130° (127.4°T) direct jusqu'à RAMIM (IAF).

MAGAV 4A

MAGAV et suivre 093° (091.3°T) direct jusqu'à MX283 (IAF).

GOSNO 4A

GOSNO et suivre 076° (073.6°T) direct jusqu'à MX283 (IAF).

LISRA 4A

LISRA et suivre 072° (069.8°T) direct jusqu'à NAPOV. à NAPOV virer à gauche 050° (047.8°T) direct jusqu'à MX283 (IAF).

MOKIR 4A

MOKIR et suivre 345° (343.3°T) direct jusqu'à MX287. à MX287 virer à droite 008° (005.9°T) direct jusqu'à MX285. à MX285 virer à gauche 278° (275.9°T) direct jusqu'à RAMIM.

OUTGOING ROUTES:

KUDAX 4A

KUDAX and follow 221°(218.7°T) direct to RAMIM (IAF).

OBOGA 4A

OBOGA and follow 180°(177.4°T) direct to RAMIM (IAF).

MABAP 3A

MABAP and follow 155°(152.9°T) direct to MX289. At MX289 turn left 130°(127.4°T) direct to RAMIM (IAF).

BENOV 4A

BENOV and follow 129°(127.1°T) direct to MX289. At MX289 follow 130°(127.4°T) direct to RAMIM (IAF).

MAGAV 4A

MAGAV and follow 093°(091.3°T) direct to MX283 (IAF).

GOSNO 4A

GOSNO and follow 076°(073.6°T) direct to MX283 (IAF).

LISRA 4A

LISRA and follow 072°(069.8°T) direct to NAPOV. At NAPOV turn left 050°(047.8°T) direct to MX283 (IAF).

MOKIR 4A

MOKIR and follow 345°(343.3°T) direct to MX287. At MX287 turn right 008° (005.9°T) direct to MX285. At MX285 turn rleft 278° (275.9°T) direct to RAMIM.

PANNE DE COM:

En sus des dispositions des paragraphes 7 (ENR 1.2.3) et 4 (ENR 1.3.2), l'aéronef doit

- Afficher code 7600.
- Suivre la STAR PLN ou autorisée. En cas de guidage radar rejoindre la STAR initiale.
- Respecter les contraintes de niveau et de vitesse publiés.
- Se présenter à l'IAF au dernier niveau de vol assigné pour lequel il y a eu accusé de réception s'il est utilisable dans l'attente, à défaut le niveau le plus élevé de l'attente.
- Attendre à ce niveau jusqu'à la plus tardive des heures suivantes :
- . HAP
- . Heure d'entrée dans l'attente plus 10 minutes.
- Puis descendre dans le circuit d'attente jusqu'au 5500 ft.
- Quitter l'IAF à ce niveau pour entreprendre la procédure d'approche connue ou estimée jusqu'à l'atterrissage.

Identificateur de noint de cheminement

RADIO FAILURE:

In addition to the provisions of the paragraphs 7 (ENR 1.2.3) and 4 (ENR 1.3.2), the aircraft must:

- Squawk code 7600
- Follow the authorized or PLN STAR. In case of radar guidance, proceed to the initial STAR.
- Observe the published flight level and speed requirements.
- Proceed to the IAF at the last assigned level that was acknowledged, if this level is available in the holding pattern, otherwise at the highest level in the holding pattern.
- stay in the holding pattern at this level until the latest time as follow: EAT.
- . Arrival time in the holding pattern plus 10 minutes.
- then descend in the holding pattern to 5500 ft.

Coordonnáos

- Leave the IAF at this level to perform the known or estimated approach procedure until landing.

identificateur de point de cheminement	Coordonnées	
KUDAX	N 31°48'30,86"	W 007°40'18,96"
OBOGA	N 31°50'15,53"	W 007°48'51,29"
MABAP	N 32°07'27,36"	W 008°11'49,62"
BENOV	N 32°05'38,77"	W 008°27'16,64"
MAGAV	N 31°31'31.05"	W 008°46'40.15"
GOSNO	N 31°19'04.79"	W 008°34'31.54"
LISRA	N 31°14'00.44"	W 008°29'03.92"
MOKIR	N 31°20'24.67"	W 007°36'46.01"
NAPOV	N 31°24'00.65"	W 007°57'22.12"
RAMIM (IAF)	N 31°40'11.66"	W 007°48'07.11"
MX291	N 31°25'12.64"	W 007°38'26.76"
MX289	N 31°48'08.33"	W 008°00'16.18"
MX287	N 31°34'35.12"	W 007°41'43.61"
MX285	N 31°39'34.14"	W 007°41'06.94"
MX283 (IAF)	N 31°30'13.70"	W 007°49'21.05"
VOR/DME MAK	N 31°36"45.90"	W 008°06'10.90"

Var : 002°13' W (01/03/2016) changing by 7.0'E per year