YETI PAW v1.2 — Safety factors, centered-pivot side plates

Designed by **Schnibbz** · YETI STRENGTH

This page covers the **optional centered-pivot side plates** (the yoke hole centered between the handle and the pad, 85 mm to each). Everything else in the build is unchanged, so the yoke and pad dowel figures are the same as on the main Safety factors page.

Rating: 75 lb working load (unchanged)

Rated working load: 75 lb (34 kg) on the cable, for repeated reps.

Not physically load-tested. The rating comes from analysis only (below); no unit has been proof-loaded.

Results

Cable load	Yoke — static	Yoke — fatigue	Centered plate — static	Centered plate — fatigue	Pad dowel — static	Pad dowel — fatigue
50 lb (23 kg)	7.0	2.4	9.1	3.2	6.9	2.4
75 lb (34 kg, rated)	**4.6**	**1.6**	**6.1**	**2.1**	**4.6**	**1.6**
100 lb (45 kg, above rating)	3.5	1.2	4.6	1.6	3.5	1.2

The yoke and the pad dowel are still the weakest parts. The centered plate has more margin than either, so it does not change the rating.

Centered plate vs standard plate, side by side. Both plates were run through the same analysis with the same mesh settings, so their numbers compare directly:

Cable load	Standard plate — static	Standard plate — fatigue	Centered plate — static	Centered plate — fatigue
50 lb	8.7	3.1	9.1	3.2
75 lb	**5.8**	**2.0**	**6.1**	**2.1**
100 lb	4.4	1.5	4.6	1.6

The centered plate comes out about 5 % stronger at every load. The standard plate's numbers here differ slightly from the main page because the main page used a finer mesh; the comparison above uses the same settings for both.

Where it is highest. The worst case for the centered plate is the load reacted at the wrist pad. For the standard plate it is the load reacted at the handle. The centered plate also uses about 21 % less plastic (78 vs 98 cm^3 before the edge radius).

How to read it. A safety factor (SF) is how many times stronger the part is than the stress it sees. SF 2 means it would take twice the load to reach the limit.

- **Static** is for a single pull.
- **Fatigue** is for many reps, on the order of a million. This is the one that matters for training, and it sets the rating.

Do not use it above 75 lb. The 100 lb row is not an allowance.

How these numbers were made

Same method as the main page:

- **Model:** 2D plane-stress finite-element analysis of the plate (a flat part loaded in its own plane), about 24 k nodes, with every boundary resampled at the same 1 mm spacing for both plates so the two meshes match.
- **Load cases:** the cable force arrives at the yoke pivot from any direction (12 directions checked) and is reacted either at the handle or at the wrist pad; the worst case is reported. Each plate carries half the cable force.
- **Stress:** von Mises, 99.5th percentile, which ignores single-point mesh spikes. Real peak stresses right at hole edges may be higher than shown.
- **Material:** ELEGOO PETG-CF, 51 MPa along the layers (the plate prints flat, so the load runs along the layers).
- **Knock-downs:** × 0.75 for printed walls and infill (**6 walls, 40 % gyroid**); × 0.35 for fatigue.
- **Yoke swing:** checked on the final plate shape. The yoke swings freely from −81° to +48°; a cable lateral raise needs about −47° to +15°.
- **Not modelled:** print defects and poor layer bonding, wet filament, impact, heat, UV ageing, bearing and sleeve wear, and the bearing pockets cut into the plate face (the 2D model treats the plate as a full 10 mm thick).

These figures only apply if you print as specified (see PRINT-SETTINGS.md): PETG-CF, dried, 6 walls, 40 % gyroid, plate printed flat. Other materials are untested here. **Never print it in PLA.**

Inspect before every session

Check the side plates around all three holes, the yoke around its pivot bosses and carabiner eye, and the dowel's ends and threads. **Stop using it** at the first sign of whitening (stress marks), cracks, new play in the pivots, or a bearing that has moved.

Not professionally engineered. The Yeti Paw was designed by a hobbyist, not by a licensed or qualified engineer. These safety factors are amateur estimates from a simplified computer model. They are not a certified load rating and come with no guarantee.

Build and use at your own risk. You are responsible for printing, assembling, inspecting and using this device. Print quality, materials, settings and assembly vary, so your parts may be weaker than described. The designer accepts no liability for injury or damage arising from building or using it.