YETI PAW v1.1 — Safety factors

Designed by **Schnibbz** · YETI STRENGTH

Rating: 75 lb working load

Rated working load: 75 lb (34 kg) on the cable, for repeated reps.

Not physically load-tested. The rating comes from analysis only (below); no unit has been proof-loaded.

Results

The weakest part is the **carabiner yoke**. The side plates and the pad dowel have more margin.

Cable load	Yoke — static	Yoke — fatigue	Side plate — static	Side plate — fatigue	Pad dowel — static	Pad dowel — fatigue
50 lb (23 kg)	6.4	2.2	8.3	2.9	6.9	2.4
75 lb (34 kg, rated)	**4.2**	**1.5**	**5.5**	**2.0**	**4.6**	**1.6**
100 lb (45 kg, above rating)	3.2	1.1	4.1	1.5	3.5	1.2

How to read it. A safety factor (SF) is how many times stronger the part is than the stress it sees. SF 2 means it would take twice the load to reach the limit.

- **Static** is for a single pull. Could one rep at this load break it?
- **Fatigue** is for many reps, on the order of a million. Could thousands of sessions at this load wear a crack into it? This is the one that matters for training, and it sets the rating.

Why 75 lb. At 75 lb the yoke's fatigue SF is 1.5, the minimum margin used here for repeated loading.

Why the 100 lb row is shown. It shows how quickly the margin disappears: one pull at 100 lb is still inside static strength (SF 3.2), but the yoke's fatigue SF drops to 1.1, which leaves no real margin for repeated use. **Do not use it above 75 lb.** The 100 lb row is not an allowance.

How these numbers were made

- **Model:**
  - Side plate and yoke: 2D plane-stress finite-element analysis (both are flat parts loaded in their own plane), about 50–75 k nodes each.
  - Pad dowel: hand calculation of bending across its length plus the D-stub ends. It prints upright, so this load runs ACROSS the layers and uses the weaker layer-to-layer strength (38 MPa).
- **Load cases:**
  - Plate: the cable force arrives at the yoke pivot from any direction (12 directions checked). It is reacted either at the handle or at the wrist pad, and the worst case is reported.
  - Yoke: the pull is along the yoke and ±30° off it.
  - Each plate carries half the cable force (assumed equal split).
- **Stress:** von Mises, 99.5th percentile, which ignores single-point mesh spikes. Real peak stresses right at hole edges may be higher than shown, and fatigue cracks start there. That is one reason the fatigue margin, not the static one, sets the rating.
- **Material:** ELEGOO PETG-CF: 51 MPa along the layers, 38 MPa across them. The plate and yoke print flat, so their load runs along the layers.
- **Knock-downs:**
  - × 0.75 for printed walls and infill: **6 walls, 40 % gyroid**;

    - × 0.35 for fatigue, a rule of thumb for polymers at about a million cycles.
- **Not modelled:**
    - print defects and poor layer bonding;
    - wet filament;
    - impact, such as dropping the stack or a cable snapping back;
    - heat (car interiors, direct sun);
    - UV ageing;
    - wear of the bearings and sleeves.

These figures only apply if you print as specified. Use PETG-CF, the walls and infill above, and dried filament (see PRINT-SETTINGS.md). Other materials, fewer walls, lower infill or a different orientation will be weaker. **Never print it in PLA**: PLA creeps under steady load and softens in a hot car.

Inspect before every session

Check the yoke, especially around the two pivot bosses and the carabiner eye, and the side plates around all three holes. Also check the dowel's D-shaped ends and its threads. **Stop using it** at the first sign of whitening (stress marks), cracks, new play in the pivots, or a bearing that has moved. **Reprint the yoke** after any drop or impact, and at any whitening.

Not professionally engineered. The Yeti Paw was designed by a hobbyist, not by a licensed or qualified engineer. These safety factors are amateur estimates from a simplified computer model. They are not a certified load rating and come with no guarantee.

Build and use at your own risk. You are responsible for printing, assembling, inspecting and using this device. Print quality, materials, settings and assembly vary, so your parts may be weaker than described. The designer accepts no liability for injury or damage arising from building or using it.