

AutoCAD Electrical 2025: AutoLISP Reference

Section F - General Functions

[Topics](#) [Send Feedback](#)

Description

General functions.

Topics

Name	Description
ace_publish_create_dsd	Creates an electrical DSD file, for an active project, that can be used to publish a list of drawing a PDF file using the -PUBLISH command.
aeqgetsqlservertimeout	Returns the currently set SQL server timeout value when called in SQL server mode only. Return called in Access mode.
aesetsqlservertimeout	Sets the SQL server timeout value when called in SQL server mode. This timeout determines how long to wait before SQL connection or query attempts are considered failed. Setting this higher in poor network conditions will result in longer waiting but might help to avoid connection errors. Timeout default is 30 seconds and persists across sessions. Does nothing and returns nil if called in Access mode.
c:acadelm	Moves entities to new layer, even entities that are embedded in inserted blocks on the drawing.
c:acadex	Use for troubleshooting gap pointers and other entities with extended entity pointer data.
c:ace_chjust	Change justification of target attribute, text entity, or attribute definition entity.
c:ace_dir_files	Perform a search of AutoCAD Electrical folders for files, wild-card matching.
c:ace_find_file	Find AutoCAD Electrical support file.
c:ace_find_substr	Find a substring. Note: this is NOT case sensitive.
c:ace_get_1000_xdata_dbx	Get XDATA (1000) value from block INSERT instance on drawing.
c:ace_get_cable_conductor_data	Find cable MFG/CAT entry in the _W0_CBLWIRES table of the catalog lookup database file. Returns parallel lists; a list of cable conductor colors and a list of cable conductor gauge values.
c:ace_get_cat_data	Do a catalog lookup query and return matching record(s).
c:ace_get_pnlval_dbx	Get ATTRIB or XDATA (1000) value from block INSERT instance on drawing. XDATA is in form "VIA_WD_attname". Look for ATTRIB first, if not found, look for XDATA value.
c:ace_get_ptag_attrval	Find panel footprint symbols or panel terminal attribute value or split tag values from block insert instance. Find P_TAG1, P_TAG1_PART* (panel footprint symbols), or P_TAGSTRIP (panel terminal attribute value or split tag values from block insert instance. Look for Xdata if target attributes are not found.
c:ace_get_tag_attrval	Get tag attribute values. Find TAG1, TAG1F, TAG1_PART*, TAG1F_PART*, (parent schematic symbols) TAG2, TAG2_PART* (child schematic symbols) or TAG, TAG_* (PLCIO and divided PLCIO children) TAGSTRIP (schematic terminal) attribute value or split tag values from block insert instance.
c:ace_get_textvals	Retrieve catalog record's TEXTVALS data, if defined. ONE of the first two arguments must be supplied.
c:ace_getattr_data	Get specific attribute information from block insert.
c:ace_mod_tag_attrval	Find tag attribute on schematic symbol and then write modified tag-ID value out to it. If the symbol carries a "split" tag, then divide the "tagstr" across the split tag attributes. Tag attribute can be TAG1, TAG2, TAG1F, TAG, TAG_*, TAGSTRIP or can be split tags TAG1_PART*, TAG2_PART*.
c:ace_projwide_script	Run a user script against each drawing to be processed. Similar to selecting the "Run command file script" option of the Project-Wide Utilities (AEUTILITI) command. The script is run against the listed drawings, but all user prompts are bypassed.
c:ace_surf_zoom_in_no_dlg	Force surf to drawing, zoom in on entity, and optionally center on coordinates.
c:ace_tag_fixed	Change block insert's "tag-ID" value to fixed or back to normal. Block can be a wire number or a schematic component.
c:wd_2ss	Trigger generation of Export DWGS-->TO Spreadsheet data dump without any user prompts.
c:wd_4_squish_fname	Replace center characters in filename string with "...". Strip characters out of the middle of file name and replace with "..." in order to make file name text fit into required number of characters.
c:wd_add_attr	Add an attribute to an existing inserted block on a drawing.
c:wd_block_path_failed_msg	Display error dialog box for block not found in AutoCAD Electrical search paths.
c:wd_bomr_ent_gb	Display full catalog information for select schematic or pnl block.
c:wd_bomr_entcat	Gather lists of catalog number information from entity and format into a list of lists.

	with the same name.
c:wd_bswap_redefine_curdwg	Update existing block with a newer version of the same block
c:wd_cat_lookup	Open AutoCAD Electrical's CATALOG LOOKUP dialog box.
c:wd_chq_to_attdef	Convert text entity to an attrib definition, in place. Note: this does NOT add an attribute to an e block insert.
c:wd_chqjst	Allows user picks to change ATTRIB or TEXT justification. Can be set up in acad.pgp as a "hot key desired (ex: "J, *wd_chgjst") where user types "J", space, , [Enter] and then starts picking.
c:wd_comp_ref_list	Return list of cross-reference information for selected component or tag name.
c:wd_del_1000_xdata	Delete an existing "dxf group code 1000" xdata record from an entity.
c:wd_del_xdata_apppnam	Deletes xdata from an entity
c:wd_delim_str_to_lst	Convert a delimited string into an AutoLISP list.
c:wd_does_block_exist	Search for schematic block name using AutoCAD Electrical's search paths.
c:wd_does_block_exist_dbx	Return the block name if the block is already defined in drawing.
c:wd_does_file_exist	Search various AutoCAD Electrical <i>install</i> paths and AutoCAD support path(s) for the file "nam".
c:wd_does_file_exist_error	Display error dialog box for file name not found in AutoCAD Electrical search paths.
c:wd_edit_attribute	Retrieve target attribute from insert and open an edit dialog box that has "pick just like" and increment/decrement toggles.
c:wd_find_wdw	Find and return the file name of the wire color/gauge mapping (.wdw) file appropriate for the cu project or else the default file if a project-specific version is not found.
c:wd_get_1000_xdata	Get xdata from entity.
c:wd_get_1005_xdata	Look for handle pointer value saved as xdata on target entity.
c:wd_get_locs_for_proj	Extract component LOC values, project-wide. Display in pick list dialog box.
c:wd_get_locs_for_proj_mult	Extract component LOC values, project-wide. Multiple selection. Display in pick list dialog box.
c:wd_get_locs_on_dwg	Extract component LOC values from the current drawing, display in a pick list dialog box.
c:wd_get_pnlval	Get ATTRIB or XDATA (1000) value from panel footprint block "ben" XDATA in form "VIA_WD_attname" (old="CIM_WD_attname"). Look for ATTRIB first, if not found, look for XDA
c:wd_getattrval	Retrieve attribute value.
c:wd_getenv	Retrieve settings out of "wd.env" environment file.
c:wd_getflist	Return directory listing list.
c:wd_import_scratch_mdb_doit	Trigger auto update of current drawing's AutoCAD Electrical component and wire number data b changed data in the project scratch ".mdb" database file.
c:wd_increment_str	Increment ASCII string by value (integer, positive or negative).
c:wd_ins_table	Display comma delimited file in a report dialog, optionally insert as a table on to the active draw
c:wd_is_it_schem_or_pnl	Return code indicating the target block insert.
c:wd_layer_move	Moves entities to new layer, even entities that are embedded in inserted blocks on the drawing. for "old" layer and "move to" layer names. It is therefore scriptable.
c:wd_make_prev_selset	Create a "Previous" selection set from entity.
c:wd_mod_1000_xdata	Add or modify existing "1000" xdata value.
c:wd_mod_1005_xdata	Save handle pointer string on entity under xdata. Create xdata if it does not exist. If it does exist overwrite with new value.
c:wd_modattrval	Modify attribute "attname" with new value "newval" on insert entity "ben". Don't trigger entity r "noupd" is 1.
c:wd_msg	Return message string from match in message Access database file wd_msg.mdb in currently st language.
c:wd_read_wdw	Read wire color/gauge mapping file.
c:wd_selsort	Sorting list of lists routine, multi-level if desired.
c:wd_split_fname	Split file name into list of path, name, extension.
c:wd_ss2_import_curdwg	Trigger an auto update of current drawing based upon changed data carried in an Excel spreads Access file. ex: comma delimited excel spreadsheet dump file

c:wd_wd2p_set_GBL_wd_pnltrmlst	Build list GBL_wd_pnltrmlst that is referenced by the SCHEM TERM-->PNL insertion pick list dial
c:wd_wdsurf	Trigger AutoCAD Electrical Surfer search and surf dialog box.
c:wd_xdata	API call - run a user script against each drawing to be processed.
wd_fio_does_pnlblock_exist	Search for panel footprint block using AcadE's search paths.

Links

[Topics](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
ace_publish_create_dsd
[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Creates an electrical DSD file, for an active project, that can be used to publish a list of drawing layouts to a PDF file using the -PUBLISH command.

AutoLISP

```
(ace_publish_create_dsd dsd_file_path drawing_list publish_type sheet_type layout_name include_bookmarks include_hyperlinks zoom_factor output
```

Parameters

Parameters	Description
dsd_file_path	The DSD file path (string)
drawing_list	A list of drawing files used for publishing, (list, set it to nil to include all drawings in the active project)
publish_type	Publish format type (string, only support PDF, set it to "PDF")
sheet_type	The sheet type (string, only support multiple sheets, set it to "MULTI")
layout_name	Name of the layout (string, example: "MODEL")
include_bookmarks	Whether to include bookmarks. (boolean, set it to T to include bookmarks)
include_hyperlinks	Whether to include hyperlinks. (boolean, set it to T to include hyperlinks)
zoom_factor	Defines the zoom factor (Integer, number between 1 to 100)
output_path	Location in which the output file is to be created (string)

Example

Publish a multiple sheet PDF document for an active electrical project

```
;; Set DSD file path for DSD file
(setq DsdFilePath "c:\\temp\\testpublish.dsd")

;; Set PDF file path
(setq PdfFilePath "c:\\temp\\testpublish.pdf")

;; Set drawing list parameter to nil to include all drawings in the project
(setq DrawingList nil)

;; Create a DSD file to publish a multi-sheet PDF file with bookmark and hyperlinks included
;; with a zoom factor of 50 including all drawing files in the project
(ace_publish_create_dsd DsdFilePath DrawingList "PDF" "MULTI" "MODEL" T T 50 PdfFilePath)
```

```
;; Generate the PDF file using the previously created DSD file
(command "_publish" "c:\\temp\\testpublish.dsd")
```

Module

[Section F - General Functions](#)

Links

[Example](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
aegetsqlservertimeout
[Section F - General Functions](#) [Send Feedback](#)

Description

Returns the currently set SQL server timeout value when called in SQL server mode only. Returns -1 If called in Access mode.

AutoLISP

```
(aegetsqlservertimeout)
```

Returns

If called in SQL server mode, an integer representing the current timeout value is returned in seconds, otherwise -1.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
aesetsqlservertimeout
[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Sets the SQL server timeout value when called in SQL server mode. This timeout determines how long to wait before SQL connection or query attempts are considered failed. This higher in poor network conditions will result in longer waiting but might help to avoid connection errors. Timeout defaults to 30 seconds and persists across sessions. nothing and returns nil if called in Access mode.

AutoLISP

```
(aesetsqlservertimeout timeout)
```

Parameters

Parameters	Description
timeout	Integer value between 15 and 500 (seconds).

Returns

T if successful; nil if unsuccessful.

Example

Links

[Example](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:acadelm

[Section F - General Functions](#) [Send Feedback](#)

Description

Moves entities to new layer, even entities that are embedded in inserted blocks on the drawing.

AutoLISP

(c:acadelm)

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:acadex

[Section F - General Functions](#) [Send Feedback](#)

Description

Use for troubleshooting gap pointers and other entities with extended entity pointer data.

AutoLISP

(c:acadex)

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:ace_chgjst

[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Change justification of target attribute, text entity, or attribute definition entity.

AutoLISP

(c:ace_chgjst en jst)

Parameters

Returns

nil=failure, 1=success

Example

```
(while (c:ace_chgjst (car (nentsel)) "TR"))
```

Module

[Section F - General Functions](#)

Links

[Example](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:ace_dir_files

[Section F - General Functions](#) [Send Feedback](#)

Description

Perform a search of AutoCAD Electrical folders for files, wild-card matching.

AutoLISP

```
(c:ace_dir_files pattern options)
```

Parameters

Parameters	Description
pattern	Wildcard pattern to match, for example, "*.xls".
options	nil or 0 to use base AutoCAD Electrical search path sequence (user folder, cur project's folder, base folder and Support folder in "program files", base Suppo and AeData folder in "documents and settings"). 1's bit set - include search of the "...catalogs" folder. 2's bit set - include search of the "...plc" folder. 4's bit set - include search of AutoCAD paths.

Returns

List of all files found with full qualified path/filenames, or nil if none found.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:ace_find_file

[Section F - General Functions](#) [Send Feedback](#)

Description

Find AutoCAD Electrical support file.

AutoLISP

Parameters	Description
nam	file name to find (for example, "ace_plc.mdb").
options	nil or 0 to use normal AutoCAD Electrical search path sequence (see wd_does_block_exist). 1's bit set - include search of the "...catalogs" folder. 2's bit set - include search of the "...plc" folder. 16's bit set - display "file not found / path list" dialog box if file not found.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:ace_find_substr
[Section F - General Functions](#) [Send Feedback](#)

Description

Find a substring. Note: this is NOT case sensitive.

AutoLISP

```
(c:ace_find_substr string sub startix)
```

Parameters

Parameters	Description
string	Overall string to search.
sub	Substring to find within "string".
startix	char starting point in "string" to start search from (1=1st character position).

Returns

nil if there is no match, or character position where sub match begins (1=1st character position).

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:ace_get_1000_xdata_dbx
[Section F - General Functions](#) [Send Feedback](#)

Description

Get XDATA (1000) value from block INSERT instance on drawing.

AutoLISP

```
(c:ace_get_1000_xdata_dbx dnam hdl aobjnam options)
```

	slashes).
hdl	AutoCAD entity handle of block insert instance.
appnam	Full Xdata name to search for.
options	For future use.

Returns

Xdata record's "1000" data, or nil if not found.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:ace_get_cable_conductor_data
[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Find cable MFG/CAT entry in the _W0_CBLWIRES table of the catalog lookup database file. Return two parallel lists; a list of cable conductor colors and a list of cable conc gauge values.

AutoLISP

(c:ace_get_cable_conductor_data param_lst)
--

Parameters

Parameters	Description
param_lst	List of parameters: nth 0 = MFG manufacturer code nth 0 = MFG manufacturer code nth 1 = CAT cable catalog number

Returns

list of returned data (or nil if no catalog match found).
nth 0 = list of cable color values.
nth 1 = list of cable gauge values.

Example

Pick on parent cable marker symbol, return conductor data.

<pre>(if (setq x (entsel "Select parent cable marker:")) (progn (setq ben (car x)) (setq mfg (c:wd_getattrval ben "MFG")) (setq cat (c:wd_getattrval ben "CAT")) (setq rtn (c:ace_get_cable_conductor_data (list mfg cat))) (princ "ncolor list=") (princ (car rtn)) ; "car" works same as "nth 0" (princ "ngauge list=") (princ (cadr rtn)) ; "cadr" works same as "nth 1" (princ)))</pre>
--

Module

[Section F - General Functions](#)

Links

c:ace_get_cat_data

[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Do a catalog lookup query and return matching record(s).

AutoLISP

```
(c:ace_get_cat_data options mfg pn asm wdblknam)
```

Parameters

Parameters	Description
options	For future use.
mfg	Manufacturer code (can be blank).
pn	Catalog part number.
asm	ASSYCODE value (can be blank).
wdblknam	Symbol block name (or WDBLKNAM value).

Returns

nil if no record found, otherwise returns (list ...) where data_1st:

- nth 0 = "0" for main part number record, "" for subsequent sub-assembly records
- nth 1 = quantity
- nth 2 = subassy count
- nth 3 = catalog part number
- nth 4 = manufacturer
- nth 5 = ASSYCODE value
- nth 6 = "" (not used)

Example

Populate selected components with USER1-USER3 catalog lookup values (assumes that components have been modified to include attributes "USER1, USER2, USER3").

```
(defun c:user_cat_2_symbol ( / x xx cat_rec ben blknam
                           mfg cat assycode)
  ; Utility to populate picked component with USER1/USER2/USER3
  ; values pulled from catalog lookup file
  (while (setq x (entsel "nPick component:"))
    (setq ben (car x))
    ; get "CAT" attribute or xdata value
    (if (AND (setq cat (c:wd_get_pnlval ben "CAT"))
              (/= cat ""))
        (progn
          (setq mfg (c:wd_get_pnlval ben "MFG"))
          (setq assycode (c:wd_get_pnlval ben "ASSYCODE"))
          (setq blknam (c:wd_get_pnlval ben "WDBLKNAM"))
          (if (OR (not blknam) (= blknam ""))
              (progn ; get actual block name
                (setq blknam (cdr (assoc 2 (entget ben)))))
            )
          ; Do catalog lookup on the target MFG/CAT/ASSYCODE combo
          (setq x (c:ace_get_cat_data nil mfg cat assycode blknam))
          (if x ; some data returned, use only first or only record
              ; returned (which will be the main part number).
              (progn
                (setq cat_rec (car x)) ; get first (or only) record
                ; nth7=catalogdesc, 8=query1, 9=query2,...14=user3
                (if (/= (nth 12 cat_rec) "") ; USER1 value
                    (progn ; non-blank USER1 value, write out to USER1
                      ; attribute on block insert
                      (c:wd_modattrval ben "USER1" (nth 12 cat_rec) nil)
                    )
                  )
                (if (/= (nth 13 cat_rec) "") ; USER2 value
                    (progn ; non-blank USER2 value, write out to USER2
                      ; attribute on block insert
                      (c:wd_modattrval ben "USER2" (nth 13 cat_rec) nil)
                    )
                  )
                (if (/= (nth 14 cat_rec) "") ; USER3 value
                    (progn ; non-blank USER3 value, write out to USER3
                      ; attribute on block insert
                      (c:wd_modattrval ben "USER3" (nth 14 cat_rec) nil)
                    )
                  )
                )
          )
    )
  )
```

[Section F - General Functions](#)

Links

[Example](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:ace_get_pnlval_dbx
[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Get ATTRIB or XDATA (1000) value from block INSERT instance on drawing. XDATA is in form "VIA_WD_attnam". Look for ATTRIB first, if not found, look for XDATA value.

AutoLISP

```
(c:ace_get_pnlval_dbx dnam hdl attnam options)
```

Parameters

Parameters	Description
dnam	nil for active dwg or full path/dwg name (use double backslashes or single for slashes)
hdl	AutoCAD entity handle of block insert instance.
attnam	Attribute's name to query for its value.
options	For future use.

Returns

Return nil if not found, otherwise return value

Example

Get attribute SHEET value from block insert hdl "B2F" on drawing "c:projectsdemo04.dwg"

```
(setq val (c:ace_get_pnlval_dbx "c:/projects/demo04.dwg" "B2F" "SHEET" nil))
```

Module

[Section F - General Functions](#)

Links

[Example](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:ace_get_ptag_attrval
[Section F - General Functions](#) [Send Feedback](#)

Description

Find panel footprint symbols or panel terminal attribute value or split tag values from block insert instance. Find P_TAG1, P_TAG1_PART* (panel footprint symbols), or P_ (panel terminal) attribute value or split tag values from block insert instance. Look for Xdata if target attributes are not found.

AutoLISP

```
(c:ace_get_ptag_attrval ben options_lst)
```

options_lst

nil (for future use).

Returns

nil=failure. If single attribute = (list tagstr 1 what attrnam attr_entname). If split-tag attributes = (list tagstr cnt what attrnam_lst attr_entname_lst attr_val_lst) where:

"tagstr" = full tag-id string (concatenated if split tag)

"cnt" = 1 for single attribute, 2 or 3 for split tag

"what" = 1 for component footprint, 0=panel terminal or unknown

"attrnam" = tag attribute name (ex: "P_TAG1")

"attr_entname" = entity name of the tag attribute

"attrnam_lst" = list of 3 split attribute names

"attr_entname_lst" = list of split attribute entity names (nil values= saved as Xdata)

"attr_val_lst" = value list of individual split attributes

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:ace_get_tag_attrval

[Section F - General Functions](#) [Send Feedback](#)

Description

Get tag attribute values. Find TAG1, TAG1F, TAG1_PART*, TAG1F_PART*, (parent schematic symbols) or TAG2, TAG2_PART* (child schematic symbols) or TAG, TAG_* (if divided PLCIO children) or TAGSTRIP (schematic terminal) attribute value or split tag values from block insert instance.

AutoLISP

(c:ace_get_tag_attrval ben options_lst)

Parameters

Parameters	Description
ben	Entity name of block insert.
options_lst	nil (for future use).

Returns

(if single attribute) = (list tagstr 1 what attrnam attr_entname). (if split-tag attributes) = (list tagstr cnt what attrnam_lst attr_entname_lst attr_val_lst) where:"tagstr" = string (concatenated if split tag)

"cnt" = 1 for single attribute, 2 or 3 for split tag

"what" = 1 for parent, 2 for child, 0=terminal or unknown

"attrnam" = tag attribute name (ex: "TAG1")

"attr_entname" = entity name of the tag attribute

"attrnam_lst" = list of 3 split attribute names

"attr_entname_lst" = list of split attribute entity names

"attr_val_lst" = value list of individual split attributes

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#) [Send Feedback](#)

Description

Retrieve catalog record's TEXTVALS data, if defined. ONE of the first two arguments must be supplied.

AutoLISP

```
(c:ace_get_textvals ben blknam mfg cat asmb)
```

Parameters

Parameters	Description
ben	Target entity name or entity handle.
blknam	Target entity block name.
mfg	manufacturer code (can be blank)
cat	catalog part number
asmb	ASSYCODE value (can be blank)

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:ace_getattr_data
[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Get specific attribute information from block insert.

AutoLISP

```
(c:ace_getattr_data ben attrnam)
```

Parameters

Parameters	Description
ben	AutoCAD entity name of selected AutoCAD Electrical component block.
attrnam	AutoCAD attribute to extract (wild cards supported).

Returns

(list attrvalue attrname attr_ent_name) or nil if failure.

Example

Hide attribute "DESC1" on the target block insert, entity name passed in variable "ben"

```
(if (setq rtn (c:ace_getattr_data ben "DESC1"))
  (progn
    (setq ed (entget (caddr rtn))) ;open up the attribute entity
    (setq xx (cdr (assoc 70 ed))) ;get the 70 subrecord
    (if (AND (= (logand xx 1) 0) (= (cdr (assoc 0 ed)) "ATTRIB"))
      (progn ;this ATTRIB is currently marked "visible", flip to invisible
        (entmod (subst (cons 70 (1+ xx)) (assoc 70 ed) ed)) ; set 1's bit for "invisible"
        (entupd (caddr rtn)) ;trigger the attribute to regen
      )
    )
)
```

Links

[Example, Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:ace_mod_tag_attrval
[Section F - General Functions](#) [Send Feedback](#)

Description

Find tag attribute on schematic symbol and then write modified tag-ID value out to it. If the symbol carries a "split" tag, then divide the "tagstr" across the split tag attrib attribute can be single TAG1, TAG2, TAG1F, TAG, TAG_*, TAGSTRIP or can be split tags TAG1_PART*, TAG2_PART*.

AutoLISP

```
(c:ace_mod_tag_attrval ben tagstr options_lst)
```

Parameters

Parameters	Description
ben	Schematic component entity to process.
tagstr	New tag-ID value.
options_lst	nil (for future use).

Returns

nil if failure, 1=success

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:ace_projwide_script
[Section F - General Functions](#) [Send Feedback](#)

Description

Run a user script against each drawing to be processed.
Similar to selecting the "Run command file script" option of the Project-Wide Utilities (AEUTILITIES) user command. The script is run against the listed drawings, but all u: are bypassed.

AutoLISP

```
(c:ace_projwide_script dlst scrfnam)
```

Parameters

Parameters	Description
dlst	nil to process all dwgs in active project, or list of dwgs to process
scrfnam	script file name to run against each drawing

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:ace_surf_zoom_in_no_dlg
[Section F - General Functions](#) [Send Feedback](#)

Description

Force surf to drawing, zoom in on entity, and optionally center on coordinates.

AutoLISP

```
(c:ace_surf_zoom_in_no_dlg fnam hdl optional_xy)
```

Parameters

Parameters	Description
fnam	Full path to target dwg, nil=active drawing.
hdl	Handle of entity to zoom up on.
optional_xy	nil to zoom up on insertion point of object "hdl", otherwise zoom up on this cc

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:ace_tag_fixed
[Section F - General Functions](#) [Send Feedback](#)

Description

Change block insert's "tag-ID" value to fixed or back to normal. Block can be a wire number or a parent schematic component.

AutoLISP

```
(c:ace_tag_fixed en fixed_flag options)
```

Parameters

Parameters	Description
en	Entity name of block insert to process.
fixed_flag	1 to force tag to "Fixed", otherwise restore to "Normal"
options	1's bit set = "read only" mode, return current fixed/normal state but do not u (ignore state of "fixed_flag")

Returns

RETURN (list return_state at_en ben value tagname) [tagname for component only] ; where "return_state" = nil if not component or wire number or no change required, changed to normal or reporting normal, 1 = fixed ; "at_en" = entity name of tag-ID or wire number attribute ; "ben" = entity name of component or wire number insert ; text value of tag-ID or wire number ; "tagname" = tag-ID attribute name (components only) - ex: "TAG1"

Module

What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_2ss
[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Trigger generation of Export DWGS-->TO Spreadsheet data dump without any user prompts.

AutoLISP

(c:wd_2ss param_lst)

Parameters

Parameters	Description
param_lst	a "list" of eight elements - dumpwhat = "comp" for schem components, "pnl" for panel components, "ts" schematic terminals, "pnlterm" for panel terminals, "sig" for wire from/to sign "wnum" for wire numbers, "wnumlay" for wire layers, "plc" for PLC modules, ' for PLC I/O points and descriptions. doall = 1 to process all dwgs in current project, nil to do current dwg only, 2: partial list of dwg indexes (list in partial_lst below). partial_lst = if doall=2 then this gives list of drawing index numbers to proc 1 = first dwg in project list, 2 = 2nd, and so on, for example, (list "2" "10" "3 todolocs = 1 to process all components, 2 process only components that hav location code, 3 process components that "wild card match with "doloc" paran below. doloc = location code to include (if todolocs = 3). Can have wild cards per Au standards (for example, "*CAB*") means any location with "CAB" substring. format = output file format: "XLS" for Excel, "MDB" for Microsoft Access forrn for comma- delimited ASCII outfilename = output file name (use double backslashes or single forward sl scriptfilename = optional script file name (executes after report extraction i: complete). The "outfilename" can be accessed from within the script file throu following AutoLISP expression: (vl-bb-ref 'FNAM).

Example

```
(c:wd_2ss (list "comp" 1 nil 1 nil "XLS" "c:/rep/datadump.xls" nil))
(setq d_lst (c:wd_pdwgs (nth 6 (c:wd_proj_wdp_data)) "Select
drawings to process" "" nil))
(setq partialtodo_ixlst nil)
(if d_lst
  (if d_lst
    (progn
      (foreach xxx (cadr d_lst)
        ; indexed to 0, have to add one to each
        (setq ix (wd_mdb_wdp2ix ix (1+ xxx)))
        (if (not (member ix partialtodo_ixlst))
          (setq partialtodo_ixlst (cons ix partialtodo_ixlst))
        ))
      (c:wd_2ss (list "comp" 2 partialtodo_ixlst 1 nil "CSV" fname nil))
    )
    ELSE
    (c:wd_2ss (list "comp" 1 nil 1 nil "CSV" fname nil))
  )
)
```

Module

[Section F - General Functions](#)

Links

[Example](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_4_squish_fname
[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Parameters

Parameters	Description
fname	Filename string to squish.
maxwdt	Maximum number of characters for result string.

Returns

Filename string reduced to required length with "..." in the center.

Example

Return active dwg's full path name limited to 50 characters.

```
(c:wd_4_squish_fname (strcat (getvar "DWGPREFIX") (getvar "DWGNAME")) 50)
```

Module

[Section F - General Functions](#)

Links

[Example](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_add_attr

[Section F - General Functions](#) [Send Feedback](#)

Description

Add an attribute to an existing inserted block on a drawing.

AutoLISP

```
(c:wd_add_attr entnam attrnam val jst hgt wdt xy visibility)
```

Parameters

Parameters	Description
entnam	Block entity name (nil = prompts user to pick block).
attrnam	Attribute name to add (nil = prompts for name).
val	Value to attach to new attribute (nil = prompts for value).
jst	Justification (ex: "L" = left) (nil = defaults to "L").
hgt	Attribute text height (nil = defaults to TEXTSIZE variable).
wdt	Width (nil = 1.0).
xy	Attrib insertion point xyz (nil = prompt user for insertion point).
visibility	1 for invisible, 0 for visible.

Returns

Entity name of the re-written block insert instance.

Module

[Section F - General Functions](#)

Links

c:wd_block_path_failed_msg

[Section F - General Functions](#) [Send Feedback](#)

Description

Display error dialog box for block not found in AutoCAD Electrical search paths.

AutoLISP

```
(c:wd_block_path_failed_msg nam)
```

Parameters

Parameters	Description
nam	Name of block not found in search paths.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_bomr_ent_qb

[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Display full catalog information for select schematic or pnl block.

AutoLISP

```
(c:wd_bomr_ent_qb ben)
```

Parameters

Parameters	Description
ben	AutoCAD entity name of selected AutoCAD Electrical schematic or pnl footprin

Example

```
(while (c:wd_bomr_ent_qb (car (entsel))))
```

Module

[Section F - General Functions](#)

Links

[Example](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_bomr_entcat

[Section F - General Functions](#) [Send Feedback](#)

Description

Parameters

Parameters	Description
ben	selected INSERT entity, AcadE schematic or panel footprint.

Returns

List of lists (rtrn): (nth 0 rtrn) = (list mfg cat assycode count dbfblknam unit_measure) (nth 1 rtrn) = (list (list {2+ multiple BOM cat number lists})) (nth 2 rtrn) = (list { suffixes for each 2+ part num list})

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_bomr_qbdat
[Section F - General Functions](#) [Send Feedback](#)

Description

Get the list of catalog look-up data lists for the selected entity.

AutoLISP

(c:wd_bomr_qbdat ben)

Parameters

Parameters	Description
ben	AutoCAD entity name of selected AutoCAD Electrical schematic or pnl footprin

Returns

List of lists where first list is for the main part number and any subsequent lists are the "Multi- BOM" extra part number. Each list consists of 17 or more elements includir number, block name, and a full dump of the data from the target catalog look-up file.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_bswap
[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Swap out INSERT entity with new block. Preserve attribute values and wire connections.

*Note: blocks swapped must have different names. Use [c:wd_bswap_redefine_curdwg](#) to swap blocks with the same name.

AutoLISP

oldben	Old block entity to swap out.
wd_symnam	New block entity.
options	1's bit set = retain old ATTRIB locations, 0 = use new. 2's bit set = suppress copy of existing attrib values to matching attribs on new = copy values from old to new where there is a match. 4's bit set = copy old to new if new's attribute value is blank (attrib MFG*,CAT*,TERM*,PINLIST*, ASSYCODE*,MAXN* attributes only). 8's bit set = return handle of swapped block, 0 = return entity name of swap 16's bit set = only reconnect to LINES that are on a valid wire layer. nil = 0 or no bits set
retain_scl	1 to keep existing symbol's scale.
force_scl	scale value override if non-nil.
maplst	nil to ignore or (list (list old new) (list old new)...) to map existing attribute v: new symbol's attribute values.

Returns

(list ent dif_fam) where:

"ent" = entity name or handle (based upon 8's bit of options) or nil if nothing swapped.

"dif_fam" = 1 if swapped block was of a different FAMILY than the original.

Example

```
(defun c:bswap_ex ( / ss en ed oldblknam newblknam slen ix)
  (setq en (entsel "nSelect block type to swap:"))
  (if en
    (progn
      ; Make sure AcadE is "awake"
      (if (not wd_load) ;if not in memory
        (if (setq x (findfile "wd_load.lsp")) (load x)) ;load AcadE init functions
      )
      (wd_load) ;wake up AcadE if not already awake
      (setq en (car en)) ;entity name of block that user picked
      (setq ed (entget en)) ;entity data
      (setq oldblknam (cdr (assoc 2 ed))) ;get actual block name
      (setq newblknam (getstring "nEnter New block name to use for swap:"))
      (if (/= newblknam "")
        (progn
          ;Okay, prepare to do the swapping!
          ;First find all instances of the old block
          (setq ss (ssget " _X" (list (cons -4 "<AND") (cons 0 "INSERT")
                                     (cons 2 oldblknam) (cons -4 ">AND>"))))
          (setq slen (sslength ss))
          (setq ix 0)
          (while (< ix slen)
            (setq old_ben (ssname ss ix)) ;next block instance to do
            ;Do the swap. Don't force attributes to old locs, keep
            ;existing block insert scale factor, no attrib mapping.
            (c:wd_bswap old_ben newblknam nil 1 nil nil)
            (setq ix (1+ ix)) ;increment counter to get next instance
          )
        )
      )
    )
  )
  (setq ss nil) ;release selection set
  (princ)
)
```

Module

[Section F - General Functions](#)

Links

[Example](#), [Section F - General Functions](#)

Description

Block swapping, drawing-wide. Connected wires automatically stretch/trim to reconnect, when possible.

Parameters

Parameters	Description
oldnams	List of old block names.
newnams	List of new block names.
retain	Retain old.
retain_scl	Retain old scale.
maplst	nil or optional list of parallel lists mapping old attrib values to new. For examp (list "OLDNAM1" "OLDNAM2" "OLDNAM3") as old names, and (list "TAG##" "E DESC2")) as corresponding new names.

Example

```
(c:wd_bswap_list (list "HCR1" "HLT1A") (list "c:/new/HCR1x" "c:/new/HLT1Ax") 1 1 nil)
```

Module

[Section F - General Functions](#)

Links

[Example](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_bswap_redefine_curdwg
[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Update existing block with a newer version of the same block

AutoLISP

```
(c:wd_bswap_redefine_curdwg ( oldnam disknam options retain_scl new_scl maplst/ )
```

Parameters

Parameters	Description
oldnam	Old block name to swap out.
disknam	New block name used to replace
options	1's bit set = retain old ATTRIB locations, 0 = use new. 2's bit set = suppress copy of existing attrib values to matching attribs on new = copy values from old to new where there is a match. 4's bit set = copy old to new if new's attribute value is blank (attrib MFG*,CAT*,TERM*,PINLIST*, ASSYCODE*,MAXN* attributes only). 8's bit set = return handle of swapped block, 0 = return entity name of swap 16's bit set = only reconnect to LINES that are on a valid wire layer. nil = 0 or no bits set
retain_scl	1 to keep existing symbol's scale.
new_scl	scale value override if retain_scl is nil.
maplst	nil to ignore or (list (list old new) (list old new)...) to map existing attribute v: new symbol's attribute values.

Example

To update all the HPB11 blocks in the current drawing with a new block of scale 5

```
(c:wd_bswap_redefine_curdwg "HPB11" "HPB11" 1 nil 5.0 nil)
```

[Example, Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_cat_lookup
[Section F - General Functions](#) [Send Feedback](#)

Description

Open AutoCAD Electrical's CATALOG LOOKUP dialog box.

AutoLISP

```
(c:wd_cat_lookup wdblnam cmp_en mfgn_old pn_old asm_old ncreate)
```

Parameters

Parameters	Description
wdblnam	block name to drive table to query (ex: "HLT1R" will access "LT1R").
cmp_en	optional entity name to find catalog number for (nil=use wdblnam for determ table name).
mfgn_old	Optional catalog info to trigger dialog box to come up with the target catalog highlighted (if it exists in the database table).
pn_old	Optional catalog info to trigger dialog box to come up with the target catalog highlighted (if it exists in the database table).
asm_old	Optional catalog info to trigger dialog box to come up with the target catalog highlighted (if it exists in the database table).
ncreate	1 to prohibit call from offering user option to create a new database table if th one does not exist.

Returns

Selected record or nil if none.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_chg_to_attdef
[Section F - General Functions](#) [Send Feedback](#)

Description

Convert text entity to an attrib definition, in place. Note: this does NOT add an attribute to an existing block insert.

AutoLISP

```
(c:wd_chg_to_attdef txten attnam)
```

Parameters

Parameters	Description
txten	Entity name of text entity to convert.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_chgjst
[Section F - General Functions](#) [Send Feedback](#)

Description

Allows user picks to change ATTRIB or TEXT justification. Can be set up in acad.pgp as a "hot key", if desired (ex: "J, *wd_chgjst") where user types "J", space, , [Enter] starts picking.

AutoLISP

(c:wd_chgjst)

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_comp_ref_list
[Section F - General Functions](#) [Send Feedback](#)

Description

Return list of cross-reference information for selected component or tag name.

AutoLISP

(c:wd_comp_ref_list en compinfo_lst freshen)

Parameters

Parameters	Description
en	Component entity name.
compinfo_lst	(list tagn inst loc family) (or nil if "en" provided).
freshen	1 to freshen database before doing search for refs.

Returns

List in the following form: (list picked used notused coil_pins used_formc avail_formc pinlist). Where :
wirenum1 and wirenum2 = wire number assignments on connected wires on each side of contact.
pin1 and pin2 = TERMDSCxx terminal pin description text associated with the two wire connections.
typ = component contact type: NO, NC, or <> for coil.
ref = line or grid reference location of component.
sh and dwgnam = the %S and %D values set up in the AcadE CONFIG dialog box.
hdl = AutoCAD object handle value of the component.

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_del_1000_xdata
[Section F - General Functions](#) [Send Feedback](#)

Description

Delete an existing "dxf group code 1000" xdata record from an entity.

AutoLISP

```
(c:wd_del_1000_xdata en appname)
```

Parameters

Parameters	Description
en	Entity name.
appname	xdata name (for example, "VIA_WD_MFG01").

Returns

1=success, nil = not found or failure.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_del_xdata_appnam
[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Deletes xdata from an entity

AutoLISP

```
(c:wd_del_xdata_appnam ben appnam)
```

Parameters

Parameters	Description
ben	Block Entity
Appnam	The xdata name. It requires the VIA_WD_ prefix for the xdata name

Example

Removing the pinlist xdata from the last inserted block entity.
(c:wd_del_xdata_appnam (entlast) "VIA_WD_PINLIST")

[Example](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_delim_str_to_lst
[Example 1](#) [Example 2](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Convert a delimited string into an AutoLISP list.

AutoLISP

```
(c:wd_delim_str_to_lst str delim_char)
```

Parameters

Parameters	Description
str	String to convert.
delim_char	Character acting as delimiter.

Returns

List of parsed strings.

Example 1

To return a 4-element list: ("I" "love" "this" "product")

```
(c:wd_delim_str_to_lst "I love this product" " ")
```

Example 2

To return a 5-element list: ("3" "5" "7" "11" "13")

```
(c:wd_delim_str_to_lst "3,5,7,11,13" ",")
```

Module

[Section F - General Functions](#)

Links

[Example 1](#), [Example 2](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_does_block_exist
[Section F - General Functions](#) [Send Feedback](#)

Description

Search for schematic block name using AutoCAD Electrical's search paths.

AutoLISP

```
(c:wd_does_block_exist nam)
```

Parameters

Parameters	Description
------------	-------------

8th = AutoCAD search paths (this is inserted as the 3rd check if the wd.env fi WD_ACADPATHFIRST setting is enabled).

Returns

Full path name if found, nil otherwise.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_does_block_exist_dbx
[Section F - General Functions](#) [Send Feedback](#)

Description

Return the block name if the block is already defined in drawing.

AutoLISP

(c:wd_does_block_exist_dbx nam ff dwgnam)

Parameters

Parameters	Description
nam	block name to search for (can include ".dwg" extension) Return block name "1" block already defined in drawing. Otherwise search for "nam" in this order: 1s name if full path was provided 2nd: in path pointed to by GBL_wd_usr 3rd: in subdirectory where current project file is located (if proj active) 4th: in path GBL_wd_lib 5th: in "c:documents and settings..." support folder 6th: in path GBL_wd_sup 7th: normal AutoCAD directories
ff	handle if target dwg is already opened with (wd_dbx_open...), nil if not
dwgnam	(if ff=nil) then = drawing name (nil=active drawing)

Returns

Return full path name. If not successful, return nil.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_does_file_exist
[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Search various AutoCAD Electrical *install* paths and AutoCAD support path(s) for the file "nam"

Parameters

Parameters	Description
nam	File name.

Returns

Full path name if found, nil otherwise.

Example

Return folder path to file "test.dwg".

```
(c:wd_does_file_exist "test.dwg")
```

Module

[Section F - General Functions](#)

Links

[Example](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_does_file_exist_error
[Section F - General Functions](#) [Send Feedback](#)

Description

Display error dialog box for file name not found in AutoCAD Electrical search paths.

AutoLISP

```
(c:wd_does_file_exist_error msg nam)
```

Parameters

Parameters	Description
msg	Message to display.
nam	File name not found in search paths.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_edit_attribute
[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Retrieve target attribute from insert and open an edit dialog box that has "pick just like" and increment/decrement toggles.

AutoLISP

ben	AutoCAD entity name of selected AcadE component block.
attnam	AutoCAD attribute to edit (wild cards supported).

Returns

Value of 1 if attribute value changed, nil = no change or attribute not found.

Example

```
(c:wd_edit_attribute (car (entsel)) "CAT")
```

Module

[Section F - General Functions](#)

Links

[Example](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_find_wdw
[Section F - General Functions](#) [Send Feedback](#)

Description

Find and return the file name of the wire color/gauge mapping (.wdw) file appropriate for the current project or else the default file if a project-specific version is not foun

AutoLISP

```
(c:wd_find_wdw)
```

Returns

.wdw file name.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_get_1000_xdata
[Section F - General Functions](#) [Send Feedback](#)

Description

Get xdata from entity.

AutoLISP

```
(c:wd_get_1000_xdata en appname)
```

Parameters

Parameters	Description

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_get_1005_xdata
[Section F - General Functions](#) [Send Feedback](#)

Description

Look for handle pointer value saved as xdata on target entity.

AutoLISP

```
(c:wd_get_1005_xdata en appname)
```

Parameters

Parameters	Description
en	Entity name.
appname	xdata name (ex: "VIA_WD_WNPTR").

Returns

Handle string if success, nil=target xdata not found.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_get_locs_for_proj
[Section F - General Functions](#) [Send Feedback](#)

Description

Extract component LOC values, project-wide. Display in pick list dialog box.

AutoLISP

```
(c:wd_get_locs_for_proj what)
```

Returns

Selected LOC code or nil if nothing picked from dialog box.

Module

[Section F - General Functions](#)

Links

c:wd_get_locs_for_proj_mult
[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Extract component LOC values, project-wide. Multiple selection. Display in pick list dialog box.

AutoLISP

```
(c:wd_get_locs_for_proj_mult what)
```

Returns

Selected LOC code or codes, comma delimited.

Example

```
(if (setq loc_string (c:wd_get_locs_for_proj_mult nil)) (setq loc_list (c:wd_delim_str_to_lst loc_string ",")))
```

Module

[Section F - General Functions](#)

Links

[Example](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_get_locs_on_dwg
[Section F - General Functions](#) [Send Feedback](#)

Description

Extract component LOC values from the current drawing, display in a pick list dialog box.

AutoLISP

```
(c:wd_get_locs_on_dwg)
```

Parameters

Parameters	Description
options	1 = display pick list dialog, allow single selection 3 = display pick list dialog, allow multiple selection - returns a comma-delimit

Returns

Selected LOC code or nil if nothing is picked from the dialog box.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_get_pnlval
[Section F - General Functions](#) [Send Feedback](#)

AutoLISP

```
(c:wd_get_pnlval ben attnam)
```

Parameters

Parameters	Description
ben	AutoCAD entity name of footprint block insert instance.
attnam	Attribute's name to query for its value (wildcards ok).

Returns

Attrib or xdata value, or nil if not found.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_getattrval
[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Retrieve attribute value.

AutoLISP

```
(c:wd_getattrval ben attnam)
```

Parameters

Parameters	Description
ben	AutoCAD entity name of selected AutoCAD Electrical component block.
attnam	AutoCAD attribute to extract (wild cards supported; capital letters only).

Returns

Attribute value or nil = attribute not found.

Example

This snippet of code illustrates how a specific attribute's value is extracted from block inserts on the drawing.

```
defun c:lastwnum ( / ss exclude_num_lst ix slen rtnrn wireno maxnum en val)
; Scan current dwg and find "last wire number" used. Drawing needs to have been processed
; by AcadE's AUTO WNUMS command or wire numbers manually inserted using AcadE's EDIT WNUM
; command. This routine can be encoded into AcadE's title block update mapping file to
; automatically populate a target attribute in the title block with the last wire number
; used on the drawing.

(setq rtnrn "") ; default to return a blank space if no wire numbers found

(if (not GBL_wd_m) (wd_cfg_read_dwg_params)) ; read WD_M block if necessary

; Step 1 - get list of all wire numbers found on DESTINATION signal arrows. These numbers
; will be excluded from the calculation because the wire number was assigned on some
; other drawing.

(setq exclude_num_lst nil)
(setq maxnum 0)
```

```
(setq en (ssname ss ix)) ; get next block entity name from the selection set
; Look for attribute WIRENO on this arrow symbol. Get its value (wire number)
(setq wireno (c:wd_getattrval en "WIRENO"))
(if (AND wireno (/= wireno ""))
  (progn ; save wire number in the "exclude" list
    (setq exclude_num_lst (cons wireno exclude_num_lst))
  )
  (setq ix (1+ ix)) ; increment counter
)
(setq ss nil) ; release the selection set
))

; Step 2 - get all wire number block inserts on current drawing
(setq ss (ssget "_X" '((-4 . "<AND")(0 . "INSERT")(2 . "WD_WN*")(-4 . "<AND>"))))
(if (/= ss nil) ; Some wire numbers found on drawing, continue
  (progn
    (setq slen (sslength ss)) ; number of wire number block inserts on dwg
    (setq ix 0)
    (while (< ix slen)
      (setq en (ssname ss ix)) ; get next wire number block/insert entity name
      ; Grab wire number off of this wire number block insert.
      (setq wireno (c:wd_getattrval en "WIRENO*")) ; could be WIRENO or WIRENOF for "fixed"
      (if (AND wireno (/= wireno "")) ; wire number is not blank
        (progn
          ; Make sure that this wire number is not one we're excluding (i.e. Destination wnum)
          (if (not (member wireno exclude_num_lst))
            (progn ; okay, good wire number to process
              (setq val (atoi wireno)) ; convert wire number to integer value
              (if (> val maxnum)
                (progn ; this wire number is biggest so far. Save it.
                  (setq rtrn wireno) ; return highest wire number so far
                  (setq maxnum val) ; save highest value so far
                )
              )
            )
          )
        )
      )
      (setq ix (1+ ix))
    )
    (setq ss nil) ; release selection set
  )
  )
  rtrn ; return "" or highest wire number found on this dwg
)
```

Module

[Section F - General Functions](#)

Links

[Example](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_getenv
[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Retrieve settings out of "wd.env" environment file.

AutoLISP

```
(c:wd_getenv varnam)
```

Parameters

Parameters	Description
varnam	Variable name (for example, "WD_LIB" or "WD_CAT").

Returns

Character string value or "nil" if not listed.

Example

Returns folder path to default catalog lookup file.

```
(c:wd_getenv "WD_CAT")
```

Module

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_getflist
[Section F - General Functions](#) [Send Feedback](#)

Description

Return directory listing list.

AutoLISP

```
(c:wd_getflist path_fname option)
```

Parameters

Parameters	Description
path_fname	Path and or path+wildcard.
option	nil (not used).

Returns

List of fully qualified file names, or nil if none found.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_import_scratch_mdb_doit
[Section F - General Functions](#) [Send Feedback](#)

Description

Trigger auto update of current drawing's AutoCAD Electrical component and wire number data based upon changed data in the project scratch ".mdb" database file.

AutoLISP

```
(c:wd_import_scratch_mdb_doit fnam dwgix table_lst options)
```

Parameters

Parameters	Description
fnam	Full path name of AcadE project database file (nil = active proj).
dwgix	The "DWGIX" field in the target table(s) to identify which records go with the dwg (the DWGIX field value in FILETIME table).
table_lst	List of tables to process, ex: (list "COMP" "TERMS" "PNLCOMP").
options	For future use (set to 0).

Module

[Section F - General Functions](#)

Links

c:wd_increment_str

[Example 1](#) [Example 2](#) [Example 3](#) [Example 4](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Increment ASCII string by value (integer, positive or negative).

AutoLISP

```
(c:wd_increment_str str val)
```

Parameters

Parameters	Description
str	Char string to increment.
val	Integer count to increment or decrement.

Example 1

To return "ABD" :

```
(c:wd_increment_str "ABC" 1)
```

Example 2

To return "W012-4" :

```
(c:wd_increment_str "W012-3" 2)
```

Example 3

To return 100 :

```
(c:wd_increment_str "99" 1)
```

Example 4

To return "100Z8" :

```
(c:wd_increment_str "100X" 10)
```

Module

[Section F - General Functions](#)

Links

[Example 1](#), [Example 2](#), [Example 3](#), [Example 4](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_ins_table

[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Display comma delimited file in a report dialog, optionally insert as a table on to the active drawing.

AutoLISP

```
(c:wd_ins_table fname)
```

Parameters

```
(c:wd_ins_table "c:/proj/wirefrm2.csv")
```

Module

[Section F - General Functions](#)

Links

[Example](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_is_it_schem_or_pnl
[Section F - General Functions](#) [Send Feedback](#)

Description

Return code indicating the target block insert.

AutoLISP

```
(c:wd_is_it_schem_or_pnl ben)
```

Parameters

Parameters	Description
ben	Block entity.

Returns

Return code as follows :

- 1 = PLCIO schematic.
- 2 = wire number block.
- 3 = master line reference, i.e. ladder.
- 4 = schematic, parent.
- 5 = schematic, child.
- 6 = source or dest arrow.
- 7 = schematic terminal.
- 8 = ref only arrow.
- 9 = panel component or panel terminal.
- 10= panel nameplate.
- 11= stand-alone cross-ref symbol.
- 12= extra wirenum copy.
- 13= conduit component (C_TAG1 or C_TAG2).
- 14= conduit marker component (C_TAG).
- 15= in-line wire number marker or in-line wire label.
- 16= in-line multi-connection sequence terminal symbol.
- 17= report table.
- 18= iec-style angled wire tee connector symbol.
- nil = unknown.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Description

Moves entities to new layer, even entities that are embedded in inserted blocks on the drawing. Prompts for "old" layer and "move to" layer names. It is therefore scriptal

AutoLISP

```
(c:wd_layer_move)
```

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_make_prev_selset
[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Create a "Previous" selection set from entity.

AutoLISP

```
(c:wd_make_prev_selset ben)
```

Parameters

Parameters	Description
ben	Entity name or entity handle string.

Returns

Entity name if success and selection set is created. nil on failure.

Example

Capture a newly created wire number entity and make it accessible using AutoCAD "Previous" selection option:

```
(c:wd_make_prev_selset (c:wd_putwnxyf xy "123A"))
```

Module

[Section F - General Functions](#)

Links

[Example](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_mod_1000_xdata
[Section F - General Functions](#) [Send Feedback](#)

Description

Add or modify existing "1000" xdata value.

AutoLISP

Parameters	Description
en	Entity name.
appname	xdata name (for example, "VIA_WD_WDBLKNAME").
data	xdata record's "1000" data.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_mod_1005_xdata

[Section F - General Functions](#) [Send Feedback](#)

Description

Save handle pointer string on entity under xdata. Create xdata if it does not exist. If it does exist, overwrite with new value.

AutoLISP

```
(c:wd_mod_1005_xdata en hdl appname)
```

Parameters

Parameters	Description
en	Entity name.
hdl	Handle pointer string.
appname	xdata name (ex: "VIA_WD_WNPTR").

Returns

non-nil=success, nil=failure

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_modattrval

[Section F - General Functions](#) [Send Feedback](#)

Description

Modify attribute "attnam" with new value "newval" on insert entity "ben". Don't trigger entity regen if "noupd" is 1.

AutoLISP

```
(c:wd_modattrval ben attnam newval noupd)
```

Parameters

newval	New attribute value to insert.
noupd	1 to suppress regen, nil to regen block insert to force screen refresh of a char attribute value.

Returns

1 if success, nil = failure or target attribute not found on block.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_msg
[Example 1](#) [Example 2](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Return message string from match in message Access database file wd_msg.mdb in currently selected language.

AutoLISP

<pre>(c:wd_msg msgcode vals default_msg)</pre>
--

Parameters

Parameters	Description
msgcode	Key field value for query.
vals	nil if none or list of values to insert into "%1", "%2" flags in the encoded mes
default_msg	Message to return if no match found in lookup.

Example 1

<pre>(princ (c:wd_msg "GEN0010" nil "Select file for report"))</pre>
--

Example 2

<pre>(princ (c:wd_msg "USER040" (list (itoa cnt)) (list "Error cnt:" (itoa cnt))))</pre>
--

Module

[Section F - General Functions](#)

Links

[Example 1](#), [Example 2](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_read_wdw
[Example](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Parameters

Parameters	Description
fname	full path name to ".wdw" wire color/gauge mapping file.

Returns

nil if file not found or (list (list laynam color-ga label)(list...))

Example

```
(setq maplst (c:wd_read_wdw (c:wd_find_wdw)))
```

Module

[Section F - General Functions](#)

Links

[Example](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_selsort
[Example 1](#) [Example 2](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Sorting list of lists routine, multi-level if desired.

AutoLISP

```
(c:wd_selsort lst function)
```

Parameters

Parameters	Description
lst	List or list of lists to sort.
function	Sort function.

Returns

Sorted list.

Example 1

This example will return (("MOTOR" "10KW") ("MOTOR" "15KW") ("FUSE" "100A") ("FUSE" "50A"))

```
(setq lst '(("FUSE" "100A") ("MOTOR" "10KW") ("FUSE" "50A") ("MOTOR" "15KW")))  
(setq lst (c:wd_selsort lst '(lambda (X Y)  
  (if (= (nth 0 X) (nth 0 Y)) ; if 1st elements are equal  
    (< (nth 1 X) (nth 1 Y)) ; then ascending sort on 2nd elem's  
    ; ELSE  
    (> (nth 0 X) (nth 0 Y)) ; else decending sort on 1st elem's  
  )))
```

Example 2

This example will return (("MOTOR" "10KW") ("MOTOR" "15KW") ("FUSE" "50A") ("FUSE" "100A"))

```
(setq lst '(("FUSE" "100A") ("MOTOR" "10KW") ("FUSE" "50A") ("MOTOR" "15KW")))  
(setq lst (c:wd_selsort lst '(lambda (X Y)  
  (if (= (nth 0 X) (nth 0 Y)) ; if 1st elements are equal  
    (< (atoi (nth 1 X)) (atoi (nth 1 Y))) ; then ascending int sort on 2nd elem's  
    ; ELSE  
    (> (nth 0 X) (nth 0 Y)) ; else decending sort on 1st elem's  
  )))
```

Links

[Example 1](#), [Example 2](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_split_fnam
[Example 1](#) [Example 2](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Split file name into list of path, name, extension.

AutoLISP

```
(c:wd_split_fnam fname)
```

Parameters

Parameters	Description
fname	Filename string to parse.

Returns

List of strings.

Example 1

Return (list "c:/acade_custom/" "wirefrm2" ".lsp")

```
(c:wd_split_fnam "c:/acade_custom/wirefrm2.lsp")
```

Example 2

Return just the base drawing name of active drawing without extension.

```
(cadr (c:wd_split_fnam (getvar "DWGNAME")))
```

Module

[Section F - General Functions](#)

Links

[Example 1](#), [Example 2](#), [Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_ss2_import_curdwg
[Section F - General Functions](#) [Send Feedback](#)

Description

Trigger an auto update of current drawing based upon changed data carried in an Excel spreadsheet, Access file, or comma-delimited ascii spreadsheet dump file.

AutoLISP

```
(c:wd_ss2_import_curdwg fname upcase options)
```

Parameters

upcase	"1" to force all updated data to upper case, "0" = as is.
options	1's bit set: force all changed tags and wire numbers to "Fixed". 2's bit set: suppress re-read of data (For example, first drawing of project-wic

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_upd_pnlval
[Section F - General Functions](#) [Send Feedback](#)

Description

Update ATTRIB or XDATA (1000) value from block "ben" XDATA in form "VIA_WD_attnam" (old="CIM_WD_attnam"). Look for ATTRIB first, if not found, look for XDATA
a "VIA_WD_" prefix, old="CIM_WD_" prefix.

AutoLISP

```
(c:wd_upd_pnlval ben attnam newval)
```

Parameters

Parameters	Description
ben	AutoCAD entity name of footprint block.
attnam	Attribute's name to query for its value (wildcards ok).
newval	New attrib value to insert.

Returns

No return value.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_wd2p_set_GBL_wd_pnlst
[Section F - General Functions](#) [Send Feedback](#)

Description

Project-wide extract of schematic components. Build list GBL_wd_pnlst that is referenced by the SCHEM-->PNL insertion pick list dialog box.

AutoLISP

```
(c:wd_wd2p_set_GBL_wd_pnlst)
```

Module

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_wd2p_set_GBL_wd_pnltrmlst
[Section F - General Functions](#) [Send Feedback](#)

Description

Build list GBL_wd_pnltrmlst that is referenced by the SCHEM TERM-->PNL insertion pick list dialog box.

AutoLISP

```
(c:wd_wd2p_set_GBL_wd_pnltrmlst)
```

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_wdsurf
[Example 1](#) [Example 2](#) [Section F - General Functions](#) [Send Feedback](#)

Description

Trigger AutoCAD Electrical Surfer search and surf dialog box.

AutoLISP

```
(c:wd_wdsurf type freshen str inst loc)
```

Parameters

Parameters	Description
type	nil or 0 for components, 1 for signals, 2 for terminals, 3 for plcio, 4 for wire ni for catalog number search
freshen	1 to check for database freshen required, nil = skip.
str	Text string to surf on (wild cards allowed). Can be tag-id, wire number, catalc signal code.
inst	Installation code (when IEC tagging mode is active).
loc	Location code (when IEC tagging mode is active).

Example 1

To surf on all schem/pnl references for CR104 :

```
(c:wd_wdsurf 0 1 "CR104" nil nil)
```

Example 2

To find and surf on all items that carry CAT part number beginning with "700" :

```
(c:wd_wdsurf 5 1 "700*" nil nil)
```

Module

[Section F - General Functions](#)

What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_xdata

[Section F - General Functions](#) [Send Feedback](#)

Description

API call - run a user script against each drawing to be processed.

AutoLISP

(c:wd_xdata)

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

wd_fio_does_pnlblock_exist

[Section F - General Functions](#) [Send Feedback](#)

Description

Search for panel footprint block using AcadE's search paths.

AutoLISP

(wd_fio_does_pnlblock_exist nam)

Parameters

Parameters	Description
nam	Name of block. Note: block name can be passed with one or more subfolder p "ab/pb- pushbuttons/abpb3r"). Paths are searched in the following order: 1st active drawing for block defined in the drawing itself. 2nd = actual name if full path provided. 3rd = in USER folder (pointed at by global GBL_wd_usr). 4th = in active project's folder (where the ".wdp" is located). 5th = in Schematic lib path(s) (pointed at by global GBL_wd_lib). 6th = in "c:documents and settings...support" folder. 7th = in folder pointed at by global GBL_wd_sup. 8th = AutoCAD search paths (this is inserted as the 3rd check if the wd.env fi WD_ACADPATHFIRST setting is enabled).

Returns

Full path name if found, nil otherwise.

Module

[Section F - General Functions](#)

Links

[Section F - General Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)