

AutoCAD Electrical 2025: AutoLISP Reference

Section G - Project Management

[Topics](#) [Send Feedback](#)

Description

Project / project database file.

Topics

Name	Description
ace_closeproject	Removes the specified project from project manager if it is not the last project. If the project is active, next available project, which may not be the same order as shown in the UI, will be activated before removing the project to be removed is the last project, remove will fail and return nil.
ace_getactiveproject	Get the active project's .wdp file name.
ace_relativetoabsolute	Resolve relative paths found for drawing file names in the ".wdp" project file into full paths.
c:ace_add_dwg_to_project	If the drawing is already listed in the project (regardless of path), it is removed from the list and then added in at the end of the list.
c:ace_language_list	Retrieve list of language name fields defined in language swap file.
c:ace_language_swap	Process active drawing only.
c:ace_proj_data	Read the Access database file and the project .wdp file of the specified project and return a list of lists of project's drawing data in the form outlined for the GBL_wd_prj_ixlst global variable.
c:ace_proj_dwg_remove	API call for Project Manager Enhanced Secondary Window (ESW) to open project dwg selection dialog box and then remove selected drawings from project.
c:ace_proj_new	Pops open dialog box for file name selection and creates a blank project file.
c:ace_proj_recent	Display dialog box listing recent projects. (carried in ...\\user\\lastproj.fil)
c:ace_update_WFRM2ALL	Rebuild WFRM2ALL / WNETLST tables to match current state of the project drawings.
c:wd_cpyprj_main	Copy project utility. At conclusion, the new copied project is the active project and the first drawing listed in the new project is opened.
c:wd_delprj_main	Delete project .wdp file and optionally all associated drawing files referenced in the .wdp file.
c:wd_get_recent_prj_list	Get list of recent project file names and descriptions from userlastproj.fil
c:wd_is_cur_dwg_in_proj	Determine if the active drawing is listed in the active project. If so, return which drawing it is in the sequence of listed project drawings (1=1st)
c:wd_make_newwp	Create new AutoCAD Electrical project (old version). Opens dialog box for file name selection, creates a blank project file, and makes it active.

c:wd_mdb_freshen_noask	Same as wd_mdb_freshen but suppresses any "OK to Freshen?" dialog box.
c:wd_mdb_get_proj_scratch_dbnam	Calculate name for project's scratch database file.
c:wd_mdb_rebuild	Force total rebuild of Access database file for specified project. Note: preferred method is to use ace_update_WFRM2ALL instead.
c:wd_mdb_update_wfrm2all_netlst_tabs	Rebuild from current state of the wire connection extraction table database WDATA.
c:wd_pdwqs	Pick from list and return list of picked drawing file names.
c:wd_proj_chkrepeat	Check whether the specified file name is in the specified file name list.
c:wd_proj_dnext	Automatically QSAVE active drawing if something in database has changed (unless the WD_PROMPT_SAVE setting is set in the wd.env environment file).
c:wd_proj_dprev	Automatically QSAVE active drawing if something in database has changed (unless the WD_PROMPT_SAVE setting is set in the wd.env environment file).
c:wd_proj_getdwgqnam	Get list of file names of drawings in project and count drawings in the project file.
c:wd_proj_wdp_data	Read active project's WDP file.
c:wd_proj_wdp_data_fname	Read project .wdp file.
c:wd_proj_wdp_write	Create WDP file from lists of list values.
c:wd_reset_proj_vars	Reset program's internal project global variables and lists.
c:wd_savproj_name	Save specified project file name in the standard LASTPROJ.FIL data file; then appears in the "Recent..." projects pick list dialog box.
wd_mdb_ix2wdp_ix	Map the project scratch database file's DWGIX field value back to the position of the drawing reference in the project drawing list.
wd_mdb_wdp2ix_ix	Get the project scratch database DWGIX field value identifier for the drawing in the specified position in the active project's drawing list.
wd_mdb2_upd_prj_ixlst	Set or update the value of variable GBL_wd_prj_ixlst, a list of lists of active project's drawing data.
wd_pds_get_open_dwgs	Get file name list of open drawings.

Links

[Topics](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

ace_closeproject

[Example](#) [Section G - Project Management](#) [Send Feedback](#)

project, remove will fail and return nil.

AutoLISP

```
(ace_closeproject wdpfilepath)
```

Parameters

Parameters	Description
wdpfilepath	Full path of project ".wdp" file.

Returns

If successful T is returned, otherwise nil

Example

Closes the project file named *123456.wpd*.

```
(ace_closeproject "n:\\projects\\123456.wdp")  
(ace_closeproject "n:/projects/123456.wdp")
```

Module

[Section G - Project Management](#)

Links

[Example](#), [Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
ace_getactiveproject
[Section G - Project Management](#) [Send Feedback](#)

Description

Get the active project's .wdp file name.

AutoLISP

```
(ace_getactiveproject)
```

Returns

The full file name of the active project's ".wdp" file.

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

ace_relativetoabsolute

[Example](#) [Section G - Project Management](#) [Send Feedback](#)

Description

Resolve relative paths found for drawing file names in the ".wdp" project file into full paths.

AutoLISP

```
(ace_relativetoabsolute dwg_relative_path full_proj_wdp_path)
```

Parameters

Parameters	Description
dwg_relative_path	drawing relative path (ex: "....0001.dwg")
full_proj_wdp_path	full path to project's ".wdp" file location

Returns

Calculated full path to the drawing

Example

```
(ace_relativetoabsolute "..\\..\\0001.dwg" (car (c:wd_split_fnam GBL_wd_prj)))
```

Module

[Section G - Project Management](#)

Links

[Example](#), [Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:ace_add_dwg_to_project

If the drawing is already listed in the project (regardless of path), it is first removed from the list and then added in at the the list.

AutoLISP

```
(c:ace_add_dwg_to_project dwg2add param_lst)
```

Parameters

Parameters	Description
dwg2add	File name of dwg to add, or nil = add CURRENT active drawing.
param_lst	(nth 0) = "Sec" section code. (nth 1) = "Subsec" code. (nth 2) = "Drawing description" or list of three descriptive words. (nth 3) = 1 to suppress project file freshen after drawing added to project. (nth 4) = subfolder to add the drawing, eg: "sub1/sub2/sub3", "sub1" or nil for root folder

Returns

1 = success, nil = failure.

Example 1

Add drawing to project with single line of drawing description text "MCC-01A", in subfolder sub1/sub2.

```
(c:ace_add_dwg_to_project "c:/customer01/mcc-01a.dwg" (list "" "" "MCC-01A" nil "sub1/sub2"))
```

Example 2

Add drawing marked with section "05" and three lines of description text, in project root folder.

```
(c:ace_add_dwg_to_project "c:/customer01/mcc-01a.dwg" (list "05" "" (list "MCC" "480V" "MAIN") nil nil))
```

Module

[Section G - Project Management](#)

Links

[Example 1](#), [Example 2](#), [Section G - Project Management](#)

Retrieve list of language name fields defined in language swap file.

AutoLISP

(c:ace_language_lst param_lst)

Parameters

Parameters	Description
param_lst	(list fnam) where "fnam" = language file to use, or nil = default file "wd_lang1.mdb".

Returns

nil if failure, or list of language column field names (to use in c:ace_language_swap function).

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:ace_language_swap
[Section G - Project Management](#) [Send Feedback](#)

Description

Process active drawing only.

AutoLISP

(c:ace_language_swap param_lst)

Parameters

Parameters	Description
param_lst	List of parameters: nth 0 = todo - 2=process all dwg, 3=prompt user pick, or can pass as list of entity names process nth 1 = from " the "From" language (exact match with name in language swap file) nth 2 = to - to "To" language

nth 6 = logfile nil=create default "trans.log"
nth 7 = gotofnam nil=create default "trans.go2"

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:ace_proj_data
[Section G - Project Management](#) [Send Feedback](#)

Description

Read the Access database file and the project .wdp file of the specified project and return a list of lists of project's drawing in the format outlined for the GBL_wd_prj_ixlst global variable.

AutoLISP

(c:ace_proj_data wdpfnam)

Parameters

Parameters	Description
wdpfnam	nil for current, active project. Otherwise pass the full path/filename of the project to query.

Remarks

The structure of GBL_wd_prj_ixlst is 16 parallel lists (pulled from the FILETIME table in the project's Access database tem and the project's ".wdp" file list):

(nth 0 GBL_wd_prj_ixlst) = DWGIX key field values

(nth 1 GBL_wd_prj_ixlst) = list of drawing file sequence in the drawing list portion of the project's ".wdp" file

(nth 2 GBL_wd_prj_ixlst) = list of full drawing name and paths

(nth 3 GBL_wd_prj_ixlst) = list of SHEET values (the %S value)

(nth 4 GBL_wd_prj_ixlst) = list of DWGNAM values (the %D value)

(nth 5 GBL_wd_prj_ixlst) = list of IEC Proj values (the %P value)

(nth 6 GBL_wd_prj_ixlst) = list of IEC Installation values (the %I value)

(nth 7 GBL_wd_prj_ixlst) = list of IEC Location values (the %L value)

- (nth 11 GBL_wd_prj_ixlst) = list of default panel "level/routing" assignments
- (nth 12 GBL_wd_prj_ixlst) = list of panel X-offset assignments for each drawing
- (nth 13 GBL_wd_prj_ixlst) = list of panel Y-offset assignments for each drawing
- (nth 14 GBL_wd_prj_ixlst) = list of panel Z-offset assignments for each drawing
- (nth 15 GBL_wd_prj_ixlst) = list of "Description 1" line assignments for each drawing
- (nth 16 GBL_wd_prj_ixlst) = list of "Description 2" line assignments for each drawing
- (nth 17 GBL_wd_prj_ixlst) = list of "Description 3" line assignments for each drawing

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:ace_proj_dwg_remove
[Section G - Project Management](#) [Send Feedback](#)

Description

API call for Project Manager Enhanced Secondary Window (ESW) to display project dwg selection dialog box and then remove selected dwgs from project.

AutoLISP

(c:ace_proj_dwg_remove options wdp_fname dwg_fname)

Parameters

Parameters	Description
options	1's bit set means update wdp file if dwg is removed, otherwise just return the new drawing list.
wdp_fname	Project wdp file nil, nil=default to active project (stored GBL_wd_prj).
dwg_fname	Drawing file name to find and remove from the project.

Returns

nil = failure (dwg not found, wdp file not found). Success = new dwg list returned.

Module

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:ace_proj_new
[Section G - Project Management](#) [Send Feedback](#)

Description

Pops open dialog box for file name selection and creates a blank project file.

AutoLISP

```
(c:ace_proj_new options)
```

Parameters

Parameters	Description
options	1 = make new project "active", nil = create but don't r active.

Returns

Project ".wdp" file name or nil if failure.

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:ace_proj_recent
[Example](#) [Section G - Project Management](#) [Send Feedback](#)

Description

Display dialog box listing recent projects.
(carried in ...\\user\\lastproj.fil)

AutoLISP

Returns

Picked project name (or nil = cancel).

Example

```
(if (setq fnam (c:ace_proj_recent)) (c:wd_makeproj_current fnam))
```

Module

[Section G - Project Management](#)

Links

[Example](#), [Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:ace_update_WFRM2ALL
[Section G - Project Management](#) [Send Feedback](#)

Description

Rebuild WFRM2ALL / WNETLST tables to match current state of the project drawings.

AutoLISP

```
(c:ace_update_WFRM2ALL options)
```

Parameters

Parameters	Description
options	nil or 0 to only rebuild these tables if out of date with a the drawings. 1 to force full rebuild of the project's scratch database f (including the WFRM2ALL and WNETLST tables).

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

c:wd_cpyprj_main

[Section G - Project Management](#) [Send Feedback](#)

Description

Copy project utility. At conclusion, the new copied project is the active one and the first drawing listed in the new project opened.

AutoLISP

(c:wd_cpyprj_main param_lst)

Parameters

Parameters	Description
param_lst	List of these elements. nth 0 = Proj ".wdp" to copy from (nil=current project). nth 1 = New proj ".wdp" to create (any existing will be overwritten!). Cannot be nil or empty string. nth 2 = dlst (list of dwgs in "copy from" proj to copy, nil=copy all). nth 3 = target "base" folder for copied dwgs. Cannot be empty string. nth 4 = optional "FIND" string for renaming dwg names insensitive). nth 5 = optional "REPLACE with" string for renaming dv copied project. nth 6 = optional list of flags for related files to copy, "0" "1" (see nth 7 below). nth 7 = list of file names for above flags. Order is as fol nth 8 = optional flag to skip opening of the first dwg frc copied project after the copy operation completes, (nil=continue, 1=skip). See Remarks for list of file names for above flags.

Remarks

Order of list of file name flags for 7th parameter:

Order	File names/extensions
0	.wdt
1	.wdl
2	.wdd
3	_cat.mdb
4	_footprint_lookup.mdb
5	wd_fam.dat
6	.wdw
7	.loc

11	.wdi
12	.wdf
13	schematic_lookup.mdb
14	.wda
15	.wdn
16	.aepx
17	symlistreport.dat (Added to 2024 release)

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_delprj_main
[Section G - Project Management](#) [Send Feedback](#)

Description

Delete project .wdp file and optionally all associated dwg files referenced in the .wdp file.

AutoLISP

```
(c:wd_delprj_main param_lst)
```

Parameters

Parameters	Description
param_lst	nil for user dialog box prompting OR list of these eleme driving by command line. (nth 0) = Proj ".wdp" to erase (Note: you cannot delet project while it is active). (nth 1) = options, 1's bit set = delete only ".wdp" file. clear = delete wdp file AND all the drawings referenced wdp file.

Module

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_get_recent_prj_lst

[Section G - Project Management](#) [Send Feedback](#)

Description

Get list of recent project file names and descriptions from userlastproj.fil.

AutoLISP

```
(c:wd_get_recent_prj_lst)
```

Returns

List (rtrn) :

(nth 0 rtrn) = list of project ".wdp" file names starting with most recent.

(nth 1 rtrn) = formatted list of names for display in selection dialog box (internal use).

(nth 2 rtrn) = internal use.

(nth 3 rtrn) = parallel list of the first four project description lines for each project in the first element (list (list line1 line2 line4)(list â€¦)).

(nth 4 rtrn) = list of Project Manager ESW status codes, "2"=active, "1"=open, "0"=not displayed.

(nth 5 rtrn) = ".wdp" name of the next "open" but not active project in the ESW list (nil=no more in list).

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_is_cur_dwg_in_proj

[Example 1](#) [Example 2](#) [Section G - Project Management](#) [Send Feedback](#)

Description

Determine if the active drawing is listed in the active project. If so, get which drawing it is in the sequence of listed project drawings (1=1st).

AutoLISP

Return value is an integer.

Example 1

Find SHEET number of next drawing past the currently displayed drawing. Find previous drawing's SHEET number as well (AutoISP). Note: these values can then be mapped to title block attributes. See example under the section "Invoking API from Title Block ".wdt" mapping file."

```
(defun c:nextsheet ( / ix sheet_lst x sheet)
  ; Return the WD_M block's SHEET attribute value of "next" dwg in project.
  ; This embedded in a global called GBL_wd_prj_ixlst.
  ; If global doesn't exist, make call to refresh it.

  (if (not GBL_wd_prj_ixlst)
    (setq GBL_wd_prj_ixlst (c:ace_proj_data nil)))
  ; GBL_wd_cip holds index of current drawing in
  ; the overall project drawing list.
  (setq ix GBL_wd_cip) ; index
  ; If index not defined for current drawing, then
  ; trigger a refresh of the global.
  (if (OR (not ix) (= ix 0))
    (setq ix (c:wd_is_cur_dwg_in_proj)))
  )
  (setq sheet "")
  (if (> ix 0)
    (progn ; current drawing is in the project,
      ; increment to next dwg in list
      (setq ix (1+ ix)) ; increment index
      ; Get list of SHEET numbers assigned to
      ; all dwgs in the project dwg set.
      (setq sheet_lst (nth 3 GBL_wd_prj_ixlst))
      ; Use index number to pull out the
      ; target drawing's SHEET value. This is
      ; done by first finding the index
      ; number is a list of index numbers
      ; (nth 1 GBL_wd_prj_ixlst), and then
      ; using the position in this list to
      ; pull SHEET number from a parallel list
      ; of sheet numbers in (nth 3 GBL_wd_prj_ixlst)
      (if (setq x (member ix (nth 1 GBL_wd_prj_ixlst)))
        ; found relative position of next
        ; dwg's data in parallel lists
        (setq sheet (nth (- (length (nth 1 GBL_wd_prj_ixlst)) (length x))
          (nth 3 GBL_wd_prj_ixlst)))
      )
    )
  )
  sheet ; return "" or next SHEET value
)
```

Example 2

Same as previous example, but find previous drawing.

```
(defun c:prevsheet ( / ix sheet_lst x sheet)
  ; Return the WD_M block's SHEET attribute value
  ; of "next" dwg in project. This embedded in a
  ; global called GBL_wd_prj_ixlst. If global
  ; doesn't exist, make call to refresh it.
  (if (not GBL_wd_prj_ixlst)
    (setq GBL_wd_prj_ixlst (c:ace_proj_data nil)))
  ; GBL_wd_cip holds index of current drawing in
  ; the overall project drawing list.
  (setq ix GBL_wd_cip) ; index
  ; If index not defined for current drawing, then
  ; trigger a refresh of the global.
  (if (OR (not ix) (= ix 0))
    (setq ix (c:wd_is_cur_dwg_in_proj)))
  )
  (setq ix (1- ix)) ; decrement index
  ; Get list of SHEET numbers assigned to
  ; all dwgs in the project dwg set.
  (setq sheet_lst (nth 3 GBL_wd_prj_ixlst))
  ; Use index number to pull out the
  ; target drawing's SHEET value. This is
  ; done by first finding the index
  ; number is a list of index numbers
  ; (nth 1 GBL_wd_prj_ixlst), and then
  ; using the position in this list to
  ; pull SHEET number from a parallel list
  ; of sheet numbers in (nth 3 GBL_wd_prj_ixlst)
  (if (setq x (member ix (nth 1 GBL_wd_prj_ixlst)))
    ; found relative position of next
    ; dwg's data in parallel lists
    (setq sheet (nth (- (length (nth 1 GBL_wd_prj_ixlst)) (length x))
      (nth 3 GBL_wd_prj_ixlst)))
  )
  sheet ; return "" or next SHEET value
)
```

```

; all dwgs in the project dwg set.
(setq sheet_lst (nth 3 GBL_wd_prj_ixlst))
; Use index number to pull out the
; target drawing's SHEET value. This is
; done by first finding the index
; number is a list of index numbers
; (nth 1 GBL_wd_prj_ixlst), and then
; using the position in this list to
; pull SHEET number from a parallel list
; of sheet numbers in (nth 3 GBL_wd_prj_ixlst)
(if (setq x (member ix (nth 1 GBL_wd_prj_ixlst)))
    ; found relative position of next
    ; dwg's data in parallel lists
    (setq sheet (nth (- (length (nth 1 GBL_wd_prj_ixlst))
                        (length x))
                     (nth 3 GBL_wd_prj_ixlst)))
    )
))
sheet ; return "" or previous SHEET value
)

```

Module

[Section G - Project Management](#)

Links

[Example 1](#), [Example 2](#), [Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_make_newp

[Section G - Project Management](#) [Send Feedback](#)

Description

Create new AutoCAD Electrical project (old version). Opens dialog box for file name selection, creates a blank project file, makes it active.

AutoLISP

```
(c:wd_make_newp)
```

Returns

Project ".wdp" file name or nil if failure.

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

c:wd_makeproj_current

[Example 1](#) [Example 2](#) [Section G - Project Management](#) [Send Feedback](#)

Description

Make specified project the active project.

AutoLISP

```
(c:wd_makeproj_current wdpfnam)
```

Parameters

Parameters	Description
wdpfnam	Full path of project ".wdp" file name. This project does have to be displayed in the list (i.e. does not have to be "open").

Returns

List of project's parameters (or nil = failure).

Example 1

```
(c:wd_makeproj_current "n:\projects\123456.wdp")
```

Example 2

```
(c:wd_makeproj_current "n:/projects/123456.wdp")
```

Module

[Section G - Project Management](#)

Links

[Example 1](#), [Example 2](#), [Section G - Project Management](#)

Description

(c:wd_mdb_freshen wdpfnam)

Parameters

Parameters	Description
wdpfnam	Project file name or nil to default to current project.

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_mdb_freshen_noask
[Section G - Project Management](#) [Send Feedback](#)

Description

Same as [wd_mdb_freshen](#) but suppresses any "OK to Freshen?" dialog box.

AutoLISP

(c:wd_mdb_freshen_noask wdpfnam)

Parameters

Parameters	Description
wdpfnam	Project file name or nil to default to current project.

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)

Description

Calculate name for project's scratch database file.

AutoLISP

```
(c:wd_mdb_get_proj_scratch_dbnam wdpfilenam)
```

Parameters

Parameters	Description
wdpfilenam	File name of the project's scratch database file. "nil"=current proj mdb file name

Example

This snippet of code shows return of the name of the current project's scratch database file, opening it, and doing a simpl on one of its tables.

```
(if (setq fnam (c:wd_mdb_get_proj_scratch_dbnam nil)) ; "nil"=get current proj mdb file name
  (progn
    (setq hdl (wd\_mdb\_GetHandle 1)) ; get next handle, MDB format
    (if hdl
      (progn
        (if (wd\_mdb\_Open hdl fnam) ; open current project's mdb file
          (progn
            ; Get list of all schematic "FIELD" devices, sort by TAGNAME field value
            (setq lst (wd\_mdb\_GetRecs hdl "COMP"
              "TAGNAME,PAR1_CHLD2,DESC1,DESC2" ; fields to return
              "LOC = 'OPSTA3'" ; query condition
              "TAGNAME,PAR1_CHLD2")) ; sort by TAGNAME first
            (foreach rec lst
              (princ "n")
              (princ (cdr (car rec))) ; TAGNAME field value
              (princ ",")
              (princ (cdr (cadr rec))) ; PAR1_CHLD2 field value
              (princ ",")
              (princ (cdr (nth 2 rec))) ; DESC1 field value
              (princ ",")
              (princ (cdr (nth 3 rec))) ; DESC2 field value
            )
          )
        )
      )
    )
  )
  (wd\_mdb\_Close hdl)
  (setq hdl nil)
)
```

Module

[Section G - Project Management](#)

Links

[Example](#), [Section G - Project Management](#)

Description

Force total rebuild of Access database file for specified project. Note: The preferred method is to use ace_update_WFRM2/ instead.

AutoLISP

```
(c:wd_mdb_rebuild dbfnam)
```

Parameters

Parameters	Description
dbfnam	nil to default to current project.

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_mdb_update_wfrm2all_netlst_tabs

[Section G - Project Management](#) [Send Feedback](#)

Description

Rebuild from current state of the wire connection extraction table data in table WDATA.

AutoLISP

```
(c:wd_mdb_update_wfrm2all_netlst_tabs options)
```

Parameters

Parameters	Description
options	nil (for future use)

Module

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_pdwgs
[Section G - Project Management](#) [Send Feedback](#)

Description

Pick from list and return list of picked drawing file names.

AutoLISP

(c:wd_pdwgs d_lst main_title title2 exclude_refonly)

Parameters

Parameters	Description
d_lst	(nth 6 (c:wd_proj_wdp_data))) or (nth 5 (c:wd_proj_wdp_data_fname wdpfname))
main_title	Description text for dialog box.
title2	Description text for dialog box.
exclude_refonly	1 to hide drawings that are marked "REF ONLY".

Returns

List (rtrn):
(nth 0 rtrn) = list of selected drawing file names.
(nth 1 rtrn) = list of index numbers

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_proj_chkrepeat
[Section G - Project Management](#) [Send Feedback](#)

AutoLISP

```
(c:wd_proj_chkrepeat fnam d_lst)
```

Parameters

Parameters	Description
fnam	Drawing name.
d_lst	List of drawings in format as returned by c:wd_proj_wdp_data, - (nth 6 rtn)

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_proj_dnext
[Section G - Project Management](#) [Send Feedback](#)

Description

Automatically QSAVE active drawing if something in database has changed (unless the WD_PROMPT_SAVE setting is set in wd.env environment file.

AutoLISP

```
(c:wd_proj_dnext)
```

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

Description

Automatically QSAVE active drawing if something in database has changed (unless the WD_PROMPT_SAVE setting is set in wd.env environment file.

AutoLISP

```
(c:wd_proj_dprev)
```

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_proj_getdwgnam
[Example](#) [Section G - Project Management](#) [Send Feedback](#)

Description

Get list of file names of drawings in project and count drawings in the project file.

AutoLISP

```
(c:wd_proj_getdwgnam wdpfnam index options)
```

Parameters

Parameters	Description
wdpfnam	Project wdp name, or nil = current.
index	0 for 1st dwg in project dwg list, 1=2nd dwg, 2=3rd and on.
options	0 to return file name and dwg cnt, 1 = execute script to the drawing (no return data).

Returns

File name of drawing in specified project.

Example

Module

[Section G - Project Management](#)

Links

[Example](#), [Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_proj_wdp_data

[Example](#) [Section G - Project Management](#) [Send Feedback](#)

Description

Read active project's WDP file.

AutoLISP

```
(c:wd_proj_wdp_data)
```

Returns

List of lists (rtrn):

(nth 0 rtrn) = wdp file name.

(nth 1 rtrn) = count of dwgs in file.

(nth 2 rtrn) = list of *[] TITLE lines (start at (nth 1)).

(nth 3 rtrn) = list of ?[] values.

(nth 4 rtrn) = list of +[] values.

(nth 5 rtrn) = list of drawing names (absolute paths).

(nth 6 rtrn) = list of dwg names (absolute paths) with sec/subsec data included.

(nth 7 rtrn) = list of drawing names (absolute paths) with "Ref only" removed.

(nth 8 rtrn) = internal use.

(nth 9 rtrn) = same as (nth 5 rtrn) but forced upper case.

(nth 10 rtrn) = sorted list of all the drawings in the project together with its subfolder data.

Example

This snippet of code uses the (nth 5) sublist of drawing file names to insert each drawing into an overall drawing in a mat format.

```
; PURPOSE: demo utility to build and extract "Master" drawing
;   containing a complete representation of all individual dwg
;   files in an AutoCAD Electrical project set.
(defun ace-proj-matrix-build ( startx starty dx dv max-x / x fnam xcnt nextx nexty
```



```

        (write-line fnam f)
        (write-line "(command \"_.EXPLODE\" (entlast))\" f)
        (write-line "(command \"_.PURGE\" \"BLOCKS\" \"*\" \"N\")\" f)
        (write-line "(command \"_.ZOOM\" \"_EXTENTS\")\" f)
        (write-line "(command \"_.QSAVE\")\" f)
    )
    (close f)
    (command \"_.QSAVE\")
    (command \"_.SCRIPT\" scr_fnam)
)
)
(princ)
)
; --
(defun c:ace_proj_matrix ( / startx starty dx dy max_x dcl_fnam dcl_id todo)

; Make sure AcadE is "awake"
(if(not wd_load) (if(setq x(findfile "wd_load.lsp")) (load x))) (wd_load)
; Defaults
(setq startx 0.0)
(setq starty 0.0)
(setq dx 30.0)
(setq dy 24.0)
(setq max_x 10)
(setq dcl_fnam (c:ace_find_file "ace_proj_matrix.dcl" 16))
(if dcl_fnam
    (progn
        (setq dcl_id (load_dialog dcl_fnam))
        (if (new_dialog "main_menu" dcl_id)
            (progn
                (set_tile "startx" (rtos startx 2 4))
                (set_tile "starty" (rtos starty 2 4))
                (set_tile "dx" (rtos dx 2 4))
                (set_tile "dy" (rtos dy 2 4))
                (set_tile "max_x" (itoa max_x))
                (action_tile "startx" "(setq startx (atof $value))(set_tile \"startx\" (rtos startx 2 4))")
                (action_tile "starty" "(setq starty (atof $value))(set_tile \"starty\" (rtos starty 2 4))")
                (action_tile "dx" "(setq dx (atof $value))(set_tile \"dx\" (rtos dx 2 4))")
                (action_tile "dy" "(setq dy (atof $value))(set_tile \"dy\" (rtos dy 2 4))")
                (action_tile "max_x" "(setq max_x (atoi $value))(set_tile \"max_x\" (itoa max_x))")
                (action_tile "extract" "(setq todo 1) (done_dialog)")
                (action_tile "combine" "(setq todo 2) (done_dialog)")
                (start_dialog)
                (unload_dialog dcl_id)
                (if (= todo 1) (proj_matrix_extract))
                (if (= todo 2) (ace_proj_matrix_build startx starty dx dy max_x))
            )))
    )
    (princ)
)

DCL file referenced in the lsp code above
// ----- A C E _ P R O J _ M A T R I X . D C L -----
// PURPOSE: demo utility to build and extract "Master" drawing
// containing a complete representation of all individual dwg
// files in an AutoCAD Electrical project set.
main_menu : dialog
{
    label = "Test";
    :row
    {
        :column
        {
            label="Archive project into single dwg";
            :paragraph
            {
                :text_part{label="1. Start with a blank drawing";}
                :text_part{label="(it cannot be an unnamed dwg!)";}
                :text_part{label="2. Set values and hit \"Archive\"";}
                :text_part{label="3. Select Toolbox/WD project set";}
                :text_part{label="to combine into this current dwg.";}
            }
            :edit_box{label="X coordinate start";key="startx";width=10;fixed_width=false;}
            :edit_box{label="Y coordinate start";key="starty";width=10;fixed_width=false;}
        }
    }
}

```

```

        {
          :text_part{label="Start with";}
          :text_part{label="a blank dwg";}
        }
      :spacer{height=0;}
    }
  :column
  {
    label="Extract drws from single";
    alignment = bottom;
    fixed_height=false;
    :paragraph
    {
      :text_part{label="1. Call up combined dwg";}
      :text_part{label="2. Hit \"Extract\"";}
      :text_part{label="3. Make sure script file runs";}
      :text_part{label="(ace_proj_matrix_fname.scr) that explodes";}
      :text_part{label="and urges the resulting drawings.";}
    }
  :column
  {
    fixed_height=true;
    :row
    {
      :button{label="Extract";key="extract";fixed_width=true;fixed_width=true;}
      :paragraph
      {
        :text_part{label="Combined dwg";}
        :text_part{label="on screen";}
      }
    }
    :spacer{height=0;}
  }
}
cancel_button;
}

```

Module

[Section G - Project Management](#)

Links

[Example](#), [Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_proj_wdp_data_fnam

[Section G - Project Management](#) [Send Feedback](#)

Description

Read project .wdp file.

AutoLISP

```
(c:wd_proj_wdp_data_fnam wdpfnam)
```

wdpfnam	.wdp file name to read.
---------	-------------------------

Returns

- List of lists (rtrn):
- (nth 0 rtrn) = count of dwgs in file.
 - (nth 1 rtrn) = list of *[] TITLE lines (start at (nth 1)).
 - (nth 2 rtrn) = list of ?[] values.
 - (nth 3 rtrn) = list of +[] values.
 - (nth 4 rtrn) = list of drawing names (absolute paths).
 - (nth 5 rtrn) = list of dwg names (absolute paths) with sec/subsec data included.
 - (nth 6 rtrn) = list of drawing names (absolute paths) with "Ref only" removed.
 - (nth 7 rtrn) = internal use.
 - (nth 8 rtrn) = same as (nth 4 rtrn) but forced upper case.

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_proj_wdp_write
[Example](#) [Section G - Project Management](#) [Send Feedback](#)

Description

Create WDP file from lists of list values.

AutoLISP

(c:wd_proj_wdp_write wdpfnam t_lst a_lst p_lst d2_lst)
--

Parameters

Parameters	Description
wdpfnam	Name of .wdp file to create.
t_lst	List of title lines for *[] entries.

d2_lst

List of dwg name with sec/subsec data included.

Example

```
(setq wdp_data_lst (c:wd_proj_wdp_data)) ; get current project's settings
(setq t_lst (nth 2 wdp_data_lst))
(setq a_lst (nth 3 wdp_data_lst))
(setq p_lst (nth 4 wdp_data_lst))
(setq d2_lst (nth 6 wdp_data_lst))
(setq wdpfname "C:\\download\\newproject.wdp")
(c:wd_proj_wdp_write wdpfname t_lst a_lst p_lst d2_lst)
```

Module

[Section G - Project Management](#)

Links

[Example](#), [Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_reset_proj_vars

[Section G - Project Management](#) [Send Feedback](#)

Description

Reset program's internal project global variables and lists.

AutoLISP

```
(c:wd_reset_proj_vars)
```

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_savproj_nam

[Section G - Project Management](#) [Send Feedback](#)

AutoLISP

```
(c:wd_savproj_nam wdpfnam)
```

Parameters

Parameters	Description
wdpfnam	project .WDP file name.

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

wd_mdb_ix2wdp_ix

[Section G - Project Management](#) [Send Feedback](#)

Description

Map the project scratch database file's DWGIX field value back to the position of the drawing reference in the project draw

AutoLISP

```
(wd_mdb_ix2wdp_ix dwgix)
```

Parameters

Parameters	Description
dwgix	Project scratch database file's DWGIX field value.

Returns

0 if not found, >0 = position in project drawing list.

Module

[Section G - Project Management](#)

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

wd_mdb_wdp2ix_ix

[Example 1](#) [Example 2](#) [Section G - Project Management](#) [Send Feedback](#)

Description

Get the project scratch database DWGIX field value identifier for the drawing in the specified position in the active project drawing list.

AutoLISP

```
(wd_mdb_wdp2ix_ix position)
```

Parameters

Parameters	Description
position	Integer number, beginning with 1 for 1st drawing in the project list.

Returns

The project scratch database DWGIX field value identifier.

Example 1

Get all wire numbers carried in the database for the 5th drawing in the project.

```
(setq fnam (c:wd_mdb_get_proj_scratch_dbnam nil)) ; nil=active project
(if (setq dwgix (wd_mdb_wdp2ix_ix 5))
  (setq wnums (wd_oledb_select fnam (strcat
    "SELECT DISTINCT WIRENO FROM [WNUM]"
    " WHERE DWGIX = '" dwgix "'" AND WIRENO <> '"
    " ORDER BY WIRENO"))))
```

Example 2

Get all cable marker records in database found on active drawing. Note: the active drawing's position in the project is carried in global variable GBL_wd_cip.

```
(setq fnam (c:wd_mdb_get_proj_scratch_dbnam nil)) ; nil=active project
(c:wd_1) ; make sure globals for active dwg are initialized
(if (AND GBL_wd_cip (> GBL_wd_cip 0))
  (setq wnums (wd_oledb_select fnam (strcat
    "SELECT * FROM [COMP]"
    " WHERE DWGIX = '" (itoa GBL_wd_cip) "'" AND CATEGORY = 'C'"
    " ORDER BY TAGNAME"))))
```

Module

[Example 1](#), [Example 2](#), [Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

wd_mdb2_upd_prj_ixlst

[Section G - Project Management](#) [Send Feedback](#)

Description

Set or update the value of variable GBL_wd_prj_ixlst, a list of lists of the active project's drawing data.

AutoLISP

```
(wd_mdb2_upd_prj_ixlst)
```

Remarks

The structure of GBL_wd_prj_ixlst is 16 parallel lists (pulled from the FILETIME table in the project's Access database tem and the project's ".wdp" file list):

(nth 0 GBL_wd_prj_ixlst) = DWGIX key field values

(nth 1 GBL_wd_prj_ixlst) = list of drawing file sequence in the drawing list portion of the project's ".wdp" file

(nth 2 GBL_wd_prj_ixlst) = list of full drawing name and paths

(nth 3 GBL_wd_prj_ixlst) = list of SHEET values (the %S value)

(nth 4 GBL_wd_prj_ixlst) = list of DWGNAM values (the %D value)

(nth 5 GBL_wd_prj_ixlst) = list of IEC Proj values (the %P value)

(nth 6 GBL_wd_prj_ixlst) = list of IEC Installation values (the %I value)

(nth 7 GBL_wd_prj_ixlst) = list of IEC Location values (the %L value)

(nth 8 GBL_wd_prj_ixlst) = list of inter-dwg cross-ref format strings

(nth 9 GBL_wd_prj_ixlst) = list of "Section" assignments (the %A value)

(nth 10 GBL_wd_prj_ixlst) = list of "Sub-section" assignments (the %B value)

(nth 11 GBL_wd_prj_ixlst) = list of default panel "level/routing" assignments

(nth 12 GBL_wd_prj_ixlst) = list of panel X-offset assignments for each drawing

(nth 13 GBL_wd_prj_ixlst) = list of panel Y-offset assignments for each drawing

(nth 14 GBL_wd_prj_ixlst) = list of panel Z-offset assignments for each drawing

(nth 15 GBL_wd_prj_ixlst) = list of "Description 1" line assignments for each drawing

(nth 16 GBL_wd_prj_ixlst) = list of "Description 2" line assignments for each drawing

(nth 17 GBL_wd_prj_ixlst) = list of "Description 3" line assignments for each drawing

Module

[Section G - Project Management](#)

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

wd_pds_get_open_dwgs

[Section G - Project Management](#) [Send Feedback](#)

Description

Get file name list of open drawings.

AutoLISP

```
(wd_pds_get_open_dwgs)
```

Returns

File name list of open drawings with the first one in the list being the active drawing.

Module

[Section G - Project Management](#)

Links

[Section G - Project Management](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)