

Section J - User Table

[Topics](#) [Send Feedback](#)

Description

User table tools.

Remarks

AutoCAD Electrical supports a user table in the project database. You can add your own application data to any AutoCAD Electrical block insert (components, footprints, wire numbers, terminals, wire jump arrows) and AutoCAD Electrical can extract and maintain a copy of this information in a USER table in the project database.

This allows you to do "queries" on the project database file (in Microsoft Access format) and access all of this user information carried on all entities project-wide. This data is stored on the entities as invisible "extended entity data". You are free to use this data in any way you see fit.

Examples include storing explicit wire sequencing information, cable or wire lengths, routing information, storing spare parts information, descriptions, or MRP data, storing engineering notes, setup, or maintenance information, and so on.

Each application data record that you add to an entity can be up to 255 char long. A single AutoCAD Electrical entity can carry several hundred of these "records". Each record is tracked on the entity by entity handle plus a three digit record number beginning at "000". This same information is automatically maintained, project-wide, by AutoCAD Electrical in a new "USER" table of the project's database file.

Topics

Name	Description
c:wd_user_del	Delete user record number from an entity.
c:wd_user_delall	Delete all existing user records from an entity.
c:wd_user_get	Get user record data from an entity.
c:wd_user_getall	Get all user record data from an entity.
c:wd_user_getnext	Get next user record from an entity.
c:wd_user_put	If the given recnum already exists, overwrite the old value with the newvalue.
c:wd_user_putnext	Put user record data on to an entity using the next unused record number.

Links

[Topics](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

Delete user record number from an entity.

AutoLISP

(c:wd_user_del ben recnum)

Parameters

Parameters	Description
ben	Entity name or entity handle number.
recnum	Record number (integer or three-digit text string val ex: "005").

Returns

1 = success, nil = not found.

Module

[Section J - User Table](#)

Links

[Section J - User Table](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_user_delall
[Section J - User Table](#) [Send Feedback](#)

Description

Delete all existing user records from an entity.

AutoLISP

(c:wd_user_delall ben)

Parameters

Parameters	Description
------------	-------------

Count (integer)of number of records deleted, nil = none found.

Module

[Section J - User Table](#)

Links

[Section J - User Table](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_user_get

[Section J - User Table](#) [Send Feedback](#)

Description

Get user record data from an entity.

AutoLISP

(c:wd_user_get ben recnum)

Parameters

Parameters	Description
ben	Entity name or entity handle number.
recnum	Record number (integer or three-digit text string val ex: "005").

Returns

Text value returned (255 char max) or nil if record not present on the target entity.

Module

[Section J - User Table](#)

Links

[Section J - User Table](#)

Description

Get all user record data from an entity.

AutoLISP

```
(c:wd_user_getall ben dataonly)
```

Parameters

Parameters	Description
ben	Entity name or entity handle number.
dataonly	1 to return a list of the data, nil = return data in the form of a list of lists where each sublist is a list of the record number and datavalue (for example, (list ("001" "Rec value one" "002" "Rec value two")...))

Returns

Data list (or list of lists), nil = no data found.

Module

[Section J - User Table](#)

Links

[Section J - User Table](#)

Description

Get next user record from an entity.

AutoLISP

```
(c:wd_user_getnext ben start)
```

ben	Entity name or entity handle number.
start	Starting record number (integer or 3-char string). V: "000" or 0 or nil means start at the first or only reco the entity.

Returns

Text value returned or nil if no more records found on entity.

Module

[Section J - User Table](#)

Links

[Section J - User Table](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_user_put
[Section J - User Table](#) [Send Feedback](#)

Description

If the given recnum already exists, overwrite the old value with the newvalue.

AutoLISP

(c:wd_user_put ben recnum newval)

Parameters

Parameters	Description
ben	Entity name or entity handle number.
recnum	Record number (integer or three-digit text string val ex: "005").
newval	Text string data (255 char max) to insert on to the e

Returns

1 = success, nil = failure.

Links

[Section J - User Table](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_user_putnext
[Section J - User Table](#) [Send Feedback](#)

Description

Put user record data on to an entity using the next unused rec number.

AutoLISP

```
(c:wd_user_putnext ben start newval)
```

Parameters

Parameters	Description
ben	Entity name or entity handle number.
start	Starting record number (integer or 3-char string). V: "000" or 0 or nil means start at the first or only reco the entity.
newval	Text string data (255 char max) to insert on to the e

Returns

Returns 3-char recnum code used, nil = failure.

Module

[Section J - User Table](#)

Links

[Section J - User Table](#)