

AutoCAD Electrical 2025: AutoLISP Reference

Section M - Project Database Service

[Modules](#) [Send Feedback](#)

Description

The Project Database Service can be accessed through ObjectARX or Visual [LISP](#). ObjectARX applications, should use the ObjectARX Linking instructions given below and avoid using the Lisp The [ObjectDBX](#) functions are written to be called from [LISP](#), but there are some classes that are exposed to ObjectARX. To use these classes you need to link to the AcePmDefun.lib and use t AcePmDefun.arx.

The [OLEDB](#) classes are written to provide a cached database connection enviroenment that can be used by any of the ACE applications. All new development should use these classes and not t modules (which will be deprecated). To use these classes you must link with the AcePmOleDb.lib and use the AcePmOleDb.dll.

Notes

Linking

To use the the Project Database Service client you need to:

1. Include the header file: "v:\acadet\aceperformance\acepmclientapp\acepmclientapi.h"
2. Link to the library file: \$(OutDir)\acepmclientapp.lib
3. Load your ARX after AcePmClientApp.arx is loaded. This is typically done in the ACADE.rx file.

The content of acepmclientapi.h is as follows:

```
extern "C"
{
    __declspec(dllimport) const TCHAR* PmGetApiName();
    __declspec(dllimport) bool PmOpenProject(const TCHAR* project, const TCHAR* mdbfile, const TCHAR* usr, const TCHAR* pwd, const TCHAR* inifile=NULL);
    __declspec(dllimport) bool PmOpenProjectDb(const TCHAR* project, const TCHAR* provider, const TCHAR* inifile=NULL);
    __declspec(dllimport) void PmCloseProject(const TCHAR* project);
    __declspec(dllimport) void PmSetActive(const TCHAR* project);
    __declspec(dllimport) bool PmGetActive(TCHAR* project, size_t bufsize);
    __declspec(dllimport) bool PmMonitorFile(const TCHAR* project, const TCHAR* filename, bool monitor);
    __declspec(dllimport) bool PmMonitorFiles(const TCHAR* project, CPtrList& files, bool monitor);
    __declspec(dllimport) bool PmLockFile(const TCHAR* filename);
    __declspec(dllimport) bool PmUnlockFile(const TCHAR* filename);
    __declspec(dllimport) bool PmLockFiles(CPtrList& files);
    __declspec(dllimport) bool PmUnlockFiles(CPtrList& files);
    __declspec(dllimport) void PmRenameStarted(const TCHAR* project, const TCHAR* filename);
    __declspec(dllimport) void PmRenameCompleted(const TCHAR* project, const TCHAR* oldname, const TCHAR* newname);
    __declspec(dllimport) bool PmIsHelperProcess(void);
    __declspec(dllimport) DWORD PmGetHelperProcessID(void);
    __declspec(dllimport) void PmUseHelperProcess(short flag);
    __declspec(dllimport) void PmProjectLoaded(const TCHAR* project);
    __declspec(dllimport) bool PmGetProjectDb(const TCHAR* project, TCHAR* db, size_t bufsize, bool initString);
    __declspec(dllimport) bool PmSetProjectVar(const TCHAR* project, TCHAR* var, VARIANT value);
    __declspec(dllimport) void PmFlushActive(void);
    __declspec(dllimport) bool PmCmdActive(void);
    __declspec(dllimport) bool PmFilesLockEd(void);
    __declspec(dllimport) void PmSetFromTo(short flag);
    __declspec(dllimport) bool PmGetFromTo(void);
    __declspec(dllimport) bool PmGetFromToAllReqd(const TCHAR* project, long& count);
    __declspec(dllimport) bool PmGetFromToAllInfo(const TCHAR* project, CPtrList& files, CPtrList& dwgix);
    __declspec(dllimport) void PmSetFromToAllDone(const TCHAR* project, bool flag);
}
```

Modules

| Name                          | Description                                                                                                                                                                                                                                                                                                                                                                                                             |
|-------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">ARX Functions</a> |                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <a href="#">ObjectDBX</a>     | The ObjectDBX classes are in the AcePmDefun.lib and AcePmDefun.arx.                                                                                                                                                                                                                                                                                                                                                     |
| <a href="#">LISP</a>          |                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <a href="#">OLEDB</a>         | The AcePmOleDb project can be used to do database operations using OleDb using ATL. The AcePmOleDb library maintains a <a href="#">cache</a> of recent connections to optimize the time taken to make a connection to t database. It is highly recommended that you use this cache to get and release connections. The following sample illus use of the AceOleDbFileRecordset class that implicitly manages the cache. |

```
//
// Simple query example to show the use of the AceOleDbFileRecordset
// and its implicit cache management.
//
bool query(const TCHAR* mdbfile, const TCHAR* sql)
{
    bool ok = false;
    // create a new record set and have it use the AceOleDbConnectionCache
    // for an MDB (Access) database file
    AceOleDbFileRecordset rs(AceOleDbFileRecordset::kConnFromCache, AceOleDbFileRecordset::kI
    // open up the MDB file
    if (rs.Open(mdbfile))
    {
        // set the SQL statement
        rs.SetCommandText(sql);
        // execute the query
        if (rs.Execute() == AceOleDbCommand::kTrue)
        {
            // save the column count - rather than compute it in a for loop
            DBORDINAL cols = rs.GetColumnCount();
            // loop through all returned records
            while (rs.FetchNext() == AceOleDbCommand::kTrue)
            {
                // scan through all columns
                // NOTE: Column counts start at 1 not 0 and go to GetColumnCount()
                for (DBORDINAL i = 1; i <= cols; ++i)
                {
                    // if not null and not a blob, then print it out
                    if (rs.IsNull(i) == AceOleDbCommand::kFalse &&
                        rs.IsBlob(i) == AceOleDbCommand::kFalse)
                        acutPrintf("%s = %s\n", rs.GetColumnName(i), rs.FieldAsStringEx(i));
                }
            }
            ok = true;
        }
        // close the recordset
        rs.Close();
    }
    // when class goes out of scope it will cache the connection
    return ok;
}

To use the AcePmOleDb classes link to the AcePmOleDb.lib and include the relevant header files from the following cl
AceOleDbConnectionCache
AceOleDbConnection
AceOleDbCommand
```

[Appendix](#)

Links

[Modules](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

ARX Functions

[Section M - Project Database Service](#) [Topics](#) [Send Feedback](#)

Module

[Section M - Project Database Service](#)

Topics

| Name                               | Description |
|------------------------------------|-------------|
| <a href="#">PmCloseProject</a>     |             |
| <a href="#">PmCmdActive</a>        |             |
| <a href="#">PmFilesLocked</a>      |             |
| <a href="#">PmFlushActive</a>      |             |
| <a href="#">PmGetActive</a>        |             |
| <a href="#">PmGetApiName</a>       |             |
| <a href="#">PmGetFromTo</a>        |             |
| <a href="#">PmGetFromToAllInfo</a> |             |
| <a href="#">PmGetFromToAllReqd</a> |             |

|                                    |  |
|------------------------------------|--|
| <a href="#">PmLockFiles</a>        |  |
| <a href="#">PmMonitorFile</a>      |  |
| <a href="#">PmMonitorFiles</a>     |  |
| <a href="#">PmOpenProject</a>      |  |
| <a href="#">PmOpenProjectDb</a>    |  |
| <a href="#">PmProjectLoaded</a>    |  |
| <a href="#">PmRenameCompleted</a>  |  |
| <a href="#">PmRenameStarted</a>    |  |
| <a href="#">PmSetActive</a>        |  |
| <a href="#">PmSetFromTo</a>        |  |
| <a href="#">PmSetFromToAllDone</a> |  |
| <a href="#">PmSetProjectVar</a>    |  |
| <a href="#">PmUnlockFile</a>       |  |
| <a href="#">PmUnlockFiles</a>      |  |
| <a href="#">PmUseHelperProcess</a> |  |

Links

[Section M - Project Database Service, Topics](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmCloseProject

[ARX Functions](#) [Send Feedback](#)

Description

PmCloseProject

void PmCloseProject(const TCHAR\* project)

| Parameters |                                                                                                           |
|------------|-----------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |

This function removes interest in the named project. If no other clients are monitoring this project, it will be removed from memory.

Module

[ARX Functions](#)

Links

[ARX Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmCmdActive

[ARX Functions](#) [See Also](#) [Send Feedback](#)

Description

PmCmdActive

bool PmCmdActive(void)

This function tests to see if PDS is currently running a command that would require the use of the AutoCAD command processor such as [ACE\\_SCRIPT](#).

See Also

[WD\\_PDS\\_CMDACTIVE](#)

Module

[ARX Functions](#)

Links

[ARX Functions](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmFilesLocked

[ARX Functions](#) [Send Feedback](#)

Description

PmFilesLocked

bool PmFilesLocked(void)

Return Value

true if the there are locked files.

This function tests to see if the server currently has any files locked.

Module

[ARX Functions](#)

Links

[ARX Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmFlushActive

[ARX Functions](#) [Send Feedback](#)

Description

PmFlushActive

void PmFlushActive(void)

This function is used to cause the client to flush any changes to the current drawing to the scratch database, even if the drawing has not been saved.

Module

[ARX Functions](#)

Links

[ARX Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmGetActive

[ARX Functions](#) [See Also](#) [Send Feedback](#)

| Parameters |                                                             |
|------------|-------------------------------------------------------------|
| project    | An output buffer to receive the name of the active project. |
| bufsize    | The size of the project buffer.                             |

| Return Value                                                                |  |
|-----------------------------------------------------------------------------|--|
| true - the PDS was able to determine that the client has an active project. |  |

This function retrieves the name of the project that the PDS currently believes is active in both the visible and hidden instances of AutoCAD Electrical.

See Also

[PmSetActive](#) and [PmGetProjectDb](#)

Module

[ARX Functions](#)

Links

[ARX Functions](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback](#)  
AutoCAD Electrical 2025: AutoLISP Reference

**PmGetApiName**  
[Example](#) [ARX Functions](#) [Send Feedback](#)

Description

**PmGetApiName**

const TCHAR\* PmGetApiName()  
Get a const TCHAR string that identifies the registered service name of AcePmClientApp. This can be used in registering or unregistering a dependency upon the AcePmClientApp.

Example

```
extern "C" AcRx::AppRetCode
acrEntryPoint(AcRx::AppMsgCode msg, void* appId)
{
    AcRxService* client = 0;
    switch (msg) {
    case AcRx::kInitAppMsg:
        acrxDynamicLinker->unlockApplication(appId);
        acrxDynamicLinker->registerAppMDIAware(appId);
        // register our dependency on the pm client
        client = AcRxService::cast(acrxServiceDictionary->at(PmGetApiName()));
        if (client)
            client->addDependency();
        break;
    case AcRx::kUnloadAppMsg:
        // remove our dependency on the pm client
        client = AcRxService::cast(acrxServiceDictionary->at(PmGetApiName()));
        if (client)
            client->removeDependency();
```

Module

[ARX Functions](#)

Links

[Example](#), [ARX Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

**PmGetFromTo**  
[ARX Functions](#) [See Also](#) [Send Feedback](#)

Description

**PmGetFromTo**

bool PmGetFromTo(void)

|                                                                                                                               |
|-------------------------------------------------------------------------------------------------------------------------------|
| Return Value                                                                                                                  |
| true if the current mode is to use the <a href="#">ObjectDBX</a> wire extraction implementation. false if Lisp is to be used. |

This function is used to query the toggle between using the [ObjectDBX](#) version of the wire information extraction and the Lisp based scripting process.

See Also

[PmSetFromTo](#) and [WD\\_PDS\\_GET\\_FROMTO](#)

Module

[ARX Functions](#)

Links

[ARX Functions](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

**PmGetFromToAllInfo**  
[ARX Functions](#) [Send Feedback](#)

Description

**PmGetFromToAllInfo**

bool PmGetFromToAllInfo(const TCHAR\* project, CPtrList& files, CPtrList& dwgix);

|            |                                                                                                           |
|------------|-----------------------------------------------------------------------------------------------------------|
| Parameters |                                                                                                           |
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |
| files      | This parameter receives the list of files that are out of date.                                           |
| dwgix      | This parameter receives the list of file IDs that are out of date.                                        |

|                                                      |
|------------------------------------------------------|
| Return Value                                         |
| True if the project is found and the query succeeds. |

Links

[ARX Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmGetFromToAllReqd

[ARX Functions](#) [See Also](#) [Send Feedback](#)

Description

PmGetFromToAllReqd

bool PmGetFromToAllReqd(const TCHAR\* project, long& count)

| Parameters |                                                                                                           |
|------------|-----------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |
| count      | This parameter receives the count of files that are out of date.                                          |

| Return Value                                         |  |
|------------------------------------------------------|--|
| True if the project is found and the query succeeds. |  |

Call this function to determine the number of drawings that are out of date in the WFRM2ALL table.

See Also

[PmSetFromToAllDone](#) and [WD\\_PDS\\_WFRM2ALL\\_REBUILD\\_REOD](#)

Module

[ARX Functions](#)

Links

[ARX Functions](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmGetHelperProcessID

[ARX Functions](#) [Send Feedback](#)

Description

PmGetHelperProcessID

DWORD PmGetHelperProcessID(void)

| Return Value |                                                                                                                                                                                                        |
|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0            | This process is a helper process.                                                                                                                                                                      |
| ~0           | An error has ocured.                                                                                                                                                                                   |
| >0 <~0       | If this instance of AutoCAD has a helper instance it will be the process ID of that process.<br>If this instance of AutoCAD does not have a helper instance of AutoCAD, it returns its own process ID. |

Links

[ARX Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmGetProjectDb

[ARX Functions](#) [See Also](#) [Send Feedback](#)

Description

PmGetProjectDb

bool PmGetProjectDb(const TCHAR\* project, TCHAR\* db, size\_t bufsize, bool initString)

| Parameters   |                                                                                                                                                                             |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| project      | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID.                                                                   |
| db           | An output buffer to receive the name of the database                                                                                                                        |
| bufsize      | The size of the output buffer.                                                                                                                                              |
| initString   | If true, get the initialization string used to open the <a href="#">OleDB</a> connection, otherwise just get the database name (a file name and path in the case of Microso |
| Return Value |                                                                                                                                                                             |
| true         | - the project was found and the information extracted.                                                                                                                      |

See Also

[PmGetActive](#), [PmOpenProject](#) and [PmOpenProjectDb](#)

Module

[ARX Functions](#)

Links

[ARX Functions](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmIsHelperProcess

[ARX Functions](#) [Send Feedback](#)

Description

PmIsHelperProcess

bool PmIsHelperProcess(void)

| Return Value |                                                                                       |
|--------------|---------------------------------------------------------------------------------------|
| true         | The current AutoCAD process is a helper to some other instance of AutoCAD Electrical. |

This function is used to determine if the current process is in fact a "hidden acad.exe" being used as a helper to another AutoCAD instance.



[ARX Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmLockFile

[ARX Functions](#) [Send Feedback](#)

Description

PmLockFile

bool PmLockFile(const TCHAR\* filename)

| Parameters |                                                      |
|------------|------------------------------------------------------|
| filename   | The full path and filename of the file to be locked. |

| Return Value |                      |
|--------------|----------------------|
| true         | The file was locked. |

This function attempts to gain a write lock on the named file.

Module

[ARX Functions](#)

Links

[ARX Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmLockFiles

[Example](#) [ARX Functions](#) [Send Feedback](#)

Description

PmLockFiles

bool PmLockFiles(CPtrList& files)

| Parameters |                                                                              |
|------------|------------------------------------------------------------------------------|
| files      | A const TCHAR* list of the full path and filename of the files to be locked. |

| Return Value |                                                                                                                                                                                                        |
|--------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| true         | The files were locked.                                                                                                                                                                                 |
| false        | The files were not locked. In this case the files list will contain a list of files that could not be locked. The calling function is responsible for freeing the memory allocated to the return list. |

This function attempts to gain a write lock on the named files.

```
extern CPtrList files;

if (!PmLockFiles(files))
{
    POSITION pos = files.GetHeadPosition();
    while (pos != NULL)
    {
        TCHAR* filename = (TCHAR *)files.GetNext(pos);
        MyErrorHandler(filename); // handle error
        delete filename;
    }
}
```

Module

[ARX Functions](#)

Links

[Example](#), [ARX Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmMonitorFile

[ARX Functions](#) [See Also](#) [Send Feedback](#)

Description

PmMonitorFile

bool PmMonitorFile(const TCHAR\* project, const TCHAR\* filename, bool monitor)

| Parameters |                                                                                                           |
|------------|-----------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |
| filename   | The name of the DWG file to monitor.                                                                      |
| monitor    | If true, start monitoring the file, if false, stop monitoring the file.                                   |

| Return Value                                                                                                |  |
|-------------------------------------------------------------------------------------------------------------|--|
| true - the project was able to locate the file and add or remove it from the list of files being monitored. |  |

Notes

Because of the overhead of COM marshalling and thread locking, do not use this function in a loop to process multiple files. If you need to add or remove more than one file, use [PmMonitorFi](#)

See Also

PmMonitorFiles and [PmProjectLoaded](#)

Module

[ARX Functions](#)

Links

Description

PmMonitorFiles

bool PmMonitorFiles(const TCHAR\* project, CPtrList& files, bool monitor)

| Parameters |                                                                                                           |
|------------|-----------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |
| files      | A list of const TCHAR* pointers to filenames.                                                             |
| monitor    | If true, start monitoring the files, if false, stop monitoring the files.                                 |

| Return Value                                                                                                   |  |
|----------------------------------------------------------------------------------------------------------------|--|
| true - the project was able to locate the files and add or remove them from the list of files being monitored. |  |

Note that after successfully adding all project files, you must call [PmProjectLoaded](#) to tell PDS to clean out unreferenced files from the scratch database.

See Also

[PmMonitorFile](#) and [PmProjectLoaded](#)

Module

[ARX Functions](#)

Links

[ARX Functions](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmOpenProject  
[Example](#) [ARX Functions](#) [Send Feedback](#)

Description

PmOpenProject

bool PmOpenProject(const TCHAR\* project, const TCHAR\* mdbfile, const TCHAR\* usr, const TCHAR\* pwd, const TCHAR\* inifile=NULL)

| Parameters |                                                                                                                                                                 |
|------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID.                                                       |
| mdbfile    | The full path and filename of the scratch database associate with this project. If NULL, the client will create the database file in a system temporary folder. |
| usr        | Database login user name. If NULL, no user name is used.                                                                                                        |
| pwd        | Database password for the login user name. If NULL no password is used                                                                                          |
| inifile    | The scratch database metadata ini file. If NULL and mdbfile is not NULL, the client will use the default scrdbmdb.ini file.                                     |

| Return Value |  |
|--------------|--|
|--------------|--|

```
if (!PmOpenProject("C:\\Projects\\Demo\\wddemo.wdp",
    "C:\\Projects\\Demo\\wddemo.mdb", NULL, NULL, NULL))
    return kError;
```

Module

[ARX Functions](#)

Links

[Example](#), [ARX Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmOpenProjectDb

[ARX Functions](#) [Send Feedback](#)

Description

PmOpenProjectDb

bool PmOpenProjectDb(const TCHAR\* project, const TCHAR\* provider, const TCHAR\* inifile=NULL);

| Parameters |                                                                                                                                                                                                                                                                        |
|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID.                                                                                                                                                              |
| provider   | An properly formatted <a href="#">OleDB</a> connection string.                                                                                                                                                                                                         |
| inifile    | The scratch database metadata ini file. If NULL , the client will use the default scrdbmdb.ini file which is written for Microsoft Access. If the provider is for a serve Microsoft Access, then this ini file must be written in the SQL dialect used by that server. |

| Return Value |                                                                          |
|--------------|--------------------------------------------------------------------------|
| false        | - the database does not exist, or a connection could not be established. |
| true         | - the project was opened and attached to the scratch database.           |

The metadata defined in the inifile will be used to confirm that the tables, indexes, views etc exist within the database. They will be created if found missing.

Module

[ARX Functions](#)

Links

[ARX Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmProjectLoaded

[Example](#) [ARX Functions](#) [See Also](#) [Send Feedback](#)

Description

PmProjectLoaded

void PmProjectLoaded(const TCHAR\* project)

This function informs the PDS that all of the files have been loaded and it should perform a database sweep to clean out unreferenced files. Call this function after [adding files](#) to a project during initialization sequence.

See Also

[PmMonitorFile](#), [PmMonitorFiles](#), [PmOpenProject](#) and [PmCloseProject](#)

Example

```
extern CPtrList files;
extern const TCHAR* project;

if (PmMonitorFiles(project, files, true))
    PmProjectLoaded(project);
```

Module

[ARX Functions](#)

Links

[Example](#), [ARX Functions](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmRenameCompleted

[ARX Functions](#) [Send Feedback](#)

Description

PmRenameCompleted

```
void PmRenameCompleted(const TCHAR* project, const TCHAR* oldname, const TCHAR* newname)
```

| Parameters |                                                                                                           |
|------------|-----------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |
| oldname    | The original name of the file which has been renamed.                                                     |
| newname    | The new name of the file if it has been renamed, or NULL if the rename failed or was cancelled.           |

This function is a balanced call with [PmRenamedStarted](#) and must be called whenever a [PmRenameStarted](#) has been used. If the rename operation is cancelled, pass NULL as the newname, as the rename operation will be cleared from the PDS.

Module

[ARX Functions](#)

Links

[ARX Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmRenameStarted

[ARX Functions](#) [Send Feedback](#)

Description

| Parameters |                                                                                                           |
|------------|-----------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |
| filename   | The name of the file which is about to be renamed.                                                        |

This function should be called prior to the file being renamed at the operating system level. The intent of the function is to place a filter on the events generated on the file so that the PDS do the rename as a system level operation.

Notes

This function call must always be balanced with a call to [PmRenameCompleted](#), even if the rename is cancelled or fails.

Module

[ARX Functions](#)

Links

[ARX Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmSetActive

[ARX Functions](#) [See Also](#) [Send Feedback](#)

Description

PmSetActive

void PmSetActive(const TCHAR\* project)

| Parameters |                                                                                                           |
|------------|-----------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |

This function passes the named project to the hidden instance of AutoCAD through a call to the Lisp function (ace\_openproject project 1) to keep both instances of AutoCAD in sync.

See Also

[PmProjectLoaded](#), [PmGetActive](#) and [PmOpenProject](#)

Module

[ARX Functions](#)

Links

[ARX Functions](#) [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmSetFromTo

[ARX Functions](#) [See Also](#) [Send Feedback](#)

Description

PmSetFromTo

void PmSetFromTo(short flag)

This function is used to toggle between using the [ObjectDBX](#) version of the wire information extraction and the Lisp based scripting process.

See Also

[PmGetFromTo](#) and [WD\\_PDS\\_SET\\_FROMTO](#)

Module

[ARX Functions](#)

Links

[ARX Functions](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmSetFromToAllDone

[ARX Functions](#) [Send Feedback](#)

Description

PmSetFromToAllDone

void PmSetFromToAllDone(const TCHAR\* project, bool flag)

| Parameters |                                                                                                                                                                 |
|------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID.                                                       |
| flag       | If true the scratch database From/To WSTAMP in the FILETIME table is marked as up to date. If false, the FILETIME table is marks as being out of date for all d |

This function is designed to be called after the WFRM2ALL table has been updated with the information gathered from the [ObjectDBX](#) version of the wire extraction.

See also [PmGetFromToAllReqd](#) and [WD\\_PDS\\_WFRM2ALL\\_COMPLETE](#)

Module

[ARX Functions](#)

Links

[ARX Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmSetProjectVar

[Example](#) [ARX Functions](#) [See Also](#) [Send Feedback](#)

Description

PmSetProjectVar

bool PmSetProjectVar(const TCHAR\* project, const TCHAR\* var, VARIANT value)

| Parameters |                                                                                                                                |
|------------|--------------------------------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID.                      |
| var        | The name of the variable, e.g. "IEC"                                                                                           |
| value      | The value of the variable, using the appropriate VARIANT members to set it. See the <a href="#">appendix</a> for more details. |

See Also

[Project Variables](#) and [WD\\_PDS\\_SET\\_PROJECT\\_VAR](#)

Example

```
extern TCHAR* project;
CComVariant vt;
vt.boolVal = VARIANT_TRUE;
PmSetProjectVar(project, "IEC", vt);
```

Module

[ARX Functions](#)

Links

[Example](#), [ARX Functions](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmUnlockFile

[ARX Functions](#) [Send Feedback](#)

Description

PmUnlockFile

```
bool PmUnlockFile(const TCHAR* filename)
```

| Parameters |                                                        |
|------------|--------------------------------------------------------|
| filename   | The full path and filename of the file to be unlocked. |

| Return Value |                        |
|--------------|------------------------|
| true         | The file was unlocked. |

This function attempts to release a write lock previously obtained with a call to [PmLockFile](#) on the named file.

Module

[ARX Functions](#)

Links

[ARX Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmUnlockFiles

[ARX Functions](#) [Send Feedback](#)

Description

PmUnlockFiles



|              |                                                                                                                                                                                                                                                               |
|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| files        | A const TCHAR* list of the full path and filename of the files to be unlocked.                                                                                                                                                                                |
| Return Value |                                                                                                                                                                                                                                                               |
| true         | The files were unlocked.                                                                                                                                                                                                                                      |
| false        | The files were not unlocked. In this case the files list will contain a list of files that could not be unlocked. The calling function is responsible for freeing the memory allocated to the return list. See the sample code in <a href="#">PmLockFiles</a> |

This function attempts to release write lock(s) previously obtained with a call to [PmLockFile](#) or [PmLockFiles](#).

Module

[ARX Functions](#)

Links

[ARX Functions](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

PmUseHelperProcess  
[ARX Functions](#) [See Also](#) [Send Feedback](#)

Description

PmUseHelperProcess

void PmUseHelperProcess(short flag)

|            |                                                                                                                                   |
|------------|-----------------------------------------------------------------------------------------------------------------------------------|
| Parameters |                                                                                                                                   |
| flag       | An entry is made in the AcePmClientApp.ini file to tell AutoCAD how to start a helper process the next time AutoCAD is started.   |
| 0          | Do not use a helper process.                                                                                                      |
| 1          | Use a helper process; start it at the same time as the host process and close it only when the host closes.                       |
| 2          | Use a helper process when required and leave it running until the host process closes.                                            |
| 3          | Use a helper process when required, and leave it running after it has been used. If it sits idle for 5 minutes, close the helper. |
| 4          | Use a helper process when required and close it when finished.                                                                    |

This function is used to enable or disable the startup of a second "helper" instance of AutoCAD when AutoCAD is started.

Notes

This does not shutdown a running helper instance or start a helper instance if not already running. It simply writes an entry to an ini file so that AutoCAD will act accordingly at the next start

See Also

[WD\\_PDS\\_USE\\_ACAD2](#)

Module

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

ObjectDBX

[Section M - Project Database Service](#) [Topics](#) [Send Feedback](#)

Description

The ObjectDBX classes are in the AcePmDefun.lib and AcePmDefun.arx.

To use the the ObjectDBX classes  
you need to:

|   |                                                                                            |
|---|--------------------------------------------------------------------------------------------|
| 1 | Include the relevant header file from the "v:\acad\aceperformance\acepmdefun\" folder.     |
| 2 | Link to the library file: \${OutDir}\acepmdefun.lib                                        |
| 3 | Load your ARX after AcePmDefun.arx is loaded. This is typically done in the ACADE.rx file. |

[AceDbManager](#)  
[AceDbWrapper](#)  
[AceDbxBlockRef](#)  
[AceDbxDatabase](#)  
[Sample](#)

Module

[Section M - Project Database Service](#)

Topics

| Name                           | Description |
|--------------------------------|-------------|
| <a href="#">AceDbManager</a>   |             |
| <a href="#">AceDbWrapper</a>   |             |
| <a href="#">AceDbxBlockRef</a> |             |
| <a href="#">AceDbxDatabase</a> |             |
| <a href="#">Sample</a>         |             |

Links

[Section M - Project Database Service](#), [Topics](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

AceDbManager

[ObjectDBX](#) [Send Feedback](#)

Description

**AceDbManager**

| AceDbManager                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <pre>-m_theManager : AceDbManager * = NULL -m_id : long = 0 #m_dbs : DatabaseMap #m_libs : StringVector  +AceDbManager() +~AceDbManager() +create() - bool +close() +instance() : AceDbManager * +open(in filename : const ACHAR*, in mode : int) : long +close(in handle : long, in save : bool) : bool +closeAll(in save : bool = false) +getDb(in handle : long, inout wrapper : AceDbWrapper) : AceDbDatabase * +getDoc(in handle : long) : AcApDocument * +getTableSearch(in handle : long) : AceDbTblSearch * +getIteratorPosition(in handle : long, in dict : const ACHAR*) : long +setIteratorPosition(in handle : long, in dict : const ACHAR*, in pos : long = 0) +isValidHandle(in handle : long) : bool +readOnly(in handle : long) : bool +addSearchPath(in path : const ACHAR*)</pre> |

AceDbManager

| Method                                                                                                                                        | Parameters                                                                                                                                                                                                      | Return Value                                                                                                     |
|-----------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|
| <b>create</b><br>Creates the singleton instance of this object. This function call is managed by the DLL and should not be called explicitly. |                                                                                                                                                                                                                 | <b>bool</b>                                                                                                      |
| <b>close</b><br>Destroys the singleton instance of this object. This function call is managed by the DLL and should not be called explicitly. |                                                                                                                                                                                                                 |                                                                                                                  |
| <b>instance</b><br>Get a pointer to the singleton instance.                                                                                   |                                                                                                                                                                                                                 | <b>AceDbManager</b>                                                                                              |
| <b>open</b><br>Open the named file.                                                                                                           | <b>filename</b> ? the name of the file to open.<br><b>mode</b> ? the requested mode; must be one of _SH_DENYNO, _SH_DENYWR, _SH_DENYRW                                                                          | <b>long</b> ? the handle of the opened file to be used as a parameter in the functions that manipulate the file. |
| <b>close</b><br>Closes the AceDbDatabase referenced by the handle.                                                                            | <b>handle</b> ? the handle returned by open().<br><b>save</b> ? a Boolean flag indicating whether the file should be saved (note that this is ignored if the file is open in the editor).                       | <b>bool</b>                                                                                                      |
| <b>closeAll</b><br>Closes all open files maintained by the class.                                                                             | <b>save</b> ? a Boolean flag indicating whether the file should be saved (note that this is ignored if the file is open in the editor).                                                                         |                                                                                                                  |
| <b>getDb</b><br>Get a pointer to the AceDbDatabase if the handle is a reference to an external file.                                          | <b>handle</b> ? the handle returned by open().<br><b>wrapper</b> & - an <a href="#">AceDbWrapper</a> object used to ensure that the use of the database will be constrained to the scope of the calling method. | <b>AceDbDatabase</b>                                                                                             |
| <b>getDoc</b><br>Get a pointer to the AceApDocument if the handle is a reference to a document already open in AutoCAD.                       | <b>handle</b> ? the handle returned by open().                                                                                                                                                                  | <b>AceApDocument</b>                                                                                             |
| <b>getIteratorPosition</b><br><i>For internal use only.</i>                                                                                   |                                                                                                                                                                                                                 |                                                                                                                  |
| <b>setIteratorPosition</b><br><i>For internal use only.</i>                                                                                   |                                                                                                                                                                                                                 |                                                                                                                  |
| <b>isValidHandle</b><br>Tests to see if the handle is still valid.                                                                            | <b>handle</b> - the handle returned by open().                                                                                                                                                                  | <b>bool</b>                                                                                                      |
| <b>readOnly</b><br>Tests to see if the AceDbDatabase was accessed in a read-only state.                                                       | <b>handle</b> - the handle returned by open().                                                                                                                                                                  | <b>bool</b>                                                                                                      |

Module

[ObjectDBX](#)

Links

[ObjectDBX](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback](#)  
AutoCAD Electrical 2025: AutoLISP Reference

AceDbWrapper  
[ObjectDBX](#) [Send Feedback](#)

Description

AceDbWrapper

```

AceDbWrapper
#m_db : AceDbDatabase *
#m_doc : AceApDocument *
#m_cur : AceApDocument *
#m_lockdoc : bool
+AceDbWrapper()
+~AceDbWrapper()
+set(in db : AceDbDatabase*, in doc : AceApDocument*) : bool
+set(in doc : AceApDocument*, in lock : bool) : bool
```

```

AceDbxBlockRef
-m_iter : AcDbBlockTableRecordIterator *
-m_block : AcDbBlockReference *
-m_btr : AcDbBlockTableRecord *
-m_mode : OpenMode
-m_libs : StringVector
-m_space : CString

+AceDbxBlockRef()
+~AceDbxBlockRef()
+setSpace(in view : const ACHAR* = ACDB_MODEL_SPACE)
+find(in param : const ACHAR*, in type : FindParam = kBlockName, in mode : OpenMode = AcDb::kForRead) : bool
+next() : bool
+close() : bool
+close(in save : bool) : bool
+getAcDbHandle(inout handle : AcDbHandle)
+getBlock() : AcDbBlockReference *
+attributeIterator() : AcDbObjectIterator *
+isValid() : bool
+hasAttribute(in tag : const ACHAR*, in ignorecase : bool = true) : bool
+getAttributeTextString(in tag : const ACHAR*, inout prompt : CString, in ignorecase : bool = true) : bool
+getAttributeTextString(in tag : const ACHAR*, in ignorecase : bool = true) : ACHAR *
+getAttribute(in tag : const ACHAR*, in fileName : const ACHAR*, in mode : OpenMode = AcDb::kForRead, in ignorecase : bool = true) : AcDbAttribute *
+setAttributeTextString(in tag : const ACHAR*, in prompt : const ACHAR*, in ignorecase : bool = true) : bool
+insert(in block : const ACHAR*, in fileName : const ACHAR*, in pt : AcGePoint3d, in scalex : double = 1, in scaley : double = 1, in rot : double = 0) : bool
+insert(in block : const ACHAR*, in pt : AcGePoint3d, in scalex : double = 1, in scaley : double = 1, in rot : double = 0) : bool
+isValidBlock(in block : const ACHAR*, in fileName : const ACHAR*) : bool
+addSearchPath(in path : const ACHAR*)
+rmSearchPath(in path : const ACHAR*) : bool
+purge(in block : const ACHAR*) : bool
+addClonedAttribute(in fromTag : const ACHAR*, in newTag : const ACHAR*, in newText : const ACHAR*, in ignorecase : bool = true, in xOffset : double = 0.000000, in yOffset : double = -1.500000, in mulTextHeight : bool)
+getBlockTableRecord(in block : const ACHAR*) : bool
+insertBlockTableRecord(in block : const ACHAR*, in fileName : const ACHAR*) : bool
+insertBlockTableRecord(in block : const ACHAR*, in file : const ACHAR*, in acdb : AcDbDatabase*) : bool
+insertFile(in block : const ACHAR*, inout file : CString) : bool
+createInstance(in pt : AcGePoint3d, in sx : double, in sy : double, in sz : double, in rot : double) : bool
+addAttributes() : bool
+getIOBlock(in block : const ACHAR*, inout btrId : AcDbObjectId) : bool
+getClonedAttributeDef(in fromTag : const ACHAR*, in newTag : const ACHAR*, in ignorecase : bool, in xOffset : double, in yOffset : double, in mulTextHeight : bool, inout attDef : AcDbAttributeDefinition*) : bool
+addAttribute(in attDef : AcDbAttributeDefinition*, in newText : const ACHAR*) : bool

```

|                                                                                                                                                                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                     |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------|
| <b>setSpace</b><br>Set the layout space. The default is ACDB_MODEL_SPACE                                                                                           | <b>view</b> ? the named layout space.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                                                                     |
| <b>find</b><br>Get the AcDbBlockReference of the named object within the AcDbDatabase. If found, the AcDbBlockReference remains ?active? for attribute operations. | <b>param</b> ? a string that represents either the block name or the handle of the block.<br><b>type</b> ? an enum that describes the param.<br><b>mode</b> ? the AcDb::OpenMode of the object.                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <b>bool</b>                                                         |
| <b>next</b><br>If find was called with a block name, this method will iterate to the next instance of that block.                                                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <b>bool</b>                                                         |
| <b>close</b><br>Releases the pointers to the various objects within the AcDbDatabase.                                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                     |
| <b>close</b><br>Closes the named file and optionally saves it.                                                                                                     | <b>save</b> ? a Boolean flag indicating whether the file should be saved (note that this is ignored if the file is open in the editor).                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | <b>bool</b>                                                         |
| <b>getAcDbHandle</b><br>Get the handle to the current AcDbBlockReference                                                                                           | <b>handle&amp;</b> - the output handle.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                                                                     |
| <b>getBlock</b><br>Get at the underlying AcDbBlockReference.                                                                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <b>AcDbBlockF</b>                                                   |
| <b>attributeIterator</b><br>Create an AcDbObjectIterator to iterate through the block attributes.                                                                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <b>AcDbObject</b>                                                   |
| <b>isValid</b><br>Test to see if there is a current AcDbBlockReference being accessed.                                                                             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <b>bool</b>                                                         |
| <b>has Attribute</b><br>Test to see if the AcDbBlockReference has the named attribute.                                                                             | <b>tag</b> ? the attribute tag.<br><b>ignorecase</b> ? Boolean flag to do case insensitive searching.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | <b>bool</b>                                                         |
| <b>getAttributeTextString</b><br>Get the value of the attribute text.                                                                                              | <b>tag</b> ? the attribute tag.<br><b>prompt&amp;</b> - a CString buffer to receive the output.<br><b>ignorecase</b> ? Boolean flag to do case insensitive searching.                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | <b>bool</b>                                                         |
| <b>getAttributeTextString</b><br>Get the value of the attribute text.                                                                                              | <b>tag</b> ? the attribute tag.<br><b>ignorecase</b> ? Boolean flag to do case insensitive searching.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | <b>ACHAR*</b><br>note that the free the men returned usir delete [] |
| <b>getAttribute</b><br>Get at the AcDbAttribute object.                                                                                                            | <b>tag</b> ? the attribute tag.<br><b>mode</b> ? the AcDb::OpenMode of the object.<br><b>ignorecase</b> ? Boolean flag to do case insensitive searching.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | <b>AcDbAttribu</b>                                                  |
| <b>setAttributeTextString</b><br>Set the value of the attribute text.                                                                                              | <b>tag</b> ? the attribute tag.<br><b>prompt</b> ? the new text value.<br><b>ignorecase</b> ? Boolean flag to do case insensitive searching.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | <b>bool</b>                                                         |
| <b>insert</b><br>Insert the named block into the AcDbDatabase.                                                                                                     | <b>block</b> ? the name of the block.<br><b>filename</b> ? the full path and name of the external block file including the DWG extension.<br><b>pt</b> ? the insertion point.<br><b>scalex</b> ? scale the block X value by this amount.<br><b>scaley</b> ? scale the block Y value by this amount.<br><b>scalez</b> ? scale the block Z value by this amount.<br><b>rot</b> ? the rotation angle.                                                                                                                                                                                                                                              | <b>bool</b>                                                         |
| <b>insert</b><br>Insert the named block into the AcDbDatabase. This version will search the paths given with <b>addSearchPath</b> to find the file.                | <b>block</b> ? the name of the block.<br><b>pt</b> ? the insertion point.<br><b>scalex</b> ? scale the block X value by this amount.<br><b>scaley</b> ? scale the block Y value by this amount.<br><b>scalez</b> ? scale the block Z value by this amount.<br><b>rot</b> ? the rotation angle.                                                                                                                                                                                                                                                                                                                                                  | <b>bool</b>                                                         |
| <b>addSearchPath</b><br>Add a folder to look in for the named block. Set this before calling <b>insert</b>                                                         | <b>path</b> ? the folder name.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |                                                                     |
| <b>rmSearchPath</b><br>Removed the named path from the search path.                                                                                                | <b>path</b> ? the folder name.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | <b>bool</b>                                                         |
| <b>purge</b><br>Purge the named block from the AcDbDatabase.                                                                                                       | <b>block</b> ? the name of the block.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | <b>bool</b>                                                         |
| <b>addClonedAttribute</b><br>Add a new attribute to the block by cloning and existing attribute.                                                                   | <b>fromTag</b> ? the name of the attribute to use as the clone.<br><b>newTag</b> ? the name of the new attribute tag.<br><b>newText</b> ? the value of the attribute.<br><b>ignorecase</b> ? Boolean flag to do case insensitive searching.<br><b>xoffset</b> ? the units to offset the X coordinate of this attribute from the X of the cloned attribute.<br><b>yoffset</b> ? the units to offset the Y coordinate of this attribute from the Y of the cloned attribute.<br><b>mulTextHeight</b> ? if this is true, the <b>yoffset</b> is multiplied by the text height to calculate the new Y coordinate relative to the cloned Y coordinate. | <b>bool</b>                                                         |

|                                                                |  |  |
|----------------------------------------------------------------|--|--|
| <b>#findFile</b><br><i>For internal use only.</i>              |  |  |
| <b>#createInstance</b><br><i>For internal use only.</i>        |  |  |
| <b>#addAttribute</b><br><i>For internal use only.</i>          |  |  |
| <b>#getIdOfBlock</b><br><i>For internal use only.</i>          |  |  |
| <b>#getClonedAttributeDef</b><br><i>For internal use only.</i> |  |  |
| <b>#addAttribute</b><br><i>For internal use only.</i>          |  |  |

Module

[ObjectDBX](#)

Links

[ObjectDBX](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference

AceDbxDatabase

[ObjectDBX](#) [Send Feedback](#)

Description

AceDbxDatabase

| AceDbxDatabase                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <pre>#m_handle : long #m_canClose : bool #m_wrapper : AceDbWrapper * #m_error : ErrorCode #m_es : ErrorStatus +AceDbxDatabase() +~AceDbxDatabase() +open(in filename : const ACHAR*, in mode : int) : bool +close(in save : bool) : bool +isOpen() : bool +database() : AcDbDatabase * +release() +attach(in handle : long, in canClose : bool = false) : bool +attach(in acdb : AcDbDatabase*) : bool +getLastError() : ErrorCode +getErrorStatus() : ErrorStatus +setError(in rval : bool, in ec : ErrorCode) : bool</pre> |

| AceDbxDatabase                                                                                        |                                                                                                                                         |                     |
|-------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|---------------------|
| Method                                                                                                | Parameters                                                                                                                              | Return Val          |
| <b>open</b><br>Opens the named file with the proposed mode of access.                                 | <b>filename</b> ? the name of the file to open.<br><b>mode</b> ? the requested mode; must be one of _SH_DENYNO, _SH_DENYWR, _SH_DENYRW  | <b>bool</b>         |
| <b>close</b><br>Closes the named file and optionally saves it.                                        | <b>save</b> ? a Boolean flag indicating whether the file should be saved (note that this is ignored if the file is open in the editor). | <b>bool</b>         |
| <b>isOpen</b><br>Test to see if the AceDbxDatabase is actually associated with a AcDbDatabase object. |                                                                                                                                         | <b>bool</b>         |
| <b>database</b>                                                                                       |                                                                                                                                         | <b>AcDbDatabase</b> |

**Module**

[ObjectDBX](#)

**Links**

[ObjectDBX](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

**Sample**

[ObjectDBX](#) [Send Feedback](#)

**Description**

**Sample**

```
#include "v:/acade/aceperformance/acepmdefun/AceDbxBlockRef.h"

// link to AcePmDefun.lib

bool myBlockDemo(void)
{
    // create a AceDbxBlockRef object
    AceDbxBlockRef br;
    // open a DWG file
    if (br.open(_T("c:/tmp/demo03.dwg"), _SH_DENYWR))
    {
        // see if we can find the WD_M block
        if (!br.find(_T("WD_M"), AceDbxBlockRef::kBlockName))
        {
            // not found - so add it...
            // add a library search path
            br.addSearchPath(
                _T("C:\\Program Files\\Autodesk\\Acade 2007\\Libs\\jic125"));
            // insert the block
            if (br.insert(_T("WD_M"), AcGePoint3d(0,0,0)))
                // it is safe to return, as the AceDbxBlockRef will
                // close the database and return everything to normal
                // when it goes out of scope
                return false;
        }
        // see if the block has our attribute
        if (!br.hasAttribute(_T("TEST-DBX")))
        {
            // no it doesn't, so let's add it after the
            // SORTMODE attribute
            if (!br.addClonedAttribute(_T("SORTMODE"), _T("TEST-DBX"), _T("It Works!")))
                return false;
        }
        // found the attribute, so change the text
        else if (!br.setAttributeTextString(_T("TEST-DBX"), _T("Updated Text")))
            return false;
        // save the changes
        return br.close(true);
    }
    return false;
}
```

**Module**

What do you think about this topic? [Send feedback](#)  
AutoCAD Electrical 2025: AutoLISP Reference

LISP

[Section M - Project Database Service](#) [Topics](#) [Send Feedback](#)

Module

[Section M - Project Database Service](#)

Topics

| Name                                    | Description                                                                                                                                                                                                                                       |
|-----------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">ACE SCRIPT</a>              | This command is a plug-in replacement for the AutoCAD SCRIPT command but is written to work in an MDI environment (across documents).<br>This is a synchronous command. At the time of returning it does not mean that the operation has complete |
| <a href="#">Envrionment</a>             |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX</a>                  |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX CLOSE</a>            |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX COMMAND</a>          |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX COPY TABLESTYLE</a>  |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX DICTADD</a>          |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX DICTGET</a>          |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX DICTNEXT</a>         |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX ENTATTR</a>          |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX ENTDEL</a>           |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX ENTGET</a>           |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX ENTLAST</a>          |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX ENTMAKE</a>          |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX ENTMOD</a>           |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX ENTNEXT</a>          |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX FILE FROM HANDLE</a> |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX GET TABLESTYLE</a>   |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX GET XREF</a>         |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX GETVAR</a>           |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX GROUP CREATE</a>     |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX GROUP DELETE</a>     |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX HANDENT</a>          |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX MTEXT</a>            |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX NAMEDOBJECT</a>      |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX OPEN</a>             |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX PUMP MSGS</a>        |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX SETVAR</a>           |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX SSGET</a>            |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX TBLNEXT</a>          |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX TBLSEARCH</a>        |                                                                                                                                                                                                                                                   |
| <a href="#">WD DBX WNUM POS</a>         |                                                                                                                                                                                                                                                   |
| <a href="#">WD OLEDB COMMAND</a>        |                                                                                                                                                                                                                                                   |
| <a href="#">WD OLEDB DELETE</a>         |                                                                                                                                                                                                                                                   |
| <a href="#">WD OLEDB FIELDSPEC</a>      |                                                                                                                                                                                                                                                   |
| <a href="#">WD OLEDB INSERT</a>         |                                                                                                                                                                                                                                                   |
| <a href="#">WD OLEDB SELECT</a>         |                                                                                                                                                                                                                                                   |
| <a href="#">WD PDS ACTIVATF PROJECT</a> |                                                                                                                                                                                                                                                   |



|                                              |                                                                                                                                                                  |
|----------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">WD_PDS_DROP_FILES</a>            |                                                                                                                                                                  |
| <a href="#">WD_PDS_FILES_LOCKED</a>          |                                                                                                                                                                  |
| <a href="#">WD_PDS_FLUSH_ACTIVE_DWG</a>      |                                                                                                                                                                  |
| <a href="#">WD_PDS_FRESHEN_PROJECT_DB</a>    |                                                                                                                                                                  |
| <a href="#">WD_PDS_GET_ACTIVE_PROJECT</a>    |                                                                                                                                                                  |
| <a href="#">WD_PDS_GET_FROMTO</a>            |                                                                                                                                                                  |
| <a href="#">WD_PDS_GET_OPEN_DWGS</a>         |                                                                                                                                                                  |
| <a href="#">WD_PDS_GET_PROJECT_DB</a>        |                                                                                                                                                                  |
| <a href="#">WD_PDS_LOCK_FILES</a>            |                                                                                                                                                                  |
| <a href="#">WD_PDS_OPEN_PROJECT</a>          |                                                                                                                                                                  |
| <a href="#">WD_PDS_PROJECT_LOADED</a>        |                                                                                                                                                                  |
| <a href="#">WD_PDS_RESET_PROJECT_DB</a>      |                                                                                                                                                                  |
| <a href="#">WD_PDS_SET_FROMTO</a>            |                                                                                                                                                                  |
| <a href="#">WD_PDS_SET_PROJECT_VAR</a>       |                                                                                                                                                                  |
| <a href="#">WD_PDS_UNLOCK_FILES</a>          |                                                                                                                                                                  |
| <a href="#">WD_PDS_USE_ACAD2</a>             |                                                                                                                                                                  |
| <a href="#">WD_PDS_WFRM2ALL_COMPLETE</a>     |                                                                                                                                                                  |
| <a href="#">WD_PDS_WFRM2ALL_REBUILD_REQD</a> |                                                                                                                                                                  |
| <a href="#">WD_PDSX_ACTIVATE</a>             |                                                                                                                                                                  |
| <a href="#">WD_PDSX_CLOSE</a>                |                                                                                                                                                                  |
| <a href="#">WD_PDSX_ENABLE_FRESHEN</a>       |                                                                                                                                                                  |
| <a href="#">WD_PDSX_MAPSCRCMD</a>            | (wd_pdsx_mapscrcmd lispfunc pdkw arg)<br><br>This is used for script file translations.<br>Purpose: Maps an AutoCAD command to one of the keywords listed below. |
| <a href="#">WD_PDSX_OPEN</a>                 |                                                                                                                                                                  |
| <a href="#">WD_PDSX_PROCESSID</a>            |                                                                                                                                                                  |
| <a href="#">WD_PDSX_PROCFILE</a>             |                                                                                                                                                                  |
| <a href="#">WD_PDSX_SCRIPT</a>               |                                                                                                                                                                  |
| <a href="#">WD_PDSX_TEMPDIR</a>              |                                                                                                                                                                  |

Links

[Section M - Project Database Service](#), [Topics](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference  
**ACE\_SCRIPT**  
[Example](#) [LISP](#) [Send Feedback](#)

Description

This command is a plug-in replacement for the AutoCAD SCRIPT command but is written to work in an MDI environment (across documents).  
This is a synchronous command. At the time of returning it does not mean that the operation has completed.

Example

Opens the "Select Script File" dialog and allows the user to select a script file to run.  
(COMMAND " \_ACE\_SCRIPT" "c:/demo/\_irefrm2.scr")  
Runs the script command using the named file.

Module

[LISP](#)

Links

[LISP](#) [See Also](#) [Send Feedback](#)

Description

Envrionment

There are several commands you can use to turn on or off the scripting process of ACADE performance. Each of these commands either reports the state of the envrionment setting or change depending upon the use of the optional argument.

(wd\_env\_function [arg])

| Parameters   |                                                                |
|--------------|----------------------------------------------------------------|
| function     | See below                                                      |
| arg          |                                                                |
| Not supplied | Returns the current setting (T or nil) as enabled or disabled. |
| nil          | Turns off the non-scripting mode of operation.                 |
| T            | Turns on the non-scripting mode of operation (DBX mode).       |

| Return Value                                           |
|--------------------------------------------------------|
| T if the non-scripting mode is enabled, nil otherwise. |

wd\_env\_retag - use this to control the Component Retagging feature.

wd\_env\_wireanno - use this to control the Wire Annotations feature.

wd\_env\_wirenum - use this to control the Wire Numbering feature.

wd\_env\_xref - use this to control the Cross Referencing feature.

See Also

[WD\\_PDS\\_GET\\_FROMTO](#), [WD\\_PDS\\_SET\\_FROMTO](#)

Module

[LISP](#)

Links

[LISP](#) [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_DBX

[LISP](#) [Send Feedback](#)

Description

WD\_DBX\_\*

The WD\_DBX\_\* functions are written to provide an environment that allows you to modify drawings that may be (a) loaded and active in the AutoCAD editor; (b) loaded and inactive; or (c) : unopened on disk. For performance purposes, the repeated use of these functions should be wrapped between a [WD\\_DBX\\_OPEN](#) and [WD\\_DBX\\_CLOSE](#) (regardless of whether the drawing is c or not).

These functions are aware of the PDS / multi-user environment and will work even if the drawings are locked using the [PDS file locking mechanism](#).

Module

[LISP](#)

Links

[LISP](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_DBX\_CLOSE

[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

|            |                                                                  |
|------------|------------------------------------------------------------------|
| filehandle | The handle returned from a call to <a href="#">wd_dbx_open</a> . |
| save       |                                                                  |
| T          | The file is saved to disk.                                       |
| nil        | The file is closed without saving.                               |
|            |                                                                  |

|                                        |
|----------------------------------------|
| Return Value                           |
| T if the file was successfully closed. |

Note that this function can be used on a file that is already open in the AutoCAD session as well as files that are not currently open. However if the file is already open for editing in the AutoC the save parameter is ignored.

See Also

[WD\\_DBX\\_OPEN](#)

Example

```
(setq fhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "w"))
(if fhand
  (progn
    ...
    (wd_dbx_close fhand T)
  )
)
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference  
**WD\_DBX\_COMMAND**  
[Example](#) [LISP](#) [Send Feedback](#)

Description

WD\_DBX\_COMMAND

```
(wd_dbx_command file command args)
```

|            |                                                                                                                    |
|------------|--------------------------------------------------------------------------------------------------------------------|
| Parameters |                                                                                                                    |
| file       |                                                                                                                    |
| nil        | Uses the current drawing.                                                                                          |
| filename   | The full path and file name of the file to query.                                                                  |
| filehandle | The handle returned from a call to <a href="#">wd_dbx_open</a> .                                                   |
|            |                                                                                                                    |
| command    | The currently supported command texts are "CLAYER" "LAYER" "MOVE" "TEXT" and "INSERT"                              |
| args       | These are the arguments supported by the above mentioned command as per the <a href="#">LISP</a> COMMAND function. |

Example

```
(setq fhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "w"))
(if fhand
  (progn
    (if (wd_dbx_command fhand " _INSERT" "MyBlock" " _S" 2.5 " _R" 90 '(3 4 0) "")
      (wd_dbx_close fhand T) ; save changes
      (wd_dbx_close fhand nil))
    )
  )
or
(wd_dbx_command "c:/tmp/demo04.dwg" " _CLAYER" "WIRES")
or
(wd_dbx_command fhand " _MOVE" "e3f" "" (list 1 1 0) (list 1 2 0))
```

Module

[LISP](#)

Links

[Example](#), [LISP](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference  
**WD\_DBX\_COPY\_TABLESTYLE**  
[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_DBX\_COPY\_TABLESTYLE

(wd\_dbx\_copy\_tablestyle fromfile tofile tablestyle)

| Parameters |                                                                                                                                  |
|------------|----------------------------------------------------------------------------------------------------------------------------------|
| fromfile   |                                                                                                                                  |
| nil        | Uses the current drawing.                                                                                                        |
| filename   | The full path and file name of the file to query.                                                                                |
| filehandle | The handle returned from a call to <a href="#">wd_dbx_open</a> .                                                                 |
|            |                                                                                                                                  |
| tofile     |                                                                                                                                  |
| nil        | Uses the current drawing.                                                                                                        |
| filename   | The full path and file name of the file to query.                                                                                |
| filehandle | The handle returned from a call to <a href="#">wd_dbx_open</a> . Note that the file must have been opened with the "w" mode set. |
|            |                                                                                                                                  |
| tablestyle | The name of the preexisting table style in fromfile.                                                                             |

See Also

[WD\\_DBX\\_TBLSEARCH](#) and [WD\\_DBX\\_GET\\_TABLESTYLE](#)

Example

```
(setq fmhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "r"))
(setq tohand (wd_dbx_open "C:/Projects/Demo/demo04.dwg" "w"))
(if (and fhand tohand)
  (progn
    (setq dosave (wd_dbx_copy_tablestyle fmhand tohand "My Table Style"))
    (wd_dbx_close fmhand nil)
    (wd_dbx_close tohand dosave)
  )
)
or
(wd_dbx_copy_tablestyle "c:/tmp/demo03.dwg" "c:/tmp/demo04.dwg" "Test Style")
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_DBX\_DICTADD

[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_DBX\_DICTADD

(wd\_dbx\_dictadd handle xname xlist file)

| Parameters |                                                                                                                                                                                                                                                                                                                                                                  |
|------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| handle     | The handle of the entity in the drawing to which you wish to add a new record in it's extension dictionary.                                                                                                                                                                                                                                                      |
| xname      | The name of the XRECORD in the extension dictionary. Any dictionary record with the same name is replaced by this new entry.                                                                                                                                                                                                                                     |
| xlist      | A list of XRECORD definition data in a format similar to that returned by the wd_dbx_dictget function. The xlist argument must contain all of the information neces- sary to define the record. If any required definition data is omitted, wd_dbx_dictadd returns nil and the record is rejected. The entity type XRECORD must be the first field of the xlist. |
| file       |                                                                                                                                                                                                                                                                                                                                                                  |
| nil        | Uses the current drawing.                                                                                                                                                                                                                                                                                                                                        |
| filename   | The full path and file name of the file to query.                                                                                                                                                                                                                                                                                                                |
| filehandle | The handle returned from a call to <a href="#">wd_dbx_open</a> . Note that the file must have been opened with the "w" mode set.                                                                                                                                                                                                                                 |
|            |                                                                                                                                                                                                                                                                                                                                                                  |

[WD\\_DBX\\_DICTGET](#)

Example

```
(setq fhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "w"))
(if fhand
  (progn
    (setq xrec (list (cons 0 "XRECORD") (cons 100 "AcDbXrecord") (cons 1 "Name") (cons 2 "Some Data"))))
  (if (wd_dbx_dictadd "B7f" "Test" xrec fhand)
    (wd_dbx_close fhand T) ; save changes
    (wd_dbx_close fhand nil))
  )
)
or
(setq xrec (list (cons 0 "XRECORD") (cons 100 "AcDbXrecord") (cons 1 "Name") (cons 2 "Some Data"))))
(wd_dbx_dictadd "4ef" "MyXrec" xrec "c:/tmp/demo04.dwg")
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback](#)  
AutoCAD Electrical 2025: AutoLISP Reference  
**WD\_DBX\_DICTGET**  
[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_DBX\_DICTGET

(wd\_dbx\_dictadd handle xname file)

| Parameters |                                                                                               |
|------------|-----------------------------------------------------------------------------------------------|
| handle     | The handle of the entity in the drawing to which you wish to query it's extension dictionary. |
| xname      | The name of the XRECORD in the extension dictionary.                                          |
| file       |                                                                                               |
| nil        | Uses the current drawing.                                                                     |
| filename   | The full path and file name of the file to query.                                             |
| filehandle | The handle returned from a call to <a href="#">wd_dbx_open</a> .                              |

| Return Value |                                                                 |
|--------------|-----------------------------------------------------------------|
|              | An association list containing the entity definition of handle. |

```
(setq fhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "r"))
(if fhand
  (progn
    (setq xrec (wd_dbx_dictadd "B7F" "Test" fhand))
    (wd_dbx_close fhand nil))
  )
)
or
(wd_dbx_dictget "4ef" "MyXrec" "c:/tmp/demo04.dwg")
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference

WD\_DBX\_DICTNEXT

[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_DBX\_DICTNEXT

(wd\_dbx\_dictadd handle rewind file)

| Parameters |                                                                                                                                                                                                                                                                                   |
|------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| handle     | The handle of the dictionary.                                                                                                                                                                                                                                                     |
| rewind     | If non-zero resets the wd_dbx_dictnext function to start at the beginning. Note: The rewind flag can only be honored in a file that has been opened using <a href="#">wd_dbx_open</a> . All other uses of this function will only return the first entry in the named dictionary. |
| file       |                                                                                                                                                                                                                                                                                   |
| nil        | Uses the current drawing.                                                                                                                                                                                                                                                         |
| filename   | The full path and file name of the file to query.                                                                                                                                                                                                                                 |
| filehandle | The handle returned from a call to <a href="#">wd_dbx_open</a> .                                                                                                                                                                                                                  |

| Return Value |                                                                                          |
|--------------|------------------------------------------------------------------------------------------|
|              | An association list containing the entry in the AcDbDictionary at the iterated position. |

See Also

[WD\\_DBX\\_NAMEDOBJDICT](#)

Example

```
(princ "\n")
(setq rewind nil)
)
(wd_dbx_close fhand nil))
)
)
or
(wd_dbx_dictnext (wd_dbx_namedobjdict) 1 "c:/tmp/demo04.dwg")
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_DBX\_ENTATTR

[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_DBX\_ENTATTR

(wd\_dbx\_entattr handle file attlist)

| Parameters              |                                                                                                                                             |
|-------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|
| handle                  | The handle of the INSERT entity in the drawing.                                                                                             |
| file                    |                                                                                                                                             |
| nil                     | Uses the current drawing.                                                                                                                   |
| filename                | The full path and file name of the file to query.                                                                                           |
| filehandle              | The handle returned from a call to <a href="#">wd_dbx_open</a> .                                                                            |
| attlist                 |                                                                                                                                             |
| nil                     | Returns a list of all attributes on the named entity.                                                                                       |
| (attname1 attname2 ...) | List of attribute tags to be found on the INSERT. Wildcards are supported, such as "TAG*" or "X?TERM*" to get a list of matching attributes |

| Return Value                                                                                                                                                                                                                                                                                                                                                                                                                  |  |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| A list of attribute TAG, VALUE and HANDLE lists. Eg:<br>(("TAG1" "PB425A" "655") ("DESC1" "INDEXING MOTOR" "656") ("DESC2" "STOP" "657") ("FAMILY" "PB" "658") ("CONTACT" "NC" "659") ("XREF" "" "65A") ("CAT" "800T-D1B" "65B") ("M" "65C") ("LOC" "OPSTA3" "65D") ("X8LINK" "" "65E") ("X2LINK" "" "65F") ("TERM02" "" "660") ("X1TERM02" "" "661") ("X4TERM01" "" "662") ("TERM01" "" "663") ("ASSYCODE" "" "664") "665")) |  |

See Also

[WD\\_DBX\\_ENTGET](#)



```
(if fhand
  (progn
    (wd_dbx_entattr "8f3" fhand nil)
    (wd_dbx_close fhand nil)
  )
)
or
(wd_dbx_entattr "4c2" "c:/tmp/demo04.dwg" (list "TAG*" "FAMILY" "LOC" "X?TERM*"))
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_DBX\_ENTDEL

[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_DBX\_ENTDEL

(wd\_dbx\_entdel handle file)

Parameters

|            |                                                                                                                                  |
|------------|----------------------------------------------------------------------------------------------------------------------------------|
| handle     | The handle of the entity in the drawing.                                                                                         |
| file       |                                                                                                                                  |
| nil        | Uses the current drawing.                                                                                                        |
| filename   | The full path and file name of the file to query.                                                                                |
| filehandle | The handle returned from a call to <a href="#">wd_dbx_open</a> . Note that the file must have been opened with the "w" mode set. |

Return Value

T if the entity was deleted successfully.

The entity specified by handle is deleted if it is currently in the drawing. The wd\_dbx\_entdel function restores the entity to the drawing if it has been deleted previously in this editing session. entities are purged from the drawing when the drawing is exited. The wd\_dbx\_entdel function can delete both graphical and nongraphical entities.

See Also

[WD\\_DBX\\_ENTGET](#) and [WD\\_DBX\\_ENTATTR](#)

Example

```
(setq fhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "w"))
```

```
)  
or  
(wd_dbx_entdel "4c2" "c:/tmp/demo04.dwg")
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_DBX\_ENTGET

[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_DBX\_ENTGET

```
(wd_dbx_entget handle file filter)  
or  
(wd_dbx_entget ename filehandle filter)  
or  
(wd_dbx_entget handlist file filter)
```

Parameters

|            |                                                                                                                                                                                                                                                     |
|------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| handle     | The handle of the entity in the drawing.                                                                                                                                                                                                            |
| handlist   | List of handles of entities to query.                                                                                                                                                                                                               |
| file       |                                                                                                                                                                                                                                                     |
| nil        | Uses the current drawing.                                                                                                                                                                                                                           |
| filename   | The full path and file name of the file to query.                                                                                                                                                                                                   |
| filehandle | The handle returned from a call to <a href="#">wd_dbx_open</a> .                                                                                                                                                                                    |
| ename      | Name of the entity being queried. The ename can refer to either a graphical or a nongraphical entity. Note that an ename is only valid for the use of a file open operation. Therefore this mode should only be used with the wd_dbx_open function. |
| filehandle |                                                                                                                                                                                                                                                     |
| nil        | Uses the current drawing.                                                                                                                                                                                                                           |
| filehandle | The handle returned from a call to <a href="#">wd_dbx_open</a> .                                                                                                                                                                                    |
| filter     | If non nil, a list of filters to apply to the Xdata on the entity.                                                                                                                                                                                  |

Return Value

An association list containing the entity definition of handle. If the filter is non-nil wd\_dbx\_entget also returns the extended data associated with the specified applications. Objects in the list are assigned AutoCAD DXF? group codes for each part of the entity data.

Example

```
(setq fhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "r"))
(if fhand
  (progn
    (if (and (setq en (wd_dbx_entget "8f3" fhand)) (assoc 330 en))
      (setq e2 (wd_dbx_entget (cdr (assoc 330 en)) fhand)) ; uses ename
    )
    (wd_dbx_close fhand nil)
  )
)
or
(wd_dbx_entget "4c2" "c:/tmp/demo04.dwg" "**")
(wd_dbx_entget (list "660" "673") "c:/tmp/demo02.dwg" (list "VIA_WD_MAX*" "*_WD_PINLIST"))
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_DBX\_ENTLAST

[LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_DBX\_ENTLAST

(wd\_dbx\_entlast file)

| Parameters |                                                                  |
|------------|------------------------------------------------------------------|
| file       |                                                                  |
| nil        | Uses the current drawing.                                        |
| filename   | The full path and file name of the file to query.                |
| filehandle | The handle returned from a call to <a href="#">wd_dbx_open</a> . |

| Return Value                                                              |  |
|---------------------------------------------------------------------------|--|
| An entity handle; otherwise nil, if there are no entities in the drawing. |  |

Examples

```
(setq e1 (wd_dbx_entlast)) ; Sets e1 to the handle of the last entity in the current drawing
(setq fhand (wd_dbx_open "c:/tmp/demo03.dwg" "r"))
(setq e1 (wd_dbx_entlast fhand))
(wd_dbx_close fhand nil)
```

See Also

Links

[LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_DBX\_ENTMAKE

[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_DBX\_ENTMAKE

(wd\_dbx\_entmake elist file)

Parameters

elist      A list of entity definition data in a format similar to that returned by the wd\_dbx\_entget function. The elist argument must contain all of the information necessary to define the entity. If any required definition data is omitted, wd\_dbx\_entmake returns nil and the entity is rejected. If you omit optional definition data (such as the layer), wd\_dbx\_entmake uses the default value. The entity type (for example, CIRCLE or LINE) must be the first or second field of the elist. If entity type is the second field, it can be preceded only by the entity name. The wd\_dbx\_entmake function ignores the entity name when creating the new entity. If the elist contains an entity handle, wd\_dbx\_entmake ignores that too.

Notes

You can pass a list of lists of entity definition data to create several entities in a single call to this method.

file

nil

Uses the current drawing.

filename

The full path and file name of the file to query.

filehandle

The handle returned from a call to [wd\\_dbx\\_open](#). Note that the file must have been opened with the "w" mode set.

Return Value

The handle of the newly created entity.

See Also

[WD\\_DBX\\_ENTGET](#) and [WD\\_DBX\\_ENTMOD](#)

Example

```
(setq fhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "w"))
(if fhand
  (progn
    (setq ring (list (cons 0 "CIRCLE") (cons 8 "0") (list 10 8.5 7.0 0.0) (cons 40 1.0)))
    (if (setq hand (wd_dbx_entmake ring fhand))
      (wd_dbx_close fhand T) ; save changes
      (wd_dbx_close fhand nil))
    )
  )
or
(setq ring (list (cons 0 "CIRCLE") (cons 8 "0") (list 10 8.5 7.0 0.0) (cons 40 1.0)))
(wd_dbx_entmake ring "c:/tmp/demo04.dwg")
```

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_DBX\_ENTMOD

[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_DBX\_ENTMOD

(wd\_dbx\_entmod elist file)

Parameters

|       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| elist | A list of entity definition data in a format similar to that returned by the wd_dbx_entget function. Unlike the AutoLISP entmod function, wd_dbx_entmod requires the object (DXF code 5) to be in elist. The ename -1 DXF code is ignored.<br>For entity fields with floating-point values (such as thickness), wd_dbx_entmod accepts integer values and converts them to floating point. Similarly, if you supply a floating for an integer entity field (such as color number), wd_dbx_entmod truncates it and converts it to an integer. |
|-------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

Notes

You can pass a list of lists of entity definiton data to modify several entities in a single call to this metod.

file

nil

Uses the current drawing.

filename

The full path and file name of the file to query.

filehandle

The handle returned from a call to [wd\\_dbx\\_open](#). Note that the file must have been opened with the "w" mode set.

Return Value

T if successful.

The wd\_dbx\_entmod function updates database information for the entity name specified by the 5 group in elist. The primary mechanism through which these DBX functions update the data! retrieving entities with wd\_dbx\_entget, modifying the list defining an entity, and updating the entity in the database with wd\_dbx\_entmod. The wd\_dbx\_entmod function can modify both gra nongraphical objects.

See Also

[WD\\_DBX\\_ENTGET](#) and [WD\\_DBX\\_ENTMAKE](#)

Example

```
(setq fhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "w"))
(if fhand
  (progn
    (setq ring (list (cons 0 "CIRCLE") (cons 8 "0") (list 10 8.5 7.0 0.0) (cons 40 1.0)))
    (if (and (setq hand (wd_dbx_entmake ring fhand))(setq en (wd_dbx_entget hand fhand))
      (progn
        (setq ring (subst (cons 40 2.5) (assoc 40 en) en))
        (wd_dbx_entmod ring fhand)
      )
    )
    (wd_dbx_close fhand T)
  )
)
```

```
(wd_dbx_entmod en "c:/tmp/demo04.dwg")
)
)
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_DBX\_ENTNEXT

[LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_DBX\_ENTNEXT

(wd\_dbx\_entnext handle file)

Parameters

handle

nil Returns the entity handle of the first nondeleted entity in the database

handle Returns the entity handle of the first nondeleted entity following handle in the database

file

nil Uses the current drawing.

filename The full path and file name of the file to query.

filehandle The handle returned from a call to [wd\\_dbx\\_open](#). Note that the file must have been opened with the "w" mode set.

Return Value

If wd\_dbx\_entnext is called with no handle argument, it returns the entity handle of the first nondeleted entity in the database. If a handle argument is supplied to wd\_dbx\_entnext, the function returns the entity handle of the first nondeleted entity following handle in the database. If there is no next entity in the database, it returns nil. The entnext function returns both main entity and subentities.

Examples

```
(setq e1 (wd_dbx_entnext)) ; Sets e1 to the handle of the first entity in the current drawing
(setq fhand (wd_dbx_open "c:/tmp/demo03.dwg" "r"))
(setq e1 (wd_dbx_entnext fhand))
(setq e2 (wd_dbx_entnext e1 fhand)) ; Sets e2 to the handle of the entity following e1
(wd_dbx_close fhand nil)
```

Notes

You can access the internal structure of complex entities by walking through the subentities with wd\_dbx\_entnext. Once you obtain a subentity's handle, you can operate on it like any other entity. To obtain the handle of a subentity with wd\_dbx\_entnext, you can find the parent entity by stepping forward with wd\_dbx\_entnext until a sequential entity is found, then extracting the -2 group code from the entity, which is the main entity's name.

[LISP](#)

Links

[LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025; AutoLISP Reference

WD\_DBX\_FILE\_FROM\_HANDLE

[Example](#) [LISP](#) [Send Feedback](#)

Description

WD\_DBX\_FILE\_FROM\_HANDLE

(wd\_dbx\_file\_from\_handle file [flag])

| Parameters                                                                             |                                                                                  |
|----------------------------------------------------------------------------------------|----------------------------------------------------------------------------------|
| file                                                                                   |                                                                                  |
| nil                                                                                    | Returns the name of the current drawing.                                         |
| filehandle                                                                             | The handle returned from a call to <a href="#">wd_dbx_open</a> .                 |
|                                                                                        |                                                                                  |
| flag                                                                                   | If T returns the file name in <a href="#">LISP</a> format (all slashes forward). |
|                                                                                        |                                                                                  |
| Return Value                                                                           |                                                                                  |
| If successful the file name associated with the file handle. Otherwise it returns nil. |                                                                                  |

Example

```
(setq fhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "r"))
(if fhand
  (progn
    (setq fname (wd_dbx_file_from_handle fhand T))
    (wd_dbx_close fhand nil)
  )
)
or
;; get the name of the current drawing
(wd_dbx_file_from_handle nil)
```

Module

[LISP](#)

Links

[Example](#), [LISP](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025; AutoLISP Reference

WD\_DBX\_GET\_TABLESTYLE

[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

| Parameters |                                                                  |
|------------|------------------------------------------------------------------|
| file       |                                                                  |
| nil        | Uses the current drawing.                                        |
| filename   | The full path and file name of the file to query.                |
| filehandle | The handle returned from a call to <a href="#">wd_dbx_open</a> . |
|            |                                                                  |
| tablestyle | If given, the name of the preexisting table style in file.       |

Return Value

If successful, the tablestyle entries are returned as a list of two lists. The first list is the names of the tablestyles, and the second list is a corresponding dotted pairs of DXF-type codes and describing the style. If there are no tablestyles, nil is returned. Deleted tablestyle entries are never returned.

The wd\_dbx\_get\_tablestyle function gets a list of tablestyle information from the named file.

See Also

[WD\\_DBX\\_TBLSEARCH](#) and [WD\\_DBX\\_GET\\_COPY\\_TABLESTYLE](#)

Example

```
(setq hand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "r"))
(if (> hand 0)
  (progn
    (setq ts (wd_dbx_get_tablestyle hand "My Table Style"))
    (wd_dbx_close hand nil)
  )
)
or
(wd_dbx_get_tablestyle "c:/tmp/demo03.dwg")
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Description

**WD\_DBX\_GET\_XREF**

(wd\_dbx\_get\_xref handle file)



|            |                                                                  |
|------------|------------------------------------------------------------------|
| file       |                                                                  |
| nil        | Uses the current drawing.                                        |
| filename   | The full path and file name of the file to query.                |
| filehandle | The handle returned from a call to <a href="#">wd_dbx_open</a> . |

|                                                   |                        |                                                           |
|---------------------------------------------------|------------------------|-----------------------------------------------------------|
| Return Value                                      |                        |                                                           |
| A list containing the XREF information of handle. |                        |                                                           |
|                                                   |                        |                                                           |
| List Position                                     | Attribute or Xdata tag | Comment                                                   |
| 0                                                 | XREF                   | Attribute                                                 |
| 1                                                 | XREFNO                 | Attribute                                                 |
| 2                                                 | XREFNC                 | Attribute                                                 |
| 3                                                 | CONTACT                | Attribute                                                 |
| 4                                                 | VIA_WD_MAXNO           | Xdata (also matches CIM_WD_MAXNO)                         |
| 5                                                 | VIA_WD_MAXNC           | Xdata (also matches CIM_WD_MAXNC)                         |
| 6                                                 | VIA_WD_MAXNONC         | Xdata (also matches CIM_WD_MAXNONC)                       |
| 7                                                 | VIA_WD_XREF            | Xdata (also matches CIM_WD_XREF)                          |
| 8                                                 | MTEXT                  | This is the MTEXT found using the handle from position 7  |
| 9                                                 | VIA_WD_XREFNO          | Xdata (also matches CIM_WD_XREFNO)                        |
| 10                                                | MTEXT                  | This is the MTEXT found using the handle from position 9  |
| 11                                                | VIA_WD_XREFNC          | Xdata (also matches CIM_WD_XREFNC)                        |
| 12                                                | MTEXT                  | This is the MTEXT found using the handle from position 11 |
| 13                                                | nil                    | Legacy SHEET from WD_M block - always nil                 |
| 14                                                | nil                    | Legacy SHEETDWGNAME from WD_M block - always nil          |

See Also

[WD\\_DBX\\_ENTGET](#) and [WD\\_DBX\\_ENTATTR](#)

Example

```
(setq fhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "r"))
(if fhand
  (progn
    (setq xrefinfo (wd_dbx_get_xref "8f3" fhand)
    (wd_dbx_close fhand nil))
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference

WD\_DBX\_GETVAR

[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_DBX\_GETVAR

(wd\_dbx\_getvar file variable)

Parameters

file

nil Uses the current drawing.

filename The full path and file name of the file to query.

filehandle The handle returned from a call to [wd\\_dbx\\_open](#).

variable One of the variable names recognized by AutoCAD

Return Value

If successful the value of the variable; otherwise it returns nil.

See Also

[WD\\_DBX\\_SETVAR](#)

Example

```
(setq fhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "r"))
(if fhand
  (progn
    (setq txtsize (wd_dbx_getvar fhand "TEXTSIZE"))
    (wd_dbx_close fhand nil)
  )
)
or
(wd_dbx_getvar "c:/tmp/demo04.dwg" "TEXTSIZE")
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Description

WD\_DBX\_GROUP\_CREATE

(wd\_dbx\_group\_create file group desc handles)

| Parameters                                  |                                                                                                                                  |
|---------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| file                                        |                                                                                                                                  |
| nil                                         | Uses the current drawing.                                                                                                        |
| filename                                    | The full path and file name of the file to query.                                                                                |
| filehandle                                  | The handle returned from a call to <a href="#">wd_dbx_open</a> . Note that the file must have been opened with the "w" mode set. |
| group                                       | The name of the group or "*" to have a name created for you.                                                                     |
| desc                                        | The description of the group. Can be nil or "" to add an empty description.                                                      |
| handles                                     | A single handle such as "E43" or a list of handles such as (list "130" "133" "DA"). If this is nil the function fails.           |
| Return Value                                |                                                                                                                                  |
| T if the command was executed successfully. |                                                                                                                                  |

See Also

[WD\\_DBX\\_GROUP\\_DELETE](#)

Example

```
(setq fhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "w"))
(if fhand
  (progn
    (if (wd_dbx_group_create fhand "MyGroup" "" (list "4EF" "32" "17E"))
      (wd_dbx_close fhand T) ; save changes
      (wd_dbx_close fhand nil))
  )
)
or
(wd_dbx_group_create "c:/tmp/demo04.dwg" "NewGroup" nil "E3F")
or
(wd_dbx_command nil "*" "General Group Desc" "e3f")
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

| Parameters                                  |                                                                                                                                   |
|---------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| file                                        |                                                                                                                                   |
| nil                                         | Uses the current drawing.                                                                                                         |
| filename                                    | The full path and file name of the file to query.                                                                                 |
| filehandle                                  | The handle returned from a call to <a href="#">wd_dbx_open</a> . Note that the file must have been opened with the "w" mode set.  |
|                                             |                                                                                                                                   |
| group                                       | The name of the group or "*" to have a name created for you.                                                                      |
| desc                                        | The description of the group. Can be nil or "" to add an empty description.                                                       |
| handles                                     | A single handle such as "E43" or a list of handles such as (list "130" "133" "DA"). If this is nil the keep parameter is ignored. |
| keep                                        | If this is T or 1 the list of handles is kept in the group and all else is deleted.                                               |
|                                             |                                                                                                                                   |
| Return Value                                |                                                                                                                                   |
| T if the command was executed successfully. |                                                                                                                                   |

See Also

[WD\\_DBX\\_GROUP\\_CREATE](#)

Example

```
(setq fhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "w"))
(if fhand
  (progn
    (if (wd_dbx_group_delete fhand "MyGroup" (list "4EF" "17E"))
      (wd_dbx_close fhand T) ; save changes
      (wd_dbx_close fhand nil))
  )
)
or delete everything except the "E3F" entity and preserve the group name
(wd_dbx_group_delete "c:/tmp/demo04.dwg" "NewGroup" "E3F" T)
or delete everything except the "E3F" and "4A5" entities in the named group in the current drawing
(wd_dbx_command nil "DemoGroup" (list "e3f" "4a5") T)
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Description

| Parameters                                                                                                                                                                              |                                                                                                                                                                                       |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| handle                                                                                                                                                                                  | The handle of the entity in the drawing. Note that an ename is only valid for the same session of a file open operation. Therefore this mode shou used with the wd_dbx_open function. |
| filehandle                                                                                                                                                                              |                                                                                                                                                                                       |
| nil                                                                                                                                                                                     | Uses the current drawing.                                                                                                                                                             |
| filehandle                                                                                                                                                                              | The handle returned from a call to <a href="#">wd_dbx_open</a> .                                                                                                                      |
|                                                                                                                                                                                         |                                                                                                                                                                                       |
| Return Value                                                                                                                                                                            |                                                                                                                                                                                       |
| If successful, wd_dbx_handent returns the entity name associated with handle. If handent is passed an invalid handle or a handle not used by any entity in the drawing, it returns nil. |                                                                                                                                                                                       |

See Also

[WD\\_DBX\\_ENTGET](#)

Example

```
(setq fhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "r"))
(if fhand
  (progn
    (wd_dbx_handent "8f3" fhand)
    (wd_dbx_close fhand T)
  )
)
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback](#)  
AutoCAD Electrical 2025: AutoLISP Reference  
**WD\_DBX\_MTEXT**  
[Example](#) [LISP](#) [Send Feedback](#)

Description

**WD\_DBX\_MTEXT**

(wd\_dbx\_mtext file handle value)

| Parameters |                                                   |
|------------|---------------------------------------------------|
| file       |                                                   |
| nil        | Uses the current drawing.                         |
| filename   | The full path and file name of the file to query. |

Return Value

If successful the value of the original text before it was changed; nil upon failure.

Example

```
(setq fhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "w"))
(if fhand
  (progn
    (wd_dbx_mtext fhand "8f3" "The new text")
    (wd_dbx_close fhand T)
  )
)
or
(wd_dbx_mtext "c:/tmp/demo04.dwg" "4c2" "Something to write about")
```

Module

[LISP](#)

Links

[Example](#), [LISP](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference

**WD\_DBX\_NAMEDOBJDICT**  
[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

**WD\_DBX\_NAMEDOBJDICT**

(wd\_dbx\_namedobjdict filename)

Parameters

file

nil Uses the current drawing.

filename The full path and file name of the file to query.

filehandle The handle returned from a call to [wd\\_dbx\\_open](#).

Return Value

nil - named object dictionary not found in the named file.  
The handle of the named object dictionary.

[WD\\_DBX\\_DICTNEXT](#)

Example

```
(setq nod (wd_dbx_namedobjdict "C:/Projects/Demo/demo03.dwg"))
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_DBX\_OPEN

[Example](#) [LISP](#) [Send Feedback](#)

Description

WD\_DBX\_OPEN

```
(wd_dbx_open filename mode [flag])
```

Parameters

|          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| filename | The full path and file name of the DWG file to be opened.                                                                                                                                                                                                                                                                                                                                                                                                                |
| mode     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| "w"      | Open the file for both read and write operations. This operation requires exclusive use of the file.                                                                                                                                                                                                                                                                                                                                                                     |
| "r"      | Open the file for read access only.                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| flag     | If T then the DBX environment will be optimized for functions that need to do spatial searches such as <a href="#">wd_dbx_ssoet</a> and <a href="#">wd_dbx_wnum_pos</a> . Note: If you use t must note use any AutoCAD commands or functions that will modify the drawing outside the contol of the WD_DBX_* environment (i.e. if the drawing is open in and in the foreground you must not use any <a href="#">LISP</a> functions or commands that modify the drawing). |

Return Value

nil - file could not be opened.  
An integer value greater than zero which is the file handle to be used is subsequent calls to this file.

Note that this function can be used on a file that is already open in the AutoCAD session as well as files that are not currently open.

Example

```
(setq fhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "w"))  
(if (fhand)  
  (progn  
    ...  
    (wd_dbx_close fhand T)  
  )  
)
```

See also [WD\\_DBX\\_CLOSE](#)

Module

What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

## WD\_DBX\_PUMP\_MSGS

[Example](#) [LISP](#) [Send Feedback](#)

### Description

#### WD\_DBX\_PUMP\_MSGS

(wd\_dbx\_pump\_msgs)

This function is used to allow ACADE time to process any pending messages in the message queue. Typically you would call this if you are doing a long tight loop.

| Return Value                                                                                                                                                       |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| If this function returns nil the user has initiated a Quit sequence and you should probably try to unwrap your code from whatever it is doing (not easy in Lisp!). |

### Example

```
(foreach n verylongn
  (wd_dbx_pump_msgs)
  ; do the rest of the processing...
)
```

### Module

[LISP](#)

### Links

[Example](#), [LISP](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

## WD\_DBX\_SETVAR

[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

### Description

#### WD\_DBX\_SETVAR

(wd\_dbx\_setvar file variable value)

| Parameters |                                                                                                               |
|------------|---------------------------------------------------------------------------------------------------------------|
| file       |                                                                                                               |
| nil        | Uses the current drawing.                                                                                     |
| filename   | The full path and file name of the file to query.                                                             |
| filehandle | The handle returned from a call to <a href="#">wd_dbx_open</a> . Note: File must be opened with the "w" flag. |
|            |                                                                                                               |
| variable   | One of the variable names recognized by AutoCAD                                                               |
| value      | Thes value of the enviornment variable.                                                                       |



See Also

[WD\\_DBX\\_GETVAR](#)

Example

```
(setq fhand (wd_dbx_open "C:/Projects/Demo/demo03.dwg" "w"))
(if fhand
  (progn
    (wd_dbx_setvar fhand "TEXTSIZE" 1.25)
    (wd_dbx_close fhand T)
  )
)
or
(wd_dbx_setvar "c:/tmp/demo04.dwg" "TEXTSIZE" 2.5)
```

Module

[LTSP](#)

Links

[Example](#), [LTSP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_DBX\_SSGET

[Example](#) [LTSP](#) [See Also](#) [Send Feedback](#)

Description

WD\_DBX\_SSGET

(wd\_dbx\_ssget file method args)

| Parameters                                                                                                   |                                                                                                     |
|--------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|
| file                                                                                                         |                                                                                                     |
| nil                                                                                                          | Uses the current drawing.                                                                           |
| filename                                                                                                     | The full path and file name of the file to query.                                                   |
| filehandle                                                                                                   | The handle returned from a call to <a href="#">wd_dbx_open</a> .                                    |
| method                                                                                                       | The currently supported methods of selection are "X" "XX" (to get all plus attributes), "C" and "W" |
| args                                                                                                         | These are the arguments and filter supported by the above mentioned method.                         |
| Return Value                                                                                                 |                                                                                                     |
| If successful a list of handles to the objects that match the method and the args. Otherwise it returns nil. |                                                                                                     |

Notes

To get ultimate performance with this function make sure you open the file with the optional flag set to T to the [wd\\_dbx\\_open](#) function.

```
;; get a list of blocks with the matching attributes
(wd_dbx_ssget nil "_XX" '((0 . "ATTRIB") (2 . "TAG*") (1 . "J3"))))
;; blocks not named WD_DOT, WD_M, WD_PNLM, WD_MLRH and that
;; are named either WD* or H* or V*
(wd_dbx_ssget nil "_X" '((-4 . "<AND")(0 . "INSERT")(2 . "~WD_DOT")(2 . "~WD_M")(2 . "~WD_PNLM")(2 . "~WD_MLRH") (-4 . "<OR")(2 . "WD*")(2 . "H*") (2 . "V*") (-4 . "OR>") (-4 . "A
;; get the entities in the crossing
(wd_dbx_ssget "c:/tmp/demo03.dwg" "C" '(6 6) '(10 10))
;; get the entities in the window
(setq fhand (wd_dbx_open "c:/tmp/demo03.dwg" "r" T))
(wd_dbx_ssget fhand "W" '(6 6) '(10 10))
(wd_dbx_close fhand)
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_DBX\_TBLNEXT

[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_DBX\_TBLNEXT

(wd\_dbx\_tblnext table rewind file)

Parameters

|            |                                                                                                                                                                                                                                                                                   |
|------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| table      | A string that identifies the symbol table to be searched. This argument is not case-sensitive.                                                                                                                                                                                    |
| rewind     | If non-zero resets the wd_dbx_dictnext function to start at the beginning. Note: The rewind flag can only be honored in a file that has been opened using <a href="#">wd_dbx_open</a> . All other uses of this function will only return the first entry in the named dictionary. |
| file       |                                                                                                                                                                                                                                                                                   |
| nil        | Uses the current drawing.                                                                                                                                                                                                                                                         |
| filename   | The full path and file name of the file to query.                                                                                                                                                                                                                                 |
| filehandle | The handle returned from a call to <a href="#">wd_dbx_open</a> .                                                                                                                                                                                                                  |

Return Value

If a symbol table entry is found, the entry is returned as a list of dotted pairs of DXF-type codes and values. If there are no more entries in the table, nil is returned. Deleted table entries : returned.

See Also

[WD\\_DBX\\_TBLSEARCH](#), [WD\\_DBX\\_ENTGET](#), [WD\\_DBX\\_ENTATTR](#) and [WD\\_DBX\\_COPY\\_TABLESTYLE](#)

```
(progn
  (wd_dbx_tblsearch "BLOCK" "WD_M" 1 fhand)
  (wd_dbx_tblnext "BLOCK" nil fhand)
  (wd_dbx_close fhand nil))
)
)
or
(wd_dbx_tblnext "block" nil "c:/tmp/demo04.dwg")
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference  
**WD\_DBX\_TBLSEARCH**  
[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_DBX\_TBLSEARCH

(wd\_dbx\_tblsearch table symbol setnext file)

| Parameters |                                                                                                                                                                                                                                                                                                                                                                                                                            |
|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| table      | A string that identifies the symbol table to be searched. This argument is not case-sensitive.                                                                                                                                                                                                                                                                                                                             |
| symbol     | A string identifying the symbol name to be searched for. This argument is not case-sensitive.                                                                                                                                                                                                                                                                                                                              |
| setnext    | If this argument is not nil, the wd_dbx_tblnext entry counter is adjusted so the following wd_dbx_tblnext call returns the entry after the one returned by this wd_dbx_tblsearch call. Otherwise, wd_dbx_tblsearch has no effect on the order of entries retrieved by wd_dbx_tblnext. Note: This parameter is only honored in wd_dbx_tblsearch function calls within a wd_dbx_open and wd_dbx_close sequence of functions. |
| file       |                                                                                                                                                                                                                                                                                                                                                                                                                            |
| nil        | Uses the current drawing.                                                                                                                                                                                                                                                                                                                                                                                                  |
| filename   | The full path and file name of the file to query.                                                                                                                                                                                                                                                                                                                                                                          |
| filehandle | The handle returned from a call to <a href="#">wd_dbx_open</a> .                                                                                                                                                                                                                                                                                                                                                           |

| Return Value                                                                                                                                                                                                  |  |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| If a symbol table entry is found, the entry is returned as a list of dotted pairs of DXF-type codes and values. If there are no more entries in the table, nil is returned. Deleted table entries : returned. |  |

See Also

[WD\\_DBX\\_TBLNEXT](#), [WD\\_DBX\\_ENTGET](#), [WD\\_DBX\\_ENTATTR](#) and [WD\\_DBX\\_COPY\\_TABLESTYLE](#)

Example

```
(wd_dbx_close fhand nil))
)
)
or
(wd_dbx_tblsearch "block" "WD_M" 0 "c:/tmp/demo04.dwg")
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_DBX\_WNUM\_POS

[LISP](#) [Send Feedback](#)

Description

WD\_DBX\_WNUM\_POS

(wd\_dbx\_wnum\_pos file wnblock wire attribute leader vert trap)

| Parameters               |                                                                                                                                                                                                                                                                            |
|--------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| file                     |                                                                                                                                                                                                                                                                            |
| nil                      | Uses the current drawing.                                                                                                                                                                                                                                                  |
| filename                 | The full path and file name of the file to query.                                                                                                                                                                                                                          |
| filehandle               | The handle returned from a call to <a href="#">wd_dbx_open</a> .                                                                                                                                                                                                           |
|                          |                                                                                                                                                                                                                                                                            |
| wnblock                  | The handle of the wire number block                                                                                                                                                                                                                                        |
| wire                     | The handle of the "wire" (line entity) associated with the block                                                                                                                                                                                                           |
| attribute                | The handle to the wire number attribute (WIRENO or WIRENOF)                                                                                                                                                                                                                |
| leader                   | The handle of the leader or nil.                                                                                                                                                                                                                                           |
| vert                     | "1" if the wire is vertical, "0" if horizontal, nil if angled.                                                                                                                                                                                                             |
| trap                     | The drawing configured trap distance (set in GBL_wd_trp if the drawing configurations have been read).                                                                                                                                                                     |
|                          |                                                                                                                                                                                                                                                                            |
| Return Value             |                                                                                                                                                                                                                                                                            |
| nil                      | Could not find a position for the attribute that doesn't clash with other entities.                                                                                                                                                                                        |
| (nil nil nil)            | Leave the wnblock (and leader if it has one) where it is.                                                                                                                                                                                                                  |
| ((x y z) nil nil)        | Move the wnblock (and leader) to this new position.                                                                                                                                                                                                                        |
| (nil (x y z) (x2 y2 z2)) | Erase the existing leader. Move the attribute to (x y z) and draw a new leader from wnblock insertion point to (x2 y2 z2). Note: if the attribute is not le the (x y z) is the alignment point of the attribute (i.e. the DXF 11 point), otherwise it is the DXF 10 point. |

The purpose of this function is to find a position for the wire number attribute that does not clash with any entities associated. This is a REX created by the [LISP](#) function and named wdnum\_pos.lsp

Module

[LISP](#)

Links

[LISP](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference  
**WD\_OLEDB\_COMMAND**  
[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

**WD\_OLEDB\_COMMAND**

([wd\\_oledb\\_command](#) dbfile sql\_stmt)  
Use this function to execute any valid SQL statement.

| Parameters       |                                                                                                                                            |
|------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| dbfile           | The full path and filename of the Microsoft Access database.                                                                               |
| sql_stmt         | A properly formatted SQL statement. Note that this function cannot be used to return results. Use <a href="#">WD_OLEDB_SELECT</a> instead. |
| Return Value     |                                                                                                                                            |
| T if successful. |                                                                                                                                            |

See Also

[WD\\_OLEDB\\_SELECT](#) and [WD\\_OLEDB\\_DELETE](#)

Example

```
(setq dbnam (wd_pds_get_project_db (ace\_getactiveproject)))  
(if dbnam  
  (progn  
    (wd_oledb_execute dbnam "DROP TABLE [COMP]")  
  )  
)
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference  
**WD\_OLEDB\_DELETE**  
[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

| Parameters |                                                                                                                                                                |
|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| dbfile     | The full path and filename of the Microsoft Access database.                                                                                                   |
| table      | The name of the table to be modified. Note that it is recommended that you enclose each table name in [ ] so as to avoid conflicts with SQL reserved keywords. |
| filter     | An optional filter statement. This can be any SQL statement that forms the WHERE clause. If no filter is supplied all rows in the table are removed.           |

DELETE FROM

***table***

WHERE

***filter***

Return Value

T if successful.

See Also

[WD\\_OLEDB\\_INSERT](#)

Example

```
(setq dbnam (wd_pds_get_project_db (ace\_getactiveproject)))  
(if dbnam  
  (progn  
    (wd\_oledb\_delete dbnam "[COMP]" "[DWGIX]='1'")  
  )  
)
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference  
**WD\_OLEDB\_FIELDSPEC**  
[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

**WD\_OLEDB\_FIELDSPEC**

(wd\_oledb\_fieldspec dbfile tables [columns])  
Use this function to get a selection set of data from the database.

| Parameters |                                                                                                                                                          |
|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
| dbfile     | The full path and filename of the Microsoft Access database.                                                                                             |
| tables     | A list of tables to be queried. Note that it is recommended that you enclose each table name in [ ] so as to avoid conflicts with SQL reserved keywords. |

Return Value

Each table's metadata is represented as a list, and each column its type and size as a list within the list. Thus for multiple tables, the return is a list of lists of lists.

Result Field Spec Code

|     |                                                      |
|-----|------------------------------------------------------|
| "L" | LONG Integral datatype                               |
| "I" | INT Integral datatype                                |
| "R" | NUMERIC datatype (real, double precision, float etc) |
| "M" | MEMO datatype (longvarchar, wchar etc)               |
| "S" | CHAR datatype (varchar, char, etc)                   |
| "B" | BOOL datatype                                        |
| "D" | DATE datatype (timestamp, date, datetime, etc)       |
| "C" | CURRENCY datatype                                    |

See Also

[WD\\_OLEDB\\_SELECT](#)

Example

```
(setq dbnam (wd_pds_get_project_db (ace\_getactiveproject)))
(if dbnam
  (progn
    (setq data (wd_oledb_fieldspec dbnam "[COMP]"))
    ;; result: (((("DWGIX" "S" 8) ("PAR1_CHLD2" "S" 3) ("FAMILY" "S" 8)...
  )
)
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference  
**WD\_OLEDB\_INSERT**  
[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_OLEDB\_INSERT

(wd\_oledb\_insert dbfile table values)  
Use this function to deletes the data in the named table using the optional filter to filter specific records.

|        |                                                                                                                                                              |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
| table  | The name of the table to be modified. Note that it is recommended that you enclose each table name in [ ] so as to avoid conflicts with SQL reserved keyword |
| values | A list of a list of list of column value pairs. Thus you can insert multiple records in one call to this function.                                           |

```
INSERT INTO table
(values_column_list)
VALUES
(values_values)
```

|                  |
|------------------|
| Return Value     |
| T if successful. |

See Also

[WD\\_OLEDB\\_SELECT](#) and [WD\\_OLEDB\\_DELETE](#)

Example

```
(setq dbnam (wd_pds_get_project_db (ace\_getactiveproject)))
(if dbnam
  (progn
    ;; insert two new rows into the TEST table
    (wd_oledb_insert dbnam "[TEST]" '(((("COL1" "test")("COL2" 100))((("COL1" "test1")("COL2" 101))))))
  )
)
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_OLEDB\_SELECT

[Example](#) [LISP](#) [Send Feedback](#)

Description

WD\_OLEDB\_SELECT

```
(wd\_oledb\_select dbfile tables columns [filter] [sort] [mode])
```

or

```
(wd\_oledb\_select dbfile statement)
```

Use this function to get a selection set of data from the database.

|            |                                                                                                                                                                                                           |
|------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Parameters |                                                                                                                                                                                                           |
| dbfile     | The full path and filename of the Microsoft Access database.                                                                                                                                              |
| tables     | A list of tables to be queried. Note that it is recommended that you enclose each table name in [ ] so as to avoid conflicts with SQL reserved keywords. This can   statement that forms the FROM clause. |



|      |                                                                                                                                                                        |
|------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| mode | If bit 1 is set and columns is a single column, the data will be returned as a single list of values.<br>If bit 2 is set all column data will be converted to strings. |
|------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|           |                                 |
|-----------|---------------------------------|
| statement | Any valid SQL SELECT statement. |
|-----------|---------------------------------|

SELECT  
***columns***  
FROM  
***tables***  
WHERE  
***filter***  
ORDER BY  
***sort***

Return Value

Each row is represented as a list, and each column as a value within the list. Thus for multiple rows, the return is a list of lists. The exception is if mode bit 1 is set and the selection is a single column, in which case the result is a single list values.

Example

```
(setq dbnam (wd_pds_get_project_db (ace\_getactiveproject)))
(if dbnam
  (progn
    (setq data (wd\_qladb\_select dbnam "[COMP]" "[DWGIX],[TAGNAME]" "[TAGNAME] LIKE 'CR%' "[DWGIX]"))

    ;; more complex example showing table join
    (setq tables "[COMP] C,[COMPPINS] CO")
    (setq columns "C.DWGIX,C.TAGNAME,CO.WIRENO,CO.TERM")
    (setq filter "C.DWGIX = CO.DWGIX AND C.HDL = CO.HDL AND CO.TERM IS NOT NULL")
    (setq sort "C.DWGIX ASC, C.TAGNAME DESC")
    (setq data (wd\_qladb\_select dbnam tables columns filter sort))
    ;; result: (("2" "XF224" "" "H4") ("2" "XF224" "" "H4") ("2" "XF224" "" "X2")...)
  )
)

;; get a unique list of manufacturers from Selector Switch table
(setq dbnam (wd_cat3_figure_catmdb_fnam))
(if dbnam
  (progn
    (setq data (wd\_qladb\_select dbnam "[SS]" "DISTINCT [MANUFACTURER]" "" "" 1))
    ;; result: ("AB" "AUTOMATIONDIRECT" "GE" "LEGRAND" "SQD")
  )
)

;; get a list of drawing index numbers
(setq dbnam (wd_pds_get_project_db (ace\_getactiveproject)))
(if dbnam
  (progn
    (setq data (wd\_qladb\_select dbnam "[PDS_DWGINDEX]" "[DWGINDEX]" "" "" 1))
    ;; result: (1 2 3 4 5)
    (setq data (wd\_qladb\_select dbnam "[PDS_DWGINDEX]" "[DWGINDEX]" "" "" 2))
    ;; result: (("1") ("2") ("3") ("4") ("5"))
    (setq data (wd\_qladb\_select dbnam "[PDS_DWGINDEX]" "[DWGINDEX]" "" "" 3))
    ;; result: ("1" "2" "3" "4" "5")
  )
)

(setq dbnam (wd_pds_get_project_db (ace\_getactiveproject)))
(if dbnam
```

)

Module

[LISP](#)

Links

[Example](#), [LISP](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback](#)

AutoCAD Electrical 2025: AutoLISP Reference

WD\_PDS\_ACTIVATE\_PROJECT

[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_PDS\_ACTIVATE\_PROJECT

(wd\_pds\_activate\_project project)

Parameters

|         |                                                                                                           |
|---------|-----------------------------------------------------------------------------------------------------------|
| project | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |
|---------|-----------------------------------------------------------------------------------------------------------|

See Also

[PmSetActive](#)

Example

(wd\_pds\_activate\_project "C:/Projects/Demo/wddemo.wdp")

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback](#)

AutoCAD Electrical 2025: AutoLISP Reference

WD\_PDS\_ADD\_FILES

[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_PDS\_ADD\_FILES

(wd\_pds\_add\_files project filename)

or

(wd\_pds\_add\_files project (list filename1 filename2 filename3 ...))

Parameters

|         |                                                                                                           |
|---------|-----------------------------------------------------------------------------------------------------------|
| project | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |
|---------|-----------------------------------------------------------------------------------------------------------|

Return Value

true - the project was able to locate the file(s) and add them to the list of files being monitored.

See Also

[PmMonitorFile](#), [PmMonitorFiles](#) and [WD\\_PDS\\_DROP\\_FILES](#)

Example

```
(wd_pds_add_files "C:/Projects/Demo/wddemo.wdp" "C:/Projects/Demo/demo01.dwg")  
or  
(wd_pds_add_files "C:/Projects/Demo/wddemo.wdp"  
  (list "C:/Projects/Demo/demo02.dwg" "C:/Projects/Demo/demo03.dwg"))
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference

WD\_PDS\_ATTRIBUTE

[Example](#) [LISP](#) [Send Feedback](#)

Description

WD\_PDS\_ATTRIBUTE

(wd\_pds\_attribute text)

Parameters

|      |                           |
|------|---------------------------|
| text | The string value to test. |
|------|---------------------------|

Return Value

T if the text is a recognized AutoCAD Electrical attribute.

The wd\_pds\_attribute function is used to determine in a text string is a recognized attribute for an AutoCAD Electrical symbol .

Example

(wd\_pds\_attribute "LOC")

Module

[LISP](#)

Links

[Example](#), [LISP](#)

**WD\_PDS\_CLOSE\_PROJECT**

(wd\_pds\_close\_project project)

| Parameters |                                                                                                           |
|------------|-----------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |

**See Also**

[PmCloseProject](#)

**Example**

(wd\_pds\_close\_project "C:/Projects/Demo/wddemo.wdp")

**Module**

[LISP](#)

**Links**

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference

**WD\_PDS\_CMDACTIVE**

[Example](#) [LISP](#) [Send Feedback](#)

**Description**

**WD\_PDS\_CMDACTIVE**

(wd\_pds\_cmdactive)

| Return Value |                                              |
|--------------|----------------------------------------------|
|              | T if the a command is active, otherwise nil. |

This function tests to see if PDS is currently running a command that would require the use of the AutoCAD command processor such as [ACE\\_SCRIPT](#).  
This is typically used to know whether certain program flow should continue.

**Example**

(if (or (wd\_pds\_cmdactive) (= (logand (getvar "CMDACTIVE") 4) 4)) (princ "\nscript active"))

**Module**

[LISP](#)

**Links**

[Example](#), [LISP](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference

**WD\_PDS\_DROP\_FILES**

```
(wd_pds_drop_files project filename)
or
(wd_pds_drop_files project (list filename1 filename2 filename3 ...))
```

| Parameters    |                                                                                                           |
|---------------|-----------------------------------------------------------------------------------------------------------|
| project       | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |
| filename      | The name of the DWG file to remove from the list being monitored.                                         |
| filename1 ... | A list of filenames to remove.                                                                            |

| Return Value                                                                                            |
|---------------------------------------------------------------------------------------------------------|
| true - the project was able to locate the file(s) and remove them to the list of files being monitored. |

See Also

[PmMonitorFile](#), [PmMonitorFiles](#) and [WD\\_PDS\\_ADD\\_FILES](#)

Example

```
(wd_pds_drop_files "C:/Projects/Demo/wddemo.wdp" "C:/Projects/Demo/demo01.dwg")
or
(wd_pds_drop_files "C:/Projects/Demo/wddemo.wdp"
(list "C:/Projects/Demo/demo02.dwg" "C:/Projects/Demo/demo03.dwg"))
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference  
**WD\_PDS\_FILES\_LOCKED**  
[LISP](#) [Send Feedback](#)

Description

**WD\_PDS\_FILES\_LOCKED**

```
(wd_pds_fileslocked)
```

| Return Value                     |
|----------------------------------|
| T if the there are locked files. |

This function tests to see if the server currently has any files locked.

Module

[LISP](#)

AutoCAD Electrical 2025; AutoLISP Reference  
WD\_PDS\_FLUSH\_ACTIVE\_DWG  
[LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_PDS\_FLUSH\_ACTIVE\_DWG

(wd\_pds\_flush\_active\_dwg)  
This function flushes the active drawing to the the scratch database while not actually saving the file.

See Also

[WD\\_PDS\\_FRESHEN\\_PROJECT\\_DB](#) and [WD\\_PDS\\_RESET\\_PROJECT\\_DB](#)

Module

[LISP](#)

Links

[LISP](#) [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025; AutoLISP Reference  
WD\_PDS\_FRESHEN\_PROJECT\_DB  
[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_PDS\_FRESHEN\_PROJECT\_DB

(wd\_pds\_freshen\_project\_db project)

| Parameters |                                                                                                           |
|------------|-----------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |

This function queries the status of the scratch database associated with the named project and will block waiting for the database to be fully updated. It does not force the server to do anythi than query for status information. While the command is blocked, the client will display an "Updating..." progress dialog.

See Also

[WD\\_PDS\\_RESET\\_PROJECT\\_DB](#) and [WD\\_PDS\\_FLUSH\\_ACTIVE\\_DWG](#)

Example

(wd\_pds\_freshen\_project\_db ([ace\\_getactiveproject](#)))

Module

[LISP](#)

Links

[Example](#), [LISP](#) [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025; AutoLISP Reference  
WD\_PDS\_GET\_ACTIVE\_PROJECT  
[LISP](#) [Send Feedback](#)

Module

[LISP](#)

Links

[LISP](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference  
**WD\_PDS\_GET\_FROMTO**  
[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

**WD\_PDS\_GET\_FROMTO**

(wd\_pds\_get\_fromto)

Notes

The function has been deprecated and always returns true.

Return Value

T if the current mode is to use the [ObjectDBX](#) wire extraction implementation. nil if Lisp is to be used.

This function is used to query the toggle between using the [ObjectDBX](#) version of the wire information extraction and the Lisp based scripting process.

See Also

[WD\\_PDS\\_SET\\_FROMTO](#) and [Scripting Environment](#)

Example

(wd\_pds\_get\_fromto)

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference  
**WD\_PDS\_GET\_OPEN\_DWGS**  
[Example](#) [LISP](#) [Send Feedback](#)

Description

**WD\_PDS\_GET\_OPEN\_DWGS**

([wd\\_pds\\_get\\_open\\_dwgs](#) write\_only lisp\_format)

Return Value

A list of open drawings.

This function is used to get a list of open drawing files in the current instance of AutoCAD. The list can be formatted to exclude read-only drawings, and to format the results in Lisp path form

Example

```
(wd_pds_get_open_dwgs T T)
("C:/PROJ/DEMO/DEMO02.DWG")
(wd_pds_get_open_dwgs nil T)
("C:/PROJ/DEMO/DEMO02.DWG" "C:/PROJ/DEMO/DEMO04.DWG")
```

Module

[LISP](#)

Links

[Example](#), [LISP](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference  
WD\_PDS\_GET\_PROJECT\_DB  
[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_PDS\_GET\_PROJECT\_DB

```
(wd_pds_get_project_db project)
```

Parameters

|         |                                                                                                           |
|---------|-----------------------------------------------------------------------------------------------------------|
| project | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |
|---------|-----------------------------------------------------------------------------------------------------------|

See Also

[PmGetProjectDb](#) and [WD\\_PDS\\_GET\\_ACTIVE\\_PROJECT](#)

Example

```
(wd_pds_get_project_db (wd_pds_get_active_project))
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference  
WD\_PDS\_LOCK\_FILES



(wd\_pds\_lock\_files filename)  
or  
(wd\_pds\_lock\_files (list filename1 filename2 filename3 ...))

| Parameters                                                                                                                                                          |                                      |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------|
| filename                                                                                                                                                            | The name of the DWG file to monitor. |
| filename1 ...                                                                                                                                                       | A list of filenames.                 |
| Return Value                                                                                                                                                        |                                      |
| nil - the command was able to locate the file(s) and gain an exclusive write lock on them.<br>(files) - a list of files that could not be locked, or may not exist. |                                      |

Returns

("c:/nosuch.dwg")

See Also

[PmLockFile](#), [PmLockFiles](#) and [WD\\_PDS\\_UNLOCK\\_FILES](#)

Example

(wd\_pds\_lock\_files "C:/Projects/Demo/demo01.dwg")  
or  
(wd\_pds\_lock\_files (list "C:/Projects/Demo/demo02.dwg" "C:/Projects/Demo/demo03.dwg"))  
Error sample:  
(wd\_pds\_lock\_files "c:/nosuch.dwg")

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference  
**WD\_PDS\_OPEN\_PROJECT**  
[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_PDS\_OPEN\_PROJECT

(wd\_pds\_open\_project project mdbfile)

| Parameters |                                                                                                                                                                                                                     |
|------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID.                                                                                                           |
| mdbfile    | The full path and filename of the scratch database associate with this project. If this is nil the PDS client will create a scratch database in the system temporary f structure and associate it with the project. |

See Also

[PmOpenProject](#)

Example

```
(wd_pds_open_project "C:/Projects/Demo/wddemo.wdp" "C:/Projects/Demo/wddemo.mdb")  
or  
(wd_pds_open_project "C:/Projects/Demo/wddemo.wdp" nil)
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_PDS\_PROJECT\_LOADED

[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_PDS\_PROJECT\_LOADED

(wd\_pds\_project\_loaded project)

| Parameters |                                                                                                           |
|------------|-----------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |

This function informs the PDS that all of the files have been loaded and it should perform a database sweep to clean out unreferenced files. Call this function after [adding files](#) to a project dur initialization sequence.

See Also

[WD\\_PDS\\_ADD\\_FILES](#) and [PmProjectLoaded](#)

Example

```
(if (wd_pds_add_files "C:/Projects/Demo/wddemo.wdp"  
  (list "C:/Projects/Demo/demo02.dwg" "C:/Projects/Demo/demo03.dwg"))  
  (wd_pds_project_loaded "C:/Projects/Demo/wddemo.wdp")  
)
```

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

(wd\_pds\_reset\_project\_db project)

| Parameters |                                                                                                           |
|------------|-----------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |

This function will force a rebuild of the scratch database associated with the named project. This is a non-blocking command and will return as soon as the server has been notified of the req

See Also

[WD\\_PDS\\_FRESHEN\\_PROJECT\\_DB](#)

Example

(wd\_pds\_reset\_project\_db ([ace\\_getactiveproject](#)))

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference  
**WD\_PDS\_SET\_FROMTO**  
[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_PDS\_SET\_FROMTO

(wd\_pds\_set\_fromto arg)

Notes

The function has been deprecated and does not change the behavior of PDS.

| Parameters |                                                                                                  |
|------------|--------------------------------------------------------------------------------------------------|
| arg        | If T the PDS version of wire extraction will be used. If nil then the Lisp version will be used. |

| Return Value                            |
|-----------------------------------------|
| T if the mode was successfully changed. |

This function is used to toggle between using the [ObjectDBX](#) version of the wire information extraction and the Lisp based scripting process.

See Also

[WD\\_PDS\\_GET\\_FROMTO](#) and [Scripting Environment](#)

Example

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference  
**WD\_PDS\_SET\_PROJECT\_VAR**  
[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

**WD\_PDS\_SET\_PROJECT\_VAR**

(wd\_pds\_set\_project\_var project var value)

| Parameters |                                                                                                           |
|------------|-----------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |
| var        | The name of the variable, e.g. "IEC"                                                                      |
| value      | The value of the variable. See the <a href="#">appendix</a> for more details.                             |

| Return Value                                    |
|-------------------------------------------------|
| T - the project was found and the variable set. |

See Also

[Project Variables](#) and [PmSetProjectVar](#)

Example

(setq project (wd\_pds\_get\_active\_project))  
(wd\_pds\_set\_project\_var project, "IEC", T)

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference  
**WD\_PDS\_UNLOCK\_FILES**  
[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

**WD\_PDS\_UNLOCK\_FILES**

(wd\_pds\_unlock\_files filename)  
or

|               |                                      |
|---------------|--------------------------------------|
| filename      | The name of the DWG file to monitor. |
| filename1 ... | A list of filenames.                 |

Return Value

nil - the command was able to locate the file(s) and release the lock.  
(files) - a list of files that could not be unlocked. This may be the case for files that were not locked to begin with.

See Also

[PmUnlockFile](#), [PmUnlockFiles](#) and [WD\\_PDS\\_LOCK\\_FILES](#)

Example

(wd\_pds\_unlock\_files "C:/Projects/Demo/demo01.dwg")  
or  
(wd\_pds\_unlock\_files (list "C:/Projects/Demo/demo02.dwg" "C:/Projects/Demo/demo03.dwg"))

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference  
**WD\_PDS\_USE\_ACAD2**  
[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_PDS\_USE\_ACAD2

(wd\_pds\_use\_acad2 arg)

| Parameters |                                                                                                                                   |
|------------|-----------------------------------------------------------------------------------------------------------------------------------|
| arg        | An entry is made in the AcePmClientApp.ini file to tell AutoCAD how to start a helper process the next time AutoCAD is started.   |
| 0 or nil   | Do not use a helper process.                                                                                                      |
| 1 or T     | Use a helper process; start it at the same time as the host process and close it only when the host closes.                       |
| 2          | Use a helper process when required and leave it running until the host process closes.                                            |
| 3          | Use a helper process when required, and leave it running after it has been used. If it sits idle for 5 minutes, close the helper. |
| 4          | Use a helper process when required and close it when finished.                                                                    |

This function is used to enable or disable the startup of a second "helper" instance of AutoCAD when AutoCAD is started.

Notes

Example

(wd\_pds\_use\_acad2 1)

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

WD\_PDS\_WFRM2ALL\_COMPLETE

[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

WD\_PDS\_WFRM2ALL\_COMPLETE

(wd\_pds\_wfrm2all\_complete project value)

| Parameters |                                                                                                                                                               |
|------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| project    | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID.                                                     |
| value      | If T the scratch database From/To WSTAMP in the FILETIME table is marked as up to date. If nil, the FILETIME table is marks as being out of date for all draw |

| Return Value                                                   |  |
|----------------------------------------------------------------|--|
| T - the project and value are valid parameters, otherwise nil. |  |

This function is designed to be called after the WFRM2ALL table has been updated with the information gathered from the [ObjectDBX](#) version of the wire extraction.

See Also

[WD\\_PDS\\_WFRM2ALL\\_REBUILD\\_REQD](#)

Example

(wd\_pds\_wfrm2all\_complete "C:/Projects/Demo/wddemo.wdp" T)

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

WD\_PDS\_WFRM2ALL\_REBUILD\_REQD

[Example](#) [LISP](#) [See Also](#) [Send Feedback](#)

Description

Parameters

|         |                                                                                                           |
|---------|-----------------------------------------------------------------------------------------------------------|
| project | A unique text string that identifies a project. This can be a fixed name, a path and file name or a GUID. |
|---------|-----------------------------------------------------------------------------------------------------------|

Return Value

An integer value between 0 and N where N represents the number of drawings that are out of date.  
nil if the named project is not being monitored by the server.

Call this function to determine the number of drawings that are out of date in the WFRM2ALL table. This can be used regardless of the [WD\\_PDS\\_SET\\_FROMTO](#) setting.

See Also

[WD\\_PDS\\_WFRM2ALL\\_COMPLETE](#)

Example

(wd\_pds\_wfrm2all\_rebuild\_reqd "C:/Projects/Demo/wddemo.wdp")

Module

[LISP](#)

Links

[Example](#), [LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_PDSX\_ACTIVATE

[LISP](#) [Send Feedback](#)

Description

WD\_PDSX\_ACTIVATE

(wd\_pdsx\_activate filename)

Parameters

|          |                                                              |
|----------|--------------------------------------------------------------|
| filename | The full path and file name of the DWG file to be activated. |
|----------|--------------------------------------------------------------|

Return Value

T if the file was brought to the foreground.

Purpose: If the named file is open, this makes that window top-most.

Notes

This is a [synchronous](#) function. At the time of returning T it does not mean that the operation has completed.

Module

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback](#)  
AutoCAD Electrical 2025: AutoLISP Reference

## WD\_PDSX\_CLOSE

[LISP](#) [Send Feedback](#)

### Description

#### WD\_PDSX\_CLOSE

(wd\_pdsx\_close filename)

| Parameters |                                                           |
|------------|-----------------------------------------------------------|
| filename   | The full path and file name of the DWG file to be closed. |

| Return Value              |
|---------------------------|
| T if the file was closed. |

Purpose: If the file is open and can be saved and closed, this closes the named file.  
Warning: This can reduce AutoCAD to a zero document state.

### Notes

This is a [synchronous](#) function. At the time of returning T it does not mean that the operation has completed.

### Module

[LISP](#)

### Links

[LISP](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback](#)  
AutoCAD Electrical 2025: AutoLISP Reference

## WD\_PDSX\_ENABLE\_FRESHEN

[LISP](#) [See Also](#) [Send Feedback](#)

### Description

#### WD\_PDSX\_ENABLE\_FRESHEN

(wd\_pdsx\_enable\_freshen arg)

| Parameters |                                                                                       |
|------------|---------------------------------------------------------------------------------------|
| arg        | T to enable or nil to disable the <a href="#">wd_pds_freshen_project_db</a> function. |

This function is a global setting that either enables or disables the client's ability to test the status of the PDS server.

### Notes

Take dure care in restoring the setting if you turn it off.



Module

[LISP](#)

Links

[LISP](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference  
**WD\_PDSX\_MAPSCRCMD**  
[Example](#) [LISP](#) [Send Feedback](#)

Description

(wd\_pdsx\_mapscrcmd lispfunc pdkw arg)

This is used for script file translations.  
Purpose: Maps an AutoCAD command to one of the keywords listed below.

| Parameters         |                                                                   |
|--------------------|-------------------------------------------------------------------|
| lispfunc           | This is the existing <a href="#">LISP</a> function name           |
| pdkw               | These are the PDS keywords:                                       |
| #ACE_PDSX_OPEN     | See the <a href="#">WD_PDSX_OPEN</a> function                     |
| #ACE_PDSX_CLOSE    | See the <a href="#">WD_PDSX_CLOSE</a> function                    |
| #ACE_PDSX_ACTIVATE | See the <a href="#">WD_PDSX_ACTIVATE</a> function                 |
| arg                | Optional default argument to add to the behavior of the function. |

| Return Value               |
|----------------------------|
| T if the mapping was made. |

Example

If we want to open a file, the map command would be:  
(wd\_pdsx\_mapscrcmd "\_.OPEN" "#ACE\_PDSX\_OPEN")  
If the second parameter is nil and the line of text in the script file only contains the text of the first parameter, then the entire line is ignored.  
(wd\_pdsx\_mapscrcmd "\_.YES" nil)  
Note that this mapping only needs to be done once for the entire AutoCAD session. Therefore there is a new [LISP](#) function in acad\_demandload3.lsp that sets these mapping values. Calling more than once with the same values does not do any harm but is unnecessary.

Module

[LISP](#)

Links

[Example](#), [LISP](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference  
**WD\_PDSX\_OPEN**  
[LISP](#) [Send Feedback](#)

Parameters

filename                      The full path and file name of the DWG file to be opened.

Return Value

T if the file was opened or brought to the foreground.

Purpose: Open or activate the named file with the AutoCAD editor.

Notes

This is a [synchronous](#) function. At the time of returning T it does not mean that the operation has completed.

Module

[LISP](#)

Links

[LISP](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference  
**WD\_PDSX\_PROCESSID**  
[Example](#) [LISP](#) [Send Feedback](#)

Description

**WD\_PDSX\_PROCESSID**

(wd\_pdsx\_processid)  
Purpose: Get the process id of the running instance of AutoCAD and return the value as a string.

Returns

"4012"

Example

(wd\_pdsx\_processid)

Module

[LISP](#)

Links

[Example](#), [LISP](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference  
**WD\_PDSX\_PROCFILE**  
[Example](#) [LISP](#) [Send Feedback](#)

Description

**WD\_PDSX\_PROCFILE**

| Parameters |                                                 |
|------------|-------------------------------------------------|
| str1       | The base string.                                |
| str2       | The string to be appended after the process ID. |

| Return Value                                     |
|--------------------------------------------------|
| A concatenation of str1 (wd_pdsx_processid) str2 |

Purpose: Acts as a strcat replacement to generate process unique file names. This function simply concatenates all of its string arguments and then finds the last ?\? or ?/? and inserts the pr that slash and before any following text. This function's purpose is to create process specific temp files in the ACADE User folder.

Returns

"c:/demo/4012wdaudit1.log"

Example

(wd\_pdsx\_procfile "c:/demo/" "wdaudit1.log")

Module

[LISP](#)

Links

[Example](#), [LISP](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

WD\_PDSX\_SCRIPT

Description

WD\_PDSX\_SCRIPT

(wd\_pdsx\_script filename)

| Parameters |                                                                |
|------------|----------------------------------------------------------------|
| filename   | The full path and file name of the script file to be executed. |

| Return Value                              |
|-------------------------------------------|
| T if the script was queued for execution. |

Purpose: Executes the named script file using the performance database service (PDS). This function allows scripts to run across multiple drawings and will open or activate the drawings as n

Notes

This is a [synchronous](#) function. At the time of returning T it does not mean that the operation has completed.

-- . . .

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

## WD\_PDSX\_TEMPDIR

[Example](#) [LISP](#) [Send Feedback](#)

### Description

#### WD\_PDSX\_TEMPDIR

(wd\_pdsx\_tempdir)

Purpose: Get the system temporary directory. This is typically ?Documents and Settings\%USERNAME%\Local Settings\Temp? but if that directory does not exist, then an attempt is made to \$TEMP or \$TMP environment variable. If that is not set, then the current working directory is returned.

### Returns

"C:\\DOCUME~1\\hollin\\LOCALS~1\\Temp"

### Example

(wd\_pdsx\_tempdir)

### Module

[LISP](#)

### Links

[Example](#), [LISP](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

## OleDB

[Section M - Project Database Service](#) [Topics](#) [Send Feedback](#)

### Description

The AcePmOleDb project can be used to do database operations using OleDb using ATL.

The AcePmOleDb library maintains a [cache](#) of recent connections to optimize the time taken to make a connection to the database. It is highly recommended that you use this cache to get ar connections. The following sample illustrates the use of the AceOleDbFileRecordset class that implicitly manages the cache.

```
//
// Simple query example to show the use of the AceOleDbFileRecordset
// and its implicit cache management.
//
bool query(const TCHAR* mdbfile, const TCHAR* sql)
{
    bool ok = false;
    // create a new record set and have it use the AceOleDbConnectionCache
    // for an MDB (Access) database file
    AceOleDbFileRecordset rs(AceOleDbFileRecordset::kConnFromCache, AceOleDbFileRecordset::kMdbFile);
    // open up the MDB file
    if (rs.Open(mdbfile))
    {
        // set the SQL statement
        rs.SetCommandText(sql);
        // execute the query
        if (rs.Execute() == AceOleDbCommand::kTrue)
        {
            // save the column count - rather than compute it in a for loop
            DBORDINAL cols = rs.GetColumnCount();
            // loop through all returned records
            while (rs.FetchNext() == AceOleDbCommand::kTrue)
            {
                // scan through all columns
                // NOTE: Column counts start at 1 not 0 and go to GetColumnCount()
                for (DBORDINAL i = 1; i <= cols; ++i)
                {
                    // if not null and not a blob, then print it out
                    if (rs.IsNull(i) == AceOleDbCommand::kFalse &&
                        rs.IsBlob(i) == AceOleDbCommand::kFalse)
                        acutPrintf("%s = %s\n", rs.GetColumnName(i), rs.FieldAsStringEx(i));
                }
            }
            ok = true;
        }
        // close the recordset
        rs.Close();
    }
    // when class goes out of scope it will cache the connection
    return ok;
}
```

To use the AcePmOleDb classes link to the AcePmOleDb.lib and include the relevant header files from the following classes.

- [AceOleDbConnectionCache](#)
- [AceOleDbConnection](#)
- [AceOleDbCommand](#)

Module

[Section M - Project Database Service](#)

Topics

| Name                                    | Description |
|-----------------------------------------|-------------|
| <a href="#">AceOleDbCommand</a>         |             |
| <a href="#">AceOleDbConnection</a>      |             |
| <a href="#">AceOleDbConnectionCache</a> |             |

Links

[Section M - Project Database Service](#), [Topics](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback](#)  
AutoCAD Electrical 2025: AutoLISP Reference

AceOleDbCommand

[OleDb](#) [See Also](#) [Send Feedback](#)

Description

AceOleDbCommand

The AceOleDbCommand class is the base class used for OLE DB statements. This class wraps the ATL CCommand class with a CDynamicAccessor and CRowset template parameters. This ther supports dynamic SQL statements (that are not known until runtime).

| AceOleDbCommand                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <pre> #m_pconn : AceOleDbConnection * #m_rs : CCommand&lt;CDynamicAccessor,CRowset&gt; #m_sql : CATIString #m_moveFirst : bool #m_isOpen : bool #m_rowsAffected : DBROWCOUNT #m_colCount : DBORDINAL +AceOleDbCommand() +~AceOleDbCommand() +SetConnection(in pconn : AceOleDbConnection*) +SetCommandText(inout cmd : const CATIString) +Execute() : dbStatus +GetColumnCount() : DBORDINAL +GetRowsAffected() : DBROWCOUNT +FetchNext() : dbStatus +FieldAsString(in colpos : DBORDINAL) : CATIString +FieldAsStringEx(in colpos : DBORDINAL) : CATIString +FieldAsLong(in colpos : DBORDINAL) : long +IsBlob(in colpos : DBORDINAL) : dbStatus +IsNull(in colpos : DBORDINAL) : dbStatus +GetRawType(in colpos : DBORDINAL) : DBTYPE +GetColumnName(in colpos : DBORDINAL) : CATIString +GetColumnIndex(inout colName : const CATIString) : DBORDINAL +GetColumnSize(in colpos : DBORDINAL) : unsigned long +HasResults() : bool +GetBlobData(in colpos : DBORDINAL, in buffer : void*, in max : unsigned long) : dbStatus +Close() </pre> |

The steps to using this class are:

1. Obtain an [AceOleDbConnection](#) either from the cache, or a non-cached instance.

```
AceOleDbConnection* pconn = aceOleDbCache->Connect(initString);
```

2. Create an instance of the AceOleDbCommand and set the [AceOleDbConnection](#) object.

```
AceOleDbCommand rs;
rs.SetConnection(pconn);
```

3. Set the SQL statement.

```
CATIString sql(_T("SELECT * FROM COMP"));
rs.SetCommandText(sql);
```

4. Execute the command:

```
if (rs.Execute() == AceOleDbCommand::kFalse)
    return false;
```

5. Process the return data (if it was a DML statement)

```
if (rs.HasResults())
{
    DBORDINAL cols = rs.GetColumnCount();
    while (rs.FetchNext() == AceOleDbCommand::kTrue)
    {
        // NOTE: Column index is from 1 not 0
        for (DBORDINAL i = 1; i <= cols; ++i)
        {
            if (rs.IsNull(i) == AceOleDbCommand::kFalse &&
                rs.IsBlob(i) == AceOleDbCommand::kFalse)
            {
                // use one of the FieldAsXXX functions
            }
        }
    }
}
```

6. Close the statement.

```
rs.Close();
```

## See Also

[AceOleDbConnection](#)

## Module

What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

AceOleDbConnection

[OleDb](#) [See Also](#) [Send Feedback](#)

Description

AceOleDbConnection

The AceOleDbConnection class represents an OLE DB connection to a data provider. This class wraps the ATL CDataSource and CSession classes.

| AceOleDbConnection                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| +m_datasource : CDataSource<br>+m_session : CSession<br>+m_convert : IDataConvert *<br>+m_initString : CComBSTR<br>+AceOleDbConnection()<br>+~AceOleDbConnection()<br>+CreateMdbFile(inout initString : const CComBSTR, inout mdbFile : const CComBSTR) : HRESULT<br>+CreateMdbFile(inout initString : const CComBSTR, inout mdbFile : const CComBSTR, inout einfo : AceOleDbErrorInfo) : HRESULT<br>+OpenFromInitializationString(inout initString : const CComBSTR, in promptForInfo : bool) : HRESULT<br>+CompactMdb() : HRESULT<br>+GetDataSource(inout source : CAIString) : bool<br>+IsConnected() : bool<br>+IsReadOnly() : bool<br>+GetSession() : CSession &<br>+GetDataConvert() : IDataConvert *<br>+SameInit(inout initString : const CComBSTR) : bool<br>+GetInit() : const CComBSTR &<br>+Close()<br>+GetCurrentCatalog(inout catalog : CAIString) : bool<br>+StartTransaction() : bool<br>+Commit() : bool<br>+Rollback() : bool |

To use this class outside of the [AceOleDbConnectionCache](#), you need to call the OpenFromInitializationString method to connect to a data source and Close to close the connection. You can u  
AceOleDbHelper class to create formatted initialization strings.  
The AceOleDbConnection class is used as the connection object within other classes such as [AceOleDbCommand](#), AceOleDbTables etc.  
The AceOleDbConnection static CreateMdbFile functions can be used to create a Microsoft Access database.

See Also

[AceOleDbConnectionCache](#)

Module

[OleDb](#)

Links

[OleDb](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025: AutoLISP Reference

AceOleDbConnectionCache

[OleDb](#) [See Also](#) [Send Feedback](#)

Description

AceOleDbConnectionCache

The purpose of this singleton class is to maintain a cache of recently used connections.

Notes

The creation and destruction of this class is handled in the DLL attach and detach entry points and should not be created explicitly by any consumer of this library.

| AceOleDbConnectionCache                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| -m_theCache : AceOleDbConnectionCache * = NULL<br>-m_refcount : long = 0<br>#m_cs : CRITICAL_SECTION<br>#m_cacheSize : size_t<br>#m_conns : ConnMap<br>-AceOleDbConnectionCache()<br>#InitConnectionCache() : bool<br>#CloseConnectionCache()<br>+~AceOleDbConnectionCache()<br>+Connect(inout initString : const CComBSTR, in promptForInfo : bool = false) : AceOleDbConnection *<br>+SetCacheSize(in size : size_t)<br>+GetCacheSize() : size_t<br>+ClearCache()<br>+Cache(in conn : AceOleDbConnection*)<br>+GetCacheMessage() : AceOleDbConnectionCache * |

Where initString is a properly formatted OLE DB connection string. You can use the AceOleDbHelper class to format a connection string for certain databases.

When you have finished with the connection:

```
aceOleDbCache->Cache(pconn);
```

See Also

[AceOleDbConnection](#)

Module

[OleDb](#)

Links

[OleDb](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference

Appendix

[Section M - Project Database Service](#) [Topics](#) [Send Feedback](#)

Module

[Section M - Project Database Service](#)

Topics

| Name                                   | Description |
|----------------------------------------|-------------|
| <a href="#">Project Variables</a>      |             |
| <a href="#">Synchronous Operations</a> |             |

Links

[Section M - Project Database Service](#), [Topics](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference

Project Variables

[Appendix](#) [See Also](#) [Send Feedback](#)

Description

Project Variables

The following are the variables supported (required) by PDS:

| Variable | Type    | Range                                     |
|----------|---------|-------------------------------------------|
| "IEC"    | Boolean | VARIANT_TRUE or VARIANT_FALSE<br>T or nil |

See Also

[PmSetProjectVar](#) and [WD\\_PDS\\_SET\\_PROJECT\\_VAR](#)

Module

[Appendix](#)

Links

[Appendix](#), [See Also](#)

Copyright (c) Autodesk 2024. All rights reserved.  
What do you think about this topic? [Send feedback!](#)  
AutoCAD Electrical 2025; AutoLISP Reference

Synchronous Operations

[Appendix](#) [Send Feedback](#)



```
_.OPEN "C:/DEMO/DEMO07.DWG"  
_.OPEN "C:/DEMO/DEMO08.DWG"  
(wd_pdsx_activate "C:/DEMO/DEMO07.DWG")  
wd_surf_zoom_in_oem "6AE" "0" "0" ""
```

You may expect that demo07 would be activated before the wd\_surf\_zoom\_in\_oem command. But because [wd\\_pdsx\\_activate](#) is synchronous, the order of execution depends entirely upon C slices and thread management. The above may work 8 out of 10, but not always. The correct construct for the above command is:

```
_.OPEN "C:/DEMO/DEMO07.DWG"  
_.OPEN "C:/DEMO/DEMO08.DWG"  
_.OPEN "C:/DEMO/DEMO07.DWG")  
wd_surf_zoom_in_oem "6AE" "0" "0" ""
```

The second \_.OPEN of demo07 will simply activate it and the entire command will run asynchronously. Alternatively you can use the keyword construct:

```
#ACE_PDSX_OPEN "C:/DEMO/DEMO07.DWG"  
#ACE_PDSX_OPEN "C:/DEMO/DEMO08.DWG"  
#ACE_PDSX_ACTIVATE "C:/DEMO/DEMO07.DWG"  
wd_surf_zoom_in_oem "6AE" "0" "0" ""
```

The bottom line is that these new commands are exposed for your usage.

**Module**

[Appendix](#)

**Links**

[Appendix](#)