directory

1 DESCRIPTION OF THE ITSAPI ACCESS MODULE 2

1.1 CGI OPERATION CONFIGURATION DESCRIPTION 2

1.1.1 Basic configuration of CGI operations 2

1.1.1.1 CGI obtains the basic configuration 2

1.1.1.2 CGI modifies the device number 2

1.1.1.3 CGI modifies the send and receive timeouts 2

1.1.2 CGI operation module configuration 3

1.1.2.1 CGI obtains the module configuration 3

1.1.2.2 CGI modifies the heartbeat cycle 3

1.1.3 CGI operation image configuration 3

1.1.3.1 CGI obtains the image configuration 3

1.1.3.2 CGI modifies the image upload type 3

1.1.3.3 CGI modifies the license plate encoding format 3

1.1.4 CGI operation channel configuration 4

1.1.4.1 CGI obtains the channel configuration 4

1.1.5 CGI operation event configuration 4

1.1.5.1 CGI obtains the event configuration 4

1.1.6 Personalized configuration of CGI operations 4

1.1.6.1 CGI gets personalized configurations 4

1.1.6.2 The number of retransmissions is modified by CGI 4

1.1.6.3 CGI changes whether to turn off the new response 4

1.1.6.4 CGI modifies the upload information 4

1.1.6.5 CGI modification feature enabled 5

1.1.6.6 CGI modifies the upload API URI 5

1 Description of the ITSAPI access module

1.1 CGI operation configuration description

You can use CGI to obtain and modify some configurations that are not displayed on the web, as described below.

Remarks:

1) After modifying the configuration through CGI, you need to restart the access service, that is, click "Refresh" in chapter 3.1.6.2, then turn off "Enable" in chapter 3.1.1 and then restart it.

2) In most scenarios, the configuration of this part will be set in the factory default configuration, if you need to modify it, please read the instructions in detail (see below for details).

1.1.1 Basic configuration of CGI operations

1.1.1.1CGI obtains the basic configuration

http:// ip/cgi-bin/configManager.cgi?action=getConfig&name=VSP_*ITSAPI_BASIC*

IP is the IP address of the device, the same below.

1.1.1.2CGI modifies the device number

http:// ip/cgi-bin/configManager.cgi?action=setConfig&*VSP_ITSAPI_BASIC. DeviceId=XXXXXX*

XXXXXX indicates the value that you want to modify.

1.1.1.3CGI modifies the send and receive timeouts

http://ip/cgi-bin/configManager.cgi?action=setConfig&*VSP_ITSAPI_ BASIC. SendTimeout=15000*

15000 indicates the timeout period for sendingin milliseconds (ms).

http://ip/cgi-bin/configManager.cgi?action=setConfig&*VSP_ITSAPI_ BASIC. RecvTimeout=15000*

15000 indicates the receive timeout periodin milliseconds (ms).

1.1.2 CGI operation module configuration

1.1.2.1 CGI obtains the module configuration

http:// ip/cgi-bin/configManager.cgi?action=getConfig&name=VSP_*ITSAPI_MODULE*

1.1.2.2 CGI modifies the heartbeat cycle

http://ip/cgi-bin/configManager.cgi?action=setConfig&*VSP_ITSAPI_MODULE. HeartbeatCycle=120000*

120,000 represents the heartbeat cycle in milliseconds (ms).

1.1.3 CGI operation image configuration

1.1.3.1CGI obtains the image configuration

http:// ip/cgi-bin/configManager.cgi?action=getConfig&name=VSP_*ITSAPI_PICTURE*

1.1.3.2CGI modifies the image upload type

http://ip/cgi-bin/configManager.cgi?action=setConfig&VSP_ITSAPI_PICTURE[0].

Group=Whole|Dig|VehicleDig

Original image: Whole; Body cutout: VehicleDig; License plate cutout: Dig

Adopt '|' separation, each combination is uploaded by multiple graph types

1.1.3.3CGI modifies the license plate encoding format

http://ip/cgi-bin/configManager.cgi?action=setConfig&VSP_ITSAPI_PICTURE[0].

Mode.CharacterEncode=1

0 : GB2312 1 : UTF8 2 : ASCII

The default value is 1, which represents the UTF8 format

1.1.4 CGI operation channel configuration

1.1.4.1CGI obtains the channel configuration

http:// ip/cgi-bin/configManager.cgi?action=getConfig&name=VSP_*ITSAPI_CHANNEL*

1.1.5 CGI operation event configuration

1.1.5.1CGI obtains the event configuration

http:// ip/cgi-bin/configManager.cgi?action=getConfig&name=VSP_*ITSAPI_EVNET*

1.1.6 Personalized configuration of CGI operations

1.1.6.1CGI gets personalized configurations

http:// ip/cgi-bin/configManager.cgi?action=getConfig&name=VSP_ITSAPI_*CUSTOM*

1.1.6.2The number of retransmissions is modified by CGI

http://ip/cgi-bin/configManager.cgi?action=setConfig&*VSP_ITSAPI_CUSTOM.Custom.HandleMode=1*

The number of retransmissions is changed to 1.

1.1.6.3CGI changes whether to turn off the new response

http:// ip/cgi-bin/configManager.cgi?action=setConfig&VSP_ITSAPI_CUSTOMIgnoreHttpResponse=0

1: Ignore the answer; 0: Concern response;

1.1.6.4CGI modifies the upload information

http://

ip/cgi-bin/configManager.cgi?action=setConfig&VSP_ITSAPI_CUSTOMInfoUpload=BlockListAttribute|

Plate| VehicleLogo| Direction

License plate: Plate

Body color: VehicleColor

Logo: VehicleLogo

Vehicle model: VehicleType

Vehicle speed: Speed

TriggerSource: TriggerSource

Driving direction: Direction

SnapTime: SnapTime

SnapAddress: SnapAddress

License plate confidence: Confidence

Separator: '|', for multiple uploads, '|' separate

1.1.6.5CGI modification feature enabled

http://ip/cgi-bin/configManager.cgi?action=setConfig&VSP_ITSAPI_CUSTOM. FunctionEnable=BasicInfo |TollgateInfo

Feature enablement selection

Open the gate: OpenStrobe

Basic: BasicInfo

Bayonet: TollgateInfo

Separator: '|', for multiple uploads, '|' Separate; If multiple options are selected, the format is BasicInfo |TollgateInfo。

1.1.6.6CGI modifies the upload API URI

http://ip/cgi-bin/configManager.cgi?action=setConfig&VSP_ITSAPI_CUSTOM. UploadApi[2].Uri=/dahua

upload interface URI; array, the size of the array is 8;

0 indicates the basic information interface,

1 indicates the heartbeat interface,

2 indicates the bayonet picture interface

Modify the value of the corresponding array according to the corresponding interface

357492 dahua 2025-03-31