

Table of Contents

1.	O	/ERVIEW	4
2.	V	DLUME MANAGEMENT	5
	2.1	GET DISK AND VOLUME INFORMATION	5
	2.2	GET DISK AND VOLUME INFORMATION WITHOUT S.M.A.R.T. VALUE	9
	2.3	BAD BLOCK SCAN	10
	2.4	VOLUME FORMAT	11
	2.5	CHECKING VOLUME	
	2.6	REMOVE VOLUME	13
	2.7	CREATE VOLUME	13
	2.8	EXPAND CAPACITY OF A RAID VOLUME	15
	2.9	ADD HARD DRIVE TO A RAID VOLUME	15
	2.10	MIGRATE A RAID VOLUME FROM ONE TYPE TO ANOTHER	16
	2.11	CONFIGURE SPARE DRIVES OF A RAID VOLUME	17
	2.12	ENABLE OR DISABLE BITMAP ON A RAID VOLUME	18
	2.13	RECOVER A RAID VOLUME	19
	2.14	SET A DISK TO BE A GLOBAL SPARE DISK	19
3.	н	DD SMART	20
	3.1	SUMMARY	
	3.2	HARD DISK INFORMATION	
	3.3	SMART Information	
	3.4	TEST	
	3.5	SETTINGS	28
4.	EN	ICRYPTED FILES SYSTEM	30
	4.1	GET ENCRYPTED FILE SYSTEM INFORMATION	30
	4.2	KEY MANAGEMENT	33
5.	ICA	CSI	25
٥.	13		33
	5.1	PORTAL MANAGEMENT	35
	5.2	TARGET MANAGEMENT	37
	5.2.1		
	5.2.2		45
	5.2.3		
	5.2.4	ISCSI EDIT TARGET	49



5.2.5.	ISCSI EDIT LUN	. 51
5.2.6.	ISCSI REMOVE TARGET	. 53
5.2.7.	ISCSI remove lun	. 54
5.2.8.	ISCSI ACTIVATE TARGET	. 55
5.2.9.	ISCSI DEACTIVATE TARGET	. 57
5.2.10.	ISCSI UNMAP LUN	. 58
5.2.11.	ISCSI MAP LUN	. 59
5.2.12.	ISCSI ENABLE LUN	. 61
5.2.13.	ISCSI disable lun	. 62
5.3 A	ADVANCED ACL	. 64
5.3.1.	ADD POLICY	. 68
5.3.2.	EDIT POLICY	. 70
5.3.3.	REMOVE POLICY	
5.4 L	UN BACKUP	. 74
	TUAL DISK	
	GET REMOTE ISCSI DISK LIST	
	ADD VIRTUAL DISK	
	EDIT VIRTUAL DISK	
	REMOVE VIRTUAL DISK	
	CONNECT VIRTUAL DISK	
	DISCONNECT VIRTUAL DISK	
6.7 F	ORMAT VIRTUAL DISK	. 88