Modbus RTU Driver V19 — Library for Coolmay FX3G PLC

Abstract

The Modbus RTU Driver enables a Coolmay FX3G PLC to operate as a Modbus RTU master or slave on its two auxiliary RS485 ports (port 2 and port 3). On L02-series PLCs the same channel model also drives the built-in Ethernet port as a Modbus TCP master (client) — a channel whose `iPort` is `MB_PORT_TCP` is handled with the same scheduling logic as an RS485 channel — and `MB_MASTER_INIT_TCP` / `MB_SLAVE_INIT_TCP` configure that port as a Modbus TCP master (client) or slave (server). The library also configures the same L02 Ethernet port as an **EtherNet/IP scanner** (`EIP_INIT`, `EIP_INIT_REMOTE`) and provides typed access to the remote coupler I/O (`EIP_DI`, `EIP_DO`, `EIP_DO_SET`, `EIP_AI`, `EIP_AO`, `EIP_AO_SET`). Communication channels are configured through an application-declared array `MB_CHANNELS` of type `MB_REG_50`; a single function block, `MB_PROCESS_50`, cycles through that array and performs the channel transfers on a **50 ms** tick.

The `MB_CHANNELS` array and the `c_MB_CHANNELS_NUM` capacity constant are declared by the application in its own global label list, sized to the number of channels it actually uses; `MB_PROCESS_50` cycles through exactly that many channels. This keeps the automatically-assigned device usage proportional to the number of channels actually configured.

Prerequisites

1. The following libraries must be installed in the project before this driver:
    - `Utils.sul`
    - `TimeControl.sul`
2. The TimeControl library's `TCO_TICKER_50` ticker must be running. It advances at **50 ms** intervals and drives the scheduling of `MB_PROCESS_50`.
3. The application must declare the Modbus channel storage in its own global label list before using `MB_PROCESS_50`:
    - `c_MB_CHANNELS_NUM` — `VAR_GLOBAL_CONSTANT` (`INT`), the upper bound (last valid index) of the channel array.
    - `MB_CHANNELS` — `VAR_GLOBAL` (`ARRAY [0..c_MB_CHANNELS_NUM] OF MB_REG_50`), the channel array itself.

    > The literal array bound must match `c_MB_CHANNELS_NUM`. For three channels (indices `0`–`2`), declare `c_MB_CHANNELS_NUM := 2` and `MB_CHANNELS : ARRAY [0..2] OF MB_REG_50`.
4. Modbus TCP channels additionally require an L02-series PLC with the built-in Ethernet interface and the `Utils` library's `L02_SET_IP` function. See § Modbus TCP (Ethernet).
5. This library is compatible with **GX Works 2 v1.631H** and later. Updates are available from the `coolmay/soft` directory.

Terminology

- **Channel** — A single configured Modbus read/write relationship, described by one element of `MB_CHANNELS`.
- **Register channel** — A channel that transfers 16-bit register data (function codes `H3`, `H4`, `H6`, `H10`). Its value buffer lives in the `D` device area.
- **Coil channel** — A channel that transfers discrete bit data (function codes `H1`, `H2`, `H5`, `HF`). Its value buffer lives in the `M` device area.
- **Scratch buffer** — A `D`-area workspace used by `MB_PROCESS_50` during a transfer, starting at the `mb_iBuffer` base device.

Type names: this document uses the IEC type names written in the GX Works 2 label CSV files. The Label Editor displays them as follows:

IEC type	GX Works 2 Label Editor display
`BOOL`	Bit
`INT`	Word [Signed]
`WORD`	Word [Unsigned] / Bit String [16-bit]
`DWORD`	Double Word [Unsigned]

Architectural Description

This library enables a Coolmay FX3G PLC to operate as a **Modbus Slave** or a **Modbus Master** on the secondary and tertiary RS485 ports (ports 2 and 3, respectively), and — on L02-series PLCs — as a **Modbus TCP Master** over the built-in Ethernet port. It provides a low-overhead interface for configuring and managing Modbus communication channels.

The Modbus channels are described in a user-declared global array `MB_CHANNELS` of type `MB_REG_50`. The library does not fix the channel count: the application declares the array and the `c_MB_CHANNELS_NUM` upper bound in its global label list, and `MB_PROCESS_50` cycles through exactly that many channels.

Coolmay PLC/HMI integrated units are equipped with two RS485 ports: port 2 is exposed on the terminal connector, and port 3 is exposed on the DB9 connector. L02-series PLCs also provide two RS485 ports, both on terminal connectors.

The recommended workflow is:

1. At startup (under the `M8002` initialisation pulse), configure the `MB_CHANNELS` array.
2. Initialise each RS485 port that is used with `MB_PORT_SETTINGS` and the relevant `MB_*_INIT_*` function. Re-trigger the initialisation periodically after startup (see the timing note in § Modbus Master). For a `MB_PORT_TCP` channel the Ethernet port is configured instead, as described in § Modbus TCP (Ethernet): `MB_MASTER_INIT_TCP` sets the role, port and server count and `L02_SET_IP` writes the addresses. To make the PLC a Modbus TCP server, call `MB_SLAVE_INIT_TCP` — that role needs no channel and no `MB_PROCESS_50` call.
3. Call `fbMbProcess` every scan (or at least faster than the shortest `tCycle`).

> **Calling convention:** the port-initialisation and settings POUs are *functions* that return their result through the function name. In GX Works 2 a function call used as a statement requires a left-hand side, so callers assign the result to a dummy bit, e.g. `M0 := MB_MASTER_INIT_PORT2(TRUE, PortSettings);`. The result value is not used elsewhere.

Function Blocks and Functions

Name	Type	Description
`MB_PORT_SETTINGS`	Function	Build the serial-port bit-field (parity, stop bits, baud rate).
`MB_MASTER_INIT_PORT2`	Function	Initialise the Modbus master on port 2.
`MB_MASTER_INIT_PORT3`	Function	Initialise the Modbus master on port 3.
`MB_SLAVE_INIT_PORT2`	Function	Initialise the Modbus slave on port 2.
`MB_SLAVE_INIT_PORT3`	Function	Initialise the Modbus slave on port 3.
`MB_SLAVE_INIT_TCP`	Function	Enable Modbus TCP slave (server) mode on the L02 Ethernet port.
`MB_MASTER_INIT_TCP`	Function	Configure the L02 Ethernet port as Modbus TCP master (client).
`MTB_SLAVE_PORT2`	Function	Reconfigure port 2 for the Mitsubishi protocol.
`MTB_SLAVE_PORT3`	Function	Reconfigure port 3 for the Mitsubishi protocol.
`MB_PROCESS_50`	Function Block	Cycle through the channels and perform their read/write transfers.
`MB_REG_50`	Structure	Per-channel configuration (declared by the application as `MB_CHANNELS`).
`EIP_INIT`	Function	Select EtherNet/IP and set the number of remote couplers.
`EIP_INIT_REMOTE`	Function	Write the DI/DO/AI/AO point configuration of one remote coupler.
`EIP_DI`	Function	Read one digital input point of a remote coupler.
`EIP_DO`	Function	Read one digital output point of a remote coupler.
`EIP_DO_SET`	Function	Write one digital output point of a remote coupler.
`EIP_AI`	Function	Read one analog input point of a remote coupler.
`EIP_AO`	Function	Read one analog output point of a remote coupler.
`EIP_AO_SET`	Function	Write one analog output point of a remote coupler.

Global Constants and Variables

Access Modes

Constant	Value	Description
MB_READ_WRITE	0	Read and write.
MB_READ	1	Read only.
MB_WRITE	2	Write only.

Clear-on-Start Modes

Constant	Value	Description
MB_CLEAR_NONE	0	Clear nothing (default).
MB_CLEAR_ALL	1	Clear both the value buffer and the change-tracking buffer.
MB_CLEAR_BUFFER	2	Clear the change-tracking buffer only.

Serial Port Settings

Constant	Value	Description
MB_DL_7	0	7 data bits.
MB_DL_8	1	8 data bits.
MB_PARITY_NONE	0	No parity.
MB_PARITY_ODD	1	Odd parity.
MB_PARITY_EVEN	2	Even parity.
MB_STOPBIT_1	0	1 stop bit.
MB_STOPBIT_2	1	2 stop bits.
MB_BPS_600	0	600 bps.
MB_BPS_1200	1	1200 bps.
MB_BPS_2400	2	2400 bps.
MB_BPS_4800	3	4800 bps.
MB_BPS_9600	4	9600 bps.
MB_BPS_19200	5	19200 bps.
MB_BPS_38400	6	38400 bps.
MB_BPS_57600	7	57600 bps.
MB_BPS_115200	8	115200 bps.

> MB_DL_7 and MB_DL_8 are provided for completeness but are not selectable through MB_PORT_SETTINGS, which always configures **8 data bits**.

EtherNet/IP Coupler Selectors

Constant	Value	Description
`EIP_REMOTE1` … `EIP_REMOTE4`	`1` … `4`	Coupler selector for `EIP_INIT_REMOTE` and the `EIP_*` I/O accessors.

> These are **not** the `IP_REMOTE1` … `IP_REMOTE4` constants of the `Utils` library: those are `R` register base addresses (`23830` … `23860`) used by `L02_SET_IP` to store the remote IP addresses. `EIP_REMOTE*` select the EtherNet/IP coupler.

Ports

Constant	Value	Physical port
`MB_PORT_2`	`0`	RS485 port 2 — terminal connector (A, B)
`MB_PORT_3`	`1`	RS485 port 3 — DB9 connector (A1, B1)
`MB_PORT_CAN`	`2`	CAN port (H, L)
`MB_PORT_TCP`	`3`	Ethernet TCP port (L02-series PLCs only; see § Modbus TCP (Ethernet))

`MB_PORT_SETTINGS` (Function)

Returns the port-configuration value passed to `MB_MASTER_INIT_*` / `MB_SLAVE_INIT_*` when initialising a port as either Master or Slave.

Variable	Scope	Type	Description
`Parity`	INPUT	`INT`	One of: `MB_PARITY_NONE`, `MB_PARITY_ODD`, `MB_PARITY_EVEN`.
`StopBit`	INPUT	`INT`	One of: `MB_STOPBIT_1`, `MB_STOPBIT_2`.
`Baudrate`	INPUT	`INT`	One of: `MB_BPS_600`, `MB_BPS_1200`, `MB_BPS_2400`, `MB_BPS_4800`, `MB_BPS_9600`, `MB_BPS_19200`, `MB_BPS_38400`, `MB_BPS_57600`, `MB_BPS_115200`.

> **Note:** the data length is fixed at **8 data bits** and is not a parameter of this function.

Declare a local variable of type `DWORD` (e.g. `PortSettings`), then invoke the function:

```
VAR
    PortSettings : DWORD;
END_VAR

PortSettings := MB_PORT_SETTINGS(MB_PARITY_NONE, MB_STOPBIT_1, MB_BPS_9600);
```

Modbus Slave

`MB_SLAVE_INIT_PORT2`, `MB_SLAVE_INIT_PORT3`

These functions initialise the Modbus slave on port 2 or port 3 of the PLC, respectively.

Variable	Scope	Type	Description
`xInit`	INPUT	`BOOL`	Initialisation command. The slave is (re-)initialised on every rising edge.
`iAddress`	INPUT	`INT`	Modbus network address assigned to this PLC.
`PortSettings`	INPUT	`DWORD`	Return value of the `MB_PORT_SETTINGS` function.

> **Important — initialisation timing:** the function acts only on a rising edge of `xInit` (see § Modbus Master). Triggering it solely from the `M8002` first-scan pulse may not retain the port settings — feed the one-second clock `M8013` into `xInit` to re-apply them every second.

Example

The following snippet configures a slave with address `1` on port 2:

```
PortSettings := MB_PORT_SETTINGS(MB_PARITY_NONE, MB_STOPBIT_1, MB_BPS_9600);
M0 := MB_SLAVE_INIT_PORT2(M8013, 1, PortSettings);
```

No further configuration is necessary for the PLC to function as a slave on port 2. The same pattern applies to port 3. The variable `M0` is not referenced elsewhere in the program — it exists solely to satisfy the syntactic requirement that a function call used as a statement must have a left-hand side assignment.

> **Modbus TCP slave:** on an L02-series PLC the Ethernet port can serve as a Modbus TCP slave (server) as well — use `MB_SLAVE_INIT_TCP` instead, see § Modbus TCP (Ethernet) → § PLC as a Modbus TCP Server.

Modbus Master

`MB_MASTER_INIT_PORT2`, `MB_MASTER_INIT_PORT3`

These functions initialise the Modbus Master on port 2 (terminal connector) or port 3 (DB9 connector), respectively.

Variable	Scope	Type	Description
`xInit`	INPUT	`BOOL`	Initialisation command. The master is (re-)initialised on every rising edge.
`PortSettings`	INPUT	`DWORD`	Return value of the `MB_PORT_SETTINGS` function.

> **Important — initialisation timing:** the function acts only on a rising edge of `xInit`. Triggering it solely from the `M8002` first-scan pulse may not retain the port settings; feed the one-second clock `M8013` into `xInit` to re-apply them every second.

Example

```
PortSettings := MB_PORT_SETTINGS(MB_PARITY_NONE, MB_STOPBIT_1, MB_BPS_9600);
(* M8013 = 1 s clock: re-applies the port settings every second. *)
M0 := MB_MASTER_INIT_PORT2(M8013, PortSettings);
```

Port Reconfiguration (Mitsubishi Protocol)

MTB_SLAVE_PORT2, MTB_SLAVE_PORT3

These functions reconfigure port 2 or port 3 to the Mitsubishi proprietary protocol (not Modbus RTU), set the station address to 1, and set the serial format to **38400 baud, 7 data bits, even parity, 1 stop bit**. They are used to switch a port back from Modbus RTU to the Mitsubishi protocol.

Variable	Scope	Type	Description
xInit	INPUT	BOOL	Reconfiguration command. The port is reconfigured on every rising edge.

Example

```
M0 := MTB_SLAVE_PORT2(TRUE);
```

MB_PROCESS_50 (Function Block)

This function block orchestrates all read and write operations across the configured channels. It must be called every scan (or at least faster than the shortest channel tCycle).

> **Prerequisite:** The TimeControl library must be installed and TCO_TICKER_50 must be running. This ticker advances at 50 ms intervals and drives the scheduling of channel operations.

Variable	Scope	Type	Description
mb_xEnable	INPUT	BOOL	Enables channel processing. When FALSE, processing is suspended; re-enabling restarts the channels from the beginning.
mb_iBuffer	INPUT	INT	Base D device number of the scratch buffer used during a transfer. The scratch buffer holds up to iNum words for register channels, or ⌈iNum / 16⌉ words for coil channels (one bit per coil). It must not overlap any channel's value or change-tracking buffer.
mb_iClearOnStart	INPUT	INT	Startup buffer-clearing mode: MB_CLEAR_ALL, MB_CLEAR_BUFFER, or MB_CLEAR_NONE (default).
mb_iTimeoutCount	INPUT	INT	Consecutive timeouts before a channel is suspended. Default (when 0): 2.

Variable	Scope	Type	Description
`mb_iSuspendRetry`	INPUT	`INT`	Suspended-channel retry interval, in 50 ms units. Default (when `0`): `80` (4 s).
`mb_iTimeoutTime`	INPUT	`INT`	Timeout duration, in 50 ms units. Default (when `0`): `4` (200 ms).
`mb_tStartDelay`	INPUT	`TIME`	Startup delay.
`mb_iTimeout`	OUTPUT	`INT`	Channel number (index) of the channel that timed out. Held for one scan; `-1` when no channel has timed out.

Timeout Tuning

> **Call-interval consideration.** The timeout is only evaluated when `MB_PROCESS_50` is executed, so the *effective* resolution of `mb_iTimeoutTime` is the block's actual call interval — not the 50 ms the name implies. `mb_iTimeoutTime` remains specified in 50 ms units (`value × 50 ms`). Set it so the timeout lands at least one full call period past the expected request completion. Example: block called every 100 ms and a request expected to finish in 2 calls (200 ms) → use `mb_iTimeoutTime := 6` (300 ms), not `4` (200 ms); otherwise the completion and the timeout are sampled on the same boundary and the request can be falsely marked as timed out.

Clear-on-Start

`mb_iClearOnStart` controls what `MB_PROCESS_50` does with each channel's two buffers when it initialises the channel array. This happens once, after the startup delay and before the first channel is processed. Every channel owns a **value buffer** (the actual register/coil values) and a **change-tracking buffer** (an internal copy used to detect local changes). The scheduler treats a value as "changed" — and, for a write-capable channel, writes it to the slave — whenever the value buffer differs from the change-tracking buffer.

Constant	Value	What is cleared
`MB_CLEAR_NONE`	`0`	Nothing (default).
`MB_CLEAR_ALL`	`1`	Value buffer and change-tracking buffer.
`MB_CLEAR_BUFFER`	`2`	Change-tracking buffer only.

What happens in each case

- `MB_CLEAR_ALL` **— read first.** Both buffers are zeroed, so they are equal and no local change is detected. Write-capable channels therefore issue **no write** on startup; read-capable channels simply perform their normal **read first** when the cycle elapses, filling the value buffer from the slave. The slave is treated as the source of truth.
- `MB_CLEAR_BUFFER` **— write current values.** The value buffer is preserved while the change-tracking buffer is zeroed. Every retained **non-zero** value therefore differs from its cleared change-tracking entry and is seen as "changed", so write-capable channels (`MB_READ_WRITE` or `MB_WRITE`) attempt to **write their current values to the slave** at the next write opportunity. A retained value of `0` matches the cleared entry and is **not** written.

- `MB_CLEAR_NONE` **— no side effects.** Nothing is cleared. Both buffers keep their contents, so no artificial "changed" state is introduced and no extra read or write is forced at startup. Retained values are written only if they genuinely differ from the retained change-tracking buffer.

Use cases

- `MB_CLEAR_NONE` — the PLC's `D`/`M` values are latched across restarts and already consistent with the change-tracking buffer. The driver is left untouched and performs only its normal `tCycle` reads/writes, with no startup write.
- `MB_CLEAR_ALL` — cold start or commissioning, or any situation where the slave is the source of truth and the driver should pull current slave values first. Because both buffers are cleared, it produces no spurious startup writes.
- `MB_CLEAR_BUFFER` — the PLC's retained value buffer is the source of truth and the slave may have lost its state (for example, the slave was power-cycled independently or replaced). On startup the driver re-pushes the retained values to the slave, re-synchronising the slave to the PLC.

> **Note:** The write-on-startup effect of `MB_CLEAR_BUFFER` applies to **non-zero** retained values only. Because the change-tracking buffer is zeroed, a retained `0` is indistinguishable from "unchanged" and is not written. If the retained value buffer is entirely zero, `MB_CLEAR_BUFFER` behaves like `MB_CLEAR_NONE` and no write occurs.

The `MB_REG_50` Structure

The application declares a global array `MB_CHANNELS` of type `MB_REG_50`, together with a global constant `c_MB_CHANNELS_NUM` that holds the array's upper bound (last valid index). The library references both labels directly — it does not declare them. `MB_PROCESS_50` cycles through channels `0` to `c_MB_CHANNELS_NUM`, so the number of channels is fully under application control (e.g. `c_MB_CHANNELS_NUM := 2` for 3 channels, `:= 29` for 30 channels). Each channel may read or write up to **125** registers. The array must be configured once, typically on PLC startup under the `M8002` initialisation pulse flag.

The structure contains the following user-configurable fields.

Variable	Type	Description
`xEnabled`	`BOOL`	Enable this channel for processing. When `FALSE`, the channel is skipped.
`iDDevNum`	`INT`	Base device number of the value buffer. Register channels use `D` devices; coil channels use `M` devices. Each channel consumes **2 × `iNum`** devices. See § `iDDevNum` for allocation rules.
`iNum`	`INT`	Number of registers or coils to read/write (max 125). Default (when `0`): `1`.
`iReg`	`WORD`	Starting Modbus register/coil address. Declared `WORD` (unsigned) so addresses above 32,000 can be specified.
`iRF`	`WORD`	Modbus read function code (`H1`–`H4`). Default (when `0`): `H3`.
`iWF`	`WORD`	Modbus write function code (`H5`, `H6`, `HF`, `H10`). Default (when `0`): `H6`.

Variable	Type	Description
`iDev`	`WORD`	Modbus slave device address. On a `MB_PORT_TCP` channel it is the remote server index (`1`–`4`); see § Modbus TCP (Ethernet).
`tCycle`	`INT`	Cycle interval for automatic reads/writes, in units of 50 ms. E.g. `20` = 1 second. Set to `0` for manual-only operation via `xReadOnce` / `xWriteOnce`.
`iWR`	`INT`	Read/write mode: `MB_READ_WRITE`, `MB_READ`, or `MB_WRITE`. Writes (including `xWriteOnce` / `xWriteOnChange`) require `MB_READ_WRITE` or `MB_WRITE`.
`iPort`	`INT`	Communication port identifier: `MB_PORT_2`, `MB_PORT_3`, `MB_PORT_CAN`, or `MB_PORT_TCP`. See § Ports.
`xWriteOnChange`	`BOOL`	When `TRUE`, changed values are written to the slave immediately upon detection. When `FALSE`, writes occur only when the `tCycle` interval elapses.
`xReadOnce`	`BOOL`	On a rising edge (`FALSE` → `TRUE`), triggers a single read of this channel. For manual-only reads, set `tCycle` to `0`.
`xWriteOnce`	`BOOL`	On a rising edge (`FALSE` → `TRUE`), triggers a single write of this channel. For manual-only writes, set `tCycle` to `0`.
`xDone`	`BOOL`	Read-only completion pulse. Set `TRUE` on completion of one read/write cycle; cleared at the start of the next cycle. Primarily useful for channels operating in manual mode (`tCycle = 0`).

Supported Read/Write Functions

Code	Mnemonic
`H1`	Read Coils
`H2`	Read Discrete Inputs
`H3`	Read Holding Registers
`H4`	Read Input Registers
`H5`	Write Single Coil
`H6`	Write Single Register
`HF`	Write Multiple Coils
`H10`	Write Multiple Registers

`iDDevNum` — Buffer Allocation

Each channel reserves **twice** the number of devices specified by `iNum`. Half of the allocation holds the actual register/coil values; the other half is used internally for change tracking. Register channels use the `D` device area; coil channels use the `M` device area.

If `iNum = 1` and `iDDevNum = 200`:

- `D200` stores the value.
- `D201` is reserved for internal use.

If `iNum = 5`:

- `D200`–`D204` store the values.
- `D205`–`D209` are reserved for internal use.

> **Caution:** Failure to account for the internal buffer when assigning `iDDevNum` values across consecutive channels will result in data corruption.

Consider the following **incorrect** configuration:

```
MB_CHANNELS[0].iDDevNum := 600;
MB_CHANNELS[0].iNum := 3;

MB_CHANNELS[1].iDDevNum := 603;
MB_CHANNELS[1].iNum := 1;
```

Channel 0 consumes devices `D600` through `D605` (3 values + 3 internal). The first free device is therefore `D606` — not `D603`. Assigning `iDDevNum := 603` to channel 1 causes its buffer to overlap with the internal area of channel 0, producing undefined behaviour.

The **correct** allocation is:

```
MB_CHANNELS[0].iDDevNum := 600;
MB_CHANNELS[0].iNum := 3;

MB_CHANNELS[1].iDDevNum := 606;
MB_CHANNELS[1].iNum := 1;
```

`iWF` — Write Function Selection

Two write-function codes are available for register channels:

- `H6` **(Write Single Register):** When assigned to a multi-register channel, only the register whose value changed is written in a dedicated request.
- `H10` **(Write Multiple Registers):** When assigned to a multi-register channel, a change to any register within the group triggers a single request that updates the entire group.

Guidance:

- For double-word values spanning multiple registers → use `H10`.
- For multiple independent single-register variables on the same channel → use `H6`.
- For a single-register channel → use `H6`.

The same principle applies to coil channels: use `H5` (Write Single Coil), even when the channel spans multiple coils.

Complete Example

Before configuring channels, declare the storage in the project's global label list. The following declares three channels (indices `0`–`2`):

Label	Class	Type / Value
`c_MB_CHANNELS_NUM`	`VAR_GLOBAL_CONSTANT`	`INT = 2`
`MB_CHANNELS`	`VAR_GLOBAL`	`ARRAY [0..2] OF MB_REG_50`

Declare the function-block instance and the port bit-field in the local label section of the POU:

```
VAR
    fbMbProcess  : MB_PROCESS_50;
    PortSettings : DWORD;
END_VAR
```

> `M0`, `M1`, `M2`, and `M8002` in the example are device labels (auxiliary relays and the initialisation-pulse special relay) and do not require a `VAR` declaration.

```
IF M8002 THEN

    (* Timeout and clear-on-start tuning are supplied to fbMbProcess below. *)
    PortSettings := MB_PORT_SETTINGS(MB_PARITY_NONE, MB_STOPBIT_1, MB_BPS_9600);

    (* Automatic read/write channel on port 2 *)
    MB_CHANNELS[0].xEnabled := TRUE;
    MB_CHANNELS[0].iDDevNum := 600;
    MB_CHANNELS[0].iNum := 3;
    MB_CHANNELS[0].iReg := K16384;
    MB_CHANNELS[0].iRF := H3;
    MB_CHANNELS[0].iWF := H6;
    MB_CHANNELS[0].iDev := H1;
    MB_CHANNELS[0].tCycle := 20; (* 20 × 50 ms = 1 000 ms = 1 second *)
    MB_CHANNELS[0].xWriteOnChange := TRUE;
    MB_CHANNELS[0].iWR := MB_READ_WRITE;
    MB_CHANNELS[0].iPort := MB_PORT_2;

    (* Minimal setup — connects to a device via Port 3 *)
    MB_CHANNELS[1].xEnabled := TRUE;
    MB_CHANNELS[1].iDDevNum := 610;
    MB_CHANNELS[1].iReg := K16385;
    MB_CHANNELS[1].iDev := K16;
    MB_CHANNELS[1].tCycle := 4;
    MB_CHANNELS[1].iWR := MB_READ;
    MB_CHANNELS[1].iPort := MB_PORT_3;

    (* Manual-cycle read/write of a 3-register group *)
    MB_CHANNELS[2].xEnabled := TRUE;
    MB_CHANNELS[2].iNum := 3;
    MB_CHANNELS[2].iDev := H1;
    MB_CHANNELS[2].iPort := MB_PORT_3;
```

```
    MB_CHANNELS[2].iDDevNum := 10;
    MB_CHANNELS[2].iReg := H1000;
    MB_CHANNELS[2].iRF := H3;
    MB_CHANNELS[2].iWR := MB_READ_WRITE;
    MB_CHANNELS[2].tCycle := 0;
END_IF;

(* Multi-master mode is available on both ports for L02-series PLCs.
   M8013 = 1 s clock re-applies the port settings every second. *)
M0 := MB_MASTER_INIT_PORT2(M8013, PortSettings);
M0 := MB_MASTER_INIT_PORT3(M8013, PortSettings);

fbMbProcess(mb_xEnable := TRUE, mb_iBuffer := 100,
    mb_iClearOnStart := MB_CLEAR_ALL,
    mb_iTimeoutCount := 2,
    mb_iSuspendRetry := 80,
    mb_iTimeoutTime := 4);

(* Manually read channel 2 once *)
IF M1 THEN
    MB_CHANNELS[2].xReadOnce := TRUE;
    IF MB_CHANNELS[2].xDone = TRUE THEN
        M1 := FALSE;
        MB_CHANNELS[2].xReadOnce := FALSE;
    END_IF;
END_IF;

(* Manually write channel 2 once *)
IF M2 THEN
    D10 := 100;
    D11 := 100;
    D12 := 100;
    MB_CHANNELS[2].xWriteOnce := TRUE;
    IF MB_CHANNELS[2].xDone = TRUE THEN
        M2 := FALSE;
        MB_CHANNELS[2].xWriteOnce := FALSE;
    END_IF;
END_IF;
```

Post-configuration behaviour:

- `D600`, `D601`, and `D602` hold the three register values read from device address `1`, refreshed every second. If any value changes locally, the slave is updated immediately (`xWriteOnChange := TRUE`).
- `D610` holds the single register value read from device address `16`. Since this channel is configured as read-only (`MB_READ`), any local modification to `D610` is overwritten by the next read cycle (every 200 ms).
- Channel 2 (`tCycle = 0`) performs no automatic transfers. It is read or written only when `xReadOnce` / `xWriteOnce` is pulsed.

Alternative Write Confirmation

The expression `IF D10 = D13 AND D11 = D14 AND D12 = D15 THEN` implements a buffer-comparison strategy for verifying write completion.

As described in § `iDDevNum`, each channel reserves twice the number of devices specified by `iNum`. With `iDDevNum := 10` and `iNum := 3`:

- `D10`–`D12` hold the actual register values.
- `D13`–`D15` serve as the change-tracking buffer.

The change-tracking registers are updated together with the write. Equality between the value registers and their corresponding change-tracking registers therefore confirms that the write has completed.

```
(* Alternative write-confirmation technique *)
IF M2 THEN
    D10 := 200;
    D11 := 200;
    D12 := 200;
    MB_CHANNELS[2].xWriteOnce := TRUE;
    IF D10 = D13 AND D11 = D14 AND D12 = D15 THEN
        M2 := FALSE;
        MB_CHANNELS[2].xWriteOnce := FALSE;
    END_IF;
END_IF;
```

This technique is particularly useful when employing `xWriteOnChange` (rather than `xWriteOnce`) with a multi-register channel and write function `H6`. If, for example, two registers within a ten-register channel are modified, `H6` writes each one individually, setting `xDone` once per successful write. Counting two distinct `xDone` pulses can rapidly become unwieldy. In contrast, a single comparison of the form `IF D10 = D13 AND D11 = D14 AND …` confirms that all changed registers have been successfully propagated to the slave in a single check.

Modbus TCP (Ethernet)

On L02-series PLCs a channel can use the built-in Ethernet port instead of an RS485 port. A TCP channel is configured and used like any other channel — the same `MB_REG_50` fields, the same `tCycle`, `xReadOnce` / `xWriteOnce`, change-tracking, timeout and suspension rules — with two differences:

1. `iPort` must be set to `MB_PORT_TCP`.
2. The Ethernet interface and the remote servers are configured with the L02 network relays and registers — through the `MB_MASTER_INIT_TCP` / `MB_SLAVE_INIT_TCP` functions for the role, port and server count, and through the `L02_SET_IP` function of the `Utils` library for the IP addresses. `MB_PORT_SETTINGS` and the `MB_MASTER_INIT_PORT2` / `MB_MASTER_INIT_PORT3` functions are not used for a TCP channel: the Ethernet port has no serial settings.

RS485 channels and TCP channels can be mixed in the same `MB_CHANNELS` array.

> **Requirement:** an L02-series PLC with the built-in Ethernet interface. RS485-only Coolmay models have no usable `MB_PORT_TCP` channel.

Setup

Device	Value	Purpose
D8395	4	Modbus TCP master (client). 3 selects Modbus TCP server (see below). Written by MB_MASTER_INIT_TCP / MB_SLAVE_INIT_TCP.
D8325	1–4	Number of remote servers polled by this PLC. Written by MB_MASTER_INIT_TCP.
R23812	502	Modbus TCP port. Written by MB_MASTER_INIT_TCP / MB_SLAVE_INIT_TCP.
M8197	—	Apply the addresses and restart the interface. Set by L02_SET_IP on every write; the PLC resets it — no application code needed.
M8193	—	Network ready (1 when the network is up).
M8395	—	Connection status: 1 = communication normal, 0 = abnormal.
M8062	—	Modbus timeout.
M8063	—	IP address conflict.
R23815, R23816	—	Number of Modbus packets sent / received.

IP addresses are written with L02_SET_IP from the Utils library (see the Utils manual). It takes a setting type followed by the four octets:

Setting type	Meaning
IP_PLC_IP	IP address of the PLC
IP_PLC_MASK	Subnet mask
IP_PLC_GATEWAY	Gateway
IP_REMOTE1 … IP_REMOTE4	Remote server 1 … 4

L02_SET_IP sets M8197 itself on every write and the PLC clears it again, so the application never writes M8197 and needs no separate "apply" pulse. The function writes while its xInit input is TRUE, so pass a trigger bit that is TRUE for **one scan only** — M8002 for the startup write, MEP of an HMI "save" pulse for a later change — and give all settings of one configuration the same trigger, so they are written and applied in a single scan:

```
xApplyIp := M8002 OR MEP(xSaveIp);

M0 := L02_SET_IP(xApplyIp, IP_PLC_IP, 192, 168, 1, 3);      (* PLC IP       *)
M0 := L02_SET_IP(xApplyIp, IP_PLC_MASK, 255, 255, 255, 0);  (* subnet mask  *)
M0 := L02_SET_IP(xApplyIp, IP_PLC_GATEWAY, 192, 168, 1, 1); (* gateway      *)
```

> Never tie xInit to TRUE: every scan is then a new write, so the interface would restart continuously and the network would never come up.

Remote Servers and iDev

For a TCP channel the `iDev` field selects the remote server: `iDev := 1` addresses the server configured with `IP_REMOTE1`, `iDev := 2` the server configured with `IP_REMOTE2`, and so on up to `iDev := 4`. At most four servers are supported, and `D8325` must match the number actually used. `iNum` remains the number of registers or coils transferred and is unrelated to the server selection.

Timeout

The PLC firmware retries a failed Modbus TCP request before reporting an error, so `mb_iTimeoutTime` must cover those retries: `mb_iTimeoutTime := 20` (1 s) is a practical starting value. Use a startup delay (`mb_tStartDelay := T#10s`) so that the first request waits for `M8193` (network ready).

Modbus TCP Master Configuration

`MB_MASTER_INIT_TCP` (Function)

Configures the L02 built-in Ethernet port as a Modbus TCP master (client): the Modbus TCP port, the number of remote servers polled by this PLC, and the master role.

Variable	Scope	Type	Description
`xInit`	INPUT	`BOOL`	Configuration trigger. The configuration is written while it is `TRUE`, so pass a one-scan pulse — `MEP(xApplyIp)` — as shown in the example.
`iTcpPort`	INPUT	`INT`	Modbus TCP port. A non-zero value is written to `R23812`; `0` keeps the current port (`502`).
`iServers`	INPUT	`INT`	Number of remote servers polled by this PLC, clamped to `1`–`4` and written to `D8325`.

The function writes `R23812`, `D8325` and `D8395`, but not `M8197` — the values are applied and the interface restarts on the `L02_SET_IP` call that sets `M8197`. Call `MB_MASTER_INIT_TCP` therefore **before** the `L02_SET_IP` writes in the same scan.

The body is deliberately **level**-triggered (`IF xInit THEN`, no internal `MEP`): the application owns the edge and passes a one-scan pulse, which keeps the trigger visible at the call site and lets the same pulse gate several calls. Never tie `xInit` to `TRUE`.

> - Do not write `D8395`, `D8325` or `R23812` from the application when this function is used.
> - `iServers` must match the number of `IP_REMOTE1` … `IP_REMOTE4` addresses written with `L02_SET_IP`; the `iDev` field of a TCP channel selects one of them.
> - Master mode is mutually exclusive with `MB_SLAVE_INIT_TCP`: one PLC cannot poll remote servers and serve requests as a slave over the same port at the same time. Select one role per project.

Example — Modbus TCP Master

Declare the function-block instance and the status labels in the local label section:

```
VAR
    fbMbProcess     : MB_PROCESS_50;
```

```
    xSaveIp        : BOOL; (* pulse to re-apply the IP addresses   *)
    xApplyIp       : BOOL; (* apply trigger passed to L02_SET_IP   *)
    xNetworkReady  : BOOL;
    xConnection    : BOOL;
    xModbusTimeout : BOOL;
    xIPConflict    : BOOL;
    iTX            : INT;
    iRX            : INT;
END_VAR
```

In the POU body, configure the Ethernet port, the channel and the scheduler:

```
(* --- Ethernet setup of the L02 built-in port ---------------------- *)
(* One trigger for the whole configuration: first scan, and again     *)
(* after an address or port change.                                   *)
xApplyIp := M8002 OR MEP(xSaveIp);

(* Role, port and server count first - applied by the writes below.   *)
M0 := MB_MASTER_INIT_TCP(xApplyIp, 502, 1); (* 502, one remote server *)

(* IP addresses - the last write sets M8197 and applies everything.   *)
M0 := L02_SET_IP(xApplyIp, IP_PLC_IP, 192, 168, 1, 3);      (* PLC IP       *)
M0 := L02_SET_IP(xApplyIp, IP_PLC_MASK, 255, 255, 255, 0);  (* subnet mask  *)
M0 := L02_SET_IP(xApplyIp, IP_PLC_GATEWAY, 192, 168, 1, 1); (* gateway      *)
M0 := L02_SET_IP(xApplyIp, IP_REMOTE1, 192, 168, 1, 5);     (* remote 1     *)

(* --- Status (monitoring) ------------------------------------------ *)
xNetworkReady  := M8193;        (* 1 = network chip ready   *)
xConnection    := M8395;        (* 1 = communication normal *)
xModbusTimeout := M8062;        (* 1 = Modbus timeout       *)
xIPConflict    := M8063;        (* 1 = IP address conflict  *)
iTX            := R23815;       (* packets sent             *)
iRX            := R23816;       (* packets received         *)

(* --- Modbus channel ----------------------------------------------- *)
IF M8002 THEN
    MB_CHANNELS[0].xEnabled       := TRUE;
    MB_CHANNELS[0].iDDevNum       := 1000;  (* values D1000, change tracking D1001
*)
    MB_CHANNELS[0].iNum           := 1;
    MB_CHANNELS[0].iReg           := K16384;
    MB_CHANNELS[0].iRF            := H3;    (* read holding registers  *)
    MB_CHANNELS[0].iWF            := H6;    (* write single register   *)
    MB_CHANNELS[0].iDev           := 1;     (* remote server 1         *)
    MB_CHANNELS[0].tCycle         := 20;    (* 20 x 50 ms = 1 s        *)
    MB_CHANNELS[0].iWR            := MB_READ_WRITE;
    MB_CHANNELS[0].iPort          := MB_PORT_TCP; (* mandatory         *)
    MB_CHANNELS[0].xWriteOnChange := TRUE;
END_IF;

(* --- Scheduler ---------------------------------------------------- *)
fbMbProcess(
```

```
    mb_xEnable       := TRUE,
    mb_iBuffer       := 900,
    mb_iClearOnStart := MB_CLEAR_NONE,
    mb_iTimeoutCount := 100,
    mb_iSuspendRetry := 4,
    mb_iTimeoutTime  := 20,
    mb_tStartDelay   := T#10s);
```

After the startup delay the scheduler reads `D1000` every second from Modbus register `16384` of the server at `192.168.1.5` (`iDev = 1`). A local change to `D1000` is written to the server immediately, because `xWriteOnChange := TRUE`.

PLC as a Modbus TCP Server

In the server (slave) role the PLC answers incoming Modbus TCP requests itself instead of polling remote servers. No `MB_CHANNELS` entry and no `MB_PROCESS_50` call are needed — the driver is not involved, and the only library call is `MB_SLAVE_INIT_TCP`.

`MB_SLAVE_INIT_TCP` (Function)

Enables Modbus TCP slave (server) mode on the L02 built-in Ethernet port.

Variable	Scope	Type	Description
`xInit`	INPUT	`BOOL`	Initialisation command. The TCP slave mode is enabled on every rising edge.
`iTcpPort`	INPUT	`INT`	Modbus TCP port. A non-zero value is written to `R23812`; `0` keeps the current port (`502`).

The function does not configure the network addresses — write them with `L02_SET_IP` from the `Utils` library (§ Setup above). `L02_SET_IP` sets `M8197` on every write, which applies both the addresses and the TCP port written by this function.

Example

```
(* Trigger: first scan, and again after an address or port change. *)
xApplyIp := M8002 OR MEP(xSaveIp);

M0 := L02_SET_IP(xApplyIp, IP_PLC_IP, 192, 168, 1, 100);     (* PLC IP      *)
M0 := L02_SET_IP(xApplyIp, IP_PLC_MASK, 255, 255, 255, 0);   (* subnet mask *)
M0 := L02_SET_IP(xApplyIp, IP_PLC_GATEWAY, 192, 168, 1, 1);  (* gateway     *)

(* Modbus TCP server on port 502. *)
M0 := MB_SLAVE_INIT_TCP(M8013, 502);
```

Feeding the one-second clock `M8013` into `xInit` re-applies the server mode every second, exactly as the RS485 initialisation functions are re-triggered after startup.

> - When this function is used, do not write `D8395` from the application — it owns that register.

- Every `L02_SET_IP` write sets `M8197` and restarts the L02 interface, including the value written to `R23812`. Write the addresses first and call `MB_SLAVE_INIT_TCP` afterwards.
- Server mode is mutually exclusive with the `MB_PORT_TCP` client channels: one PLC cannot poll remote servers and serve requests as a slave over the same port at the same time. Select one role per project.

Notes

- `iPort := MB_PORT_TCP` is mandatory; if it is left at an RS485 port, the channel is driven on that serial port instead of the Ethernet port.
- The IP addresses are written explicitly by the `L02_SET_IP` calls above; re-pulse `xSaveIp` after any address change so that the new addresses are applied.
- `M8062` (Modbus timeout) and `M8395` (connection flag) are network indications that complement the driver's per-channel `mb_iTimeout` output. The suspend/retry policy is the same as for an RS485 channel.

EtherNet/IP Scanner

The L02 built-in Ethernet port can run either a Modbus TCP role (this library) or the EtherNet/IP scanner role (this chapter). The IP addresses of both roles are written with `L02_SET_IP` from the `Utils` library. The scanner role is configured with two functions: `EIP_INIT` selects the protocol and the number of remote couplers, `EIP_INIT_REMOTE` writes the point configuration of each coupler. The values are applied by the `L02_SET_IP` call that sets `M8197`, so the configuration order inside one scan is `EIP_INIT` → `EIP_INIT_REMOTE` (×4) → `L02_SET_IP` (PLC IP, mask, gateway, remote addresses).

The expansion capacity of the PLC is **512 DI**, **512 DO**, **50 AI** and **50 AO** points in total; these limits cover all enabled couplers together.

Device	Value	Meaning
`D8395`	`0`	Protocol selector: EtherNet/IP. Written by `EIP_INIT`
`D8325`	`1`–`4`	Number of remote couplers. Written by `EIP_INIT`
`R23830` / `R23840` / `R23850` / `R23860`	—	Block base of coupler 1 / 2 / 3 / 4 (`IP_REMOTE1` … `IP_REMOTE4`)

Each coupler owns a ten-register block. Within a block the point counts are located at fixed offsets from the base:

Offset	Register (coupler 1)	Meaning
`+4`	`R23834`	DI points
`+5`	`R23835`	AI points
`+6`	`R23836`	DO points
`+7`	`R23837`	AO points

> **Note:** the register order is DI, **AI**, **DO**, AO — AI precedes DO, which differs from the argument order of `EIP_INIT_REMOTE`.

`EIP_INIT`

Selects the EtherNet/IP protocol and sets the number of remote couplers while `xInit` is `TRUE`. `iModules` is clamped to `1`–`4` and written to `D8325`; `D8395` is set to `0`.

Variable	Scope	Type	Description
`xInit`	INPUT	BOOL	Trigger. The configuration is written while this input is `TRUE`
`iModules`	INPUT	INT	Number of remote couplers, clamped to `1`–`4` and written to `D8325`

Example:

```
xEipDone := EIP_INIT(M8002, 2);   (* EtherNet/IP, 2 remote couplers *)
```

> **Trigger (`xInit`):** pass a bit that is `TRUE` for **one scan only** (`M8002`, `MEP` of an HMI "save" pulse) and never tie `xInit` to `TRUE`. `EIP_INIT` returns `xInit`.

> **Note:** `EIP_INIT` writes `D8325` and `D8395` only — it does not touch `M8197`. The values become active on the `L02_SET_IP` call of the same scan. Do not write `D8325` or `D8395` from the application while this function is used.

`EIP_INIT_REMOTE`

Writes the point configuration (DI, DO, AI, AO) of one remote coupler into its register block. The body is an explicit `CASE iRemote OF` with integer labels `1`–`4` and the R registers written literally — no address arithmetic. The L02 expansion capacity is **512 DI**, **512 DO**, **50 AI** and **50 AO** points in total; each value is clamped to its own capacity (`0`–`512` for DI and DO, `0`–`50` for AI and AO). Any other value of `iRemote` writes nothing.

Variable	Scope	Type	Description
`iRemote`	INPUT	INT	Coupler selector — one of the `EIP_REMOTE1` … `EIP_REMOTE4` constants (`1`–`4`)
`iDI`	INPUT	INT	Number of DI points, clamped to `0`–`512` — written to `R23834` / `R23844` / `R23854` / `R23864`
`iDO`	INPUT	INT	Number of DO points, clamped to `0`–`512` — written to `R23836` / `R23846` / `R23856` / `R23866`
`iAI`	INPUT	INT	Number of AI points, clamped to `0`–`50` — written to `R23835` / `R23845` / `R23855` / `R23865`
`iAO`	INPUT	INT	Number of AO points, clamped to `0`–`50` — written to `R23837` / `R23847` / `R23857` / `R23867`

> **Note:** the capacity limits apply to the **whole PLC**, not to one coupler. The function clamps each value to its own limit but does not verify the sum, so the application must keep the totals over all enabled couplers within 512 DI, 512 DO, 50 AI and 50 AO points.

Register written per coupler (the column order is the register order DI, AI, DO, AO):

Coupler	DI	AI	DO	AO
EIP_REMOTE1	R23834	R23835	R23836	R23837
EIP_REMOTE2	R23844	R23845	R23846	R23847
EIP_REMOTE3	R23854	R23855	R23856	R23857
EIP_REMOTE4	R23864	R23865	R23866	R23867

Example:

```
(* Four remote couplers, written once from PRG_INIT (M8002 execution condition). *)
xDone := EIP_INIT_REMOTE(EIP_REMOTE1, 8, 8, 4, 2);   (* 8 DI, 8 DO, 4 AI, 2 AO *)
xDone := EIP_INIT_REMOTE(EIP_REMOTE2, 16, 16, 0, 0);
xDone := EIP_INIT_REMOTE(EIP_REMOTE3, 0, 0, 8, 0);
xDone := EIP_INIT_REMOTE(EIP_REMOTE4, 4, 4, 2, 2);
```

> **Note:** EIP_INIT_REMOTE has no trigger input and writes on every call, so call it from PRG_INIT or gate the call with a one-scan pulse. It performs no return assignment, so its result is always the default (FALSE); the function is used for its device side effect.

> **Coupler selector constants:** EIP_REMOTE1 … EIP_REMOTE4 are the values 1–4. They are not the same as IP_REMOTE1 … IP_REMOTE4, which are the R register base addresses (23830 … 23860).

Remote I/O Access

The remote points are mapped into the PLC device areas with a fixed stride per coupler. Six functions give typed, bounds-checked access to those devices — the coupler is selected with the EIP_REMOTE1 … EIP_REMOTE4 constants and iNum is a **0-based** point number inside that coupler.

Function	Call	Returns
EIP_DI	EIP_DI(iRemote, iNum)	BOOL — state of a digital input
EIP_DO	EIP_DO(iRemote, iNum)	BOOL — state of a digital output
EIP_DO_SET	EIP_DO_SET(iRemote, iNum, xVal)	BOOL — the value written
EIP_AI	EIP_AI(iRemote, iNum)	INT — raw analog input value
EIP_AO	EIP_AO(iRemote, iNum)	INT — value last written to an analog output
EIP_AO_SET	EIP_AO_SET(iRemote, iNum, iVal)	INT — the value written

Device map (point count per coupler and the resulting device range):

Area	Points per coupler	Coupler 1	Coupler 2	Coupler 3	Coupler 4
DI	200	M5000–M5199	M5200–M5399	M5400–M5599	M5600–M5799

Area	Points per coupler	Coupler 1	Coupler 2	Coupler 3	Coupler 4
DO	200	M6000–M6199	M6200–M6399	M6400–M6599	M6600–M6799
AI	50	R23100–R23149	R23150–R23199	R23200–R23249	R23250–R23299
AO	50	R23300–R23349	R23350–R23399	R23400–R23449	R23450–R23499

Example:

```
(* Digital inputs of coupler 2, point 5 = M5205 *)
IF EIP_DI(EIP_REMOTE2, 5) THEN
    iCounter := iCounter + 1;
END_IF;

(* Switch digital output 7 of coupler 1 = M6007 *)
For

(* Analog input 3 of coupler 4 = R23253, scaled to engineering units *)
iValue := F_SCALE(EIP_AI(EIP_REMOTE4, 3), 0, 4000, 0, 1000, FALSE);

(* Analog output 0 of coupler 2 = R23350 *)
iWritten := EIP_AO_SET(EIP_REMOTE2, 0, 2000);
```

> **Range clamping:** arguments are clamped with `LIMITATION`, never rejected — `iRemote` to `1`–`4` and `iNum` to `0`–`199` (DI, DO) or `0`–`49` (AI, AO). An out-of-range call therefore reads/writes the nearest valid point instead of silently doing nothing, which also keeps a mis-indexed write inside the remote I/O area instead of escaping to another device.

> **Address space vs. capacity:** the device map above reserves 200 DI, 200 DO, 50 AI and 50 AO per coupler (fixed stride), while the L02 scanner accepts **512 DI, 512 DO, 50 AI and 50 AO in total**. With three or four couplers the reserved slots exceed the total capacity, so `EIP_INIT_REMOTE` must be called with point counts that keep the *sum* inside those limits — the functions do not verify the sum.

> **Index registers:** the functions use `Z0` (bit areas) and `Z1` (word areas) to address the device. Do not rely on the contents of `Z0`/`Z1` across these calls, and do not use those two index registers for the application's own indexed addressing.

> **Role exclusivity:** `D8395` holds one protocol selector for the whole port — `0` = EtherNet/IP scanner, `3` = Modbus TCP server, `4` = Modbus TCP client. The EtherNet/IP scanner and the Modbus TCP roles are mutually exclusive; whichever POU runs last in a scan wins, so configure only one role per project.

> **Library dependency:** the `EIP_*` functions are part of this library; `L02_SET_IP` and the `IP_*` constants belong to the `Utils` library, and `F_SCALE` used in the example above is also a `Utils` function.

Timeout and Suspension Mechanism

The library implements a channel-suspension policy for fault tolerance. If a channel fails to receive a response for `mb_iTimeoutCount` consecutive attempts, it is flagged as **suspended**. Once suspended, the channel is polled at a reduced rate — once every `mb_iSuspendRetry` interval. As soon as a valid response is received,

the suspension flag is cleared and the channel resumes its normal cycle interval as defined by `MB_CHANNELS[*].tCycle`.

When a request times out, `MB_PROCESS_50.mb_iTimeout` reports the index of the failing channel (0-based) for one scan and is `-1` otherwise. This output can be used to react to a specific channel timing out, e.g. to latch an alarm or log the event.

A request that completes within its time window is always counted as a success, even if the completion arrives in the same block call as the timeout deadline. Set `mb_iTimeoutTime` comfortably longer than the expected request and response round-trip time and account for the block's call interval (see Timeout Tuning above); if it is too short, every request is abandoned as timed out, the channel never clears its timeout counter, and it enters the suspend/retry loop.