

Fastener Torque Schedule

Bracket Assembly / antenna deployment mechanism

Position	Fastener	Torque	Preload

M4-1	M4x12 A2-70	2.8 Nm	+/- 0.2 Nm
M4-2	M4x12 A2-70	2.8 Nm	+/- 0.2 Nm
Base-1..4	M3x8 A2-70	1.2 Nm	+/- 0.1 Nm

Sequence

1. Seat all fasteners hand-tight before torquing.
2. Torque the base fasteners diagonally, then the M4 pair.
3. Re-check the base fasteners after the M4 pair is set.

Lubrication

Dry. Values assume no thread lubricant. A lubricated thread reaches the same preload at roughly 70% of the torque above, so do not substitute without recalculating.

Inspection and Rework

Page 2 of the torque schedule

Witness marking

Mark every torqued fastener with a continuous line across the head, washer and substrate. A broken line at a later inspection means the joint moved and must be re-torqued.

Rework limits

Two re-torques per position. A third means the insert is replaced, not the fastener.

Records

Log the wrench serial number and calibration date against each assembly serial. Torque values without a traceable wrench are not acceptance evidence.