# **Lab 1.5.2: Basic Router Configuration**

# **Topology Diagram**



# **Addressing Table**

Device	Interface	IP Address	Subnet Mask	Def. Gateway
R1	Fa0/0	192.168.1.1	255.255.255.0	N/A
KI	S0/0/0	192.168.2.1	255.255.255.0	N/A
R2	Fa0/0	192.168.3.1	255.255.255.0	N/A
KZ	S0/0/0	192.168.2.2	255.255.255.0	N/A
PC1	N/A	192.168.1.10	255.255.255.0	192.168.1.1
PC2	N/A	192.168.3.10	255.255.255.0	192.168.3.1

# **Learning Objectives**

Upon completion of this lab, you will be able to:

- Cable a network according to the Topology Diagram.
- Erase the startup configuration and reload a router to the default state.
- Perform basic configuration tasks on a router.
- Configure and activate Ethernet interfaces.
- Test and verify configurations.
- Reflect upon and document the network implementation.

# **Scenario**

In this lab activity, you will create a network that is similar to the one shown in the Topology Diagram. Begin by cabling the network as shown in the Topology Diagram. You will then perform the initial router configurations required for connectivity. Use the IP addresses that are provided in the Topology Diagram to apply an addressing scheme to the network devices. When the network configuration is complete, examine the routing tables to verify that the network is operating properly. This lab is a shorter version of **Lab 1.5.1: Cabling a Network and Basic Router Configuration** and assumes you are proficient in basic cabling and configuration file management.

#### Task 1: Cable the Network.

Cable a network that is similar to the one in the Topology Diagram. The output used in this lab is from 1841 routers. You can use any current router in your lab as long as it has the required interfaces as shown in the topology. Be sure to use the appropriate type of Ethernet cable to connect from host to switch, switch to router, and host to router. Refer to **Lab 1.5.1: Cabling a Network and Basic Router Configuration** if you have any trouble connecting the devices. Be sure to connect the serial DCE cable to router R1 and the serial DTE cable to router R2.

Answer the following questions:

What type of cable is used to connect the Ethernet interface on a host PC to the Ethernet interface on a switch? **Straight through cable** 

What type of cable is used to connect the Ethernet interface on a switch to the Ethernet interface on a router? **Straight through Cable** 

What type of cable is used to connect the Ethernet interface on a router to the Ethernet interface on a host PC? \_ Crossover cable \_

#### Task 2: Erase and Reload the Routers.

#### Step 1: Establish a terminal session to router R1.

Refer to Lab 1.5.1, "Cabling a Network and Basic Router Configuration," for review of terminal emulation and connecting to a router.

#### Step 2: Enter privileged EXEC mode.

Router>enable
Router#

#### Step 3: Clear the configuration.

To clear the configuration, issue the **erase startup-config** command. Press **Enter** when prompted to [**confirm**] that you really do want to erase the configuration currently stored in NVRAM.

```
Router#erase startup-config
Erasing the nvram filesystem will remove all files! Continue? [confirm]
[OK]
Erase of nvram: complete
Router#
```

#### Step 4: Reload configuration.

When the prompt returns, issue the reload command. Answer no if asked to save changes.

What would happen if you answered **yes** to the question, "System configuration has been modified. Save?"

# The router would bootup with a configuration, extended setup will ask to configure each interface on the system

The result should look something like this:

```
Router#reload
```

```
System configuration has been modified. Save? [yes/no]: no Proceed with reload? [confirm]
```

Press **Enter** when prompted to [confirm] that you really do want to reload the router. After the router finishes the boot process, choose not to use the AutoInstall facility, as shown:

```
Would you like to enter the initial configuration dialog? [yes/no]: no Would you like to terminate autoinstall? [yes]: [Press Return] Press Enter to accept default.

Press RETURN to get started!
```

# Step 5: Repeat Steps 1 through 4 on router R2 to remove any startup configuration file that may be present.

# Task 3: Perform Basic Configuration of Router R1.

Step 1: Establish a HyperTerminal session to router R1.

#### Step 2: Enter privileged EXEC mode.

```
Router>enable Router#
```

#### Step 3: Enter global configuration mode.

```
Router#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#
```

# Step 4: Configure the router name as R1.

Enter the command hostname R1 at the prompt.

```
Router(config) #hostname R1
R1(config) #
```

#### Step 5: Disable DNS lookup.

Disable DNS lookup with the no ip domain-lookup command.

```
R1(config) #no ip domain-lookup
R1(config) #
```

Why would you want to disable DNS lookup in a lab environment?

#### If it is not disabled, the router would look up a DNS entry for any incorrect command

What would happen if you disabled DNS lookup in a production environment?

A switch would not have the option to determine names leading to potential issues when the switch needs an IP address for to address a parcel.

#### Step 6: Configure the EXEC mode password.

Configure the EXEC mode password using the enable secret password command. Use class for the password.

```
R1(config) #enable secret class
R1(config) #
```

Why is it not necessary to use the enable password password command?

# enable secret Command overrides the enable password command

# Step 7: Configure a message-of-the-day banner.

Configure a message-of-the-day banner using the banner motd command.

```
R1(config) #banner motd &
Enter TEXT message. End with the character '&'.
***************
!!!AUTHORIZED ACCESS ONLY!!!
***********************
&
R1(config) #
```

When does this banner display?

#### When user logins into the router

Why should every router have a message-of-the-day banner?

### To provide a waring

#### Step 8: Configure the console password on the router.

Use cisco as the password. When you are finished, exit from line configuration mode.

```
R1(config) #line console 0
R1(config-line) #password cisco
R1(config-line) #login
R1(config-line) #exit
R1(config) #
```

#### Step 9: Configure the password for the virtual terminal lines.

Use cisco as the password. When you are finished, exit from line configuration mode.

```
R1(config) #line vty 0 4
R1(config-line) #password cisco
R1(config-line) #login
R1(config-line) #exit
R1(config) #
```

#### Step 10: Configure the FastEthernet0/0 interface.

Configure the FastEthernet0/0 interface with the IP address 192.168.1.1/24.

```
R1(config) #interface fastethernet 0/0
R1(config-if) #ip address 192.168.1.1 255.255.255.0
R1(config-if) #no shutdown
```

```
%LINK-5-CHANGED: Interface FastEthernet0/0, changed state to up
%LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/0, changed
state to up
R1(config-if)#
```

#### Step 11: Configure the Serial0/0/0 interface.

Configure the Serial0/0/0 interface with the IP address 192.168.2.1/24. Set the clock rate to 64000.

Note: The purpose of the clock rate command is explained in Chapter 2: Static Routes.

```
R1(config-if)#interface serial 0/0/0
R1(config-if)#ip address 192.168.2.1 255.255.255.0
R1(config-if)#clock rate 64000
R1(config-if)#no shutdown
R1(config-if)#
```

Note: The interface will be activated until the serial interface on R2 is configured and activated

#### Step 12: Return to privileged EXEC mode.

Use the end command to return to privileged EXEC mode.

```
R1(config-if)#end
R1#
```

#### Step 13: Save the R1 configuration.

Save the R1 configuration using the copy running-config startup-config command.

```
R1#copy running-config startup-config Building configuration...
[OK]
R1#
```

What is a shorter version of this command? Copy run start

#### Task 4: Perform Basic Configuration of Router R2.

#### Step 1: For R2, repeat Steps 1 through 9 from Task 3.

#### Step 2: Configure the Serial 0/0/0 interface.

Configure the Serial 0/0/0 interface with the IP address 192.168.2.2/24.

```
R2(config) #interface serial 0/0/0
R2(config-if) #ip address 192.168.2.2 255.255.255.0
R2(config-if) #no shutdown
%LINK-5-CHANGED: Interface Serial0/0/0, changed state to up
%LINEPROTO-5-UPDOWN: Line protocol on Interface Serial0/0/0, changed state to up
R2(config-if) #
```

# Step 3: Configure the FastEthernet0/0 interface.

Configure the FastEthernet0/0 interface with the IP address 192.168.3.1/24.

```
R2(config-if)#interface fastethernet 0/0
R2(config-if)#ip address 192.168.3.1 255.255.255.0
R2(config-if)#no shutdown
%LINK-5-CHANGED: Interface FastEthernet0/0, changed state to up
%LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/0, changed state to up
R2(config-if)#
```

#### Step 4: Return to privileged EXEC mode.

Use the end command to return to privileged EXEC mode.

```
R2(config-if)#end
R2#
```

# Step 5: Save the R2 configuration.

Save the R2 configuration using the copy running-config startup-config command.

```
R2#copy running-config startup-config Building configuration...
[OK]
R2#
```

# Task 5: Configure IP Addressing on the Host PCs.

# Step 1: Configure the host PC1.

Configure the host PC1 that is attached to R1 with an IP address of 192.168.1.10/24 and a default gateway of 192.168.1.1.

#### Step 2: Configure the host PC2.

Configure the host PC2 that is attached to R2 with an IP address of 192.168.3.10/24 and a default gateway of 192.168.3.1.

# Task 6: Verify and Test the Configurations.

#### Step 1: Verify that routing tables have the following routes using the show ip route command.

The **show ip route** command and output will be thoroughly explored in upcoming chapters. For now, you are interested in seeing that both R1 and R2 have two routes. Both routes are designated with a c. These are the directly connected networks that were activated when you configured the interfaces on each router. If you do not see two routes for each router as shown in the following output, proceed to Step 2

```
R1#show ip route
```

```
Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
    D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
    N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
    E1 - OSPF external type 1, E2 - OSPF external type 2
    i - IS-IS, su - IS-IS summary, L1 - IS-IS level-1, L2 - IS-IS level-2
    ia - IS-IS inter area, * - candidate default, U - per-user static route
    o - ODR, P - periodic downloaded static route

Gateway of last resort is not set

C    192.168.1.0/24 is directly connected, FastEthernet0/0
    192.168.2.0/24 is directly connected, Serial0/0/0
```

#### R2#show ip route

```
Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
    D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
    N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
    E1 - OSPF external type 1, E2 - OSPF external type 2
    i - IS-IS, su - IS-IS summary, L1 - IS-IS level-1, L2 - IS-IS level-2
    ia - IS-IS inter area, * - candidate default, U - per-user static route
    O - ODR, P - periodic downloaded static route

Gateway of last resort is not set

C 192.168.2.0/24 is directly connected, Serial0/0/0
```

# Step 2: Verify interface configurations.

Another common problem is router interfaces that are not configured correctly or not activated. Use the **show ip interface brief** command to quickly verify the configuration of each router's interfaces. Your output should look similar to the following:

#### R1#show ip interface brief

Interface	IP-Address	OK? Method Status	Protocol
FastEthernet0/0	192.168.1.1	YES manual <mark>upup</mark>	
FastEthernet0/1	unassigned	YES unset administratively down	down
Serial0/0/0	192.168.2.1	YES manual <mark>up</mark>	<mark>up</mark>
Serial0/0/1	unassigned	YES unsetadministratively down	down
Vlan1	unassigned	YES manual administratively do	wn down

192.168.3.0/24 is directly connected, FastEthernet0/0

# R2#show ip interface brief Interface IP-Address OK? Method Status Protestation of the state of th Protocol

Cton	2.	Toot	0000	ectivity.	
Sten	3:	Lest	conr	iectivity.	

		192.168.2.2	YES	manual	up	up
		_		unset	down	down
Vlan1	<u> </u>	unassigned	YES	manual	administratively do	own down
	interfaces are <b>up</b> and <b>up</b> ip route command.	, then both routes will	be i	n the rout	ng table. Verify this again	by using the
Step 3	3: Test connectivity.					
Test co	onnectivity by pinging fror	n each host to the def	ault	gateway t	hat has been configured fo	or that host.
From t	the host attached to R1, is	s it possible to ping the	e def	ault gatew	/ay? <b>Yes</b>	
From t	the host attached to R2, is	s it possible to ping the	e def	ault gatew	/ay? <u>Yes</u>	
	answer is <b>no</b> for any of the lowing systematic proces	-	uble	shoot the	configurations to find the	error using
1.	Check the PCs.					
	Are they physically condinectly.) _ Yes	nected to the correct r —	oute	r? (Conne	ection could be through a	switch or
	Are link lights blinking o	n all relevant ports?_	<u>Y</u>	es	<u>-</u>	
2.	Check the PC configura	ations.				
	Do they match the Topo	ology Diagram? Yes				
3.	Check the router interfa	ces using the show	ip i	nterfac	e briefcommand.	
	Are the interfaces <b>up</b> ar	nd <b>up</b> ? <u>Yes</u>	_			
If your	answer to all three steps	is <b>yes</b> , then you shou	ıld be	e able to s	successfully ping the defar	ult gateway.
Step 4	4: Test connectivity betv	veen router R1 and F	R2.			
From t	the router R1, is it possible	e to ping R2 using the	com	nmandpi	ng 192.168.2.2? <u> </u>	<u>es</u> _
From t	the router R2, is it possible	e to ping R1 using the	com	nmandpi	ng 192.168.2.1? <u>Yes</u>	
	answer is <b>no</b> for the questing systematic process:	ions above, troublesh	oot t	he configi	urations to find the error u	sing the
1.	Check the cabling.					
	Are the routers physical	ly connected? Yes				
	Are link lights blinking o	n all relevant ports?_	Yes		<u>-</u>	
2.	Check the router config	urations.				
	Do they match the Topo	ology Diagram? <u>Yes</u>				
	Did you configure the c	lock rate command	d on	the DCE	side of the link? Yes	
3.	Check the router interfa	ces using the show	ip i	nterfac	e briefcommand.	

Are the interfaces "up" and "up"? Yes

If your answer to all three steps is **yes**, then you should be able to successfully ping from R2 to R1 and from R2 to R3.

#### Task 7: Reflection

#### Step 1: Attempt to ping from the host connected to R1 to the host connected to R2.

This ping should be unsuccessful.

# Step 2: Attempt to ping from the host connected to R1 to router R2.

This ping should be unsuccessful.

#### Step 3: Attempt to ping from the host connected to R2 to router R1.

This ping should be unsuccessful.

What is missing from the network that is preventing communication between these devices?

# The network is missing routing

#### **Task 8: Documentation**

On each router, capture the following command output to a text (.txt) file and save for future reference.

- show running-config
- show ip route
- show ip interface brief

If you need to review the procedures for capturing command output, refer to Lab 1.5.1, "Cabling a Network and Basic Router Configuration."

# Task 9: Clean Up

Erase the configurations and reload the routers. Disconnect and store the cabling. For PC hosts that are normally connected to other networks (such as the school LAN or to the Internet), reconnect the appropriate cabling and restore the TCP/IP settings.