

Seating Depth Explained

Seating Depth Tuning

Powder controls timing, seating depth controls bullet alignment.

- Measure lands with BTO
- Start at 0.020–0.040 off lands
- Adjust in 0.005–0.010 increments