	ShutdowntriggerWriteRe	RangEst_MemoryCurrInter_P RangEst_MemoryODOInfo_P	
CtAp_NVMApp	ImmediateWrite	GearMgmt_MemoryGearInfo_P TBD	
			OvE194 Dood active diagnostic session
			0xF186 Read active diagnostic session 0xF187 Read ECU Part Number
			OxF18A System supplier identifier OxF18B Read ECU manufacturing date
			0xF18C Read ECU Serial Number
			0xF101 Bootloader version number 0xF102 Operational reference
		ECU Identification	0xF192 Supplier ECU hardware part number
			0xF104 ECU application software (ASW) part number
			0x016C HV Status and Charging Status 0xF104 ECU application software (ASW) part
			number 0xF011 Read Levell OEM_Key written status
			0xF013 Read Level2 OEM_Key written status
			0xF015 Read Level3 OEM_Key written status 0xF017 Read Level4 OEM_Key written status
	\$22		0x1D01 VCU_AccPealparameter
			OxID02 VCU_Torque parameter OxID03 Driver Mode
			0x1D04 VCU_PowerMaxAllowed parameter1
			0x1D05 AC_charging parameter0x1D06 Chargestatus
Middle software			0x1D07 Electronic lock state
			OxID08 VCU HV InterLock PWM pfrequency 0xID09 S2 status
		Stored Data	0x1D10 VCU_PowerMaxAllowed parameter2
			OxIDI1 VCU control main relay OxIDI2 PWT vehicle fault Level
			0xFIA0 DID 0x0020
			0xF1A1 Battery Voltage 0xF1A2 Total Odometer
			0xF1A3 Vehicle speed
			0xF1A4 Date And Time 0xF1A5 VCU_HVStatus
			0xFIA6 SOC
	¢ Z I	Pouting Central	0xF1A7 Gear 0x0203 CheckProgrammingPreCondition
	\$31	P110012 Accelerator pedal opening signal 1	0xF000 Turn Off HV &Turn Off Charging
		Short-circuits the power supply P110112 Accelerator pedal opening signal 2	
		Short-circuits the power supply P110211 Accelerator pedal opening signal 1	
		Short circuit to ground P110311 Accelerator pedal opening signal 2	
		Short circuit to ground P11041E Accelerator pedal opening signal 1	
		and opening signal 2 are abnormal P110A1E Brake pedal signal switch is improper	
CtAp_DiagnosticApp	-	P110B1E The brake pedal function is improper	
		P111152 Read and write of the RAM are abnormal. Procedure	
		P111252 EEPROM initialization fails. P111352 EEPROM reading failure	
		P111E71 AC charging gun electronic lock close abnormally	
		P111F16 Input voltage of the AC charging gun for OBC is too low	
		P11291C VCU high voltage interlock is faulty P11309A DC and AC charging guns are	
		pluged together P113197 AC charging S2 closed abnormally	
		P113297 CP connection exception	
		P113497 Slow charge OBC preheating function is abnormal	
		P113597 Charging preheating main negative relay open abnormally	
		P113697 Charging preheating main negative relay close abnormally	
		P113797 DC charging relay is not closed normally	
		P113897 DC charging CRM (SPN2560=0x00) response timeout	
		P113997 DC charging CRM (SPN2560=0xAA) response timeout	
		P114097 DC charging CML response timeout P114197 DC charging CRO(SPN283=0x00)	
		response timeout P114297 DC charging CRO(SPN283=0xAA)	
		response timeou P114397 DC charging CCS response timeout	
		P114497 DC charging CST response timeout	
		P114571 AC charging gun electronic lock open abnormally	
		P114697 KL15e relay close abnormally P114792 LV Power-on failure fault for HV system	
	DTC	P114892 HV Power-on fault for BMS	
		P114992 HV Power-on fault for MCU P115092 Stop POD timeout fault	
		P115092 Stop POD timeout fault P115192 Stop TCU timeout fault	
		P115292 Power-off fault for BMS P115392 Enable MCU timeout fault	
		P115392 Enable MCU timeout fault P115492 Close MCU timeout fault	
		P115592 Enable POD timeout fault P115692 Enable TCU timeout fault	
		P11571E Accelerator pedal opening signal 1 and the opening signal 2 are different	
		P115816 Output voltage of the AC charging for OBC is too low	
		P11591E Accelerator pedal opening signal 1 && the opening signal 2 are different and	
		one abnormal signal B108017 Low-voltage system overvoltages	
		B108116 Low voltage system undervoltage U007388 Control Module Communication	
		U007388 Control Module Communication Bus "A" Off U007488 Control Module Communication	
		Bus "B" Off U010387 Lost Communication With Gear	
		Shift Control Module (0x145) U011087 Lost Communication With Drive	
		Motor Control Module U011187 Lost Communication With Battery	
		Energy Control Module U011D87 Lost Communication With All Wheel	
		Drive Control Module U012187 Lost Communication With Airbag Control Module	
		Control Module U012387 Lost Communication With Yaw Rate Sensor Module (0x130)	
		U012987 Lost Communication With Integrated Brake System	
		U014087 Lost Communication With Body Control Module	
		U014787 Lost Communication With Gateway	
		U016687 Lost Communication With Auxiliary Heater Control Module	
		U019687 Lost Communication With Entertainment Control Modul	
		U019987 Lost Communication With "Door	

U019987 Lost Communication With "Door Control Module A"

U019B87 Lost Communication With Battery Charger Control Module

- Ull0587 Lost Communication With ADCU