## 密级: 内部公开

## mx53 SD/MMC 烧写步骤


- 1、设置拨码开关为: 00100111; mx53 启动时会进入串行下载模式; 注意: 拨码开关打开 ON 一侧为 1,另一侧为 0。电路板上的拨码开关较小,使用镊子轻轻一拨即可。
- 2、使用 USB 线连接 mx53 与笔记本; 电路板上电后,电脑显示发现新硬件,安装位于烧写软件目录下的驱动程序 Drivers/iMX\_BulkIO\_Driver/i386



3、打开 MFGTool.exe 烧写软件;



4、配置软件,选择烧写 USB 端口及烧写文件;Options->Configurations...



邮箱: info@bioequ.com.cn

网址: <u>www.bioequ.com.cn</u>

密级:内部公开

在 Profiles 选项卡下选择烧写文件,这里直接选择 IMB\_DCI 就好了,因为烧写控制文件 ucl.xml 已经写好了。




在 USB Ports 选项下选择被 Windows 识别的下载口,在前面打对勾。注意,如果驱动没有安装的话,此处是不会显示的。所以必须要先安装好 BulkIO 驱动程序。



单击窗口右边的"开始"按钮,开始烧写芯片。

## 密级: 内部公开



- 5、烧写完成后,将拨码开关设置为: 00100110, 让 mx53 从 Nand Flash 启动。
- 6、使用串口线接电路板上的 TxD、RxD、GND 经 Max3232 电平转换芯片后直接连接 USB 转串口线上。电脑端必须 安装 USB 转串口线的驱动程序。(自己找个 max3232 焊个小板或者是借用别的电路板上的 max3232,飞几根线也可以)。
- 7、在电脑端, 打开超级终端, 配置参数如下:



邮箱: info@bioequ.com.cn

网址: <u>www.bioequ.com.cn</u>

8、 电路板上电, 信息会从串口输出, 显示在超级终端上, 如果出现乱码, 请检查串口线、电平转换, 重上电。

```
- - X
asfas - 超级终端
文件(F) 编辑(E) 查看(V) 呼叫(C) 传送(T) 帮助(H)
esdhc4 clock :
                          80000000Hz
                          2666666Hz
  nfc clock
  Board: MX53-SMD Rev. A
  Boot Reason: [POR]
Boot Device: MMC
I2C: readv
  DRAM:
  DRAM: 1 GB
MMC: FSL_ESDHC: 0, FSL_ESDHC: 1
*** Warning – bad CRC or MMC, using default environment
  MMC:
  In:
             serial
  Out:
             serial
  Err:
             serial
  Net: got MAC address from IIM: 00:00:00:00:00:00
FEC0 [PRIME]
  Hit any key to stop autoboot:
  MMC read: dev # 0, block # 2048, count 6144 partition # 0 ...
Card did not respond to voltage select!
MMC: block number 0x2000 exceeds max(0x0)
0 blocks read: ERROR
  Wrong Image Format for bootm command ERROR: can't get kernel image! MX53-SMD U-Boot > _
已连接 0:01:03 自动检测 115200 8-N-1 SCROLL CAPS NUM 捕 打印
```

9、配置 uboot, 让 uboot 能找到内核。在超级终端里输入以下命令:

```
- - X
asfas - 超级终端
文件(F) 编辑(E) 查看(V) 呼叫(C) 传送(T) 帮助(H)
In:
           serial
  Out:
           serial
  Err:
           serial
  Net: got MAC address from IIM: 00:00:00:00:00:00
FEC0 [PRIME]
  Hit any key to stop autoboot:
  MMC read: dev # 0, block # 2048, count 6144 partition # 0 ...
Card did not respond to voltage select!
MMC: block number_0x2000 exceeds max(0x0)
  0 blocks read: ERROR
  Wrong Image Format for bootm command ERROR: can't get kernel image!
  MX53-SMD U-Boot > setenv bootargs 'console=ttymxc0,115200 root=/dev/mmcblk0p1 ro
  otwait rw
  MX53-SMD U-Boot > setenv bootcmd_mmc 'run bootargs;mmc read 1 ${loadaddr} 0x800
  0x1800; bootm
  MX53-SMD U-Boot > setenv bootcmd 'run bootcmd_mmc'
MX53-SMD U-Boot > setenv ethaddr 00:01:02:03:04:05
MX53-SMD U-Boot > saveenv
  Saving Environment to MMC.
  Writing to MMC(1)... done
MX53-SMD U-Boot > re_
已连接 0:03:36 自动检测 115200 8-N-1 SCROLL CAPS NUM 捕 打印
```

setenv bootargs 'console=ttymxc0,115200 root=/dev/mmcblk0p1 rootwait rw' setenv bootcmd\_mmc 'run bootargs;mmc read 1 \${loadaddr} 0x800 0x1800;bootm' setenv bootcmd 'run bootcmd\_mmc' saveenv re

地址:北京市通州区北杨洼 251 号 网址: www.bioequ.com.cn

邮箱: info@bioequ.com.cn

密级:内部公开

10、重启电路板后, uboot 引导内核, 内核挂载根文件系统, 进入 shell, 如下:

11、烧写完毕。



shell.albert 2012/12/14