

Samsung Smart Remote - HomeFix Demo Manual

UNOFFICIAL DEMO DOCUMENT FOR HOMEFIX RAG TESTING. This is not an official manufacturer manual and must not replace the product's real manual.

Manufacturer: Samsung

Device type: TV remote control

Model: Generic Smart Remote (demo)

Identifying common controls

Many Samsung Smart Remote models include a Power button, a Home button, a Back button, a directional pad, and a central Select button. Some models include a Source button, while others access inputs through the Home menu.

- Power: turns the television on or off.
- Home: opens the television's main smart menu.
- Back: returns to the previous screen.
- Directional pad and Select: navigate menus and confirm a choice.
- Volume and Channel controls may be rocker-style buttons.

Changing to HDMI

To select an HDMI input, press Home and open the Source or Connected Devices menu. Select the required HDMI input, such as HDMI 1 or HDMI 2. On remotes with a dedicated Source button, press it and choose the input.

- Confirm that the external device is powered on.
- Confirm that the HDMI cable is firmly connected.
- Try another HDMI port if the input shows no signal.

Remote does not respond

Check the batteries or charging state. Point the remote toward the television and try the Power button. If only some functions work, the remote may require pairing.

- Replace batteries with new batteries of the correct type.
- Move close to the television and remove objects blocking the sensor.
- Restart the television by disconnecting power for about one minute.
- Use the official model-specific pairing procedure from the real manual.

When professional service may be needed

A technician may be appropriate if the television does not respond to its physical power button, repeatedly shuts down, smells burnt, shows visible damage, or has no picture on

every input after basic checks.

- Disconnect power if there is smoke, a burning smell, liquid intrusion, or exposed wiring.
- Do not open the television housing.

Useful RAG search phrases

- Samsung Smart Remote HDMI input
- Samsung remote pairing
- Samsung TV no signal HDMI
- Samsung remote buttons not working