

# User Manual of Automated Heat Stress at Work Warning System

Prepared by Amy TSE & Simon NG

### Contents


Setup Instructions	2
Maintenance	9
Monitoring	9
Co-owner	10
Undate Connection	11


# Objective


The Automated Heat Stress at Work Warning System aims to enhance the workplace safety by providing timely alerts to relevant stakeholders. When Hong Kong Labour Department issues a Heat Stress at Work Warning, the system will automatically:


- Notify contractors and engineers via email to ensure immediate awareness.
- Send WhatsApp notifications for rapid communication and accessibility.


## **Setup Instructions**













# 8. Set up the WhatsApp Notification

- I . Add "Apply to each" and "HTTP" actions next to PhoneNumbersArray action.
- II . Configure HTTP action as shown in the image







## Maintenance

### Monitoring

To check your flow's status, navigate to 'My flows' in the left panel. Your created flow will appear either in 'Cloud flows' (for personal web-created flows) or 'Shared with me' (for collaborative flows with multiple owners).





After selecting the flow, the Flow Overview is shown, you'll see its current status including when alerts were last sent, average delivery time, and activation status (on/off), etc.



### Co-owner


You can add co-owner in the Flow Overview by clicking the "Share" button in the Flow Overview.






### **Update Connection**

To alter the sender of the warning email. You may click "Edit" on the Flow Overview Page.



After opening the editing panel of the flow, click the "Send an email(V2)" widget. Then click the "Change connection" button at the bottom of the action panel.



Select the desired sender or add a new connection by signing in that person's account.

