

# Supplementary sheet for installing ELOP II V5.8



## 1 System Requirements

ELOP II V5.8 can be used for all the following operating system versions:

BS41q/51q V7.0-8

ELOP II V5.8 can be used in PCs with the following operating system:

Microsoft® Windows 10

The minimum requirements for the computer used to run ELOP II V5.8 are specified on the current HIMA DVD. In particular with very large projects, old PCs may require long processing times and thus be inappropriate for this task. Therefore, state-of-the-art computers should be used whenever possible. Enhanced hardware features, such as computing power and memory space, result in improved performance.

## 2 Starting the User Interface

Insert the HIMA DVD into the DVD drive. The DVD user interface starts automatically after a few seconds. If certain parameters have been set (if the DVD drive's Auto-Run function is deactivated), the DVD user interface must be started manually. To do so, double-click the index.htm file in the DVD root directory.

- Select German as user interface language.
- Select Document Type, Software Installation from the Filter menu bar.

A list of software products appears. Select the ELOP II V5.8 ZIP file from the list and download it. After unpacking, the ELOP II V5.8 installation can be started.

### 3 Installation

ELOP II V5.8 uses a hardlock as licensing method. Install the hardlock driver and ELOP II V5.8 on the PC. Follow the setup instructions.

#### Installation notes for the hardlock driver:

- 1. Windows administrator rights on the PC are required to install the hardlock driver.
- Ensure that the hardlock is not connected to the PC.If a USB hardlock is used and already plugged in, remove the hardlock and restart the PC.
- Install the hardlock drive and connect the hardlock to the PC. The hardlock is recognized automatically. The LED on the USB hardlock is lit.

## Installation notes for ELOP II V5.8:

- Windows administrator rights on the PC are required to install ELOP II V5.8.
   Once the installation is complete, ELOP II V5.8 can be used with all Windows user accounts of the current work-station. User privileges of the "Users" group are sufficient to operate ELOP II V5.8.
- Have you already installed a previous version of ELOP II?When installing ELOP II V5.8, do not use the same installation directory as the previous version, but create a new installation directory.
- 3. The installation language (e.g., German) is used as default language for ELOP II V5.8. Upon completion of the installation process, however, the language may be changed, e.g., to English using "Administration" in the Control Center.
- 4. The hardlock delivered with ELOP II V5.8 is already activated for this version. If a hardlock for a previous licence is in use, follow the instructions specified in the upgrade supplementary sheet (HI 800 769 E) to activate it.

# 4 Upgrading from a Previous Version to ELOP II V5.8

Observe the following points:

- ELOP II versions as of V3.0 can be installed simultaneously and operated by the same Windows user.
   Separate installation paths must be specified to install different ELOP II versions.
   A new registration is required whenever switching between ELOP II versions. To do so, administrator rights are needed.
- Projects that were created with a version as of V5.1 need not be converted.
- Projects that were created with a version prior to V5.1 need be converted.
   Observe the conversion instructions provided in the New Features ELOP II V5.1 manual (HI 800 185 E).

# 5 Support

For problems occurred during installation or license activation, please contact HIMA technical support.

#### Contact details:

Safety Lifecycle Services https://www.hima.com/en/about-hima/contacts-worldwide/
Technical support https://www.hima.com/en/products-services/support/
Seminar program https://www.hima.com/en/products-services/seminars/