S C - 3 0 0
A L A R M / E V E N T
C O L O R
C O N F I G U R A T I O N
M A N U A L

P R E L I M I N A R Y

D R A F T

Do Not Duplicate or Redistribute
Without Written Permission
By the GE Company

Copyright (C) 1988 General Electric Company, Drives Department, Erie, PA 16531 8/29/88

TABLE OF CONTENTS

1.0	INTRODUCTION	2
2.0	DEFINING ALARM COLORS	3
3.0	DEFINING ALARM REPORTING ZONES	4

Copyright (C) 1988 General Electric Company, Drives Department, Erie, PA 16531 8/29/88

1.0 Introduction

The SETCOLOR tool is used to define both the colors to be used when displaying a point in any alarm condition as well as the routing zones to be used when reporting an alarm condition. These zones are needed when the user defines alarm configurations with the **Alarm Linker** utility. All of the above definitions are stored in the file ONSPEC.DAT. If SETCOLOR is invoked and no ONSPEC.DAT file exists, one will be created with default values.

1.1 Index Terms

Throughout this document, the term **user** refers to the person, male or female, who is using SETCOLOR to define the alarm colors and report routing zones. The term **operator** refers to the person who runs the system after it has been configured, installed, and is on-line.

1.2 Starting SETCOLOR

The SETCOLOR configuration utility is invoked by entering the following at the Concurrent DOS prompt:

>SETCOLOR <cr>

1.3 Required Files

The following file must be present in the current directory/path in order to use SETCOLOR:

SETCOLOR.COM

Copyright (C) 1988 General Electric Company, Drives Department, Erie, PA 16531 8/29/88

2.0 Defining Alarm Colors

The alarm color definition screen is divided into five areas. Area one, **Alarm Palette for Color 130,** is used to define both the background and foreground colors for ingredients which are displayed using color 130. For each alarm priority, event to urgent, the user may select the colors to be displayed when the point is not in alarm (OK), is in digital alarm (DA), is in high alarm (HA), and is in low alarm (LA). Use the arrow keys to move between fields within area one. Use the tab and shift-tab keys to move to another screen area. Screen area two, **Alarm Palette for Color 131,** is identical to screen area one except that its definitions apply to ingredients which are displayed in color 131 instead of color 130.

Area three, **Digital State Palette for Color 128,** is used to define the foreground and background colors used to display the set and reset state of ingredients which are displayed using color 128. As with screen areas one and two, the arrow keys move between fields while the tab and shift-tab keys move to a different screen area. Screen area four, **Digital State Palette for Color 129,** is identical to area three except that its definitions apply to ingredients which are displayed using color 129 instead of color 128.

The last screen area, **Set Point Change Event Message Color,** defines the colors used when displaying a set point change event message on the alarm console. Whenever the operator changes the value of an ingredient, a message is sent to the alarm console reflecting this change. The color in which that message is to be displayed is defined by this field.

For all fields, the foreground and background colors are set by selecting from the palette shown in the upper left hand corner of the screen. Use function key nine to toggle between foreground and background definition. Use function keys one through eight to select a color. For example, to set the foreground color of the current field under the cursor to light green, press F9 until the letters 'FOR' appear in the upper left corner of the screen. Finally, press F3 to switch the foreground color to light green. This changes the letters 'FOR' to light green as well as the foreground of the current field. Once the proper foreground/background has been selected, a field can be changed simply by moving to it using the arrow/tab keys and then pressing the enter key.

After color definition is completed, the user may move to the routing zone definition screen with either the pageup or pagedown keys, or may exit (and optionally save) from the SETCOLOR utility with the escape key.

Copyright (C) 1988 General Electric Company, Drives Department, Erie, PA 16531 8/29/88

3.0 Defining Alarm Report Routing Zones

The alarm report routing zone screen consists of five lines, one for each of the routing zones one through five. Up to four devices can be defined for each zone, plus a single digital output database location for activating a horn or other warning device. The arrow keys are used to move between fields on the screen. To select a device, press one of the function keys one through four. Use function key one to increment the digital output database location when in a HORN field or function key two to decrement the database location. Either the pageup or pagedown key can be used to return to the color definition screen while the escape key is used to exit (and optionally save) from the SETCOLOR utility.

Copyright (C) 1988 General Electric Company, Drives Department, Erie, PA 16531 8/29/88