

7/11/2026

Some other irrelevant content for this issue

If the remote controller doesn't respond, first replace the batteries.

If that doesn't help, restart the router and TV.

If the issue persists, visit the closest branch office to get the remote controller replaced.

Router restart procedure:

Unplug the router power cable, wait 10 seconds, then plug it back in. Wait for all lights to turn solid before checking your connection again.

Some other irrelevant content for this issue