

最左侧	
核心板	实验箱
GND	PORT1
NC	PORT3
NC	PORT5
NC	PORT7
NC	PORT9
NC	PORT11
PB13	PORT13
PB15	PORT15
PD9	PORT17
PD11	PORT19
PD13	PORT21
PD15	PORT23
PC7	PORT25
PC9	PORT27
PA9	PORT29
PA11	PORT31
PA13	PORT33
GND	PORT35
NC	PORT37
PA15	PORT39
PC11	PORT41
PD0	PORT43
PD2	PORT45
PD4	PORT47
PD6	PORT49
PB3	PORT51
PB5	PORT53
PB7	PORT55
PB8	PORT57
PE0	PORT59
GND	PORT61
NC	PORT63
NC	PORT65
NC	PORT67
NC	PORT69
NC	PORT71
NC	PORT73

左侧中间	
核心板	实验箱
GND	PORT0
NC	PORT2
NC	PORT4
NC	PORT6
NC	PORT8
PB12	PORT10
PB14	PORT12
PD8	PORT14
PD10	PORT16
PD12	PORT18
PD14	PORT20
PC6	PORT22
PC8	PORT24
PA8	PORT26
PA10	PORT28
PA12	PORT30
NC	PORT32
3V3	PORT34
NC	PORT36
PA14	PORT38
PC10	PORT40
PC12	PORT42
PD1	PORT44
PD3	PORT46
PD5	PORT48
PD7	PORT50
PB4	PORT52
PB6	PORT54
BOOT0	PORT56
PB9	PORT58
PE1	PORT60
3V3	PORT62
NC	PORT64
NC	PORT66
NC	PORT68
NC	PORT70
NC	PORT72

右侧中间	
核心板	实验箱
5V	PORT75
NC	PORT77
NC	PORT79
NC	PORT81
NC	PORT83
3V3	PORT85
PB11	PORT87
PE15	PORT89
PE13	PORT91
PE11	PORT93
PE9	PORT95
PE7	PORT97
PB1	PORT99
PC5	PORT101
PA7	PORT103
PA5	PORT105
3V3	PORT107
PA3	PORT109
NC	PORT111
PA2	PORT113
PA0	PORT115
VREF+	PORT117
GND	PORT119
PC2	PORT121
PC0	PORT123
OSCOUT	PORT125
3V3	PORT127
PC15	PORT129
PC13	PORT131
PE6	PORT133
PE4	PORT135
PE2	PORT137
NC	PORT139
NC	PORT141
NC	PORT143
NC	PORT145
NC	PORT147

最右侧	
核心板	实验箱
5V	PORT74
NC	PORT76
NC	PORT78
NC	PORT80
NC	PORT82
NC	PORT84
GND	PORT86
PB10	PORT88
PE14	PORT90
PE12	PORT92
PE10	PORT94
PE8	PORT96
PB2	PORT98
PB0	PORT100
PC4	PORT102
PA6	PORT104
PA4	PORT106
GND	PORT108
NC	PORT110
PA1	PORT112
3V3	PORT114
VREF-	PORT116
PC3	PORT118
PC1	PORT120
NRST	PORT122
OSCIN	PORT124
GND	PORT126
PC14	PORT128
VBAT	PORT130
PE5	PORT132
PE3	PORT134
NC	PORT136
NC	PORT138
NC	PORT140
NC	PORT142
NC	PORT144
NC	PORT146

a	b
	24
	23
	22
	21
	20
	19
	18
	17
	16
	15
	14
	13
	12
	11
	10
	9
	8
	7
	6
	5
	4
	3
	2
	1