

MAX40 Protocol

● Data from PC to ALP-1

Communication set	4800 BAUD , 1 START , 1 STOP , 8 BIT DATA , NONE PARITY
-------------------	---

● Data from PC to ALP-1

No.		Send (PC -> ALP-1)			Response (ALP-1 -> PC)		Note
		ASCII		HEX	ASCII	HEX	
1	connection check	\$I0000		0D 0A	#I7 ~~~~~~	0D 0A	
2	connection end	\$U0000		0D 0A			
3	normal test	\$STARTSENTECH		0D 0A			
4	Fast test	\$FASTSENTECH		0D 0A			
5	Device Stop	\$STOPSENTECH		0D 0A			

● Data from ALP-1 to PC

No.				Send (ALP-1 -> PC)		Note	PC display	
				ASCII	HEX			
1	Ready	Ready state		\$END	0D 0A	commend receive only at "\$STARTSENTECH"	READY	
2	Operation	Stabilization	Cal request	\$CALIBRATION	0D 0A		CALIBRATION	
			Stabilization	\$WAIT	0D 0A		WAIT	
3		Ready for test		\$STANBY	0D 0A		BLOW	
4		Trigger		\$TRIGGER	0D 0A		TRIGGER	
5		Analyzing		\$BREATH	0D 0A		ANALYZING	
6		Result	Normal Mode	%BAC	\$R:xxxx,y,R	0D 0A	xxxx : result "0.000" ~ "0.500" %BAC, 0.501 over "OVER" send y : Z - Zero(PC color "Basic"), L - Low(PC color "Orange"), H - High(PC color "red")	0.000 %BAC
				g/L	\$R:xxxx,y,G	0D 0A	xxxx : 수치 "0.000" ~ "5.000" g/L, 5.001이상 "OVER" send y : Z - Zero(PC color "Basic"), L - Low(PC color "Orange"), H - High(PC color "red")	0.000 g/L
				‰	\$R:xxxx,y,P	0D 0A	xxxx : 수치 "0.000" ~ "5.000" ‰, 5.001이상 "OVER" send y : Z - Zero(PC color "Basic"), L - Low(PC color "Orange"), H - High(PC color "red")	0.000 ‰
				mg/L	\$R:xxxx,y,M	0D 0A	xxxx : 수치 "0.000" ~ "2.500" mg/L, 2.501이상 "OVER" send y : Z - Zero(PC color "Basic"), L - Low(PC color "Orange"), H - High(PC color "red")	0.000 mg/L
				µg/L	\$R:xxxx,y,U	0D 0A	xxxx : 수치 "00000" ~ "02500" µg/L, 2501이상 "OVER" send y : Z - Zero(PC color "Basic"), L - Low(PC color "Orange"), H - High(PC color "red")	0 µg/L
				µg/100mL	\$R:xxxx,y,Z	0D 0A	xxxx : 수치 "00000" ~ "00250" µg/100mL, 251이상 "OVER" send y : Z - Zero(PC color "Basic"), L - Low(PC color "Orange"), H - High(PC color "red")	0 µg/100mL
			Fast Mode	PASS	\$R:PASS	0D 0A		PASS
				FAIL	\$R:FAIL	0D 0A		FAIL
7	Auto power off OFF		\$TIME,OUT	0D 0A		OUT		
8	Error	Flow error		\$FLOW,ERR	0D 0A		FLOW	
9		Battery error		\$BAT,LOW	0D 0A		BAT ERR	
10		Sensor error		\$SENSOR,ERR	0D 0A		SENSOR ERR	
11		System error		\$SYSTEM,ERR	0D 0A		SYSTEM ERR	
12		Module error		\$MODULE,ERR	0D 0A		MODULE ERR	
13		Temperature range error		\$TEMP,ERR	0D 0A		TEMP ERR	
14	ETC	Enter into option		\$OPTION,SET	0D 0A		OPTION	