FAT KARTING LEAGUE

MECHANIC

Your workshop day in KART. From the Workshop App to KART.

STEPS

1. Sign in, choose your hub, tap **Workshop**. It opens in a new tab.
2. Start on **Overview**: check the **Readiness board** against the karts.
3. Open **Service Queue**, tap a kart under **Requires service**, tap **Start service**.
4. On **Servicing** tap each cell: Unchecked, **Good**, **Blocked**. Type readings.
5. Fitted a part? Under **Components replaced** tap **Select**, then **Add to components replaced**. Every part, every time.
6. Stopping work? **Pause** and pick a **Pause reason**. Resume from **Paused services**.
7. Tap **Complete service**, tick the declaration, **Confirm**.
8. Problem on a kart: **Report a kart problem**. An incident is information only; each finding becomes a repair.
9. Must not be used? Raise a stopping reliability ticket (needs Reliability). It takes the kart out of use.
10. Repair done: **Log remedy / complete repair** with the parts used.
11. Campaign tasks: **Campaign work**, **Start work**, fit parts, **Complete work**.
12. Find a kart: **Open kart**, type the number (e.g. 207) or scan the QR.

STATUSES

- **Ready** can race
- **Requires service** used, needs a service (was Turn Required)
- **In Progress** service started
- **Paused** service paused with a reason
- **Repair Needed (usable)** open repair, kart still available
- **Repair Required** must not be used: stopping ticket or blocking repair
- **Campaign Required** open campaign task, kart usable

WATCH OUT

Incidents are information only and never stop a kart. A stopping reliability ticket, an open damage ticket or missing batteries take a kart out of use. After your hub's switch time, never record anything in the Workshop App.

HELP

KART problems: tell your hub manager (hub lead), with the kart number. Help with KART: AI Support in KART Comms first (bookmark the KART address ending in /comms); it escalates to Remote Support or FKL Central. Give the kart number.