

2.2.7 Special Auxiliary Relays (SM)

Every special auxiliary relay has its specific function. Do not use the special auxiliary relays which are not defined.

The special auxiliary relays and their functions are listed as follows. As to the SM numbers marked “*”, users can refer to the additional remarks on special auxiliary relays/special data registers. “R” in the attribute column indicates that the special auxiliary relay can read the data, whereas “R/W” in the attribute column indicates that it can read and write the data. In addition, the mark “—” indicates that the status of the special auxiliary relay does not make any change. The mark “#” indicates that the system will be set according to the status of the PLC, and users can read the setting value and refer to the related manual for more information.

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SM0	Error: the operation or operand exceeds the allowed range	○	○	OFF	OFF	—	N	R	OFF
SM1	Error: the operation or operand exceeds the allowed range is locked.	○	○	OFF	OFF	—	N	R	OFF
SM5	Instruction inspection error	○	○	OFF	OFF	—	N	R	OFF
SM6	Data lost in the latched area	○	○	OFF	—	—	N	R/W	OFF
SM7	Insufficient power supply (24 V)	○	○	OFF	—	—	N	R	OFF
*SM8	Watchdog timer error	○	○	OFF	—	—	N	R	OFF
SM9	System error	○	○	OFF	—	—	N	R	OFF
SM10	I/O bus error	○	○	OFF	—	—	N	R	OFF
*SM22	Clearing the error log	○	○	OFF	OFF	OFF	N	R/W	OFF
SM23	Clearing the download log	○	○	OFF	OFF	OFF	N	R/W	OFF
SM24	Clearing the state-changing log of the PLC	○	○	OFF	OFF	OFF	N	R/W	OFF
SM25	The online-editing processing flag is on when the online-editing mode starts.	○	○	OFF	—	—	N	R	OFF
SM26	The debugging mode processing flag is on when the debugging mode starts.	○	○	OFF	—	—	N	R	OFF
SM27	AS-F2AD: flags for built-in AD errors	○	○	OFF	—	—	N	R	OFF
SM28	Error: the output point is the same as the output that the high speed instruction used	○	○	OFF	OFF	OFF	N	R/W	OFF
SM30	Error in the remote module	○	○	OFF	—	—	N	R	OFF
SM34	Incorrect password	○	○	OFF	—	—	N	R/W	OFF
*SM36	Enable saving data to the memory card. When ON, the PLC runs according to the value in SR36.	○	○	OFF	—	—	N	R/W	OFF
SM76	The data is sent through Function Card 1.	○	—	OFF	OFF	—	N	R/W	OFF
SM77	The data is sent through Function Card 2.	○	—	OFF	OFF	—	N	R/W	OFF
SM78	Waiting to receive the reply through Function Card 1	○	—	OFF	OFF	—	N	R	OFF
SM79	Waiting to receive the reply through Function Card 2	○	—	OFF	OFF	—	N	R	OFF
SM80	Reception through Function Card 1 is complete.	○	—	OFF	OFF	—	N	R/W	OFF
SM81	Reception through Function Card 2 is complete.	○	—	OFF	OFF	—	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SM82	Error during receiving data through Function Card 1 when using the MODRW instruction or the RS instruction.	○	-	OFF	OFF	-	N	R	OFF
SM83	Error during receiving data through Function Card 2 when using the MODRW instruction or the RS instruction.	○	-	OFF	OFF	-	N	R	OFF
SM84	No data received through Function Card 1 after a specified period of time.	○	-	OFF	OFF	-	N	R/W	OFF
SM85	No data received through Function Card 2 after a specified period of time.	○	-	OFF	OFF	-	N	R/W	OFF
SM86	Choice made by Function Card 1 between the 8-bit processing mode and the 16-bit processing mode ON: 8-bit processing mode OFF: 16-bit processing mode	○	-	OFF	-	-	N	R/W	OFF
SM87	Choice made by Function Card 2 between the 8-bit processing mode and the 16-bit processing mode ON: 8-bit processing mode OFF: 16-bit processing mode	○	-	OFF	-	-	N	R/W	OFF
SM90	The communication protocol of Function Card 1 changes	○	-	OFF	-	-	N	R/W	OFF
SM91	The communication protocol of Function Card 2 changes	○	-	OFF	-	-	N	R/W	OFF
SM94	Change in the LED lighting control in COM1	○	○	-	-	-	H	R/W	OFF
SM95	Change in the LED lighting control in COM2	○	○	-	-	-	H	R/W	OFF
*SM96	Data is sent through COM1.	○	○	OFF	OFF	-	N	R/W	OFF
*SM97	Data is sent through COM2.	○	○	OFF	OFF	-	N	R/W	OFF
*SM98	Waiting to receive the reply through COM1	○	○	OFF	OFF	-	N	R	OFF
*SM99	Waiting to receive the reply through COM2	○	○	OFF	OFF	-	N	R	OFF
*SM100	Reception through COM1 is complete.	○	○	OFF	OFF	-	N	R/W	OFF
*SM101	Reception through COM2 is complete.	○	○	OFF	OFF	-	N	R/W	OFF
*SM102	Error during receiving data through COM1 when using the MODRW instruction or the RS instruction.	○	○	OFF	OFF	-	N	R/W	OFF
*SM103	Error during receiving data through COM2 when using the MODRW instruction or the RS instruction.	○	○	OFF	OFF	-	N	R/W	OFF
*SM104	No data received through COM1 after a specified period of time.	○	○	OFF	OFF	-	N	R/W	OFF
*SM105	No data received through COM2 after a specified period of time.	○	○	OFF	OFF	-	N	R/W	OFF
*SM106	Choice made by COM1 between the 8-bit processing mode and the 16-bit processing mode	○	○	OFF	-	-	N	R/W	OFF

SM	Function	AS100/200 Series AS300 Series		OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
	ON: 8-bit processing mode OFF: 16-bit processing mode								
*SM107	Choice made by COM2 between the 8-bit processing mode and the 16-bit processing mode ON: 8-bit processing mode OFF: 16-bit processing mode	○	○	OFF	–	–	N	R/W	OFF
*SM120	I200 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM121	I201 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM122	I202 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM123	I203 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM124	I210 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM125	I211 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM126	I212 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM127	I213 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM128	I220 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM129	I221 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM130	I222 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM131	I223 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM132	I230 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM133	I231 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM134	I232 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM135	I233 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM136	I240 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM137	I241 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM138	I242 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM139	I243 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM140	I250 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM141	I251 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM142	I252 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM143	I253 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM144	I260 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM145	I261 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM146	I262 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM147	I263 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM148	I264 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM149	I265 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM150	I266 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
*SM151	I267 high-speed comparison interrupt for DPLSY to temporarily store output parameters	○	○	OFF	OFF	–	N	R/W	OFF
SM166	VR0 started (works with SR166)	○	○	OFF	–	–	N	R/W	OFF
SM167	VR1 started (works with SR167)	○	○	OFF	–	–	N	R/W	OFF
SM168	The connection for Function Card 1 established.	○	–	–	–	–	N	R	OFF
SM169	Function Card 1 is in operation.	○	–	OFF	–	–	N	R	OFF
SM170	The connection for Function Card 2 established.	○	–	–	–	–	N	R	OFF
SM171	Function Card 12 is in operation.	○	–	OFF	–	–	N	R	OFF
*SM203	When PLC RUN->STOP, it clears the non-latched area once.	○	○	OFF	–	–	N	R/W	OFF
*SM204	All non-latched areas are cleared.	○	○	OFF	OFF	OFF	N	R/W	OFF
*SM205	All latched areas are cleared.	○	○	OFF	OFF	OFF	N	R/W	OFF
SM206	All output is inhibited	○	○	OFF	–	–	N	R/W	OFF
*SM209	The communication protocol of COM1 changes	○	○	OFF	OFF	OFF	N	R/W	OFF
*SM210	Choice made by COM1 between the ASCII mode and the RTU mode ON: RTU mode OFF: ASCII mode	○	○	–	–	–	H	R/W	OFF
*SM211	The communication protocol of COM1 changes	○	○	OFF	OFF	OFF	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM212	Choice made by COM2 between the ASCII mode and the RTU mode ON: RTU mode OFF: ASCII mode	○	○	—	—	—	H	R/W	OFF
SM215	Running state of the PLC	○	○	OFF	ON	OFF	N	R/W	OFF
SM218	Error: real-time clock malfunction	○	○	—	—	—	N	R	OFF
SM219	Error: battery power for the real-time clock is low	○	○	—	—	—	N	R	OFF
*SM220	Calibrating the real-time clock within ±30 seconds	○	○	OFF	OFF	—	N	R/W	OFF
SM221	Enable daylight saving time (D.S.T.)	○	○	—	—	—	H	R	OFF
*SM230	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 1 st module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM231	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 2 nd module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM232	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 3 rd module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM233	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 4 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM234	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 5 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM235	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 6 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM236	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 7 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM237	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 8 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM238	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 9 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM239	When selecting "Manual + Flags" in "I/O allocation	○	○	—	—	—	Y	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
	setting when Power On", use this flag to activate the 10 th module on the right-side of the CPU module.								
*SM240	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 11 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM241	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 12 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM242	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 13 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM243	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 14 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM244	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 15 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM245	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 16 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM246	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 17 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM247	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 18 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM248	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 19 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM249	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 20 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM250	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 21 st module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF

SM	Function	AS100/200 Series AS300 Series		OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM251	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 22 nd module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM252	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 23 rd module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM253	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 24 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM254	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 25 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM255	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 26 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM256	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 27 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM257	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 28 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM258	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 29 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM259	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 30 th module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM260	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 31 st module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
*SM261	When selecting "Manual + Flags" in "I/O allocation setting when Power On", use this flag to activate the 32 nd module on the right-side of the CPU module.	○	○	—	—	—	Y	R/W	OFF
SM270	Reversing the input direction for MPG 1 flag (X0.0/X0.1)	○	○	OFF	OFF	—	N	R/W	OFF
SM271	Reversing the input direction for MPG 2 flag	○	○	OFF	OFF	—	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
	(X0.2/X0.3)								
SM272	Reversing the input direction for MPG 3 flag (X0.4/X0.5)	○	○	OFF	OFF	–	N	R/W	OFF
SM273	Reversing the input direction for MPG 4 flag (X0.6/X0.7)	○	○	OFF	OFF	–	N	R/W	OFF
SM274	Reversing the input direction for MPG 5 flag (X0.8/X0.9)	○	○	OFF	OFF	–	N	R/W	OFF
SM275	Reversing the input direction for MPG 6 flag (X0.10/X0.11)	○	○	OFF	OFF	–	N	R/W	OFF
SM281	Reversing the input direction for high-speed counter 1 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM282	Reversing the input direction for high-speed counter 2 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM283	Reversing the input direction for high-speed counter 3 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM284	Reversing the input direction for high-speed counter 4 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM285	Reversing the input direction for high-speed counter 5 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM286	Reversing the input direction for high-speed counter 6 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM287	Reversing the input direction for high-speed counter 7 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM288	Reversing the input direction for high-speed counter 8 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM291	Clearing the input point for high-speed counter 1 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM292	Clearing the input point for high-speed counter 2 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM293	Clearing the input point for high-speed counter 3 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM294	Clearing the input point for high-speed counter 4 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM295	Clearing the input point for high-speed counter 5 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM296	Clearing the input point for high-speed counter 6 flag	○	○	OFF	OFF	–	N	R/W	OFF
SM300	Setting counting mode for HC200. HC200 counts down when SM300 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM301	Setting counting mode for HC201. HC201 counts down when SM301 is ON.	○	○	OFF	–	–	N	R	OFF
SM302	Setting counting mode for HC202. HC202 counts down when SM302 is ON.	○	○	OFF	–	–	N	R	OFF
SM303	Setting counting mode for HC203. HC203 counts down when SM303 is ON.	○	○	OFF	–	–	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SM304	Setting counting mode for HC204. HC204 counts down when SM304 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM305	Setting counting mode for HC205. HC205 counts down when SM305 is ON.	○	○	OFF	–	–	N	R	OFF
SM306	Setting counting mode for HC206. HC206 counts down when SM306 is ON.	○	○	OFF	–	–	N	R	OFF
SM307	Setting counting mode for HC207. HC207 counts down when SM307 is ON.	○	○	OFF	–	–	N	R	OFF
SM308	Setting counting mode for HC208. HC208 counts down when SM308 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM309	Setting counting mode for HC209. HC209 counts down when SM309 is ON.	○	○	OFF	–	–	N	R	OFF
SM310	Setting counting mode for HC210. HC210 counts down when SM310 is ON.	○	○	OFF	–	–	N	R	OFF
SM311	Setting counting mode for HC211. HC211 counts down when SM311 is ON.	○	○	OFF	–	–	N	R	OFF
SM312	Setting counting mode for HC212. HC212 counts down when SM312 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM313	Setting counting mode for HC213. HC213 counts down when SM313 is ON.	○	○	OFF	–	–	N	R	OFF
SM314	Setting counting mode for HC214. HC214 counts down when SM314 is ON.	○	○	OFF	–	–	N	R	OFF
SM315	Setting counting mode for HC215. HC215 counts down when SM315 is ON.	○	○	OFF	–	–	N	R	OFF
SM316	Setting counting mode for HC216. HC216 counts down when SM316 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM317	Setting counting mode for HC217. HC217 counts down when SM317 is ON.	○	○	OFF	–	–	N	R	OFF
SM318	Setting counting mode for HC218. HC218 counts down when SM318 is ON.	○	○	OFF	–	–	N	R	OFF
SM319	Setting counting mode for HC219. HC219 counts down when SM319 is ON.	○	○	OFF	–	–	N	R	OFF
SM320	Setting counting mode for HC220. HC220 counts down when SM320 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM321	Setting counting mode for HC221. HC221 counts down when SM321 is ON.	○	○	OFF	–	–	N	R	OFF
SM322	Setting counting mode for HC222. HC222 counts down when SM322 is ON.	○	○	OFF	–	–	N	R	OFF
SM323	Setting counting mode for HC223. HC223 counts down when SM323 is ON.	○	○	OFF	–	–	N	R	OFF
SM332	Setting counting mode for HC232. HC232 counts down when SM332 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM333	Setting counting mode for HC233.	○	○	OFF	–	–	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
	HC233 counts down when SM333 is ON.								
SM334	Setting counting mode for HC234. HC234 counts down when SM334 is ON.	○	○	OFF	–	–	N	R	OFF
SM335	Setting counting mode for HC235. HC235 counts down when SM335 is ON.	○	○	OFF	–	–	N	R	OFF
SM336	Setting counting mode for HC236. HC236 counts down when SM336 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM337	Setting counting mode for HC237. HC237 counts down when SM337 is ON.	○	○	OFF	–	–	N	R	OFF
SM338	Setting counting mode for HC238. HC238 counts down when SM338 is ON.	○	○	OFF	–	–	N	R	OFF
SM339	Setting counting mode for HC239. HC239 counts down when SM339 is ON.	○	○	OFF	–	–	N	R	OFF
SM340	Setting counting mode for HC240. HC240 counts down when SM340 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM341	Setting counting mode for HC241. HC241 counts down when SM341 is ON.	○	○	OFF	–	–	N	R	OFF
SM342	Setting counting mode for HC242. HC242 counts down when SM342 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM343	Setting counting mode for HC243. HC243 counts down when SM343 is ON.	○	○	OFF	–	–	N	R	OFF
SM344	Setting counting mode for HC244. HC244 counts down when SM344 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM345	Setting counting mode for HC245. HC245 counts down when SM345 is ON.	○	○	OFF	–	–	N	R	OFF
SM346	Setting counting mode for HC246. HC246 counts down when SM346 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM347	Setting counting mode for HC247. HC247 counts down when SM347 is ON.	○	○	OFF	–	–	N	R	OFF
SM348	Setting counting mode for HC248. HC248 counts down when SM348 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM349	Setting counting mode for HC249. HC249 counts down when SM349 is ON.	○	○	OFF	–	–	N	R	OFF
SM350	Setting counting mode for HC250. HC250 counts down when SM350 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM351	Setting counting mode for HC251. HC251 counts down when SM351 is ON.	○	○	OFF	–	–	N	R	OFF
SM352	Setting counting mode for HC252. HC252 counts down when SM352 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
SM353	Setting counting mode for HC253. HC253 counts down when SM353 is ON.	○	○	OFF	OFF	–	N	R/W	OFF
*SM360	I200 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function	AS100/200 Series		OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM361	I201 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM362	I202 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM363	I203 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM364	I210 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM365	I211 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM366	I212 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM367	I213 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM368	I220 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM369	I221 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM370	I222 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM371	I223 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM372	I230 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM373	I231 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM374	I232 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM375	I233 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM376	I240 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM377	I241 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM378	I242 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM379	I243 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM380	I250 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM381	I251 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM382	I252 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM383	I253 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM384	I260 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM385	I261 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM386	I262 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM387	I263 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM388	I264 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM389	I265 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM390	I266 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM391	I267 high-speed comparison interrupt for DPLSY to activate output	○	○	OFF	OFF	–	N	R/W	OFF
*SM400	The flag is always ON (normally open) when the CPU runs.	○	○	OFF	ON	OFF	N	R	OFF
*SM401	The flag is always OFF (normally closed) when the CPU runs.	○	○	OFF	OFF	ON	N	R	OFF
*SM402	The flag is ON only at the first scan.	○	○	OFF	ON	OFF	N	R	OFF
*SM403	The flag is OFF only at the first scan.	○	○	OFF	OFF	ON	N	R	OFF
*SM404	10 millisecond clock pulse during which the pulse is ON for 5 milliseconds and then OFF for 5 milliseconds	○	○	OFF	–	–	N	R	OFF
*SM405	100 millisecond clock pulse during which the pulse is ON for 50 milliseconds and then OFF for 50 milliseconds	○	○	OFF	–	–	N	R	OFF
*SM406	200 millisecond clock pulse during which the pulse is ON for 100 milliseconds and then OFF for 100 milliseconds	○	○	OFF	–	–	N	R	OFF
*SM407	One second clock pulse during which the pulse is ON for 500 milliseconds and then OFF for 500 milliseconds	○	○	OFF	–	–	N	R	OFF
*SM450	Memory card is present ON: the memory card is present. OFF: the memory card is not present.	○	○	–	–	–	N	R	OFF
*SM452	The data in the memory card is being accessed. ON: the data in the memory card is being accessed. OFF: the data in the memory card is not accessed.	○	○	OFF	–	–	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM453	Error during the operation of the memory card. ON: an error occurs. OFF: no error.	○	○	OFF	—	—	N	R	OFF
SM454	Enabling/disabling the data logger. ON: enable OFF: disable	○	○	OFF	—	—	N	R/W	OFF
SM455	The data logger is currently taking samples. ON: number of records has reached its sampling limit	○	○	OFF	—	—	N	R	OFF
*SM456	Execution of data logger and the memory card. ON: execution by the values in SR902.	○	○	OFF	—	—	N	R/W	OFF
SM457	State of the sample parameters in data logger ON: the sample parameter is set.	○	○	—	—	—	N	R	OFF
SM460	Outputting Y0.0/axis 1 (Y0.0/Y0.1).	○	○	OFF	OFF	—	N	R	OFF
SM461	Y0.0/axis 1 (Y0.0/Y0.1) output is complete.	○	○	OFF	OFF	—	N	R/W	OFF
SM462	Reversing the output direction of axis 1 (Y0.1)	○	○	OFF	OFF	—	N	R/W	OFF
*SM463	Stopping the output of Y0.0/axis 1 (Y0.0/Y0.1)	○	○	OFF	OFF	—	N	R/W	OFF
SM464	Enabling the hardware positive limit on axis 1 (Y0.0/Y0.1)	○	○	—	—	—	Y	R/W	OFF
SM465	Alarm: exceeding the positive limit on axis 1 (Y0.0/Y0.1)	○	○	OFF	OFF	—	N	R/W	OFF
SM466	Enabling the hardware negative limit on axis 1 (Y0.0/Y0.1)	○	○	—	—	—	Y	R/W	OFF
SM467	Alarm: exceeding the negative limit on axis 1 (Y0.0/Y0.1)	○	○	OFF	OFF	—	N	R/W	OFF
SM469	Enabling fixed slope ramp-up/down on axis 1 (Y0.0/Y0.1)	○	○	OFF	OFF	—	N	R/W	OFF
SM470	Auto-reset when Y0.0/axis 1 (Y0.0/Y0.1) output is complete.	○	○	OFF	OFF	—	N	R/W	OFF
SM471	Executing an interrupt I500 when pulse output ends on axis 1 (Y0.0/Y0.1)	○	○	OFF	OFF	—	N	R/W	OFF
SM472	Outputting Y0.1.	○	○	OFF	OFF	—	N	R	OFF
SM473	Y0.1 output is complete.	○	○	OFF	OFF	—	N	R/W	OFF
*SM474	Stopping the output of Y0.1.	○	○	OFF	OFF	—	N	R/W	OFF
SM475	Auto-reset when Y0.1 output is complete.	○	○	OFF	OFF	—	N	R/W	OFF
*SM476	Output immediately stops when the instruction is disabled or stops for Y0.0/axis 1 (Y0.0/Y0.1)	○	○	OFF	OFF	—	N	R/W	OFF
*SM477	Output immediately stops when the instruction is disabled or stops for Y0.1	○	○	OFF	OFF	—	N	R/W	OFF
SM478	Change the target positon while outputting Y0.0/axis 1 (Y0.0/Y0.1)	○	○	OFF	OFF	—	N	R/W	OFF
SM479	Change the target positon while outputting Y0.1	○	○	OFF	OFF	—	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SM480	Outputting Y0.2/axis 2 (Y0.2/Y0.3).	○	○	OFF	OFF	–	N	R	OFF
SM481	Y0.2/axis 2 (Y0.2/Y0.3) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM482	Reversing the output direction of axis 2 (Y0.3)	○	○	OFF	OFF	–	N	R/W	OFF
*SM483	Stopping the output of Y0.2/axis 2 (Y0.2/Y0.3)	○	○	OFF	OFF	–	N	R/W	OFF
SM484	Enabling the hardware positive limit on axis 2 (Y0.2/Y0.3)	○	○	–	–	–	Y	R/W	OFF
SM485	Alarm: exceeding the positive limit on axis 2 (Y0.2/Y0.3)	○	○	OFF	OFF	–	N	R/W	OFF
SM486	Enabling the hardware negative limit on axis 2 (Y0.2/Y0.3)	○	○	–	–	–	Y	R/W	OFF
SM487	Alarm: exceeding the negative limit on axis 2 (Y0.2/Y0.3)	○	○	OFF	OFF	–	N	R/W	OFF
SM489	Enabling fixed slope ramp-up/down on axis 2 (Y0.2/Y0.3).	○	○	OFF	OFF	–	N	R/W	OFF
SM490	Auto-reset when Y0.2/axis 2 (Y0.2/Y0.3) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM491	Executing an interrupt I501 when pulse output ends on axis 2 (Y0.2/Y0.3).	○	○	OFF	OFF	–	N	R/W	OFF
SM492	Outputting Y0.3.	○	○	OFF	OFF	–	N	R	OFF
SM493	Y0.3 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM494	Stopping the output of Y0.3.	○	○	OFF	OFF	–	N	R/W	OFF
SM495	Auto-reset when Y0.3 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM496	The output immediately stops when the instruction is disabled or stops for Y0.2/axis 2 (Y0.2/Y0.3).	○	○	OFF	OFF	–	N	R/W	OFF
*SM497	The output immediately stops when the instruction is disabled or stops for Y0.3.	○	○	OFF	OFF	–	N	R/W	OFF
SM498	Change the target positon while outputting Y0.2/axis 2 (Y0.2/Y0.3)	○	○	OFF	OFF	–	N	R/W	OFF
SM499	Change the target positon while outputting Y0.3	○	○	OFF	OFF	–	N	R/W	OFF
SM500	Outputting Y0.4/axis 3 (Y0.4/Y0.5).	○	○	OFF	OFF	–	N	R	OFF
SM501	Y0.4/axis 3 (Y0.4/Y0.5) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM502	Reversing the output direction of axis 3 (Y0.5).	○	○	OFF	OFF	–	N	R/W	OFF
*SM503	Stopping the output of Y0.4/axis 3 (Y0.4/Y0.5).	○	○	OFF	OFF	–	N	R/W	OFF
SM504	Enabling the hardware positive limit on axis 3 (Y0.4/Y0.5)	○	○	–	–	–	Y	R/W	OFF
SM505	Alarm: exceeding the positive limit on axis 3 (Y0.4/Y0.5)	○	○	OFF	OFF	–	N	R/W	OFF
SM506	Enabling the hardware negative limit on axis 3 (Y0.4/Y0.5)	○	○	–	–	–	Y	R/W	OFF
SM507	Alarm: exceeding the negative limit on axis 3 (Y0.4/Y0.5)	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SM509	Enabling fixed slope ramp-up/down on axis 3 (Y0.4/Y0.5)	○	○	OFF	OFF	–	N	R/W	OFF
SM510	Auto-reset when Y0.4/axis 3 (Y0.4/Y0.5) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM511	Executing an interrupt I502 when pulse output ends for axis 3 (Y0.4/Y0.5).	○	○	OFF	OFF	–	N	R/W	OFF
SM512	Outputting Y0.5.	○	○	OFF	OFF	–	N	R	OFF
SM513	Y0.5 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM514	Stopping the output of Y0.5.	○	○	OFF	OFF	–	N	R/W	OFF
SM515	Auto-reset when Y0.5 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM516	Output immediately stops when the instruction is disabled or stops on Y0.4/axis 3 (Y0.4/Y0.5).	○	○	OFF	OFF	–	N	R/W	OFF
*SM517	Output immediately stops when the instruction is disabled or stops on Y0.5.	○	○	OFF	OFF	–	N	R/W	OFF
SM518	Change the target position while outputting Y0.4/axis 3 (Y0.4/Y0.5)	○	○	OFF	OFF	–	N	R/W	OFF
SM519	Change the target position while outputting Y0.5	○	○	OFF	OFF	–	N	R/W	OFF
SM520	Outputting Y0.6/axis 4 (Y0.6/Y0.7).	○	○	OFF	OFF	–	N	R	OFF
SM521	Y0.6/axis 4 (Y0.6/Y0.7) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM522	Reversing the output direction of axis 4 (Y0.7) .	○	○	OFF	OFF	–	N	R/W	OFF
*SM523	Stopping the output of Y0.6/axis 4 (Y0.6/Y0.7).	○	○	OFF	OFF	–	N	R/W	OFF
SM524	Enabling the hardware positive limit on axis 4 (Y0.6/Y0.7).	○	○	–	–	–	Y	R/W	OFF
SM525	Alarm: exceeding the positive limit on axis 4 (Y0.6/Y0.7).	○	○	OFF	OFF	–	N	R/W	OFF
SM526	Enabling the hardware negative limit on axis 4 (Y0.6/Y0.7).	○	○	–	–	–	Y	R/W	OFF
SM527	Alarm: exceeding the negative limit on axis 4 (Y0.6/Y0.7).	○	○	OFF	OFF	–	N	R/W	OFF
SM529	Enabling fixed slope ramp-up/down on axis 4 (Y0.6/Y0.7).	○	○	OFF	OFF	–	N	R/W	OFF
SM530	Auto-reset when Y0.6/axis 4 (Y0.6/Y0.7) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM531	Executing an interrupt I503 when pulse output ends on axis 4 (Y0.6/Y0.7).	○	○	OFF	OFF	–	N	R/W	OFF
SM532	Outputting Y0.7.	○	○	OFF	OFF	–	N	R	OFF
SM533	Y0.7 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM534	Stopping the output of Y0.7.	○	○	OFF	OFF	–	N	R/W	OFF
SM535	Auto-reset when Y0.7 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM536	Output immediately stops when the instruction is disabled or stops for Y0.6/axis 4 (Y0.6/Y0.7).	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM537	Output immediately stops when the instruction is disabled or stops for Y0.7.	○	○	OFF	OFF	–	N	R/W	OFF
SM538	Change the target position while outputting Y0.6/axis 4 (Y0.6/Y0.7)	○	○	OFF	OFF	–	N	R/W	OFF
SM539	Change the target position while outputting Y0.7	○	○	OFF	OFF	–	N	R/W	OFF
SM540	Outputting Y0.8/axis 5 (Y0.8/Y0.9).	○	○	OFF	OFF	–	N	R	OFF
SM541	Y0.8/axis 5 (Y0.8/Y0.9) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM542	Reversing the output direction of axis 5 (Y0.9).	○	○	OFF	OFF	–	N	R/W	OFF
*SM543	Stopping the output of Y0.8/axis 5 (Y0.8/Y0.9).	○	○	OFF	OFF	–	N	R/W	OFF
SM544	Enabling the hardware positive limit on axis 5 (Y0.8/Y0.9).	○	○	–	–	–	Y	R/W	OFF
SM545	Alarm: exceeding the positive limit on axis 5 (Y0.8/Y0.9).	○	○	OFF	OFF	–	N	R/W	OFF
SM546	Enabling the hardware negative limit on axis 5 (Y0.8/Y0.9).	○	○	–	–	–	Y	R/W	OFF
SM547	Alarm: exceeding the negative limit on axis 5 (Y0.8/Y0.9).	○	○	OFF	OFF	–	N	R/W	OFF
SM549	Enabling fixed slope ramp-up/down on axis 5 (Y0.8/Y0.9).	○	○	OFF	OFF	–	N	R/W	OFF
SM550	Auto-reset when Y0.8/axis 5 (Y0.8/Y0.9) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM551	Executing an interrupt I504 when pulse output ends on axis 5 (Y0.8/Y0.9).	○	○	OFF	OFF	–	N	R/W	OFF
SM552	Outputting Y0.9.	○	○	OFF	OFF	–	N	R	OFF
SM553	Y0.9 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM554	Stopping the output of Y0.9.	○	○	OFF	OFF	–	N	R/W	OFF
SM555	Auto-reset when Y0.9 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM556	Output immediately stops when the instruction is disabled or stops for Y0.8/axis 5 (Y0.8/Y0.9).	○	○	OFF	OFF	–	N	R/W	OFF
*SM557	The output immediately stops when the instruction is disabled or stops for Y0.9.	○	○	OFF	OFF	–	N	R/W	OFF
SM558	Change the target position while outputting Y0.8/axis 5 (Y0.8/Y0.9)	○	○	OFF	OFF	–	N	R/W	OFF
SM559	Change the target position while outputting Y0.9	○	○	OFF	OFF	–	N	R/W	OFF
SM560	Outputting Y0.10/axis 6 (Y0.10/Y0.11).	○	○	OFF	OFF	–	N	R	OFF
SM561	Y0.10/axis 6 (Y0.10/Y0.11) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM562	Reversing the output direction of axis 6 (Y0.11).	○	○	OFF	OFF	–	N	R/W	OFF
*SM563	Stopping the output of Y0.10/axis 6 (Y0.10/Y0.11).	○	○	OFF	OFF	–	N	R/W	OFF
SM564	Enabling the hardware positive limit on axis 6 (Y0.10/Y0.11).	○	○	–	–	–	Y	R/W	OFF
SM565	Alarm: exceeding the positive limit on axis 6 (Y0.10/Y0.11).	○	○	OFF	OFF	–	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SM566	Enabling the hardware negative limit on axis 6 (Y0.10/Y0.11).	○	○	–	–	–	Y	R/W	OFF
SM567	Alarm: exceeding the negative limit on axis 6 (Y0.10/Y0.11).	○	○	OFF	OFF	–	N	R/W	OFF
SM569	Enabling fixed slope ramp-up/down on axis 6 (Y0.10/Y0.11).	○	○	OFF	OFF	–	N	R/W	OFF
SM570	Auto-reset when Y0.10/axis 6 (Y0.10/Y0.11) output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
SM571	Executing an interrupt I505 when pulse output ends on axis 6 (Y0.10/Y0.11).	○	○	OFF	OFF	–	N	R/W	OFF
SM572	Outputting Y0.11.	○	○	OFF	OFF	–	N	R	OFF
SM573	Y0.11 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM574	Stopping Y0.11 output.	○	○	OFF	OFF	–	N	R/W	OFF
SM575	Auto-reset when Y0.11 output is complete.	○	○	OFF	OFF	–	N	R/W	OFF
*SM576	Output immediately stops when the instruction is disabled or stops for Y0.10/axis 6 (Y0.10/Y0.11).	○	○	OFF	OFF	–	N	R/W	OFF
*SM577	Output immediately stops when the instruction is disabled or stops for Y0.11.	○	○	OFF	OFF	–	N	R/W	OFF
SM578	Change the target positon while outputting Y0.10/axis 6 (Y0.10/Y0.11)	○	○	OFF	OFF	–	N	R/W	OFF
SM579	Change the target positon while outputting Y0.11	○	○	OFF	OFF	–	N	R/W	OFF
SM580	All outputs immediately stop when the instruction is disabled or stops.	○	○	OFF	OFF	–	N	R/W	OFF
SM585	When the single-axis parameter is modified in the position planning table, its acceleration/deceleration time in SR should also be synchronized.	○	○	OFF	OFF	–	N	R/W	OFF
*SM586	Used to calculate the interval frequency of acceleration and deceleration (for axis 1-6)	○	○	OFF	OFF	–	N	R/W	OFF
*SM587	When TPO instruction uses position planning table to control the output, if the output is stopped during execution, the axis should refer to its relevant flags (e.g. SM476, SM496--SM576) for the action to stop.	○	○	OFF	OFF	–	N	R/W	OFF
SM600	Zero flag	○	○	OFF	–	–	N	R	OFF
SM601	Borrow flag	○	○	OFF	–	–	N	R	OFF
SM602	Carry flag	○	○	OFF	–	–	N	R	OFF
SM603	The number of tasks to do has exceeded the number of tasks the work station can manage for XCMP instruction.	○	○	OFF	OFF	–	N	R/W	OFF
SM604	Setting the working mode of the SORT instruction. ON: descending order OFF: ascending order	○	○	OFF	–	–	N	R/W	OFF
SM605	Designating the working mode of the SMOV	○	○	OFF	–	–	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
	instruction.								
SM606	8-bit or 16-bit working mode. ON: 8-bit OFF: 16-bit	○	○	OFF	—	—	N	R/W	OFF
SM607	Matrix comparison flag. ON: Comparing equivalent values. OFF: Comparing different values.	○	○	OFF	—	—	N	R/W	OFF
SM608	Matrix comparison complete. When the last bits are compared, SM608 is ON.	○	○	OFF	—	—	N	R	OFF
SM609	When SM609 is ON, the comparison starts from bit 0.	○	○	OFF	—	—	N	R	OFF
SM610	Matrix bit search flag. When the matrix search finds the matching bits or completes the search, the search stops immediately and SM610 is ON.	○	○	OFF	—	—	N	R	OFF
SM611	Matrix pointer error flag. When the value of the pointer exceeds the comparison range, SM611 is ON.	○	○	OFF	—	—	N	R	OFF
SM612	Matrix pointer increasing flag. The current value of the pointer increases by one.	○	○	OFF	—	—	N	R/W	OFF
SM613	Matrix pointer clearing flag. The current value of the pointer is cleared to zero.	○	○	OFF	—	—	N	R/W	OFF
SM614	Carry flag for the matrix rotation/shift/output.	○	○	OFF	—	—	N	R	OFF
SM615	Borrow flag for the matrix shift/output.	○	○	OFF	—	—	N	R/W	OFF
SM616	Direction flag for the matrix rotation/shift. OFF: the bits are shifted leftward. ON: The bits are shifted rightward.	○	○	OFF	—	—	N	R/W	OFF
SM617	The bits with the value 0 or 1 are counted.	○	○	OFF	—	—	N	R/W	OFF
SM618	ON when the matrix counting result is 0.	○	○	OFF	—	—	N	R/W	OFF
SM619	ON when the instruction EI is executed.	○	○	OFF	OFF	—	N	R	OFF
SM620	When the results from the comparison using the instruction CMPT# are that all devices are ON, SM620 is ON.	○	○	OFF	—	—	N	R	OFF
SM621	Setting counting mode for HC0. HC0 counts down when SM621 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM622	Setting counting mode for HC. HC1 counts down when SM622 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM623	Setting counting mode for HC2. HC2 counts down when SM623 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM624	Setting counting mode for HC3. HC3 counts down when SM624 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM625	Setting counting mode for HC4. HC4 counts down when SM625 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM626	Setting counting mode for HC5. HC5 counts down when SM626 is ON.	○	○	OFF	—	—	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SM627	Setting counting mode for HC6. HC6 counts down when SM627 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM628	Setting counting mode for HC7. HC7 counts down when SM628 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM629	Setting counting mode for HC8. HC8 counts down when SM629 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM630	Setting counting mode for HC9. HC9 counts down when SM630 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM631	Setting counting mode for HC10. HC10 counts down when SM631 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM632	Setting counting mode for HC11. HC11 counts down when SM632 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM633	Setting counting mode for HC12. HC12 counts down when SM633 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM634	Setting counting mode for HC13. HC13 counts down when SM634 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM635	Setting counting mode for HC14. HC14 counts down when SM635 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM636	Setting counting mode for HC15. HC15 counts down when SM636 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM637	Setting counting mode for HC16. HC16 counts down when SM637 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM638	Setting counting mode for HC17. HC17 counts down when SM638 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM639	Setting counting mode for HC18. HC18 counts down when SM639 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM640	Setting counting mode for HC19. HC19 counts down when SM640 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM641	Setting counting mode for HC20. HC20 counts down when SM641 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM642	Setting counting mode for HC21. HC21 counts down when SM642 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM643	Setting counting mode for HC22. HC22 counts down when SM643 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM644	Setting counting mode for HC23. HC23 counts down when SM644 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM645	Setting counting mode for HC24. HC24 counts down when SM645 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM646	Setting counting mode for HC25. HC25 counts down when SM646 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM647	Setting counting mode for HC26. HC26 counts down when SM647 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM648	Setting counting mode for HC27.	○	○	OFF	—	—	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
	HC27 counts down when SM648 is ON.								
SM649	Setting counting mode for HC28. HC28 counts down when SM649 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM650	Setting counting mode for HC29. HC29 counts down when SM650 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM651	Setting counting mode for HC30. HC30 counts down when SM651 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM652	Setting counting mode for HC31. HC31 counts down when SM652 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM653	Setting counting mode for HC32. HC32 counts down when SM653 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM654	Setting counting mode for HC33. HC33 counts down when SM653 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM655	Setting counting mode for HC34. HC34 counts down when SM655 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM656	Setting counting mode for HC35. HC35 counts down when SM656 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM657	Setting counting mode for HC36. HC36 counts down when SM657 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM658	Setting counting mode for HC37. HC37 counts down when SM658 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM659	Setting counting mode for HC38. HC38 counts down when SM659 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM660	Setting counting mode for HC39. HC39 counts down when SM660 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM661	Setting counting mode for HC40. HC40 counts down when SM661 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM662	Setting counting mode for HC41. HC41 counts down when SM662 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM663	Setting counting mode for HC42. HC42 counts down when SM663 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM664	Setting counting mode for HC43. HC43 counts down when SM664 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM665	Setting counting mode for HC44. HC44 counts down when SM665 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM666	Setting counting mode for HC45. HC45 counts down when SM666 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM667	Setting counting mode for HC46. HC46 counts down when SM667 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM668	Setting counting mode for HC47. HC47 counts down when SM668 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM669	Setting counting mode for HC48. HC48 counts down when SM669 is ON.	○	○	OFF	—	—	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SM670	Setting counting mode for HC49. HC49 counts down when SM670 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM671	Setting counting mode for HC50. HC50 counts down when SM671 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM672	Setting counting mode for HC51. HC51 counts down when SM672 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM673	Setting counting mode for HC52. HC52 counts down when SM673 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM674	Setting counting mode for HC53. HC53 counts down when SM674 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM675	Setting counting mode for HC54. HC54 counts down when SM675 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM676	Setting counting mode for HC55. HC55 counts down when SM676 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM677	Setting counting mode for HC56. HC56 counts down when SM677 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM678	Setting counting mode for HC57. HC57 counts down when SM678 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM679	Setting counting mode for HC58. HC58 counts down when SM679 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM680	Setting counting mode for HC59. HC59 counts down when SM680 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM681	Setting counting mode for HC60. HC60 counts down when SM681 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM682	Setting counting mode for HC61. HC61 counts down when SM682 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM683	Setting counting mode for HC62. HC62 counts down when SM683 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM684	Setting counting mode for HC63. HC63 counts down when SM684 is ON.	○	○	OFF	—	—	N	R/W	OFF
SM685	The DSCLP instruction uses floating-point operations.	○	○	OFF	—	—	N	R/W	OFF
SM686	RAMP instruction mode	○	○	OFF	—	—	N	R/W	OFF
SM687	RAMP instruction execution is complete.	○	○	OFF	—	—	N	R/W	OFF
SM688	INCD instruction execution is complete.	○	○	OFF	—	—	N	R/W	OFF
SM690	String control mode.	○	○	OFF	—	—	N	R/W	OFF
SM691	HKY instruction input mode is 16-bit. ON: the input is the hexadecimal input OFF: A–F are function keys.	○	○	OFF	—	—	N	R/W	OFF
SM692	After the execution of the HKY instruction is complete, SM692 is ON for a scan cycle.	○	○	OFF	—	—	N	R/W	OFF
SM693	After the execution of the SEGL instruction is complete, SM693 is ON for a scan cycle.	○	○	OFF	—	—	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SM694	After the execution of the DSW instruction is complete, SM694 is ON for a scan cycle.	○	○	OFF	—	—	N	R/W	OFF
SM695	Radian/degree flag. ON: degrees OFF: Radians	○	○	OFF	—	—	N	R/W	OFF
SM749	Error occurs in the initialization of the data exchange through COM1.	○	○	OFF	—	—	N	R/W	OFF
*SM750	Data exchange through COM1 enabled by ISPSOft.	○	○	OFF	—	—	H	R/W	OFF
*SM752	Connection 1 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM753	Connection 2 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM754	Connection 3 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM755	Connection 4 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM756	Connection 5 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM757	Connection 6 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM758	Connection 7 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM759	Connection 8 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM760	Connection 9 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM761	Connection 10 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM762	Connection 11 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM763	Connection 12 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM764	Connection 13 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM765	Connection 14 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM766	Connection 15 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM767	Connection 16 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM768	Connection 17 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM769	Connection 18 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM770	Connection 19 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM771	Connection 20 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM772	Connection 21 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM773	Connection 22 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM774	Connection 23 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM775	Connection 24 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM776	Connection 25 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM777	Connection 26 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM778	Connection 27 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM779	Connection 28 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM780	Connection 29 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM781	Connection 30 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM782	Connection 31 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM783	Connection 32 for data exchange through COM1 started	○	○	OFF	—	—	H	R/W	OFF
*SM784	Successful data exchange connection 1 through COM1	○	○	OFF	—	—	N	R	OFF
*SM785	Successful data exchange connection 2 through COM1	○	○	OFF	—	—	N	R	OFF
*SM786	Successful data exchange connection 3 through COM1	○	○	OFF	—	—	N	R	OFF
*SM787	Successful data exchange connection 4 through COM1	○	○	OFF	—	—	N	R	OFF
*SM788	Successful data exchange connection 5 through COM1	○	○	OFF	—	—	N	R	OFF
*SM789	Successful data exchange connection 6 through COM1	○	○	OFF	—	—	N	R	OFF
*SM790	Successful data exchange connection 7 through COM1	○	○	OFF	—	—	N	R	OFF
*SM791	Successful data exchange connection 8 through COM1	○	○	OFF	—	—	N	R	OFF
*SM792	Successful data exchange connection 9 through COM1	○	○	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM793	Successful data exchange connection 10 through COM1	○	○	OFF	—	—	N	R	OFF
*SM794	Successful data exchange connection 11 through COM1	○	○	OFF	—	—	N	R	OFF
*SM795	Successful data exchange connection 12 through COM1	○	○	OFF	—	—	N	R	OFF
*SM796	Successful data exchange connection 13 through COM1	○	○	OFF	—	—	N	R	OFF
*SM797	Successful data exchange connection 14 through COM1	○	○	OFF	—	—	N	R	OFF
*SM798	Successful data exchange connection 15 through COM1	○	○	OFF	—	—	N	R	OFF
*SM799	Successful data exchange connection 16 through COM1	○	○	OFF	—	—	N	R	OFF
*SM800	Successful data exchange connection 17 through COM1	○	○	OFF	—	—	N	R	OFF
*SM801	Successful data exchange connection 18 through COM1	○	○	OFF	—	—	N	R	OFF
*SM802	Successful data exchange connection 19 through COM1	○	○	OFF	—	—	N	R	OFF
*SM803	Successful data exchange connection 20 through COM1	○	○	OFF	—	—	N	R	OFF
*SM804	Successful data exchange connection 21 through COM1	○	○	OFF	—	—	N	R	OFF
*SM805	Successful data exchange connection 22 through COM1	○	○	OFF	—	—	N	R	OFF
*SM806	Successful data exchange connection 23 through COM1	○	○	OFF	—	—	N	R	OFF
*SM807	Successful data exchange connection 24 through COM1	○	○	OFF	—	—	N	R	OFF
*SM808	Successful data exchange connection 25 through COM1	○	○	OFF	—	—	N	R	OFF
*SM809	Successful data exchange connection 26 through COM1	○	○	OFF	—	—	N	R	OFF
*SM810	Successful data exchange connection 27 through COM1	○	○	OFF	—	—	N	R	OFF
*SM811	Successful data exchange connection 28 through COM1	○	○	OFF	—	—	N	R	OFF
*SM812	Successful data exchange connection 29 through COM1	○	○	OFF	—	—	N	R	OFF
*SM813	Successful data exchange connection 30 through COM1	○	○	OFF	—	—	N	R	OFF
*SM814	Successful data exchange connection 31 through COM1	○	○	OFF	—	—	N	R	OFF
*SM815	Successful data exchange connection 32 through COM1	○	○	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM816	Error in data exchange connection 1 through COM1	○	○	OFF	—	—	N	R	OFF
*SM817	Error in data exchange connection 2 through COM1	○	○	OFF	—	—	N	R	OFF
*SM818	Error in data exchange connection 3 through COM1	○	○	OFF	—	—	N	R	OFF
*SM819	Error in data exchange connection 4 through COM1	○	○	OFF	—	—	N	R	OFF
*SM820	Error in data exchange connection 5 through COM1	○	○	OFF	—	—	N	R	OFF
*SM821	Error in data exchange connection 6 through COM1	○	○	OFF	—	—	N	R	OFF
*SM822	Error in data exchange connection 7 through COM1	○	○	OFF	—	—	N	R	OFF
*SM823	Error in data exchange connection 8 through COM1	○	○	OFF	—	—	N	R	OFF
*SM824	Error in data exchange connection 9 through COM1	○	○	OFF	—	—	N	R	OFF
*SM825	Error in data exchange connection 10 through COM1	○	○	OFF	—	—	N	R	OFF
*SM826	Error in data exchange connection 11 through COM1	○	○	OFF	—	—	N	R	OFF
*SM827	Error in data exchange connection 12 through COM1	○	○	OFF	—	—	N	R	OFF
*SM828	Error in data exchange connection 13 through COM1	○	○	OFF	—	—	N	R	OFF
*SM829	Error in data exchange connection 14 through COM1	○	○	OFF	—	—	N	R	OFF
*SM830	Error in data exchange connection 15 through COM1	○	○	OFF	—	—	N	R	OFF
*SM831	Error in data exchange connection 16 through COM1	○	○	OFF	—	—	N	R	OFF
*SM832	Error in data exchange connection 17 through COM1	○	○	OFF	—	—	N	R	OFF
*SM833	Error in data exchange connection 18 through COM1	○	○	OFF	—	—	N	R	OFF
*SM834	Error in data exchange connection 19 through COM1	○	○	OFF	—	—	N	R	OFF
*SM835	Error in data exchange connection 20 through COM1	○	○	OFF	—	—	N	R	OFF
*SM836	Error in data exchange connection 21 through COM1	○	○	OFF	—	—	N	R	OFF
*SM837	Error in data exchange connection 22 through COM1	○	○	OFF	—	—	N	R	OFF
*SM838	Error in data exchange connection 23 through COM1	○	○	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM839	Error in data exchange connection 24 through COM1	○	○	OFF	—	—	N	R	OFF
*SM840	Error in data exchange connection 25 through COM1	○	○	OFF	—	—	N	R	OFF
*SM841	Error in data exchange connection 26 through COM1	○	○	OFF	—	—	N	R	OFF
*SM842	Error in data exchange connection 27 through COM1	○	○	OFF	—	—	N	R	OFF
*SM843	Error in data exchange connection 28 through COM1	○	○	OFF	—	—	N	R	OFF
*SM844	Error in data exchange connection 29 through COM1	○	○	OFF	—	—	N	R	OFF
*SM845	Error in data exchange connection 30 through COM1	○	○	OFF	—	—	N	R	OFF
*SM846	Error in data exchange connection 31 through COM1	○	○	OFF	—	—	N	R	OFF
*SM847	Error in data exchange connection 32 through COM1	○	○	OFF	—	—	N	R	OFF
SM861	Error in the initialization of the data exchange through COM2.	○	○	OFF	—	—	N	R/W	OFF
*SM862	Data exchange through COM2 enabled by ISPSOft.	○	○	OFF	—	OFF	H	R/W	OFF
*SM864	Connection 1 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM865	Connection 2 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM866	Connection 3 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM867	Connection 4 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM868	Connection 5 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM869	Connection 6 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM870	Connection 7 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM871	Connection 8 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM872	Connection 9 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM873	Connection 10 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM874	Connection 11 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM875	Connection 12 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM876	Connection 13 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM877	Connection 14 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM878	Connection 15 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM879	Connection 16 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM880	Connection 17 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM881	Connection 18 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM882	Connection 19 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM883	Connection 20 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM884	Connection 21 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM885	Connection 22 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM886	Connection 23 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM887	Connection 24 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM888	Connection 25 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM889	Connection 26 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM890	Connection 27 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM891	Connection 28 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM892	Connection 29 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM893	Connection 30 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM894	Connection 31 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM895	Connection 32 for data exchange through COM2 started	○	○	OFF	—	—	H	R/W	OFF
*SM896	Successful data exchange connection 1 through COM2	○	○	OFF	—	—	N	R	OFF
*SM897	Successful data exchange connection 2 through COM2	○	○	OFF	—	—	N	R	OFF
*SM898	Successful data exchange connection 3 through COM2	○	○	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM899	Successful data exchange connection 4 through COM2	○	○	OFF	—	—	N	R	OFF
*SM900	Successful data exchange connection 5 through COM2	○	○	OFF	—	—	N	R	OFF
*SM901	Successful data exchange connection 6 through COM2	○	○	OFF	—	—	N	R	OFF
*SM902	Successful data exchange connection 7 through COM2	○	○	OFF	—	—	N	R	OFF
*SM903	Successful data exchange connection 8 through COM2	○	○	OFF	—	—	N	R	OFF
*SM904	Successful data exchange connection 9 through COM2	○	○	OFF	—	—	N	R	OFF
*SM905	Successful data exchange connection 10 through COM2	○	○	OFF	—	—	N	R	OFF
*SM906	Successful data exchange connection 11 through COM2	○	○	OFF	—	—	N	R	OFF
*SM907	Successful data exchange connection 12 through COM2	○	○	OFF	—	—	N	R	OFF
*SM908	Successful data exchange connection 13 through COM2	○	○	OFF	—	—	N	R	OFF
*SM909	Successful data exchange connection 14 through COM2	○	○	OFF	—	—	N	R	OFF
*SM910	Successful data exchange connection 15 through COM2	○	○	OFF	—	—	N	R	OFF
*SM911	Successful data exchange connection 16 through COM2	○	○	OFF	—	—	N	R	OFF
*SM912	Successful data exchange connection 17 through COM2	○	○	OFF	—	—	N	R	OFF
*SM913	Successful data exchange connection 18 through COM2	○	○	OFF	—	—	N	R	OFF
*SM914	Successful data exchange connection 19 through COM2	○	○	OFF	—	—	N	R	OFF
*SM915	Successful data exchange connection 20 through COM2	○	○	OFF	—	—	N	R	OFF
*SM916	Successful data exchange connection 21 through COM2	○	○	OFF	—	—	N	R	OFF
*SM917	Successful data exchange connection 22 through COM2	○	○	OFF	—	—	N	R	OFF
*SM918	Successful data exchange connection 23 through COM2	○	○	OFF	—	—	N	R	OFF
*SM919	Successful data exchange connection 24 through COM2	○	○	OFF	—	—	N	R	OFF
*SM920	Successful data exchange connection 25 through COM2	○	○	OFF	—	—	N	R	OFF
*SM921	Successful data exchange connection 26 through COM2	○	○	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM922	Successful data exchange connection 27 through COM2	○	○	OFF	—	—	N	R	OFF
*SM923	Successful data exchange connection 28 through COM2	○	○	OFF	—	—	N	R	OFF
*SM924	Successful data exchange connection 29 through COM2	○	○	OFF	—	—	N	R	OFF
*SM925	Successful data exchange connection 30 through COM2	○	○	OFF	—	—	N	R	OFF
*SM926	Successful data exchange connection 31 through COM2	○	○	OFF	—	—	N	R	OFF
*SM927	Successful data exchange connection 32 through COM2	○	○	OFF	—	—	N	R	OFF
*SM928	Error in data exchange connection 1 through COM2	○	○	OFF	—	—	N	R	OFF
*SM929	Error in data exchange connection 2 through COM2	○	○	OFF	—	—	N	R	OFF
*SM930	Error in data exchange connection 3 through COM2	○	○	OFF	—	—	N	R	OFF
*SM931	Error in data exchange connection 4 through COM2	○	○	OFF	—	—	N	R	OFF
*SM932	Error in data exchange connection 5 through COM2	○	○	OFF	—	—	N	R	OFF
*SM933	Error in data exchange connection 6 through COM2	○	○	OFF	—	—	N	R	OFF
*SM934	Error in data exchange connection 7 through COM2	○	○	OFF	—	—	N	R	OFF
*SM935	Error in data exchange connection 8 through COM2	○	○	OFF	—	—	N	R	OFF
*SM936	Error in data exchange connection 9 through COM2	○	○	OFF	—	—	N	R	OFF
*SM937	Error in data exchange connection 10 through COM2	○	○	OFF	—	—	N	R	OFF
*SM938	Error in data exchange connection 11 through COM2	○	○	OFF	—	—	N	R	OFF
*SM939	Error in data exchange connection 12 through COM2	○	○	OFF	—	—	N	R	OFF
*SM940	Error in data exchange connection 13 through COM2	○	○	OFF	—	—	N	R	OFF
*SM941	Error in data exchange connection 14 through COM2	○	○	OFF	—	—	N	R	OFF
*SM942	Error in data exchange connection 15 through COM2	○	○	OFF	—	—	N	R	OFF
*SM943	Error in data exchange connection 16 through COM2	○	○	OFF	—	—	N	R	OFF
*SM944	Error in data exchange connection 17 through COM2	○	○	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM945	Error in data exchange connection 18 through COM2	○	○	OFF	—	—	N	R	OFF
*SM946	Error in data exchange connection 19 through COM2	○	○	OFF	—	—	N	R	OFF
*SM947	Error in data exchange connection 20 through COM2	○	○	OFF	—	—	N	R	OFF
*SM948	Error in data exchange connection 21 through COM2	○	○	OFF	—	—	N	R	OFF
*SM949	Error in data exchange connection 22 through COM2	○	○	OFF	—	—	N	R	OFF
*SM950	Error in data exchange connection 23 through COM2	○	○	OFF	—	—	N	R	OFF
*SM951	Error in data exchange connection 24 through COM2	○	○	OFF	—	—	N	R	OFF
*SM952	Error in data exchange connection 25 through COM2	○	○	OFF	—	—	N	R	OFF
*SM953	Error in data exchange connection 26 through COM2	○	○	OFF	—	—	N	R	OFF
*SM954	Error in data exchange connection 27 through COM2	○	○	OFF	—	—	N	R	OFF
*SM955	Error in data exchange connection 28 through COM2	○	○	OFF	—	—	N	R	OFF
*SM956	Error in data exchange connection 29 through COM2	○	○	OFF	—	—	N	R	OFF
*SM957	Error in data exchange connection 30 through COM2	○	○	OFF	—	—	N	R	OFF
*SM958	Error in data exchange connection 31 through COM2	○	○	OFF	—	—	N	R	OFF
*SM959	Error in data exchange connection 32 through COM2	○	○	OFF	—	—	N	R	OFF
SM976	AS remote module #1 connection status (ON: connected; OFF: disconnected or not connected)	○	○	OFF	—	—	N	R	OFF
SM977	AS remote module #2 connection status	○	○	OFF	—	—	N	R	OFF
SM978	AS remote module #3 connection status	○	○	OFF	—	—	N	R	OFF
SM979	AS remote module #4 connection status	○	○	OFF	—	—	N	R	OFF
SM980	AS remote module #5 connection status	○	○	OFF	—	—	N	R	OFF
SM981	AS remote module #6 connection status	○	○	OFF	—	—	N	R	OFF
SM982	AS remote module #7 connection status	○	○	OFF	—	—	N	R	OFF
SM983	AS remote module #8 connection status	○	○	OFF	—	—	N	R	OFF
SM984	AS remote module #9 connection status	○	○	OFF	—	—	N	R	OFF
SM985	AS remote module #10 connection status	○	○	OFF	—	—	N	R	OFF
SM986	AS remote module #11 connection status	○	○	OFF	—	—	N	R	OFF
SM987	AS remote module #12 connection status	○	○	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SM988	AS remote module #13 connection status	○	○	OFF	—	—	N	R	OFF
SM989	AS remote module #14 connection status	○	○	OFF	—	—	N	R	OFF
SM990	AS remote module #15 connection status	○	○	OFF	—	—	N	R	OFF
SM1000	Ethernet setting flag; ON: the data in SR1000–SR1006 is written into the flash memory.	○	○	OFF	—	—	N	R/W	OFF
SM1001	State of the Ethernet connectivity	○	○	OFF	—	—	N	R	OFF
*SM1006	Data exchange through AS-FEN02 enabled by ISPSOft.	○	—	OFF	—	—	N	R/W	OFF
*SM1008	Connection 1 for data exchange through AS-FEN02 started	○	—	OFF	—	—	N	R/W	OFF
*SM1009	Connection 2 for data exchange through AS-FEN02 started	○	—	OFF	—	—	N	R/W	OFF
*SM1010	Connection 3 for data exchange through AS-FEN02 started	○	—	OFF	—	—	N	R/W	OFF
*SM1011	Connection 4 for data exchange through AS-FEN02 started	○	—	OFF	—	—	N	R/W	OFF
*SM1012	Connection 5 for data exchange through AS-FEN02 started	○	—	OFF	—	—	N	R/W	OFF
*SM1013	Connection 6 for data exchange through AS-FEN02 started	○	—	OFF	—	—	N	R/W	OFF
*SM1014	Connection 7 for data exchange through AS-FEN02 started	○	—	OFF	—	—	N	R/W	OFF
*SM1015	Connection 8 for data exchange through AS-FEN02 started	○	—	OFF	—	—	N	R/W	OFF
*SM1016	Successful data exchange connection 1 through AS-FEN02	○	—	OFF	—	—	N	R	OFF
*SM1017	Successful data exchange connection 2 through AS-FEN02	○	—	OFF	—	—	N	R	OFF
*SM1018	Successful data exchange connection 3 through AS-FEN02	○	—	OFF	—	—	N	R	OFF
*SM1019	Successful data exchange connection 4 through AS-FEN02	○	—	OFF	—	—	N	R	OFF
*SM1020	Successful data exchange connection 5 through AS-FEN02	○	—	OFF	—	—	N	R	OFF
*SM1021	Successful data exchange connection 6 through AS-FEN02	○	—	OFF	—	—	N	R	OFF
*SM1022	Successful data exchange connection 7 through AS-FEN02	○	—	OFF	—	—	N	R	OFF
*SM1023	Successful data exchange connection 8 through AS-FEN02	○	—	OFF	—	—	N	R	OFF
*SM1024	Error in data exchange connection 1 through AS-FEN02	○	—	OFF	—	—	N	R	OFF
*SM1025	Error in data exchange connection 2 through AS-FEN02	○	—	OFF	—	—	N	R	OFF
*SM1026	Error in data exchange connection 3 through AS-	○	—	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
	FEN02								
*SM1027	Error in data exchange connection 4 through AS-FEN02	○	—	OFF	—	—	N	R	OFF
*SM1028	Error in data exchange connection 5 through AS-FEN02	○	—	OFF	—	—	N	R	OFF
*SM1029	Error in data exchange connection 6 through AS-FEN02	○	—	OFF	—	—	N	R	OFF
*SM1030	Error in data exchange connection 7 through AS-FEN02	○	—	OFF	—	—	N	R	OFF
*SM1031	Error in data exchange connection 8 through AS-FEN02	○	—	OFF	—	—	N	R	OFF
*SM1090	TCP connection busy.	○	○	OFF	—	—	N	R	OFF
*SM1091	UDP connection busy.	○	○	OFF	—	—	N	R	OFF
SM1100	Ethernet connection error	○	○	OFF	—	—	N	R	OFF
*SM1106	Basic Ethernet management: connection error	○	○	OFF	—	—	N	R	OFF
*SM1107	Basic Ethernet management: Basic setting error	○	○	OFF	—	—	N	R	OFF
*SM1109	Basic TCP/UDP socket management: the local port is already used.	○	○	OFF	—	—	N	R	OFF
SM1111	EtherNet/IP data exchange flag	○	○	OFF	—	—	N	R	OFF
*SM1113	Email service error	○	○	OFF	—	—	N	R	OFF
*SM1116	Trigger 1 switch for the email.	○	○	OFF	—	—	N	R	OFF
*SM1117	Trigger 1 for the email	○	○	OFF	—	—	N	R	OFF
*SM1119	ON: Trigger 1 is triggered and the email has been sent successfully.	○	○	OFF	—	—	N	R	OFF
*SM1120	ON: Trigger 1 is triggered but the email cannot be sent due to email content error.	○	○	OFF	—	—	N	R	OFF
*SM1122	ON: Trigger 1 is triggered and there is an SMTP server response timeout.	○	○	OFF	—	—	N	R	OFF
*SM1123	ON: Trigger 1 is triggered and there is an SMTP server response error.	○	○	OFF	—	—	N	R	OFF
*SM1124	ON: Trigger 1 is triggered and the size of the attachment exceeds the limit.	○	○	OFF	—	—	N	R	OFF
*SM1125	Trigger 1 is triggered and the attachment is not found.	○	○	OFF	—	—	N	R	OFF
*SM1126	Trigger 2 switch for the email.	○	○	OFF	—	—	N	R	OFF
*SM1127	Trigger 2 for the email	○	○	OFF	—	—	N	R	OFF
*SM1129	ON: Trigger 2 is triggered and the email has been sent successfully.	○	○	OFF	—	—	N	R	OFF
*SM1130	ON: Trigger 2 is triggered but the email cannot be sent due to email content error.	○	○	OFF	—	—	N	R	OFF
*SM1132	ON: Trigger 2 is triggered and there is an SMTP server response timeout.	○	○	OFF	—	—	N	R	OFF
*SM1133	ON: Trigger 2 is triggered and there is an SMTP server response error.	○	○	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM1134	ON: Trigger 2 is triggered and the size of the attachment exceeds the limit.	○	○	OFF	—	—	N	R	OFF
*SM1135	ON: Trigger 2 is triggered and the attachment is not found.	○	○	OFF	—	—	N	R	OFF
*SM1136	Trigger 3 switch for the email.	○	○	OFF	—	—	N	R	OFF
*SM1137	Trigger 3 for the email	○	○	OFF	—	—	N	R	OFF
*SM1139	ON: Trigger 3 is triggered and the email has been sent successfully.	○	○	OFF	—	—	N	R	OFF
*SM1140	ON: Trigger 3 is triggered but the email cannot be sent due to email content error.	○	○	OFF	—	—	N	R	OFF
*SM1142	ON: Trigger 3 is triggered and there is an SMTP server response timeout.	○	○	OFF	—	—	N	R	OFF
*SM1143	ON: Trigger 3 is triggered and there is an SMTP server response error.	○	○	OFF	—	—	N	R	OFF
*SM1144	ON: Trigger 3 is triggered and the size of the attachment exceeds the limit.	○	○	OFF	—	—	N	R	OFF
*SM1145	ON: Trigger 3 is triggered and the attachment is not found.	○	○	OFF	—	—	N	R	OFF
*SM1146	Trigger 4 switch for the email.	○	○	OFF	—	—	N	R	OFF
*SM1147	Trigger 4 for the email	○	○	OFF	—	—	N	R	OFF
*SM1149	ON: Trigger 4 is triggered and the email has been sent successfully.	○	○	OFF	—	—	N	R	OFF
*SM1150	ON: Trigger 4 is triggered but the email cannot be sent due to email content error.	○	○	OFF	—	—	N	R	OFF
*SM1152	ON: Trigger 4 is triggered and there is an SMTP server response timeout.	○	○	OFF	—	—	N	R	OFF
*SM1153	ON: Trigger 4 is triggered and there is an SMTP server response error.	○	○	OFF	—	—	N	R	OFF
*SM1154	ON: Trigger 4 is triggered and the size of the attachment exceeds the limit.	○	○	OFF	—	—	N	R	OFF
*SM1155	ON: Trigger 4 is triggered and the attachment is not found.	○	○	OFF	—	—	N	R	OFF
SM1160	The process to restore drive parameters has been complete. OFF: When the value in SR1600 switches from 1 to 0, this flag is cleared to OFF. ON: When the process to restore parameters has been complete and without any error, this flag is ON.	○	○	OFF	—	—	N	R	OFF
SM1161	Error occurred during the process to restore drive parameters. OFF: When the value in SR1600 switches from 1 to 0, this flag is cleared to OFF. ON: When an error occurred during the process to restore parameter, this flag is ON.	○	○	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM1166	Error in data exchange through Ethernet	○	○	—	—	—	N	R	OFF
*SM1167	Data exchange through Ethernet started	○	○	OFF	—	—	H	R/W	OFF
*SM1168	Connection 1 for data exchange through Ethernet started	○	○	OFF	—	—	H	R/W	OFF
*SM1169	Connection 2 for data exchange through Ethernet started	○	○	OFF	—	—	H	R/W	OFF
*SM1170	Connection 3 for data exchange through Ethernet started	○	○	OFF	—	—	H	R/W	OFF
*SM1171	Connection 4 for data exchange through Ethernet started	○	○	OFF	—	—	H	R/W	OFF
*SM1172	Connection 5 for data exchange through Ethernet started	○	○	OFF	—	—	H	R/W	OFF
*SM1173	Connection 6 for data exchange through Ethernet started	○	○	OFF	—	—	H	R/W	OFF
*SM1174	Connection 7 for data exchange through Ethernet started	○	○	OFF	—	—	H	R/W	OFF
*SM1175	Connection 8 for data exchange through Ethernet started	○	○	OFF	—	—	H	R/W	OFF
*SM1176	Connection 9 for data exchange through Ethernet started	○	○	OFF	—	—	H	R/W	OFF
*SM1177	Connection 10 for data exchange through Ethernet started	○	○	OFF	—	—	H	R/W	OFF
*SM1178	Connection 11 for data exchange through Ethernet started	○	○	OFF	—	—	H	R/W	OFF
*SM1179	Connection 12 for data exchange through Ethernet started	○	○	OFF	—	—	H	R/W	OFF
*SM1180	Connection 13 for data exchange through Ethernet started	○	○	OFF	—	—	H	R/W	OFF
*SM1181	Connection 14 for data exchange through Ethernet started	○	○	OFF	—	—	H	R/W	OFF
*SM1182	Connection 15 for data exchange through Ethernet started	○	○	OFF	—	—	H	R/W	OFF
*SM1183	Connection 16 for data exchange through Ethernet started	○	○	OFF	—	—	H	R/W	OFF
*SM1184	Connection 17 for data exchange through Ethernet started	○	—	OFF	—	—	H	R/W	OFF
*SM1185	Connection 18 for data exchange through Ethernet started	○	—	OFF	—	—	H	R/W	OFF
*SM1186	Connection 19 for data exchange through Ethernet started	○	—	OFF	—	—	H	R/W	OFF
*SM1187	Connection 20 for data exchange through Ethernet started	○	—	OFF	—	—	H	R/W	OFF
*SM1188	Connection 21 for data exchange through Ethernet started	○	—	OFF	—	—	H	R/W	OFF
*SM1189	Connection 22 for data exchange through Ethernet started	○	—	OFF	—	—	H	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM1190	Connection 23 for data exchange through Ethernet started	○	—	OFF	—	—	H	R/W	OFF
*SM1191	Connection 24 for data exchange through Ethernet started	○	—	OFF	—	—	H	R/W	OFF
*SM1192	Connection 25 for data exchange through Ethernet started	○	—	OFF	—	—	H	R/W	OFF
*SM1193	Connection 26 for data exchange through Ethernet started	○	—	OFF	—	—	H	R/W	OFF
*SM1194	Connection 27 for data exchange through Ethernet started	○	—	OFF	—	—	H	R/W	OFF
*SM1195	Connection 28 for data exchange through Ethernet started	○	—	OFF	—	—	H	R/W	OFF
*SM1196	Connection 29 for data exchange through Ethernet started	○	—	OFF	—	—	H	R/W	OFF
*SM1197	Connection 30 for data exchange through Ethernet started	○	—	OFF	—	—	H	R/W	OFF
*SM1198	Connection 31 for data exchange through Ethernet started	○	—	OFF	—	—	H	R/W	OFF
*SM1199	Connection 32 for data exchange through Ethernet started	○	—	OFF	—	—	H	R/W	OFF
*SM1200	Successful data exchange connection 1 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1201	Successful data exchange connection 2 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1202	Successful data exchange connection 3 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1203	Successful data exchange connection 4 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1204	Successful data exchange connection 5 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1205	Successful data exchange connection 6 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1206	Successful data exchange connection 7 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1207	Successful data exchange connection 8 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1208	Successful data exchange connection 9 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1209	Successful data exchange connection 10 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1210	Successful data exchange connection 11 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1211	Successful data exchange connection 12 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1212	Successful data exchange connection 13 through Ethernet	○	○	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM1213	Successful data exchange connection 14 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1214	Successful data exchange connection 15 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1215	Successful data exchange connection 16 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1216	Successful data exchange connection 17 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1217	Successful data exchange connection 18 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1218	Successful data exchange connection 19 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1219	Successful data exchange connection 20 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1220	Successful data exchange connection 21 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1221	Successful data exchange connection 22 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1222	Successful data exchange connection 23 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1223	Successful data exchange connection 24 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1224	Successful data exchange connection 25 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1225	Successful data exchange connection 26 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1226	Successful data exchange connection 27 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1227	Successful data exchange connection 28 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1228	Successful data exchange connection 29 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1229	Successful data exchange connection 30 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1230	Successful data exchange connection 31 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1231	Successful data exchange connection 32 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1232	Error in data exchange connection 1 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1233	Error in data exchange connection 2 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1234	Error in data exchange connection 3 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1235	Error in data exchange connection 4 through Ethernet	○	○	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM1236	Error in data exchange connection 5 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1237	Error in data exchange connection 6 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1238	Error in data exchange connection 7 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1239	Error in data exchange connection 8 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1240	Error in data exchange connection 9 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1241	Error in data exchange connection 10 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1242	Error in data exchange connection 11 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1243	Error in data exchange connection 12 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1244	Error in data exchange connection 13 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1245	Error in data exchange connection 14 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1246	Error in data exchange connection 15 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1247	Error in data exchange connection 16 through Ethernet	○	○	OFF	—	—	N	R	OFF
*SM1248	Error in data exchange connection 17 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1249	Error in data exchange connection 18 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1250	Error in data exchange connection 19 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1251	Error in data exchange connection 20 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1252	Error in data exchange connection 21 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1253	Error in data exchange connection 22 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1254	Error in data exchange connection 23 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1255	Error in data exchange connection 24 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1256	Error in data exchange connection 25 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1257	Error in data exchange connection 26 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1258	Error in data exchange connection 27 through Ethernet	○	—	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM1259	Error in data exchange connection 28 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1260	Error in data exchange connection 29 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1261	Error in data exchange connection 30 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1262	Error in data exchange connection 31 through Ethernet	○	—	OFF	—	—	N	R	OFF
*SM1263	Error in data exchange connection 32 through Ethernet	○	—	OFF	—	—	N	R	OFF
SM1269	Socket configuration error	○	○	OFF	—	—	N	R/W	OFF
SM1270	Successful TCP socket 1 connection	○	○	OFF	—	—	N	R	OFF
SM1271	TCP socket 1 data received	○	○	OFF	—	—	N	R	OFF
SM1272	TCP socket 1 data sent	○	○	OFF	—	—	N	R	OFF
SM1273	TCP socket 1 connection starting	○	○	OFF	—	—	N	R	OFF
SM1274	TCP socket 1 connection closing	○	○	ON	—	—	Y	R	ON
SM1275	TCP socket 1 data is being sent	○	○	OFF	—	—	N	R	OFF
SM1277	TCP socket 1—Error flag	○	○	OFF	—	—	N	R	OFF
SM1278	Successful TCP socket 2 connection	○	○	OFF	—	—	N	R	OFF
SM1279	TCP socket 2 data received	○	○	OFF	—	—	N	R	OFF
SM1280	TCP socket 2 data sent	○	○	OFF	—	—	N	R	OFF
SM1281	TCP socket 2 connection starting	○	○	OFF	—	—	N	R	OFF
SM1282	TCP socket 2 connection closing	○	○	ON	—	—	Y	R	ON
SM1283	TCP socket 2 data is being sent	○	○	OFF	—	—	N	R	OFF
SM1285	TCP socket 2—Error flag	○	○	OFF	—	—	N	R	OFF
SM1286	Successful TCP socket 3 connection	○	○	OFF	—	—	N	R	OFF
SM1287	TCP socket 3 data received	○	○	OFF	—	—	N	R	OFF
SM1288	TCP socket 3 data sent	○	○	OFF	—	—	N	R	OFF
SM1289	TCP socket 3 connection starting	○	○	OFF	—	—	N	R	OFF
SM1290	TCP socket 3 connection closing	○	○	ON	—	—	Y	R	ON
SM1291	TCP socket 3 data is being sent.	○	○	OFF	—	—	N	R	OFF
SM1293	TCP socket 3—Error flag	○	○	OFF	—	—	N	R	OFF
SM1294	Successful TCP socket 4 connection	○	○	OFF	—	—	N	R	OFF
SM1295	TCP socket 4 data received	○	○	OFF	—	—	N	R	OFF
SM1296	TCP socket 4 data sent	○	○	OFF	—	—	N	R	OFF
SM1297	TCP socket 4 connection starting	○	○	OFF	—	—	N	R	OFF
SM1298	TCP socket 4 connection closing	○	○	ON	—	—	Y	R	ON
SM1299	TCP socket 4 data is being sent.	○	○	OFF	—	—	N	R	OFF
SM1301	TCP socket 4—Error flag	○	○	OFF	—	—	N	R	OFF
SM1312	RTU-EN01 connection 1 status (ON: connected; OFF: disconnected or not	○	○	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
	connected)								
SM1313	RTU-EN01 connection 2 status	○	○	OFF	—	—	N	R	OFF
SM1314	RTU-EN01 connection 3 status	○	○	OFF	—	—	N	R	OFF
SM1315	RTU-EN01 connection 4 status	○	○	OFF	—	—	N	R	OFF
SM1334	UDP socket 1 connection started	○	○	OFF	—	—	N	R	OFF
SM1335	UDP socket 1 data receiving	○	○	OFF	—	—	N	R	OFF
SM1336	UDP socket 1 data sending	○	○	OFF	—	—	N	R	OFF
SM1337	UDP socket 1 connection closed	○	○	ON	—	—	Y	R	ON
SM1338	UDP socket 1—Error flag	○	○	OFF	—	—	N	R	OFF
SM1339	UDP socket 2 connection started	○	○	OFF	—	—	N	R	OFF
SM1340	UDP socket 2 data receiving	○	○	OFF	—	—	N	R	OFF
SM1341	UDP socket 2 data sending	○	○	OFF	—	—	N	R	OFF
SM1342	UDP socket 2 connection closed	○	○	ON	—	—	Y	R	ON
SM1343	UDP socket 2—Error flag	○	○	OFF	—	—	N	R	OFF
SM1344	UDP socket 3 connection started	○	○	OFF	—	—	N	R	OFF
SM1345	UDP socket 3 data receiving	○	○	OFF	—	—	N	R	OFF
SM1346	UDP socket 3 data sending	○	○	OFF	—	—	N	R	OFF
SM1347	UDP socket 3 connection closed	○	○	ON	—	—	Y	R	ON
SM1348	UDP socket 3—Error flag	○	○	OFF	—	—	N	R	OFF
SM1349	UDP socket 4 connection started	○	○	OFF	—	—	N	R	OFF
SM1350	UDP socket 4 data receiving	○	○	OFF	—	—	N	R	OFF
SM1351	UDP socket 4 data sending	○	○	OFF	—	—	N	R	OFF
SM1352	UDP socket 4 connection closed	○	○	ON	—	—	Y	R	ON
SM1353	UDP socket 4—Error flag	○	○	OFF	—	—	N	R	OFF
*SM1375	Data exchange through EtherNet/IP (Scanner) started.	○	○	OFF	—	—	H	R/W	OFF
*SM1376	Connection 1 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	—	—	H	R/W	OFF
*SM1377	Connection 2 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	—	—	H	R/W	OFF
*SM1378	Connection 3 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	—	—	H	R/W	OFF
*SM1379	Connection 4 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	—	—	H	R/W	OFF
*SM1380	Connection 5 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	—	—	H	R/W	OFF
*SM1381	Connection 6 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	—	—	H	R/W	OFF
*SM1382	Connection 7 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	—	—	H	R/W	OFF
*SM1383	Connection 8 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	—	—	H	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM1384	Connection 9 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	—	—	H	R/W	OFF
*SM1385	Connection 10 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	—	—	H	R/W	OFF
*SM1386	Connection 11 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	—	—	H	R/W	OFF
*SM1387	Connection 12 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	—	—	H	R/W	OFF
*SM1388	Connection 13 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	—	—	H	R/W	OFF
*SM1389	Connection 14 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	—	—	H	R/W	OFF
*SM1390	Connection 15 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	—	—	H	R/W	OFF
*SM1391	Connection 16 for data exchange through EtherNet/IP (Scanner) started	○	○	OFF	—	—	H	R/W	OFF
*SM1392	Connection 17 for data exchange through EtherNet/IP (Scanner) started	○	—	OFF	—	—	H	R/W	OFF
*SM1393	Connection 18 for data exchange through EtherNet/IP (Scanner) started	○	—	OFF	—	—	H	R/W	OFF
*SM1394	Connection 19 for data exchange through EtherNet/IP (Scanner) started	○	—	OFF	—	—	H	R/W	OFF
*SM1395	Connection 20 for data exchange through EtherNet/IP (Scanner) started	○	—	OFF	—	—	H	R/W	OFF
*SM1396	Connection 21 for data exchange through EtherNet/IP (Scanner) started	○	—	OFF	—	—	H	R/W	OFF
*SM1397	Connection 22 for data exchange through EtherNet/IP (Scanner) started	○	—	OFF	—	—	H	R/W	OFF
*SM1398	Connection 23 for data exchange through EtherNet/IP (Scanner) started	○	—	OFF	—	—	H	R/W	OFF
*SM1399	Connection 24 for data exchange through EtherNet/IP (Scanner) started	○	—	OFF	—	—	H	R/W	OFF
*SM1400	Connection 25 for data exchange through EtherNet/IP (Scanner) started	○	—	OFF	—	—	H	R/W	OFF
*SM1401	Connection 26 for data exchange through EtherNet/IP (Scanner) started	○	—	OFF	—	—	H	R/W	OFF
*SM1402	Connection 27 for data exchange through EtherNet/IP (Scanner) started	○	—	OFF	—	—	H	R/W	OFF
*SM1403	Connection 28 for data exchange through EtherNet/IP (Scanner) started	○	—	OFF	—	—	H	R/W	OFF
*SM1404	Connection 29 for data exchange through EtherNet/IP (Scanner) started	○	—	OFF	—	—	H	R/W	OFF
*SM1405	Connection 30 for data exchange through EtherNet/IP (Scanner) started	○	—	OFF	—	—	H	R/W	OFF
*SM1406	Connection 31 for data exchange through EtherNet/IP (Scanner) started	○	—	OFF	—	—	H	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM1407	Connection 32 for data exchange through EtherNet/IP (Scanner) started	○	—	OFF	—	—	H	R/W	OFF
*SM1408	Error in data exchange connection 1 through EtherNet/IP (Scanner)	○	○	OFF	—	—	N	R	OFF
*SM1409	Error in data exchange connection 2 through EtherNet/IP (Scanner)	○	○	OFF	—	—	N	R	OFF
*SM1410	Error in data exchange connection 3 through EtherNet/IP (Scanner)	○	○	OFF	—	—	N	R	OFF
*SM1411	Error in data exchange connection 4 through EtherNet/IP (Scanner)	○	○	OFF	—	—	N	R	OFF
*SM1412	Error in data exchange connection 5 through EtherNet/IP (Scanner)	○	○	OFF	—	—	N	R	OFF
*SM1413	Error in data exchange connection 6 through EtherNet/IP (Scanner)	○	○	OFF	—	—	N	R	OFF
*SM1414	Error in data exchange connection 7 through EtherNet/IP (Scanner)	○	○	OFF	—	—	N	R	OFF
*SM1415	Error in data exchange connection 8 through EtherNet/IP (Scanner)	○	○	OFF	—	—	N	R	OFF
*SM1416	Error in data exchange connection 9 through EtherNet/IP (Scanner)	○	○	OFF	—	—	N	R	OFF
*SM1417	Error in data exchange connection 10 through EtherNet/IP (Scanner)	○	○	OFF	—	—	N	R	OFF
*SM1418	Error in data exchange connection 11 through EtherNet/IP (Scanner)	○	○	OFF	—	—	N	R	OFF
*SM1419	Error in data exchange connection 12 through EtherNet/IP (Scanner)	○	○	OFF	—	—	N	R	OFF
*SM1420	Error in data exchange connection 13 through EtherNet/IP (Scanner)	○	○	OFF	—	—	N	R	OFF
*SM1421	Error in data exchange connection 14 through EtherNet/IP (Scanner)	○	○	OFF	—	—	N	R	OFF
*SM1422	Error in data exchange connection 15 through EtherNet/IP (Scanner)	○	○	OFF	—	—	N	R	OFF
*SM1423	Error in data exchange connection 16 through EtherNet/IP (Scanner)	○	○	OFF	—	—	N	R	OFF
*SM1424	Error in data exchange connection 17 through EtherNet/IP (Scanner)	○	—	OFF	—	—	N	R	OFF
*SM1425	Error in data exchange connection 18 through EtherNet/IP (Scanner)	○	—	OFF	—	—	N	R	OFF
*SM1426	Error in data exchange connection 19 through EtherNet/IP (Scanner)	○	—	OFF	—	—	N	R	OFF
*SM1427	Error in data exchange connection 20 through EtherNet/IP (Scanner)	○	—	OFF	—	—	N	R	OFF
*SM1428	Error in data exchange connection 21 through EtherNet/IP (Scanner)	○	—	OFF	—	—	N	R	OFF
*SM1429	Error in data exchange connection 22 through EtherNet/IP (Scanner)	○	—	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM1430	Error in data exchange connection 23 through EtherNet/IP (Scanner)	○	—	OFF	—	—	N	R	OFF
*SM1431	Error in data exchange connection 24 through EtherNet/IP (Scanner)	○	—	OFF	—	—	N	R	OFF
*SM1432	Error in data exchange connection 25 through EtherNet/IP (Scanner)	○	—	OFF	—	—	N	R	OFF
*SM1433	Error in data exchange connection 26 through EtherNet/IP (Scanner)	○	—	OFF	—	—	N	R	OFF
*SM1434	Error in data exchange connection 27 through EtherNet/IP (Scanner)	○	—	OFF	—	—	N	R	OFF
*SM1435	Error in data exchange connection 28 through EtherNet/IP (Scanner)	○	—	OFF	—	—	N	R	OFF
*SM1436	Error in data exchange connection 29 through EtherNet/IP (Scanner)	○	—	OFF	—	—	N	R	OFF
*SM1437	Error in data exchange connection 30 through EtherNet/IP (Scanner)	○	—	OFF	—	—	N	R	OFF
*SM1438	Error in data exchange connection 31 through EtherNet/IP (Scanner)	○	—	OFF	—	—	N	R	OFF
*SM1439	Error in data exchange connection 32 through EtherNet/IP (Scanner)	○	—	OFF	—	—	N	R	OFF
*SM1440	Error in I/O connection 1 through EtherNet/IP (Adapter)	○	○	OFF	-	-	N	R	OFF
*SM1441	Error in I/O connection 2 through EtherNet/IP (Adapter)	○	○	OFF	-	-	N	R	OFF
*SM1442	Error in I/O connection 3 through EtherNet/IP (Adapter)	○	○	OFF	-	-	N	R	OFF
*SM1443	Error in I/O connection 4 through EtherNet/IP (Adapter)	○	○	OFF	-	-	N	R	OFF
*SM1444	Error in I/O connection 5 through EtherNet/IP (Adapter)	○	○	OFF	-	-	N	R	OFF
*SM1445	Error in I/O connection 6 through EtherNet/IP (Adapter)	○	○	OFF	-	-	N	R	OFF
*SM1446	Error in I/O connection 7 through EtherNet/IP (Adapter)	○	○	OFF	-	-	N	R	OFF
*SM1447	Error in I/O connection 8 through EtherNet/IP (Adapter)	○	○	OFF	-	-	N	R	OFF
*SM1448	I/O connection 1 is established through EtherNet/IP (Adapter)	○	○	OFF	-	-	N	R	OFF
*SM1449	I/O connection 2 is established through EtherNet/IP (Adapter)	○	○	OFF	-	-	N	R	OFF
*SM1450	I/O connection 3 is established through EtherNet/IP (Adapter)	○	○	OFF	-	-	N	R	OFF
*SM1451	I/O connection 4 is established through EtherNet/IP (Adapter)	○	○	OFF	-	-	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
*SM1452	I/O connection 5 is established through EtherNet/IP (Adapter)	○	○	OFF	-	-	N	R	OFF
*SM1453	I/O connection 6 is established through EtherNet/IP (Adapter)	○	○	OFF	-	-	N	R	OFF
*SM1454	I/O connection 7 is established through EtherNet/IP (Adapter)	○	○	OFF	-	-	N	R	OFF
*SM1455	I/O connection 8 is established through EtherNet/IP (Adapter)	○	○	OFF	-	-	N	R	OFF
SM1581	Auto-reset the control over Delta servo axis 1 on the CAN bus.	○	○	OFF	OFF	—	N	R/W	OFF
SM1582	Auto-reset the control over Delta servo axis 2 on the CAN bus.	○	○	OFF	OFF	—	N	R/W	OFF
SM1583	Auto-reset the control over Delta servo axis 3 on the CAN bus.	○	○	OFF	OFF	—	N	R/W	OFF
SM1584	Auto-reset the control over Delta servo axis 4 on the CAN bus.	○	○	OFF	OFF	—	N	R/W	OFF
SM1585	Auto-reset the control over Delta servo axis 5 on the CAN bus.	○	○	OFF	OFF	—	N	R/W	OFF
SM1586	Auto-reset the control over Delta servo axis 6 on the CAN bus.	○	○	OFF	OFF	—	N	R/W	OFF
SM1587	Auto-reset the control over Delta servo axis 7 on the CAN bus.	○	○	OFF	OFF	—	N	R/W	OFF
SM1588	Auto-reset the control over Delta servo axis 8 on the CAN bus.	○	○	OFF	OFF	—	N	R/W	OFF
SM1601	Auto-reset the control over Delta inverter axis 21 on the CAN bus.	○	○	OFF	OFF	—	N	R/W	OFF
SM1602	Auto-reset the control over Delta inverter axis 22 on the CAN bus.	○	○	OFF	OFF	—	N	R/W	OFF
SM1603	Auto-reset the control over Delta inverter axis 23 on the CAN bus.	○	○	OFF	OFF	—	N	R/W	OFF
SM1604	Auto-reset the control over Delta inverter axis 24 on the CAN bus.	○	○	OFF	OFF	—	N	R/W	OFF
SM1605	Auto-reset the control over Delta inverter axis 25 on the CAN bus.	○	○	OFF	OFF	—	N	R/W	OFF
SM1606	Auto-reset the control over Delta inverter axis 26 on the CAN bus.	○	○	OFF	OFF	—	N	R/W	OFF
SM1607	Auto-reset the control over Delta inverter axis 27 on the CAN bus.	○	○	OFF	OFF	—	N	R/W	OFF
SM1608	Auto-reset the control over Delta inverter axis 28 on the CAN bus.	○	○	OFF	OFF	—	N	R/W	OFF
SM1611	Heartbeat error of Delta inverter CAN communication ID 21	○	○	OFF	OFF	—	N	R	OFF
SM1612	Heartbeat error of Delta inverter CAN communication ID 22	○	○	OFF	OFF	—	N	R	OFF
SM1613	Heartbeat error of Delta inverter CAN communication ID 23	○	○	OFF	OFF	—	N	R	OFF
SM1614	Heartbeat error of Delta inverter CAN communication ID 24	○	○	OFF	OFF	—	N	R	OFF
SM1615	Heartbeat error of Delta inverter CAN communication ID 25	○	○	OFF	OFF	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SM1616	Heartbeat error of Delta inverter CAN communication ID 26	○	○	OFF	OFF	–	N	R	OFF
SM1617	Heartbeat error of Delta inverter CAN communication ID 27	○	○	OFF	OFF	–	N	R	OFF
SM1618	Heartbeat error of Delta inverter CAN communication ID 28	○	○	OFF	OFF	–	N	R	OFF
SM1621	Delta inverter CAN communication ID 21 is starting	○	○	OFF	OFF	–	N	R	OFF
SM1622	Delta inverter CAN communication ID 22 is starting	○	○	OFF	OFF	–	N	R	OFF
SM1623	Delta inverter CAN communication ID 23 is starting	○	○	OFF	OFF	–	N	R	OFF
SM1624	Delta inverter CAN communication ID 24 is starting	○	○	OFF	OFF	–	N	R	OFF
SM1625	Delta inverter CAN communication ID 25 is starting	○	○	OFF	OFF	–	N	R	OFF
SM1626	Delta inverter CAN communication ID 26 is starting	○	○	OFF	OFF	–	N	R	OFF
SM1627	Delta inverter CAN communication ID 27 is starting	○	○	OFF	OFF	–	N	R	OFF
SM1628	Delta inverter CAN communication ID 28 is starting	○	○	OFF	OFF	–	N	R	OFF
SM1631	Positioning completed for Delta servo CAN axis 1	○	○	OFF	OFF	–	N	R/W	OFF
SM1632	Positioning completed for Delta servo CAN axis 2	○	○	OFF	OFF	–	N	R/W	OFF
SM1633	Positioning completed for Delta servo CAN axis 3	○	○	OFF	OFF	–	N	R/W	OFF
SM1634	Positioning completed for Delta servo CAN axis 4	○	○	OFF	OFF	–	N	R/W	OFF
SM1635	Positioning completed for Delta servo CAN axis 5	○	○	OFF	OFF	–	N	R/W	OFF
SM1636	Positioning completed for Delta servo CAN axis 6	○	○	OFF	OFF	–	N	R/W	OFF
SM1637	Positioning completed for Delta servo CAN axis 7	○	○	OFF	OFF	–	N	R/W	OFF
SM1638	Positioning completed for Delta servo CAN axis 8	○	○	OFF	OFF	–	N	R/W	OFF
SM1641	Communication stops for Delta servo CAN axis 1	○	○	OFF	OFF	–	N	R/W	OFF
SM1642	Communication stops for Delta servo CAN axis 2	○	○	OFF	OFF	–	N	R/W	OFF
SM1643	Communication stops for Delta servo CAN axis 3	○	○	OFF	OFF	–	N	R/W	OFF
SM1644	Communication stops for Delta servo CAN axis 4	○	○	OFF	OFF	–	N	R/W	OFF
SM1645	Communication stops for Delta servo CAN axis 5	○	○	OFF	OFF	–	N	R/W	OFF
SM1646	Communication stops for Delta servo CAN axis 6	○	○	OFF	OFF	–	N	R/W	OFF
SM1647	Communication stops for Delta servo CAN axis 7	○	○	OFF	OFF	–	N	R/W	OFF
SM1648	Communication stops for Delta servo CAN axis 8	○	○	OFF	OFF	–	N	R/W	OFF
SM1651	Servo is ON for Delta servo CAN axis 1	○	○	OFF	OFF	–	N	R	OFF
SM1652	Servo is ON for Delta servo CAN axis 2	○	○	OFF	OFF	–	N	R	OFF
SM1653	Servo is ON for Delta servo CAN axis 3	○	○	OFF	OFF	–	N	R	OFF
SM1654	Servo is ON for Delta servo CAN axis 4	○	○	OFF	OFF	–	N	R	OFF
SM1655	Servo is ON for Delta servo CAN axis 5	○	○	OFF	OFF	–	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SM1656	Servo is ON for Delta servo CAN axis 6	○	○	OFF	OFF	–	N	R	OFF
SM1657	Servo is ON for Delta servo CAN axis 7	○	○	OFF	OFF	–	N	R	OFF
SM1658	Servo is ON for Delta servo CAN axis 8	○	○	OFF	OFF	–	N	R	OFF
SM1661	The function of going back and forth is enabled for Delta servo CAN axis 1. See the DDRVAC instruction (API 2804).	○	○	OFF	OFF	–	N	R/W	OFF
SM1662	The function of going back and forth is enabled for Delta servo CAN axis 2. See the DDRVAC instruction (API 2804).	○	○	OFF	OFF	–	N	R/W	OFF
SM1663	The function of going back and forth is enabled for Delta servo CAN axis 3. See the DDRVAC instruction (API 2804)	○	○	OFF	OFF	–	N	R/W	OFF
SM1664	The function of going back and forth is enabled for Delta servo CAN axis 4. See the DDRVAC instruction (API 2804)	○	○	OFF	OFF	–	N	R/W	OFF
SM1665	The function of going back and forth is enabled for Delta servo CAN axis 5. See the DDRVAC instruction (API 2804)	○	○	OFF	OFF	–	N	R/W	OFF
SM1666	The function of going back and forth is enabled for Delta servo CAN axis 6. See the DDRVAC instruction (API 2804)	○	○	OFF	OFF	–	N	R/W	OFF
SM1667	The function of going back and forth is enabled for Delta servo CAN axis 7. See the DDRVAC instruction (API 2804)	○	○	OFF	OFF	–	N	R/W	OFF
SM1668	The function of going back and forth is enabled for Delta servo CAN axis 8. See the DDRVAC instruction (API 2804)	○	○	OFF	OFF	–	N	R/W	OFF
SM1671	The go-back/go-forth direction indication flag for Delta servo CAN axis 1	○	○	OFF	OFF	–	N	R	OFF
SM1672	The go-back/go-forth direction indication flag for Delta servo CAN axis 2	○	○	OFF	OFF	–	N	R	OFF
SM1673	The go-back/go-forth direction indication flag for Delta servo CAN axis 3	○	○	OFF	OFF	–	N	R	OFF
SM1674	The go-back/go-forth direction indication flag for Delta servo CAN axis 4	○	○	OFF	OFF	–	N	R	OFF
SM1675	The go-back/go-forth direction indication flag for Delta servo CAN axis 5	○	○	OFF	OFF	–	N	R	OFF
SM1676	The go-back/go-forth direction indication flag for Delta servo CAN axis 6	○	○	OFF	OFF	–	N	R	OFF
SM1677	The go-back/go-forth direction indication flag for Delta servo CAN axis 7	○	○	OFF	OFF	–	N	R	OFF
SM1678	The go-back/go-forth direction indication flag for Delta servo CAN axis 8	○	○	OFF	OFF	–	N	R	OFF
SM1681	Initialization and CAN communication (INITC and CASD) completed for Delta servo	○	○	OFF	OFF	–	N	R	OFF
SM1682	The CAN communication error flag for Delta servo	○	○	OFF	OFF	–	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
SM1683	Initialization and CAN communication completed for Delta inverter	○	○	OFF	OFF	–	N	R	OFF
SM1684	To set the Delta special CAN communication ON/OFF when a connection is lost OFF: stops all the communications ON: stops only the lost-connection one	○	○	OFF	OFF	–	N	R/W	OFF
SM1685	To read the self-defined Delta servo parameters P0-12	○	○	OFF	OFF	–	N	R/W	OFF
SM1686	OFF: initialize a consecutive number of modules ON: initialize a specific module	○	○	OFF	OFF	–	N	R/W	OFF
SM1691	Heartbeat error of Delta special CAN axis 1	○	○	OFF	OFF	–	N	R	OFF
SM1692	Heartbeat error of Delta special CAN axis 2	○	○	OFF	OFF	–	N	R	OFF
SM1693	Heartbeat error of Delta special CAN axis 3	○	○	OFF	OFF	–	N	R	OFF
SM1694	Heartbeat error of Delta special CAN axis 4	○	○	OFF	OFF	–	N	R	OFF
SM1695	Heartbeat error of Delta special CAN axis 5	○	○	OFF	OFF	–	N	R	OFF
SM1696	Heartbeat error of Delta special CAN axis 6	○	○	OFF	OFF	–	N	R	OFF
SM1697	Heartbeat error of Delta special CAN axis 7	○	○	OFF	OFF	–	N	R	OFF
SM1698	Heartbeat error of Delta special CAN axis 8	○	○	OFF	OFF	–	N	R	OFF
*SM1700	Flag to activate the backlash compensation at Y0.0/Y0.1 for CSFO instruction	○	○	OFF	OFF	–	N	R/W	OFF
*SM1701	Flag to activate the backlash compensation at Y0.2/Y0.3 for CSFO instruction	○	○	OFF	OFF	–	N	R/W	OFF
*SM1702	Flag to activate the backlash compensation at Y0.4/Y0.5 for CSFO instruction	○	○	OFF	OFF	–	N	R/W	OFF
*SM1703	Flag to activate the backlash compensation at Y0.6/Y0.7 for CSFO instruction	○	○	OFF	OFF	–	N	R/W	OFF
*SM1704	Flag to activate the backlash compensation at Y0.8/Y0.9 for CSFO instruction	○	○	OFF	OFF	–	N	R/W	OFF
*SM1705	Flag to activate the backlash compensation at Y0.10/Y0.11 for CSFO instruction	○	○	OFF	OFF	–	N	R/W	OFF
* SM1709	Error in the initialization of the data exchange through Function Card 1	○	–	OFF	–	–	N	R/W	OFF
* SM1710	Data exchange through Function Card 1 enabled by ISPSOft	○	–	OFF	–	OFF	N	R/W	OFF
* SM1712	Connection 1 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1713	Connection 2 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1714	Connection 3 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1715	Connection 4 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF
* SM1716	Connection 5 for data exchange through Function Card 1 started	○	–	OFF	–	–	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
* SM1717	Connection 6 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1718	Connection 7 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1719	Connection 8 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1720	Connection 9 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1721	Connection 10 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1722	Connection 11 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1723	Connection 12 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1724	Connection 13 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1725	Connection 14 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1726	Connection 15 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1727	Connection 16 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1728	Connection 17 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1729	Connection 18 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1730	Connection 19 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1731	Connection 20 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1732	Connection 21 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1733	Connection 22 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1734	Connection 23 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1735	Connection 24 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1736	Connection 25 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1737	Connection 26 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1738	Connection 27 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1739	Connection 28 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
* SM1740	Connection 29 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1741	Connection 30 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1742	Connection 31 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1743	Connection 32 for data exchange through Function Card 1 started	○	—	OFF	—	—	N	R/W	OFF
* SM1744	Successful data exchange connection 1 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1745	Successful data exchange connection 2 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1746	Successful data exchange connection 3 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1747	Successful data exchange connection 4 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1748	Successful data exchange connection 5 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1749	Successful data exchange connection 6 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1750	Successful data exchange connection 7 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1751	Successful data exchange connection 8 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1752	Successful data exchange connection 9 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1753	Successful data exchange connection 10 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1754	Successful data exchange connection 11 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1755	Successful data exchange connection 12 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1756	Successful data exchange connection 13 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1757	Successful data exchange connection 14 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1758	Successful data exchange connection 15 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1759	Successful data exchange connection 16 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1760	Successful data exchange connection 17 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1761	Successful data exchange connection 18 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1762	Successful data exchange connection 19 through Function Card 1	○	—	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
* SM1763	Successful data exchange connection 20 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1764	Successful data exchange connection 21 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1765	Successful data exchange connection 22 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1766	Successful data exchange connection 23 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1767	Successful data exchange connection 24 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1768	Successful data exchange connection 25 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1769	Successful data exchange connection 26 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1770	Successful data exchange connection 27 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1771	Successful data exchange connection 28 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1772	Successful data exchange connection 29 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1773	Successful data exchange connection 30 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1774	Successful data exchange connection 31 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1775	Successful data exchange connection 32 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1776	Error in data exchange connection 1 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1777	Error in data exchange connection 2 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1778	Error in data exchange connection 3 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1779	Error in data exchange connection 4 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1780	Error in data exchange connection 5 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1781	Error in data exchange connection 6 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1782	Error in data exchange connection 7 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1783	Error in data exchange connection 8 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1784	Error in data exchange connection 9 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1785	Error in data exchange connection 10 through Function Card 1	○	—	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
* SM1786	Error in data exchange connection 11 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1787	Error in data exchange connection 12 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1788	Error in data exchange connection 13 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1789	Error in data exchange connection 14 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1790	Error in data exchange connection 15 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1791	Error in data exchange connection 16 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1792	Error in data exchange connection 17 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1793	Error in data exchange connection 18 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1794	Error in data exchange connection 19 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1795	Error in data exchange connection 20 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1796	Error in data exchange connection 21 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1797	Error in data exchange connection 22 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1798	Error in data exchange connection 23 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1799	Error in data exchange connection 24 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1800	Error in data exchange connection 25 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1801	Error in data exchange connection 26 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1802	Error in data exchange connection 27 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1803	Error in data exchange connection 28 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1804	Error in data exchange connection 29 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1805	Error in data exchange connection 30 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1806	Error in data exchange connection 31 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1807	Error in data exchange connection 32 through Function Card 1	○	—	OFF	—	—	N	R	OFF
* SM1821	Error in the initialization of the data exchange through Function Card 2	○	—	OFF	—	—	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
* SM1822	Data exchange through Function Card 2 enabled by ISPSOft	○	—	OFF	—	OFF	N	R/W	OFF
* SM1824	Connection 1 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1825	Connection 2 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1826	Connection 3 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1827	Connection 4 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1828	Connection 5 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1829	Connection 6 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1830	Connection 7 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1831	Connection 8 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1832	Connection 9 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1833	Connection 10 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1834	Connection 11 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1835	Connection 12 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1836	Connection 13 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1837	Connection 14 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1838	Connection 15 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1839	Connection 16 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1840	Connection 17 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1841	Connection 18 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1842	Connection 19 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1843	Connection 20 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1844	Connection 21 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1845	Connection 22 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
* SM1846	Connection 23 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1847	Connection 24 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1848	Connection 25 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1849	Connection 26 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1850	Connection 27 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1851	Connection 28 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1852	Connection 29 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1853	Connection 30 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1854	Connection 31 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1855	Connection 32 for data exchange through Function Card 2 started	○	—	OFF	—	—	N	R/W	OFF
* SM1856	Successful data exchange connection 1 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1857	Successful data exchange connection 2 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1858	Successful data exchange connection 3 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1859	Successful data exchange connection 4 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1860	Successful data exchange connection 5 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1861	Successful data exchange connection 6 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1862	Successful data exchange connection 7 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1863	Successful data exchange connection 8 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1864	Successful data exchange connection 9 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1865	Successful data exchange connection 10 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1866	Successful data exchange connection 11 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1867	Successful data exchange connection 12 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1868	Successful data exchange connection 13 through Function Card 2	○	—	OFF	—	—	N	R	OFF

SM	Function	AS100/200 Series	AS300 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
* SM1869	Successful data exchange connection 14 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1870	Successful data exchange connection 15 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1871	Successful data exchange connection 16 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1872	Successful data exchange connection 17 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1873	Successful data exchange connection 18 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1874	Successful data exchange connection 19 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1875	Successful data exchange connection 20 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1876	Successful data exchange connection 21 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1877	Successful data exchange connection 22 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1878	Successful data exchange connection 23 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1879	Successful data exchange connection 24 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1880	Successful data exchange connection 25 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1881	Successful data exchange connection 26 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1882	Successful data exchange connection 27 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1883	Successful data exchange connection 28 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1884	Successful data exchange connection 29 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1885	Successful data exchange connection 30 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1886	Successful data exchange connection 31 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1887	Successful data exchange connection 32 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1888	Error in data exchange connection 1 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1889	Error in data exchange connection 2 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1890	Error in data exchange connection 3 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1891	Error in data exchange connection 4 through Function Card 2	○	—	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
* SM1892	Error in data exchange connection 5 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1893	Error in data exchange connection 6 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1894	Error in data exchange connection 7 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1895	Error in data exchange connection 8 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1896	Error in data exchange connection 9 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1897	Error in data exchange connection 10 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1898	Error in data exchange connection 11 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1899	Error in data exchange connection 12 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1900	Error in data exchange connection 13 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1901	Error in data exchange connection 14 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1902	Error in data exchange connection 15 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1903	Error in data exchange connection 16 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1904	Error in data exchange connection 17 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1905	Error in data exchange connection 18 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1906	Error in data exchange connection 19 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1907	Error in data exchange connection 20 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1908	Error in data exchange connection 21 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1909	Error in data exchange connection 22 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1910	Error in data exchange connection 23 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1911	Error in data exchange connection 24 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1912	Error in data exchange connection 25 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1913	Error in data exchange connection 26 through Function Card 2	○	—	OFF	—	—	N	R	OFF
* SM1914	Error in data exchange connection 27 through Function Card 2	○	—	OFF	—	—	N	R	OFF

SM	Function	AS300 Series	AS100/200 Series	OFF ↓ ON	STOP ↓ RUN	RUN ↓ STOP	Latched	Attribute	Default
* SM1915	Error in data exchange connection 28 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1916	Error in data exchange connection 29 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1917	Error in data exchange connection 30 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1918	Error in data exchange connection 31 through Function Card 2	○	–	OFF	–	–	N	R	OFF
* SM1919	Error in data exchange connection 32 through Function Card 2	○	–	OFF	–	–	N	R	OFF

*1: For items with a * mark, Refer to Section 2.2.1.6 for Additional Remarks on Special Auxiliary Relays and Special Data Registers for details.

*2: The system executes according to the parameters set in HWCONFIG. When the SM power changes from OFF to ON, the state is –, and the latched area is marked as N.

*3: The function card here means AS-F232, AS-F422 and AS-F485.

2.2.8 Refresh Time for Special Auxiliary Relays

Special auxiliary relay	Refresh time
SM0–SM1	The system automatically sets the flag to ON and resets it to OFF. ON: operation error.
SM5	The system automatically sets the flag to ON and resets it to OFF. ON: an error occurs when the program is written in the PLC.
SM6	During power-on, the system checks whether the data in the latched area has been lost. ON: data in the latched area has been lost. You reset it to OFF.
SM7	ON: power supply (24 V) is not sufficient. You reset it to OFF.
SM8	The system automatically sets SM8 to ON and resets it to OFF. ON: there is a watchdog timer error.
SM9	The system automatically sets SM9 to ON and resets it to OFF. ON: there is a system error.
SM10	The system automatically sets SM10 to ON and resets it to OFF. ON: there is an I/O bus error.
SM22–SM24	You set the flag to ON, and the system automatically resets it to OFF. ON: the log is cleared.
SM25–SM26	ON: users are editing with ISPSOft. OFF: users have logged out of ISPSOft.
SM27	Update the value in the built-in AD for AS-F2AD. The system resets it to OFF.
SM28	The system checks for anything wrong. ON: something is wrong. You reset it to OFF.
SM30	ON: an error occurs in the remote module. The system resets it to OFF.
SM34	ON: the wrong password is entered. The system resets it to OFF.
SM36	ON: the system saves the data to the memory card. After saving is complete, the system resets it