


Enable the camera

From the Menu, select Preferences > Raspberry Pi Settings



Shutdown the Raspberry Pi and remove the power.

Connect the camera





Test the camera

Power up the Raspberry Pi

Open Terminal

Type:

raspistill -o image.jpg

If you need to flip the image horizontally or vertically, use the following:

-vf or -hf eg

raspistill -vf -o image.jpg

Camera Worksheet

https://picamera.readthedocs.org

If you need to flip the camera picture use the following commands:

camera.hflip = True camera.vflip = True

Do not save your program with the name picamera