

AS Rivas

hux460

Pre-Lab Questions

1. What is the difference between the TL071, TL072, and TL074 packages regarding the number of op-amps provided?
2. How are the IC pin numbers labelled with respect to the pins' orientation along the IC package?

1. The difference between TL071, TL072, and TL074 packages regarding to the number of Op-Amps provided is TL071 only has 1, TL072 have 2, and TL074 have 4.
2. The pins numbers are label from 1-8, Starting on the left side where it goes from 1-4 from Top to Bottom, Then on the right side from the Bottom to Top from 5-8

3. For the TL071 package, what are the pin numbers associated with the following inputs/outputs: inverting input, non-inverting input, positive power supply, negative power supply, output.
4. For the TL072 package, what are the pin numbers associated with the inputs/outputs of op-amp 1?... of op-amp 2? What are the pin numbers associated with the positive power supply and negative power supply?

3. The pin out for the TL071 for the following Inputs/ Outputs :

Inverting / Non-inverting is 2 and 3

Positive / Negative Power Supply 4+ and 7-

Output is 5 and 6

Inputs are 1 2 and 3

4. Op-Amp1 Inputs / Outputs :

Inverting / Non-inverting is 2 and 3

Positive/ Negative Power Supply 4- and 8+

Input / Outputs are 1 2 and 3

Op-Amp2 Inputs / Outputs :

Inverting / Non-inverting is 5 and 6

Positive / Negative Power Supply 4- and 8+

Inputs / Outputs are 5 6 and 7