

Page: 1 of 8
Procedure No:
MDII-OPN-SOP-

Rev.1

Title: RECLAIMER DUST SUPPRESSION SYSTEM

Issue Date: 31/10/2019

STANDARD OPERATING PROCEDURE

SUPPRESSION SYSTEM RECLAIMER DUST

MDPCL-OMH-SOP-01-004

Approved by Team Leader: Duong Thuc Son Approved by Operation Manager: Sid Phan Date Approved: 31/10/2019 Date Approved:

1st Reviewed by 2nd Reviewed by		Nguyen Van Tan	
1st Reviewed by		Doan Van Lieu	
Prepared by	Nguyen Thi Phuong	Ban Trung Hung	
Revision Date	15-Oct-2018	22-Oct-2019	
Description	First Issue	First revise	
Revision No.	0	possed	



MDII-OPN-SOP-Procedure No: Page: 2 of 8

Rev.1

Title: RECLAIMER DUST SUPPRESSION SYSTEM

Issue Date: 31/10/2019

REVISION HISTORY

No.	No. Date of revision	Description of change	Reviewed by	Reviewed by Approved by
0				
1				

1. PURPOSE AND SCOPE

The purpose of this document is to provide a systematic guideline to operating the Dust

Suppression System of Reclaimer.

The dust suppression system covers the water spray for:

- Primary Scraper Arm
- Secondary Scraper Arm Discharge Reclaimer

2. DEFINITION AND ABBREVIATIONS

Programmable Logic Controller PLC

100

Input/ Output Human Machine Interface HMI

Piping and Instrument Diagram Coal handling control room CHCR

Conveyor P&ID CV

3. PRECAUTION



Page: 3 of 8 Rev.1 Procedure No: MDII-OPN-SOP-


Title: RECLAIMER DUST SUPPRESSION
SYSTEM

Issue Date: 31/10/2019

F - F	T 11	£ 11 - 7 121 - 7 11
gor	Hazard	How to Eniminate Hazard
Operation of electric	Electric shock cause leak	Use PPE is proper
system	water from line pipe or	Check daily line pipe, valves and coal pile
	valves is broken	spray pumps status.
Operation of system	Leak water from line pipe	Check daily line pipe and valves status
	or valves is broken or	following design drawing specification
	open/close valves status is	
	wrong.	

4. PROCEDURE INSTRUCTIONS


REMARK								-												
RESPONSIBLE	Operator	Operator	Operator	Operator	Operator	Operator	Operator		Operator	Operator	Operator	Onerator			Operator	Operator		Operator		CBO
ACTION	. Check lamps on the control panel.	. Check coal pile spray pumps.	. Check water hose reel and water hose reel motors.	. Check switches and controls on the control panel.	. Check power state of control panel.	6. Check essential devices for damage,	Check distribution piping for damage	or corrosion.	. Check start/stop switch of the pump	. Check gauges pressures of pump	10. Check installed state of devices	Within the 110W Could of Uox.	for damage, operability, or	obstruction.	12. Check state of auto/manual switch.	13. Check cleanliness of surrounding	areas.	14. Check accessories for damage or	trouble.	1. HMI
ACTIVITY/TASK	I. CHECKING	1. Daily Inspection 2	3				16	•	<u> ∞</u>	.16	1	1-	•			<u> </u>				2. Periodic Inspection



Rev.1 Page: 4 of 8
Procedure No:
MDII-OPN-SOP-

Issue Date: 31/10/2019


ACTIVITY/TASK	ACTION	RESPONSIBLE	REMARK
Periodic inspections	Check oneration of all Jamps and		
shall be performed by	switches		
the operator,	Check switch controls for proper		
maintenance engineer,	indication or connection to		
or administrator under	instruments and gauges.		
the presence of	Check terminal blocks and power to		
representative of the	make sure they are operational.		
owner, at least, every	Check operation of the main		
three months.	controls on the control panel.		
	Check operation of the solenoid	-	
	valve under no load to the control		
	panel.		
	2. Piping	Operator	
	Check distribution piping for		
	damage or corrosion.		
	Check pipe connections for damage		
	or corrosion.		
	Check state of pipe supports.		
	3. Valves and Instruments	Operator	
	 Check ball valves for damage or 		,
	leakage,		
	 Check fixing state of flow control 		
	valve and operation of auto drain		,
	valve.		
	 Check operation of pressure 		
	reducing valve.		
	4. Nozzle	Operator	
	 Check connective movement of 		
	conveyor belt and spray of spray		
	nozzles.		
	 Check nozzles if they are sprayed in 		
	exact locations and directions.		
	 Check nozzles for foreign materials 		
	and clean them on a regular basis.		
II. OPERATE	1. Condition open solenoid valves at		
SYSTEM	automatic mode:		
	 CV04 A/B running 		
	 Primary scraper arm operating 		
	 Secondary scraper arm operating 		
	2. Start sequence	Operator	



Rev.1 Page: 5 of 8
Procedure No:
MDII-OPN-SOP-

Issue Date: 31/10/2019

ACTIVITY/TASK	ACTION	RESPONSIBLE	REMARK
	Step 1: Open/close valves at outside		
	as attachment 1		
	Step 2: Open solenoid valves at		
	operator control panel of reclaimer		
	A/B by select enable when:		
	 Solenoid valve FV 78CE701/ 		
	FV 79CE701: Open dust suppressor		
	for discharge chute reclaimer A/B		
	when CV04A/B run		
	Solenoid valve FV 78CE702/		
-	FV_79CE702: Open dust		
	suppressor when primary scraper		
	arm reclaimer A/B running		
	Solenoid valve FV 78CE703/		;
	FV_79CE703: Open dust suppressor		
	when secondary scraper arm		
	reclaimer A/B running		
	• Note: The solenoid valves will		
	automatic open/ close following as		
	time set on/off		
		Ç q	-
	• Step 3: Start one coal pile pump	CBO	Cueck pressure
	AP101 (P0GHD68AP101) on HMI		outlet on HMI
	(AP101/AP102). Pump AP102		or pressure
	(P0GHD68AP102) is at standby		gauges PS
	status.		POGHD50CE25
	 Note: If change coal pile pump to 		2
	auto mode then when pump will		Check water
	auto turn on when water pressure in		level at nozzles
	pipe low and auto turn off when		
	water pressure in pipe high		
	3. Stop sequence	CBO	to perturb food
	Step 1: Stop coal pile spray pump		Clieck status of
	APÎ01 (POĞHD68APÎ01)		duind
	Step 2: Close solenoid valves	Operator	
Prepared by:		Approved by:	
· ^ I		· ^ =	



Procedure No: MDII-OPN-SOP-Page: 6 of 8

Rev.1

Issue Date: 31/10/2019

5. ALGORITHM FLOWCHART WHEN RUN AUTO MODE



Rev.1 MDII-OPN-SOP-Procedure No: Page: 7 of 8

Issue Date: 31/10/2019

SYSTEM

GR Eng___ Dust Suppression Dust Suppression Pump Run(AP101) Dust Suppression Punp "Error" Indicated in GFeng Normal Operating Yes Dust Suppression Pump "Error" Indicated in Reclaimer Dischage Recisimer Open' Lead Belt Conveyer 'Open' Dust Suppression Normal Operating Aux Scraper Suppression Line Open Primary Scraper Suppression Line 'Open' All Dust Suppression Line Aux, Scraper Suppression Line 'Close' Coal Shed .A £ ŝ Primary Scraper Arm Operating Aux, Scrapes Arm Operating Dust suppression Line on Reclaimer A 'OH' Dust suppression Line on Dard Suna A 'ACE' FV PoGHD78CE702 'OH' FV POGHD78CE701 'OH' FV POGHO78CE703 'OH'
(Solenold Valve) Primary Scraper Arm Operating "OFF" Coureyor 0.K.? 0.K.? YES YES

♣ Attachment 1: (in case run pump AP101 P0GHD68AP101)



Page: 8 of 8
Procedure No:
MDII-OPN-SOP-

Rev.1

ION Issue Date: 31/10/2019

Title: RECLAIMER DUST SUPPRESSION
SYSTEM

Suction is (AP 101) Discharge	Suction isolate valve of pump	TO LA LOS A LOS	
2 Discha	11)	rochDosAA103	Open
AP 101	Discharge isolate valve of pump P0GHD68AA101 AP 101	P0GHD68AA101	Open
3. Return	Return isolate valve	P0GHD68AA102	Open
Suction 4. hose re	Suction isolate valve of water hose reel motor (inside coal	Miss KKS	Open
(shed)	,		
5. Ball ve	Ball valve of water hose reel	P0GHD83AA101/P0GHD82AA101	Open