



Roaming Assist

Motorola Restricted Confidential

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners. © Motorola, Inc. 2008



- **Clients generally decide when to roam and which access point to connect to. With the huge influx of wireless devices, we have a varied behavior based on device, operating system, wireless chipset and client software. A better way to handle the network is for access points to make forceful roaming decisions, instead of letting the clients handle it all.**
- **By constantly monitoring a client's packets and the received signal strength indicator (RSSI) of a given client, decision can be made on the access point to deauthenticate clients which have poor connectivity and forcing them to associate to access points with better connectivity.**

How does it work?



- Requires a roaming-assist-policy to be mapped to a wlan. Roaming assist then monitors the client rssi values and periodically scans for clients with poor connectivity. Once such a client has been found, the client is deauthenticated.
- Association-response filter (wlan/radio config) and probe-response filter (radio config) can be used to filter association and probe requests from the client based on rssi values, thereby preventing clients with very low signal strength from associating.



- (config) roaming-assist-policy rasst
 - (config-rasst)# sampling-interval <5-60>
 - (config-rasst)# detection-threshold <-100--40>
 - (config-rasst)# monitoring-interval <1-60>
 - (config-rasst)# handoff-threshold <-100--40>
 - (config-rasst)# handoff-count <1-10>
 - (config-rasst)# action (deauth|log)
-
- (config-wlan)# use roaming-assist-policy rasst
 - (config-wlan)# assoc-response rssi-threshold <-100--40>
 - (config-radio)# assoc-response rssi-threshold <-100--40>
 - (config-radio)# probe-response rssi-threshold <-128--40>



- **Use show event-history**
 - RASST ROAM_ASSIST_DEAUTH Client [mac] on radio [str] monitored RSSI [int] deauthed
 - RASST ROAM_ASSIST_LOG Client [mac] on radio [str] monitored RSSI [int]
- **Use 'debug wireless rasst' to get logs specific to roaming-assist.**